

M433 Series BSP Guide

Directory Introduction for 32-bit NuMicro® Family

Directory Information

Document	Driver reference guide and revision history.
Library	Driver header and source files.
SampleCode	Driver sample code.
ThirdParty	Library from third party, including FatFs, LibMAD, lwIP, uIP, FreeRTOS™, libjpeg, and Mbed TLS.

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NuMicro microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

www.nuvoton.com

TABLE OF CONTENTS

1	DOCUMENT.....	4
2	LIBRARY	5
3	SAMPLECODE	6
4	THIRDPARTY.....	7
5	SAMPLECODE\CORTEXM4.....	8
6	SAMPLECODE\ISP	9
7	SAMPLECODE\ POWERMANAGEMENT.....	10
8	SAMPLECODE\STDDRIVER.....	11
	Analog Comparator Controller (ACMP)	11
	Basic PWM Generator and Capture Timer (BPWM).....	11
	Controller Area Network (CAN).....	11
	Clock Controller (CLK).....	12
	CRC Controller (CRC)	12
	Enhanced 12-bit Analog-to-Digital Converter (EADC)	12
	External Bus Interface (EBI)	13
	Enhanced Input Capture Timer (ECAP)	13
	Enhanced PWM Generator and Capture Timer (EPWM)	13
	Flash Memory Controller (FMC)	14
	General Purpose I/O (GPIO).....	15
	I ² C Serial Interface Controller (I ² C)	15
	USB On-The-Go (OTG).....	16
	PDMA Controller (PDMA)	16
	Quadrature Encoder Interface(QEI).....	16
	Quad Serial Peripheral Interface (QSPI)	16
	Real Timer Clock (RTC)	17
	Smartcard Host Interface (SC)	17

SD Host Controller (SDH)	17
Serial Peripheral Interface (SPI)	17
System Manager (SYS)	18
Timer Controller (TIMER).....	19
UART Interface Controller (UART).....	20
USB 1.1 Device Controller (USBD)	20
USB 1.1 Host Controller (USBH)	22
Watchdog Timer (WDT)	23
Window Watchdog Timer (WWDT)	23

1 Document

CMSIS.html	Document of CMSIS version 4.5.0.
NuMicro M433 CMSIS BSP Revision History.pdf	This document shows the revision history of M433 BSP.
NuMicro M433 Driver Reference Guide.html	This document describes the usage of drivers in M433 BSP.

2 Library

CMSIS	Cortex® Microcontroller Software Interface Standard (CMSIS) V4.5.0 definitions by Arm® Corp.
Device	CMSIS compliant device header file.
SmartcardLib	Smartcard library binary and header file.
StdDriver	All peripheral driver header and source files.
UsbHostLib	USB host library source code.

3 SampleCode

CortexM4	Cortex®-M4 sample code.
FreeRTOS	Simple FreeRTOS™ demo code.
Hard_Fault_Sample	Show hard fault information when hard fault happened.
ISP	ISP firmware samples.
PowerManagement	Power management sample code.
Semihost	Show how to debug with semi-host message print.
StdDriver	Sample code to demonstrate the usage of M433 MCU peripheral driver APIs.
Template	A project template for M433.

4 ThirdParty

BLE_AB1602	AB1602 BLE (Bluetooth Low Energy) module driver.
FatFs	A generic FAT file system module for small embedded systems. Its official website is: http://elm-chan.org/fsw/ff/00index_e.html .
FreeRTOS	A real time operating system available for free download. Its official website is: http://www.freertos.org/ .
libjpeg	A software implements JPEG baseline, extended-sequential, and progressive compression processes maintained and published by the Independent JPEG Group (IJG). Its official website is: http://ijg.org/ .

5 SampleCode\CortexM4

BitBand	Demonstrate the usage of Cortex®-M4 Bit-band.
DSP_FFT	Demonstrate how to call ARM CMSIS DSP library to calculate FFT.
MPU	Demonstrate the usage of Cortex®-M4 MPU.

6 SampleCode\ISP

ISP_CAN	In-System-Programming sample code through CAN interface.
ISP_DFU	In-System-Programming sample code through USB DDFU(Device Firmware Upgrade) class.
ISP_HID	In-System-Programming sample code through a USB DDFU HID interface.
ISP_I2C	In-System-Programming sample code through I ² C interface.
ISP_RS485	In-System-Programming sample code through RS485 interface.
ISP_SPI	In-System-Programming sample code through SPI interface.
ISP_UART	In-System-Programming sample code through UART interface.

7 SampleCode\ PowerManagement

SYS_DPDMode_Wakeup	Show how to wake up system form DPD Power-down mode by Wake-up pin(PC.0) or Wake-up Timer or RTC Tick or RTC Alarm.
SYS_PowerDownMode	Show how to enter to different Power-down mode and wake-up by RTC.
SYS_PowerDown_MinCurrent	Demonstrate how to minimize power consumption when entering power down mode.
SYS_PowerMode	Show how to set different core voltage.
SYS_SPDMode_Wakeup	Show how to wake up system form SPD Power-down mode by Wake-up pin(PA.0) or Wake-up Timer or Wake-up ACMP or RTC Tick or RTC Alarm and or LVR or BOD.

8 SampleCode\StdDriver

Analog Comparator Controller (ACMP)

ACMP_ComapreVBG	Demonstrate analog comparator (ACMP) comparison by comparing ACMP0_P0 input and VBG voltage and shows the result on UART console.
ACMP_Wakeup	Use ACMP to wake up system from Power-down mode while comparator output changes.
ACMP_WindowCompare	Show how to monitor ACMP input with window compare function.
ACMP_WindowLatch	Demonstrate how to use ACMP window latch mode.

Basic PWM Generator and Capture Timer (BPWM)

BPWM_Capture	Use BPWM0 Channel 0 (PA.0) to capture the BPWM1 Channel 0(PE.13) Waveform
BPWM_DoubleBuffer	Change duty cycle and period of output waveform by BPWM Double Buffer function.
BPWM_OutputWaveform	Demonstrate how to use BPWM counter output waveform.
BPWM_SwitchDuty	Change duty cycle of output waveform by configured period.
BPWM_SyncStart	Demonstrate how to use BPWM counter synchronous start function.

Controller Area Network (CAN)

CAN_BasicMode_Rx	Demonstrate CAN bus receive a message with basic mode. This sample code could work with CAN_BasicMode_Tx sample code.
CAN_BasicMode_Tx	Demonstrate CAN bus transmit a message with basic mode. This sample code could work with CAN_BasicMode_Rx sample code.

CAN_BasicMode_Tx_Rx	Demonstrate CAN bus transmit and receive a message with basic mode by connecting CAN0 and CAN1 to the same CAN bus.
CAN_NormalMode_Rx	Demonstrate CAN bus receive a message with normal mode. This sample code could work with CAN_NormalMode_Tx sample code.
CAN_NormalMode_Tx	Demonstrate CAN bus transmit a message with normal mode. This sample code could work with CAN_NormalMode_Rx sample code.
CAN_NormalMode_Tx_Rx	Demonstrate CAN bus transmit and receive a message with normal mode by connecting CAN 0 and CAN1 to the same CAN bus.

Clock Controller (CLK)

CLK_ClockDetector	Demonstrate the usage of clock fail detector and clock frequency range detector function.
--------------------------	---

CRC Controller (CRC)

CRC_CCITT	Implement CRC in CRC-CCITT mode and get the CRC checksum result.
CRC_CRC8	Implement CRC in CRC-8 mode and get the CRC checksum result.
CRC_CRC32	Implement CRC in CRC-32 mode and get the CRC checksum result.

Enhanced 12-bit Analog-to-Digital Converter (EADC)

EADC_ADINT_Trigger	Use ADINT interrupt to do the EADC continuous scan conversion.
EADC_BandGap	Convert Band-gap (Sample module 16) and print conversion result.
EADC_EPWM_Trigger	Demonstrate how to trigger EADC by EPWM.

EADC_PDMA_EPWM_Trigger	Demonstrate how to trigger EADC by EPWM and transfer conversion data by PDMA.
EADC_Pending_Priority	Demonstrate how to trigger multiple sample modules and got conversion results in order of priority.
EADC_ResultMonitor	Monitor the conversion result of channel 2 by the digital compare function.
EADC_SWTRG_Trigger	Trigger EADC by writing EADC_SWTRG register.
EADC_TempSensor	Convert temperature sensor (Sample module 17) and print conversion result.
EADC_Timer_Trigger	Show how to trigger EADC by timer.

External Bus Interface (EBI)

EBI_NOR	Configure EBI interface to access NOR Flash connected to EBI interface.
EBI_SRAM	Configure EBI interface to access SRAM connected to EBI interface.

Enhanced Input Capture Timer (ECAP)

ECAP_GetInputFreq	Show how to use ECAP to measure clock frequency.
ECAP_GetQEIFreq	Show how to use ECAP interface to get QEIA frequency.

Enhanced PWM Generator and Capture Timer (EPWM)

EPWM_AccumulatorINT_TriggerPDMA	Demonstrate EPWM accumulator interrupt trigger PDMA.
EPWM_AccumulatorStopMode	Demonstrate EPWM accumulator stop mode.
EPWM_Brake	Demonstrate how to use EPWM brake function.
EPWM_Capture	Capture the EPWM1 Channel 0 waveform by EPWM1 Channel 2.

EPWM_DeadTime	Demonstrate how to use EPWM Dead Time function.
EPWM_DoubleBuffer	Change duty cycle and period of output waveform by EPWM Double Buffer function.
EPWM_OutputWaveform	Demonstrate how to use PWM output waveform.
EPWM_PDMA_Capture	Capture the EPWM1 Channel 0 waveform by EPWM1 Channel 2, and use PDMA to transfer captured data.
EPWM_SwitchDuty	Change duty cycle of output waveform by configured period.
EPWM_SyncStart	Demonstrate how to use PWM counter synchronous start function.

Flash Memory Controller (FMC)

FMC_CRC32	Demonstrate how to use FMC CRC32 ISP command to calculate the CRC32 checksum of APROM, LDROM, and SPROM.
FMC_ExecInSRAM	Implement a code and execute in SRAM to program embedded Flash.
FMC_IAP	Demonstrate FMC IAP boot mode and show how to use vector remap function. LDROM image was embedded in APROM image and be programmed to LDROM Flash at run-time. This sample also shows how to branch between APROM and LDROM.
FMC_MultiBoot	Implement a multi-boot system to boot from different applications in APROM. A LDROM code and 4 APROM code are implemented in this sample code.
FMC_MultiWordProgram	Show FMC multi-word program ISP command to program APROM 0x00000~0x20000 area.
FMC_OTP	Demonstrate how to program, read, and lock OTP.
FMC_ReadAllOne	Demonstrate how to use FMC Read-All-One ISP command to verify APROM/LDROM pages are all 0xFFFFFFFF or not.

FMC_RW	Show FMC read Flash IDs, erase, read, and write functions.
FMC_SecureKey	Show how to setup the KPROM and how to perform KPROM comparison.

General Purpose I/O (GPIO)

GPIO_EINTAndDebounce	Show the usage of GPIO external interrupt function and de-bounce function.
GPIO_INT	Show the usage of GPIO interrupt function.
GPIO_OutputInput	Show how to set GPIO pin mode and use pin data input/output control.
GPIO_PowerDown	Show how to wake up system from Power-down mode by GPIO interrupt.

I²C Serial Interface Controller (I²C)

I2C_EEPROM	Read/write EEPROM via I ² C interface.
I2C_Loopback	Demonstrate how a Master accesses Slave.
I2C_Master	An I ² C master mode demo code.
I2C_MultiBytes_Master	Demonstrate how to use multi-bytes API to access slave. This sample code needs to work with I2C_Slave .
I2C_PDMA_TRX	Demonstrate I ² C PDMA mode that needs to connect I2C0 (Master) and I2C1 (Slave).
I2C_SingleByte_Master	Demonstrate how to use single byte API to access slave. This sample code needs to work with I2C_Slave .
I2C_Slave	An I ² C slave mode demo code.
I2C_SMBus	Show how to control SMBus interface and use SMBus protocol between host and slave.
I2C_Wakeup_Slave	Demonstrate how to set I ² C to wake up MCU from Power-down mode. This sample code needs to work

with [I2C Master](#).

USB On-The-Go (OTG)

OTG_Dual_Role_UMAS	An OTG sample code that will become a USB host when connected with a Micro-A cable, and can access the pen drive when plugged in. It will become a removable disk when connected with a Micro-B cable, and then plug into PC.
OTG_HNP	Show HID mouse with OTG HNP protocol.

PDMA Controller (PDMA)

PDMA_BasicMode	Use PDMA channel 2 to demonstrate memory to memory transfer.
PDMA_ScatterGather	Use PDMA channel 5 to demonstrate memory to memory transfer by scatter-gather mode.
PDMA_ScatterGather_PingPongBuffer	Use PDMA to implement Ping-Pong buffer by scatter-gather mode (memory to memory).
PDMA_Stride	Use PDMA channel 2 to transfer data from memory to memory with stride.
PDMA_Stride_Repeat	Use PDMA channel 0 to transfer data from memory to memory with stride and repeat.
PDMA_TimeOut	Demonstrate PDMA timeout feature.

Quadrature Encoder Interface(QEI)

QEI_CompareMatch	Show the usage of QEI compare function.
------------------	---

Quad Serial Peripheral Interface (QSPI)

QSPI_DualMode_Flash	Access SPI Flash using QSPI dual mode.
QSPI_QuadMode_Flash	Access SPI Flash using QSPI quad mode.

QSPI_Slave3Wire	Demonstrate QSPI0 3-wire mode.
-----------------	--------------------------------

Real Timer Clock (RTC)

RTC_Alarm_Test	Demonstrate the RTC alarm function. It sets an alarm 10 seconds after execution.
RTC_Alarm_Wakeup	Use RTC alarm interrupt event to wake up system.
RTC_Time_Display	Demonstrate the RTC function and displays current time to the UART console.

Smartcard Host Interface (SC)

SC_ReadATR	Read the smartcard ATR from smartcard 1 interface.
SC_ReadSIM_PhoneBook	Demonstrate how to read phone book information in the SIM card.
SC_Timer	Demonstrate how to use SC embedded timer
SCUART_TxRx	Demonstrate smartcard UART mode by connecting PA.0 and PA.1 pins.

SD Host Controller (SDH)

SDH_FATFS	Access a SD card formatted in FAT file system.
SDH_Firmware_Update	Automatically search and read new firmware from SD card, if found, update APROM Flash with it.

Serial Peripheral Interface (SPI)

SPI_Flash	Access SPI Flash through a SPI interface.
SPI_HalfDuplex	Demonstrate SPI half-duplex mode.
SPI_LoopBack	A SPI read/write demo connecting SPI0 MISO and MOSI pins.

SPI_MasterFIFOmode	Configure SPI0 as Master mode and demonstrate how to communicate with an off-chip SPI Slave device with FIFO mode. This sample code needs to work with SPI_SlaveFIFOmode sample code.
SPI_PDMA_LoopTest	Demonstrate SPI data transfer with PDMA. SPI0 will be configured as Master mode and SPI1 will be configured as Slave mode. Both TX PDMA function and RX PDMA function will be enabled.
SPI_SlaveFIFOmode	Configure SPI0 as Slave mode and demonstrate how to communicate with an off-chip SPI Master device with FIFO mode. This sample code needs to work with SPI_MasterFIFOmode sample code.
SPII2S_Master	Configure SPI1 as I ² S Master mode and demonstrate how I ² S works in Master mode.
SPII2S_PDMA_Codec	An I ² S demo with PDMA function connected with audio codec.
SPII2S_PDMA_Play	An I ² S demo for playing data and demonstrating how I ² S works with PDMA.
SPII2S_PDMA_PlayRecord	An I ² S demo for playing and recording data with PDMA function.
SPII2S_PDMA_Record	An I ² S demo for recording data and demonstrating how I ² S works with PDMA.
SPII2S_Slave	Configure SPI1 as I ² S Slave mode and demonstrate how I ² S works in Slave mode. This sample code needs to work with SPII2S_Master.

System Manager (SYS)

SYS_BODWakeup	Demonstrate how to wake up system from Power-down mode by brown-out detector interrupt.
SYS_PLLClockOutput	Change system clock to different PLL frequency and output system clock from CLKO pin.
SYS_TrimIRC	Demonstrate how to use LXT to trim HIRC.

Timer Controller (TIMER)

TIMER_ACMPTrigger	Use ACMP to trigger timer reset mode.
TIMER_CaptureCounter	Show how to use the timer2 capture function to capture timer2 counter value.
TIMER_Delay	Demonstrate the usage of TIMER_Delay() API to generate a 1 second delay.
TIMER_EventCounter	Use pin PD.4 to demonstrate timer event counter function.
TIMER_FreeCountingMode	Use the timer pin PA.7 to demonstrate timer free counting mode function. And displays the measured input frequency to UART console.
TIMER_InterTimerTriggerMode	Use the timer pin PD.4 to demonstrate inter-timer trigger mode function. Also display the measured input frequency to UART console.
TIMER_Periodic	Use the timer periodic mode to generate timer interrupt every 1 second.
TIMER_PeriodicINT	Implement timer counting in periodic mode.
TIMER_PWM_Brake	Demonstrate how to use Timer PWM brake function.
TIMER_PWM_ChangeDuty	Change duty cycle and period of output waveform by Timer PWM Double Buffer function.
TIMER_PWM_DeadTime	Demonstrate how to use Timer PWM Dead Time function.
TIMER_PWM_OutputWaveform	Enable 4 Timer PWM output channels with different frequency and duty ratio.
TIMER_TimeoutWakeup	Use Timer to wake up system from Power-down mode periodically.
TIMER_ToggleOut	Demonstrate the timer 0 toggle out function on pin PD.4.

UART Interface Controller (UART)

UART_AutoBaudRate	Show how to use auto baud rate detection function.
UART_AutoFlow	Transmit and receive data using auto flow control.
UART_IrDA	Transmit and receive UART data in UART IrDA mode.
UART_LIN	Demonstrate how to send data to LIN bus.
UART_PDMA	Demonstrate UART transmit and receive function with PDMA.
UART_RS485	Transmit and receive data in UART RS485 mode.
UART_TxRxFunction	Transmit and receive data from PC terminal through a RS232 interface.
UART_Wakeup	Show how to wake up system from Power-down mode by UART interrupt.

USB 1.1 Device Controller (USB D)

USB D_HID_Keyboard	Demonstrate how to implement a USB keyboard device. This sample code supports to use GPIO to simulate key input.
USB D_HID_Mouse	Simulate a USB mouse and draws circle on the screen.
USB D_HID_MouseKeyboard	Simulate an USB HID mouse and HID keyboard. Mouse draws circle on the screen and Keyboard uses GPIO to simulate key input.
USB D_HID_RemoteWakeup	Simulate a HID mouse supports USB suspend and remote wakeup.
USB D_HID_Touch	Demonstrate how to implement a USB touch digitizer device. Two lines demo in Paint.
USB D_HID_Transfer	Demonstrate how to transfer data between a USB device and PC through a USB HID interface. A windows tool is also included in this sample code to connect with a USB device.

USBD_HID_Transfer_And_Keyboard	Demonstrate how to implement a composite device (HID Transfer and keyboard). Transfer data between USB device and PC through a USB HID interface. A windows tool is also included in this sample code to connect with a USB device.
USBD_HID_Transfer_And_MSC	Demonstrate how to implement a composite device (HID Transfer and Mass storage). Transfer data between USB device and PC through a USB HID interface. A windows tool is also included in this sample code to connect with a USB device.
USBD_HID_Transfer_CTRL	Use USB Host core driver and HID driver. It shows how to submit HID class request and how to read data from control pipe. A windows tool is also included in this sample code to connect with a USB device.
USBD_Mass_Storage_CDROM	Demonstrate the emulation of USB Mass Storage Device CD-ROM.
USBD_Mass_Storage_Flash	Use internal Flash as back end storage media to simulate a USB pen drive.
USBD_Mass_Storage_SD	Implement a SD card reader.
USBD_Mass_Storage_SRAM	Use internal SRAM as back end storage media to simulate a 30 KB USB pen drive.
USBD_Micro_Printer	Demonstrate how to implement a USB micro printer device.
USBD_Printer_And_HID_Transfer	Demonstrate how to implement a composite device (USB micro printer device and HID Transfer). Transfer data between USB device and PC through a USB HID interface. A windows tool is also included in this sample code to connect with a USB device.
USBD_VCOM_And_HID_Keyboard	Demonstrate how to implement a composite device (VCOM and HID keyboard).
USBD_VCOM_And_HID_Transfer	Demonstrate how to implement a composite device (VCOM and HID Transfer). Transfer data between USB device and PC through a USB HID interface. A windows tool is also included in this sample code to connect with

	a USB device.
USBD_VCOM_And_Mass_Storage	Demonstrate how to implement a composite device (Virtual COM port and Mass storage device).
USBD_VCOM_DualPort	Demonstrate how to implement a USB dual virtual COM port device.
USBD_VCOM_SerialEmulator	Demonstrate how to implement a USB virtual COM port device.
USBD_VENDOR_LBK	Implement a proprietary Vendor LBK device. This sample requires a M433 USB host running sample USBH_VENDOR_LBK to be connected.

USB 1.1 Host Controller (USBH)

USBH_AudioClass	Demonstrate how to use USBH Audio Class driver. It shows the mute, volume, auto-gain, channel, and sampling rate control.
USBH_DEV_CONN	Use connect/disconnect callback functions to handle of device connect and disconnect events.
USBH_Firmware_Update	Automatically search and read new firmware from USB drive, if found, update APROM Flash with it.
USBH_HID	Use USB Host core driver and HID driver. This sample demonstrates how to submit HID class request and read data from interrupt pipe. This sample supports dynamic device plug/un-plug and multiple HID devices.
USBH_HID_Keyboard	Demonstrate reading key inputs from USB keyboards. This sample includes an USB keyboard driver which is based on the HID driver.
USBH_HID_Mouse_Keyboard	Demonstrates how to support USB mouse and keyboard input.
USBH_MassStorage	Use a command-shell-like interface to demonstrate how to use USBH mass storage driver and make it work as a disk driver under the FATFS file system.

USBH_UAC_HID	Show how to use USBH Audio Class driver and HID driver at the same time. The target device is a Game Audio (UAC+HID composite device).
USBH_UAC_LoopBack	Receive audio data from an UAC device, and immediately send back to the UAC device.
USBH_VCOM	Demonstrate how to use the USB Host core driver and CDC driver to connect a CDC class VCOM device.
USBH_VENDOR_LBK	Show how to do transfer on a known device with a vendor driver. This sample requires a M433 USB device running sample USBD_VENDOR_LBK to be connected.

Watchdog Timer (WDT)

WDT_TimeoutWakeupAndReset	Implement WDT time-out interrupt event to wake up system and generate time-out reset system event while WDT time-out reset delay period expired.
----------------------------------	--

Window Watchdog Timer (WWDT)

WWDT_CompareINT	Show how to reload the WWDT counter value.
------------------------	--

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

*Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*