

# **N9H26**

## **Non-OS Library Reference Guide**

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NuMicro microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

[www.nuvoton.com](http://www.nuvoton.com)

# Table of Contents

<b>1</b>	<b>AAC LIBRARY .....</b>	<b>8</b>
1.1	Overview .....	8
1.2	AAC API.....	8
1.3	Example code.....	10
<b>2</b>	<b>AES LIBRARY .....</b>	<b>11</b>
2.1	Overview .....	11
2.2	Feature .....	11
2.3	API Data Structure.....	11
2.4	API Function .....	11
2.5	Error Code Table .....	16
<b>3</b>	<b>AUDIO ADC LIBRARY .....</b>	<b>17</b>
3.1	Overview .....	17
3.2	Audio ADC Library APIs Specification .....	17
<b>4</b>	<b>AVI LIBRARY .....</b>	<b>28</b>
4.1	Video render .....	28
4.2	How to use AVI player library .....	28
4.3	AVI player user callback.....	28
4.4	AVI playback information .....	29
4.5	API Enumeration .....	29
4.6	API Structure .....	30
4.7	Functions.....	30
4.8	Error Code Table .....	34
4.9	MP3 Library Overview.....	36
4.10	API Enumeration .....	36
4.11	Structure .....	36
4.12	Functions.....	37
<b>5</b>	<b>BLT LIBRARY .....</b>	<b>40</b>
5.1	Overview .....	40
5.2	Feature .....	40
5.3	Transformation Matrix .....	40

5.4 Pixel Mapping .....	46
5.5 Color Transformation .....	47
5.6 Palette .....	47
5.7 API Data Structure .....	48
5.8 API Function .....	52
5.9 Error Code Table .....	65
<b>6 CRC LIBRARY .....</b>	<b>67</b>
6.1 overview .....	67
6.2 Feature .....	67
6.3 API Data Structure .....	67
6.4 API Function .....	69
6.5 Error Code Table .....	72
<b>7 EDMA LIBRARY .....</b>	<b>73</b>
7.1 Overview .....	73
7.2 Programming Guide .....	73
7.3 APIs Specification Functions .....	76
7.4 Error Code Table .....	85
<b>8 EMAC LIBRARY .....</b>	<b>86</b>
8.1 Overview .....	86
8.2 Feature .....	86
8.3 API Data Structure .....	86
8.4 API Function .....	87
8.5 Error Code Table .....	89
<b>9 FONT LIBRARY .....</b>	<b>90</b>
9.1 Overview .....	90
9.2 Font Library API .....	90
<b>10 GNAND LIBRARY .....</b>	<b>97</b>
10.1 Overview .....	97
10.2 GNAND Library Introduction .....	97
10.3 Programming Guide .....	97
10.4 API Function .....	101
10.5 Example code .....	106

10.6	Error Code Table .....	106
<b>11</b>	<b>GPIO LIBRARY .....</b>	<b>108</b>
11.1	Overview.....	108
11.2	API Functions .....	108
<b>12</b>	<b>H264 CODEC LIBRARY.....</b>	<b>117</b>
12.1	Overview.....	117
12.2	Feature .....	117
12.3	Rate Control for Encoder .....	117
12.4	API Data Structure .....	118
12.5	API Function .....	121
12.6	Return Code Table .....	125
12.6.1	AVC_RET .....	125
<b>13</b>	<b>I2C LIBRARY.....</b>	<b>126</b>
13.1	Overview.....	126
13.2	I2C Library APIs Specification.....	126
13.3	Error Code Table .....	130
<b>14</b>	<b>I2S LIBRARY .....</b>	<b>132</b>
14.1	Overview.....	132
14.2	API Functions .....	132
<b>15</b>	<b>JPEG LIBRARY.....</b>	<b>137</b>
15.1	Overview.....	137
15.2	JPEG Overview .....	137
15.3	Programming Guide.....	137
15.4	JPEG Library Constant Definition.....	144
15.5	JPEG API .....	147
15.6	Example code .....	155
<b>16</b>	<b>PWM LIBRARY .....</b>	<b>156</b>
16.1	Overview.....	156
16.2	Programming Guide.....	156
16.3	PWM Timer Control .....	157
16.3.2	PWM Library Constant Definition.....	161
16.3.3	PWM Library Property Definition.....	162
16.4	PWM API .....	162

<b>17 RFC LIBRARY .....</b>	<b>175</b>
17.1 Overview.....	175
17.2 Feature .....	175
17.3 API Data Structure .....	175
17.4 API Function .....	176
17.5 Error Code Table .....	179
<b>18 ROTATION LIBRARY.....</b>	<b>180</b>
18.1 Overview.....	180
18.2 Rotation Library APIs Specification .....	180
<b>19 RSC LIBRARY.....</b>	<b>185</b>
19.1 Overview.....	185
19.2 Feature .....	185
19.3 Function.....	185
<b>20 RTC LIBRARY .....</b>	<b>188</b>
20.1 Overview.....	188
20.2 Programming Guide.....	188
20.3 RTC API.....	194
20.4 Error Code Table .....	200
<b>21 SDIO LIBRARY .....</b>	<b>201</b>
21.1 Overview.....	201
21.2 SDIO Library .....	201
21.3 Programming Guide.....	201
21.4 SDIO API .....	202
21.5 SDIO API .....	204
21.6 Error Code Table .....	207
<b>22 SIC LIBRARY .....</b>	<b>208</b>
22.1 Overview.....	208
22.2 Storage Interface Controller Library .....	208
22.3 Programming Guide.....	208
22.4 SIC API .....	209
22.5 SIC / SD API .....	211
22.6 SIC / NAND API.....	214

22.7	Error Code Table .....	221
<b>23</b>	<b>SPI LIBRARY .....</b>	<b>223</b>
23.1	Overview.....	223
23.2	API Functions .....	223
<b>24</b>	<b>SPI_SECUREIC LIBRARY .....</b>	<b>232</b>
24.1	Overview.....	232
24.2	API Functions .....	232
<b>25</b>	<b>SPU LIBRARY .....</b>	<b>239</b>
25.1	Overview.....	239
25.2	API Functions .....	239
<b>26</b>	<b>SYSTEM LIBRARY .....</b>	<b>244</b>
26.1	Overview.....	244
26.2	Timer API Functions .....	244
26.3	Cache Function .....	273
26.4	Clock Control function .....	276
26.5	Error Code Table .....	285
<b>27</b>	<b>TOUCH ADC LIBRARY.....</b>	<b>287</b>
27.1	Overview.....	287
27.2	Touch ADC Library APIs Specification .....	287
27.3	Error Code Table .....	294
<b>28</b>	<b>UDC LIBRARY .....</b>	<b>295</b>
28.1	Overview.....	295
28.2	Programming Guide.....	295
28.3	USB Device (UDC) API .....	298
28.4	Mass Storage Class (MSCD) API.....	301
28.5	Example code .....	311
<b>29</b>	<b>USB CORE LIBRARY .....</b>	<b>312</b>
29.1	USB Core Library Overview .....	312
29.2	Data Structures .....	312
29.3	USB Core Library API.....	335
<b>30</b>	<b>VIDEOIN LIBRARY .....</b>	<b>344</b>
30.1	Features .....	344

30.2 VIDEOIN Library Description ..... 344

30.3 VIDEOIN Library API ..... 345

30.4 Error Code Table ..... 369

**31 VPE LIBRARY ..... 370**

31.1 Features ..... 370

31.2 VPE Library Description ..... 371

31.3 VPE Library API ..... 371

31.4 Error Code Table ..... 383

**32 VPOST ..... 384**

32.1 VPOST Overview ..... 384

32.2 API Enumeration ..... 385

32.3 API Structure ..... 387

32.4 API Functions ..... 390

32.5 Error Code Table ..... 396

**33 REVISION HISTORY ..... 397**

# 1 AAC LIBRARY

## 1.1 OVERVIEW

This library is designed to make user application to use N9H26 AAC IMDCT/MDCT more easily.

The AAC library has the following features:

- AAC IMDCT for decoder.
- AAC MDCT for encoder.

BSP Non-OS provide one library and one sample code to test AAC IMDCT/MDCT function. User could use them to verify hardware IP.

## 1.2 AAC API

### ***DrvAAC\_Open***

#### **Synopsis**

VOID DrvAAC\_Open(VOID)

#### **Description**

This function enables the AAC engine clock.

#### **Parameter**

None

#### **Return Value**

None

#### **Example**

```
DrvAAC_Open ();
```

### ***DrvAAC\_Close***

#### **Synopsis**

VOID DrvAAC\_Close (VOID)

#### **Description**

This function disables the AAC engine clock.

#### **Parameter**



None

#### **Return Value**

None

#### **Example**

```
DrvAAC_Close ();
```

### ***DrvAAC\_Decoder***

#### **Synopsis**

```
INT32
DrvAAC_Decoder(
    INT32  i32Size,
    INT32 *pi32inbuf,
    INT32 *pi32outbuf
)
```

#### **Description**

Set the parameters for AAC IMDCT of decoder, it will return the size of output buffer and the output buffer for the result of IMDCT.

#### **Parameter**

i32Size                    2048 or 256  
 pi32inbuf                The input encoded data.  
 Pi32outbufThe output data by running AAC IMDCT of decoder.

#### **Return Value**

The size of output buffer. Its bytes is the size x 4.

#### **Example**

```
DrvAAC_Open();
DrvAAC_Decoder(128*2, pi32inptr,pi32resultptr);
DrvAAC_Close();
```

### ***DrvAAC\_Encoder***

#### **Synopsis**

```
INT32
DrvAAC_Encoder(
```

```

INT32 *pi32inbuf,
INT32 *pi32outbuf,
INT32 i32Size

)

```

#### Description

Set the parameters for AAC MDCT of encoder, it will return the size of output buffer and the output buffer for the result of IMDCT.

#### Parameter

pi32inbuf	The input encoded data.
Pi32outbuf	The output data by running AAC MDCT of encoder.
i32Size	2048 or 256

#### Return Value

The size of output buffer , its bytes is the size x 4.

#### Example

```

DrvAAC_Open();
DrvAAC_Encoder(pi32inptr,pi32resultptr,256);
DrvAAC_Close();

```

### 1.3 EXAMPLE CODE

This demo code includes sample code and library code. Please refer to AAC sample codes of BSP Non-OS.

## 2 AES LIBRARY

### 2.1 OVERVIEW

The AES accelerator is a fully compliant implementation of the AES algorithm. Such accelerator supports both encryption and decryption. The AES accelerator can be used in different data security applications, such as secure communications, which need to provide cryptographic protection.

### 2.2 FEATURE

- Supports both encryption and decryption.
- Supports only CBC (Cipher Block Chaining) mode.
- All three kinds of key lengths, 128, 192, and 256 bits, are supported.

### 2.3 API DATA STRUCTURE

#### ***KEYSIZE***

Key size.

Name	Value	Description
KEY_128	0	128-bit key size
KEY_192	1	192-bit key size
KEY_256	2	256-bit key size

### 2.4 API FUNCTION

#### ***AES\_Initial***

##### **Synopsis**

```
VOID AES_Initial(VOID);
```

##### **Description**

Initialize AES engine and install interrupt service routine.

##### **Parameter**

None

**Return Value**

None

***AES\_Final***

**Synopsis**

VOID AES\_Final(VOID);

**Description**

Tear down AES engine.

**Parameter**

None

**Return Value**

None

***AES\_Encrypt***

**Synopsis**

int AES\_Encrypt(UINT8 \*input\_buf, UINT8 \*output\_buf, UINT32 input\_len, UINT8 \*iv, UINT8 \*key, KEYSIZE key\_size);

**Description**

Start to encrypt in AES CBC mode and wait for its finish.

**Parameter**

input_buf	4-byte aligned address of input buffer
output_buf	4-byte aligned address of output buffer. If
NULL, output_buf = input_buf	
input_len	Length of input buffer in bytes
iv	16-byte initialization vector
key	16-, 24-, or 32-byte key buffer
key_size	key size as defined in <a href="#">KEYSIZE</a>

**Return Value**

Success

AES\_ERR\_DATA\_LEN                      Data length is not 16-byte aligned

AES\_ERR\_DATA\_BUF                      Address of input buffer is NULL

AES\_ERR\_CIPHER\_KEY                      Key size not defined in [KEYSIZE](#)

AES\_ERR\_IV                              NULL initialization vector

## AES\_Encrypt\_Async

### Synopsis

```
int AES_Encrypt_Async(UINT8 *input_buf, UINT8 *output_buf, UINT32 input_len,
UINT8 *iv, UINT8 *key, KEYSIZE key_size);
```

### Description

Start to encrypt in AES CBC mode but doesn't wait for its finish.

### Parameter

input_buf	4-byte aligned address of input buffer
output_buf	4-byte aligned address of output buffer. If
NULL, output_buf = input_buf	
input_len	Length of input buffer in bytes
iv	16-byte initialization vector
key	16-, 24-, or 32-byte key buffer
key_size	key size as defined in <a href="#">KEYSIZE</a>

### Return Value

Success	
AES_ERR_DATA_LEN	Data length is not 16-byte aligned
AES_ERR_DATA_BUF	Address of input buffer is NULL
AES_ERR_CIPHER_KEY	Key size not defined in <a href="#">KEYSIZE</a>
AES_ERR_IV	NULL initialization vector
AES_ERR_RUNNING	Operation is on-going. Wait by
<a href="#">AES Flush</a> or Poll by <a href="#">AES Check Status</a>	

## AES\_Decrypt

### Synopsis

```
int AES_Decrypt(UINT8 *input_buf, UINT8 *output_buf, UINT32 input_len, UINT8
*iv, UINT8 *key, KEYSIZE key_size);
```

### Description

Start to decrypt in AES CBC mode and wait for its finish.

### Parameter

input_buf	4-byte aligned address of input buffer
output_buf	4-byte aligned address of output buffer. If
NULL, output_buf = input_buf	
input_len	Length of input buffer in bytes
iv	16-byte initialization vector

key	16-, 24-, or 32-byte key buffer
key_size	key size as defined in <a href="#">KEYSIZE</a>

#### Return Value

Success	
AES_ERR_DATA_LEN	Data length is not 16-byte aligned
AES_ERR_DATA_BUF	Address of input buffer is NULL
AES_ERR_CIPHER_KEY	Key size not defined in <a href="#">KEYSIZE</a>
AES_ERR_IV	NULL initialization vector

### AES\_Decrypt\_Async

#### Synopsis

```
int AES_Decrypt_Async(UINT8 *input_buf, UINT8 *output_buf, UINT32
input_len, UINT8 *iv, UINT8 *key, KEYSIZE key_size);
```

#### Description

Start to decrypt in AES CBC mode but doesn't wait for its finish.

#### Parameter

input_buf	4-byte aligned address of input buffer
output_buf	4-byte aligned address of output buffer. If
NULL, output_buf = input_buf	
input_len	Length of input buffer in bytes
iv	16-byte initialization vector
key	16-, 24-, or 32-byte key buffer
key_size	key size as defined in <a href="#">KEYSIZE</a>

#### Return Value

Success	
AES_ERR_DATA_LEN	Data length is not 16-byte aligned
AES_ERR_DATA_BUF	Address of input buffer is NULL
AES_ERR_CIPHER_KEY	Key size not defined in <a href="#">KEYSIZE</a>
AES_ERR_IV	NULL initialization vector
AES_ERR_RUNNING	Operation is on-going. Wait by
<a href="#">AES_Flush</a> or Poll by <a href="#">AES_Check_Status</a>	

### AES\_Flush

#### Synopsis

```
int AES_Flush(VOID);
```

**Description**

Wait for operation done

**Parameter**

None

**Return Value**

Success

Operation done

AES\_ERR\_BUS\_ERROR

Encounter bus error

***AES\_Check\_Status***

**Synopsis**

int AES\_Check\_Status(VOID);

**Description**

Check operation status

**Parameter**

None

**Return Value**

Success

Operation done

AES\_ERR\_BUS\_ERROR

Encounter bus error

AES\_ERR\_BUSY

Operation busy

***AES\_Enable\_Interrupt***

**Synopsis**

VOID AES\_Enable\_Interrupt(VOID);

**Description**

Enable the only interrupt source

**Parameter**

None

**Return Value**

None

***AES\_Disable\_Interrupt***

**Synopsis**

VOID AES\_Disable\_Interrupt(VOID);

**Description**

Disable the only interrupt source

**Parameter**

None

**Return Value**

None

## 2.5 ERROR CODE TABLE

Code Name	Value	Description
Successful	0	Success
AES_ERR_FAIL	AES_ERR_ID   0x01	Internal
AES_ERR_DATA_LEN	AES_ERR_ID   0x02	Not 16-byte aligned
AES_ERR_DATA_BUF	AES_ERR_ID   0x03	NULL buffer
AES_ERR_CIPHER_KEY	AES_ERR_ID   0x04	NULL key or invalid key size
AES_ERR_IV	AES_ERR_ID   0x05	NULL initialization vector
AES_ERR_MODE	AES_ERR_ID   0x06	Internal
AES_ERR_BUS_ERROR	AES_ERR_ID   0x07	Encounter bus error
AES_ERR_RUNNING	AES_ERR_ID   0x08	Operation is on-going. Need to flush.
AES_ERR_BUSY	AES_ERR_ID   0x09	Operation is busy.
AES_ERR_CMPDAT	AES_ERR_ID   0x0A	Internal



## 3 AUDIO ADC LIBRARY

### 3.1 OVERVIEW

The N9H26 Audio ADC library provides a set of APIs to record audio data from input device. With these APIs, user can set sampling rate. Pre-gain and post gain control if AGC disable, Output target level if AGC enable and so on.

These libraries are created by using Keil uVision IDE. Therefore, they only can be used in Keil environment.

### 3.2 AUDIO ADC LIBRARY APIS SPECIFICATION

#### *DrvAUR\_Open*

##### Synopsis

INT32 DrvAUR\_Open(E\_AUR\_MIC\_SEL eMIC, BOOL blsCoworkEDMA)

##### Description

This function is used to open the Audio ADC library.

##### Parameter

eIntType Input device type. Please refer [Table 3-1:Input Device](#)

blsCoworkEDMA Corporate with EDMA driver to receiver audio data. The parameter should be always equal to TRUE.

TRUE: Enable corporation with EDMA.

FALSE: Disable corporation with EDMA

Table 3-1:Input Device

Field name	Value	Description
eAUR_MONO_LINE_IN	0	Mono Line In
eAUR_MONO_MIC_IN	1	Mono MIC In
eAUR_MONO_DIGITAL_MIC_IN	2	Mono Digital MIC In
eAUR_STEREO_DIGITAL_MIC_IN	3	Stereo Digital MIC In

##### Return Value

Successful

##### Example

```
/* Input device is Mono MIC and corporate with EDMA */
DrvAUR_Open(eAUR_MONO_MIC_IN, TRUE);
```

### **DrvAUR\_Close**

#### **Synopsis**

```
INT32 DrvAUR_Close(void)
```

#### **Description**

Close the Audio ADC library.

#### **Parameter**

None

#### **Return Value**

Successful

#### **Example**

```
/* Close Audio ADC library*/
DrvAUR_Close();
```

### **DrvAUR\_InstallCallback**

#### **Synopsis**

```
INT32 DrvAUR_InstallCallback (PFN_AUR_CALLBACK pfnCallback,
PFN_AUR_CALLBACK* pfnOldCallback);
```

#### **Description**

This function is used to install callback function that is used to notice the upper layer for specified audio sample is done. The function will be useless if corporation with EDMA.

The specified audio sample is set in

#### **Parameter**

pfnCallback	The callback function that register to the library to handle event.
pfnOldCallback	Old callback function

#### **Return Value**

-1 or Successful

#### **Example**

```
volatile BOOL blsAudioSampleDone = FALSE;
INT32 i32Count = 0;
void AudioRecordSampleDone(void)
{
    i32Count = i32Count+1;
    blsAudioSampleDone = TRUE;
}
void Audio_Record(void)
{
    PFN_AUR_CALLBACK pfnOldCallback;
    ...
    DrvAUR_Open(eMicType, TRUE);
    DrvAUR_InstallCallback(AudioRecordSampleDone, &pfnOldCallback);
    ...
}
```

### ***DrvAUR\_EnableInt***

#### **Synopsis**

```
void DrvAUR_EnableInt(void);
```

#### **Description**

This function was used to enable interrupt if converse audio sample done. The function will be useless if corporation with EDMA.

#### **Parameter**

None

#### **Return Value**

-1 or Successful.

#### **Example**

```
DrvAUR_EnableInt();
```

### ***DrvAUR\_DisableInt***

#### **Synopsis**

```
void DrvAUR_DisableInt(void);
```

**Description**

This function was used to disable interrupt if converse audio sample done. The function will be called if corporation with EDMA.

**Parameter**

None

**Return Value**

-1 or Successful.

**Example**

```
DrvAUR_DisableInt();
```

**DrvAUR\_AutoGainCtrl**
**Synopsis**

```
INT32 DrvAUR_ AutoGainCtrl(BOOL blsEnable,  
    BOOL blsChangeStep,  
    E_AUR_AGC_LEVEL eLevel);
```

**Description**

This function is used to enable or disable auto gain control-AGC function. And set output target level.

**Parameter**

blsEnable Enable AGC or not.

Field name	Value	Description
eAUR_OTL_N3	0	-3 db
eAUR_OTL_N4P6	1	-4.6 db
eAUR_OTL_N6P2	2	-6.2 db
eAUR_OTL_N7P8	3	-7.8 db
eAUR_OTL_N9P4	4	-9.4 db
eAUR_OTL_N11	5	-11 db
eAUR_OTL_N12P6	6	-12.6 db
eAUR_OTL_N14P2	7	-14.2 db
eAUR_OTL_N15P8	8	-15.8 db
eAUR_OTL_N17P4	9	-17.4 db

eAUR_OTL_N19	10	-19 db
eAUR_OTL_N20P6	11	-20.6 db
eAUR_OTL_N22P2	12	-22.2 db
eAUR_OTL_N23P8	13	-23.8 db
eAUR_OTL_N25P4	14	-25.4 db
	15	Mute

**blsChangeStep** To trace the output target level, AGC algorithm change gain for each step.

**eLevel** Output target level. Please refer Table 3-2:Output Target Level

Table 3-2:Output Target Level

#### Return Value

Successful

#### Example

```
DrvAUR_AutoGainCtrl(TRUE, TRUE, eAUR_OTL_N12P6);
```

### ***DrvAUR\_AutoClampingGain***

#### Synopsis

INT32 DrvAUR\_AutoClampingGain ( UINT32 u32MaxGain, UINT32 u32MinGain)

#### Description

This function was used to clamp the maximum and minimum gain if enable AGC function. It will be useless if disable AGC.

#### Parameter

**u32MaxGain** Maximum gain to clamp AGC. The value is from 0 ~15.

**u32MinGain** Minimum gain to clamp AGC. The value is from 0 ~15.

#### Return Value

Successful

#### Example

```
DrvAUR_AutoClampingGain(eAUR_CLAMP_GAIN_P16, eAUR_CLAMP_GAIN_P3P2);
```

### ***DrvAUR\_SetSampleRate***

**Synopsis**

INT32 DrvAUR\_SetSampleRate(E\_AUR\_SPS eSampleRate)

**Description**

This function is used to set sampling rate.

**Parameter**

eSampleRate      Sampling rate from 8K to 192K. Please refer Table 3-3:  
Sampling Rate

Table 3-3: Sampling Rate

Field name	Value	Description
eAUR_SPS_48000	48000	48K sampling rate
eAUR_SPS_44100	44100	44.1K sampling rate
eAUR_SPS_32000	32000	32K sampling rate
eAUR_SPS_24000	24000	24K sampling rate
eAUR_SPS_22050	22050	22K sampling rate
eAUR_SPS_16000	16000	16K sampling rate
eAUR_SPS_12000	12000	12K sampling rate
eAUR_SPS_11025	11025	11.025K sampling rate
eAUR_SPS_8000	8000	8K sampling rate
eAUR_SPS_96000	96000	96K sampling rate
eAUR_SPS_192000	192000	192K sampling rate

**Return Value**

Successful

**Example**

```
DrvAUR_SetSampleRate((E_AUR_SPS)eAUR_SPS_48000);
```

**DrvAUR\_AudioI2cRead**
**Synopsis**

INT32 DrvAUR\_AudioI2cRead(UINT32 u32Addr, UINT8\* p8Data)

**Description**

This function is used to read back the internal register of Sigma-Delta ADC. Programmer can use the API to adjust pre-gain and post-gain if AGC is disable.

## Parameter

u32Addr Register address. Please refer Table 3-4: Sigma-Delta Register Address.

p8Data Register content after read back.

Table 3-4: Sigma-Delta Register Address

Field name	Value	Description
eAUR_ADC_H20	0x20	Please refer IP programming guide
eAUR_ADC_H21	0x21	Please refer IP programming guide
eAUR_ADC_H22	0x22	Please refer IP programming guide
eAUR_ADC_H23	0x23	Please refer IP programming guide
eAUR_ADC_H24	0x24	Please refer IP programming guide
eAUR_ADC_H25	0x25	Please refer IP programming guide
eAUR_ADC_H26	0x26	Please refer IP programming guide
eAUR_ADC_H29	0x29	Please refer IP programming guide

## Return Value

Successful

## Example

```

UINT8 u8RegDac;
DrvAUR_AudioI2cRead((E_AUR_ADC_ADDR)REG_ADC_H20, &u8RegDac);
DrvAUR_AudioI2cWrite((E_AUR_ADC_ADDR)REG_ADC_H23, 0x0E); /* Adjust Post-
gain*/

```

## DrvAUR\_AudioI2cWrite

### Synopsis

```
INT32 DrvAUR_AudioI2cWrite(UINT32 u32Addr, UINT32 u32Data);
```

### Description

This function is used to program the internal register of Sigma-Delt ADC. Programmer can use the API to adjust pre-gain and post-gain if AGC is disable.

### Parameter

u32Addr Register address. Please refer Table 3-4: Sigma-Delta Register Address.

u32Data The data that wants to program sigma-delta

**Return Value**

Successful

**Example**

```
DrvAUR_AudioI2cWrite(0x22, 0x1E); /* Adjust Pre-gain */
DrvAUR_AudioI2cWrite(0x23, 0x0E); /* Adjust Post-gain*/
```

**DrvAUR\_SetDigiMicGain**

**Synopsis**

```
VOID DrvAUR_SetDigiMicGain(BOOL blsEnable,
                           E_AUR_DIGI_MIC_GAIN eDigiGain)
```

**Description**

This function is used to set digital gain if input device is digital MIC. It is only for input device is Mono Digital MIC In or Stereo Digital MIC In. Please refer [Table 3-1:Input Device](#)

**Parameter**

blsEnable      Enable digital gain for digital MIC.  
eDigiGain      Digital gain. Please refer Table 3-5:Digital Gain

Table 3-5:Digital Gain

Field name	Value	Description
eAUR_DIGI_MIC_GAIN_P0	0	+0db
eAUR_DIGI_MIC_GAIN_P1P6	1	+1.6db
eAUR_DIGI_MIC_GAIN_P3P2	2	+3.2db
eAUR_DIGI_MIC_GAIN_P4P8	3	+4.8db
eAUR_DIGI_MIC_GAIN_P6P4	4	+6.4db
eAUR_DIGI_MIC_GAIN_P8	5	+8db
eAUR_DIGI_MIC_GAIN_P9P6	6	+9.6db
eAUR_DIGI_MIC_GAIN_P11P2	7	+11.2db
eAUR_DIGI_MIC_GAIN_P12P8	8	+12.8db
eAUR_DIGI_MIC_GAIN_P14P4	9	+14.4db
eAUR_DIGI_MIC_GAIN_P16	10	+16db
eAUR_DIGI_MIC_GAIN_P17P6	11	+17.6db
eAUR_DIGI_MIC_GAIN_P19P2	12	+19.2db
eAUR_DIGI_MIC_GAIN_P20P8	13	+20.8db



eAUR_DIGI_MIC_GAIN_P22P4	14	+22.4db
eAUR_DIGI_MIC_GAIN_P24	15	+24db

### Return Value

Successful

### Example

```
DrvAUR_SetDigiMicGain(TRUE, eAUR_DIGI_MIC_GAIN_P19P2);
```

**DrvAUR\_StartRecord**

## Synopsis

```
VOID DrvAUR_StartRecord(E_AUR_MODE eMode);
```

### Description

Start-up sigma-delta ADC to converse audio data.

### Parameter

eMode	Only eAUR_MODE_1 can be set if corporate with EDMA
-------	--

Please refer Table 3-6:Interface Between Audio ADC

and EDMA

### Table 3-6: Interface Between Audio ADC and EDMA

Field name	Value	Description
eAUR_MODE_0	0	1 sample
eAUR_MODE_1	1	2 Samples
eAUR_MODE_2	2	4 Samples
eAUR_MODE_3	3	8 Samples

### Return Value

Successful

### Example

```
DrvAUR StartRecord(eAUR MODE 1);
```

**DrvAUR\_StopRecord**

## Synopsis

```
VOID DrvAUR_StopRecord(void);
```

**Description**

Stop audio recording

**Parameter**

None

**Return Value**

Successful

**Example**

```
DrvAUR_StopRecord();
```

***DrvAUR\_SetDataOrder***
**Synopsis**

```
VOID DrvAUR_SetDataOrder(E_AUR_ORDER eOrder)
```

**Description**

This function is used to set the PCM data order for each audio sample

**Parameter**

eOrder PCM data format. Please refer Table 3-7: Supported PCM Data Format

Table 3-7: Supported PCM Data Format

Field name	Value	Description
eAUR_ORDER_MONO_32BITS	0	Mono little endian 32 bits signed PCM
eAUR_ORDER_MONO_16BITS	1	Mono little endian 16 bits signed PCM
eAUR_ORDER_STEREO_16BITS	2	Stereo little endian 16 bits signed PCM
eAUR_ORDER_MONO_24BITS	3	(Non-standard 24 bits PCM)

**Return Value**

Successful

**Example**

```
DrvAUR_Open(eMicType, TRUE);
DrvAUR_SetDataOrder(eAUR_ORDER_MONO_16BITS);
if(eMicType == eAUR_MONO_MIC_IN){
    DrvAUR_AudioI2cWrite(0x22, 0x1E); /* Adjust Pre-gain */
    DrvAUR_AudioI2cWrite(0x23, 0x0E); /* Adjust Post-gain */
    DrvAUR_DisableInt();
}
```

```

    DrvAUR_SetSampleRate(aArraySampleRate[i32Idx]);
    DrvAUR_AutoGainTiming(1,1,1);
    DrvAUR_AutoGainCtrl(TRUE, TRUE, eAUR_OTL_N12P6);
}else if((eMicType == eAUR_MONO_DIGITAL_MIC_IN) ||
(eMicType == eAUR_STEREO_DIGITAL_MIC_IN)){
    DrvAUR_SetDigiMicGain(TRUE, eAUR_DIGI_MIC_GAIN_P19P2);
    DrvAUR_DisableInt();
    DrvAUR_SetSampleRate(eAUR_DIGI_MIC_GAIN_P19P2);

```

## 4 AVI LIBRARY

### 4.1 VIDEO RENDER

N9H26 can support JPEG decoder to output decoded packet data in DIRECT\_RGB555, DIRECT\_RGB565, DIRECT\_RGB888 or DIRECT\_YUV422 format. User application must initialize VPOST as corresponding format specified in AVI function call `aviPlayFile(...)`. AVI player library will configure JPEG output format as specified format and use DMA to copy the decoded data to VPOST frame buffer in Vsync period to avoid the tearing issue.

In this way, three frame buffers are required. One is allocated in VPOST initialized function and two buffers are allocated in AVI library.

### 4.2 HOW TO USE AVI PLAYER LIBRARY

The AVI player library has managed the file access, JPEG decode and audio decode. User only gives the AVI file name and render method to play the movie. The AVI player required user to prepare the following things before playing an AVI movie:

- Initialize system with cache on
- Initialize file system and storage interface (ex. SD card)
- Initialize timer 0
- Initialize VPOST

The VPOST frame buffer format should be consistent with the AVI playback render mode:

- Direct RGB555 – VPOST should select **DRVVPOST\_FRAME\_RGB555**
- Direct RGB565 – VPOST should select **DRVVPOST\_FRAME\_RGB565**
- Direct RGB888 – VPOST should select **DRVVPOST\_FRAME\_RGBx888** or **DRVVPOST\_FRAME\_RGB888x**
- Direct YUV422 – VPOST should select **DRVVPOST\_FRAME\_CBYCRY** or **DRVVPOST\_FRAME\_YCBYCR** or **DRVVPOST\_FRAME\_CRYCBY** or **DRVVPOST\_FRAME\_YCRYCB**

The AVI playback function supports (x, y) coordinate that are the second and third argument of ***aviPlayFile()*** used to specify the render location on LCD now. Moreover, decoded image scales by 1/2 in horizontal and vertical direction if the decoded video width is larger than the panel width.

### 4.3 AVI PLAYER USER CALLBACK

While playing an AVI move, user application may want to draw information on screen or manage user inputs. AVI library provides a callback function to allow user application to grab pieces of CPU time. The callback function pointer was passed to AVI player as the last argument of ***aviPlayFile()***.

Depends on the loading of playing an AVI movie, the user callback will be called several times in each one second. User application should finish the execution of callback function as soon as possible. Otherwise, the

AVI playback can be broken because of not enough CPU time.

## 4.4 AVI PLAYBACK INFORMATION

While playing an AVI movie, user application can get AVI file information and playback progress information from AVI player. The AVI information will be passed to user application as a parameter of callback function. All information is packed in the AVI\_INFO\_T structure.

## 4.5 API ENUMERATION

Name	Value	Description
JV_MODE_E		
DIRECT_RGB555	0x0	Direct RGB555 output format
DIRECT_RGB565	0x1	Direct RGB565 output format
DIRECT_RGB888	0x2	Direct RGB888 output format
DIRECT_YUV422	0x3	Direct YUV422 output format
AU_TYPE_E		
AU_CODEC_UNKNOWN	0x0	Unknown audio format
AU_CODEC_PCM	0x1	PCM audio format
AU_CODEC_IMA_ADPCM	0x2	ADPCM audio format
AU_CODEC_MP3	0x3	MP3 audio format
PLAY_CTRL_E		
PLAY_CTRL_FF	0x0	(Not supported)
PLAY_CTRL_FB	0x1	(Not supported)
PLAY_CTRL_FS	0x2	(Not supported)
PLAY_CTRL_PAUSE	0x3	Pause Playback
PLAY_CTRL_RESUME	0x4	Resume Playback
PLAY_CTRL_STOP	0x5	Stop Playback
PLAY_CTRL_SPEED	0x6	(Not supported)

## 4.6 API STRUCTURE

Figure 4.6-1 AVI\_INFO\_T structure

Field	Type	Description
uMovieLength	UINT32	The total length of input AVI movie (in 0.01 second unit)
uPlayCurTimePos	UINT32	The current playback position. (in 0.01 second unit)
eAuCodec	AU_TYPE_E	Audio format type
nAuPlayChnNum	INT	Audio channel number. (1: mono, 2: stereo, 0: video-only)
nAuPlaySRate	INT	audio sampling rate
uVideoFrameRate	UINT32	Video frame rate.
usImageWidth	UINT16	Video image width
usImageHeight	UINT16	Video image height
uVidTotalFrames	UINT32	total number of video frames
uVidFramesPlayed	UINT32	Indicate how many video frames have been played
uVidFramesSkipped	UINT32	The number of frames was skipped. Video frames may be skipped due to A/V sync

## 4.7 FUNCTIONS

### ***aviStopPlayFile***

#### **Synopsis**

```
int
aviStopPlayFile(void);
```

#### **Description**

Stop current AVI file playback.

#### **Parameter**

None

#### **Return Value**

Successful: Success  
 ERRCODE: Error

#### **Example**

None.

## **aviPlayFile**

### **Synopsis**

```
int
aviPlayFile(
char *suFileName,
int x,
int y,
JV_MODE_E mode,
AVI_CB *cb
);
```

### **Description**

Play an AVI file.

### **Parameter**

**suFileName [in]**

The full path file name of input AVI file.

**x [in]**

The x-coordinate from left-up corner of AVI video render area.

**y [in]**

The y-coordinate from left-up corner of AVI video render area.

There are 3 cases for the x/y coordinate specified.

Case 1: x=0 and y=0

The AVI display data is aligned to center of panel.

Case 2: x<0 or y<0

The AVI display data is aligned to coordinate (0,0) on the left-up corner

Case 3: others

The AVI display data is aligned to coordinate (x,y).

**mode [in]**

Video render mode.

**cb [in]**

User application callback function.

### **Return Value**

Successful: Success

ERRCODE: Error

**Example**

```

/*-----*/
/*  Direct RGB565 AVI playback !!          */
/*-----*/

lcdformatex.ucVASrcFormat = DRVVPOST_FRAME_RGB565;
vpostLCMInit(&lcdformatex, (UINT32 *)_VpostFrameBuffer);
fsAsciiToUnicode("c:\\Flip-20fps_640x480.avi", suFileName, TRUE);
aviPlayFile(suFileName, 0, 0, DIRECT_RGB565, avi_play_control);

```

**aviGetFileInfo**
**Synopsis**

```

int
aviGetFileInfo (
char *suFileName,
AVI_INFO_T *ptAviInfo
);

```

**Description**

Get the AVI file information.

**Parameter**

**suFileName [in]**

The full path file name of input AVI file.

**ptAviInfo [in]**

Return AVI parsing information.

**Return Value**

Successful: Success

ERRCODE: Error

**Example**

```

fsAsciiToUnicode("c:\\Flip-20fps.avi", suFileName, TRUE);
aviPlayFile(suFileName, &sAVIInfo);

```

**aviSetPlayVolume**



#### Synopsis

```
int
aviSetPlayVolume (
int vol
);
```

#### Description

Set the Left channel and Right channel playback audio volume.

#### Parameter

**vol [in]**  
The audio volume

#### Return Value

Successful: Success  
ERRCODE: Error

#### Example

```
aviSetPlayVolume(suFileName, 0x1F);
```

### ***aviSetRightChannelVolume***

#### Synopsis

```
int
aviSetRightChannelVolume (
int vol
);
```

#### Description

Set the Right channel audio playback volume only.

#### Parameter

**vol [in]**  
The audio volume

#### Return Value

Successful: Success  
ERRCODE: Error

#### Example

```
// Set Right Channel as Mute
```

```
aviSetPlayRightChannelVolume(suFileName, 0x0);
```

## 4.8 ERROR CODE TABLE

Code Name	Value	Description
MFL_ERR_NO_MEMORY	0xFFFF8000	no memory
MFL_ERR_HARDWARE	0xFFFF8002	hardware general error
MFL_ERR_NO_CALLBACK	0xFFFF8004	must provide callback function
MFL_ERR_AU_UNSupport	0xFFFF8006	not supported audio type
MFL_ERR_VID_UNSupport	0xFFFF8008	not supported video type
MFL_ERR_OP_UNSupport	0xFFFF800C	unsupported operation
MFL_ERR_PREV_UNSupport	0xFFFF800E	preview of this media type was not supported or not enabled
MFL_ERR_FUN_USAGE	0xFFFF8010	incorrect function call parameter
MFL_ERR_RESOURCE_MEM	0xFFFF8012	memory is not enough to play/record a media file
MFL_ERR_FILE_OPEN	0xFFFF8020	cannot open file
MFL_ERR_FILE_TEMP	0xFFFF8022	temporary file access failure
MFL_ERR_STREAM_IO	0xFFFF8024	stream access error
MFL_ERR_STREAM_INIT	0xFFFF8026	stream was not opened
MFL_ERR_STREAM_EOF	0xFFFF8028	encounter EOF of file
MFL_ERR_STREAM_SEEK	0xFFFF802A	stream seek error
MFL_ERR_STREAM_TYPE	0xFFFF802C	incorrect stream type
MFL_ERR_STREAM_METHOD	0xFFFF8030	missing stream method
MFL_ERR_STREAM_MEMOUT	0xFFFF8032	recorded data has been over the application provided memory buffer
MFL_INVALID_BITSTREAM	0xFFFF8034	invalid audio/video bitstream forma
MFL_ERR_AVI_FILE	0xFFFF8080	Invalid AVI file format
MFL_ERR_AVI_VID_CODEC	0xFFFF8081	AVI unsupported video codec type
MFL_ERR_AVI_AU_CODEC	0xFFFF8082	AVI unsupported audio codec type
MFL_ERR_AVI_CANNOT_SEEK	0xFFFF8083	The AVI file is not fast-seekable
MFL_ERR_AVI_SIZE	0xFFFF8080	Exceed estimated size
MFL_ERR_MP3_FORMAT	0xFFFF80D0	incorrect MP3 frame format
MFL_ERR_MP3_DECODE	0xFFFF80D2	MP3 decode error
MFL_ERR_HW_NOT_READY	0xFFFF8100	the picture is the same as the last one
MFL_ERR_SHORT_BUFF	0xFFFF8104	buffer size is not enough

MFL_ERR_VID_DEC_ERR	0xFFFF8106	video decode error
MFL_ERR_VID_DEC_BUSY	0xFFFF8108	video decoder is busy
MFL_ERR_VID_ENC_ERR	0xFFFF810A	video encode error
MFL_ERR_UNKNOWN_MEDIA	0xFFFF81E2	unknow media type

## 4.9 MP3 LIBRARY OVERVIEW

Support MP3 sampling rate 8000 Hz, 11025 Hz, 16000 Hz, 22050 Hz, 32000 Hz, 44100 Hz and 48000 Hz.

### *How to use MP3 player library*

Init cache.  
Init UART.  
Init timer.  
Init filesystem.  
Init storage device.  
Init audio device.  
Start play MP3 file.

### *MP3 player user callback*

"ap\_time", the member of structure MV\_CFG\_T can excute user defined API. Any time information or control can be handled in it.

### *MP3 player information*

Structure MV\_INFO\_T will give you the time information, inclde current time and total time.

## 4.10 API ENUMERATION

Name	Value	Description
MEDIA_TYPE_E		
MFL_MEDIA_MP3	0x5	MP3 audio format
STRM_TYPE_E		
MFL_STREAM_FILE	0x1	MP3 file
PLAY_CTRL_E		
PLAY_CTRL_STOP	0x5	Stop playback

## 4.11 STRUCTURE

Table 4-1 :MV\_CFG\_T structure

Field	Type	Description
elnMediaType	MEDIA_TYPE_E	PLAY - indicae the type of media to be played
elnStrmType	STRM_TYPE_E	PLAY - indicae the input stream method
szIMFAscii	CHAR *	PLAY - if in stream type is MFL_STREAM_FILE

szInMetaFile	CHAR *	PLAY - if in stream type is MFL_STREAM_FILE
szlTFAscii	CHAR *	PLAY - if in stream type is MFL_STREAM_FILE
nAudioPlayVolume	INT	PLAY - volume of playback, 0~31, 31 is max.
uStartPlaytimePos	INT	PLAY - On MP3 playback start, just jump to a specific time offset then start playback. The time position unit is 1/100 seconds.
nAuABRScanFrameCnt	INT	PLAY - on playback, ask MFL scan how many leading frames to evaluate average bit rate. -1 means scan the whole file
ap_time	callback	callback
szInMediaFile	CHAR *	PLAY - if in stream type is MFL_STREAM_FILE

Table 4-2: MV\_INFO\_T structure

Field	Type	Description
uAuTotalFrames	UINT32	For playback, it's the total number of audio frames. For recording, it's the currently recorded frame number.
uPlayCurTimePos	UINT32	for playback, the play time position, in 1/100 seconds
uMovieLength	UINT32	in 1/100 seconds

## 4.12 FUNCTIONS

### *mflMediaPlayer*

#### Synopsis

INT `mflMediaPlayer(MV_CFG_T *ptMvCfg)`

#### Description

Start play MP3 file.

#### Parameter

ptMvCfg [in]

The MV\_CFG\_T structure

#### Return Value

Successful: Success

ERRCODE: Error

#### Example

`mflMediaPlayer(&_tMvCfg)`

mflGetMovieInfo

### ***mflGetMovieInfo***

#### **Synopsis**

INT mflGetMovieInfo(MV\_CFG\_T \*ptMvCfg, MV\_INFO\_T \*\*ptMvInfo)

#### **Description**

Get MP3 time information.

#### **Parameter**

ptMvCfg [in]

The MV\_CFG\_T structure

ptMvInfo [in/out]

The MV\_INFO\_T structure

#### **Return Value**

Successful: Success

ERRCODE: Error

#### **Example**

mflGetMovieInfo(ptMvCfg, &ptMvInfo)

mflPlayControl

### ***mflPlayControl***

#### **Synopsis**

INT mflPlayControl(MV\_CFG\_T \*ptMvCfg, PLAY\_CTRL\_E ePlayCtrl, INT nParam)

Description

Control operation while playing MP3 file.

#### **Parameter**

ptMvCfg [in]

The MV\_CFG\_T strcture

ePlayCtrl [in]

The PLAY\_CTRL\_E enumeration

nParam [in]

Reserved

#### **Return Value**

Successful: Success

ERRCODE: Error

**Example**

```
mflPlayControl(&_tMvCfg, PLAY_CTRL_STOP, 0)
```

## 5 BLT LIBRARY

### 5.1 OVERVIEW

This document is written for user applications which want to make use of BLT through provided API.

### 5.2 FEATURE

- Fill operation.
  - Fill color with alpha channel
- Blit operation
  - Transformation effects (Scaling, Rotation, Shearing, etc.) through 2x2 inverse transformation matrix.
  - Bitmap smoothing in bi-linear algorithm.
  - Tiling mode (for inversely mapped source pixels lying outside the boundaries of the source image)
    - ◆ No drawing
    - ◆ Clip to edge (closest edge pixel of the source image)
    - ◆ Repeat (source image repeated indefinitely in all directions)
  - Color transformation as defined in Adobe Flash
  - RGB565 color key
- Source format for Blit operation
  - ARGB8888
  - RGB565
  - Palette index with color ARGB8888
    - ◆ 1-bit, 2-bit, 4-bit, and 8-bit palette index
    - ◆ Endianness of palette index
- Destination format for Fill/Blit operation
  - ARGB8888
  - RGB555
  - RGB565

### 5.3 TRANSFORMATION MATRIX


In blit operation, transformation effects, such as scaling, rotation, translation, etc. can be achieved through a transformation matrix. These transformations can be combined into one and just one blit operation is needed to finish all the transformations. In the following, common transformations are listed, and user application can



combine them to achieve wanted result.

## Scaling


Resize the image by multiplying the location of each pixel by  $s_x$  on the x axis and  $s_y$  on the y axis.



$$\begin{pmatrix} x_d \\ y_d \\ 1 \end{pmatrix} = \begin{pmatrix} s_x & 0 & 0 \\ 0 & s_y & 0 \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} x_s \\ y_s \\ 1 \end{pmatrix}$$

## Rotation


Rotate the image by an angle  $\theta$  clockwise.



$$\begin{pmatrix} x_d \\ y_d \\ 1 \end{pmatrix} = \begin{pmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} x_s \\ y_s \\ 1 \end{pmatrix}$$

## Translation

Translate the image by  $t_x$  along the x axis and  $t_y$  along the y axis.



$$\begin{pmatrix} x_d \\ y_d \\ 1 \end{pmatrix} = \begin{pmatrix} 1 & 0 & t_x \\ 0 & 1 & t_y \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} x_s \\ y_s \\ 1 \end{pmatrix}$$

### Amendment to User Transformation Matrix

On mapping back from destination CS<sup>1</sup> to source CS, a mapping point of destination pixel must be taken into consideration. Mapping point can be top-left ([Top-left point as mapping point of destination pixel](#)) or center ([Center point as mapping point of destination pixel](#)). In the blit implementation, top-left point is chosen and we may encounter an error due to the choice of mapping point. To help explain the issue, an example is given: blit with rotate 180°.




Figure 5.3-1: Top-left point as mapping point of destination pixel

<sup>1</sup> Coordinate system.




Figure 5.3-2: Center point as mapping point of destination pixel

1. We want to blit **Source image** and get **Final** result, This blit operation involves rotation and translation applied to the source image.




Figure 5.3-3: Source image




Figure 5.3-4: Final

2. First, just copy without any transformation effect and get **No transform** result.




Figure 5.3-5: No transform

3. Rotate 180° clockwise and get Rotate 180o result.




Figure 5.3-6: Rotate 180°

4. Translate 3 along x-axis and 2 along y-axis and get Rotate 180o + Translate (3, 2) result. But actually, we will get incorrect Rotate 180o + Translate (3, 2) (2) result. It is because in the hardware implementation, the top-left point of a destination pixel is picked as the mapping point. Take D(0, 0) as an example. It will map to S(3, 2) instead of S(2, 1) which is actually what we want.




Figure 5.3-7: Rotate 180° + Translate (3, 2)




Figure 5.3-8: Rotate 180° + Translate (3, 2) (2)

5. To fix the issue, translate  $(-0.5, -0.5)$  to the end of all above transformations, and get Rotate 180° + Translate (3, 2) + Translate  $(-0.5, -0.5)$  result. And we finally get wanted Final result. In this case,  $D(0, 0)$  maps to  $S(2.5, 1.5)$ , and so the source (2, 1) pixel (magenta) is blitted on the destination (0, 0) pixel.




Figure 5.3-9: Rotate 180° + Translate (3, 2) + Translate (-0.5, -0.5)

## 5.4 PIXEL MAPPING

To use blit operation, think of pixel mapping in the inverse direction, that is, from destination CS to source CS. Fields associated with transformation matrix include:

- Elements a, b, c, and d in [S\\_DRVBLT\\_MATRIX](#).
- i32XOffset and i32YOffset in [S\\_DRVBLT\\_SRC\\_IMAGE](#).

Equations below give how these fields are associated with transformation matrix.

$$\begin{pmatrix} x_d \\ y_d \\ 1 \end{pmatrix} = \begin{pmatrix} s & t & t_x \\ u & v & t_y \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} x_s \\ y_s \\ 1 \end{pmatrix}$$

$$\begin{pmatrix} s & t & t_x \\ u & v & t_y \\ 0 & 0 & 1 \end{pmatrix}^{-1} \begin{pmatrix} x_d \\ y_d \\ 1 \end{pmatrix} = \begin{pmatrix} x_s \\ y_s \\ 1 \end{pmatrix}$$

$$\begin{vmatrix} a & b & i32XOffset \\ c & d & i32YOffset \\ 0 & 0 & 1 \end{vmatrix} = \begin{vmatrix} s & t & t_x \\ u & v & t_y \\ 0 & 0 & 1 \end{vmatrix}^{-1}$$

When a point is mapped from destination CS to source CS, there are several cases to consider. Below gives an example to help explain:

$$\begin{pmatrix} x_d \\ y_d \\ 1 \end{pmatrix} = \begin{pmatrix} 1 & 0 & -1 \\ 0 & 1 & -1 \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} x_s \\ y_s \\ 1 \end{pmatrix}$$

1. In M0, D(0, 0) (origin pixel of destination CS) is inversely mapped to S(1, 1), which needn't be

the origin pixel of the source image. D(0, 0) is filled with Red color.

2. In M1, D(1, 1) is inversely mapped to S(2, 2), which lies inside the source image. D(1, 1) is filled with Green color.
3. In M2, D(4, 2) is inversely mapped to S(5, 3), which lies outside the source image. Dependent on tiling mode specified in [E\\_DRVBLT\\_FILL\\_STYLE](#), there are 3 different rendering results:
  - 甲、No drawing: D(4, 2) is not drawn.
  - 乙、Clip to edge: D(4, 2) is inversely mapped to S(3, 3). D(4, 2) is filled with Blue color.
  - 丙、Repeat: Think of whole source CS as filled with source images and D(4, 2) is inversely mapped to S(5, 3), and then wraps to S(1, 3). D(4, 2) is filled with Yellow color.




Figure 5.4-1: Mapping from destination CS to source CS

## 5.5 COLOR TRANSFORMATION

In Blit operation, user application can decide to apply color transformation or not, which is defined by Adobe Flash and has the following formula. Besides, user application can further decide to apply the alpha channel only.

$$\text{New alpha value} = (\text{old alpha value} * \text{alphaMultiplier}) + \text{alphaOffset}$$

$$\text{New red value} = (\text{old red value} * \text{redMultiplier}) + \text{redOffset}$$

$$\text{New green value} = (\text{old green value} * \text{greenMultiplier}) + \text{greenOffset}$$

$$\text{New blue value} = (\text{old blue value} * \text{blueMultiplier}) + \text{blueOffset}$$

## 5.6 PALETTE

To use BLT palette, user must choose index size first. There are 4 index sizes (SFMT) supported:

- 1-bit index
- 2-bit index
- 4-bit index
- 8-bit index

After determination of index size, user then must set up two parts: palette entries and source image in palette index format, both of which will depend on index size.

### Palette entries

Palette ranges from BLT\_BA+0x400. Its format is ARGB8888, premultiplied-alpha by default and user can change it by setting up the field SET2DA.S\_ALPHA.

For n-bit index size where n can only be 1, 2, 4, or 8, user must prepare 2 to the power of n (2, 4, 16, or 256 respectively) palette entries. Take n=2 for example, user must fill in 4 palette entries in the range, BLT\_BA+0x400~BLT\_BA+0x400+3 words.

### Source image in palette index format

To specify source image in palette index format is the same as in other formats: pixel format (SFMT), start address (SADDR), width (SWIDTH), height (SEIGHT), stride (SSTRIDE). Note stride must be word-aligned. If palette index is not 8-bit, index order in one byte image data must be taken into consideration.

For example,

One byte in image data=b7b6b5b4b3b2b1b0

Index size=2-bit

Index order=big-endian (SET2DA.L\_ENDIAN=0) →

b7b6=1<sup>st</sup> pixel, b5b4=2<sup>nd</sup> pixel, b3b2=3<sup>rd</sup> pixel, b1b0=4<sup>th</sup> pixel

Index order=little-endian (SET2DA.L\_ENDIAN=1) →

b7b6=4<sup>th</sup> pixel, b5b4=3<sup>rd</sup> pixel, b3b2=2<sup>nd</sup> pixel, b1b0=1<sup>st</sup> pixel

## 5.7 API DATA STRUCTURE

### ***E\_BLT\_INT\_TYPE***

Interrupt type.

Name	Value	Description
BLT_INT_CMPLT	1	Fill/Blit operation completed

### ***E\_DRVBLT\_FILLOP***

Fill or Blit operation.

Name	Value	Description
------	-------	-------------



eDRVBLT_DISABLE	0	Blit operation
eDRVBLT_ENABLE	1	Fill operation

### ***E\_DRVBLT\_REVEAL\_ALPHA***

Premultiplied alpha or not for source format of ARGB8888

Name	Value	Description
eDRVBLT_EFFECTIVE	0	Premultiplied alpha
eDRVBLT_NO_EFFECTIVE	1	Non-premultiplied alpha

### ***E\_DRVBLT\_TRANSFORM\_FLAG***

Transform flags for Blit operation.

Color transformation formula applied when eDRVBLT\_HASCOLORTRANSFORM specified:

New alpha value = (old alpha value \* alphaMultiplier) + alphaOffset

New red value = (old red value \* redMultiplier) + redOffset

New green value = (old green value \* greenMultiplier) + greenOffset

New blue value = (old blue value \* blueMultiplier) + blueOffset

Alpha-only color transformation formula applied when both eDRVBLT\_HASCOLORTRANSFORM and eDRVBLT\_HASALPHAONLY specified:

New alpha value = (old alpha value \* alphaMultiplier) + alphaOffset

Name	Value	Description
eDRVBLT_NONTRANSPARENCYE	0	No per-pixel transparency in the source.
eDRVBLT_HASTRANSARENCY	1	Has per-pixel transparency in the source.
eDRVBLT_HASCOLORTRANSFORM	2	Apply color transformation formula.
eDRVBLT_HASALPHAONLY	4	If color transformation enabled, just apply the alpha-only formula.

### ***E\_DRVBLT\_BMPixel\_FORMAT***

Source format for Blit operation.

If eDRVBLT\_SRC\_ARGB8888/palette index, source/palette color can be RGB888 or ARGB8888 dependent on [E\\_DRVBLT\\_TRANSFORM\\_FLAG](#).

Name	Value	Description
eDRVBLT_SRC_ARGB8888	1	RGB888/ARGB8888
eDRVBLT_SRC_RGB565	2	RGB565
eDRVBLT_SRC_1BPP	4	1-bit palette index

eDRVBLT_SRC_2BPP	8	2-bit palette index
eDRVBLT_SRC_4BPP	16	4-bit palette index
eDRVBLT_SRC_8BPP	32	8-bit palette index

### ***E\_DRVBLT\_DISPLAY\_FORMAT***

Destination format for Fill/Blit operation.

Name	Value	Description
eDRVBLT_DEST_ARGB8888	1	ARGB8888
eDRVBLT_DEST_RGB565	2	RGB565
eDRVBLT_DEST_RGB555	4	RGB555

### ***E\_DRVBLT\_FILL\_STYLE***

Other flags for Blit operation.

eDRVBLT\_CLIP\_TO\_EDGE/eDRVBLT\_NONE\_FILL specify how to behave when reverse mapping doesn't fall in the range of source bitmap.

Name	Value	Description
eDRVBLT_CLIP_TO_EDGE	1	The bitmap should be clipped to its edges, otherwise a repeating texture.
eDRVBLT_NOTSMOOTH	2	The bitmap should not be smoothed
eDRVBLT_NONE_FILL	4	Neither clip to edge nor repeating texture

### ***E\_DRVBLT\_PALETTE\_ORDER***

Palette index in big-endian or little-endian.

Name	Value	Description
eDRVBLT_BIG_ENDIAN	0	Palette index in big endian
eDRVBLT_LITTLE_ENDIAN	1	Palette index in little endian

### ***S\_DRVBLT\_MATRIX***

Transformation matrix used in inverse mapping.

Name	Type	Description
a	INT32	

b	INT32	
c	INT32	
d	INT32	

### ***S\_DRVBLT\_ARGB16***

Multiplier/offset of A, R, G, and B channels used in color transformation.

Name	Type	Description
i16Blue	INT16	Color multiplier/offset of blue channel
i16Green	INT16	Color multiplier/offset of green channel
i16Red	INT16	Color multiplier/offset of red channel
i16Alpha	INT16	Color multiplier/offset of alpha channel

### ***S\_DRVBLT\_ARGB8***

ARGB8888 color

Name	Type	Description
u8Blue	UINT8	Value of blue channel
u8Green	UINT8	Value of green channel
u8Red	UINT8	Value of red channel
u8Alpha	UINT8	Value of alpha channel

### ***S\_DRVBLT\_SRC\_IMAGE***

Source image.

Name	Type	Description
u32SrcImageAddr	UINT32	Source image start address
i32Stride	INT32	Source image's stride in bytes
i32XOffset	INT32	X offset into the source to start rendering from
i32YOffset	INT32	Y offset into the source to start rendering from
i16Width	INT16	Source image's width in pixels
i16Height	INT16	Source image's height in pixels

### ***S\_DRVBLT\_DEST\_FB***

Destination buffer.

Name	Type	Description
u32FrameBufAddr	UINT32	Destination buffer address to start rendering to
i32XOffset	INT32	No use
i32YOffset	INT32	No use
i32Stride	INT32	Destination buffer's stride in bytes
i16Width	INT16	Destination buffer's width in pixels
i16Height	INT16	Destination buffer's height in pixels

## 5.8 API FUNCTION

### ***bltOpen***

#### **Synopsis**

```
ERRCODE bltOpen(void);
```

#### **Description**

Initialize BLT and install interrupt service routine.

#### **Parameter**

None

#### **Return Value**

E_SUCCESS	Success
-----------	---------

### ***bltClose***

#### **Synopsis**

```
void bltClose(void);
```

#### **Description**

Tear down BLT.

#### **Parameter**

None

#### **Return Value**

None

### ***bltSetTransformMatrix***

#### Synopsis

```
void bltSetTransformMatrix(S_DRVBLT_MATRIX sMatrix);
```

#### Description

Set up inverse transformation matrix.

#### Parameter

sMatrix Transformation matrix as defined in [S\\_DRVBLT\\_MATRIX](#).

#### Return Value

None

### ***bltGetTransformMatrix***

#### Synopsis

```
void bltGetTransformMatrix(S_DRVBLT_MATRIX *psMatrix);
```

#### Description

Retrieve inverse transformation matrix which has set up.

#### Parameter

psMatrix User-prepared buffer to save read-back transformation matrix as defined in [S\\_DRVBLT\\_MATRIX](#).

#### Return Value

None

### ***bltSetSrcFormat***

#### Synopsis

```
ERRCODE bltSetSrcFormat (E_DRVBLT_BMPixel_FORMAT eSrcFmt);
```

#### Description

Set up source format.

#### Parameter

eSrcFmt Source format as defined in [E\\_DRVBLT\\_BMPixel\\_FORMAT](#).

#### Return Value

E_SUCCESS	Success
ERR_BLT_INVALID_SRCFMT	Invalid source format

### ***bltGetSrcFormat***

**Synopsis**

```
E_DRVBLT_BMPIXEL_FORMAT bltGetSrcFormat(void);
```

**Description**

Retrieve source format which has set up.

**Parameter**

None

**Return Value**

Source format as defined in [E\\_DRVBLT\\_BMPIXEL\\_FORMAT](#).

***bltSetDisplayFormat***

**Synopsis**

```
ERRCODE bltSetDisplayFormat(E_DRVBLT_DISPLAY_FORMAT  
eDisplayFmt);
```

**Description**

Set up destination format.

**Parameter**

eDisplayFmt	Destination	format	defined	in
<a href="#">E_DRVBLT_DISPLAY_FORMAT</a> .				

**Return Value**

E_SUCCESS	Success
ERR_BLT_INVALID_DSTFMT	Invalid destination format

***bltGetDisplayFormat***

**Synopsis**

```
E_DRVBLT_DISPLAY_FORMAT bltGetDisplayFormat(void);
```

**Description**

Retrieve destination format which has set up.

**Parameter**

None

**Return Value**

Destination format as defined in [E\\_DRVBLT\\_DISPLAY\\_FORMAT](#).

***bltEnableInt***

### Synopsis

```
void bltEnableInt(E_BLT_INT_TYPE eIntType);
```

### Description

Enable specified interrupt type.

### Parameter

eIntType                      Interrupt type as defined in [E\\_BLT\\_INT\\_TYPE](#).

### Return Value

None

## ***bltDisableInt***

### Synopsis

```
void bltDisableInt(E_BLT_INT_TYPE eIntType);
```

### Description

Disable specified interrupt type.

### Parameter

eIntType                      Interrupt type as defined in [E\\_BLT\\_INT\\_TYPE](#).

### Return Value

None

## ***bltIsIntEnabled***

### Synopsis

```
BOOL bltIsIntEnabled (E_BLT_INT_TYPE eIntType);
```

### Description

Query if the specified interrupt type is enabled.

### Parameter

eIntType                      Interrupt type as defined in [E\\_BLT\\_INT\\_TYPE](#).

### Return Value

TRUE	Specified interrupt enabled
FALSE	Specified interrupt disabled

## ***bltPollInt***

### Synopsis

```
BOOL bltPollInt(E_BLT_INT_TYPE eIntType);
```

**Description**

Query interrupt status of the specified interrupt type.

**Parameter**

eIntType                      Interrupt type as defined in [E\\_BLT\\_INT\\_TYPE](#).

**Return Value**

TRUE                              Specified interrupt type active.  
FALSE                              Specified interrupt type inactive.

***bltInstallCallback***

**Synopsis**

```
void bltInstallCallback (E_BLT_INT_TYPE eIntType, PFN_BLT_CALLBACK  
pfnCallback, PFN_BLT_CALLBACK* pfnOldCallback);
```

**Description**

Install callback function invoked on interrupt generated.

**Parameter**

eIntType                      Interrupt type as defined in [E\\_BLT\\_INT\\_TYPE](#).  
pfnCallback                      New callback function to install. NULL to  
uninstall.  
pfnOldCallback                      User-prepared buffer to save previously  
installed callback function.

**Return Value**

None

***bltSetColorMultiplier***

**Synopsis**

```
void bltSetColorMultiplier(S_DRVBLT_ARGB16 sARGB16);
```

**Description**

Set up color multipliers of A, R, G, and B channels for color transformation.

**Parameter**

sARGB16                      Color multipliers of A, R, G, and B channels as defined  
in [S\\_DRVBLT\\_ARGB16](#).

**Return Value**

None



### ***bltGetColorMultiplier***

#### **Synopsis**

```
void bltGetColorMultiplier(S_DRVBLT_ARGB16* psARGB16);
```

#### **Description**

Retrieve color multipliers of A, R, G, and B channels which has set up.

#### **Parameter**

psARGB16                                      User-prepared buffer to save color multipliers of A, R, G, and B channels as defined in [S\\_DRVBLT\\_ARGB16](#).

#### **Return Value**

None

### ***bltSetColorOffset***

#### **Synopsis**

```
void bltSetColorOffset(S_DRVBLT_ARGB16 sARGB16);
```

#### **Description**

Set up color offsets of A, R, G, and B channels for color transformation.

#### **Parameter**

sARGB16                                      Color offsets of A, R, G, and B channels as defined in [S\\_DRVBLT\\_ARGB16](#).

#### **Return Value**

None

### ***bltGetColorOffset***

#### **Synopsis**

```
void bltGetColorOffset(S_DRVBLT_ARGB16* psARGB16);
```

#### **Description**

Retrieve color offsets of A, R, G, and B channels which has set up.

#### **Parameter**

psARGB16                                      User-prepared buffer to save color offsets of A, R, G, and B channels as defined in [S\\_DRVBLT\\_ARGB16](#).

#### **Return Value**

None

### ***bltSetSrcImage***

#### **Synopsis**

```
void bltSetSrcImage(S_DRVBLT_SRC_IMAGE sSrcImage);
```

#### **Description**

Set up source image..

#### **Parameter**

sSrcImage                      Source              image              as              defined              in  
[S\\_DRVBLT\\_SRC\\_IMAGE](#).

#### **Return Value**

None

### ***bltSetDestFrameBuf***

#### **Synopsis**

```
void bltSetDestFrameBuf(S_DRVBLT_DEST_FB sFrameBuf);
```

#### **Description**

Set up destination buffer..

#### **Parameter**

sFrameBuf                      Destination              buffer              as              defined              in  
[S\\_DRVBLT\\_DEST\\_FB](#).

#### **Return Value**

None

### ***bltSetARGBFillColor***

#### **Synopsis**

```
void bltSetARGBFillColor(S_DRVBLT_ARGB8 sARGB8);
```

#### **Description**

Set up fill color for Fill operation, which can be ARGB8888 or RGB888 dependent on [bltSetFillAlpha](#).

#### **Parameter**

sARGB8                      Fill color as defined in [S\\_DRVBLT\\_ARGB8](#).

#### **Return Value**

None

#### **Note**

If ARGB8888, it must be in non-premultiplied alpha format.

### ***bltGetARGBFillColor***

#### **Synopsis**

```
void bltGetARGBFillColor(S_DRVBLT_ARGB8* psARGB8 );
```

#### **Description**

Retrieve ARGB8888 color for Fill operation which has set up.

#### **Parameter**

psARGB8	User-prepared buffer to save read-back ARGB8888
color for Fill operation.	

#### **Return Value**

None

### ***bltGetBusyStatus***

#### **Synopsis**

```
BOOL bltGetBusyStatus(void);
```

#### **Description**

Query if Fill/Blit operation is busy.

#### **Parameter**

None

#### **Return Value**

TRUE	Busy
FALSE	Free

### ***bltSetFillAlpha***

#### **Synopsis**

```
void bltSetFillAlpha(BOOL bEnable);
```

#### **Description**

Set up whether or not fill color's alpha channel is in effect.

#### **Parameter**

bEnable	
TRUE	Fill color is ARGB8888
FALSE	Fill color is RGB888

**Return Value**

None

***bltGetFillAlpha***

**Synopsis**

BOOL bltGetFillAlpha(void);

**Description**

Retrieve whether or not fill color's alpha channel is in effect which has set up.

**Parameter**

None

**Return Value**

TRUE	Fill color is ARGB8888.
FALSE	Fill color is RGB888

***bltSetTransformFlag***

**Synopsis**

void bltSetTransformFlag(UINT32 u32TransFlag);

**Description**

Set up transform flag.

**Parameter**

U32TransFlag                      Transform      flag      as      defined      in  
[E\\_DRVBLT\\_TRANSFORM\\_FLAG](#).

**Return Value**

None

***bltGetTransformFlag***

**Synopsis**

UINT32 bltGetTransformFlag(void);

**Description**

Retrieve transform flag which has set up.

**Parameter**

None.

**Return Value**

Transform flag as defined in [E\\_DRVBLT\\_TRANSFORM\\_FLAG](#).

***bltSetPaletteEndian***

## Synopsis

```
void bltSetPaletteEndian(E_DRVBLT_PALETTE_ORDER eEndian);
```

### Description

Set up endianness of palette index..

### Parameter

eEndian                      Endianness of palette index as defined in  
E\_DRVBLT\_PALETTE\_ORDER.

## Return Value

None

***bltGetPaletteEndian***

## Synopsis

```
E_DRVBLT_PALETTE_ORDER bltGetPaletteEndian(void);
```

### Description

Retrieve endianness of palette index which has set up.

### Parameter

None

## Return Value

Endianness of palette index as defined in [E\\_DRVBLT\\_PALETTE\\_ORDER](#).

## ***bltSetColorPalette***

## Synopsis

```
void bltSetColorPalette(UINT32 u32PaletteIdx, UINT32 u32Num,
S_DRVBLT_ARGB8 *psARGB);
```

### Description

Set up palette's colors.

### Parameter

u32PaletteIdx	Index of palette to start to set up
u32Num	Number of colors to set up
psARGB	ARGB8888 colors

## None

## Synopsis

```
void bltSetFillOP(E_DRVBLT_FILLOP eOP);
```

Set up operation to be Fill or Blit.

eOP

Operation as defined in [E DRVBLT FILLOP](#).

## None

## Synopsis

BOOL bltGetFillOP(void);

Retrieve operation which has set up..

## None

TRUE

Fill operation.

FALSE

## Blit operation

## Synopsis

```
void bltSetFillStyle(E_DRVBLT_FILL_STYLE eStyle);
```

Set up other flags for Blit operation.

## eStyle

eStyle Other flags as defined in  
E\_DRVBLT\_FILL\_STYLE.

## V1.0

None

## ***bltGetFillStyle***

## Synopsis

```
E_DRVBLT_FILL_STYLE bltGetFillStyle(void);
```

### Description

Retrieve other flags for Blit operation which has set up.

### Parameter

None

## Return Value

Other flags as defined in [E\\_DRVBLT\\_FILL\\_STYLE](#).

## ***bltSetRevealAlpha***

## Synopsis

```
void bltSetRevealAlpha(E_DRVBLT_REVEAL_ALPHA eAlpha);
```

### Description

Set up premultiplied alpha or not for source format of ARGB8888

### Parameter

eAlpha Premultiplied alpha or not as specified in  
E\_DRVBLT\_REVEAL\_ALPHA

## Return Value

None

## ***bltGetRevealAlpha***

## Synopsis

BOOL bltGetRevealAlpha(void);

### Description

Retrieve premultiplied alpha or not for source format of ARGB8888.

### Parameter

None

## Return Value

Premultiplied alpha or not as specified in [E\\_DRVBLT\\_REVEAL\\_ALPHA](#)

***bltTrigger***

## Synopsis

```
void bltTrigger(void);
```

### Description

Start Fill/Blit operation..

### Parameter

None

### Return Value

None

## ***bltSetRGB565TransparentColor***

## Synopsis

```
void bltSetRGB565TransparentColor(UINT16 u16RGB565);
```

### Description

### Set up transparent color for source format of RGB565 for color key enabled

### Parameter

u16RGB565	RGB565 to be transparent color
-----------	--------------------------------

### Return Value

None

### ***bltGetRGB565TransparentColor***

## Synopsis

UINT16 bltGetRGB565TransparentColor(void);

## Description

Retrieve transparent color which has set up..

## Parameter

None

## Return Value

RGB565 to be transparent color

***bltSetRGB565TransparentCtl***

## Synopsis



```
void bltSetRGB565TransparentCtl(BOOL bEnable);
```

#### Description

Enable color key or not.

#### Parameter

bEnable

TRUE	Enable color key
FALSE	Disable color key

#### Return Value

None

### ***bltGetRGB565TransparentCtl***

#### Synopsis

```
BOOL bltGetRGB565TransparentCtl(void);
```

#### Description

Retrieve color key enabled or not.

#### Parameter

None

#### Return Value

TRUE	Color key enabled
FALSE	Color key disabled

### ***bltFlush***

#### Synopsis

```
void bltFlush(void);
```

#### Description

Wait for Fill/Blit operation to complete.

#### Parameter

None

#### Return Value

None

## 5.9 ERROR CODE TABLE

Code Name	Value	Description
Successful	0	Success
ERR_BLT_INVALID_INT	BLT_ERR_ID   0x01	Invalid interrupt type
ERR_BLT_INVALID_SRCFMT	BLT_ERR_ID   0x02	Invalid source format
ERR_BLT_INVALID_DSTFMT	BLT_ERR_ID   0x03	Invalid destination format

## 6 CRC LIBRARY

### 6.1 OVERVIEW

The cyclic redundancy check (CRC) generator can perform CRC calculation with programmable polynomial settings. It supports CPU PIO mode directly and can use the VDMA function to get the data.

### 6.2 FEATURE

- Supports four common polynomials CRC-CCITT, CRC-8, CRC-16, and CRC-32
  - CRC-CCITT:  $X^{16} + X^{12} + X^5 + 1$
  - CRC-8:  $X^8 + X^2 + X + 1$
  - CRC-16:  $X^{16} + X^{15} + X^2 + 1$
  - CRC-32:  $X^{32} + X^{26} + X^{23} + X^{22} + X^{16} + X^{12} + X^{11} + X^{10} + X^8 + X^7 + X^5 + X^4 + X^2 + X + 1$
- Programmable seed value
- Supports programmable order reverse setting for input data and CRC checksum
- Supports programmable 1's complement setting for input data and CRC checksum.
- Supports 8/16/32-bit of data width in CPU PIO mode
  - 8-bit write mode: 1-AHB clock cycle operation
  - 16-bit write mode: 2-AHB clock cycle operation
  - 32-bit write mode: 4-AHB clock cycle operation
- Two CRC channels

### 6.3 API DATA STRUCTURE

#### ***E\_CRC\_CHANNEL\_INDEX***

CRC channel index.

Name	Value	Description
E_CHANNEL_0	0	CRC channel 0
E_CHANNEL_1	1	CRC channel 1

#### ***E\_CRC\_OPERATION***

CRC channel operation.

Name	Value	Description
E_CH_DISABLE	0	CRC channel disable
E_CH_ENABLE	1	CRC channel enable

### ***E\_CRC\_MODE***

CRC polynomials.

Name	Value	Description
E_CRCCITT	0	CRC-CCITT polynomial
E_CRC8	1	CRC-8 polynomial
E_CRC16	2	CRC-16 polynomial
E_CRC32	3	CRC-32 polynomial

### ***E\_WRITE\_LENGTH***

CRC data width in CPU PIO mode, VDMA mode only supports 32-bit write mode.

Name	Value	Description
E_LENGTH_BYTE	0	8-bit write mode
E_LENGTH_HALF_WORD	1	16-bit write mode
E_LENGTH_WORD	2	32-bit write mode

### ***E\_DATA\_1sCOM***

1's complement setting for input data and CRC checksum.

Name	Value	Description
E_1sCOM_OFF	0	1's complement disable
E_1sCOM_ON	1	1's complement enable

### ***E\_DATA\_REVERSE***

Order reverse setting for input data and CRC checksum.

Name	Value	Description
E_REVERSE_OFF	0	Order reverse disable
E_REVERSE_ON	1	Order reverse enable

### ***E\_TRANSFER\_MODE***

CRC CPU PIO or VDMA mode.

Name	Value	Description
E_CRC_CPU_PIO	0	CRC CPU PIO mode
E_CRC_VDMA	1	CRC VDMA mode

### ***S\_CRC\_CHANNEL\_INFO***

CRC channel information.

Name	Type	Description
blnRequest	BOOL	CRC channel is in request or not
blnUse	BOOL	CRC channel is in use or not

### ***S\_CRC\_DESCRIPTOR\_SETTING***

CRC channel description of a calculation.

Name	Type	Description
ePolyMode	E_CRC_MODE	CRC polynomials
eWriteLength	E_WRITE_LENGTH	Data width of write modes
eChecksumCom	E_DATA_1sCOM	1's Complement setting for checksum
eWdataCom	E_DATA_1sCOM	1's Complement setting for input data
eChecksumRvs	E_DATA_REVERSE	order reverse setting for checksum
eWdataRvs	E_DATA_REVERSE	order reverse setting for input data
eTransferMode	E_TRANSFER_MODE	CRC run in CPU PIO or VDMA mode
uSeed	UINT32	CRC seed value

## **6.4 API FUNCTION**

### ***CRC\_Init***

#### **Synopsis**

```
INT32 CRC_Init(void);
```

#### **Description**

Initialize the software resource of CRC driver, call EDMA\_Init to initialize VDMA

and enable interrupt.

**Parameter**

None

**Return Value**

Successful

Always returns Successful

**CRC\_Exit**

**Synopsis**

void CRC\_Exit(void);

**Description**

Clear CRC initial flag.

**Parameter**

None

**Return Value**

None

**CRC\_Request**

**Synopsis**

INT32 CRC\_Request(INT32 channel);

**Description**

Specify a channel for request.

**Parameter**

channel

CRC channel number

**Return Value**

Successful

Specified channel is requested

CRC\_ERR\_INVALID Specified channel number is invalid

CRC\_ERR\_BUSY Specified channel is busy

**CRC\_Free**

**Synopsis**

void CRC\_Free(INT32 channel);

**Description**

Release a previously acquired channel.

**Parameter**

channel	CRC channel number
---------	--------------------

**Return Value**

None

***CRC\_FindandRequest***
**Synopsis**

```
INT32 CRC_FindandRequest(void);
```

**Description**

Try to find a free channel and request it.

**Parameter**

None

**Return Value**

Successful	Allocated channel is returned
CRC_ERR_NODEV	No free channel is found

***CRC\_Run***
**Synopsis**

```
UINT32 CRC_Run(INT32 channel, UINT8 *pDataBuf, UINT32 uDataLen,  
S_CRC_DESCRIPTOR_SETTING *psCRCDescript);
```

**Description**

Start to run a CRC calculation and wait for its finish.

**Parameter**

channel	CRC channel number
pDataBuf	Input buffer address
uDataLen	Length of input buffer in bytes
psCRCDescript calculation	Pointer to the channel description of this CRC calculation

**Return Value**

Successful	CRC checksum is returned
CRC_ERR_STATUS	Channel is not in request
CRC_ERR_BUSY	Channel is in use and cannot run a calculation

## 6.5 ERROR CODE TABLE

Code Name	Value	Description
Successful	0	Success
CRC_ERR_INVALID	CRC_ERR_ID   0x01	Channel number is invalid
CRC_ERR_NODEV	CRC_ERR_ID   0x02	No free channel is found
CRC_ERR_STATUS	CRC_ERR_ID   0x03	Channel status is wrong
CRC_ERR_BUSY	CRC_ERR_ID   0x04	Channel is busy



## 7 EDMA LIBRARY

### 7.1 OVERVIEW

This library is designed to make user application to set N9H26 EDMA more easily.

The EDMA library has the following features:

- Support color space transforms (RGB565, RGB555, RGB888 and YUV422) for VDMA.
- Support transfers data to and from memory or transfer data to and from APB.
- Support hardware Scatter-Gather function.

### 7.2 PROGRAMMING GUIDE

#### System Overview

The N9H26 contains an enhanced direct memory access (EDMA) controller that transfers data to and from memory or transfers data to and from APB. The EDMA controller has 11-channel DMA that include 3 channel VDMA (Video-DMA, Memory-to-Memory) and 8 channels PDMA (Peripheral-to-Memory or Memory-to-Peripheral). For channel 0/5/8 VDMA mode, it also supports color format transform and stride mode transfer. For PDMA channel (EDMA CH1~CH4, CH9~CH12), it can transfer data between the Peripherals APB IP (ex: UART, SPI, ADC....) and Memory. The N9H26 also supports hardware scatter-gather function, software can set CSRx [SG\_EN] to enable scatter-gather function.


Software can stop the EDMA operation by disable DMA [DMACEN]. The CPU can recognize the completion of an EDMA operation by software polling or when it receives an internal EDMA interrupt. The N9H26 VDMA controller can increment source or destination address, decrement or fixed them as well, and the PDMA can increment source or destination, fixed or wrap around address.

#### EDMA Features

- AMBA AHB master/slave interface compatible, for data transfer and register read/write.
- Support packaging format color space transforms (RGB565, RGB555, RGB888 and YUV422) for VDMA.
- Support stride mode transfer mode for VDMA.
- VDMA support 32-bit source and destination addressing range, address increment, decrement and fixed.
- PDMA support 32-bit source and destination addressing range address increment, fixed and wrap around.
- Support hardware Scatter-Gather function.

#### Block Diagram

The following figure describes the architecture of EDMA.



## EDMA Control

### VDMA Transfer

The main purpose of VDMA channel is to perform a memory-to-memory transfer. Besides the pure memory copy, it also provides the color format transformation in packet during the transfer.

Software must enable DMA channel DMA [DMACEN] and then write a valid source address to the DMA\_SARx register, a destination address to the DMA\_DARx register, and a transfer count to the DMA\_BCRx register. Next, trigger the DMA\_CSRx [Trig\_EN]. If the source address and destination are not in wrap around mode, the transfer will start transfer until DMA\_CBCRx reaches zero (in wrap around mode, when DMA\_CBCRx equal zero, the DMA will reload DMA\_CBCRx and work around until software disable DMA\_CSRx [DMACEN]). If an error occurs during the EDMA operation, the channel stops unless software clears the error condition, sets the DMA\_CSRx [SW\_RST] to reset the EDMA channel and set EDMA\_CSRx [EDMACEN] and [Trig\_EN] bits field to start again.

### PDMA Transfer

The PDMA is used to transfer data between SDRAM and APB device. Currently, the APB device only supports UART 0/1, SPIMS 0/1 and ADC audio recording. The data direction can be from APB device or to APB device

dependent on the setting of PDMA\_CSRx[MODE\_SEL]. Hardware IP will do the necessary handshaking signal between PDMA and APB device.

In the PDMA transfer, the APB device data port should be set as the source or destination address dependent on the setting of PDMA\_CSRx[MODE\_SEL], and the address direction must be set as fixed for APB address. Besides this, the APB device has corresponding register setting to enable PDMA transfer.


Below table lists the control register and control bit for it.

APB IP	Control Register	Control Bits
Uart 0/1	UA_IER (UA_BA0/1+0x04)	DMA_Tx_En and DMA_Rx_En
SPI0/1	SPI0/1_EDMA	EDMA_RW and EDMA_GO
ADC	AGCP1	EDMA_MODE

Moreover, the EDSSR register in global control is necessary to notice. The PDMA cannot use the same channel selection in it when PDMA is set.

## Scatter Gather Transfer

The N9H26 also supports hardware scatter-gather function, software can set DMA\_CSRx [SG\_EN] to enable scatter-gather function. When in scatter-gather function mode, some register will be automatically updated by descriptor table. The descriptor table format is show as following:



The field definition of scatter table is as below:

- Physical Source Address (32 bits)
- Physical Destination Address (32 bits)
- Byte Count : Transfer Byte Count (17 bits)
- Stride Transfer Byte Count (15 bits)

- EOT : End of Table (1 bit)
- Source Offset Byte Length (15 bits)
- Oder : Scatter Gather table in Link list mode or not (1 bit)
- Destination Offset Byte length (15 bits)
- Next Scatter Gather Table Address (32 bits)

Note : only when in stride transfer mode (CTCSR[Stride\_EN]=1), Stride Transfer Byte count, Source Offset Byte length and Destination Offset Byte Length is meaningful

## 7.3 APIS SPECIFICATION FUNCTIONS

### ***EDMA\_Init***

#### **Synopsis**

```
int EDMA_Init(void)
```

#### **Description**

This function initializes the software resource.

#### **Parameter**

None

#### **Return Value**

0 Always successes

#### **Example**

```
EDMA_Init ();
```

### ***EDMA\_Exit***

#### **Synopsis**

```
void EDMA_Exit(void)
```

#### **Description**

Disable EDMA engine clock.

#### **Parameter**

None

#### **Return Value**

None

#### **Example**

```
EDMA_Exit ();
```

### ***EDMA\_Enable***

#### **Synopsis**

```
void EDMA_Enable(int channel)
```

#### **Description**

This function is used to start EDMA channel operation.

#### **Parameter**

channel	EDMA channel number
---------	---------------------

#### **Return Value**

None

#### **Example**

```
EDMA_Enable (0);
```

### ***EDMA\_Disable***

#### **Synopsis**

```
void EDMA_Disable(int channel)
```

#### **Description**

This function is used to stop EDMA channel operation.

#### **Parameter**

channel	EDMA channel number
---------	---------------------

#### **Return Value**

None

#### **Example**

```
EDMA_Disable (0);
```

### ***EDMA\_Request***

#### **Synopsis**

```
int EDMA_Request(int channel)
```

#### **Description**

This function is used to allocate specified channel number.

**Parameter**

channel	EDMA channel number
---------	---------------------

**Return Value**

SUCCESS	Allocation channel is returned.
---------	---------------------------------

FAIL	< 0 is returned.
------	------------------

EDMA\_ERR\_BUSY : specified channel is busy.

EDMA\_ERR\_INVALID : specified channel is greater than the maximum number of channels.

**Example**

```
EDMA_Request (0);
```

***VDMA\_FindandRequest***
**Synopsis**

```
int VDMA_FindandRequest(void)
```

**Description**

This function tries to find a free channel in the specified priority group.

**Parameter**

None

**Return Value**

SUCCESS	Allocation channel is returned.
---------	---------------------------------

FAIL	EDMA_ERR_NODEV is returned.
------	-----------------------------

**Example**

```
int g_VdmaCh;
g_VdmaCh = VDMA_FindandRequest ();
```

***PDMA\_FindandRequest***
**Synopsis**

```
int PDMA_FindandRequest(void)
```

**Description**

This function tries to find a free channel in the specified priority group.

**Parameter**

None

**Return Value**

SUCCESS	Allocation channel is returned.
FAIL	EDMA_ERR_NODEV is returned.

**Example**

```
int g_PdmaCh;
g_PdmaCh = PDMA_FindandRequest ();
```

**EDMA\_SetupHandlers**
**Synopsis**

```
int EDMA_SetupHandlers(int channel, int interrupt,
PFN_DRVEDMA_CALLBACK irq_handler, void *data)
```

**Description**

This function is used to setup EDMA channel notification handlers.

**Parameter**

channel	EDMA channel number
interrupt	EDMA interrupt enable
irq_handler	The callback function pointer for specified EDMA channel .
data	User specified value to be passed to the handlers.

**Return Value**

SUCCESS	0 is returned.
FAIL	EDMA_ERR_NODEV is returned.

**Example**

```
/* Install Callback function */
EDMA_SetupHandlers(0, eDRVEDMA_BLKD_FLAG, EdmaIrqHandler, 0);
```

**EDMA\_SetupSingle**
**Synopsis**

```
int EDMA_SetupSingle(int channel, unsigned int src_addr, unsigned int
dest_addr, unsigned int dma_length)
```

**Description**

This function is used to setup EDMA channel for linear memory to/from device transfer.

**Parameter**

channel	EDMA channel number
src_addr	Source address
dest_addr	Destination address
dma_length	Length of the transfer request in bytes

**Return Value**

SUCCESS	0 is returned.
FAIL	< 0 is returned.
	EDMA_ERR_BUSY : specified channel is busy.
	EDMA_ERR_INVALID : null address or zero length.

**Example**

```
EDMA_SetupSingle (0, SRC_ADDR, DEST_ADDR, 0x10000);
```

**EDMA\_Free**

**Synopsis**

```
void EDMA_Free(int channel)
```

**Description**

This function is used to release previously acquired channel.

**Parameter**

Channel	EDMA channel number
---------	---------------------

**Return Value**

None

**Example**

```
EDMA_Free (0);
```

**EDMA\_SetupSG**

**Synopsis**

```
int EDMA_SetupSG(int channel, unsigned int src_addr, unsigned int dest_addr, unsigned int dma_length)
```

**Description**



This function is used to setup EDMA channel SG list.

**Parameter**

channel	EDMA channel number
src_addr	Source address
dest_addr	Destination address
length	Total length of the transfer request in bytes

**Return Value**

SUCCESS	0 is returned.
FAIL	< 0 is returned.
	EDMA_ERR_BUSY : specified channel is busy.
	EDMA_ERR_INVALID : zero length or address is not PAGE_SIZE alignment.

**Example**

```
EDMA_SetupSG (0, SRC_ADDR, DEST_ADDR, 0x10000);
```

**EDMA\_FreeSG**
**Synopsis**

```
void EDMA_FreeSG(int channel)
```

**Description**

This function is used to release previously acquired channel SG list.

**Parameter**

Channel	EDMA channel number
---------	---------------------

**Return Value**

None

**Example**

```
EDMA_FreeSG (0);
```

**EDMA\_SetupCST**
**Synopsis**

```
int EDMA_SetupCST(int channel, E_DRVEDMA_COLOR_FORMAT  
eSrcFormat, E_DRVEDMA_COLOR_FORMAT eDestFormat)
```

**Description**

This function is used to setup EDMA channel for color space transform.

**Parameter**

channel	EDMA channel number
eSrcFormat	The source color format
eDestFormat	The destination color format

**Return Value**

SUCCESS	0 is returned.
FAIL	EDMA_ERR_BUSY is returned.

**Example**

```
/* Setup color space transform RGB565 to YCbCr422 */
EDMA_SetupCST(g_VdmaCh, eDRVEDMA_RGB565, eDRVEDMA_YCbCr422);
```

**EDMA\_ClearCST**
**Synopsis**

```
int EDMA_ClearCST(int channel)
```

**Description**

This function is used to disable EDMA channel color space transform.

**Parameter**

channel	EDMA channel number
---------	---------------------

**Return Value**

SUCCESS	0 is returned.
---------	----------------

**Example**

```
/* Disable EDMA color space transform */
EDMA_ClearCST (g_VdmaCh);
```

**EDMA\_Trigger**
**Synopsis**

```
void EDMA_Trigger(int channel)
```

**Description**

This function is used to start EDMA channel transfer.

**Parameter**

channel                      EDMA channel number

**Return Value**

None.

**Example**

```
/* Trigger EDMA channel transfer */
EDMA_Trigger (g_VdmaCh);
```

**EDMA\_TriggerDone**

**Synopsis**

void EDMA\_TriggerDone(int channel)

**Description**

This function is used to set the variable of EDMA channel transfer done.

**Parameter**

channel                      EDMA channel number

**Return Value**

None.

**Example**

```
EDMA_TriggerDone (g_VdmaCh);
```

**EDMA\_IsBusy**

**Synopsis**

int EDMA\_IsBusy(int channel)

**Description**

This function is used to query EDMA channel is busy or not.

**Parameter**

channel                      EDMA channel number

**Return Value**

TRUE                      EDMA channel is busy.  
FALSE                      EDMA channel is ready.

**Example**

```
EDMA_IsBusy (g_VdmaCh);
```

### **EDMA\_SetAPB**

#### **Synopsis**

```
int EDMA_SetAPB(int channel, E_DRVEDMA_APB_DEVICE eDevice,
E_DRVEDMA_APB_RW eRWAPB, E_DRVEDMA_TRANSFER_WIDTH
eTransferWidth)
```

#### **Description**

This function is used to setup EDMA channel for APB device.

#### **Parameter**

channel	EDMA channel number
eDevice	Specify the APB device which will use the EDMA channel
eRWAPB	Indicate that read or write APB device
eTransferWidth	Set the transfer width for specified channel

#### **Return Value**

SUCCESS	0 is returned.
FAIL	EDMA_ERR_BUSY is returned.

#### **Example**

```
/* Setup ADC use EDMA channel*/
EDMA_SetAPB (g_PdmaCh, eDRVEDMA_ADC, eDRVEDMA_READ_APB,
eDRVEDMA_WIDTH_32BITS);
```

### **EDMA\_SetWrapINTType**

#### **Synopsis**

```
int EDMA_SetWrapINTType(int channel, int type)
```

#### **Description**

Set the EDMA wrap around interrupt select for specified channel.

#### **Parameter**

channel	EDMA channel number
type	Set the wrap around mode for specified channel

#### **Return Value**

SUCCESS	0 is returned.
FAIL	EDMA_ERR_BUSY is returned.

### Example

```
/* Set wrap around mode with half and empty */
EDMA_SetWrapINTType    (g_PdmaCh,    eDRVEDMA_WRAPAROUND_EMPTY    |
eDRVEDMA_WRAPAROUND_HALF);
```

## EDMA\_SetDirection

### Synopsis

```
int EDMA_SetDirection(int channel, int src_dir, int dest_dir)
```

### Description

This function is used to set transfer direction for specified channel.

### Parameter

channel	EDMA channel number
src_dir	The source transfer direction
dest_dir	The destination transfer direction

### Return Value

SUCCESS	0 is returned.
FAIL	EDMA_ERR_BUSY is returned.

### Example

```
/* Set source transfer direction fixed and destination wraparound*/
EDMA_SetDirection      (g_PdmaCh      ,      eDRVEDMA_DIRECTION_FIXED,
eDRVEDMA_DIRECTION_WRAPAROUND);
```

## 7.4 ERROR CODE TABLE

Code Name	Value	Description
EDMA_ERR_NODEV	0xFFFF0401	No device error
EDMA_ERR_INVAL	0xFFFF0402	Invalid parameter error
EDMA_ERR_BUSY	0xFFFF0403	Channel busy error

## 8 EMAC LIBRARY

### 8.1 OVERVIEW

This document is written for user applications which want to make use of EMAC through provided API.

### 8.2 FEATURE

- Supports IEEE Std. 802.3 CSMA/CD protocol.
- Supports both half and full duplex for 10M/100M bps operation.
- Supports RMI interface.
- Supports MII Management function.
- Supports pause and remote pause function for flow control.
- Supports long frame (more than 1518 bytes) and short frame (less than 64 bytes) reception.
- Supports 16 entries CAM function for Ethernet MAC address recognition.
- Supports internal loop back mode for diagnostic.
- Supports 256 bytes embedded transmit and receive FIFO.
- Supports DMA function.

### 8.3 API DATA STRUCTURE

#### ***S\_FrameDescriptor***

Tx/Rx buffer descriptor.

Name	Type	Description
Status1	UINT32	RX/TX ownership, RX status, TX controlbits
FrameDataPtr	UINT32	Frame data pointer
Status2	UINT32	TX status, RX NAT info
NextFrameDescriptor	UINT32	Next frame descriptor pointer

#### ***S\_Ethead***

Ethernet header

Name	Type	Description
------	------	-------------

DestinationAddr[6]	UINT8	Destination MAC address
SourceAddr[6]	UINT8	Source MAC address
LengthOrType[2]	UINT8	Frame size or type

### ***S\_MACFrame***

MAC frame data structure.

<b>Name</b>	<b>Type</b>	<b>Description</b>
Header	S_Etheader	Ethernet header
LLCData[1522]	UNT8	Payload

### ***S\_MACTxStatus: reserve***

### ***S\_MACRxStatus: reserve***

### ***NVT\_EMAC\_T***

Major data structure for EMAC Init.

<b>Name</b>	<b>Type</b>	<b>Description</b>
srcMAcAddr[6]	UINT8	Source MAC address
speedMode	UINT32	100M or 10M bps, Half or Full duplex
recvPacketType	UINT32	Accept packet type, ex: unicast, broadcast.
rxFDBaseAddr	UINT32	RX fame descriptor base address
txFDBaseAddr	UINT32	TX frame descriptor base address
rxFBABaseAddr	UINT32	RX frame buffer address base
txFBABaseAddr	UINT32	TX frame buffer address base
portNo	UINT32	EMAC port0 or port1

## **8.4 API FUNCTION**

### ***EMAC\_Init***

#### **Synopsis**

```
BOOL EMAC_Init(NVT_EMAC_T *emac);
```

#### **Description**

Initialize EMAC and PHY.

#### **Parameter**

emac  
NVT\_EMAC\_T. Init setting structure as defined in

Return Value

True	Sucess
False	Failed

EMAC\_SetRxCallBack

Synopsis

BOOL EMAC\_SetRxCallBack(PVOID pvFun);

Description

Set RX call back function

Parameter

pvFun	callback function pointer
-------	---------------------------

Return Value

True	Sucess
False	Failed

EMAC\_SendPacket

Synopsis

BOOL EMAC\_SendPacket(UINT8 \*data,int size);

Description

Send one packet.

Parameter

data	Paket data pointer
size	Packet size

Return Value

True	Sucess
False	Failed

EMAC\_EnableWakeOnLan

Synopsis

void EMAC\_EnableWakeOnLan();

Description



To enable EMAC support WOL and set as one wake up source

**Parameter**

None

**Return Value**

None

***EMAC\_Exit***
**Synopsis**

```
void EMAC_Exit()
```

**Description**

Close EMAC and let it down

**Parameter**

None

**Return Value**

None

## 8.5 ERROR CODE TABLE

Code Name	Value	Description
True	1	Success
False	0	Failure

## 9 FONT LIBRARY

### 9.1 OVERVIEW

The N9H26 Font library provides a set of APIs to write character or draw rectangle border to frame buffer. With these APIs, user can quickly to show some string on N9H26 demo board or evaluation board. The library is a software solution. After update the frame buffer, VPOST controller can show the content to panel or TV.

These libraries are created by using Keil uVision IDE. Therefore, they only can be used in Keil environment.

### 9.2 FONT LIBRARY API

#### *InitFont*

##### Synopsis

```
void InitFont(S_DEMO_FONT* ptFont, UINT32 u32FrameBufAddr);
```

##### Description

This function is used to initialize the font library. To get some information of font library.

##### Parameter

ptFont                                      Font library information pointer.  
u32FrameBufAddr Frame buffer base address.

Table 9-1:Font Information

Field name	Data Type	Description
u32FontRectWidth	UINT32	Font width. Now it is fixed in 16
u32FontRectHeight	UINT32	Font height. Now it is fixed in 22
u32FontOffset	UINT32	Font Offset. Now it is fixed in 11
u32FontStep	UINT32	Font Step. Now fixed in 10
u32FontOutputStride	UINT32	Output Stride. It should same as the panel width
u32FontInitDone	UINT32	1 = Font library initialized done. 0 = Font library not yet initialized done or de-initialized.
u32FontFileSize	UINT32	Reserved
pu32FontFileTmp	UINT32	Reserved

pu32FontFile	UINT32	Pointer of font file
au16FontColor[3]	UINT16	RGB565 color au16FontColor[0]: Font background color au16FontColor[1]: Font color au16FontColor[2]: Border color

**Return Value**

None

**Example**

```
/* Initialize font library */
__align(32) static S_DEMO_FONT s_sDemo_Font;
__align(32) UINT16 u16FrameBuffer[_LCM_WIDTH_*_LCM_HEIGHT_];

InitFont(&s_sDemo_Font, u16FrameBufAddr);
```

**DemoFont\_PaintA**
**Synopsis**

```
void DemoFont_PaintA(S_DEMO_FONT* ptFont, UINT32 u32x, UINT32 u32y,
PCSTR pszString)
```

**Description**

This function writes a specified string to frame buffer.

**Parameter**

ptFont	Font library information pointer. Reference the Table 9-1:Font Information
u32x	start x position.
u32y	start y position.
pszString	The specified string for writing to frame buffer.

**Return Value**

None

**Example**

```
/* Draw a string to the position (0, 0) of frame buffer */
__align(32) static S_DEMO_FONT s_sDemo_Font
char szString[64];
sprintf(szString, "FA93 Font Code");
```

```
DemoFont_PaintA(&s_sDemo_Font, 0, 0, szString);
```

## UnInitFont

### Synopsis

```
void UnInitFont(S_DEMO_FONT* ptFont)
```

### Description

De-Initialize the font library.

### Parameter

ptFont                      Font library information pointer. Reference the Table 9-1:Font Information

### Return Value

None

### Example

```
/* De-Initialize the font library */
__align(32) static S_DEMO_FONT s_sDemo_Font
UninitFont(&s_sDemo_Font);
```

## DemoFont\_Rect

### Synopsis

```
void DemoFont_Rect(SDEMO_FONT* ptFont, S_DEMO_RECT* ptRect)
```

### Description

This function draws a solid rectangle to frame buffer.

### Parameter

ptFont                      Font library information pointer. Reference the Table 9-1:Font Information

ptRect                      Solid rectangle pointer

Table 9-2:Rectangle Information

Field name	Data Type	Description
u32StartX	UINT32	X position for the upper-left corner
u32StartY	UINT32	Y position for the upper-left corner
u32EndX	UINT32	X position for the lower-right corner
u32EndY	UINT32	Y position for the lower-right corner

**Return Value**

None

**Example**

```
/* Draw a solid rectangle with dimension 320x240*/
__align(32) static S_DEMO_FONT s_sDemo_Font;
static S_DEMO_RECT s_sDemo_Rect;
s_sDemo_Rect.u32StartX = 0;
s_sDemo_Rect.u32StartY = 0;
s_sDemo_Rect.u32EndX = 320-1;
s_sDemo_Rect.u32EndY =240-1;
DemoFont_Rect(&ptFont,
               &s_sDemo_Rect);
```

***DemoFont\_RectClear***

**Synopsis**

```
void DemoFont_RectClear(SDEMO_FONT* ptFont, S_DEMO_RECT* ptRect)
```

**Description**

This function clears a solid rectangle to background color in frame buffer. The background color was fixed as 0. It means the color is black for RGB565 format.

**Parameter**

ptFont Information	Font library information pointer. Reference the Table 9-1:Font
ptRect Information	Solid rectangle pointer. Reference the Table 9-2:Rectangle

**Return Value**

None

**Example**

```
/* Clear a solid rectangle from position (0, 0) to (319, 240) */
__align(32) static S_DEMO_FONT s_sDemo_Font;
static S_DEMO_RECT s_sDemo_Rect;
s_sDemo_Rect.u32StartX = 0;
```

```
s_sDemo_Rect.u32StartY = 0;
s_sDemo_Rect.u32EndX = 320-1;
s_sDemo_Rect.u32EndY =240-1;
DemoFont_RectClear(&ptFont,
                   &s_sDemo_Rect);
```

### Font\_ClrFrameBuffer

#### Synopsis

```
void Font_ClrFrameBuffer(UINT32 u32FrameBufAddr)
```

#### Description

This function clears the specified frame buffer to fixed background color (black color). The dimension is specified in the header file- `_LCM_WIDTH_` and `_LCM_HEIGHT_` with 16-bit pixel format.

#### Parameter

u32FrameBufAddr Frame buffer base address.

#### Return Value

None

#### Example

```
__align(32) UINT16 u16FrameBuffer[_LCM_WIDTH_*_LCM_HEIGHT_];

/* Clear frame buffer to background color-black*/
Font_ClrFrameBuffer(u16FrameBuffer);
```

### DemoFont\_Border

#### Synopsis

```
void DemoFont_Border(S_DEMO_FONT* ptFont, S_DEMO_RECT* ptRect,
                    UINT32 u32Width);
```

#### Description

This function draw a hollow rectangle with the specified border width.

#### Parameter

ptFont	Font library information pointer. Reference the Table 9-1:Font Information
ptRect	Solid rectangle pointer. Reference the Table 9-2:Rectangle

Information.  
u32Width Border width.

**Return Value**  
None

**Example**

```
__align(32) static S_DEMO_FONT s_sDemo_Font;
S_DEMO_RECT s_sDemo_Rect;
__align(32) UINT16 u16FrameBuffer[_LCM_WIDTH_*_LCM_HEIGHT_];

InitFont(&s_sDemo_Font, u16FrameBuffer);
s_sDemo_Rect.u32StartX =0;
s_sDemo_Rect.u32StartY = 0;
s_sDemo_Rect.u32EndX = _LCM_WIDTH_-1;
s_sDemo_Rect.u32EndY = _LCM_HEIGHT_-1;
/* Draw a hollow rectangle with dimension same as panel and border is 2 pixels width */
DemoFont_Border(&s_sDemoFont,
                &s_sDemo_Rect,
                2);
```

***DemoFont\_ChangeFontColor***

**Synopsis**  
void DemoFont\_ChangeFontColor(S\_DEMO\_FONT\* ptFont, UINT16 u16RGB565);

**Description**  
This function sets the font color. The format is RGB565.

**Parameter**

ptFont	Font library information pointer. Reference the Table 9-1:Font Information
u16RGB565	RGB565n format

**Return Value**  
None

**Example**

```
__align(32) static S_DEMO_FONT s_sDemo_Font;
/* Set the blue font color */
DemoFont_ChangeFontColor(&s_sDemo_Font, 0x001F);
```

### ***DemoFont\_GetFontColor***

#### **Synopsis**

```
UINT16 DemoFont_GetFontColor(S_DEMO_FONT* ptFont);
```

#### **Description**

This function gets current font color. The return value format is RGB565.

#### **Parameter**

ptFont	Font library information pointer. Reference the Table 9-1:Font
Information	

#### **Return Value**

RGB565 format

#### **Example**

```
__align(32) static S_DEMO_FONT s_sDemo_Font;
UINT16 u16FontColor;
/* Get font color */
u16FontColor = DemoFont_GetFontColor(&s_sDemo_Font);
```



## 10 GNAND LIBRARY

### 10.1 OVERVIEW

N9H26 Non-OS library consists of a sets of libraries. These libraries are built to access those on-chip functions such as VPOST, APU, SIC, USBH, USBD, GPIO, I2C, SPI and UART, as well as File System (NVT FAT), USB MassStorage devices (UMAS) and NAND Flash devices (GNAND). This document describes the provided APIs of GNAND library. With these APIs, user can quickly build a binary target for GNAND library on N9H26 microprocessor.

These libraries are created by using Keil uVision IDE. Therefore, they only can be used in Keil environment.

### 10.2 GNAND LIBRARY INTRODUCTION

In GNAND library, a NAND was thought of as a disk. User can access NAND by logical block address and don't worry about the bad block issue. It's possible that a few leading physical blocks were reserved for boot code or information area. GNAND library will not access those reserved blocks.


The Generic NAND (GNAND) library has the following features:

- Mapping between logical block and physical block to support bad block management
- Platform independent.
- Support both FAT file system and USB mass storage device
- Support both SLC and MLC NAND
- Able to recover from any power-off exceptions
- High performance, fast startup
- Support multiple NAND disk
- Support two disks in one NAND (reserved NAND partition)
- Dirty page management to support garbage collection feature
- Balanced usage on all physical blocks to support wear-leveling feature (will supported in the future)

### 10.3 PROGRAMMING GUIDE

#### System Overview

GNAND library works as a hardware independent library. NAND disk access service was provided by NAND driver. File system access service was provided by upper layer FAT file system library or USB mass storage device driver. The relationship between these component libraries was shown in the following picture:



### Initialize GNAND Library

To initialize GNAND library, just invoke **GNAND\_InitNAND()**. Application must give corresponding NAND driver as input argument to **GNAND\_InitNAND()**, then GNAND library can access NAND disk through NAND driver service.

GNAND library will validate the NAND disk is GNAND format or not. If it is not GNAND format, application can determine to program it as GNAND format or not. It depends on the third argument of **GNAND\_InitNAND()**.

### GNAND work with Nuvoton FAT Library

If **GNAND\_InitNAND()** returns GNAND\_OK, application can invoke **GNAND\_MountNandDisk()** to mount NAND disk to NVTFAT file system.

#### *NAND driver function set*

To work as an underlying driver of GNAND, the NAND driver must provide the following function set and pass it to GNAND library with **GNAND\_InitNAND()**.

```

#define NDRV_T struct ndrvt_t
struct ndrvt_t
{
    INT  (*init)(NDISK_T *NDInfo);
    INT  (*pread)(INT nPBlockAddr, INT nPageNo, UINT8 *buff);
    INT  (*pwrite)(INT nPBlockAddr, INT nPageNo, UINT8 *buff);
    INT  (*is_page_dirty)(INT nPBlockAddr, INT nPageNo);
}
  
```

```

INT  (*is_valid_block)(INT nPBlockAddr);
INT  (*ioctl)(INT param1, INT param2, INT param3, INT param4);
INT  (*block_erase)(INT nPBlockAddr);
INT  (*chip_erase)(VOID);
VOID *next;
};

```

In `init(NDISK_T *NDInfo)` function, NAND driver should detect NAND disk and fill NAND disk information into `<NDISK_T *NDInfo>`, which was passed as an argument. If success, return 0.

#### NDISK\_T members

Member Name	Return by init()	Comments
vendor_ID	Optional	
device_ID	Optional	
NAND_type	Must	NAND_TYPE_SLC or NAND_TYPE_MLC
nZone	Must	Number of zones
nBlockPerZone	Must	Maximum number of physical blocks per zone
nPagePerBlock	Must	Number of pages per block
nLBPerZone	Must	Maximum number of allowed logical blocks per zone
nPageSize	Must	Page size in bytes
nStartBlock	Must	Reserved number of leading blocks
nBadBlockCount	Optional	Bad block count for all zones
driver	Must	NAND driver function set pointer
nNandNo	Optional	
pDisk	Optional	
write_page_in_seq	Must	Programming pages out of sequence within a block is prohibited or not
reserved[59]	Ignore	
need2P2LN	Optional	Need second P2LN block or not
p2ln_block1	Optional	Physical block address for second P2LN block
p2lm	Ignore	GNAND internal used
l2pm	Ignore	GNAND internal used
dp_tbl	Ignore	GNAND internal used
db_idx[16]	Ignore	GNAND internal used

p2ln_block	Ignore	GNAND internal used
op_block	Ignore	GNAND internal used
op_offset	Ignore	GNAND internal used
last_op[32]	Ignore	GNAND internal used
err_sts	Ignore	GNAND internal used
next	Ignore	GNAND internal used

In **pread(INT nPBlockAddr, INT nPageNo, UINT8 \*buff)** function, NAND driver execute a page read operation from physical block <nPBlockAddr> page <nPageNo>. And <buff> was guaranteed to be non-cacheable memory.

In **pwrite(INT nPBlockAddr, INT nPageNo, UINT8 \*buff)** function, NAND driver execute a page programming operation to physical block <nPBlockAddr> page <nPageNo>. And <buff> was guaranteed to be non-cacheable memory.

In **is\_page\_dirty(INT nPBlockAddr, INT nPageNo)** function, NAND driver check the redundant area of physical block <nPBlockAddr> page <nPageNo>. If this page had ever been written, NAND driver should return 1, otherwise, return 0.

In **is\_valid\_block(INT nPBlockAddr)** function, NAND driver check if physical block <nPBlockAddr> is a valid block or not. If the block is a valid block, NAND driver should return 1, otherwise, return 0.

At current version, **ioctl()** was not used by GNAND library. NAND driver can give it a NULL value.

In **block\_erase(INT nPBlockAddr)** function, NAND driver execute a block erase operation on physical block <nPBlockAddr>.

In **chip\_erase()** function, NAND driver execute a chip erase operation on the NAND disk. Note that the whole GNAND information will lost after chip\_erase(). You have to call GNAND\_InitNAND() to rebuild GNAND format.

## 10.4 API FUNCTION

### ***GNAND\_InitNAND***

#### **Synopsis**

```
INT    GNAND_InitNAND (NDRV_T  *ndriver, NDISK_T  *ptNDisk, BOOL
bEraseIfNotGnandFormat)
```

#### **Description**

Initialize a NAND disk.

#### **Parameter**

ndriver NAND driver function set to hook NAND driver on GNAND library.

ptNDisk NAND disk information that GNAND initiated. You need this pointer to call other GNAND APIs.

bEraseIfNotGnandFormat

If NAND disk was GNAND format, ignore this argument.

If NAND disk was not GNAND format, format it if this argument is 1, otherwise, return an GNERR\_GNAND\_FORMAT error.

#### **Return Value**

0 – Success

Otherwise – error code defined in Error Code Table

#### **Example**

```
NDRV_T _nandDiskDriver0 =
{
    nandInit0,
    nandpread0,
    nandpwrite0,
    nand_is_page_dirty0,
    nand_is_valid_block0,
    nand_ioctl,
    nand_block_erase0,
    nand_chip_erase0,
    0
};
...
```

```

NDISK_T *ptNDisk;
int status;

fsInitFileSystem();

/* Initialize FMI */
siclockl(SIC_SET_CLOCK, 240000, 0, 0);
sicOpen();

ptNDisk = (NDISK_T *)malloc(sizeof(NDISK_T));
if (ptNDisk == NULL)
{
    printf("malloc error!!\n");
    return -1;
}

status = GNAND_InitNAND(&_nandDiskDriver0, ptNDisk, TRUE);
if (status < 0)
{
    printf("NAND disk init failed, status = %x\n", status);
    return status;
}

status = GNAND_MountNandDisk(ptNDisk);
if (status < 0)
{
    printf("Mount NAND disk failed, status = %x\n", status);
    return status;
}

```

### ***GNAND\_MountNandDisk***

#### **Synopsis**

INT GNAND\_MountNandDisk (NDISK\_T \*ptNDisk)

#### Description

Mount NAND disk to NVTFAT file system.

#### Parameter

ptNDisk The pointer refer to the NAND disk information that initiated by GNAND\_InitNAND().

#### Return Value

0 – Success

Otherwise – error code defined in Error Code Table

#### Example

Refer to the example code of GNAND\_InitNAND();

### **GNAND\_read**

#### Synopsis

INT GNAND\_read (NDISK\_T \*ptNDisk, UINT32 nSectorNo, INT nSectorCnt, UINT8 \*buff)

#### Description

Read logical sectors from NAND disk.

#### Parameter

ptNDisk The pointer refer to the NAND disk information that initiated by GNAND\_InitNAND().

nSectorNoRead start sector number.

nSectorCnt Number of sectors to be read.

buff Memory buffer to receive data, which is 32 bytes aligned non-cacheable buffer.

#### Return Value

0 – Success

Otherwise – error code defined in Error Code Table

#### Example

```
/* Read data from NAND disk sector 100 to sector 104 and store data to buff on RAM */
__align (32) UINT8 buff [512*5];
GNAND_read(ptNDISK, 100, 5, buff);
```

## **GNAND\_write**

### **Synopsis**

```
INT GNAND_write (NDISK_T *ptNDisk, UINT32 nSectorNo, INT nSectorCnt,
UINT8 *buff)
```

### **Description**

Write logical sectors to NAND disk

### **Parameter**

ptNDisk The pointer refer to the NAND disk information that initiated by GNAND\_InitNAND().

nSectorNo Write start sector number.

nSectorCnt Number of sectors to be written.

buff Memory buffer to write data, which is 32 bytes aligned non-cacheable buffer

### **Return Value**

0 – Success

Otherwise – error code defined in Error Code Table

### **Example**

```
/* Write data from buff to NAND disk sector 100 to sector 104 */
__align (32) UINT8 buff [512*5];
...
GNAND_write(ptNDISK, 100, 5, buff);
```

## **GNAND\_block\_erase**

### **Synopsis**

```
INT GNAND_block_erase (NDISK_T *ptNDisk, INT pba)
```

### **Description**

Erase a physical block.

### **Parameter**

ptNDisk The pointer refer to the NAND disk information that initiated by GNAND\_InitNAND().

pba NAND physical block address.

### **Return Value**

0 – Success



Otherwise – error code defined in Error Code Table

**Example**

```
int status;

/* erase physical block 10*/
status = GNAND_block_erase(ptNDisk, 10);
if (status != 0)
{
    /* handle error status */
}
```

**GNAND\_chip\_erase**
**Synopsis**

INT **GNAND\_chip\_erase** (NDISK\_T \*ptNDisk)

**Description**

This function erase all blocks in NAND chip. All data in chip will lost that include information for GNAND library.

**Parameter**

ptNDisk The pointer refer to the NAND disk information that initiated by **GNAND\_InitNAND()**.

**Return Value**

0 – Success

Otherwise – error code defined in Error Code Table

**Example**

```
int status;

/* erase whole NAND chip */
status = GNAND_chip_erase(ptNDisk);
if (status != 0)
{
    /* handle error status */
}
```

## **GNAND\_UnMountNandDisk**

### **Synopsis**

VOID GNAND\_UnMountNandDisk (NDISK\_T \*ptNDisk)

### **Description**

Unmount NAND disk from NVT FAT file system.

### **Parameter**

ptNDisk The pointer refer to the NAND disk information that initiated by GNAND\_InitNAND().

### **Return Value**

0 – Success

Otherwise – error code defined in Error Code Table

### **Example**

```
int status;

status = GNAND_UnMountNandDisk(ptNDisk);
if (status != 0)
{
    /* handle error status */
}
```

## **10.5 EXAMPLE CODE**

The example code tests the GNAND library please refer to the SIC example code of BSP Non-OS.

## **10.6 ERROR CODE TABLE**

CODE NAME	Value	Description
GNAND_OK	0	Success
GNERR_GENERAL	0xFFFFC001	General access error
GNERR_MEMORY_OUT	0xFFFFC005	No available memory
GNERR_GNAND_FORMAT	0xFFFFC010	NAND disk was not GNAND format
GNERR_FAT_FORMAT	0xFFFFC015	NAND disk was unformatted as FAT
GNERR_BLOCK_OUT	0xFFFFC020	There's no available physical blocks
GNERR_P2LN_SYNC	0xFFFFC025	Internal error for P2LN table sync problem

GNERR_READONLY_NAND	0xFFFFC026	Cannot write data into read only NAND disk
GNERR_IO_ERR	0xFFFFC030	NAND read/write/erase access failed
GNERR_NAND_NOT_FOUND	0xFFFFC040	NAND driver cannot find NAND disk.
GNERR_UNKNOW_ID	0xFFFFC042	Not supported NAND ID

## 11 GPIO LIBRARY

### 11.1 OVERVIEW

The GPIO library provides a set of APIs to control on-chip GPIO pins. This library depends on N9H26 System Library.

### 11.2 API FUNCTIONS

#### *gpio\_open*

##### **Synopsis**

int gpio\_open (unsigned char port)

##### **Description**

It has replaced gpio\_open (unsigned char port) with gpio\_configure (unsigned char port, unsigned short num).

#### *gpio\_configure*

##### **Synopsis**

int gpio\_configure (unsigned char port, unsigned short num)

##### **Description**

This function configures the specified pin of a port as GPIO.

##### **Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
          GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

num      pin number

##### **Return Value**

Return 0 on success. -1 for unknown port number

##### **Example**

```
/* Configure the pin 0 of port D as GPIO*/  
gpio_configure (GPIO_PORTD, 0);
```

#### *gpio\_readport*

**Synopsis**

```
int gpio_readport (unsigned char port, unsigned short *val)
```

**Description**

This function reads back all pin value of a GPIO port, ignore the direction of each pin.

**Parameter**

port        GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

\*val        Return port value

**Return Value**

Return 0 one success, -1 for unknown port number

**Example**

```
/* Read PORT C value*/
unsigned short val;
gpio_readport(GPIO_PORTC, &val);
```

***gpio\_setportdir***
**Synopsis**

```
int gpio_setportdir (unsigned char port, unsigned short mask, unsigned short dir)
```

**Description**

This function sets the pin direction of GPIO port. It could select the pin(s) to be configured with its second parameter.

**Parameter**

port        GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

mask        pin mask, each bit stands for one pin

dir         Direction, each bit configures one pin, 0 means input, 1 means output

**Return Value**

Return 0 one success, -1 for unknown port number

**Example**

```
/* Set PORT C pin 1 to output mode, and pin 0 to input mode */
gpio_setportdir (GPIO_PORTC, 0x3, 0x2);
```

## ***gpio\_setportval***

### **Synopsis**

int gpio\_setportval (unsigned char port, unsigned short mask, unsigned short val)

### **Description**

This function sets the output value of GPIO port. It could select the pin(s) to be configured with its second parameter.

### **Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD, GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

mask      pin mask, each bit stands for one pin

val        Output value, each bit configures one pin, 0 means low, 1 means high

### **Return Value**

Return 0 one success, -1 for unknown port number

### **Example**

```
/* Set PORT C pin 1 to output high, and pin 0 to low */
gpio_setportval (GPIO_PORTC, 0x3, 0x2);
```

## ***gpio\_setportpull***

### **Synopsis**

int gpio\_setportpull (unsigned char port, unsigned short mask, unsigned short pull)

### **Description**

This function sets the pull up/down resistor of GPIO port. It could select the pin(s) to be configured with its second parameter.

### **Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD, GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

mask      pin mask, each bit stands for one pin

pull       Pull up/down resistor state, each bit configures one pin, 0 means disable, 1 means enable

### **Return Value**

Return 0 one success, -1 for unknown port number

### **Example**

```
/* Enable PORT C pin 1 pull up resistor, and disable pin 0 pull up resistor */
gpio_setportpull (GPIO_PORTC, 0x3, 0x2);
```

### ***gpio\_setdebounce***

#### **Synopsis**

```
int gpio_setdebounce(unsigned int clk, unsigned char src)
```

#### **Description**

This function is used to configure external interrupt de-bounce time.

#### **Parameter**

clk            Debounce sampling clock, could be 1, 2, 4, 8, 16, 32, 64, 128, 256, 2\*256, 4\*256, 8\*256, 16\*256, 32\*256, 64\*256 and 128\*256

src            Debounce sampling interrupt source. Valid values are between 0~15. Each bit represents one interrupt source

#### **Return Value**

Return 0 on success, -1 on parameter error

#### **Example**

```
/* Set nIRQ0 debounce sampling clock to 128 clocks*/
gpio_setdebounce (128, 1);
```

### ***gpio\_getdebounce***

#### **Synopsis**

```
void gpio_getdebounce(unsigned int *clk, unsigned char *src)
```

#### **Description**

This function gets current external interrupt de-bounce time setting.

#### **Parameter**

\*clk           Debounce sampling clock

\*src           Debounce sampling interrupt source

#### **Return Value**

None

#### **Example**

```
unsigned int clk;
```

```
unsigned char src;
gpio_getdebounce (&clk, &src);
```

### ***gpio\_setsrcgrp***

#### **Synopsis**

```
int gpio_setsrcgrp (unsigned char port, unsigned short mask, unsigned char irq)
```

#### **Description**

This function is used to set external interrupt source group.

#### **Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
          GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH  
mask      pin mask, each bit stands for one pin  
irq        external irq number. Could be 0~3

#### **Return Value**

Return 0 on success, -1 on parameter error

#### **Example**

```
/* Set GPIO port C pin 0 as source of nIRQ3 */
gpio_setsrcgrp (GPIO_PORTC, 1, 3);
```

### ***gpio\_getsrcgrp***

#### **Synopsis**

```
int gpio_getsrcgrp (unsigned char port, unsigned int *val)
```

#### **Description**

This function is used to get current external interrupt source setting.

#### **Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
          GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH  
\*val      Current source setting. Every two bits stands for the interrupt source  
          each pin triggers

#### **Return Value**

Return 0 on success, and -1 for unknown port number

#### **Example**



```
/* Read GPIO port C interrupt group status */
unsigned int val;
gpio_setsrcgrp (GPIO_PORTC, &val);
```

### ***gpio\_setintmode***

#### **Synopsis**

int gpio\_setintmode (unsigned char port, unsigned short mask, unsigned short falling, unsigned short rising)

#### **Description**

This function sets the interrupt trigger mode of GPIO port. It could select the pin(s) to be configured with its second parameter.

#### **Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD, GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH  
mask      Pin mask, each bit stands for one pin  
falling    Triggers on falling edge, each bit stands for one pin  
rising     Triggers on rising edge, each bit stands for one pin

#### **Return Value**

Return 0 on success, -1 for parameter error

#### **Example**

```
/* Set PORT C pin 0 triggers on both falling and rising edge */
gpio_setintmode (GPIO_PORTC, 1, 1, 1);
```

### ***gpio\_getintmode***

#### **Synopsis**

int gpio\_getintmode (unsigned char port, unsigned short \*falling, unsigned short \*rising)

#### **Description**

This function is used to get interrupt trigger mode of GPIO port.

#### **Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD, GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH  
\*falling   Triggers on falling edge, each bit stands for one pin

\*rising      Triggers on rising edge, each bit stands for one pin

**Return Value**

Return 0 on success, -1 for parameter error

**Example**

```
/* Get PORT C trigger mode */
unsigned short falling;
unsigned short rising;
gpio_getintmode (GPIO_PORTC, &falling, &rising);
```

***gpio\_setlatchtrigger***
**Synopsis**

```
int gpio_setlatchtrigger (unsigned char src)
```

**Description**

This function used to set latch trigger source.

**Parameter**

src                      Latch trigger source. Each bit stands for one external interrupt source. If the value is 1, GPIO port input value will be latched while interrupt triggers

**Return Value**

Return 0 on success, -1 for parameter error

**Example**

```
/* Enable latch for nIRQ0 and nIRQ3*/
gpio_setlatchtrigger (9);
```

***gpio\_getlatchtrigger***
**Synopsis**

```
void gpio_getlatchtrigger (unsigned char *src)
```

**Description**

This function used to get latch trigger source.

**Parameter**

\*src                      Latch trigger source

**Return Value**

None

**Example**

```
/* Get latch trigger source*/
unsigned char src;
gpio_getlatchtrigger (&src);
```

***gpio\_getlatchval***
**Synopsis**

```
int gpio_getlatchval (unsigned char port, unsigned short *val)
```

**Description**

This function is used to get interrupt latch value.

**Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

\*val      Variable to store latch value

**Return Value**

Return 0 on success, -1 for parameter error

**Example**

```
/* Get port C latch value */
unsigned short val;
gpio_getlatchval (GPIO_PORTC, &val);
```

***gpio\_gettriggersrc***
**Synopsis**

```
int gpio_gettriggersrc (unsigned char port, unsigned short *src)
```

**Description**

This function is used to get interrupt trigger source.

**Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

\*src      Variable to store trigger source

**Return Value**

Return 0 on success, -1 for parameter error

**Example**

```
/* Get port C interrupt trigger source */
unsigned short src;
gpio_gettriggersrc (GPIO_PORTC, &src);
```

***gpio\_cleartriggersrc***
**Synopsis**

```
int gpio_cleartriggersrc(unsigned char port)
```

**Description**

This function is used to clear interrupt trigger source.

**Parameter**

port      GPIO\_PORTA, GPIO\_PORTB, GPIO\_PORTC, GPIO\_PORTD,  
GPIO\_PORTE, GPIO\_PORTG, and GPIO\_PORTH

**Return Value**

Return 0 on success, -1 for parameter error

**Example**

```
/* Clear port C interrupt trigger source */
gpio_cleartriggersrc (GPIO_PORTC);
```

## 12 H264 CODEC LIBRARY

### 12.1 OVERVIEW

This document is written for user applications which want to use H264 Encoder or Decoder library API.

### 12.2 FEATURE

#### Encoder Features

- Follows MPEG-4 AVC/JVT/H.264 (ISO/IEC 14496-10) video coding standards
- Supports baseline profile to level 3.1
- Supports resolutions from 128x80 to 1280x720 in a step of 16 units
- Supports I and P frame encodings
- CBR and VBR rate controls by firmware
- Supports programmable in-loop filter parameters
- Supports programmable chroma QP index offset parameter

#### Decoder Features.

- Compliant with ITU-T Recommendation H.264|ISO/IEC 14496-10 Advanced Video Coding Standard (MPEG 4 Part 10)
- Supports baseline profile with a level from 1 to 3
- Supports resolutions of up to 720 x 480 at 60 fps
- Supports motion estimation with variable block sizes
- Supports quarter-pixel motion compensation
- Supports Context-based Adaptive Variable-Length Decoding (CAVLD)
- Supports I and P slices
- Supports in-loop de-blocking filter function (disable\_deblocking\_filter\_idc! = 1) to execute filtering function, including slice boundary
- Not supports Arbitrary Slice Order (ASO) or Flexible Macroblock Ordering (FMO)

### 12.3 RATE CONTROL FOR ENCODER

The encoded bitstream rate control is implemented in application level. At the beginning, the application needs to call H264RateControlInit(...) function to initialize the variable in H264RateControl structure. After that, H264RateControlUpdate(...) function is used to calculate the next Quant value for next encode frame which is stored in the rtn\_quant field of H264RateControl structure.

Specify this `rtn_quant` in `u32Quant` field of `FAVC_ENC_PARAM` structure for next encode frame. Then, the rate control will be completed in such kind of loop.

## 12.4 API DATA STRUCTURE

### ***IOCTL COMMAND***

Ioctl command set for `H264_ioctl` function

Name	Value	Description
<code>FAVC_IOCTL_DECODE_INIT</code>	0x4170	Init H264 decoder
<code>FAVC_IOCTL_DECODE_FRAME</code>	0x4172	Decode one H264 frame
<code>FAVC_IOCTL_ENCODE_INIT</code>	0x4173	Init H264 Encode
<code>FAVC_IOCTL_ENCODE_FRAME</code>	0x4175	Encode one H264 frame
<code>FAVC_IOCTL_GET_SPSPPS</code>	0x4179	Get the encoded SPS PPS bitstream

**FAVC\_DEC\_RESULT**

H264 bitstream decoding result.

Name	Type	Description
<code>bEndOfDec</code>	UINT32	Used by library only
<code>u32Width</code>	UINT32	Decoded bitstream width
<code>u32Height</code>	UINT32	Decoded bitstream height
<code>u32UsedBytes</code>	UINT32	Reported used bitstream byte in buffer
<code>u32FrameNum</code>	UINT32	Decoded frame number
<code>isDisplayOut</code>	UINT32	0 -> Buffer in reorder buffer, 1 -> available buffer, -1 -> last flush frame
<code>isISlice</code>	UINT32	1-> I Slice, 0 -> P slice
<code>Reserved0</code>	UINT32	reserved

**FAVC\_DEC\_PARAM**

H264 bitstream decoding parameter.

Name	Type	Description
<code>u32API_version</code>	UINT32	API version
<code>u32MaxWidth</code>	UINT32	Not used now
<code>u32MaxHeight</code>	UINT32	Decoded bitstream height
<code>u32FrameBufferWidth</code>	UINT32	if ( <code>u32FrameBufferWidth</code> != -1), decoded image width is cropped with

		u32FrameBufferWidth if (u32FrameBufferWidth == -1), decoded image width is continued on memory
u32FrameBufferHeight	UINT32	if (u32FrameBufferHeight != -1), decoded image height is cropped with u32FrameBufferHeight if (u32FrameBufferHeight == -1), decoded image height is continued on memory
u32Pkt_size	UINT32	Current decoding bitstream length ( the exact bitstream length for one frame)
pu8Pkt_buf	UINT8*	Current decoding bitstream buffer address (application ready bitstream here)
pu8Display_addr[3]	UINT32	Buffer address for decoded data
got_picture	UINT32	0 -> Decoding has something error. 1 -> decoding is OK in current bitstream
pu8BitStream_phy	UINT8*	physical address. buffer for bitstream (allocated and used by library only)
u32OutputFmt	UINT32	Decoded output format, 0-> Planar YUV420 format, 1-> Packet YUV422 format
crop_x	UINT32	pixel unit: crop x start point at decoded-frame (not supported now)
crop_y	UINT32	pixel unit: crop y start point at decoded-frame (not supported now)
tResult	FAVC_DEC_RESULT	Return decoding result by library

### **FAVC\_ENC\_PARAM**

H264 encoding parameter.

<b>Name</b>	<b>Type</b>	<b>Description</b>
u32API_version	UINT32	API version
u32BitRate	UINT32	The encoded bitrate in bps.
u32FrameWidth	UINT32	The width of encoded frame in pels.
u32FrameHeight	UINT32	The height of encoded frame in pels
fFrameRate	UINT32	The base frame rate per second
u32IPInterval	UINT32	The frame interval between I-frames.
u32MaxQuant	UINT32	The maximum quantization value. (max = 51)
u32MinQuant	UINT32	The minimum quantization value. (min=0)
u32Quant	UINT32	The frame quantization value for initialization
ssp_output	INT32	This variable tells the H.264 must be encoded out sps + pps before slice data. --> 1 : force the encoder to output sps+pps -> 0 : force the encoder to output sps+pps on any Slice I frame

		-> -1: (default) only output SPS+PPS on first IDR frame.
intra	INT32	This variable tells the H.264 must be encoded out an I-Slice type frame. -> 1 : forces the encoder to create a keyframe. -> 0 : forces the encoder not to create a keyframe. -> -1: (default) let the encoder decide (based on contents and u32IPInterval)
bROIEnable	INT32	To enable the function of encoding rectangular region of interest(ROI) within captured frame
u32ROIX	UINT32	The upper-left corner x coordinate of rectangular region of interest
u32ROIY	UINT32	The upper-left corner coordinate y of region of interest
u32ROIWidth	UINT32	The width of user-defined rectangular region of interest
u32ROIHeight	UINT32	The height of user-defined rectangular region of interest
pu8YFrameBaseAddr	UINT8*	The base address for input Y frame buffer
pu8UVFrameBaseAddr	UINT8*	The base address for input UV frame buffer in H.264 2D mode
pu8UFrameBaseAddr	UINT8*	The base address for input U frame buffer
pu8VFrameBaseAddr	UINT8*	The base address for input V frame buffer
bitstream	UINT8*	Bitstream Buffer address for driver to write bitstream
pu8BitstreamAddr	UINT8*	The bitstream buffer address while encoding one single frame allocated by library
bitstream_size	UINT32	Bitstream length for current frame
keyframe	UINT32	This parameter is indicated the Slice type of frame
frame_cost	UINT32	frame_cout is updated by driver
no_frames	UINT32	The number of frames to be encoded
threshold_disable	UINT32	The transform coefficients threshold
chroma_threshold	UINT32	The chroma coefficients threshold (0 ~ 7)
luma_threshold	UINT32	The luma coefficients threshold (0 ~ 7)
beta_offset	UINT32	The beta offset for in-loop filter.
alpha_offset	UINT32	The alpha offset for in-loop filter.
chroma_qp_offset	UINT32	The chroma qp offset (-12 to 12 inclusively)
disable_ilf	UINT32	To disable in-loop filter or not
watermark_enable	UINT32	To enable watermark function or not (Don't enable it now)
watermark_interval	UINT32	To specify the watermark interval if watermark function is enabled



watermark_init_pattern	UINT32	To specify the initial watermark pattern if watermark function is enabled
pu8ReConstructFrame	UINT8*	The address of reconstruct frame buffer.
pu8ReferenceFrame	UINT8*	The address of reference frame buffer
pu8SysInfoBuffer	UINT8*	The address of system info buffer
pu8DMABuffer_virt	UINT8*	The physical address of DMA buffer
nvop_ioctl	INT32	This parameter is valid only on FAVC_IOCTL_ENCODE_NVOP
multi_slice	UINT32	Multi-slice mode
pic_height	UINT32	This parameter is used to keep the frame height for sps and pps on Multi Slice mode
pic_width	UINT32	This parameter is used to keep the frame width for sps and pps on Multi Slice mode
img_fmt	UINT32	0: 2D format, CbCr interleave, named H264_2D (VideoIn supported only)
control	UINT32	0 : Do NOT force one frame as one slice(default), 1 : Force one frame as one slice

## 12.5 API FUNCTION

### ***H264Dec\_Open***

#### **Synopsis**

```
int H264Dec_open(void);
```

#### **Description**

Initialize H264 Decoder and install interrupt service routine.

#### **Parameter**

None

#### **Return Value**

>=0	Decoder handle
-1	Fail

### ***H264Enc\_Open***

#### **Synopsis**

```
int H264Enc_Open(void);
```

#### **Description**

Initialize H264 Encoder and install interrupt service routine.

## Parameter

None

## Return Value

>=0	Encoder handle
-1	Fail

## ***H264\_ioctl***

### Synopsis

```
int H264_ioctl(int cmd, void* param);
```

### Description

Perform the H264 encoder/decoder related operation

### Parameter

cmd	Specify the operation for Encoder or Decoder which is defined
in ioctl	
	command set.
param	The pointer to FAVC_ENC_PARAM or
FAVC_DEC_PARAM	dependent on cmd

### Return Value

0	Success
-1	Fail

## ***H264\_ioctl\_ex***

### Synopsis

```
int H264_ioctl(int handle, int cmd, void* param);
```

### Description

Perform the H264 encoder/decoder related operation for multi-codec

### Parameter

handle	Specify the handle for Encoder or Decoder which gets from
	H264Dec_Open or H264Enc_Open function.
cmd	Specify the operation for Encoder or Decoder which is defined
in ioctl	
	command set.
param	The pointer to FAVC_ENC_PARAM or
FAVC_DEC_PARAM	dependent on cmd

### Return Value

0	Success
-1	Fail

### ***H264Enc\_Close***

#### **Synopsis**

```
void H264Enc_Close(void);
```

#### **Description**

This function is used for only one Encoder. Close H264 Encoder and free related buffer allocation.

#### **Parameter**

None

#### **Return Value**

None

### ***H264Enc\_Close\_ex***

#### **Synopsis**

```
void H264Enc_Close_ex(int handle);
```

#### **Description**

This function is used for multi-encoder. Close H264 Encoder and free related buffer allocation for encoder with specified handle.

#### **Parameter**

None

#### **Return Value**

None

### ***H264Dec\_Close***

#### **Synopsis**

```
void H264Dec_Close (void);
```

#### **Description**

This function is used for only one decoder. Close H264 Decoder and free related buffer allocation.

#### **Parameter**

None

**Return Value**

None

***H264Dec\_Close\_ex***
**Synopsis**

```
void H264Dec_Close_ex (int handle);
```

**Description**

This function is used for multi-decoder. Close H264 Decoder and free related buffer allocation for decoder with specified handle

**Parameter**

None

**Return Value**

None

***nv\_malloc***
**Synopsis**

```
void* nv_malloc(int size, int alignment);
```

**Description**

Allocate memory in size which is alignment.

**Parameter**

size                      specify the allocated memory size  
alignment   specify the allocated memory alignment

**Return Value**

Pointer to allocated memory

***nv\_free***
**Synopsis**

```
int nv_free(void* ptr);
```

**Description**

Free the memory specified by ptr.

**Parameter**

ptr                      pointer to memory which is to free.

**Return Value**

0

Success

## 12.6 RETURN CODE TABLE

### 12.6.1 AVC\_RET

API return value for decoder

Name	Value	Description
RETCODE_OK	0	
RETCODE_ERR_MEMORY	1	
RETCODE_ERR_API	2	
RETCODE_ERR_HEADER	3	
RETCODE_ERR_FILL_BUFFER	4	
RETCODE_ERR_FILE_OPEN	5	
RETCODE_HEADER_READY	6	
RETCODE_BS_EMPTY	7	
RETCODE_WAITING	8	
RETCODE_DEC_OVERFLOW	9	
RETCODE_HEADER_FINISH	10	
RETCODE_DEC_TIMEOUT	11	
RETCODE_PARSING_TIMEOUT	12	
RETCODE_ERR_GENERAL	13	
RETCODE_NOT_SUPPORT	14	
RETCODE_FAILURE	15	
RETCODE_FRAME_NOT_COMPLETE	16	

## 13 I2C LIBRARY

### 13.1 OVERVIEW

This library provides APIs for programmers to access I2C slaves connecting with N9H26 I2C interfaces. The default clock frequency is configured at 100 kHz after `i2cOpen()` is called, programmers could use `i2cIoctl()` function to change the frequency.

The maximum receive/transmit buffer length of this library is 450 bytes, which includes slave address and sub address. Data beyond this range will be ignored.

The I2C library will get the APB clock frequency from system library, application must set the CPU clock before using I2C library.

### 13.2 I2C LIBRARY APIS SPECIFICATION

#### ***i2cInit***

##### **Synopsis**

INT32 i2cInit(VOID)

##### **Description**

This function configures GPIO to I2C mode.

##### **Parameter**

None

##### **Return Value**

0 Always successes

##### **Example**

```
i2cInit();
```

#### ***i2cOpen***

##### **Synopsis**

INT32 i2cOpen(VOID)

##### **Description**

This function initializes the software resource, enables I2C engine clock and sets the clock frequency to 100 kHz.

**Parameter**

None

**Return Value**

0                      Successful  
I2C\_ERR\_BUSY    Interface already opened

**Example**

```
INT32      status;
status = i2cOpen();
```

***i2cClose***
**Synopsis**

INT32 i2cClose(VOID)

**Description**

This function disables I2C engine clock.

**Parameter**

None

**Return Value**

0                      Successful

**Example**

```
i2cClose();
```

***i2cRead***
**Synopsis**

INT32 i2cRead(PUINT8 buf, UINT32 len)

**Description**

This function reads data from I2C slave.

**Parameter**

buf              Receive buffer pointer  
len              Receive length

**Return Value**

> 0                      Return read length on success

I2C_ERR_BUSY	Interface busy
I2C_ERR_IO	Interface not opened
I2C_ERR_NACK	Slave returns an erroneous ACK
I2C_ERR_LOSTARBITRATION	Arbitration lost during transmission

**Example**

```

UCHAR8 buf[8];
INT32 len = 0;
len = i2cRead(buf, 8); // Read 8 bytes from i2c slave

```

***i2cRead\_OV***
**Synopsis**

```
INT32 i2cRead_OV(PUINT8 buf, UINT32 len)
```

**Description**

This function reads data from OmniVision sensor.

**Parameter**

buf	Receive buffer pointer
len	Receive length

**Return Value**

> 0	Return read length on success
I2C_ERR_BUSY	Interface busy
I2C_ERR_IO	Interface not opened
I2C_ERR_NACK	Slave returns an erroneous ACK
I2C_ERR_LOSTARBITRATION	Arbitration lost during transmission

**Example**

```

UCHAR8 buf[1];
INT32 len = 0;
len = i2cRead_OV(buf, 1); // Read one bytes from OmniVision sensor

```

***i2cWrite***
**Synopsis**

```
INT32 i2cWrite(PUINT8 buf, UINT32 len)
```

**Description**



This function writes data to I2C slave.

### Parameter

buf      Transmit buffer pointer

len Transmit length

### Return Value

> 0                      Return writes length on success

I2C\_ERR\_BUSY                      Interface busy

I2C_ERR_IO	Interface not opened
------------	----------------------

I2C ERR NACK      Slave returns an erroneous ACK

I2C_ERR_LOSTARBITRATION	Arbitration lost during transmission
-------------------------	--------------------------------------

### Example

```

UINT8 buf [5] = {0x00, 0x01, 0x02, 0x03, 0x04};
UINT32 len;

len = i2cWrite(buf, 5); // Write 5 bytes to I2C slave

```

***i2cloctl***

## Synopsis

```
INT32 i2cloctl(UINT32 cmd, UINT32 arg0, UINT32 arg1)
```

### Description

This function allows programmers configure I2C interface, the supported command and arguments listed in the table below.

Command	Argument 0	Argument 1	Description
I2C_IOC_SET_DEV_ADDRESS	Unsigned integer stores the slave address	Not used	This command sets the slave address
I2C_IOC_SET_SPEED	Unsigned integer stores the new frequency	Not used	Valid clock frequencies are 100 kHz and 400 kHz
I2C_IOC_SET_SUB_ADDRESS	Unsigned integer stores the sub address	Sub-address length	This command sets the sub-address and its length
I2C_IOC_SET_SINGLE_MASTER	Enable single master mode	Not used	This command enable/disable single master mode

### Parameter

cmd	Command
-----	---------

arg0      First argument of the command

arg1      Second argument of the command

**Return Value**

0                              On Success  
 I2C\_ERR\_IO                  Interface not activated  
 I2C\_ERR\_NOTTY Command not support, or parameter error

**Example**

```
/* Set clock frequency to 400 kHz */
i2cIoctl(I2C_IOC_SET_SPEED, 400, 0);
```

***i2cExit***
**Synopsis**

INT32 i2cExit(VOID)

**Description**

This function does nothing.

**Parameter**

None

**Return Value**

0 Always successful

**Example**

```
i2cExit();
```

### 13.3 ERROR CODE TABLE

Code Name	Value	Description
I2C_ERR_LOSTARBITRATION	0xFFFF1101	Arbitration lost during transmission
I2C_ERR_BUSBUSY	0xFFFF1102	I2C bus is busy
I2C_ERR_NACK	0xFFFF1103	Slave returns an erroneous ACK
I2C_ERR_SLAVENACK	0xFFFF1104	slave not respond after address
I2C_ERR_NODEV	0xFFFF1105	Interface number out of range
I2C_ERR_BUSY	0xFFFF1106	Interface busy
I2C_ERR_IO	0xFFFF1107	Interface not activated
I2C_ERR_NOTTY	0xFFFF1108	Command not support, or parameter error



## 14 I2S LIBRARY

### 14.1 OVERVIEW

This library provides APIs for programmers to play/record PCM audio data from I2S engine.

### 14.2 API FUNCTIONS

#### *DrvI2S\_Open*

**Synopsis**

VOID DrvI2S\_Open(VOID)

**Description**

This function will open I2S pins and engine clock.

**Parameter**

None

**Return Value**

None

**Example**

```
DrvI2S_Open();
```

#### *DrvI2S\_Close*

**Synopsis**

VOID DrvI2S\_Close(VOID)

**Description**

This function will close I2S pins and engine clock.

**Parameter**

None

**Return Value**

None

**Example**

```
DrvI2S_Close();
VOID DrvI2S_StartPlay (
    S_DRVI2S_PLAY* psPlayStruct
)
```

### ***DrvI2S\_EnableInt***

#### **Synopsis**

```
VOID DrvI2S_EnableInt (UINT32 u32InterruptFlag, PFN_DRVI2S_CB_FUNC*
    pfnCallBack)
```

#### **Description**

Enable the selected interrupt and setup the callback function, respectively.

#### **Parameter**

u32InterruptFlag	Selected interrupt
pfnCallBack	Callback function

#### **Return Value**

None

#### **Example**

```
DrvI2S_EnableInt (DRVI2S_IRQ_PLAYBACK, audio_PlayCallBack);
```

### ***DrvI2S\_DisableInt***

#### **Synopsis**

```
VOID DrvI2S_DisableInt (UINT32 u32InterruptFlag)
```

#### **Description**

Disable the related interrupt

#### **Parameter**

u32InterruptFlag	Selected interrupt
------------------	--------------------

#### **Return Value**

None

#### **Example**

```
DrvI2S_DisableInt (DRVI2S_IRQ_PLAYBACK);
```

### ***DrvI2S\_ClearInt***

#### **Synopsis**

VOID DrvI2S\_ClearInt (UINT32 u32InterruptFlag)

#### **Description**

Clear the related interrupt flag

#### **Parameter**

u32InterruptFlag    Interrupt flag

#### **Return Value**

None

#### **Example**

```
DrvI2S_ClearInt (DRV_I2S_IRQ_RECORD);
```

### ***DrvI2S\_PollInt***

#### **Synopsis**

VOID DrvI2S\_PollInt (UINT32 u32InterruptFlag)

#### **Description**

Get the status of related interrupt flag

#### **Parameter**

u32InterruptFlag    Selected interrupt flag

#### **Return Value**

Current status of selected interrupt flag

#### **Example**

```
IntStatus = DrvI2S_PollInt (DRV_I2S_IRQ_RECORD);
```

### ***DrvI2S\_StartPlay***

#### **Synopsis**

VOID DrvI2S\_StartPlay(S\_DRV\_I2S\_PLAY\* psPlayStruct)

#### **Description**

After opening I2S pins and engine clock, this function will trigger I2S engine to start playing.

#### **Parameter**

psPlayStruct      Structure pointer for Play related parameters

**Return Value**

None

**Example**

```
DrvI2S_StartPlay((S_DRVI2S_PLAY*) &g_sPlay);
```

***DrvI2S\_StopPlay***

**Synopsis**

VOID DrvI2S\_StopPlay (VOID)

**Description**

Stop playing.

**Parameter**

None

**Return Value**

None

**Example**

```
DrvI2S_StopPlay();
```

***DrvI2S\_StartRecord***

**Synopsis**

VOID DrvI2S\_StartRecord(S\_DRVI2S\_RECORD\* psRecordStruct)

**Description**

After opening I2S pins and engine clock, this function will trigger I2S engine to start recording.

**Parameter**

psRecordStruct      Structure pointer for Record related parameters

**Return Value**

None

**Example**

```
DrvI2S_StartRecord((S_DRVI2S_RECORD*) &g_sRecord);
```

### ***DrvI2S\_StopRecord***

**Synopsis**

VOID DrvI2S\_StopRecord (VOID)

**Description**

Stop recording.

**Parameter**

None

**Return Value**

None

**Example**

```
DrvI2S_StopRecord();
```

### ***DrvI2S\_SetSampleRate***

**Synopsis**

VOID DrvI2S\_SetSampleRate(E\_DRVI2S\_SAMPLING eSampleRate)

**Description**

Set Play/Record sampling rate.

**Parameter**

eSampleRate      Given sampling rate.

**Return Value**

None

**Example**

```
DrvI2S_SetSampleRate((E_DRVI2S_SAMPLING) eDRV12S_FREQ_44100);
```



## 15 JPEG LIBRARY

### 15.1 OVERVIEW

N9H26 Non-OS library consists of a set of libraries. These libraries are built to access those on-chip functions such as VPOST, APU, SIC, USBH, USBD, GPIO, I2C, SPI and UART, as well as File System (NVTfAT), USB Mass Storage devices (UMAS) and NAND Flash devices (GNAND). This document describes the provided APIs of JPEG library. With these APIs, user can quickly build a binary target for JPEG library on N9H26 microprocessor.

### 15.2 JPEG OVERVIEW

This library is designed to make user application to use N9H26 JPEG more easily.

The JPEG library has the following features:

- JPEG Normal / Encode function
- JPEG Encode Upscale function
- JPEG Decode Downscale function
- JPEG Window Decode function
- JPEG Decode Input Wait function
- JPEG Decode Output Wait function

### 15.3 PROGRAMMING GUIDE

#### System Overview

The JPEG Codec supports Baseline Sequential Mode JPEG still image compression and decompression that is fully compliant with ISO/IEC International Standard 10918-1 (T.81). The features and capability of the JPEG codec are listed below.

#### JPEG Features


- Support to encode interleaved YCbCr 4:2:2/4:2:0 and gray-level (Y only) format image
- Support to decode interleaved YCbCr 4:4:4/4:2:2/4:2:0/4:1:1 and gray-level (Y only) format image
- Support to decode YCbCr 4:2:2 transpose format
- The encoded JPEG bit-stream format is fully compatible with JFIF and EXIF standards
- Support Capture and JPEG hardware on-the-fly access mode for encode
- Support JPEG and Playback hardware on-the-fly access mode for decode
- Support software input/output on-the-fly access mode for both encode and decode
- Support arbitrary width and height image encode and decode

- Support three programmable quantization-tables
- Support standard default Huffman-table and programmable Huffman-table for decode
- Support arbitrarily 1X~8X image up-scaling function for encode mode
- Support down-scaling function for encode and decode modes
- Support specified window decode mode
- Support quantization-table adjustment for bit-rate and quality control in encode mode
- Support rotate function in encode mode


## JPEG Operation Control

### Memory access


The following figure shows the encode mode to access the source data which are from sensor normally and stored on the SDRAM.




Following figure shows the decode mode to output the decoded raw data on the SDRAM.




User can use stride function to output decoded image to any position on the Display Frame Buffer for Display. Following figure shows the decode mode with stride to output the decoded raw data on the Display Frame Buffer.



**Encode operation flow**




## Decode operation flow




## Decode stride

Before clearing Header Decode End interrupt, the value of stride must be set to stride value instead of original width. Offset is the difference between Stride and Image width. If Offset is 0, the decoded Raw data is continuous.



## Window Decode

The JPEG decoder supports specified window decode mode. This function allows user to specify a sub-window region within the whole image to be decoded as shown in the following figure. Only the specified window region image will be decoded and stored to frame memory.




## Decode Input Wait

When the JPEG is in decoding mode, the input source is the JPEG bit-stream written by software. The bit-stream buffer size is in 2K unit dual-buffer manner. If the buffer-size is 2KB, user needs to fill 1KB bit-stream into one of the half buffer region before resuming JPEG operation when an input-wait interrupt is generated.


When JPEG engine decodes one of the half buffers, the Decode Input Wait call back function will be called. The Only thing user needs to do is to fill bit stream to the other buffer like the following Step 1 & Step 2 until entire

bit stream is filled into the buffer.

[Step 1] JPEG engine decodes the data in Buffer 0 and S/W fills the data into Buffer 1



[Step 2] JPEG engine decodes the data in Buffer1 and S/W fills the data into Buffer 0




## Decode Output Wait

When there is not enough continuous space to store the decode output raw data, JPEG engine support a function to output data partially. User can get the whole data by assigning several output data address and size settings (JPEG\_IOCTL\_SET\_DECOUPTWAIT). Using this function, user can get the JPEG decoded image that larger than the available continuous memory space.

The decode output wait call back function will be called when the Output Data size is equal to the Size assigned

by IOCTL - JPEG\_IOCTL\_SET\_DECOUPTWAIT. In the call back function, user should move the data to it's destination address and call the IOCTL again to set next address and data size.

The data size of the final ICOTL must equal to the extract output size. Otherwise, user will get the Decode complete interrupt instead of Decode output wait interrupt.



## Header Decode Complete

In the callback function, user can get JPEG image width and height by calling `jpegGetInfo()`. After getting the information, user can use `jpegIoctl` to

- Allocate and set output buffer → `JPEG_IOCTL_SET_YADDR` for Packet format Only
- Change output buffer address → `JPEG_IOCTL_SET_YADDR` for Packet format Only
- Set Downscale → `JPEG_IOCTL_SET_DECODE_DOWNSCALE`
- Set Decode output Stride → `JPEG_IOCTL_SET_DECODE_STRIDE`
- Set windows decode → `JPEG_IOCTL_SET_WINDOW_DECODE`

## 15.4 JPEG LIBRARY CONSTANT DEFINITION



## Encode operation

Name	Value	Description
Encode format		
JPEG_ENC_PRIMARY	0	Encode operation : Primary JPEG
JPEG_ENC_THUMBNAIL	1	Encode operation : Thumbnail JPEG
JPEG_ENC_SOURCE_PLANAR	0	Encode source : planar format
JPEG_ENC_SOURCE_PACKET	1	Primary Encode source : packet format
JPEG_ENC_PRIMARY_YUV420	0xA0	Primary Encode image format : YUV 4:2:0
JPEG_ENC_PRIMARY_YUV422	0xA8	Primary Encode image format : YUV 4:2:2
JPEG_ENC_PRIMARY_GRAY	0xA1	Primary Encode image format : GRAY
JPEG_ENC_THUMBNAIL_YUV420	0x90	Thumbnail Encode image format : YUV 4:2:0
JPEG_ENC_THUMBNAIL_YUV422	0x98	Thumbnail Encode image format : YUV 4:2:2
JPEG_ENC_THUMBNAIL_GRAY	0x91	Thumbnail Encode image format : GRAY
Encode Header control		
JPEG_ENC_PRIMARY_DRI	0x10	Restart Interval in Primary JPEG Header
JPEG_ENC_PRIMARY_QTAB	0x20	Quantization-Table in Primary JPEG Header
JPEG_ENC_PRIMARY_HTAB	0x40	Huffman-Table in Primary JPEG Header
JPEG_ENC_PRIMARY_JFIF	0x80	JFIF Header in Primary JPEG Header
JPEG_ENC_THUMBNAIL_DRI	0x1	Restart Interval in Thumbnail JPEG Header
JPEG_ENC_THUMBNAIL_QTAB	0x2	Quantization-Table in Thumbnail JPEG Header
JPEG_ENC_THUMBNAIL_HTAB	0x4	Huffman-Table in Thumbnail JPEG Header
JPEG_ENC_THUMBNAIL_JFIF	0x8	JFIF Header in Thumbnail JPEG Header

## Decode operation

Name	Value	Description
Decode output format		
JPEG_DEC_PRIMARY_PLANAR_YUV	0x8021	Primary Decode output format : planar format
JPEG_DEC_PRIMARY_PACKET_YUV422	0x0021	Primary Decode output format : planar YUV422
JPEG_DEC_PRIMARY_PACKET_RGB555	0x004021	Primary Decode output format : packet RGB555
JPEG_DEC_PRIMARY_PACKET_RGB555R1	0x404021	Primary Decode output format :

		packet RGB555R1
JPEG_DEC_PRIMARY_PACKET_RGB555R2	0x804021	Primary Decode output format : packet RGB555R2
JPEG_DEC_PRIMARY_PACKET_RGB565	0x006021	Primary Decode output format : packet RGB565
JPEG_DEC_PRIMARY_PACKET_RGB565R1	0x406021	Primary Decode output format : packet RGB565R1
JPEG_DEC_PRIMARY_PACKET_RGB565R2	0x806021	Primary Decode output format : packet RGB565R2
JPEG_DEC_PRIMARY_PACKET_RGB888	0x14021	Primary Decode output format : packet RGB888
JPEG_DEC_THUMBNAIPLANAR_YUV	0x8031	Thumbnail Decode output format : planar YUV
JPEG_DEC_THUMBNAI_PACKET_YUV422	0x0031	Thumbnail Decode output format : packet RGB555
JPEG_DEC_THUMBNAI_PACKET_RGB555	0x4031	Thumbnail Decode output format : packet RGB565
JPEG format		
JPEG_DEC_YUV420	0x000	JPEG format is YUV420
JPEG_DEC_YUV422	0x100	JPEG format is YUV422
JPEG_DEC_YUV444	0x200	JPEG format is YUV444
JPEG_DEC_YUV411	0x300	JPEG format is YUV411
JPEG_DEC_GRAY	0x400	JPEG format is Gray
JPEG_DEC_YUV422T	0x500	JPEG format is YUV422 Transport

## JPEG Library Property Definition

The JPEG library provide property structure to set JPEG property.

JPEG\_INFO\_T;

Name	Value	Description
yuvformat	JPEG_DEC_YUV420 JPEG_DEC_YUV422 JPEG_DEC_YUV444 JPEG_DEC_YUV411 JPEG_DEC_GRAY JPEG_DEC_YUV422T	JPEG format (Decode only)
width	< 8192	Decode Output width (Decode only)
height	< 8192	Decode Output height (Decode only)
jpeg_width	< 65535	JPEG width (Decode only)

jpeg_height	< 65535	JPEG height (Decode only)
stride	< 8192	Decode output Stride (Decode only)
bufferend	Reserved	Reserved
image_size[2]	< 2 <sup>24</sup> -1	Encode Bitstream Size (Encode Only)

The JPEG library provide window decode function, user can partially decode the JPEG image by MCU unit (16 pixels \*16 pixels).

JPEG\_WINDOW\_DECODE\_T

Name	Value	Description
u16StartMCUX	0~511	Decode MCU Horizontal Start index
u16StartMCUY	0~511	Decode MCU Vertical Start index
u16EndMCUX	0~511	Decode MCU Horizontal End index
u16EndMCUY	0~511	Decode MCU Vertical End index
u32Stride	< 8192	Decode output Stride

## 15.5 JPEG API

### *jpegOpen*

#### Synopsis

INT jpegOpen(VOID)

#### Description

This function initializes the software resource, sets the engine clock and enables its interrupt

#### Parameter

None

#### Return Value

E\_SUCCESS - Always successes

#### Example

```
jpegOpen();
```

### *jpegClose*

#### Synopsis

VOID jpegClose(VOID)

**Description**

Disable clock of JPEG engine and disable its interrupt

**Parameter**

None

**Return Value**

None

**Example**

```
jpegClose();
```

***jpegInit***

**Synopsis**

VOID jpegInit(VOID)

**Description**

Reset JPEG engine and set default value to its registers

**Parameter**

None

**Return Value**

None

**Example**

```
jpegInit();
```

***jpegGetInfo***

**Synopsis**

VOID jpegGetInfo(JPEG\_INFO\_T \*info)

**Description**

This function can get JPEG width and height after header decode complete and get JPEG bit stream size after encode complete.

**Parameter**

info                      JPEG Data type pointer stores the returned JPEG header information

**Return Value**

None

**Example**

```
JPEG_INFO_T jpegInfo;
/* Get JPEG Header information */
jpegGetInfo(&jpegInfo);
```

***jpegWait***

**Synopsis**

INT jpegWait(VOID)

**Description**

After triggers JPEG engine, application need to wait the completion flag while JPEG engine completes it's job.

**Parameter**

None

**Return Value**

E_FAIL	Error happen
E_SUCCESS	Action is done

**Example**

```
jpegWait();
```

***jpegIsReady***

**Synopsis**

BOOL jpegIsReady(VOID)

**Description**

The function can get the JPEG engine status.

**Parameter**

None

**Return Value**

TRUE	Engine is ready
FALSE	Engine is busy

**Example**

```
jpegIsReady ();
```

***jpegSetQTAB***

**Synopsis**

```
INT jpegSetQTAB(
    PUINT8    puQTable0,
    PUINT8    puQTable1,
    PUINT8    puQTable2,
    UINT8     u8num
);
```

**Description**

The function can specify the Quantization table

**Parameter**

puQTable0	Specify the address of Quantization table 0
puQTable1	Specify the address of Quantization table 1
puQTable2	Specify the address of Quantization table 2
u8num	Specify the number of Quantization table

**Return Value**

E\_SUCCESS : Success  
E\_JPEG\_TIMEOUT : Set Quantization table timeout

**Example**

```
jpegSetQTAB(g_au8QTable0,g_au8QTable1, 0, 2);
```

***jpegIoctl***

**Synopsis**

```
VOID jpegIoctl(UINT32 cmd, UINT32 arg0, UINT32 arg1)
```

**Description**

This function allows programmers configure JPEG engine, the supported command and arguments listed in the table below.

Command	Argument 0	Argument 1	comment
---------	------------	------------	---------

JPEG_IOCTL_SET_YADDR	JPEG Y component frame buffer address		Specify the JPEG Y component frame buffer address.
JPEG_IOCTL_SET_YSTRIDE	JPEG Y component frame buffer stride		Specify the JPEG Y component frame buffer stride
JPEG_IOCTL_SET_USTRIDE	JPEG U component frame buffer stride		Specify the JPEG U component frame buffer stride
JPEG_IOCTL_SET_VSTRIDE	JPEG V component frame buffer stride		Specify the JPEG V component frame buffer stride
JPEG_IOCTL_SET_BITSTREAM_ADDR	JPEG bit stream buffer starting address		Specify the bit stream frame buffer starting address
JPEG_IOCTL_SET_SOURCE_IMAGE_HEIGHT	The encode source image height in pixel		Specify the encode source image height in pixel
JPEG_IOCTL_ENC_SET_HEADER_CONTROL	JPEG_ENC_PRIMARY_DRI JPEG_ENC_PRIMARY_QTAB JPEG_ENC_PRIMARY_HTAB JPEG_ENC_PRIMARY_JFIF		Specify the header information includes in the encoding bit stream
JPEG_IOCTL_SET_DEFAULT_QTAB			Specify the Quantization table
JPEG_IOCTL_SET_DECODE_MODE	JPEG_DEC_PRIMARY_PLANAR_YUV JPEG_DEC_PRIMARY_PACKET_YUV422 JPEG_DEC_PRIMARY_PACKET_RGB555 JPEG_DEC_PRIMARY_PACKET_RGB555R1 JPEG_DEC_PRIMARY_PACKET_RGB555R2 JPEG_DEC_PRIMARY_PACKET_RGB565 JPEG_DEC_PRIMARY_PACKET_RGB565R1 JPEG_DEC_PRIMARY_PACKET_RGB565R2 JPEG_DEC_PRIMARY_PACKET_RGB888		Specify the decoded image output format
JPEG_IOCTL_SET_ENCODE_MODE	JPEG_ENC_SOURCE_PLANAR JPEG_ENC_SOURCE_PACKET	JPEG_ENC_PRIMARY_YUV420 JPEG_ENC_PRIMARY_YUV422	Specify the encode source format and encoding image format
JPEG_IOCTL_SET_DIMENSION	Image height	Image width	Set the encode image dimension or decode output image dimension
JPEG_IOCTL_ENCODE_TRIGGER			Trigger the JPEG operation for encoding

JPEG_IOCTL_DECODE_TRIGGER			Trigger the JPEG operation for decoding
JPEG_IOCTL_WINDOW_DECODE	JPEG_WINDOW_DECODE_T		Enable window decode mode and set the decode window region
JPEG_IOCTL_SET_DECODE_STRIDE	Decode Output Stride (in pixel)		Specify the decode output stride
JPEG_IOCTL_SET_DECODE_DOWNSCALE	Scaled Height	Scaled Width	Set Decode downscale function
JPEG_IOCTL_SET_ENCODE_UPSCALE	Scaled Height	Scaled Width	Set Encode Upscale function
JPEG_IOCTL_SET_HEADER_DECODE_CALLBACKFUN	Header Decode Complete Call Back function pointer		Set Header Decode Complete Call Back function pointer
JPEG_IOCTL_SET_DECINPUWAIT_CALLBACKFUN	Decode Input Wait Call Back function pointer		Set Decode Input Wait Call Back function pointer
JPEG_IOCTL_ADJUST_QTAB	JPEG_ENC_PRIMARY JPEG_ENC_THUMBNAIL	Quantization-Table Adjustment and control values[0]	Set Quantization-Table Adjustment and control
JPEG_IOCTL_ENC_RESERVED_FOR_SOFTWARE	Reserved size		Reserve memory space for user application
JPEG_IOCTL_SET_UADDR	Address for U Component		Set address for U Component
JPEG_IOCTL_SET_VADDR	Address for V Component		Set address for V Component
JPEG_IOCTL_SET_ENCODE_PRIMARY_RESTART_INTERVAL	Primary Restart interval		Set Primary Restart interval size
JPEG_IOCTL_SET_ENCODE_THUMBNAIL_RESTART_INTERVAL	Thumbnail Restart interval		Set Thumbnail Restart interval size
JPEG_IOCTL_GET_ENCODE_PRIMARY_RESTART_INTERVAL	The pointer to store Primary Restart interval size		Get Primary Restart interval size
JPEG_IOCTL_GET_ENCODE_THUMBNAIL_RESTART_INTERVAL	The pointer to store Thumbnail Restart interval size		Get Thumbnail Restart interval size
JPEG_IOCTL_SET_THUMBNAIL_DIMENSION	Thumbnail Height	Thumbnail Width	Set Thumbnail Dimension
JPEG_IOCTL_SET_ENCODE_SW_OFFSET	Offset		Set Software Encode Offset
JPEG_IOCTL_GET_THUMBNAIL_DIMENSION	The pointer to store Thumbnail Height	The pointer to store Thumbnail Width	Get Thumbnail Dimension
JPEG_IOCTL_GET_ENCODE_SW_OFFSET	The pointer to store Encode Offset		Get Software Encode Offset



JPEG_IOCTL_SET_ENCODE_PRIMARY_DOWNSCALE	Primary Downscaled Height	Primary Downscaled Width	Set Primary Encode downscale Size (Planar format only)
JPEG_IOCTL_SET_ENCODE_THUMBNAIL_DOWNSCALE	Thumbnail Downscaled Height	Thumbnail Downscaled Width	Set Thumbnail Encode downscale Size (Planar format only)
JPEG_IOCTL_SET_ENCODE_PRIMARY_ROTATE_RIGHT			Encode rotate right (Planar format only)
JPEG_IOCTL_SET_ENCODE_PRIMARY_ROTATE_LEFT			Encode rotate left (Planar format only)
JPEG_IOCTL_SET_ENCODE_PRIMARY_ROTATE_NORMAL			Encode no rotate (Planar format only)
JPEG_IOCTL_SET_DECOUT_PUTWAIT_CALBACKFUN	Decode Output Wait call back function pointer		Set Decode Output Wait call back function (Packet format Only)
JPEG_IOCTL_SET_DECOUT_PUTWAIT	Data Output Address	Data Output Size	Set Decode Output Wait address and size
JPEG_IOCTL_GET_DECOUT_PUTWAIT_ADDR	The pointer to store Decode Output Wait Address		Get Decode Output Wait Address
JPEG_IOCTL_GET_DECOUT_PUTWAIT_SIZE	The pointer to store Decode Output Wait Size		Get Decode Output Wait Size

**Parameter**

cmd	Command
arg0	First argument of the command
arg1	Second argument of the command

**Return Value**

None

**Example**

```

/* Set Downscale to QVGA */
jpegloctl(JPEG_IOCTL_SET_DECODE_DOWNSCALE, 240, 320);

/* Set Decode Stride to Panel width (480 pixel)*/
jpegloctl(JPEG_IOCTL_SET_DECODE_STRIDE, 480, 0);

/* Set Decoded Image Address */
jpegloctl(JPEG_IOCTL_SET_YADDR, u32FrameBuffer, 0);

```

```

/* Set Bit stream Address */
jpegloctl(JPEG_IOCTL_SET_BITSTREAM_ADDR, u32BitStream, 0);

/* Set Decode Input Wait mode (Input wait buffer is 8192) */
jpegloctl(JPEG_IOCTL_SET_DECINPUTWAIT_CALLBACKFUN, (UINT32) JpegDecInputWait,
8192);

/* Decode mode */
jpegloctl(JPEG_IOCTL_SET_DECODE_MODE, JPEG_DEC_PRIMARY_PACKET_YUV422, 0);

/* Set JPEG Header Decode End Call Back Function */
jpegloctl(JPEG_IOCTL_SET_HEADERDECODE_CALLBACKFUN, (UINT32)
JpegDecHeaderComplete, 0);

/* Trigger JPEG decoder */
jpegloctl(JPEG_IOCTL_DECODE_TRIGGER, 0, 0);

/* Set Source Y/U/V Stride */
jpegloctl(JPEG_IOCTL_SET_YSTRIDE, u16Width, 0);
jpegloctl(JPEG_IOCTL_SET_USTRIDE, u16Width/2, 0);
jpegloctl(JPEG_IOCTL_SET_VSTRIDE, u16Width/2, 0);

/* Primary Encode Image Width / Height */
jpegloctl(JPEG_IOCTL_SET_DIMENSION, u16Height, u16Width);

/* Encode upscale 2x */
jpegloctl(JPEG_IOCTL_SET_ENCODE_UPSCALE, u16Height * 2, u16Width * 2);

/* Set Encode Source Image Height */
jpegloctl(JPEG_IOCTL_SET_SOURCE_IMAGE_HEIGHT, u16Height, 0);


/* Include Quantization-Table and Huffman-Table */
jpegloctl(JPEG_IOCTL_ENC_SET_HEADER_CONTROL, JPEG_ENC_PRIMARY_QTAB |

```

```
JPEG_ENC_PRIMARY_HTAB, 0);

/* Use the default Quantization-table 0, Quantization-table 1 */
jpegloctl(JPEG_IOCTL_SET_DEFAULT_QTAB, 0, 0);
```

**Note [0]**  
8 bits Quantization-Table Adjustment and control value.



Bits	Descriptions	
[7:4]	P_QADJUST	Primary Quantization-Table Adjustment If the sum of the position (x, y) of quantization-table is greater than <b>P_QADJUST</b> , the quantization value will be set to 127. Otherwise the value will keep as the original. 8x8 DCT block: x = 0~7, y = 0~7 if ((x+y) > P_QADJUST) => Q' = 127 else => Q' = Q
[3:0]	P_QVS	Primary Quantization-Table Scaling Control $Q' = (P\_QVS[3]*2*Q)+(P\_QVS[2]*Q)+(P\_QVS[1]*Q/2)+(P\_QVS[0]*Q/4)$

15.6 EXAMPLE CODE

This demo code has sample code for “Normal Encode”, “Encode Upscale”, “Normal Decode”, “Decode Downscale & Stride”, “Decode Input Wait”, and “Decode Output Wait” (write/read from SD Card). Please refer to the JPEG sample code of BSP Non-OS.

## 16 PWM LIBRARY

### 16.1 OVERVIEW

This library is designed to make user application to set N9H26 PWM more easily.

The PWM library has the following features:

- PWM signal frequency and duty setting
- PWM Capture function

### 16.2 PROGRAMMING GUIDE

#### System Overview

The N9H26 have 4 channels pwm-timers. The 4 channels pwm-timers has 2 prescalers, 2 clock dividers, 4 clock selectors, 4 16-bit counters, 4 16-bit comparators, 2 Dead-Zone generators. They are all driven by system clock. Each channel can be used as a timer and issue interrupt independently.

Each two channels pwm-timers share the same prescaler(channel0-1 share prescaler0 and channel2-3 share prescaler1). Clock divider provides each channel with 5 clock sources (1, 1/2, 1/4, 1/8, 1/16). Each channel receives its own clock signal from clock divider which receives clock from 8-bit prescaler. The 16-bit counter in each channel receive clock signal from clock selector and can be used to handle one pwm period. The 16-bit comparator compares number in counter with threshold number in register loaded previously to generate pwm duty cycle.

The N9H26 have 4 channels pwm-timers and each pwm-timer includes a capture channel. The Capture 0 and PWM 0 share a timer that included in PWM 0; and the Capture 1 and PWM 1 share another timer, and etc. Therefore user must setup the PWM-timer before turn on Capture feature. After enabling capture feature, the capture always latched PWM-counter to CRLR when input channel has a rising transition and latched PWM-counter to CFLR when input channel has a falling transition. Capture channel 0 interrupt is programmable by setting CCR0[1] (Rising latch Interrupt enable) and CCR0[2] (Falling latch Interrupt enable) to decide the condition of interrupt occur. Capture channel 1 has the same feature by setting CCR0[17] and CCR0[18]. And capture channel 2 & 3 has the same feature by setting CCR1[1], CCR1[2] and CCR1[17], CCR1[18] respectively. Whenever Capture issues Interrupt 0/1/2/3, the PWM counter 0/1/2/3 will be reload at this moment.

There are only four interrupts from PWM to advanced interrupt controller (AIC). PWM 0 and Capture 0 share the same interrupt channel, PWM1 and Capture 1 share the same interrupt and so on. Therefore, PWM function and Capture function in the same channel cannot be used at the same time.



#### PWM Features

- Two 8-bit prescalers and Two clock dividers
- Four clock selectors
- Four 16-bit counters and four 16-bit comparators
- Two Dead-Zone generators

- Capture function

## Block Diagram

The following figure describes the architecture of pwm in one group. (channel0&1 are in one group and channel2&3 are in another group)



## 16.3 PWM TIMER CONTROL

## Prescaler and clock selector

The PWM has two groups (two channels in each group) of timers. The clock input of the group is according to the PWM Prescaler Register (**PPR**) value. The PWM prescaler divided the clock input by PPR+1 before it is fed to the counter. Please notice that when the PPR value equals zero, the prescaler output clock will stop. Furthermore, according to the PWM Clock Select Register (**CSR**) value, the clock input of PWM timer channel can be divided by 1,2,4,8 and 16.

Consider following examples, which explain the PWM timer period (Duty).

$$\text{period} = \frac{1}{(\text{SourceClock}) \div (\text{PPR} + 1) \div \text{CSR}}$$

PWM source clock can be APLL/UPLL/XIN.

When the PWM engine clock = 60 MHz, the maximum and minimum PWM timer counting period is described as follows.

Maximum period: PPR = 255 (since the length of PPR is 8bit) and CSR = 16


$$\text{period}_{\max} = \frac{1}{(60\text{MHz}) \div (255 + 1) \div 16} = 68.266\mu\text{s}$$

Minimum period: PWM engine clock = 60 MHz, PPR=1 and CSR=1

$$\text{period}_{\min} = \frac{1}{(60\text{MHz}) \div (1 + 1) \div 1} = 0.0333\mu\text{s}$$

The maximum and minimum intervals between two interrupts depend on the  $\text{period}_{\max}$ ,  $\text{period}_{\min}$  and PWM Counter Register(**CNRx**) length. The maximum interval between two interrupts is  $(65535+1) \times (68.266\mu\text{s})$  since the length of CNR is 16bit. Please notice that the above calculation is based on the PWM engine clock = 60MHz. Therefore, all of the values need to be recalculated when the PWM engine clock is not equal to 60MHz.

## Basic Timer Operation




## PWM Double Buffering and Automatic Reload

N9H26 PWM Timers have a double buffering function, enabling the reload value changed for next timer operation without stopping current timer operation. Although new timer value is set, current timer operation still operate successfully.


The counter value can be written into CNR0~3 and current counter value can be read from PDR0~3.

The auto-reload operation copies from CNR0~3 to down-counter when down-counter reaches zero. If CNR0~3 are set as zero, counter will be halt when counter count to zero. If auto-reload bit is set as zero, counter will be stopped immediately




## PWM Double Buffering and Automatic Reload

The double buffering function allows CMR written at any point in current cycle. The loaded value will take effect from next cycle.




## PWM Double Buffering and Automatic Reload

N9H26 PWM is implemented with Dead Zone generator. They are built for power device protection. This function enables generation of a programmable time gap at the rising of PWM output waveform. User can program PPR [31:24] and PPR [23:16] to determine the two Dead Zone interval respectively.



## Capture Basic Timer Operation





At this case, the CNR is 8:

1. When set falling interrupt enable, the pwm counter will be reload at time of interrupt occur.
2. The channel low pulse width is (CNR – CRLR).
3. The channel high pulse width is (CRLR - CFLR).
4. The channel cycle time is (CNR – CFLR).

### 16.3.2 PWM LIBRARY CONSTANT DEFINITION

Name	Value	Description
PWM_TIMER0	0x0	PWM Timer 0
PWM_TIMER1	0x1	PWM Timer 1
PWM_TIMER2	0x2	PWM Timer 2
PWM_TIMER3	0x3	PWM Timer 3
PWM_CAP0	0x10	PWM Capture 0
PWM_CAP1	0x11	PWM Capture 1
PWM_CAP2	0x12	PWM Capture 2
PWM_CAP3	0x13	PWM Capture 3
PWM_CAP_ALL_INT	0	PWM Capture All Interrupt
PWM_CAP_RISING_INT	1	PWM Capture Rising Interrupt
PWM_CAP_FALLING_INT	2	PWM Capture Falling Interrupt
PWM_CAP_RISING_FLAG	6	Capture rising interrupt flag
PWM_CAP_FALLING_FLAG	7	Capture falling interrupt flag
PWM_CLOCK_DIV_1	1	Input clock divided by 1
PWM_CLOCK_DIV_2	2	Input clock divided by 2
PWM_CLOCK_DIV_4	4	Input clock divided by 4
PWM_CLOCK_DIV_8	8	Input clock divided by 8

PWM_CLOCK_DIV_16	16	Input clock divided by 16
PWM_TOGGLE_MODE	TRUE	PWM Timer Toggle mode
PWM_ONE_SHOT_MODE	FALSE	PWM Timer One-shot mode

## 16.3.3 PWM LIBRARY PROPERTY DEFINITION

The PWM library provides property structure to set PWM timer property.

Name	Value	Description
fFrequency	>= 0	The timer/capture frequency[0]
u8HighPulseRatio	1~100	High pulse ratio
u8Mode	PWM_ONE_SHOT_MODE / PWM_TOGGLE_MODE	PWM Timer Trigger mode
bInverter	TRUE / FALSE	Inverter Enable / Inverter Disable
u8ClockSelector	PWM_CLOCK_DIV_1/ PWM_CLOCK_DIV_2/ PWM_CLOCK_DIV_4/ PWM_CLOCK_DIV_8/ PWM_CLOCK_DIV_16	Clock Selector [1]
u16PreScale	2 ~ 256	Clock Prescale [1]
u32Duty	0~65535	Pulse duty [2]

[0] PWM provides two timer setting mode: Frequency-setting and Property-setting modes.

- Frequency-setting mode (**fFrequency** > 0)

User doesn't need to set **u8ClockSelector** / **u16PreScale** / **u32Duty** fields. PWM library will set the proper values according to current PWM engine clock automatically.

- Property-setting mode (**fFrequency** = 0)

- User must set **u8ClockSelector** / **u16PreScale** / **u32Duty** fields by himself. Please refer to the previous section "Prescaler and clock selector."

[1] The value take effect only when Property-setting mode.

[2] The value takes effect when Property-setting mode or the Capture functions. It is the capture monitor period.

## 16.4 PWM API

### ***PWM\_Open***

#### **Synopsis**

VOID PWM\_Open (VOID)

#### **Description**

Enable PWM engine clock and reset PWM

#### **Parameter**

None

#### **Return Value**

None

#### **Example**

```
/* Enable PWM clock */
PWM_Open();
```

### ***PWM\_Close***

#### **Synopsis**

VOID PWM\_Close (VOID)

#### **Description**

Disable PWM engine clock and the I/O enable

#### **Parameter**

None

#### **Return Value**

None

#### **Example**

```
/* Disable PWM clock */
PWM_Close();
```

### ***PWM\_SetClockSetting***

#### **Synopsis**

BOOL PWM\_SetClockSetting(E\_SYS\_SRC\_CLK eSrcClk, UINT32 u32PIIDiver,  
UINT32 u32EngineDiver)

#### **Description**

This function is used to set PWM engine clock source and divider

**Parameter**

eSrcClk	PWM clock source.
It could be eSYS_EXT=0, eSYS_APLL= 2 and eSYS_UPLL = 3.	
u32PIIDiver	PWM PLL divider selection (1~8)
u32EngineDiver	Engine clock divider (1~256)

**Return Value**

TRUE	- Success.
FALSE	- Setting Fail..

**Note**

1. Parameter "u32PIIDiver" is only be valid when eSrcClk is eSYS\_APLL or eSYS\_UPLL

**Example**

```
/* PWM Engine clock is UPLL / 4, and Engine Clock divider is 2 */
PWM_SetClockSetting(eSYS_UPLL, 4, 2);
```

**PWM\_GetEngineClock**
**Synopsis**

```
UINT32 PWM_GetEngineClock(E_SYS_SRC_CLK* peSrcClk)
```

**Description**

This function is used to get current PWM engine clock

**Parameter**

peSrcClk	PWM engine clock source pointer.
It could be eSYS_EXT=0, eSYS_APLL= 2 and eSYS_UPLL = 3.	

**Return Value**

PWM Engine Clock (Hz)

**Example**

```
u32PWMClock = PWM_GetEngineClock(&eSrcClk);
sysprintf("PWM Clock Source is ");
switch(eSrcClk)
{
```

```

case eSYS_EXT:
    sysprintf("External Crystal\n");
    break;
case eSYS_APLL:
    sysprintf("APLL\n");
    break;
case eSYS_UPLL:
    sysprintf("UPLL\n");
    break;
}
sysprintf("PWM Clock is %dHz\n",u32PWMClock);

```

### ***PWM\_SetTimerClk***

#### **Synopsis**

Float PWM\_SetTimerClk (UINT8 u8Timer, PWM\_TIME\_DATA\_T \*sPt)

#### **Description**

This function is used to configure the frequency/pulse/mode/inverter function

#### **Parameter**

u8Timer	The function to be set PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3 PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3
sPt	PWM property information

#### **Return Value**

= 0	- Setting Fail.
> 0	- Success. The actual frequency by PWM timer.

#### **Note**

2. The function will set the frequency property automatically (It will change the parameters to the values that it sets to hardware) when user set a nonzero frequency value
3. The function can set the proper frequency property (Clock selector/Prescale) for capture function and user needs to set the proper pulse duty by himself.

#### **Example**

```
/* Set PWM Timer 0 Configuration */
```

```
PWM_SetTimerClk(PWM_TIMER0,&sPt);
```

### **PWM\_SetTimerIO**

#### **Synopsis**

```
VOID PWM_SetTimerIO (UINT8 u8Timer, BOOL bEnable)
```

#### **Description**

This function is used to enable/disable PWM timer/capture I/O function

#### **Parameter**

u8Timer	The function to be set PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3 PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3
bEnable	Enable (TRUE) / Disable (FALSE)

#### **Return Value**

None

#### **Example**

```
/* Enable Output for PWM Timer 0 */
PWM_SetTimerIO(PWM_TIMER0,TRUE);
```

### **PWM\_Enable**

#### **Synopsis**

```
VOID PWM_Enable (UINT8 u8Timer, BOOL bEnable)
```

#### **Description**

This function is used to enable PWM timer / capture function

#### **Parameter**

u8Timer	The function to be set PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3 PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3
bEnable	Enable (TRUE) / Disable (FALSE)

#### **Return Value**

None

#### **Example**

```
/* Enable the PWM Timer0 */
PWM_Enable(PWM_TIMER0,TRUE);
```

### ***PWM\_IsTimerEnabled***

#### **Synopsis**

BOOL PWM\_IsTimerEnabled (UINT8 u8Timer)

#### **Description**

This function is used to get PWM specified timer enable/disable state

#### **Parameter**

u8Timer	The function to be set PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3
---------	--

#### **Return Value**

TURE	- The specified timer is enabled.
FALSE	- The specified timer is disabled.

#### **Example**

```
/* Check PWM Timer0 is enabled or not */
If (PWM_IsTimerEnabled(PWM_TIMER0))
    sysprintf("PWM Timer 0 is enabled\n");
else
    sysprintf("PWM Timer 0 isn't enabled\n");
```

### ***PWM\_SetTimerCounter***

#### **Synopsis**

VOID PWM\_SetTimerCounter (UINT8 u8Timer, UINT16 u16Counter)

#### **Description**

This function is used to set the PWM specified timer counter

#### **Parameter**

u8Timer	The function to be set PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3
u16Counter	The timer value. (0~65535)

#### **Return Value**

None

**Note**

If the counter is set to 0, the timer will stop.

**Example**

```
/* Set PWM Timer 0 counter as 0 */
PWM_SetTimerCounter(PWM_TIMER0,0);
```

**PWM\_GetTimerCounter**

**Synopsis**

UINT32 PWM\_GetTimerCounter (UINT8 u8Timer)

**Description**

This function is used to get the PWM specified timer counter value

**Parameter**

u8Timer	The function to be set
	PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3

**Return Value**

The specified timer-counter value

**Example**

```
/* Loop when Counter of PWM Timer0 isn't 0 */
while(PWM_GetTimerCounter(PWM_TIMER0));
```

**PWM\_EnableDeadZone**

**Synopsis**

VOID PWM\_EnableDeadZone (UINT8 u8Timer, UINT8 u8Length, BOOL bEnableDeadZone)

**Description**

This function is used to set the dead zone length and enable/disable Dead Zone function

**Parameter**

u8Timer	The function to be set
	PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3
u8Length	Dead Zone Length : 0~255



bEnableDeadZone Enable DeadZone (TRUE) / Disable DeadZone (FALSE)

#### Return Value

None

#### Note

1. If Deadzone for PWM\_TIMER0 or PWM\_TIMER1 is enabled, the output of PWM\_TIMER1 is inverse waveform of PWM\_TIMER0.
2. If Deadzone for PWM\_TIMER2 or PWM\_TIMER3 is enabled, the output of PWM\_TIMER3 is inverse waveform of PWM\_TIMER2.

#### Example

```
/* Enable Deadzone of PWM Timer 0 and set it to 100 units*/
PWM_EnableDeadZone(PWM_TIMER0, 100, TRUE)
```

### **PWM\_EnableInt**

#### Synopsis

VOID PWM\_EnableInt (UINT8 u8Timer, UINT8 u8Int)

#### Description

This function is used to enable the PWM timer/capture interrupt

#### Parameter

u8Timer	The function to be set PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3 PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3
u8Int capture	Capture interrupt type (The parameter is valid only when function) PWM_CAP_RISING_INT: The capture rising interrupt. PWM_CAP_FALLING_INT: The capture falling interrupt. PWM_CAP_ALL_INT: All capture interrupt.

#### Return Value

None

#### Example

```
/* Enable Interrupt Sources of PWM Timer 0 */
PWM_EnableInt(PWM_TIMER0,0);
/* Enable Interrupt Sources of PWM Capture3 */
```

```
PWM_EnableInt(PWM_CAP3, PWM_CAP_FALLING_INT);
```

### **PWM\_DisableInt**

#### **Synopsis**

```
VOID PWM_DisableInt (UINT8 u8Timer, UINT8 u8Int)
```

#### **Description**

This function is used to disable the PWM timer/capture interrupt

#### **Parameter**

u8Timer	The function to be set PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3 PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3
u8Int capture	Capture interrupt type (The parameter is valid only when function) PWM_CAP_RISING_INT: The capture rising interrupt. PWM_CAP_FALLING_INT: The capture falling interrupt. PWM_CAP_ALL_INT: All capture interrupt.

#### **Return Value**

None

#### **Example**

```
/* Disable Capture Interrupt */
PWM_DisableInt(PWM_CAP3,PWM_CAP_ALL_INT);
```

### **PWM\_InstallCallBack**

#### **Synopsis**

```
VOID PWM_InstallCallBack (UINT8 u8Timer, PFN_PWM_CALLBACK  
pfncallback, PFN_PWM_CALLBACK *pfnOldcallback)
```

#### **Description**

This function is used to install the specified PWM timer/capture interrupt call back function

#### **Parameter**

u8Timer	The function to be set
---------	------------------------

PWM\_TIMER0 ~ PWM\_TIMER3: PWM timer 0 ~ 3

PWM\_CAP0 ~ PWM\_CAP3: PWM capture 0 ~ 3

pfncallback      The callback function pointer for specified timer / capture.

pfnOldcallback    The previous callback function pointer for specified timer / capture.

#### **Return Value**

None

#### **Example**

```
/* Install Callback function */
PWM_InstallCallBack(PWM_TIMER0, PWM_PwmIRQHandler, &pfnOldcallback);
```

### ***PWM\_ClearInt***

#### **Synopsis**

VOID PWM\_ClearInt (UINT8 u8Timer)

#### **Description**

This function is used to clear the PWM timer/capture interrupt.

#### **Parameter**

u8Timer            The function to be set

PWM\_TIMER0 ~ PWM\_TIMER3: PWM timer 0 ~ 3

PWM\_CAP0 ~ PWM\_CAP3: PWM capture 0 ~ 3

#### **Return Value**

None

#### **Example**

```
/* Clear the PWM Capture 3 Interrupt */
PWM_ClearInt(PWM_CAP3);
```

### ***PWM\_GetIntFlag***

#### **Synopsis**

BOOL PWM\_GetIntFlag (UINT8 u8Timer)

#### **Description**

This function is used to get the PWM timer/capture interrupt flag

#### **Parameter**

u8Timer	The function to be set
	PWM_TIMER0 ~ PWM_TIMER3: PWM timer 0 ~ 3
	PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3

### Return Value

TRUE - The specified interrupt occurs.

FALSE - The specified interrupt doesn't occur.

### Example

```
/* Get PWM Timer 0 Interrupt flag*/
PWM_GetIntFlag(PWM_TIMER0);
```

## PWM\_GetCaptureIntStatus

## Synopsis

```
VOID PWM_GetCaptureIntStatus (UINT8 u8Capture, UINT8 u8IntType)
```

### Description

Check if there's a rising / falling transition

### Parameter

u8Timer	The function to be set		
	PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3		
u8Int capture	Capture interrupt type (The parameter is valid only when function)		
	PWM_CAP_RISING_INT:	The	
capture rising interrupt.			
	PWM_CAP_FALLING_INT:	The	
capture falling interrupt.			

## Return Value

TRUE - The specified interrupt occurs.

FALSE - The specified interrupt doesn't occur.

### Example

```
/* Wait for Interrupt Flag (Falling) */
while(PWM_GetCaptureIntStatus(PWM_CAP0, PWM_CAP_FALLING_FLAG)!=TRUE);
```

## PWM\_ClearCaptureIntStatus

## Synopsis

VOID PWM\_ClearCaptureIntStatus (UINT8 u8Capture, UINT8 u8IntType)

**Description**

Clear the rising / falling transition interrupt flag

**Parameter**

u8Timer	The function to be set
	PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3
u8Int capture	Capture interrupt type (The parameter is valid only when function)
	PWM_CAP_RISING_INT: The capture rising interrupt.
	PWM_CAP_FALLING_INT: The capture falling interrupt.

**Return Value**

None

**Example**

```
/* Clear the Capture Interrupt Flag */
PWM_ClearCaptureIntStatus(PWM_CAP0, PWM_CAP_FALLING_FLAG);
```

**PWM\_GetRisingCounter**
**Synopsis**

UINT16 PWM\_GetRisingCounter (UINT8 u8Capture)

**Description**

This function is used to get value which latches the counter when there's a rising transition

**Parameter**

u8Timer	The function to be set
	PWM_CAP0 ~ PWM_CAP3: PWM capture 0 ~ 3

**Return Value**

The value which latches the counter when there's a rising transition

**Example**

```
/* Get the Rising Counter Data */
u32Count[u32i++] = PWM_GetRisingCounter(PWM_CAP0);
```

## **PWM\_GetFallingCounter**

### **Synopsis**

UINT16 PWM\_GetFallingCounter (UINT8 u8Capture)

### **Description**

This function is used to get value which latches the counter when there's a falling transition

### **Parameter**

u8Timer                      The function to be set  
PWM\_CAP0 ~ PWM\_CAP3: PWM capture 0 ~ 3

### **Return Value**

The value which latches the counter when there's a falling transition

### **Example**

```
/* Get the Falling Counter Data */
u32Count[u32i++] = PWM_GetFallingCounter(PWM_CAP0);
```

## 17 RFC LIBRARY

### 17.1 OVERVIEW

The RF-CODEC includes the Convolution encode, Viterbi decode, Inner Interleave, and Inner De- Interleave. These are a forward error correction code (FEC) for wireless transceiver. The convolution encode includes a puncture function to change the coding rate from 1/2 to 2/3, 3/4, 5/6, or 7/8. If selecting 7/8 coding rate, the transfer data rate is maximum; otherwise, if selecting 1/2 coding rate, it gains the maximum BER performance. The Viterbi Decode is hard decision and the trace-back length is 32. The interleave function is used to disperse the transfer data. Because the performance of the Viterbi decode will be worst by burst error. The RF-CODEC block diagram is in Figure1. One thing is important that the RF-CODEC only supports PDMA function to handle the data from or to memory.




Figure17.1-1. RF-CODEC Block Diagram

### 17.2 FEATURE

- Supports Convolution encode and Viterbi decode
  - Coding rate supports 1/2, 2/3, 3/4, 5/6 and 7/8
- Supports Inner Interleave and Inner De-Interleave
- Supports PDMA function to handle the data from or to memory

### 17.3 API DATA STRUCTURE

#### ***E\_RF\_PNCTR\_MODE***

The coding rate setting in the puncture function.

Name	Value	Description
E_PNCTR_1_2	0	Coding rate is 1/2
E_PNCTR_2_3	1	Coding rate is 2/3
E_PNCTR_3_4	2	Coding rate is 3/4
E_PNCTR_5_6	3	Coding rate is 5/6
E_PNCTR_7_8	4	Coding rate is 7/8

## 17.4 API FUNCTION

### ***RF\_Open***

#### **Synopsis**

INT32 RF\_Open(void);

#### **Description**

Initialize RFC engine, install interrupt service routine, and call EDMA\_Init to initialize PDMA engine.

#### **Parameter**

None

#### **Return Value**

Successful	Always returns Successful
------------	---------------------------

### ***RF\_Close***

#### **Synopsis**

void RF\_Close(void);

#### **Description**

Tear down RFC engine.

#### **Parameter**

None

#### **Return Value**

None

### ***RF\_Enable\_Int***

#### **Synopsis**



void RF\_Enable\_Int(void);

**Description**

Enable RFC interrupt souce.

**Parameter**

None

**Return Value**

None

***RF\_Disable\_Int***

**Synopsis**

void RF\_Disable\_Int(void);

**Description**

Disable RFC interrupt souce.

**Parameter**

None

**Return Value**

None

***RF\_Set\_Puncture***

**Synopsis**

INT32 RF\_Set\_Puncture(E\_RF\_PNCTR\_MODE ePnctrMod);

**Description**

Set the coding rate of the puncture function.

**Parameter**

ePnctrMod	The coding rate of the puncture function
-----------	--

**Return Value**

Successful	Set puncture is successful
RFC_ERR_PNCTR_MODE	Invalid puncture coding rate

***RF\_Get\_Puncture***

**Synopsis**

E\_RF\_PNCTR\_MODE RF\_Get\_Puncture(void);

Get the coding rate of the puncture function.

## None

Successful	The puncture coding rate is returned
------------	--------------------------------------

```
INT32 RF_Encrypt(UINT8* plainBuf, UINT8* cipherBuf, INT32 plainDataLen);
```

Start to run a RFC encryption calculation and wait for its finish.

plainBuf	Pointer to input plain text buffer
cipherBuf	Pointer to output cipher text buffer
plainDataLen	Length of plain buffer in bytes

(Value > 0)	Length of output buffer in bytes
RFC_ERR_DATA_BUF	RFC input buffer address is wrong

```
INT32 RF_Decrypt(UINT8* cipherBuf, UINT8* plainBuf, UINT32 plainDataLen);
```

Start to run a RFC decryption calculation and wait for its finish.

cipherBuf	Pointer to input cipher text buffer
plainBuf	Pointer to output plain text buffer
plainDataLen	Length of plain buffer in bytes

(Value > 0)	Length of output buffer in bytes
RFC_ERR_DATA_BUF	RFC input buffer address is wrong

**17.5 ERROR CODE TABLE**

Code Name	Value	Description
Successful	0	Success
RFC_ERR_FAIL	RFC_ERR_ID   0x01	Internal error
RFC_ERR_PNCTR_MODE	RFC_ERR_ID   0x02	Invalid puncture coding rate
RFC_ERR_DATA_BUF	RFC_ERR_ID   0x03	NULL buffer address

## 18 ROTATION LIBRARY

### 18.1 OVERVIEW

The N9H26 Rotation library provides a set of APIs to rotate image in SDRAM. It uses SRAM as temporary buffer. With these APIs, user can rotate image quickly.

The Rotation engine supports rotation left 90 degrees and right 90 degrees. It doesn't support downscale and format conversion. It only supports to rotate packet RGB565, packet XRGB888 and packet YUV422. It supports source line offset and destination line offset.

These libraries are created by using Keil uVision IDE. Therefore, they only can be used in Keil environment.

### 18.2 ROTATION LIBRARY APIS SPECIFICATION

#### ***rotOpen***

##### **Synopsis**

VOID rotOpen(VOID)

##### **Description**

This function is used to open the rotation library.

##### **Parameter**

None

##### **Return Value**

None

##### **Example**

```
/* Open Rotation engine clock */
rotOpen();
```

#### ***rotClose***

##### **Synopsis**

VOID rotClose(VOID)

##### **Description**

Close the rot library.

**Parameter**

None

**Return Value**

None

**Example**

```
/* Close Rotation library*/
rotClose();
```

**rotInstallISR**

**Synopsis**

```
void rotInstallCallback (UINT32 u32IntNum,
                        PVOID pvIsr);
```

**Description**

This function is used to install callback function that is used to notice the upper layer for specified rotation image is done, buffer overrun or memory abort.

**Parameter**

u32IntNum	Rotation interrupt type. Please refer Table 18-1:Interrupt Type
pvIsr	Callback function

Table 18-1:Interrupt Type

Field name	Value	Description
E_ROT_COMP_INT	0	Rotation done interrupt
E_ROT_ABORT_INT	1	Memory abort interrupt
E_ROT_OVERFLOW_INT	2	Buffer overrun interrupt

**Return Value**

None.

**Example**

```
rotOpen();
rotInstallISR(E_ROT_COMP_INT, (PVOID)rotDoneHandler); /* Rotation done */
rotInstallISR(E_ROT_ABORT_INT, (PVOID)rotAbortHandler); /* Memory Abort */
```

## rotImageConfig

### Synopsis

INT32 rotImageConfig(T\_ROT\_CONF\* ptRotConf)

### Description

This function is used to configure Rotation engine.

### Parameter

ptRotConf The structure to configure Rotation engine. Please refer Table 18-2:  
The definition of configuration structure

Table 18-2: The definition of configuration structure

Field name	Value	Description
eRotFormat	E_ROT_PACKET_RGB565 = 0 E_ROT_PACKET_RGB888 = 1 E_ROT_PACKET_YUV422 = 2	Pixel Format
eBufSize	E_LBUF_4 = 0 E_LBUF_8 = 2 E_LBUF_16 = 16	Use SRAM line.
eRotDir	E_ROT_ROT_R90 = 0 E_ROT_ROT_L90 = 1	Right or left rotation
u32RotDimHW	[31:16] : Rotate image height [15:0] : Rotate image width	Rotate image dimension
u32SrcLineOffset	0 ~ 4095	Source line offset
u32DstLineOffset	0 ~ 4095	Source line offset
u32SrcAddr	< Memory size	Source Buffer Address
u32DstAddr	< Memory size	Destination Buffer Address

### Return Value

Successful

### Example

```
T_ROT_CONF tRotConf;
rotOpen();
rotInstallISR(E_ROT_COMP_INT, (PVOID)rotDoneHandler); /* Rotation done */
rotInstallISR(E_ROT_ABORT_INT, (PVOID)rotAbortHandler); /* Memory Abort */
tRotConf.eBufSize = E_LBUF_4;
tRotConf.eRotDir = E_ROT_ROT_L90;
```

```
tRotConf.eRotFormat = E_ROT_PACKET_RGB565;
tRotConf.u32RotDimHW = 0x01E00280;
tRotConf.u32SrcLineOffset = 0;
tRotConf.u32DstLineOffset = 0;
tRotConf.u32SrcAddr = ADDR_ROT_SRC_ADDR;
tRotConf.u32DstAddr = ADDR_ROT_DST_ADDR
```

### ***rotGetPacketPixelWidth***

#### **Synopsis**

INT32 rotGetPacketPixelWidth(E\_ROTENG\_FMT ePacFormat)

#### **Description**

The function is used to get data width for the specified format.

#### **Parameter**

ePacFormat      Rotation format. Please refer Table 18-3:Rotation Format

Table 18-3:Rotation Format

Field name	Value	Description
E_ROT_PACKET_RGB565	0	Packet RGB565. The data width is 2
E_ROT_PACKET_RGB888	1	Packet RGB888. The data width is 4
E_ROT_PACKET_YUV422	2	Packet YUV422. The data width is 2

#### **Return Value**

The data width of rotation image. Byte unit.

#### **Example**

```
UINT8 u8PixelWidth;
u8PixelWidth = rotGetPacketPixelWidth(ptRotConf->eRotFormat);
```

### ***rotTrigger***

#### **Synopsis**

INT32 rotTrigger (void)

#### **Description**

The function is used to get data width for the specified format

**Parameter**

None

**Return Value**

1: Meaning Rotation engine busy

0: Successful.

**Example**

```
UINT8 u8PixelWidth;
u8PixelWidth = rotGetPacketPixelWidth(ptRotConf->eRotFormat);
```

**Error Code Table**

Code Name	Value	Description
Successful	0	Successful
ERR_ROT_BUSY	0xFFFF2001	Rotation engine is busy



## 19 RSC LIBRARY

### 19.1 OVERVIEW

The RS\_CODEC controller performs two main functions - Reed-Solomon Encoder / Decoder and Convolutional Interleaver / Deinterleaver. When in encode mode, data from system bus can be encoded by Reed-Solomon Encoder and interleaved by convolutional interleaver. When in decode mode, data from system bus can be de-interleaved and decoded by Reed-Solomon Decoder.

### 19.2 FEATURE

- Supports Reed-Solomon Encoder / Decoder
  - (N=204, K=188, t=8) with the Field Generator Polynomial:  $p(x)=x^8+x^4+x^3+x^2+1$
  - Can correct 8 bytes error in 188 bytes block transmission
- Supports Convolutional Interleaver / Deinterleaver
  - Convolutional byte-wise interleaving with depth l=12 and 17 bytes FIFO
- Support PDMA to access RSC read / write buffers

### 19.3 FUNCTION

#### ***RS\_Open***

##### **Synopsis**

```
INT32 RS_Open(void);
```

##### **Description**

Initialize RSC engine, install interrupt service routine, and call EDMA\_Init to initialize PDMA engine.

##### **Parameter**

None

##### **Return Value**

Successful

Always returns Successful

#### ***RS\_Close***

##### **Synopsis**

```
void RS_Close(void);
```

**Description**

Tear down RSC engine.

**Parameter**

None

**Return Value**

None

***RS\_Enable\_Int***

**Synopsis**

void RS\_Enable\_Int(void);

**Description**

Enable RSC interrupt souce.

**Parameter**

None

**Return Value**

None

***RS\_Disable\_Int***

**Synopsis**

void RS\_Disable\_Int(void);

**Description**

Disable RSC interrupt souce.

**Parameter**

None

**Return Value**

None

***RS\_Encrypt***

**Synopsis**

INT32 RS\_Encrypt(UINT8\* plainBuf, UINT8\* cipherBuf, INT32 dataLen, UINT8 isInterleave);

**Description**

Start to run a RSC encryption calculation and wait for its finish.

**Parameter**

plainBuf	Pointer to input plain text buffer
cipherBuf	Pointer to output cipher text buffer
dataLen	Length of input buffer in bytes
isInterleave	RSC runs in interleave or deinterleave mode

**Return Value**

(Value > 0)	Length of output buffer in bytes
RSC_ERR_DATA_LEN	RSC input data length is wrong
RSC_ERR_DATA_BUF	RSC input buffer address is wrong

**RS\_Decrypt**
**Synopsis**

```
INT32 RS_Decrypt(UINT8* cipherBuf, UINT8* plainBuf, UINT32 dataLen, UINT8
isInterleave);
```

**Description**

Start to run a RSC decryption calculation and wait for its finish.

**Parameter**

cipherBuf	Pointer to input cipher text buffer
plainBuf	Pointer to output plain text buffer
dataLen	Length of input buffer in bytes
isInterleave	RSC runs in interleave or deinterleave mode

**Return Value**

(Value > 0)	Length of output buffer in bytes
RSC_ERR_DATA_LEN	RSC input data length is wrong
RSC_ERR_DATA_BUF	RSC input buffer address is wrong
RSC_ERR_DEC_ERROR	RSC decode error and cannot fix

**Error Code Table**

Code Name	Value	Description
Successful	0	Success
RSC_ERR_FAIL	RSC_ERR_ID   0x01	Internal error
RSC_ERR_DATA_LEN	RSC_ERR_ID   0x02	Data length is not block alignment
RSC_ERR_DATA_BUF	RSC_ERR_ID   0x03	NULL buffer address
RSC_ERR_DEC_ERROR	RSC_ERR_ID   0x04	RSC decode error

## 20 RTC LIBRARY

### 20.1 OVERVIEW

This library is designed to make user application access N9H26 RTC more easily.

The RTC library has the following features:

- Support RTC Current/Alarm time access.
- Support System Power Off Control

### 20.2 PROGRAMMING GUIDE

#### System Overview

Real Time Clock (RTC) block can be operated by independent power supply while the system power is off. The RTC uses a 32.768 KHz external crystal. It can transmit data to CPU with BCD values. The data includes the time by (second, minute and hour), the day by (day, month and year). In addition, to achieve better frequency accuracy, the RTC counter can be adjusted by software.

The built in RTC is designed to generate the alarm interrupt and periodic interrupt signals. The period interrupt can be 1/128, 1/64, 1/32, 1/16, 1/8, 1/4, 1/2 and 1 second. The alarm interrupt indicates that time counter and calendar counter have counted to a specified time recorded in TAR and CAR.

The wakeup signal is used to wake the system up from sleep mode.


#### RTC Features

- There is a time counter (second, minute, hour) and calendar counter (day, month, year) for user to check the time.
- Absolute Alarm register (second, minute, hour, day, month, year).
- Relative Alarm
- Alarm Mask for Minutely / Hourly / Daily / Weekly / Monthly/Yearly Alarm
- 12-hour or 24-hour mode is selectable.
- Recognize leap year automatically.
- The day of week counter.
- Frequency compensate register (FCR).
- Besides FCR, all clock and alarm data expressed in BCD code.
- Support time tick interrupt.
- Support wake up function.
- System Power off Control function


#### System Power Control Flow

## Power On from Key


User presses the Power Key to make the Power Control Signal, PWCE to high. If PWR\_ON bit is set, the Power Key can be released and the PWCE will be keep on. When system is power on, IBR will set PWR\_ON first.



If PWR\_ON doesn't be set to 1, the PWCE will back to low when the Power Key is released.



And RTC supports a function (POWER\_KEY\_DURATION\_LENGTH) to postpone the time to set PWCE to high when pressing Power Key or to postpone the time to set PWCE to low when releasing Power Key. The delay time is from 62ms to 868ms. The function is default disabled. User can enable it after first power on and the setting can be kept when RTC is powered even whole system is power-off.



[Note] The function (POWER\_KEY\_DURATION\_LENGTH) only works only when Power Key is pressed or released.

## Power Key Duration (POWER\_KEY\_DURATION)

The delay time between Power Key pressed and PWCE high (or Power Key released and PWCE low). Minimum duration that power key must be pressed to turn on core power.

Minimum power key duration =  $0.25 * (\text{POWER\_KEY\_DURATION} + 1)$  sec.

## Normal system Power Control Flow

The control steps are as follows

1. User press the power key, RPWR, to makes the power control signal, PWCE pin, to high. If the PWR\_ON bit, PWRON[0], be set, the power key can be released and the PWCE will keep on. If the PWR\_ON bit, PWRON [0], doesn't be set as 1, the PWCE will back to low when the power key is released.
2. If there is another pulse on power key when the PWR\_ON bit is set, the system will get an interrupt signal (PSWI). User can decide to clear the PWR\_ON or not. If this bit is clear, the PWCE will be low to turn off the core power. If the PWRON bit is also kept high, the PWCE pin will keep in high level. If there is not any pulse on the power key and the PWR\_ON bit is clear by user, the PWCE pin is also set to low at this time.

The follow table is the system power control flow true table.

Input		Output	Note
PWRKey	PWR_ON	PWCE	
X1	X2	Y	
1	0	0	RTC powered only (Default state)
0	0	1	Press key, Power On
0	1	1	keep key & S/W Set X2, Power On
1	1	1	Left key, Power keep On
0	1	1	Press key, get INT, intend to power Off
1	0	0	Left key & S/W clean X2, power Off Or S/W clean X2 , don't need press key, power off
X	1	1	RST_ active, still keep power when X2=1
PWCE is open drain output X1, internal pull-up X2, it is R/W able There is Interrupt from key be pressed			


## Force system Power Off Control Flow

The RTC supports a hardware automatic power off function and a software power off function like Notebook. For hardware power off function, it can be enable and disable in HW\_PCLR\_EN bit and the user presses the power button for a few seconds to power off system. The time to press power the button to power off is configured in PCLR\_TIME.


PCLR_TIME Setting	Pressed time to power off	PCLR_TIME Setting	Pressed time to power off
0	2~3 second	8	10~11 seconds
1	3~4 second	9	11~12 seconds
2	4~5 seconds	10	12~13 seconds
3	5~6 seconds	11	13~14 seconds
4	6~7 seconds	12	14~15 seconds
5	7~8 seconds	13	15~16 seconds
6	8~9 seconds	14	16~17 seconds
7	9~10 seconds	15	17~18 seconds

The RTC supports a hardware power off function to provide the power off flow like Notebook. The user presses the power button for a few seconds to power off the system. The time to press power key to power off is counted by hardware. After the time, hardware will set the PWCE to low and clear the PWR\_ON and HW\_PCLR\_EN. After power off, user can decide to set the PWR\_ON bit to power on system or not when the PWRKey is pressed.

The timing of the hardware power off function is following



The RTC also supports a software power off function. The user presses the power button for a few seconds to power off the system. The time to press power key to power off is counted by user. When the PWR\_ON bit is cleared by user, the PWCE outputs low after 116us and the SW\_PCLR bit is cleared when the power key is released. See the timing Figure as following.



### RTC Library Constant Definition

Name	Value	Description
RTC_CLOCK_12	0	12-Hour mode
RTC_CLOCK_24	1	24-Hour mode
RTC_AM	1	a.m.
RTC_PM	2	p.m.
RTC_LEAP_YEAR	1	Leap year
RTC_TICK_1_SEC	0	1 tick per second
RTC_TICK_1_2_SEC	1	2 tick per second
RTC_TICK_1_4_SEC	2	4 tick per second
RTC_TICK_1_8_SEC	3	8 tick per second
RTC_TICK_1_16_SEC	4	16 tick per second
RTC_TICK_1_32_SEC	5	32 tick per second
RTC_TICK_1_64_SEC	6	64 tick per second
RTC_TICK_1_128_SEC	7	128 tick per second
RTC_SUNDAY	0	Day of Week: Sunday
RTC_MONDAY	1	Day of Week: Monday
RTC_TUESDAY	2	Day of Week: Tuesday
RTC_WEDNESDAY	3	Day of Week: Wednesday
RTC_THURSDAY	4	Day of Week: Thursday
RTC_FRIDAY	5	Day of Week: Friday
RTC_SATURDAY	6	Day of Week: Saturday



RTC_ALARM_INT	0x01	Absolute Alarm Interrupt
RTC_TICK_INT	0x02	Tick Interrupt
RTC_PSWI_INT	0x04	Power Switch Interrupt
RTC_RELATIVE_ALARM_INT	0x08	Relative Alarm Interrupt
RTC_ALL_INT	0x0F	All Interrupt
RTC_IOC_IDENTIFY_LEAP_YEAR	0	Identify the leap year command
RTC_IOC_SET_TICK_MODE	1	Set tick mode command
RTC_IOC_GET_TICK	2	Get tick command
RTC_IOC_RESTORE_TICK	3	Restore tick command
RTC_IOC_ENABLE_INT	4	Enable interrupt command
RTC_IOC_DISABLE_INT	5	Disable interrupt command
RTC_IOC_SET_CURRENT_TIME	6	Set Current time command
RTC_IOC_SET_ALAMRM_TIME	7	Set Alarm time command
RTC_IOC_SET_FREQUENCY	8	Set Frequency command
RTC_IOC_SET_POWER_ON	9	Set Power On (Set PWR_ON to 1)
RTC_IOC_SET_POWER_OFF	10	Set Power Off (Set PWR_ON to 0)
RTC_IOC_SET_POWER_OFF_PERIOD	11	Set Power Off Period (PCLR_TIME)
RTC_IOC_ENABLE_HW_POWEROFF	12	Enable H/W Power Off
RTC_IOC_DISABLE_HW_POWEROFF	13	Disable H/W Power Off
RTC_IOC_GET_POWERKEY_STATUS	14	Get Power Key Status
RTC_IOC_SET_PSWI_CALLBACK	15	Set Power Switch Interrupt Callback function
RTC_IOC_GET_SW_STATUS	16	Get SW Status data (8 bits)
RTC_IOC_SET_SW_STATUS	17	Set SW Status data (8 bits)
RTC_IOC_SET_RELEATIVE_ALARM	18	Set relative alarm and install call back function
RTC_IOC_SET_POWER_KEY_DELAY	19	Set Power Control Signal Delay
RTC_IOC_SET_CLOCK_SOURCE	20	Set Clock Source
RTC_IOC_GET_CLOCK_SOURCE	21	Get Clock Source
RTC_CURRENT_TIME	0	Current time
RTC_ALARM_TIME	1	Alarm time
RTC_WAIT_COUNT	10000	RTC Initial Time out Value
RTC_YEAR2000	2000	RTC Year Reference Value

RTC_EXTERNAL	0	Clock from Internal
RTC_INTERANL	1	Clock from External

### ***RTC Library Time and Date Definition***

The RTC library provides time structure to access RTC time property.

<b>Name</b>	<b>Value</b>	<b>Description</b>
u8cClockDisplay	RTC_CLOCK_12 / RTC_CLOCK_24	12 Hour Clock / 24 Hour Clock
u8cAmPm	RTC_AM / RTC_PM	the AM hours / the PM hours
u32cSecond	0~59	Second value
u32cMinute	0~59	Minute value
u32cHour	1~11 / 0~23	Hour value
u32cDayOfWeek	RTC_SUNDAY~ RTC_SATURDAY	Day of week
u32cDay	1~31	Day value
u32cMonth	1~12	Month value
u32Year	0~99	Year value
u32AlarmMaskDayOfWeek	0/1 (Disable/Enable)	Day of Week Alarm Mask Enable
u32AlarmMaskSecond	0/1 (Disable/Enable)	Second Alarm Mask Enable
u32AlarmMaskMinute	0/1 (Disable/Enable)	Minute Alarm Mask Enable
u32AlarmMaskHour	0/1 (Disable/Enable)	Hour Alarm Mask Enable
u32AlarmMaskDay	0/1 (Disable/Enable)	Day Alarm Mask Enable
u32AlarmMaskMonth	0/1 (Disable/Enable)	Month Alarm Mask Enable
u32AlarmMaskYear	0/1 (Disable/Enable)	Year Alarm Mask Enable

## **20.3 RTC API**

### ***RTC\_Init***

#### **Synopsis**

UINT32 RTC\_Init (VOID)

#### **Description**

This function is to initialize RTC and install Interrupt service routine

#### **Parameter**

None

#### Return Value

E\_SUCCESS - Success  
E\_RTC\_ERR\_EIO - Access RTC Failed.

#### Example

```
/* RTC Initialize */
RTC_Init();
```

### RTC\_Open

#### Synopsis

UINT32 RTC\_Open (RTC\_TIME\_DATA\_T \*sPt )

#### Description

This function configures RTC current time.

#### Parameter

sPt RTC time property and current time information

#### Return Value

E\_SUCCESS - Success  
E\_RTC\_ERR\_EIO - Access RTC Failed.  
E\_RTC\_ERR\_CALENDAR\_VALUE - Wrong Calendar Value  
E\_RTC\_ERR\_TIMESACLE\_VALUE - Wrong Time Scale Value  
E\_RTC\_ERR\_TIME\_VALUE - Wrong Time Value  
E\_RTC\_ERR\_DWR\_VALUE - Wrong Day Value  
E\_RTC\_ERR\_FCR\_VALUE - Wrong Compensation value

#### Example

```
/* Initialization the RTC timer */
if(RTC_Open(&sInitTime) !=E_RTC_SUCCESS)
    sysprintf("Open Fail!!\n");
```

### RTC\_Close

#### Synopsis

UINT32 RTC\_Close (VOID)

#### Description

Disable AIC channel of RTC and both tick and alarm interrupt

**Parameter**

None

**Return Value**

E\_SUCCESS - Success

**Example**

```
/* Disable RTC */
RTC_Close();
```

## RTC\_Read

**Synopsis**

UINT32 RTC\_Read (E\_RTC\_TIME\_SELECT eTime, RTC\_TIME\_DATA\_T \*sPt)

**Description**

Read current date/time or alarm date/time from RTC

**Parameter**

eTime	The current/alarm time to be read RTC_CURRENT_TIME - Current time RTC_ALARM_TIME - Alarm time
sPt	RTC time property and current time information

**Return Value**

E\_SUCCESS - Success  
E\_RTC\_ERR\_EIO - Access RTC Failed.  
E\_RTC\_ERR\_ENOTTY - Command not support, or incorrect parameters.

**Example**

```
/* Get the current time */
RTC_Read(RTC_CURRENT_TIME, &sCurTime);
```

## RTC\_WriteEnable

**Synopsis**

UITN32 RTC\_WriteEnable (BOOL bEnable)

**Description**

Enable /Disable RTC register access

**Parameter**

bEnable                      TRUE/FALSE

**Return Value**

E\_SUCCESS                      - Success  
E\_RTC\_ERR\_EIO - Access RTC Failed.

**Example**

```
/* Enable RTC Access */
RTC_WriteEnable(TRUE);
/* Disable RTC Access */
RTC_WriteEnable(FALSE);
```

## ***RTC\_DoFrequencyCompensation***

**Synopsis**

BOOL RTC\_DoFrequencyCompensation(VOID)

**Description**

Set Frequency Compensation Data if RTC crystal frequency isn't accurate.

**Parameter**

None

**Return Value**

E\_SUCCESS                      - Success  
E\_RTC\_ERR\_FCR\_VALUE           - Can't do compensation.

**Example**

```
RTC_DoFrequencyCompensation ()
```

## ***RTC\_ioctl***

**Synopsis**

UINT32 RTC\_ioctl (INT32 i32Num, E\_RTC\_CMD eCmd,, UINT32 u32Arg0,  
UINT32 u32Arg1)

**Description**

This function allows user to set some commands for application, the support commands and arguments listed in the table below (Argument 1 is reserved for

feature use).

Command	Argument 0	Argument 1	Comment
RTC_IOC_IDENTIFY_LEAP_YEAR	Unsigned integer pointer to store the return leap year value	None	Get the leap year
RTC_IOC_SET_TICK_MODE	Unsigned integer stores the tick mode data	None	Set Tick mode
RTC_IOC_GET_TICK	Unsigned integer pointer to store the return tick number	None	Get the tick counter
RTC_IOC_RESTORE_TICK	None	None	Restore the tick counter
RTC_IOC_ENABLE_INT	interrupt type	None	Enable interrupt
RTC_IOC_DISABLE_INT	interrupt type	None	Disable interrupt
RTC_IOC_SET_CURRENT_TIME	None	None	Set current time
RTC_IOC_SET_ALAMRM_TIME	None	None	Set alarm time
RTC_IOC_SET_FREQUENCY	Unsigned integer stores the Frequency Compensation value	None	Set Frequency Compensation Data
RTC_IOC_SET_PWRON	None	None	Set Power on
RTC_IOC_SET_PWROFF	None	None	Set Power off
RTC_IOC_SET_POWER_OFF_PERIOD	Unsigned integer stores the power off period value : 0~15	None	Set Power Off Period
RTC_IOC_ENABLE_HW_POWEROFF	None	None	Enable H/W Power Off
RTC_IOC_DISABLE_HW_POWEROF	None	None	Disable H/W Power Off
RTC_IOC_GET_POWERKEY_STATUS	Unsigned integer pointer to store the return Power Key status	None	Get Power Key Status
RTC_IOC_SET_PSWI_CALLBACK	The call back function pointer for Power Switch Interrupts	None	Set Power Switch Interrupt Callback function
RTC_IOC_GET_SW_STATUS	Unsigned integer pointer to store the return SW Status (8 Bits)	None	Get SW Status data (8 bits)
RTC_IOC_SET_SW_STATUS	Unsigned integer stores the SW Status data (8 Bits)	None	Set SW Status data (8 bits)
RTC_IOC_SET_RELEATIVE_ALARM	The call back function pointer for Relative Alarm Interrupts	Alarm time (0~4095)	Set relative alarm and install call back function

RTC_IOC_SET_POWER_KEY_DELAY	power key delay time	None	Set Power Control Signal Delay
RTC_IOC_SET_CLOCK_SOURCE	Unsigned integer pointer to store the return Clock Status (32 Bits)	None	Set Power Key Trigger Mode – Level Trigger
RTC_IOC_GET_CLOCK_SOURCE	Unsigned integer pointer to store the return Clock Status (32 Bits)	None	Set Power Key Trigger Mode – Edge Trigger

**Parameter**

u32Arg0            Depend on feature setting  
u32Arg1            Depend on feature setting

**Return Value**

None

**Example**

```
/* Set Tick setting */
RTC_IocI(0,RTC_IOC_SET_TICK_MODE, (UINT32)&sTick,0);

/* Enable RTC Tick Interrupt and install tick call back function */
RTC_IocI(0,RTC_IOC_ENABLE_INT, (UINT32)RTC_TICK_INT,0);

/* Press Power Key during 6 sec to Power off */
RTC_IocI(0, RTC_IOC_SET_POWER_OFF_PERIOD, 6, 0);

/* Install the callback function for Power Key Press */
RTC_IocI(0, RTC_IOC_SET_PSWI_CALLBACK, (UINT32)PowerKeyPress, 0);

/* Enable Hardware Power off */
RTC_IocI(0, RTC_IOC_ENABLE_HW_POWEROFF, 0, 0);

/* Query Power Key Status */
RTC_IocI(0, RTC_IOC_GET_POWERKEY_STATUS, (UINT32)&u32PowerKeyStatus, 0);

/* Power Off - S/W can call the API to power off any time he wants */
```

```

RTC_Iocctl(0, RTC_IOC_SET_POWER_OFF, 0, 0);

/* Enable RTC Relative alarm Interrupt and install call back function */
RTC_Iocctl(0, RTC_IOC_SET_RELEATIVE_ALARM, 10, (UINT32)RTC_Releative_AlarmISR);

/* Set Power Control Signal Delay */
RTC_Iocctl(0, RTC_IOC_SET_POWER_KEY_DELAY, 1, 0);

Delay time Formula
Minimum Power key duration = 0.25*(POWER_KEY_DURATION+1) sec

```

### Example code

The demo code test “Time display”, “Absolute Alarm”, “Relative Alarm”, “Power down Wakeup”, “Software Power Off (Normal Case) Control Flow”, “Hardware Power Off (System Crash) Control Flow”, “Software Force to Power Off”, and “Alarm Mask”. Please refer to the RTC sample code of BSP Non-OS.

## 20.4 ERROR CODE TABLE

Code Name	Value	Description
E_RTC_SUCCESS	0	Operation success
E_RTC_ERR_CALENDAR_VALUE	1	Wrong Calendar Value
E_RTC_ERR_TIMESACLE_VALUE	2	Wrong Time Scale Value
E_RTC_ERR_TIME_VALUE	3	Wrong Time Value
E_RTC_ERR_DWR_VALUE	4	Wrong Day Value
E_RTC_ERR_FCR_VALUE	5	Wrong Compensation value
E_RTC_ERR_EIO	6	Access RTC Failed.
E_RTC_ERR_ENOTTY	7	Command not support, or parameter incorrect.
E_RTC_ERR_ENODEV	8	Interface number incorrect.



## **21 SDIO LIBRARY**

### **21.1 OVERVIEW**

N9H26 Non-OS library consists of a sets of libraries. These libraries are built to access those on-chip functions such as VPOST, APU, SIC, USBH, USBD, GPIO, I2C, SPI and UART, as well as File System (NVT FAT), USB MassStorage devices (UMAS) and NAND Flash devices (GNAND). This document describes the provided APIs of SDIO library. With these APIs, user can quickly build a binary target for SDIO library on N9H26 microprocessor.

These libraries are created by using Keil uVision IDE. Therefore, they only can be used in Keil environment.

### **21.2 SDIO LIBRARY**

This library is designed to make user application access N9H26 SDIO (Secure-Digital Input / Output) controller more easily. This interface can directly connect to SD card.


The SDIO library has the following features:

- Support single DMA channel and address in non-word boundary.
- Support SD/SDHC/SDIO/MMC card.

### **21.3 PROGRAMMING GUIDE**

#### **System Overview**

The SDIO controller of N9H26 chip has DMAC unit and SD unit. The DMAC unit provides a DMA (Direct Memory Access) function for SD unit to exchange data between system memory (ex. SDRAM) and shared buffer (128 bytes), and the SD unit control the interface of SD/SDHC/SDIO/MMC. The SDIO controller can support SD/SDHC/SDIO/MMC card and the SD unit is cooperated with DMAC unit to provide a fast data transfer between system memory and cards. The block diagram of SDIO controller is shown as following:



## 21.4 SDIO API

### *sdioOpen*

#### Synopsis

```
void sdioOpen (VOID)
```

#### Description

`sdioOpen()` will initialize the SDIO and DMAC interface hardware. It configures GPIO to SDIO mode, and installs ISR. This function is board dependent. It probably needs some modifications before it can work properly on your target board.

#### Parameter

None

#### Return Value

None

#### Example

```
/* initialize SDIO mode */
sdioctl(SDIO_SET_CLOCK, 240000, 0, 0); /* clock from PLL */
sdioOpen();
```

## ***sdioClose***

### **Synopsis**

void sdioClose (VOID)

### **Description**

sdioClose() will Close the SDIO and DMAC interface hardware. It configures GPIO to close DMAC and disable ISR for SDIO.

### **Parameter**

None

### **Return Value**

None

### **Example**

```
sdioClose();
```

## ***sdioctl***

### **Synopsis**

VOID sdioctl (INT32 sdioFeature, INT32 sdioArg0, INT32 sdioArg1, INT32 sdioArg2)

### **Description**

sdioctl() allows user set engine clock and callback functions, the support features and arguments listed in the table below.

Feature	Argument 0	Argument 1	Argument 2
SDIO_SET_CLOCK	AHB clock by KHz	None	None
SDIO_SET_CALLBACK	Card type (FMI_SDIO_CARD / FMI_SDIO1_CARD)	SD Card Remove callback function	SD Card Insert callback function
SDIO_GET_CARD_STATU S / SDIO1_GET_CARD_STAT US	Pointer to return value of SD card status	None	None

SDIO_SET_CARD_DETECT / SDIO1_SET_CARD_DETECT	TRUE to enable SD card detect feature; FALSE to disable it	None	None
---	---	------	------

#### Parameter

sdioFeature SDIO\_SET\_CLOCK, SDIO\_SET\_CALLBACK,  
SDIO\_GET\_CARD\_STATUS, SDIO1\_GET\_CARD\_STATUS,  
SDIO\_SET\_CARD\_DETECT, SDIO1\_SET\_CARD\_DETECT

sdioArg0 Depend on feature setting

sdioArg1 Depend on feature setting

sdioArg2 Depend on feature setting

#### Return Value

For SDIO\_GET\_CARD\_STATUS / SDIO1\_GET\_CARD\_STATUS, the card status assign to sdioArg0. The value TRUE means SD card inserted, FALSE means SD card removed.

#### Example

Refer to the example code of sdioOpen().

## 21.5 SDIO API

### *sdioSdOpen*

#### Synopsis

INT sdioSdOpen (void)                   open SD card 0  
INT sdioSdOpen0 (void)               open SD card 0  
INT sdioSdOpen1 (void)               open SD card 1

#### Description

This function initialize the SDIO host interface and program the SD card from identify mode to stand-by mode.

#### Parameter

None

#### Return Value

>0           – Total sector number of SD card  
Otherwise    – Refer error code defined in Error Code Table

#### Example

```
if (sdioSdOpen0() <= 0)    // Open SDIO port 0
```

```
{
printf("Error in initializing SD card !! \n");
sdioSdClose();
/* handle error status */
}
```

### ***sdioSdClose***

#### **Synopsis**

void sdioSdClose (void)	close SD card 0
void sdioSdClose0 (void)	close SD card 0
void sdioSdClose1 (void)	close SD card 1

#### **Description**

This function close the SDIO host interface.

#### **Parameter**

None

#### **Return Value**

None

#### **Example**

```
sdioSdClose();           // Close SDIO port 0
```

### ***sdioSdRead***

#### **Synopsis**

INT sdioSdRead (INT32 sdSectorNo, INT32 sdSectorCount, INT32 sdTargetAddr)	for SD card 0
INT sdioSdRead0 (INT32 sdSectorNo, INT32 sdSectorCount, INT32 sdTargetAddr)	for SD card 0
INT sdioSdRead1 (INT32 sdSectorNo, INT32 sdSectorCount, INT32 sdTargetAddr)	for SD card 1

#### **Description**

This function will read the data from SD card.

#### **Parameter**

sdSectorNo	Sector number to get the data from
sdSectorCount	Sector count of this access
sdTargetAddr	The address which data upload to SDRAM

**Return Value**

0	- On success
FMISDIO_TIMEOUT	- Access timeout
FMISDIO_NO_SD_CARD	- Card removed
FMISDIO_SD_CRC7_ERROR	- Command/Response error
FMISDIO_SD_CRC16_ERROR	- Data transfer error

**Example**

```
#define SDIO_TEST_SIZE      (512*128)
__align(4096) UINT8 sdioReadBackBuf[SDIO_TEST_SIZE];
// read 128 sectors data from SD card sector address 3000.
status = sdioSdRead(3000, SDIO_TEST_SIZE/512, (UINT32)sdioReadBackBuf);
```

**sdioSdWrite**
**Synopsis**

```
INT  sdioSdWrite (INT32  sdSectorNo,  INT32  sdSectorCount,  INT32
sdSourceAddr)
    for SD card 0

INT  sdioSdWrite0 (INT32  sdSectorNo,  INT32  sdSectorCount,  INT32
sdSourceAddr)
    for SD card 0

INT  sdioSdWrite1 (INT32  sdSectorNo,  INT32  sdSectorCount,  INT32
sdSourceAddr)
    for SD card 1
```

**Description**

This function write the data into SD card.

**Parameter**

sdSectorNo	Sector number to get the data from
sdSectorCount	Sector count of this access
sdSourcetAddr	The address which download data from SDRAM

**Return Value**

0	- On success
FMISDIO_TIMEOUT	- Access timeout

FMISDIO_NO_SD_CARD	- Card removed
FMISDIO_SD_CRC7_ERROR	- Command/Response error
FMISDIO_SD_CRC_ERROR	- Data transfer error

**Example**

```
#define SDIO_TEST_SIZE    (512*128)
__align(4096) UINT8 sdio_Buf[SDIO_TEST_SIZE];
// write 128 sectors data to SD card sector address 3000.
status = sdioSdWrite(3000, SDIO_TEST_SIZE/512, (UINT32)sdio_Buf);
```

**Example code**

The example code tests the SD card by read / write / compare please refer to the SDIO example code of BSP Non-OS.

**21.6 ERROR CODE TABLE**

Code Name	Value	Description
FMISDIO_TIMEOUT	0xFFFF00101	Access timeout
FMISDIO_NO_MEMORY	0xFFFF00102	No available memory
Error Code for SD Card		
FMISDIO_NO_SD_CARD	0xFFFF00110	No SD card inserted
FMISDIO_ERR_DEVICE	0xFFFF00111	Unknown device type
FMISDIO_SD_INIT_TIMEOUT	0xFFFF00112	SD command/response timeout
FMISDIO_SD_SELECT_ERROR	0xFFFF00113	Select card from identify mode to stand-by mode error
FMISDIO_SD_INIT_ERROR	0xFFFF00115	SD Card initial and identify error
FMISDIO_SD_CRC7_ERROR	0xFFFF00116	SD command/response error
FMISDIO_SD_CRC16_ERROR	0xFFFF00117	Data reading error
FMISDIO_SD_CRC_ERROR	0xFFFF00118	Data writing error
FMISDIO_SD_CMD8_ERROR	0xFFFF00119	SD command 8 response error

## 22 SIC LIBRARY

### 22.1 OVERVIEW

N9H26 Non-OS library consists of a sets of libraries. These libraries are built to access those on-chip functions such as VPOST, APU, SIC, USBH, USBD, GPIO, I2C, SPI and UART, as well as File System (NVT FAT), USB MassStorage devices (UMAS) and NAND Flash devices (GNAND). This document describes the provided APIs of SIC library. With these APIs, user can quickly build a binary target for SIC library on N9H26 microprocessor.

These libraries are created by using Keil uVision IDE. Therefore, they only can be used in Keil environment.

### 22.2 STORAGE INTERFACE CONTROLLER LIBRARY

This library is designed to make user application access N9H26 Storage Interface Controller (SIC) more easily. This interface can directly connect to SD card and NAND Flash.

The SIC library has the following features:


- Support single DMA channel and address in non-word boundary.
- Support SD/SDHC/SDIO/MMC card.
- Supports SLC and MLC NAND type Flash.
- Adjustable NAND page sizes. (512 / 2048 / 4096 / 8192 bytes + spare area)
- Support up to 4bit / 8bit / 12bit / 15bit / 24bit hardware ECC calculation circuit to protect data communication.
- Programmable NAND/SM timing cycle.

### 22.3 PROGRAMMING GUIDE

#### System Overview

The Storage Interface Controller (SIC) of N9H26 chip has SIC\_DMACH unit and SIC\_FMI unit. The SIC\_DMACH unit provides a DMA (Direct Memory Access) function for FMI to exchange data between system memory (ex. SDRAM) and shared buffer (128 bytes), and the SIC\_FMI unit control the interface of SD/SDHC/SDIO/MMC or NAND/SM. The storage interface controller can support SD/SDHC/SDIO/MMC card and NAND-type flash and the FMI is cooperated with DMACH to provide a fast data transfer between system memory and cards. The block diagram of SIC controller is shown as following:





## NAND Driver and GNAND Library

The SIC library provides NAND driver API to access NAND chip directly. However, the NAND driver don't support management features for NAND chip that don't guarantee all blocks are valid. The management features include bad block management, garbage collection, and wear-leveling. We provide GNAND library to support these management features and suggest to use GNAND library before using SIC NAND driver.

### 22.4 SIC API

#### *sicOpen*

##### Synopsis

```
void sicOpen (VOID)
```

##### Description

sicOpen() will initialize the SIC and DMAC interface hardware. It configures GPIO to FMI mode, and installs ISR. This function is board dependent. It probably needs some modifications before it can work properly on your target board.

##### Parameter

None

**Return Value**

None

**Example**

```
/* initialize SIC to FMI (Flash Memory Interface controller) mode */
sicloctl(SIC_SET_CLOCK, 240000, 0, 0); /* clock from PLL */
sicOpen();
```

***sicClose***
**Synopsis**

void sicClose (VOID)

**Description**

sicClose() will Close the SIC and DMAC interface hardware. It configures GPIO to close DMAC and disable ISR for SIC.

**Parameter**

None

**Return Value**

None

**Example**

```
sicClose();
```

***sicloctl***
**Synopsis**

VOID sicloctl (INT32 sicFeature, INT32 sicArg0, INT32 sicArg1, INT32 sicArg2)

**Description**

sicloctl() allows user set engine clock and callback functions, the support features and arguments listed in the table below.

Feature	Argument 0	Argument 1	Argument 2
SIC_SET_CLOCK	AHB clock by KHz	None	None
SIC_SET_CALLBACK	Card type (FMI_SD_CARD)	SD Card Remove callback function	SD Card Insert callback function
SIC_GET_CARD_STATUS	Pointer to return value of SD card status	None	None

SIC_SET_CARD_DETECT	TRUE to enable SD card detect feature; FALSE to disable it	None	None
---------------------	---	------	------

**Parameter**

sicFeature SIC\_SET\_CLOCK, SIC\_SET\_CALLBACK,  
SIC\_GET\_CARD\_STATUS, SIC\_SET\_CARD\_DETECT

sicArg0 Depend on feature setting

sicArg1 Depend on feature setting

sicArg2 Depend on feature setting

**Return Value**

For SIC\_GET\_CARD\_STATUS, the card status assign to sicArg0. The value TRUE means SD card inserted, FALSE means SD card removed.

**Example**

Refer to the example code of sicOpen().

## 22.5 SIC / SD API

### *sicSdOpen*

**Synopsis**

INT sicSdOpen (void)	open SD card 0
INT sicSdOpen0 (void)	open SD card 0
INT sicSdOpen1 (void)	open SD card 1
INT sicSdOpen2 (void)	open SD card 2

**Description**

This function initializes the SD host interface and program the SD card from identify mode to stand-by mode.

**Parameter**

None

**Return Value**

>0 – Total sector number of SD card  
Otherwise – Refer error code defined in Error Code Table

**Example**

```
if (sicSdOpen0() <= 0)    // Open SD port 0
{
```

```
printf("Error in initializing SD card !! \n");
sicSdClose0();
/* handle error status */
}
```

## ***sicSdClose***

### **Synopsis**

```
void sicSdClose (void)           close SD card 0
void sicSdClose0 (void)         close SD card 0
void sicSdClose1 (void)         close SD card 1
void sicSdClose2 (void)         close SD card 2
```

### **Description**

This function close the SD host interface.

### **Parameter**

None

### **Return Value**

None

### **Example**

```
sicSdClose();           // Close SD port 0
```

## ***sicSdRead***

### **Synopsis**

```
INT sicSdRead (INT32 sdSectorNo, INT32 sdSectorCount, INT32 sdTargetAddr)
    for SD card 0
INT  sicSdRead0 (INT32 sdSectorNo, INT32 sdSectorCount, INT32
sdTargetAddr)
    for SD card 0
INT  sicSdRead1 (INT32 sdSectorNo, INT32 sdSectorCount, INT32
sdTargetAddr)
    for SD card 1
INT  sicSdRead2 (INT32 sdSectorNo, INT32 sdSectorCount, INT32
sdTargetAddr)
    for SD card 2
```

### **Description**

### Parameter

sdSectorNo	Sector number to get the data from
sdSectorCount	Sector count of this access
sdTargetAddr	The address which data upload to SDRAM

0	- On success
FMI_TIMEOUT	- Access timeout
FMI_NO_SD_CARD	- Card removed
FMI_SD_CRC7_ERROR	- Command/Response error
FMI_SD_CRC16_ERROR	- Data transfer error

```
#define FMI_TEST_SIZE      (512*128)
__align(4096) UINT8 fmiReadBackBuffer[FMI_TEST_SIZE];
// read 128 sectors data from SD card sector address 3000.
status = sicSdRead(3000, FMI_TEST_SIZE/512, (UINT32)fmiReadBackBuffer);
```

## Synopsis

INT sicSdWrite (INT32 sdSectorNo, INT32 sdSectorCount, INT32 sdSourceAddr) for SD card 0						
INT sicSdWrite0 sdSourceAddr) for SD card 0	(INT32	sdSectorNo,	INT32	sdSectorCount,	INT32	
INT sicSdWrite1 sdSourceAddr) for SD card 1	(INT32	sdSectorNo,	INT32	sdSectorCount,	INT32	
INT sicSdWrite2 sdSourceAddr) for SD card 2	(INT32	sdSectorNo,	INT32	sdSectorCount,	INT32	

This function write the data into SD card.

sdSectorNo	Sector number to get the data from
sdSectorCount	Sector count of this access

### Return Value

FMI SD CRC ERROR - Data transfer error

### Example

```
#define FMI_TEST_SIZE      (512*128)
__align(4096) UINT8 fmiFlash_Buf[FMI_TEST_SIZE];
// write 128 sectors data to SD card sector address 3000.
status = sicSdWrite(3000, FMI_TEST_SIZE/512, (UINT32)fmiFlash_Buf);
```

## 22.6 SIC / NAND API

***nandInit0***

## Synopsis

INT nandInit1 (NDISK\_T \*NDISK\_info) for NAND chip 1

### Description

This function configures SIC register to initial DMAC and FMI to NAND mode. It also initial the internal data structure for future use. Since different NAND chip need different parameters, `nanInit0()` also read the product ID from NAND chip to try to configure correct parameters for it. This function is NAND chip dependent. It probably needs some modifications before it can work properly on your target NAND chip.

### Parameter

**NDISK\_info**      The internal data for NAND disk information. `nandInit0()` will  
initial it and return to caller.

### Return Value

Otherwise - Refer error code defined in Error Code Table

### Example

```
NDISK_T *ptMassNDisk;
```

```

NDISK_T MassNDisk;
ptMassNDisk = (NDISK_T *)&MassNDisk;
sicOpen();
if (nandInit0(ptMassNDisk) < 0)
{
    printf("NAND initial fail !!\n");
    /* handle error status */
}

```

### ***nand\_ioctl***

#### **Synopsis**

INT nand\_ioctl (INT param1, INT param2, INT param3, INT param4)

#### **Description**

nand\_ioctl() is reserved for I/O control utility for NAND. It is empty now and could support new functions in the future.

#### **Parameter**

param1	Depend on feature setting
param2	Depend on feature setting
param3	Depend on feature setting
param4	Depend on feature setting

#### **Return Value**

0	- Success
Otherwise	- Refer error code defined in Error Code Table

#### **Example**

None

### ***nandpread0***

#### **Synopsis**

INT nandpread0 (INT PBA, INT page, UINT8 \*buff) for NAND chip 0

INT nandpread1 (INT PBA, INT page, UINT8 \*buff) for NAND chip 1

#### **Description**

This function read a page of data from NAND.

**Parameter**

PBA	physical block address of NAND that read data from.
page	page number in PBA block that read data from.
buff	the RAM address to store the reading data.

**Return Value**

0	- Success
Otherwise	- Refer error code defined in Error Code Table

**Example**

```
__align(32) UINT8 fmiFlash_Buf[PAGE_SIZE];
// read a page of data from NAND block 5 page 10 and store at fmiFlash_Buf
status = nandpread0(5, 10, fmiFlash_Buf);
if (status < 0)
{
    /* handle error status */
}
```

***nandpwrite0***
**Synopsis**

INT nandpwrite0 (INT PBA, INT page, UINT8 \*buff) for NAND chip 0  
 INT nandpwrite1 (INT PBA, INT page, UINT8 \*buff) for NAND chip 1

**Description**

This function write a page of data to NAND.

**Parameter**

PBA	physical block address of NAND to write data.
page	page number in PBA block to write data.
buff	the RAM address to get the writing data.

**Return Value**

0	- Success
Otherwise	- Refer error code defined in Error Code Table

**Example**

```
__align(32) UINT8 fmiFlash_Buf[PAGE_SIZE];
// write a page of data from fmiFlash_Buf to NAND block 5 page 10
```



```
status = nandpwrite0(5, 10, fmiFlash_Buf);
if (status < 0)
{
/* handle error status */
}
```

### ***nand\_is\_page\_dirty0***

#### **Synopsis**

INT nand_is_page_dirty0 (INT PBA, INT page)	for NAND chip 0
INT nand_is_page_dirty1 (INT PBA, INT page)	for NAND chip 1

#### **Description**

This function check the redundancy area of the NAND page and return the dirty status to indicate whether a page is dirty or not. Dirty page means you cannot write data to it directly. You have to erase this block first to clean it.

#### **Parameter**

PBA	physical block address of NAND to check the dirty status.
page	page number in PBA block to check the dirty status.

#### **Return Value**

0	- Clean page that can write data directly
1	- Dirty page that cannot write data directly

#### **Example**

```
/* check dirty status for NAND block 5 page 10 */
status = nand_is_page_dirty0(5, 10);
if (status == 0)
{
printf("This page is clean !! You can write data to it directly.\n");
}
else
{
printf("This page is dirty !! You cannot write data to it directly.\n");
}
```

### ***nand\_is\_valid\_block0***

#### **Synopsis**

INT nand_is_valid_block0 (INT PBA)	for NAND chip 0
INT nand_is_valid_block1 (INT PBA)	for NAND chip 1

#### **Description**

This function check the redundancy area of the NAND block and return the valid status to indicate whether a block is valid or not. Valid block page means you can write data to it directly or indirectly (maybe need to erase block first). You cannot write data into a invalid block always since it could be a bad block.

#### **Parameter**

PBA	physical block address of NAND to check the valid status.
-----	---

#### **Return Value**

0	- Invalid block that cannot write data into it always
1	- Valid block that can write data into it directly or indirectly

#### **Example**

```
/* check valid status for NAND block 5 */
status = nand_is_valid_block0(5);
if (status == 1)
{
    printf("This block is valid !! You can write data to it directly or indirectly.\n");
}
else
{
    printf("This block is invalid !! You cannot write data to it always.\n");
}
```

### ***nand\_block\_erase0***

#### **Synopsis**

INT nand_block_erase0 (INT PBA)	for NAND chip 0
INT nand_block_erase1 (INT PBA)	for NAND chip 1

#### **Description**

This function erase a block. You should call this API first if you want to write data into a dirty page.

**Parameter**

PBA                      physical block address of NAND to erase.

**Return Value**

0                          - Erase block successfully  
 Otherwise               - Refer error code defined in Error Code Table

**Example**

```
/* erase NAND block 5 */
status = nand_block_erase0(5);
if (status == 0)
{
    printf("This block is erased !!\n");
}
else
{
    printf("This block erase fail !!\n");
}
```

***nand\_chip\_erase0***
**Synopsis**

INT nand\_chip\_erase0 (VOID)                      for NAND chip 0  
 INT nand\_chip\_erase1 (VOID)                      for NAND chip 1

**Description**

This function erase all blocks in NAND chip. All data in chip will lost that include information for GNAND library.

**Parameter**

None

**Return Value**

0                          - Erase chip successfully  
 Otherwise               - Refer error code defined in Error Code Table

**Example**

```
/* erase whole NAND chip */
status = nand_chip_erase0();
```

```

if (status == 0)
{
    printf("This chip is erased !!\n");
}
else
{
    printf("This chip erase fail !!\n");
}

```

### ***nandRegionProtect0***

#### **Synopsis**

INT nandRegionProtect0 (INT PBA, INT page)	for NAND chip 0
INT nandRegionProtect1 (INT PBA, INT page)	for NAND chip 1

#### **Description**

This function configures Region Protect feature. The protected region is from block 0 page 0 to block "PBA" page "page". If both "PBA" and "page" are 0, the Region Protect feature will be disabled.

#### **Parameter**

PBA	physical block address of NAND that is the end address of protected region.
page	page number in PBA block that is the end address of protected region.

#### **Return Value**

0	- Success
Otherwise	- Refer error code defined in Error Code Table

#### **Example**

```

/* Set protected region from block 0 page 0 to block 5 page 10 */
status = nandRegionProtect0(5, 10);
if (status == 0)
{
    printf("This Region Protect configuration successful !!\n");
}
else
{

```

```
printf("This Region Protect configuration fail !!\n");
}
```

### Example code

The example code tests the NAND flash and SD card by read / write / compare please refer to the SIC example code of BSP Non-OS.

## 22.7 ERROR CODE TABLE

Code Name	Value	Description
FMI_TIMEOUT	0xFFFF0101	Access timeout
FMI_NO_MEMORY	0xFFFF0102	No available memory
Error Code for SD Card		
FMI_NO_SD_CARD	0xFFFF0110	No SD card insert
FMI_ERR_DEVICE	0xFFFF0111	Unknown device type
FMI_SD_INIT_TIMEOUT	0xFFFF0112	SD command/response timeout
FMI_SD_SELECT_ERROR	0xFFFF0113	Select card from identify mode to stand-by mode error
FMI_SD_INIT_ERROR	0xFFFF0115	SD Card initial and identify error
FMI_SD_CRC7_ERROR	0xFFFF0116	SD command/response error
FMI_SD_CRC16_ERROR	0xFFFF0117	Data reading error
FMI_SD_CRC_ERROR	0xFFFF0118	Data writing error
FMI_SD_CMD8_ERROR	0xFFFF0119	SD command 8 response error
Error Code for NAND		
FMI_SM_INIT_ERROR	0xFFFF0120	NAND/SM card initial error
FMI_SM_RB_ERR	0xFFFF0121	NAND don't become ready from busy status
FMI_SM_STATE_ERROR	0xFFFF0122	NAND return fail for write command
FMI_SM_ECC_ERROR	0xFFFF0123	Read data error and uncorrectable by ECC
FMI_SM_STATUS_ERR	0xFFFF0124	NAND return fail for erase command
FMI_SM_ID_ERR	0xFFFF0125	NAND chip ID don't supported
FMI_SM_INVALID_BLOCK	0xFFFF0126	NAND block is invalid to erase or write
FMI_SM_MARK_BAD_BLOCK_ERR	0xFFFF0127	Fail to mark a block to bad

FMI_SM_REGION_PROTECT_ERR	0xFFFF0128	NAND return fail for write command because of region protect
---------------------------	------------	--

## 23 SPI LIBRARY

### 23.1 OVERVIEW

This library provides APIs for programmers to access SPI device connecting with N9H26 SPI interfaces. The SPI library will get the APB clock frequency from system library, application must set the CPU clock before using SPI library.

### 23.2 API FUNCTIONS

#### *spiOpen*

##### Synopsis

```
INT32 spiOpen(SPI_INFO_T *pInfo)
```

##### Description

This function initialize the SPI interface.

##### Parameter

```
typedef struct _spi_info_t
{
    INT32  nPort;           /* select SPI0 (0) or SPI1 (1) */
    BOOL   bIsSlaveMode;    /* set the interface mode - master mode or
slave                        mode */
    BOOL   bIsClockIdleHigh; /* set the clock idle state – high or low */
    BOOL   bIsLSBFirst;     /* set LSB transfer first or MSB first */
    BOOL   bIsAutoSelect;   /* set automatically active / inactive CS pin */
    BOOL   bIsActiveLow;    /* define the active level of device select
signal */
    BOOL   bIsTxNegative;   /* set the Tx signal changed on rising
edge or
falling edge */
    BOOL   bIsLevelTrigger; /* set slave select signal is edge-
trigger or
level-trigger */
} SPI_INFO_T;
```

##### Return Value

```
= 0      Success
```

< 0      Fail

**Example**

```
/* Set SPI0 as master mode, clock idle low, MSB transfer first, not auto CS, receive on
negative edge, slave select signal is active Low and edge-trigger */
SPI_INFO_T spi0;
spi0.nPort = 0;
spi0.bIsSlaveMode = FALSE;
spi0.bIsClockIdleHigh = FALSE;
spi0.bIsLSBFirst = FALSE;
spi0.bIsAutoSelect = FALSE;
spi0.bIsActiveLow = TRUE;
spi0.bIsTxNegative = FALSE;
spi0.bIsLevelTrigger = FALSE;
spiOpen(&spi0);
```

***spiClose***

**Synopsis**

INT32 spiClose(UINT8 u8Port)

**Description**

This function disable SPI engine clock.

**Parameter**

u8Port                      Select SPI0 (0) or SPI1 (1)

**Return Value**

= 0                      Success

< 0                      Fail

**Example**

```
spiClose(0);
```

***spiloctl***

**Synopsis**

VOID spiloctl(INT32 spiPort, INT32 spiFeature, INT32 spiArg0, INT32 spiArg1)



### Description

This function allows programmers configure SPI interface.

### Parameter

spiPort	Select SPI0 (0) or SPI1 (1)
spiFeatureSPI_SET_CLOCK	
spiArg0	APB clock by MHz
spiArg1	Device output clock by kHz

### Return Value

None

### Example

```
/* apb clock is 48MHz, output clock is 10MHz */
spilockl(0, SPI_SET_CLOCK, 48, 10000);
```

## **spiEnable**

### Synopsis

INT spiEnable(INT32 spiPort)

### Description

This function will active the SPI interface to access device (active CS#).

### Parameter

spiPort	Select SPI0 (0) or SPI1 (1)
---------	-----------------------------

### Return Value

0 Success

### Example

```
spiEnable(0);
```

## **spiDisable**

### Synopsis

INT spiDisable(INT32 spiPort)

### Description

This function will inactive the SPI interface (inactive CS#).

### Parameter

spiPort                      Select SPI0 (0) or SPI1 (1)

#### Return Value

0 Success

#### Example

```
spiDisable(0);
```

### **spiRead**

#### Synopsis

INT spiRead(INT port, INT RxBitLen, INT len, CHAR \*pDst)

#### Description

This function is used to read the data back from the SPI interface and store it into the buffer pDst..

#### Parameter

port	select SPI0 (0) or SPI1 (1)
RxBitLen	set the receive bit length. <i>SPI_8BIT, SPI_16BIT, SPI_32BIT</i>
len count;	data count. SPI_8BIT is byte count; SPI_16BIT is half-word SPI_32BIT is word count.
pDst	The buffer stores the read back data.

#### Return Value

0 Success

#### Example

```
/* read 1 byte data from SPI device */
spiRead(0, SPI_8BIT, 1, (CHAR *)&rdata);
```

### **spiWrite**

#### Synopsis

INT spiWrite(INT port, INT TxBitLen, INT len, CHAR \*pSrc)

#### Description

This function is used to write the data to the SPI interface.

#### Parameter

port	select SPI0 (0) or SPI1 (1)
TxBitLen	set the transmit bit length. <i>SPI_8BIT, SPI_16BIT, SPI_32BIT</i>

len	data count. SPI_8BIT is byte count; SPI_16BIT is half-word
count;	SPI_32BIT is word count
pSrc	The buffer stores the data that is written into SPI interface.

#### Return Value

0 Success

#### Example

```
/* write 1 half-word to SPI device */
wdata = 0x80ff;
spiWrite(0, SPI_16BIT, 1, (CHAR *)&wdata);
```

### ***spiTransfer***

#### Synopsis

INT spiTransfer(UINT32 port, UINT32 TxBitLen, UINT32 len, PUINT8 RxBuf , PUINT8 TxBuf)

#### Description

This function is used to read/write the data from/to the SPI interface.

#### Parameter

port	select SPI0 (0) or SPI1 (1)
TxBitLen	set the transmit bit length. <i>SPI_8BIT</i> , <i>SPI_16BIT</i> , <i>SPI_32BIT</i>
len	data count. SPI_8BIT is byte count; SPI_16BIT is half-word
count;	SPI_32BIT is word count.
RxBuf	The buffer stores the read back data.
TxBuf	The buffer stores the data that is written into SPI interface.

#### Return Value

0 Success

#### Example

```
/* write 1 byte to SPI device and read 1 byte data from SPI device */
spiRead(0, SPI_8BIT, 1, (PUINT8)&rdata, (PUINT8)& wdata);
```

### ***spiSSEnable***

#### Synopsis

INT spiSSEnable(UINT32 spiPort, UINT32 SSPin, UINT32 ClockMode)

#### Description

The function will be set specified SS pin of the SPI interface to active state and set transfer timing.

#### Parameter

spiPort	select SPI0 (0) or SPI1 (1)
SSPin	select SS0 (0) or SS1 (1)
ClockMode	Decides the transfer timing. (SPI_CLOCK_MODE 0~3 )

#### Return Value

0 Success

#### Example

```
/* Set SS0 pin of SPI0 to active state and transfer timing as SPI mode 3 */
#define SPI_CLOCK_MODE 3
spiSSEnable(0, 0, SPI_CLOCK_MODE);
```

### ***spiSSDisable***

#### Synopsis

INT spiSSDisable(UINT32 spiPort, UINT32 SSPin)

#### Description

The function will be set specified SS pin of the SPI interface to inactive state.

#### Parameter

spiPort	select SPI0 (0) or SPI1 (1)
SSPin	select SS0 (0) or SS1 (1)

#### Return Value

0 Success

#### Example

```
/* Set SS0 pin of SPI0 to inactive state */
spiSSDisable(0, 0);
```

### ***spiInstallCallBack***

#### Synopsis

ERRCODE spiInstallCallBack(UINT8 u8Port, PFN\_DRVSPI\_CALLBACK  
pfncallback, PFN\_DRVSPI\_CALLBACK \*pfnOldcallback)

#### Description

This function is used to install the specified SPI port interrupt call back function.

#### Parameter

u8Port	select SPI0 (0) or SPI1 (1)
pfncallback	The callback function pointer for specified SPI port.
pfnOldcallback	The previous callback function pointer for specified SPI port.

#### Return Value

0 Success

#### Example

```
/* Install Callback function */
spiInstallCallBack (0, SPI0_Handler, &pfnOldcallback);
```

### ***spilsBusy***

#### Synopsis

BOOL spilsBusy(UINT8 u8Port)

#### Description

This function is used to get the SPI busy state.

#### Parameter

u8Port	select SPI0 (0) or SPI1 (1)
--------	-----------------------------

#### Return Value

TURE	- The specified SPI is busy.
FALSE	- The specified SPI is not busy.

#### Example

```
/* Wait for SPI0 transfer finish */
while(spilsBusy(0)!= FALSE);
```

### ***spiEnableInt***

#### Synopsis

VOID spiEnableInt(UINT8 u8Port)

#### Description

This function is used to enable the SPI interrupt.

**Parameter**

u8Port                      Select SPI0 (0) or SPI1 (1)

**Return Value**

None

**Example**

```
/* Enable Interrupt Sources of SPI0 */
spiEnableInt(0);
```

***spiDisableInt***

**Synopsis**

VOID spiDisableInt(UINT8 u8Port)

**Description**

This function is used to disable the SPI interrupt.

**Parameter**

u8Port                      Select SPI0 (0) or SPI1 (1)

**Return Value**

None

**Example**

```
/* Disable Interrupt Sources of SPI0 */
spiDisableInt(0);
```

***spiSetGo***

**Synopsis**

VOID spiSetGo(UINT8 u8Port)

**Description**

This function is used to set SPI starts to transfer data.

**Parameter**

u8Port                      select SPI0 (0) or SPI1 (1)

**Return Value**

None

### Example

```
/* Set SPI0 starts to transfer data */
spiSetGo(0);
```

## ***spiSetByteEndin***

### Synopsis

```
VOID spiSetByteEndin(UINT8 u8Port, E_DRVSPI_OPERATION eOP)
```

### Description

This function is used to enable or disable byte endin.

### Parameter

u8Port	Select SPI0 (0) or SPI1 (1)
eOP	Select enable or disable the byte endin

### Return Value

None

### Example

```
/* Set SPI0 disable byte endin */
spiSetByteEndin(0, eDRVSPI_DISABLE);
```

## 24 SPI\_SECUREIC LIBRARY

### 24.1 OVERVIEW

This library provides APIs for programmers to access Winbond SPI Flash (Only for W74M) connecting with N9H26 SPI interfaces. The SPI library will get the APB clock frequency from system library, application must set the CPU clock before using SPI library.

### 24.2 API FUNCTIONS

#### ***RPMC\_ReadJEDECID***

##### **Synopsis**

INT32 RPMC\_ReadJEDECID(PUINT8 data)

##### **Description**

This function reads JEDEC ID.

##### **Parameter**

data                      the JEDEC ID pointer

##### **Return Value**

= 0              Success

< 0              Fail

##### **Example**

```
if ((RPMC_ReadJEDECID(u8JID)) == -1)
{
    sysprintf("read id error !!\n");
    return -1;
}
```

#### ***RPMC\_ReadUID***

##### **Synopsis**

INT16 RPMC\_ReadUID (PUINT8 data)

##### **Description**



This function reads Unique ID.

**Parameter**

data                      the Unique ID pointer

**Return Value**

= 0              Success  
< 0              Fail

**Example**

```
if ((RPMC_ReadUID(u8UID)) == -1)
{
    sysprintf("read id error !!\n");
    return -1;
}
```

***RPMC\_ReadCounterData***
**Synopsis**

unsigned int RPMC\_ReadCounterData(void)

**Description**

This function read counter data in stoage in public array counter[], data is available if RPMC\_IncCounter() operation succeeded

**Parameter**

None

**Return Value**

Counter data

**Example**

```
/* counter data in stoage in public array counter[], data is available if
RPMC_IncCounter() operation succeeded */
RPMC_counter = RPMC_ReadCounterData();
```

***RPMC\_WrRootKey***
**Synopsis**

unsigned int RPMC\_WrRootKey(unsigned int cadr,unsigned char \*rootkey)

#### Description

This function writes root key to W74M.

#### Parameter

cadr	Key index (0~3)
rootkey	Root key pointer

#### Return Value

0x80	Success
Other	Fail

#### Example

```
RPMCStatus = RPMC_WrRootKey(KEY_INDEX, ROOTKey);          /* initial Rootkey,
use first rootkey/counter pair */

if(RPMCStatus == 0x80)
{
    /* Write rootkey success */
    sysprintf("RPMC_WrRootKey Success - 0x%02X!!\n",RPMCStatus );
}
else
{
    /* write rootkey fail, check datasheet for the error bit */
    sysprintf("RPMC_WrRootKey Fail - 0x%02X!!\n",RPMCStatus );
}
```

### **RPMC\_UpHMACkey**

#### Synopsis

```
unsigned int RPMC_UpHMACkey(unsigned int cadr,unsigned char
*rootkey,unsigned char *hmac4,unsigned char *hmackey);
```

#### Description

This function updates HMAC Key

#### Parameter

cadr	Key index (0~3)
rootkey	Root key pointer
hmac4	HMAC Key message pointer
hmackey	HMAC Key pointer (generated by Rootkey and hmac4)

**Return Value**

0x80	Success
Other	Fail

**Example**

```

RPMCStatus = RPMC_UpHMACkey(KEY_INDEX, ROOTKey, HMACMessage,
HMACKey);
if(RPMCStatus == 0x80)
{
    /* update HMACkey success */
    sysprintf("RPMC_UpHMACkey Success - 0x%02X!!\n",RPMCStatus );
}
else
{
    /* write HMACkey fail, check datasheet for the error bit */
    sysprintf("RPMC_UpHMACkey Fail - 0x%02X!!\n",RPMCStatus );
}

```

***RPMC\_IncCounter***

**Synopsis**

```

unsigned int RPMC_IncCounter(unsigned int cadr,unsigned char
*hmackey,unsigned char *input_tag);

```

**Description**

This function is used to increase counter data

**Parameter**

cadr	Key index (0~3)
hmackey	HMAC Key pointer (generated by Rootkey and input_tag)
input_tag	Message for increase counter

**Return Value**

0x80	Success
Other	Fail

**Example**

```

RPMCStatus = RPMC_IncCounter(KEY_INDEX, HMACKey, Input_tag);
if(RPMCStatus == 0x80)
{
    /* increase counter success */
    sysprintf("RPMC_IncCounter Success - 0x%02X!!\n",RPMCStatus );
}
else
{
    /* increase counter fail, check datasheet for the error bit */
    sysprintf("RPMC_IncCounter Fail - 0x%02X!!\n",RPMCStatus );
}

```

**RPMC\_Challenge**
**Synopsis**

```

unsigned char RPMC_Challenge(unsigned int cadr,unsigned char
*hmackey,unsigned char *input_tag);

```

**Description**

This function is used to do authentication check.

**Parameter**

cadr	Key index (0~3)
hmackey	HMAC Key pointer (generated by Rootkey and input_tag)
input_tag	Message for authentication

**Return Value**

0x80	Success
Other	Fail

**Example**

```

/* Main security operation call challenge*/
while(1)
{
    if(RPMC_Challenge(KEY_INDEX, HMACKey, Input_tag)!=0)

```

```

    {
        sysprintf("RPMC_Challenge Fail!!\n" );
        /* return signature miss-match */
        return 0;
    }
else
{
    if(count > 500)
    {
        sysprintf("\n" );
        RPMCStatus = RPMC_IncCounter(KEY_INDEX, HMACKey, Input_tag);
        if(RPMCStatus == 0x80)
        {
            /* increase counter success */
            sysprintf("RPMC_IncCounter          Success          -
0x%02X!!\n",RPMCStatus );
        }
        else
        {
            /* increase counter fail, check datasheet for the error bit */
            sysprintf("RPMC_IncCounter Fail - 0x%02X!!\n",RPMCStatus );
            while(1);
        }
        /* counter data in stoage in public array counter[], data is available if
RPMC_IncCounter() operation succeeded */
        RPMC_counter = RPMC_ReadCounterData();

        /* increase RPMC counter done*/
        sysprintf("RPMC_counter 0x%X\n",RPMC_counter);
        count = 0;
    }
    else
        count++;
}

```

```
        sysprintf("." );  
    }  
}
```

## 25 SPU LIBRARY

### 25.1 OVERVIEW

This library provides APIs for programmers play PCM audio data from SPU engine. Except playing audio this library also provides 10-band equalizer APIs. SPU engine only plays audio, no record function is included.

### 25.2 API FUNCTIONS

#### ***spuOpen***

##### **Synopsis**

```
VOID spuOpen(UINT32 u32SampleRate)
```

##### **Description**

This function will set the audio clock, play buffer address and install its interrupt.

##### **Parameter**

u32SampleRate    Specific sampling rate

##### **Return Value**

None

##### **Example**

```
spuOpen();
```

#### ***spuStartPlay***

##### **Synopsis**

```
VOID spuStartPlay(PFN_DRVSPU_CB_FUNC *fnCallBack, UINT8 *data)
```

##### **Description**

After setting IO control to engine, this function will trigger SPU engine to start playing.

##### **Parameter**

fnCallBackPlay call back function pointer

data            Source PCM audio data pointer

##### **Return Value**

None

**Example**

```
int playCallBack(UINT8 * pu8Buffer)
{
    ...
}

spuStartPlay((PFN_DRVSPU_CB_FUNC *) playCallBack, (UINT8 *)SPU_SOURCE);
```

***spuStopPlay***
**Synopsis**

VOID spuStopPlay (VOID)

**Description**

Stop play.

**Parameter**

None

**Return Value**

None

**Example**

spuStopPlay ();

***spuClose***
**Synopsis**

VOID spuClose(VOID)

**Description**

This function disables SPU engine.

**Parameter**

None

**Return Value**

None

**Example**

spuClose ();

***spuIoctl***



**Synopsis**

```
VOID spulctl(UINT32 cmd, UINT32 arg0, UINT32 arg1)
```

**Description**

This function allows programmers configure SPU engine, the supported command and arguments listed in the table below.

Command	Argument 0	Argument 1	Description
SPU_IOCTL_SET_VOLUME	Specifies left channel volume ranging from 0 (min.) to 0x3F (max.)	Specifies right channel volume ranging from 0 (min.) to 0x3F (max.)	Set SPU volume
SPU_IOCTL_SET_MONO	Not used	Not used	Set SPU to the mono mode
SPU_IOCTL_SET_STEREO	Not used	Not used	Set SPU to the stereo mode
SPU_IOCTL_GET_FRAG_SIZE	Fragment size	Not used	Get the fragment size from library

**Parameter**

Cmd      Command  
 arg0     First argument of the command  
 arg1     Second argument of the command

**Return Value**

None

**Example**

```
spulctl(SPU_IOCTL_SET_VOLUME, 0x3f, 0x3f);
```

***spuDacOn***
**Synopsis**

```
VOID spuDacOn(UINT8 level)
```

**Description**

This function is used to enable DAC interface and must used before calling spuStartPlay().

**Parameter**

level      delay time for de-pop noise

**Return Value**

None

#### Example

```
spuDacOn (1);
```

### ***spuDacOff***

#### Synopsis

VOID spuDacOff(VOID)

#### Description

This function is used to disable DAC interface and must used after calling spuStopPlay().

#### Parameter

None

#### Return Value

None

#### Example

```
spuDacOff ();
```

### ***spuEqOpen***

#### Synopsis

VOID spuEqOpen (E\_DRVSPU\_EQ\_BAND eEqBand, E\_DRVSPU\_EQ\_GAIN eEqGain)

#### Description

Open 10-band equalizer.

#### Parameter

eEqBand Equalizer band setting

eEqGain Equalizer gain setting for each band

#### Return Value

None

#### Example

```
spuEqOpen(eDRVSPU_EQBAND_2, eDRVSPU_EQGAIN_P7DB);
```

### ***spuEqClose***

**Synopsis**

VOID spuEqClose (VOID)

**Description**

Close Equalizer function.

**Parameter**

None

**Return Value**

None

**Example**

```
spuEqClose ();
```

## 26 SYSTEM LIBRARY

### 26.1 OVERVIEW

The System library provides a set of APIs to control on-chip functions such as Timers, UARTs, AIC, Cache and power management. With these APIs, user can quickly create a test program to run on demo board or evaluation board.

This library is created by using Keil uVision IDE. Therefore, it only can be used in Keil environment.

### 26.2 TIMER API FUNCTIONS

Table 26-1 : Timer Channel

Channel name	Value	Description
TIMER0	0	Timer 0
TIMER1	1	Timer 1
TIMER2	2	Timer 2
TIMER3	3	Timer 3
WDTIMER	4	Watch Dog Timer

Table 26-2:Timer Mode

Timer Mode	Value	Description
ONE_SHOT_MODE	0	One shot mode.
PERIODIC_MODE	1	Periodic mode.
TOGGLE_MODE	2	Toggle mode.
UNINTERRUPT_MODE	3	Uninterrupt mode.

Table 26-3:Watch-Dog Interval Select

Interval Select	Value	Description
WDT_14BITS	0	14 bits Interval
WDT_16BITS	1	16 bits Interval
WDT_18BITS	2	18 bits Interval
WDT_20BITS	3	20 bits Interval

***sysSetTimerEvent***

**Synopsis**

INT32 sysSetTimerEvent(UINT32 nTimeNo, UINT32 nTimeTick, PVOID pvFun);

#### Description

This function is used to set the event of selected timer. *nTimeNo* is used to select timer 0 to timer 3. The event function which pointed by *pvFun* shall be executed after *nTimeTick* system timer tick. The function is useless for WDTIMER.

#### Parameter

nTimeNo TIMER0, TIMER1, TIMER2 or TIMER3. Please refer Table 26-1 : Timer Channel.

nTimeTick Tick count before event executed

pvFun Event function pointer

#### Return Value

Event number. Please remember the event number if you want to uninstall the timer event.

#### Example

```
/* Set event function "hello" after 100 tick */
INT nEventNo;
VOID hello(VOID)
{
    sysPrintf("Hello World!\n");
}
nEventNo = sysSetTimerEvent (TIMER0, 100, (PVOID)hello);
.....
sysClearTimerEvent (TIMER0, nEventNo);
```

### ***sysClearTimerEvent***

#### Synopsis

VOID sysClearTimerEvent(UINT32 nTimeNo, UINT32 uTimeEventNo);

#### Description

This function is used to clear the event of selected timer. *nTimeNo* is used to select timer 0 ~ timer 3. The event function which indicated by *uTimeEventNo* shall be cleared. The function is useless for WDTIMER.

#### Parameter

nTimeNo TIMER0, TIMER1, TIMER2 or TIMER3.

uTimeEventNo Event number which want to clear. The event number is the return value of function-sysSetTimerEvent().

**Return value**

None

**Example**

```
/* clear event NO 5 */  
sysClearTimerEvent (TIMER0, 5);
```

***sysClearWatchDogTimerCount*****Synopsis**

```
VOID sysClearWatchDogTimerCount(VOID);
```

**Description**

This function is used to clear watch dog timer reset counter. When interrupt occurred, the system will be reset after 1024 clock cycles. Clear the timer reset counter, the system will not be reset.

**Parameter**

None

**Return value**

None

**Example**

```
sysClearWatchDogTimerCount();
```

***sysClearWatchDogTimerInterruptStatus*****Synopsis**

```
VOID sysClearWatchDogTimerInterruptStatus(VOID);
```

**Description**

This function is used to clear watch dog timer interrupt status. When interrupt occurred, the watch dog timer interrupt flag will be set. Clear this flag, the interrupt will occur again as reaching next watch dog timer interval.

**Parameter**

None

**Return value**

None

**Example**

```
sysClearWatchDogTimerInterruptStatus();
```

## ***sysDelay***

### **Synopsis**

VOID sysDelay(UINT32 uTicks);

### **Description**

This function is used to delay a specific period. *uTicks* is the length of delay time is ten milliseconds default. The tick time bases on function-sysSetTimerReferenceClock(). Please notice that the delay period has an extent of error which is less than ten milliseconds.

### **Parameter**

uTicks      Delay period which unit is ten milliseconds

### **Return value**

None

### **Example**

```
/* delay 1s*/  
sysDelay(100);
```

## ***sysDisableWatchDogTimer***

### **Synopsis**

VOID sysDisableWatchDogTimer(VOID);

### **Description**

This function is used to disable watch dog timer.

### **Parameter**

None

### **Return value**

None

### **Example**

```
sysDisableWatchDogTimer();
```

## ***sysDisableWatchDogTimerReset***

### **Synopsis**

VOID sysDisableWatchDogTimerReset(VOID);

### **Description**

This function is used to disable watch dog timer reset function.

**Parameter**

None

**Return value**

None

**Example**

```
sysDisableWatchDogTimerReset();
```

***sysEnableWatchDogTimer*****Synopsis**

```
VOID sysEnableWatchDogTimer(VOID);
```

**Description**

This function is used to enable watch dog timer.

**Parameter**

None

**Return value**

None

**Example**

```
sysEnableWatchDogTimer();
```

***sysEnableWatchDogTimerReset*****Synopsis**

```
VOID sysEnableWatchDogTimerReset(VOID);
```

**Description**

This function is used to enable watch dog timer reset function. The system will be reset when this function is enabled.

**Parameter**

None

**Return value**

None

**Example**

```
sysEnableWatchDogTimerReset();
```



## ***sysGetCurrentTime***

### **Synopsis**

```
VOID sysGetCurrentTime(DateTime_T *curTime);
```

### **Description**

This function is used to get local time. *curTime* is a structure pointer which contains year, month, day, hour, minute, and second information.

### **Parameter**

\*curTime structure pointer which contains the following information

```
typedef struct datetime_t
{
    UINT32 year;
    UINT32 mon;
    UINT32 day;
    UINT32 hour;
    UINT32 min;
    UINT32 sec;
} DateTime_T;
```

### **Return value**

None

### **Example**

```
/* set local time*/
DateTime_T    TimeInfo;
sysGetCurrentTime(TimeInfo);
```

## ***sysGetTicks***

### **Synopsis**

```
UINT32 sysGetTicks(INT32 nTimeNo);
```

### **Description**

This function gets the Timer 0 or Timer 1's current tick count.

### **Parameter**

nTimeNo TIMER0, TIMER1, TIMER2 or TIMER3.

### **Return value**

The current selected timer tick count.

### Example

```
/* Get current timer 0 tick count */  
UINT32 btime;  
btime = sysGetTicks(TIMER0);
```

## ***sysInstallWatchDogTimerISR***

### Synopsis

PVOID sysInstallWatchDogTimerISR(INT32 nIntTypeLevel, PVOID pvNewISR);

### Description

This function is used to set up own watch dog timer interrupt service routine. *nIntTypeLevel* is select interrupt to be FIQ or IRQ, and level group 0 ~ 7. *pvNewISR* is the own interrupt service routine's pointer.

### Parameter

nIntTypeLevel     FIQ\_LEVEL\_0, IRQ\_LEVEL\_1 ~ IRQ\_LEVEL\_7  
pvNewISR     The pointer of watch dog timer interrupt service routine

### Return value

a pointer which point to old ISR

### Example

```
/* Set watch dog timer interrupt to be IRQ and group level 1 */  
PVOID oldVect;  
oldVect = sysInstallWatchDogTimerISR(IRQ_LEVEL_1, myWatchDogISR);
```

## ***sysResetTicks***

### Synopsis

INT32 sysResetTicks(INT32 nTimeNo);

### Description

This function used to reset Timer 0, Timer 1, Timer 2 or Timer 3's global tick counter. The function is useless for WDTIMER.

### Parameter

nTimeNo     TIMER0, TIMER1, TIMER2 or TIMER3

### Return value

Successful

### Example

```

/* Reset timer 0 tick count */
INT32 status;
status = sysResetTicks(TIMER0);

```

## ***sysSetLocalTime***

### **Synopsis**

```
VOID sysSetLocalTime(DateTime_T ltime);
```

### **Description**

This function is used to set local time. *ltime* is a structure which contains year, month, day, hour, minute, and second information.

### **Parameter**

*ltime*      Structure which contains the following information

```

typedef struct datetime_t
{
    UINT32 year;
    UINT32 mon;
    UINT32 day;
    UINT32 hour;
    UINT32 min;
    UINT32 sec;
} DateTime_T;

```

### **Return value**

None

### **Example**

```

/* set local time*/
DateTime_T      TimeInfo;
TimeInfo.year = 2006;
TimeInfo.mon = 6;
TimeInfo.day = 12
TimeInfo.hour = 9;
TimeInfo.min = 0;
TimeInfo.sec = 30;
sysSetLocalTime(TimeInfo);

```

## ***sysSetTimerReferenceClock***

## Synopsis

```
INT32 sysSetTimerReferenceClock(UINT32 nTimeNo, UINT32 uClockRate);
```

## Description

This function used to set the timer's reference clock. The default reference clock is system clock (12MHz). The function is useless for WDTIMER.

**Parameter**

nTimeNo TIMER0, TIMER1, TIMER2 or TIMER3

uClockRate	Reference clock
------------	-----------------

### Return Value

Successful

### Example

```
/* Set 20MHz to be timer 0's reference clock */
INT32 status;

status = sysSetTimerReferenceClock(TIMER0, 20000000);
```

## ***sysSetWatchDogTimerInterval***

## Synopsis

```
INT32 sysSetWatchDogTimerInterval(INT32 nWdtInterval);
```

### Description

This function is used to set the watch dog timer interval. The default is 0.5 minutes. You can select interval to be 0.5, 1, 2, and 4 minutes.

**Parameter**

```
nWdtInterval      WDT_INTERVAL_0,          WDT_INTERVAL_1,
WDT_INTERVAL_2, WDT_INTERVAL_3.
```

The watch dog timer interval is shown as follows bases on 12MHz.

nWdtInterval	Interrupt Timeout	Reset Timeout	Real Time Interval
WDT_INTERVAL_0	$2^{14}$ clocks	$2^{14} + 1024$ clocks	0.371 sec.
WDT_INTERVAL_1	$2^{16}$ clocks	$2^{16} + 1024$ clocks	1.419 sec.
WDT_INTERVAL_2	$2^{18}$ clocks	$2^{18} + 1024$ clocks	5.614 sec.
WDT_INTERVAL_3	$2^{20}$ clocks	$2^{20} + 1024$ clocks	22.391 sec.

### Return value

Successful

### Example

```
/* Set watch dog timer interval to WDT_INTERVAL_0 */  
INT32 status;  
status = sysSetWatchDogTimerInterval(WDT_INTERVAL_0);
```

## ***sysStartTimer***

### Synopsis

```
INT32 sysStartTimer(INT32 nTimeNo, UINT32 uTicksPerSecond, INT32  
nOpMode);
```

### Description

*nTimeNo* is used to select Timer 0, Timer 1, Timer 2, Timer3 or What-dog Timer. Because of the chip's timer has four operation modes, the *nOpMode* is used to set the operation mode. *uTicksPerSecond* indicates that how many ticks per second.

### Parameter

*nTimeNo* TIMER0, TIMER1, TIMER2, TIMER3 or WDTIMER.

*nTickPerSecond* Tick number per second. It is useless if WDTIMER

*nOpMode* Working mode. Please refer the [Table 26-2:Timer Mode](#). It is useless for WDTIMER

### Return Value

Successful

### Example

```
/* Start the timer 1, and set it to periodic mode and 100 ticks per second */  
INT32 status;  
status = sysStartTimer(TIMER1, 100, PERIODIC_MODE);
```

## ***sysStopTimer***

### Synopsis

```
INT32 sysStopTimer(INT32 nTimeNo);
```

### Description

*sysStopTimer* will stop the specified timer channel. *nTimeNo* is used to select timer 0 ~ timer 3 or Watch Dog Timer. After disabling timer, this function will restore the interrupt service routine.

### Parameter

*nTimeNo* TIMER0, TIMER1, TIMER2, TIMER3 or WDTIMER.

**Return Value**

Successful

**Example**

```
/* Stop the timer 1 */  
INT32 status;  
status = sysStopTimer(TIMER1);
```

***sysUpdateTickCount*****Synopsis**

INT32 sysUpdateTickCount(INT32 nTimeNo, UINT32 uCount);

**Description**

This function used to update Timer 0, Timer 1, Timer 2 or Timer 3's global tick counter.

**Parameter**

nTimeNo   TIMER0, TIMER1, TIMER2 or TIMER3

uCount     Tick counter value

**Return Value**

Successful

**Example**

```
/* update timer 0's tick counter as 3000 */  
sysUpdateTickCount (TIMER0, 3000);
```

***UART Function***

Table 26-4: UART Port

Port Name	Value	Description
WB_UART_0	0	UART 0 – High Speed UART
WB_UART_1	1	UART 1 – Normal Speed UART

Table 26-5: UART Data Bits

Data Bits	Value	Description
WB_DATA_BITS_5	0	5 Data Bits
WB_DATA_BITS_6	1	6 Data Bits

WB_DATA_BITS_7	2	7 Data Bits
WB_DATA_BITS_8	3	8 Data Bits

Table 26-6: UART Stop Bits

Stop Bits	Value	Description
WB_STOP_BITS_1	0x0	1 Stop Bit
WB_STOP_BITS_2	0x4	2 Stop Bits

Table 26-7: UART Parity Bits

Parity Buts	Value	Description
WB_PARITY_NONE	0x0	Non Parity Bit
WB_PARITY_ODD	0x8	Odd Parity Bit
WB_PARITY_EVEN	0x18	Even Parity Bit

Table 26-8: UART FIFO Threshold

FIFO	Value	Description
LEVEL_1_BYTE	0x0	1 Byte FIFO
LEVEL_4_BYTES	0x1	4 Bytes FIFO
LEVEL_8_BYTES	0x2	8 Bytes FIFO
LEVEL_14_BYTES	0x3	14 Bytes FIFO
LEVEL_30_BYTE	0x4	30 Bytes FIFO (High Speed UART Only)
LEVEL_46_BYTES	0x5	46 Bytes FIFO (High Speed UART Only)
LEVEL_62_BYTES	0x6	62 Bytes FIFO (High Speed UART Only)

Table 26-9: UART Interrupt type

FIFO	Value	Description
UART_INT_RDA	0x0	UART Data Ready
UART_INT_RDTO	0x1	UART Time out
UART_INT_NONE	0xFF	Not to enable UART

**sysUartPort**

**Synopsis**

```
VOID    sysUartPort(UINT32 u32Port);
```

**Description**

This function is used to set UART port that will be used in the future.

**Parameter**

u32Port 0 or 1. The value stands for UART port 0 and port 1.

**Return Value**

None.

**Example**

```
/* Set UART port 1 for the future that UART API will work on */
sysUartPort(1);
```

***sysGetChar*****Synopsis**

```
CHAR sysGetChar(VOID);
```

**Description**

This function is user to obtain the next available character from the UART. Nothing is echoed. When no available characters are found, the function waits until a character from UART is found.

**Parameter**

None

**Return Value**

A character from UART

**Example**

```
/* get user's input*/
CHAR cUserInput;
cUserInput = sysGetChar();
```

***sysInitializeUART*****Synopsis**

```
INT32 sysInitializeUART(WB_UART *uart);
```

**Description**

WB\_UART is the device initialization structure. The definition is as following:



```
typedef struct UART_INIT_STRUCT
```

```
{
    UINT32 uart_no;
    UINT32 freq;
    UINT32 baud_rate;
    UINT32 data_bits;
    UINT32 stop_bits;
    UINT32 parity;
    UINT32 rx_trigger_level;
} WB_UART;
```

*uart->uart\_no* is UART port to be initialized.

*uart->freq* is UART reference clock. Default is 15MHz. If user have different reference clock, used this parameter to change it.

*uart->baud\_rate* is used to set the COM port baud rate. The range is from 9600 to 230400.

The UART data bit can be 5, 6, 7, or 8. Use *uart->data\_bits* to set the suitable data bits.

The UART stop bit can be 1, or 2. Use *uart->stop\_bits* to set the suitable stop bits.

*uart->parity* is used to set the suitable parity check.

*uart->rx\_trigger\_level* is used to set the suitable trigger level.

#### Parameter

*uart->uart\_no*      WB\_UART\_0: High speed UART    port.

                    WB\_UART\_1: Normal speed UART port.

*uart->data\_bits*    WB\_DATA\_BITS\_5 ~ WB\_DATA\_BITS\_8

*uart->stop\_bits*    WB\_STOP\_BITS\_1, WB\_STOP\_BITS\_2

*uart->parity*        WB\_PARITY\_NONE,                      WB\_PARITY\_ODD,  
WB\_PARITY\_EVEN

*uart->rx\_trigger\_level*      LEVEL\_1\_BYTE,                      LEVEL\_4\_BYTES,  
LEVEL\_8\_BYTES, LEVEL\_14\_BYTES are for normal/high speed UART. And  
LEVEL\_30\_BYTES, LEVEL\_46\_BYTES and LEVEL\_62\_BYTES are only for high  
speed UART. Normal speed UART means the baud rate less or equal to 115200  
bps. And high speed UART means the baud rate up to 921600 bps.

#### Return Value

Successful/              WB\_INVALID\_PARITY/              WB\_INVALID\_DATA\_BITS/  
WB\_INVALID\_STOP\_BITS/ WB\_INVALID\_BAUD

#### Example

```
WB_UART_T uart;
```

```

uart.uart_no = WB_UART_1 ;
uart.uiFreq = APB_SYSTEM_CLOCK;
uart.uiBaudrate = 115200;
uart.uiDataBits = WB_DATA_BITS_8;
uart.uiStopBits = WB_STOP_BITS_1;
uart.uiParity = WB_PARITY_NONE;
uart.uiRxTriggerLevel = LEVEL_1_BYTE;
sysInitializeUART(&uart);    WB_UART_T uart;

```

## ***sysPrintf***

### **Synopsis**

VOID sysPrintf(PCHAR pcStr, ...);

### **Description**

The function sends the specified *str* to the terminal through the RS-232 interface by interrupt mode.

### **Parameter**

pcStr      pointer of string which want to display

### **Return Value**

None

### **Example**

```
sysPrintf("Hello World!\n");
```

## ***sysprintf***

### **Synopsis**

VOID sysPrintf(PCHAR pcStr, ...);

### **Description**

The function sends the specified *str* to the terminal through the RS-232 interface by polling mode.

### **Parameter**

pcStr      pointer of string which want to display

### **Return Value**

None

### Example

```
sysprintf("Hello World!\n");
```

## ***sysPutChar***

### **Name**

sysPutChar – put a character out to UART

### **Synopsis**

```
VOID sysPutChar(UCHAR ch);
```

### **Description**

The function sends the specified *ch* to the UART.

### **Parameter**

ch character which want to display

### **Return Value**

None

### Example

```
sysPutChar("A");
```

## ***sysUartInstallcallback***

### **Name**

sysUartInstallcallback – install callback function for high speed UART data ready event or data time out event processing.

### **Synopsis**

```
void sysUartInstallcallback(UINT32 u32IntType,  
                             PFN_SYS_UART_CALLBACK pfnCallback);
```

### **Description**

The function is used to install the call back function for received data ready or received data time out. The call back function need following structure.

```
typedef void (*PFN_SYS_UART_CALLBACK)(  
    UINT8* u8Buf,  
    UINT32 u32Len);  
  
u8Buf          Received data buffer pointer.  
u32Len         Received data length.
```

### **Parameter**

u32IntType            interrupt type. Please refer Table 26-9: UART Interrupt type  
 pfnCallback           a function pointer to process the received data ready and  
 received data time out event.

**Return Value**

None

**Example**

```
sysUartInstallcallback(UART_INT_RDA, UartDataValid_Handler);
sysUartInstallcallback(UART_INT_RDTO, UartDataTimeOut_Handler);
```

***sysUartEnableInt***

**Name**

sysUartEnableInt– enable UART interrupt type.

**Synopsis**

VOID sysUartEnableInt(INT32 eIntType);

**Description**

The function is used to enable UART interrupt.

**Parameter**

eIntType    UART interrupt type. Please refer Table 26-9: UART Interrupt type

**Return Value**

None

**Example**

```
sysUartEnableInt(UART_INT_RDA);
sysUartEnableInt(UART_INT_RDTO);
.....
sysUartEnableInt(UART_INT_NONE);
```

***sysUartTransfer***

**Name**

sysUartTransfer– Start up the UART transfer.

**Synopsis**

VOID sysUartTransfer(char\* pu8buf, UINT32 u32Len);

**Description**

The function is used to transfer data.

**Parameter**

pu8buf	Transfer data buffer pointer.
u32Len	Transfer data length.

**Return Value**

None

**Example**

```
sysUartTransfer(pi8UartBuf, u32Count);
```

## ***sysInitializeHUART***

**Synopsis**

```
INT32 sysInitializeHUART(WB_UART *uart);
```

**Description**

Initialize high speed UART. WB\_UART is the device initialization structure. The definition is as following:

```
typedef struct UART_INIT_STRUCT
{
    UINT32 uart_no;
    UINT32 freq;
    UINT32 baud_rate;
    UINT32 data_bits;
    UINT32 stop_bits;
    UINT32 parity;
    UINT32 rx_trigger_level;
} WB_UART;
```

*uart->uart\_no* is UART port to be initialized. It will be WB\_UART\_0.

*uart->freq* is UART reference clock. Default is 12MHz. If user have different reference clock, used this parameter to change it.

*uart->baud\_rate* is used to set the COM port baud rate. The range is from 9600 to 230400.

The UART data bit can be 5, 6, 7, or 8. Use *uart->data\_bits* to set the suitable data bits.

The UART stop bit can be 1, or 2. Use *uart->stop\_bits* to set the suitable stop bits.

*uart->parity* is used to set the suitable parity check.

*uart->rx\_trigger\_level* is used to set the suitable trigger level.

### Parameter

```
uart->uart_no      WB_UART_0: High speed UART port.
                  WB_UART_1: Normal speed UART port.
uart->data_bits    WB_DATA_BITS_5 ~ WB_DATA_BITS_8
uart->stop_bits    WB_STOP_BITS_1, WB_STOP_BITS_2
uart->parity       WB_PARITY_NONE,                  WB_PARITY_ODD,
WB_PARITY_EVEN
uart->rx_trigger_level  LEVEL_1_BYTE,                  LEVEL_4_BYTES,
LEVEL_8_BYTES, LEVEL_14_BYTES are for normal/high speed UART. And
LEVEL_30_BYTES, LEVEL_46_BYTES and LEVEL_62_BYTES are only for high
speed UART. Normal speed UART means the baud rate less or equal to 115200
bps. And high speed UART means the baud rate up to 921600 bps.
```

### Return Value

Successful/ WB\_INVALID\_PARITY/ WB\_INVALID\_DATA\_BITS/  
WB\_INVALID\_STOP\_BITS/ WB\_INVALID\_BAUD

### Example

```
WB_UART_T uart;

uart.uart_no = WB_UART_0;

uart.uiFreq = APB_SYSTEM_CLOCK;

uart.uiBaudrate = 115200;

uart.uiDataBits = WB_DATA_BITS_8;

uart.uiStopBits = WB_STOP_BITS_1;

uart.uiParity = WB_PARITY_NONE;

uart.uiRxTriggerLevel = LEVEL_1_BYTE;

sysInitializeHUART(&uart);
```

## ***sysHuartEnableInt***

## Name

**sysHuartEnableInt**– Enable high speed UART interrupt by specified interrupt type or disable UART port interrupt.

## Synopsis

```
VOID sysHuartEnableInt(INT32 eIntType);
```

### Description

The function is used to enable high speed UART interrupt.

### Parameter

**eIntType** High speed UART interrupt type. Please refer Table 26-9: UART

Interrupt type

**Return Value**

None

**Example**

```
sysHuartEnableInt(UART_INT_RDA);  
sysHuartEnableInt(UART_INT_RDTO);  
.....  
sysHuartEnableInt(UART_INT_NONE);
```

***sysHuartTransfer***

**Name**

sysHuartTransfer– Start up the high speed UART transfer.

**Synopsis**

```
VOID sysHuartTransfer(char* pu8buf, UINT32 u32Len);
```

**Description**

The function is used to transfer data.

**Parameter**

pu8buf	Transfer data buffer pointer.
u32Len	Transfer data length.

**Return Value**

None

**Example**

```
sysHuartTransfer(pi8UartBuf, u32Len);
```

***sysHuartReveive***

**Name**

sysHuartReceive– Receive one byte from high speed UART.

**Synopsis**

```
INT8 sysHuartReceive(VOID);
```

**Description**

The function is used to receive data from high speed UART port.

**Parameter**

None

**Return Value**

Receive data

**Example**

```
i8UartData = sysHuartReceive();
```

**AIC Functions**

Table 26-10: Interrupt No.

AIC Interrupt No	Value	Description
IRQ_WDT	1	Watch Dog Timer Interrupt
IRQ_EXTINT0	2	GPIO Group 0 interrupt
IRQ_EXTINT1	3	GPIO Group 1 interrupt
IRQ_EXTINT2	4	GPIO Group 2 interrupt
IRQ_EXTINT3	5	GPIO Group 3 interrupt
IRQ_IPSEC	6	AES Interrupt
IRQ_SPU	7	SPU Interrupt
IRQ_I2S	8	I2S Interrupt
IRQ_VPOST	9	VPOST Interrupt
IRQ_VIN	10	Video In 0 Interrupt
IRQ_MDCT	11	MDCT Interrupt
IRQ_BLT	12	BLT Interrupt
IRQ_VPE	13	VPE Interrupt
IRQ_HUART	14	High Speed UART Interrupt
IRQ_TMR0	15	Timer 0 Interrupt
IRQ_TMR1	16	Timer 1 Interrupt
IRQ_UDC	17	USB Device Controller Interrupt
IRQ_SIC	18	Storage Interrupt Controller Interrupt
IRQ_SDIO	19	Secure Digital Input / Output Control Interrupt
IRQ_UHC	20	USB Host Controller Interrupt
IRQ_EHCI	21	Enhanced Host Controller Interface Interrupt
IRQ_OHCI	22	Host Controller Interface Interrupt



IRQ_EDMA0	23	Enhanced DMA 0 Interrupt
IRQ_EDMA1	24	Enhanced DMA 1 Interrupt
IRQ_SPIMS0	25	SPI Master / Slave 0 Interrupt
IRQ_SPIMS1	26	SPI Master / Slave 1 Interrupt
IRQ_AUDIO	27	Audio Record Interrupt
IRQ_TOUCH	28	Touch Controller Interrupt
IRQ_RTC	29	RTC Interrupt
IRQ_UART	30	UART Interrupt
IRQ_PWM	31	PWM Interrupt
IRQ_JPG	32	JPEG Codec Interrupt
IRQ_VDE	33	H264 Decode Interrupt
IRQ_VEN	34	H264 Encode Interrupt
IRQ_SDIC	35	SDIC Interrupt
IRQ_EMCTX	36	EMC TX Interrupt
IRQ_EMCRX	37	EMC RX Interrupt
IRQ_I2C	38	I2C Interrupt
IRQ_KPI	39	Keypad Interrupt
IRQ_RSC	40	RS Codec Interrupt
IRQ_VTB	41	Convolution / Viterbi Codec Interrupt
IRQ_ROT	42	Convolution / Viterbi Codec Interrupt
IRQ_PWR	43	System Wake-Up Interrupt
IRQ_LVD	44	Low Voltage Detector Interrupt
IRQ_VIN1	45	Video In 1 Interrupt
IRQ_TMR2	46	Timer 2 Interrupt
IRQ_TMR3	47	Timer 3 Interrupt

Table 26-11 : Interrupt Exception Type

Exception Type	Value	Description
WB_SWI	0	Software Interrupt
WB_D_ABORT	1	Data Abort Interrupt
WB_I_ABORT	2	Instruction Abort Interrupt
WB_UNDEFINE	3	Undefined Interrupt

Table 26-12: Interrupt Priority

Interrupt Priority	Value	Description
FIQ_LEVEL_0	0	Highest Priority
IRQ_LEVEL_1	1	Level 1 Priority
IRQ_LEVEL_2	2	Level 2 Priority
IRQ_LEVEL_3	3	Level 3 Priority
IRQ_LEVEL_4	4	Level 4 Priority
IRQ_LEVEL_5	5	Level 5 Priority
IRQ_LEVEL_6	6	Level 6 Priority
IRQ_LEVEL_7	7	Lowest Priotity

Table 26-13: Local Interrupt Type

Local Interrupt Type	Value	Description
ENABLE_IRQ	0x7F	Enable ARM Core's IRQ bit
ENABLE_FIQ	0xBF	Enable ARM Core's FIQ bit
ENABLE_FIQ_IRQ	0x3F	Enable ARM core's FIQ and IRQ bit
DISABLE_IRQ	0x80	Disable ARM Core's IRQ bit
DISABLE_FIQ	0x40	Disable ARM Core's FIQ bit
DISABLE_FIQ_IRQ	0xC0	Disable ARM core's FIQ and IRQ bit

Table 26-14: Interrupt Trigger Type

Interrupt Trigger Type	Value	Description
LOW_LEVEL_SENSITIVE	0x00	Low Level Trigger Type
HIGH_LEVEL_SENSITIVE	0x01	High Level Trigger Type
NEGATIVE_EDGE_TRIGGER	0x02	Falling Edge Trigger Type
POSITIVE_EDGE_TRIGGER	0x03	Rising Edge Trigger Type

### ***sysDisableInterrupt***

#### **Name**

sysDisableInterrupt – disable interrupt source

#### **Synopsis**

```
INT32 sysDisableInterrupt(UINT32 intNo);
```

#### **Description**

This function is used to disable interrupt source.

**Parameter**

intNo      interrupt source number. Please refer the Table 26-10: Interrupt No.

**Return Value**

Successful or Fail.

**Example**

```
/* Disable timer 0 interrupt (source number is 7) */  
INT32 status;  
status = sysDisableInterrupt(7);
```

***sysEnableInterrupt*****Synopsis**

```
INT32 sysEnableInterrupt(UINT32 intNo);
```

**Description**

This function is used to enable interrupt source. Please refer the [Table 26-10: Interrupt No.](#)

**Parameter**

intNo      interrupt source number

**Return Value**

Successful or Fail.

**Example**

```
/* Enable timer 0 interrupt (source number is 7) */  
INT32 status;  
status = sysEnableInterrupt(7);
```

***sysGetIbitState*****Synopsis**

```
BOOL      sysGetIbitState (VOID);
```

**Description**

This function is used to get the status of interrupt disable bit, I-bit, of CPSR register.

**Parameter**

None

**Return Value**

TRUE – I-bit is clear, FALSE – I-bit is set.

**Example**

```
BOOL int_status;  
Int_status = sysGetIBitState();
```

***sysGetInterruptEnableStatus*****Synopsis**

UINT32      sysGetInterruptEnableStatus(VOID);

**Description**

This function is used to get the enable/disable status of low channel interrupts which save in AIC\_IMR register.

**Parameter**

None

**Return Value**

value of AIC\_IMR register

**Example**

```
/* Set AIC as software mode */  
UINT32 uIMRValue;  
uIMRValue = sysGetInterruptEnableStatus();
```

***sysGetInterruptHighEnableStatus*****Synopsis**

UINT32      sysGetInterruptHighEnableStatus(VOID);

**Description**

This function is used to get the enable/disable status of high channel interrupts which save in AIC\_IMRH register.

**Parameter**

None

**Return Value**

value of AIC\_IMRH register

**Example**

```

/* Set AIC as software mode */
UINT32 uIMRValue;
uIMRValue = sysGetInterruptHighEnableStatus();

```

## ***sysInstallExceptionHandler***

### **Synopsis**

PVOID sysInstallExceptionHandler(INT32 exceptType, PVOID pNewHandler);

### **Description**

This function is used to install *pNewHandler* into *exceptType* exception.

### **Parameter**

exceptType      WB\_SWI, WB\_D\_ABORT, WB\_I\_ABORT, WB\_UNDEFINE

Please refer the Table 26-11 : Interrupt Exception Type

pNewHandler    pointer of the new handler

### **Return Value**

a pointer which point to old handler

### **Example**

```

/* Setup own software interrupt handler */
PVOID oldVect;
oldVect = sysInstallExceptionHandler(WB_SWI, pNewSWIHandler);

```

## ***sysInstallFiqHandler***

### **Synopsis**

PVOID sysInstallFiqHandler(PVOID pNewISR);

### **Description**

Use this function to install FIQ handler into interrupt vector table.

### **Parameter**

pNewISR    pointer of the new ISR handler

### **Return Value**

a pointer which point to old ISR

### **Example**

```

/* Setup own FIQ handler */

```

```
PVOID oldVect;  
oldVect = sysInstallFiqHandler(pNewFiqISR);
```

### ***sysInstallIrqHandler***

#### **Synopsis**

```
PVOID sysInstallIrqHandler(PVOID pNewISR);
```

#### **Description**

Use this function to install FIQ handler into interrupt vector table.

#### **Parameter**

pNewISR pointer of the new ISR handler

#### **Return Value**

A pointer which point to old ISR

#### **Example**

```
/* Setup own IRQ handler */  
PVOID oldVect;  
oldVect = sysInstallIrqHandler(pNewIrqISR);
```

### ***sysInstallISR***

#### **Synopsis**

```
PVOID sysInstallISR(INT32 intTypeLevel, INT_SOURCE_E intNo, PVOID  
pNewISR);
```

#### **Description**

Interrupt priority level is 0 ~ 7. Level 0 is FIQ, and level 1 ~ 7 are IRQ. The highest priority is 0, and the lowest priority is 7. Use this function to set up interrupt source (*intNo*) *pNewISR* handler to AIC interrupt vector table.

#### **Parameter**

intTypeLevel      FIQ\_LEVEL\_0, IRQ\_LEVEL\_1 ~ IRQ\_LEVEL\_7

Please refer the Table 26-12: Interrupt Priority

intNo              interrupt source number

Please refer the Table 26-10: Interrupt No.

pNewISR      Function pointer of new ISR.

#### **Return Value**

A function pointer which points to old ISR

### Example

```
/* Setup timer 0 handler */  
PVOID oldVect;  
oldVect = sysInstallISR(IRQ_LEVEL_1, IRQ_TMR0, pTimerISR);
```

## ***sysSetAIC2SWMode***

### Synopsis

```
INT32 sysSetAIC2SWMode(VOID);
```

### Description

This function is used to set AIC as software mode. When the system AIC in software mode, the priority of each interrupt source shall be handled by software.

### Parameter

intState    ENABLE\_IRQ, ENABLE\_FIQ, ENABLE\_FIQ\_IRQ, DISABLE\_IRQ,  
             DISABLE\_FIQ, DISABLE\_FIQ\_IRQ

### Return Value

Successful

### Example

```
/* Set AIC as software mode */  
sysSetAIC2SWMode();
```

## ***sysSetGlobalInterrupt***

### Synopsis

```
INT32 sysSetGlobalInterrupt(INT32 intState);
```

### Description

The function is used to enable or disable all interrupt sources.

### Parameter

intState            ENABLE\_ALL\_INTERRUPTS or  
                     DISABLE\_ALL\_INTERRUPTS

### Return Value

Successful

### Example

```
/* Disable all interrupt */
```

```
INT32 status;  
status = sysSetGlobalInterrupt(DISABLE_ALL_INTERRUPTS);
```

## ***sysSetInterruptPriorityLevel***

### **Synopsis**

```
INT32 sysSetInterruptPriorityLevel(INT_SOURCE_E intNo, UINT32 intLevel);
```

### **Description**

The interrupt has 8 group levels. The highest priority is 0, and the lowest priority is 7. Use this function can change the priority level after install ISR.

### **Parameter**

intNo                      interrupt source number

Please refer the Table 26-10: Interrupt No.

intLevel                  Interrupt priority. Please refer Table 26-12: Interrupt Priority.

### **Return Value**

Successful or Fail.

### **Example**

```
/* Change timer 0 priority to level 4 */  
INT32 status;  
status = sysSetInterruptPriorityLevel(7, 4);
```

## ***sysSetInterruptType***

### **Synopsis**

```
INT32 sysSetInterruptType(INT_SOURCE_E intNo, UINT32 intSourceType);
```

### **Description**

The interrupt has four kinds of interrupt source types. They are low level sensitive, high level sensitive, negative edge trigger, and positive edge trigger. The default is high level sensitive. This function is used to change the interrupt source type.

### **Parameter**

intNo                      interrupt source number

Please refer the Table 26-10: Interrupt No.

intSourceType            Interrupt trigger type.

Please refer the Table 26-14: Interrupt Trigger Type

### **Return Value**

Successful or Fail.



### Example

```
/* Change timer 0 source type to be positive edge trigger */
INT32 status;
status = sysSetInterruptType(IRQ_TMR0, POSITIVE_EDGE_TRIGGER);
```

## ***sysSetLocalInterrupt***

### Synopsis

```
INT32 sysSetLocalInterrupt(INT32 intState);
```

### Description

The CPSR I bit and F bit need to be enabled or disabled, when using interrupt. This function is used to enable / disable I bit and F bit.

### Parameter

intState                      Enable or disable ARM core's F and I bit.  
Please refer Table 26-13: Local Interrupt Type

### Return Value

Successful

### Example

```
/* Enable I bit of CPSR */
INT32 state;
state = sysSetLocalInterrupt(ENABLE_IRQ);
```

## **26.3 CACHE FUNCTION**

### ***sysDisableCache***

### Synopsis

```
VOID sysDisableCache(VOID);
```

### Description

This function is used to disable cache.

### Parameter

None

### Return Value

None

### Example

```
/* disabled cache */  
sysDisableCache();
```

## ***sysEnableCache***

### Synopsis

```
VOID sysEnableCache(UINT32 uCacheOpMode);
```

### Description

This function is used to enable cache.

### Parameter

uCacheOpMode    CACHE\_WRITE\_BACK, CACHE\_WRITE\_THROUGH

### Return Value

None

### Example

```
/* enable cache */  
sysEnableCache();
```

## ***sysFlushCache***

### Synopsis

```
VOID sysFlushCache(INT32 cacheType);
```

### Description

This function is used to flush system cache. The parameter, cacheType is used to select cache which needs to be flushed.

### Parameter

cacheType        I\_CACHE, D\_CACHE, I\_D\_CACHE

### Return Value

None

### Example

```
/* flush cache */  
sysFlushCache(I_D_CACHE);
```

## ***sysGetCacheState***

**Synopsis**

VOID sysGetCacheState (VOID);

**Description**

This function is used to get the enable/disable status of cache.

**Parameter**

None

**Return Value**

None

**Example**

```
/* Read cache status */  
BOOL status;  
status = sysGetCacheState();
```

***sysGetSdramSizebyMB*****Synopsis**

INT32 sysGetSdramSizebyMB(VOID);

**Description**

This function returns the size (in Mbytes) of total memory.

**Parameter**

None

**Return Value**

Memory size or Fail

**Example**

```
/* Get the memory size */  
INT32 memsize;  
memsize = sysGetSdramSizebyMB();  
sysprintf("The total memory size is %dMbytes\n", memsize);
```

***sysInvalidCache*****Synopsis**

VOID sysInvalidCache (VOID);

**Description**

This function is used to invalid both Instruction and Data cache contents.

**Parameter**

None

**Return Value**

None

**Example**

```
/* Invalid cache */  
sysInvalideCache();
```

## ***sysSetCachePages***

**Synopsis**

```
INT32 sysSetCachePages(UINT32 addr, INT32 size, INT32 cache_mode);
```

**Description**

This function is used to change the cache mode of a memory area. Note that the starting address and the size must be 4Kbytes boundary.

**Parameter**

addr        The memory starting address.

size        The memory size.

cache\_mode    CACHE\_WRITE\_BACK / CACHE\_WRITE\_THROUGH /  
                CACHE\_DISABLE.

**Return Value**

Successful or Fail

**Example**

```
/* enable cache to write-back mode */  
sysEnableCache(CACHE_WRITE_BACK);  
  
...  
sysFlushCache();  
  
/* Change the memory region 0x1000000 ~ 0x1001000 to be non-cacheable */  
sysSetCachePages(0x1000000, 4096, CACHE_DISABLE);
```

## **26.4 CLOCK CONTROL FUNCTION**

### ***sysGetExternalClock***

### Synopsis

UINT32 sysGetExternalClock(void);

### Description

This function is used to get external clock setting. IBR only support 2 kinds of external clock frequency. 12MHz or 27MHz. So external clock will be 12MHz or 27MHz. The power on setting must meet the external clock.

### Parameter

None

### Return Value

External clock. Unit : Hz

### Example

```
/* Read system clock setting */
UINT32 u32ExtFreq;
u32ExtFreq = sysGetExternalClock();
```

## ***sysSetSystemClock***

### Synopsis

UINT32 sysSetSystemClock(E\_SYS\_SRC\_CLK eSrcClk,  
UINT32 u32PIIHz,  
UINT32 u32SysHz);

### Description

This function is used to write system clock setting includes PLL output frequency, System clock. The function gets the external clock automatically by power on setting.

### Parameter

eSrcClk : System clock source.

It could be eSYS\_EXT, eSYS\_APLL and eSYS\_UPLL. They mean the system clock source come from external clock, APLL and UPLL respectively.

u32PIIHz : Set the APLL or UPLL output frequency.

Unit : Hz.

u32SysHz : Set the system clock output frequency.

Unit : Hz. The system clock source can be external, APLL or UPLL.

There are some limitations in the clock function due to hardware's limitation.

1. These frequency exist multiplication factor It means  $PLL \geq n * SYS$ , And HCLK clock is always equal to  $SYS / 2$ .

Where n is integer. And HCLK clock is SDR/DDR/DDR2 clock.

2. PLL clock must under or equal to 432MHz.
3. System clock must under or equal to the source clock.
4. HCLK clock depends on the layout and core power. Generally, it can up to 150MHz in core power 1.2V.

#### Return Value

Successful or Error code

#### Example

```
/* Write system clock setting */
sysSetSystemClock(eSYS_UPLL,          // system clock come from UPLL
                  288000000,          // UPLL = 288MHz
                  288000000)          // SYS = 288MHz
```

### **sysSetDramClock**

#### Synopsis

```
UINT32 sysSetDramClock(E_SYS_SRC_CLK eSrcClk,
                      UINT32 u32PIIHz,
                      UINT32 u32DdrHz);
```

#### Description

This function is used to write memory clock setting includes PLL output frequency, memory clock. The function gets the external clock automatically by power on setting.

#### Parameter

eSrcClk : System clock source.

It will be limited to eSYS\_MPLL.

u32PIIHz MPLL output frequency.

Unit : Hz.

u32DdrHz : Set the memory clock output frequency.

Unit : Hz. The system clock source can only be MPLL.

There are some limitations in the clock function due to hardware's limitation.

1. MCLK clock is equal to half of u32DdrHz. .
2. MCLK need great than HCLK1, HCLK2 and HCLK3.
3. Max MPLL output clock will be 360MHz.

#### Return Value

Successful or Error code

#### Example

```

/* Write memory clock setting */
sysSetDramClock(eSYS_MPLL,          // system clock come from MPLL
                360000000,          // MPLL = 360MHz
                360000000)          // DDR = 360MHz
sysSetSystemClock(eSYS_UPLL,        // system clock come from UPLL
                  288000000,        // UPLL = 288MHz
                  288000000)        // SYS = 288MHz

```

## ***sysSetCPUClock***

### **Synopsis**

```
UINT32 sysSetCPUClock(UINT32 u32CPUClock);
```

### **Description**

This function is used to set CPU clock.

### **Parameter**

u32CPUClock: CPU clock.

There are some limitations in the clock function due to hardware's limitation.

1. The CPU clock comes from SYS clock. It must less or equal to SYS clock.
2. The CPU divider only support even divider. It means CPU = SYS, SYS/2, SYS/4,... or SYS/16.
3. HCLK1 clock depends on CPU clock.
  - If CPU divider =1, HCLK1 = CPU/2.
  - If CPU divider !=1, HCLK1 = CPU.

### **Return Value**

Successful or Error code

### **Example**

```

/* Write system clock setting */
sysSetSystemClock(eSYS_UPLL,        //E_SYS_SRC_CLK eSrcClk,
                  192000000,        //UINT32 u32PIIKHz,
                  192000000);        //UINT32 u32SysKHz,
sysSetCPUClock(192000000);

```

## ***sysSetAPBClock***

### **Synopsis**

UINT32 sysSetAPBClock(UINT32 u32APBClock);

### **Description**

This function is used to set APB clock.

### **Parameter**

u32APBClock: APB clock.

There are some limitations in the clock function due to hardware's limitation.

1. The APB clock comes from HCLK1 clock. It must less or equal to HCLK1 clock.
2. Max APB divider is 8.

### **Return Value**

Successful or Error code

### **Example**

```
/* Write system clock setting */
sysSetSystemClock(eSYS_UPLL,          //E_SYS_SRC_CLK eSrcClk,
                  288000000,          //UINT32 u32PIIKHz,
                  288000000);         //UINT32 u32SysKHz,
sysSetCPUClock(288000000);             //HCLK1 = 144MHz.
sysSetAPBClock(72000000);              //APB = 72MHz
```

## ***sysGetPLLOutputHz***

### **Synopsis**

UINT32 sysGetPLLOutputHz ( E\_SYS\_SRC\_CLK eSysPll,  
 UINT32 u32FinHz);

### **Description**

This function is used to read PLL output frequency.

### **Parameter**

eSysPll Specified PLL wants to know.

It could be eSYS\_APLL= 2 and eSYS\_UPLL = 3.

u32FinHz: External clock. Unit : Hz.

### **Return Value**

Specified PLL output clock. Unit : Hz.



#### Example

```
u32ExtFreq = sysGetExternalClock();  
u32PllOutHz = sysGetPLLOutputHz(eSYS_UPLL, u32ExtFreq);
```

### ***sysGetSystemClock***

#### Synopsis

```
UINT32 sysGetSystemClock(void);
```

#### Description

This function is used to get system clock.

#### Parameter

None

#### Return Value

System clock. Unit: Hz.

#### Example

```
/* Read system clock setting */  
UINT32 u32SysFreq;  
u32SysFreq = sysGetSystemClock();
```

### ***sysGetDramClock***

#### Synopsis

```
UINT32 sysGetDramClock(void);
```

#### Description

This function is used to get DRAM clock.

#### Parameter

None

#### Return Value

DRAM clock. Unit: Hz.

#### Example

```
/* Read DRAM clock setting */  
UINT32 u32DramFreq;  
u32DramFreq = sysGetDramClock();
```

### ***sysGetCPUClock***

#### **Synopsis**

UINT32 sysGetCPUClock(void);

#### **Description**

This function is used to get CPU clock.

#### **Parameter**

None

#### **Return Value**

CPU clock. Unit: Hz.

#### **Example**

```
/* Read CPU clock setting */  
UINT32 u32CPUFreq;  
u32CPUFreq = sysGetCPUClock();
```

### ***sysGetHCLK1Clock***

#### **Synopsis**

UINT32 sysGetHCLK1Clock(void);

#### **Description**

This function is used to get HCLK1 clock.

#### **Parameter**

None

#### **Return Value**

HCLK1 clock. Unit: Hz.

#### **Example**

```
/* Read HCLK1 clock setting */  
UINT32 u32HCLK1Freq;  
u32HCLK1Freq = sysGetHCLK1Clock();
```

### ***sysGetAPBClock***

#### **Synopsis**

UINT32 sysGetAPBClock(void);

**Description**

This function is used to get APB clock.

**Parameter**

None

**Return Value**

APB clock. Unit: Hz.

**Example**

```
/* Read HCLK1 clock setting */
UINT32 u32APBFreq;
u32APBFreq = sysGetAPBClock();
```

***sysSetPllClock*****Synopsis**

```
UINT32 sysSetPllClock(E_SYS_SRC_CLK eSrcClk,
                     UINT32 u32TargetHz);
```

**Description**

There are two PLL in the chip. User can assign one PLL as system clock source. The other one PLL can be assigned the output frequency through the function.

**Parameter**

eSrcClk: eSYS\_APLL = 2 or eSYS\_UPLL = 3.

u32TargetHz: Target PLL output frequency. Unit : Hz.

**Return Value**

Specified PLL output frequency. Unit : Hz. The return value may not same as the specified value due to hardware's limitation. If not meet the hardware SPEC, library will auto to search the nearly frrequency.

**Example**

```
/* Write system clock setting */
sysSetSystemClock(eSYS_UPLL,           // system clock come from UPLL
                  300000000,           // UPLL = 300MHz
                  300000000);           // SYS = 300MHz
/* Specified APLL clock */
sysSetPllClock(eSYS_APLL,
               432000000);              // SYS = 432MHz
```

## ***sysCheckPllConstraint***

### **Synopsis**

UINT32 sysCheckPllConstraint (BOOL blsCheck);

### **Description**

This function is used to enable or disable PLL constraints checking as set PLL clock.

### **Parameter**

None

### **Return Value**

None

### **Example**

```
/* Set PLL clock without constraint check */
sysCheckPllConstraint(FALSE);    //Disable constraint checking
sysSetSystemClock(eSYS_UPLL,    // system clock come from UPLL
                  318000000,    // UPLL = 318MHz
                  318000000);   // SYS = 318MHz
sysCheckPllConstraint(FALSE);    //Enable constraint checking for next time.
```

## ***Power management Function***

System can enter standby mode with DDR memory enter self refresh mode. The program code was kept in DDR memory and PLLs, CPU, system clock, AHB and APB were turned off. There are 10 wake-up channels to wake-up system if system in standby mode.

Table 26-15: Wakeup Channels.

Wake up channel	Value	Description
WE_EMAC	0x1	Wake up by magic packet
WE_UHC20	0x2	Wake up by device attached or de-attached
WE_GPIO	0x100	Wake up by GPIO level change
WE_RTC	0x200	Wake up by RTC
WE_UART	0x800	Wake up by UART (RTS pin)
WE_UDC	0x1000	Wake up by attached/detached from USB host

WE_UHC	0x2000	Wake up by device attached/detached
WE_ADC	0x4000	Wake up by touch panel touch
WE_KPI	0x8000	Wake up by KPI pressing

## ***sysPowerDown***

### **Synopsis**

```
INT sysPowerDown(UINT u32WakeUpSrc);
```

### **Description**

This function is used to enter standby mode. The function also specified the wake-up channel to wake up system. Programmer need to disable the analog IPs such as TV DAC, ADC and LVD and so on before entry standby mode.

### **Parameter**

u32WakeUpSrc    Wakeup channels. Please reference Table 26-15: Wakeup Channels.

### **Return Value**

Successful

### **Example**

```
sysPowerDown(WE_GPIO);
```

## **26.5 ERROR CODE TABLE**

Code Name	Value	Description
Successful	0	Successful
Fail	1	Fail
WB_INVALID_PARITY	0xFFFF0A01	Invalid parity
WB_INVALID_DATA_BITS	0xFFFF0A02	Invalid data bits
WB_INVALID_STOP_BITS	0xFFFF0A03	Invalid stop bits
WB_INVALID_BAUD	0xFFFF0A04	Invalid baud rate
WB_PM_PD_IRQ_Fail	0xFFFF0A05	Invalid power down IRQ
WB_PM_Type_Fail	0xFFFF0A06	Invalid power manager type
WB_PM_INVALID_IRQ_NUM	0xFFFF0A07	Invalid IRQ number
WB_MEM_INVALID_MEM_SIZE	0xFFFF0A08	Invalid memory size
WB_INVALID_TIME	0xFFFF0A09	Wrong or invalid time setting
WB_INVALID_CLOCK	0xFFFF0A0A	Wrong or invalid clock setting



## 27 TOUCH ADC LIBRARY

### 27.1 OVERVIEW

The N9H26 Touch ADC library provides a set of APIs to report the X and Y-axis coordinate, battery voltage and analog keypad. With these APIs, user can read the position that was touched in touch panel, get current battery voltage and get keypad scan-code. If user want to scan ADC keypad, please use channel 2 to utilize key down detection circuit.

These libraries are created by using Keil uVision IDE. Therefore, they only can be used in Keil environment.

### 27.2 TOUCH ADC LIBRARY APIS SPECIFICATION

#### ***DrvADC\_Open***

##### **Synopsis**

INT32 DrvADC\_Open (void);

##### **Description**

This function is used to open the Touch ADC library.

##### **Parameter**

None

##### **Return Value**

Successful

##### **Example**

```
/* Initialize Touch ADC library and enable IP clock*/  
DrvADC_Open();
```

#### ***DrvADC\_Close***

##### **Synopsis**

INT32 DrvADC\_Close(void)

##### **Description**

Close the ADC library.

##### **Parameter**

None

##### **Return Value**

Successful

### Example

```
/* Close Touch ADC library*/  
DrvADC_Close();
```

## DrvADC\_InstallCallback

### Synopsis

```
INT32 DrvADC_InstallCallback(E_ADC_INT_TYPE eIntType,  
  
                             PFN_ADC_CALLBACK pfnCallback,  
  
                             PFN_ADC_CALLBACK* pfnOldCallback);
```

### Description

This function is used to install callback function that is used to notice the upper layer for event complete.

### Parameter

eIntType   Interrupt event type.

pfnCallback       The callback function that is registered to the library to handle event.

pfnOldCallback    Old callback function

Table 27-1: ADC read mode

Field name	Value	Description
eADC_KEY	0	(Unused in the driver)
eADC_TOUCH	1	(Unused in the driver)
eADC_AIN	2	Normal ADC conversion event done type.
eADC_POSITION	3	Converse position event done type
eADC_PRESSURE	4	Conversion pressure event done type

### Return Value

-1 or Successful.

### Example

```
/* Read the x and y-axis coordinate */  
static void Pressure_callback(UINT32 u32code)  
{/* The u32code[14:0] is parameterZ2. u32code[15] is Valid(1) or Invalid(0).  
The u32code[30:16] is Z1 position. u32code[31] is Valid(1) or Invalid(0) */  
  
...
```



```

}
static void Position_callback(UINT32 u32code)
{
    /* The u32code[14:0] is Y position. u32code[15] is Valid(1) or Invalid(0).
    The u32code[30:16] is X position. u32code[31] is Valid(1) or Invalid(0).*/

    ...
}
DrvADC_Open();
DrvADC_InstallCallback(eADC_POSITION,
                      Position_callback,
                      &pfnOldCallback);
DrvADC_InstallCallback(eADC_PRESSURE,
                      Pressure_callback,
                      &pfnOldCallback);

```

### **INT32 IsPenDown(VOID)**

#### **Description**

This function is used to check if the pen down or pen up for touch panel.

#### **Parameter**

None

#### **Return Value**

Error code

Name	Value	Description
E_ADC_BUSY	0xB800F001	Touch ADC is busy
TRUE	1	Pen is down state
FALSE	0	Pen is up state

#### **Example**

```

if(IsPenDown()==TRUE)
{
    if(adc_read(0, &x, &y)==1)
        sysprintf("(x, y)= (0x%x, 0x%x)\n", x, y);
    else
        sysprintf("Invalid data\n");
}

```

```
}
```

### ***INT32 adc\_read(UINT8 mode, UINT16 \*x, UINT16 \*y)***

#### **Description**

This function is used to read touch position with software filter.

#### **Parameter**

mode      Unused and reserved.

x    X – axis position.

y    Y – axis position.

#### **Return Value**

Error code

Name	Value	Description
E_ADC_BUSY	0xB800F001	Touch ADC is busy
TRUE	1	Reported position is valid
FALSE	0	Reported position is invalid

#### **Example**

```
if(IsPenDown()==TRUE)
{
    if(adc_read(0, &x, &y)==1)
        sysprintf("(x, y)= (0x%x, 0x%x)\n", x, y);
    else
        DBG_PRINTF("Invalid position\n");
}
```

### ***DrvADC\_PenDetection***

#### **Synopsis**

INT32 DrvADC\_PenDetection(BOOL bls5Wire)

#### **Description**

This function was used to read the touching position and pressure without software filter.

#### **Parameter**

bls5Wire    5 wires or 4 wires touch panel.

1: 5 wires touch panel

0: 4 wires touch panel

### Return Value

Error code

Name	Value	Description
E_ADC_BUSY	0xB800F001	Touch ADC is busy
E_TOUCH_UP	1	Pen state is up. (No touching event)
Successful	0	Pen state is down. Touch ADC is triggering.

### Example

```
/* Touch Callback function to report position */
static void Position_callback(UINT32 u32code)
{
    u16X = (u32code>>16)&0x7FFF;
    u16Y = u32code & 0x7FFF;
    if((u32code&(BIT31 | BIT15)) == (BIT31 | BIT15))
        sysprintf("(X, Y) = %d x %d\n", u16X, u16Y);
    else
        sysprintf("Position is invalid 0x%x\n", u32code);
}

.....
DrvADC_Open();
DrvADC_InstallCallback(eADC_POSITION, Position_callback, &pfnOldCallback);
DrvADC_InstallCallback(eADC_PRESSURE, Pressure_callback, &pfnOldCallback);
btime = sysGetTicks(TIMERO);
etime = btime;
while ((etime - btime) <= 300)
{
    while(TouchPanel_time==TRUE)
    {
        TouchPanel_time = FALSE;
        do{
            ret = DrvADC_PenDetection(bIs5Wire);
        }while(ret != Successful);
    }
}
```

```

    }
    etime = sysGetTicks(TIMER0);
}
sysClearTimerEvent(TIMER0, tmp);

```

## ***DrvADC\_KeyDetection***

### **Synopsis**

INT32 DrvADC\_KeyDetection(UINT32 u32Channel, UINT32\* pu32KeyCode)

### **Description**

This function is used to read the Scan-code of keypad.

### **Parameter**

u32Channel            Channel number. The value from 1 to 3.  
 pu32KeyCode        Reported Scan-code if keypad state is down.

### **Return Value**

Error code

Name	Value	Description
E_ADC_BUSY	0xB800F001	Touch ADC is busy
E_KEYPAD_UP	1	keypad state is up.
Successful	0	keypad state is down.

### **Example**

```

DrvADC_Open();
btime = sysGetTicks(TIMER0);
etime = btime;
while ((etime - btime) <= 300){
    if(DrvADC_KeyDetection(u32Channel, &u32KeyCode)==Successful)
{    // ready
        if(u32KeyCode!=0)
            sysprintf("Key Scan code = 0x%x\n", u32KeyCode);
    }
else
{
        if(u32KeyCode!=0)

```

```

        sysprintf("Key Scan code = 0x%x\n", u32KeyCode);
    }
    etime = sysGetTicks(TIMER0);
}
sysClearTimerEvent(TIMER0, tmp);

```

## ***DrvADC\_VoltageDetection***

### **Synopsis**

INT32 DrvADC\_VoltageDetection (UINT32 u32Channel)

### **Description**

This function is used to read the conversion value.

### **Parameter**

u32Channel          Channel number. The value from 1 to 3.

### **Return Value**

Error code

Name	Value	Description
E_ADC_BUSY	0xB800F001	Touch ADC is busy
Successful	0	Touch ADC is triggering.

### **Example**

```

static void VoltageDetect_callback(UINT32 u32code)
{
    /* u32code is the ADC value */
    blsValidVoltageDet = TRUE;
    u32VoltageValue = u32code;
    u32Count = u32Count+1;
    if(u32code==0){
        sysprintf("Voltage Detect Value %d = %d\n", u32Count, u32code);
    }
    sysprintf("Voltage Detect Value %d = %d\n", u32Count, u32code);
}

DrvADC_Open();
DrvADC_InstallCallback(eADC_AIN, VoltageDetect_callback, &pfnOldCallback);
btime = sysGetTicks(TIMER0);

```

```

etime = btime;
while ((etime - btime) <= 1000)
{
    while(VoltageDetect_time==TRUE){
        VoltageDetect_time = FALSE;
        if(DrvADC_VoltageDetection(u32Channel)==Successful){//ready
            if(bIsValidVoltageDet==TRUE){ //Key code has been updated
                bIsValidVoltageDet = FALSE;
            }
        }
    }
    etime = sysGetTicks(TIMER0);
}
sysClearTimerEvent(TIMER0, tmp);

```

### 27.3 ERROR CODE TABLE

Code Name	Value	Description
E_ADC_BUSY	0xB800F000	Touch ADC is busy
E_TOUCH_UP	1	Pen state is up
E_KEYPAD_UP	1	Keypad state is up
Successful	0	No error

## 28 UDC LIBRARY

### 28.1 OVERVIEW

This library is designed to make user application to use N9H26 UDC more easily.

The UDC library has the following features:

- Support all Basic USB operations.
- Pass USB-IF Chapter 9.

BSP Non-OS provide two usb class libraries for the USB class reference sample. User can refer to the libraries to develop him own class libraries. Mass Storage Class device: mscd library.

- Pass the USB-IF Mass Storage Class Test
- Provide flash options to build MSC device as a Composite device with RAM disk, NAND Disk, and SD Card Reader.
- Pass the USB-IF Video Class Test
- Provide a video cam sample to send two test patterns to PC.

User can use UDC library to implement all USB basic operations (Send descriptors, Reset command and etc.), and a USB class library (like MSCD) to provide USB class functions.

MSC Device	VCOM Device	Other Devices
MSC Library	VCOM Library	Other Libraries
UDC Library		

### 28.2 PROGRAMMING GUIDE

#### System Overview

The USB device controller interfaces the AHB bus and the UTMI bus. The USB controller contains both the AHB master interface and AHB slave interface. CPU programs the USB controller registers through the AHB slave interface. For IN or OUT transfer, the USB device controller needs to write data to memory or read data from memory through the AHB master interface. The USB device controller is complaint with USB 2.0 specification and it contains four configurable endpoints in addition to control endpoint. These endpoints could be configured to BULK, INTERRUPT or ISO. The USB device controller has a built-in DMA to relieve the load of CPU.

#### Features

- USB Specification version 2.0 compliant.
- Interfaces between USB 2.0 bus and the AHB bus.
- Supports 16-bit UTMI Interface to USB2.0 Transceiver.
- Support direct register addressing for all registers from the AHB bus.

- Software control for device remote-wakeup.
- AHB bus facilitates connection to common micro controllers and DMA controllers.
- Supports 4 configurable endpoints in addition to Control Endpoint
- Each of these endpoints can be Isochronous, Bulk or Interrupt and they can be either of IN or OUT direction.
- Three different modes of operation of an in-endpoint (Auto validation mode, manual validation mode, Fly mode.)
- DP RAM is used as end point buffer.
- DMA operation is carried out by AHB master
- Supports Endpoint Maximum Packet Size up to 1024 bytes.

## UDC Library Property Definition

The UDC library provides property structure to set UDC property more easily.

USBD\_INFO\_T (The fields for internal used are not in the table)

Name	Description
Descriptor pointer	
pu32DevDescriptor	Device Descriptor pointer
pu32QulDescriptor	Device Qualifier Descriptor pointer
pu32HSConfDescriptor	Standard Configuration Descriptor pointer for High speed
pu32FSConfDescriptor	Standard Configuration Descriptor pointer for Full speed
pu32HOSConfDescriptor	Other Speed Configuration Descriptor pointer for High speed
pu32FOSConfDescriptor	Other Speed Configuration Descriptor pointer for Full speed
pu32HIDDescriptor	HID Device Descriptor pointer
pu32HIDRPTDescriptor	HID Device Report Descriptor pointer
pu32StringDescriptor[5]	String Descriptor pointer
Descriptor length	
u32DevDescriptorLen	Device Descriptor Length
u32QulDescriptorLen	Device Qualifier Descriptor pointer Length
u32HSConfDescriptorLen	Standard Configuration Descriptor Length for High speed
u32FSConfDescriptorLen	Standard Configuration Descriptor Length for Full speed
u32HOSConfDescriptorLen	Other Speed Configuration Descriptor Length for High speed
u32FOSConfDescriptorLen	Other Speed Configuration Descriptor Length for Full speed
u32HIDDescriptorLen	HID Device Descriptor Length
u32HIDRPTDescriptorLen	HID Device Report Descriptor Length
u32StringDescriptorLen[5]	String Descriptor Length
USBD Init	
pfHnHighSpeedInit	High speed USB Device Initialization function



pfnFullSpeedInit	Full speed USB Device Initialization function
Endpoint Number	
i32EPA_Num	Endpoint Number for EPA
i32EPB_Num	Endpoint Number for EPB
i32EPC_Num	Endpoint Number for EPC
i32EPD_Num	Endpoint Number for EPD
Endpoint Call Back	
pfnEPACallBack	Callback function pointer for Endpoint A Interrupt
pfnEPBCallBack	Callback function pointer for Endpoint B Interrupt
pfnEPCCallBack	Callback function pointer for Endpoint C Interrupt
pfnEPDCallBack	Callback function pointer for Endpoint D Interrupt
Class Call Back	
pfnClassDataINCallBack	Callback function pointer for Class Data IN
pfnClassDataOUTCallBack	Callback function pointer for Class Data OUT
pfnDMACompletion	Callback function pointer for DMA Complete
pfnReset	Callback function pointer for USB Reset Interrupt
pfnSOF	Callback function pointer for USB SOF Interrupt
pfnPlug	Callback function pointer for USB Plug Interrupt
pfnUnplug	Callback function pointer for USB Un-Plug Interrupt
VBus status	
u32VbusStatus	VBus Status


The USB Device initial function initializes the basic setting of USB device controller including endpoints buffer allocate, endpoint number, endpoint type, speed mode, and interrupt, etc. User can modify the function to change USB speed and endpoint properties.

- pfnHighSpeedInit
  - mscdHighSpeedInit
- pfnFullSpeedInit
  - mscdFullSpeedInit

PC classifies USB device according to the descriptors. With Non-OS BSP structure, the descriptors are initialized in the class Init functions. The functions set proper descriptors and the callback functions.

- mscdInit

### ***Programming Flow***



## 28.3 USB DEVICE (UDC) API

### ***udcOpen***

#### **Synopsis**

VOID udcOpen(VOID)

#### **Description**

This function enables the engine clock.

**Parameter**

None

**Return Value**

None

**Example**

```
udcOpen ();
```

***udcClose*****Synopsis**

VOID udcClose (VOID)

**Description**

This function disables the engine clock.

**Parameter**

None

**Return Value**

None

**Example**

```
udcClose ();
```

***udcInit*****Synopsis**

VOID udcInit(VOID)

**Description**

This function initializes the software resource, enables its interrupt, and set VBus detect function.

**Parameter**

None

**Return Value**

None

**Example**

```
udcInit ();
```

### ***udcDeinit***

#### **Synopsis**

VOID udcDeinit (VOID)

#### **Description**

Disable VBus detect function

#### **Parameter**

None

#### **Return Value**

None

#### **Example**

```
udcDeinit ();
```

### ***udclsAttached***

#### **Synopsis**

BOOL udclsAttached(VOID)

#### **Description**

This function can get USB attach status.

#### **Parameter**

None

#### **Return Value**

TRUE                   - USB is attached.  
FALSE                  - USB isn't attached.

#### **Example**

```
/* Check USB attach status */  
if(udclsAttached ())  
    sysprintf("USB is attached\n");  
else  
    sysprintf("USB isn't attached\n");
```

### ***udclsAttachedToHost***

#### **Synopsis**

BOOL udclsAttachedToHost (VOID)

**Description**

This function can get USB current attach device status.

**Parameter**

None

**Return Value**

TRUE                   - USB is attached to Host now.  
FALSE                  - USB doesn't get any command from Host now.

**Example**

```
/* Check USB HOST attach status */  
if(udclsAttachedToHost ())  
    sysprintf("USB is attached to Host now\n");  
else  
    sysprintf("USB doesn't get any command from Host \n");
```

**Note**

It takes time for Host to send command to device. So user may set a timeout time to check the status, i.e., user needs to polling the status during the timeout time.

***udcSetSuspendCallBack*****Synopsis**

VOID udcSetSuspendCallBack (PFN\_USBD\_CALLBACK pfun)

**Description**

This function is to install the Suspend call back function

**Parameter**

pfun                   The Suspend Call back function pointer

**Return Value**

None

**Example**

```
udcSetSuspendCallBack(Demo_PowerDownWakeUp);
```

## 28.4 MASS STORAGE CLASS (MSCD) API

## ***mscdInit***

### **Synopsis**

VOID mscdInit(VOID)

### **Description**

This function initializes software source (descriptors, callback functions, buffer configuration)

### **Parameter**

None

### **Return Value**

None

### **Example**

```
mscdInit ();
```

## ***mscdDeinit***

### **Synopsis**

VOID mscdDeinit (VOID)

### **Description**

This function release software source (allocated by mscdInit)

### **Parameter**

None

### **Return Value**

None

### **Example**

```
mscdDeinit ();
```

## ***mscdFlashInit***

### **Synopsis**

UINT8 mscdFlashInit (NDISK\_T \*pDisk, INT SDsector);

### **Description**

Initial the Flash capacity for usb device controller use.(One chip selector NAND flash and one port SD)

### **Parameter**

pDisk                      The internal data for NAND disk information.  
SDsector    Total sector for SD disk.

#### Return Value

0                            - Fail  
1                            - Success

#### Example

```
NDISK_T MassNDisk;
INT SDsector;
SDsector = sicSdOpen0();
mscdFlashInit(&MassNDisk, SDsector);
```

#### Note

- ◆ User can assign the export NAND flash (CS0/CS1/CS2) by mscdNandEnable.(Default is CS0 if user doesn't use mscdNandEnable)
- ◆ User can assign the export SD card (Port0/Port1/Port2) by **mscdSdEnable**. (Default is Port0 if user doesn't use mscdSdEnable)
- ◆ The API can only single port SD and single CS NAND by mscdSdEnable or mscdNandEnable.
- ◆ If user wants to export only SD, please link N9H26\_MSC\_SD.a
- ◆ If user wants to export only NAND, please link N9H26\_MSC\_NAND.a
- ◆ If user wants to export both SD and NAND, please link N9H26\_MSC\_NAND\_SD.a

### ***mscdFlashInitNAND***

#### Synopsis

```
UINT8
mscdFlashInitNAND (
    NDISK_T *pDisk,
    NDISK_T *pDisk1,
    NDISK_T *pDisk2,
    INT SDsector
);
```

#### Description

Initial the Flash capacity for usb device controller use (three chip selector NAND flash and one port SD).

#### Parameter

pDisk                      The internal data for NAND disk information for CS0.

pDisk1                    The internal data for NAND disk information for CS1.  
pDisk2                    The internal data for NAND disk information for CS2.  
SDsector    Total sector for SD disk.

#### Return Value

0                         - Fail  
1                         - Success

#### Example

```
NDISK_T MassNDisk, MassNDisk1, MassNDisk2;
INT SDsector;
SDsector = sicSdOpen0();
mscdFlashInitNAND (&MassNDisk, &MassNDisk1, &MassNDisk2, SDsector);
```

#### Note

1. User can assign the export NAND flash (CS0/CS1/CS2) by mscdNandEnable.(Default is CS0 if user doesn't use mscdNandEnable)
2. User can assign the export SD card (Port0/Port1/Port2) by mscdSdEnable. (Default is Port0 if user doesn't use mscdSdEnable)
3. The API can only single port SD by mscdSdEnable.
4. If user wants to export only SD, please link N9H26\_MSC\_SD.a
5. If user wants to export only NAND, please link N9H26\_MSC\_NAND.a
6. If user wants to export both SD and NAND, please link N9H26\_MSC\_NAND\_SD.a

### ***mscdFlashInitExtend***

#### Synopsis

```
UINT8
mscdFlashInitExtend (
    NDISK_T *pDisk,
    NDISK_T *pDisk1,
    NDISK_T *pDisk2,
    INT SDsector0,
    INT SDsector1,
    INT SDsector2,
    INT RamSize
);
```

#### Description



Initial the Flash capacity for usb device controller use (three chip selector NAND flash and three ports SD).

#### Parameter

pDisk                      The internal data for NAND disk information for CS0.  
pDisk1                    The internal data for NAND disk information for CS1.  
pDisk2                    The internal data for NAND disk information for CS2.  
SDsector0 Total sector for SD0 disk.  
SDsector1 Total sector for SD1 disk.  
SDsector2 Total sector for SD2 disk.  
RamSize MSC\_RAMDISK\_1M~ MSC\_RAMDISK\_64M

#### Return Value

0                          - Fail  
1                          - Success

#### Example

```
NDISK_T MassNDisk, MassNDisk1, MassNDisk2;  
INT SDsector;  
SDsector = sicSdOpen0();  
mscdFlashInitNAND (&MassNDisk, &MassNDisk1, &MassNDisk2, SDsector);
```

#### Note

1. User can assign the export NAND flash (CS0/CS1/CS2) by mscdNandEnable.(Default is CS0 if user doesn't use mscdNandEnable)
2. User can assign the export SD card (Port0/Port1/Port2) by mscdSdEnable. (Default is Port0 if user doesn't use mscdSdEnable)
3. If user wants to export only SD, please link N9H26\_MSC\_ SD.a
4. If user wants to export only NAND, please link N9H26\_MSC\_ NAND.a
5. If user wants to export both SD and NAND, please link N9H26\_MSC\_NAND\_SD.a
6. If user wants to export only all flash, please link N9H26\_MSC\_All.a

### ***mscdFlashInitCDROM***

#### Synopsis

```
UINT8 mscdFlashInitCDROM (  
    NDISK_T *pDisk,  
    INT SDsector,  
    PFN_MSCD_CDROM_CALLBACK pfnCallBack,  
    INT CdromSizeInByte
```

)

### Description

Initialize the Flash capacity for usb device controller use.

### Parameter

pDisk	The internal data for NAND disk information.
SDsector	The total sector number of SD card
pfnCallBack	The callback function for CDROM read function
CdromSizeInByte	The size of CDROM size

### Return Value

0	- Fail
1	- Success

### Example

```
NDISK_T MassNDisk;  
mscdFlashInitCDROM(&MassNDisk,NULL,CDROM_Read,u32CdromSize);
```

### Note

1. User can modify the mscd.c and rebuild library to select the flash types you want
  - TEST\_RAM: Ram Disk
    - Change RAM\_DISK\_SIZE to change RAM Disk size
      - ◆ RAMDISK\_1M / RAMDISK\_2M / RAMDISK\_4M / RAMDISK\_8M /  
RAMDISK\_16M / RAMDISK\_32M
  - TEST\_SM: NAND Disk
  - TEST\_SD: SD Card Reader
2. The pDisk is used only when TEST\_SM is defined.

## ***mscdFlashInitExtendCDROM***

### Synopsis

```
UINT8  
mscdFlashInitExtendCDROM (  
    NDISK_T *pDisk,  
    NDISK_T *pDisk1,  
    NDISK_T *pDisk2,  
    INT SDsector0,  
    INT SDsector1,  
    INT SDsector2,  
    INT RamSize
```

```

        PFN_MSCD_CDROM_CALLBACK pfnCallBack,
        INT CdromSizeInByte
    );

```

### Description

Initial the Flash capacity for usb device controller use (three chip selector NAND flash and three ports SD).

### Parameter

pDisk	The internal data for NAND disk information for CS0.
pDisk1	The internal data for NAND disk information for CS1.
pDisk2	The internal data for NAND disk information for CS2.
SDsector0	Total sector for SD0 disk.
SDsector1	Total sector for SD1 disk.
SDsector2	Total sector for SD2 disk.
RamSize	MSC_RAMDISK_1M~ MSC_RAMDISK_64M
pfnCallBack	The callback function for CDROM read function
CdromSizeInByte	The size of CDROM size

### Return Value

0	- Fail
1	- Success

### Example

```

NDISK_T MassNDisk, MassNDisk1, MassNDisk2;
INT SDsector;
SDsector = sicSdOpen0();
mscdFlashInitNAND (&MassNDisk, &MassNDisk1, &MassNDisk2, SDsector);

```

### Note

7. User can assign the export NAND flash (CS0/CS1/CS2) by mscdNandEnable.(Default is CS0 if user doesn't use mscdNandEnable)
8. User can assign the export SD card (Port0/Port1/Port2) by mscdSdEnable. (Default is Port0 if user doesn't use mscdSdEnable)
9. If user wants to export only SD, please link N9H26\_MSC\_ SD.a
10. If user wants to export only NAND, please link N9H26\_MSC\_ NAND.a
11. If user wants to export both SD and NAND, please link N9H26\_MSC\_NAND\_SD.a
12. If user wants to export only all flash, please link N9H26\_MSC\_All.a

### ***mscdSdEnable***

**Synopsis**

VOID msCdSdEnable (UINT32 u32Enable)

**Description**

This function enables the SD port for MSC.

**Parameter**

u32EnableMSC\_SD\_MP\_PORT0~ MSC\_SD\_MP\_PORT2  
MSC\_SD\_PORT0~ MSC\_SD\_PORT2

**Return Value**

None

**Example**

```
/* Export two SD ports (Multiple partition) */  
msCdSdEnable (MSC_SD_MP_PORT0| MSC_SD_MP_PORT1);  
/* Export one SD port (Single partition) */  
msCdSdEnable (MSC_SD_ PORT0);
```

***msCdNandEnable*****Synopsis**

VOID msCdNandEnable (UINT32 u32Enable)

**Description**

This function enables the NAND CS for MSC.

**Parameter**

u32EnableMSC\_NAND\_CS0~ MSC\_NAND \_CS2

**Return Value**

None

**Example**

```
/* Export two NAND CS */  
msCdSdEnable (MSC_NAND_CS0| MSC_NAND_CS2);  
/* Export one NAND CS */  
msCdSdEnable (MSC_NAND_CS0);
```

***msCdSdUserWriteProtectPin*****Synopsis**

```

VOID mscdSdUserWriteProtectPin (
    UINT32 u32SdPort,
    BOOL bEnable,
    UINT32 u32GpioPort,
    UINT32 u32GpioPin
)

```

#### Description

This function enables/disables the SD write protect function and SD write protect pin for MSC.

#### Parameter

u32SdPort	MSC_SD_PORT0~ MSC_SD_PORT2
bEnable	Enable or Disable Write Protection function (TRUE/FALSE)
u32GpioPort	MSC_SD_GPIO_PORTA~ MSC_SD_GPIO_PORTG, MSC_SD_GPIO_PORTH
u32GpioPin	GPIO pin number : 0~15

#### Return Value

None

#### Example

```

/* Set GPIOA Pin 2 for SD port0 Write Protect Pin */
mscdSdUserWriteProtectPin (MSC_SD_PORT0, TRUE, MSC_SD_GPIO_PORTA, 2);

/* Disable SD Port 0 Write Protect Pin function*/
mscdSdUserWriteProtectPin (MSC_SD_PORT0, FALSE, 0, 0);

```

#### Note

Only SD Port0 has default Write Protection pin and Write Protection function is default enable and use the default pin (GPA0).

### ***mscdSdUserCardDetectPin***

#### Synopsis

```

VOID mscdSdUserCardDetectPin (
    UINT32 u32SdPort,
    BOOL bEnable,
    UINT32 u32GpioPort,
    UINT32 u32GpioPin
)

```

**Description**

This function enables/disables the SD card detection function for MSC.

**Parameter**

u32SdPortMSC\_SD\_PORT0~ MSC\_SD\_PORT2  
 bEnable                    Enable or Disable card detection (TRUE/FALSE)  
 u32GpioPort                MSC\_SD\_GPIO\_PORTA~ MSC\_SD\_GPIO\_PORTG, MSC\_SD\_GPIO\_PORTH  
 u32GpioPin                GPIO pin number : 0~15

**Return Value**

None

**Example**

```
/* Set GPIOA Pin 2 for SD port0 Card detect Pin */
mscdSdUserCardDetectPin (MSC_SD_PORT0, TRUE, MSC_SD_GPIO_PORTA, 2);

/* Disable SD Port 0 Card detect function*/
mscdSdUserCardDetectPin (MSC_SD_PORT0, FALSE, 0, 0);
```

**Note**

1. Only SD Port0/2 has default Card detect pin and Card detect function is default enable and use the default pin (GPA1 for Port 0 and GPE11 for Port2).
2. If user disable the Card detect function, MSC will consider that the SD card is always exist.

***mscdMassEvent*****Synopsis**

VOID mscdMassEvent (PFN\_USBD\_EXIT\_CALLBACK\* callback\_fun)

**Description**

This function processes all the mass storage class commands such as read, write, inquiry, etc. The function has loop in it and it exits the loop according to the return value of the callback function.

**Parameter**

callback\_fun                The callback function for the Mass Event Exit condition. If it returns FALSE, the mass event service is disabled.

**Return Value**

None

**Example**

```
mscdMassEvent(udclsAttached);
```

**Note**

The API must be called when all APIs about MSC is completed.

***mscdBlcokModeEnable***

**Synopsis**

VOID mscdBlcokModeEnable (BOOL bEnable)

**Description**

This function can set MSC to Block mode or Non-Block mode.

**Parameter**

bEnable            TRUE / FALSE

**Return Value**

None

**Example**

```
#ifndef NON_BLOCK_MODE
    mscdBlcokModeEnable(FALSE);    /* Non-Block mode */
    while(1)
    {
        if(!PlugDetection())
            break;
        mscdMassEvent(NULL);
    }
#else
    mscdMassEvent(PlugDetection); /* Default : Block mode */
#endif
```

## 28.5 EXAMPLE CODE

This demo code has sample code for MSC (Mass Storage Class), VCOM, and HID.

Please refer to the mass storage device sample code of BSP Non-OS.

## 29 USB CORE LIBRARY

### 29.1 USB CORE LIBRARY OVERVIEW

The USB Core library is composed of four major parts, which are OHCI driver, EHCI driver, USB driver, and USB hub device driver. Each of these four drivers also represents one of the three-layered USB driver layers. Figure 1-1 presents the driver layers of the USB library.




Figure 29.1-1 USB driver layer of USB library

### 29.2 DATA STRUCTURES

The USB Core library has included many complicated data structures to describe a USB bus, a device, a driver, various descriptors, and so on. To realize these data structures may be necessary for a USB device driver designer. In the following sections, we will introduce all data structures you may need. These data structures are all defined in header file `<usb.h>`.

#### USB\_DEV\_T

**USB\_DEV\_T** is the data structure used to represent a device instance. Once the host finds that a device presented on a USB bus, the USB system software is notified. The USB system software resets and enables the hub port to reset the device. It then creates a **USB\_DEV\_T** for the newly detected device. For each USB device presented on the bus, even the same device type, USB system software will create a **USB\_DEV\_T** to



represent it as an instance.

The contents of all members of **USB\_DEV\_T** are automatically assigned by USB system software. The USB system software will assign a unique device number, read device descriptor and configuration descriptors, and create parent/child relationships. The definition of USB\_DEV\_T is listed below, and the detailed descriptions can be found in [Table 29-1: Members of USB\\_DEV\\_T](#)

```
typedef struct usb_device
{
    INT      devnum;
    INT      slow;
    enum
    {
        USB_SPEED_UNKNOWN = ,
        USB_SPEED_LOW,
        USB_SPEED_FULL,
        USB_SPEED_HIGH
    } speed;
    struct usb_tt  *tt;
    INT      ttport;
    INT      refcnt;
    UINT32    toggle[2];
    UINT32    halted[2];
    INT      epmaxpacketin[16];
    INT      epmaxpacketout[16];
    struct usb_device  *parent;
    INT      hub_port;
    USB_BUS_T *bus;
    USB_DEV_DESC_T  descriptor;
    USB_CONFIG_DESC_T *config;
    USB_CONFIG_DESC_T *actconfig;
    CHAR      **rawdescriptors;
    INT      have_langid;
    INT      string_langid;
    VOID      *hcpriv;
```

```

    INT      maxchild;

    struct usb_device  *children[USB_MAXCHILDREN];
} USB_DEV_T;

```

Table 29-1: Members of USB\_DEV\_T

Member	Description
devnum	Device number on USB bus; each device instance has a unique device number
slow	Is low speed device speed ? (1: yes; 0: no)
speed	Device speed
refcnt	Reference count (to count the number of users using the device)
toggle[2]	Data toggle; one bit for each endpoint ( [0] = IN, [1] = OUT )
halted[2]	Endpoint halts; one bit for each endpoint ( [0] = IN, [1] = OUT )
epmaxpacketin[16]	IN endpoints specific maximum packet size (each entry represents for an IN endpoint of this device)
epmaxpacketout[16]	OUT endpoints specific maximum packet size (each entry represents for an OUT endpoint of this device)
parent	Parent device in the bus topology (generally, it should be a hub)
bus	The bus on which this device was presented
descriptor	Device descriptor
config	All of the configuration descriptors
actconfig	The descriptor of the active configuration
rawdescriptors	Raw descriptors for each configuration descriptor (driver can find class specific or vendor specific descriptors from the <i>raw descriptors</i> )
have_langid	Whether string_langid is valid yet
string_langid	Language ID for strings
hcpriv	Host controller private data
maxchild	Number of ports if this is a hub device
children[ ]	Link to the downstream port device if this is a hub device

## Descriptor Structures

In the USB\_DEV\_T structure, device descriptor, configuration descriptors, and raw descriptor are included. The USB Driver will acquire these descriptors from device automatically while the device is probed. The USB Driver issues GET\_DESCRIPTOR standard device request to acquire the configuration descriptors. It also parses the returned descriptors to create configuration-interface-endpoint descriptor links. Client software can obtain any configuration, interface, or endpoint descriptors by tracing the descriptor link started from USB\_DEV\_T. As USB Driver cannot understand class-specific and vendor-specific descriptors, it does not create link for these descriptors. If the client software wants to obtain any class-specific or vendor-specific descriptors, it can parse the descriptors stored in raw descriptor, which is the original descriptors list returned from the device. Table2-2, Table 2-3, Table 2-4, and Table 2-5 describe the structures defined for device descriptors, configuration descriptors, interface descriptors, and endpoint descriptors, respectively.

Figure 2-1 presents an overview on the relationship of these data structures. From USB\_DEV\_T (device instance structure), USB\_DEV\_DESC\_T (device descriptor structure) and USB\_CONFIG\_DESC\_T (configuration descriptor structure), USB\_IF\_DESC\_T (interface descriptor structure), to USB\_EP\_DESC\_T (endpoint descriptor structure), all structure entries are linked in top-down order.




Figure 29.2-1:Descriptors relationship

```

/* Device descriptor */
typedef struct usb_device_descriptor
{
    __packed UINT8  bLength;
    __packed UINT8  bDescriptorType;
    __packed UINT16 bcdUSB;
    __packed UINT8  bDeviceClass;
    __packed UINT8  bDeviceSubClass;
    __packed UINT8  bDeviceProtocol;
    __packed UINT8  bMaxPacketSize0;
}
  
```

```

__packed UINT16 idVendor;
__packed UINT16 idProduct;
__packed UINT16 bcdDevice;
__packed UINT8  iManufacturer;
__packed UINT8  iProduct;
__packed UINT8  iSerialNumber;
__packed UINT8  bNumConfigurations;
} USB_DEV_DESC_T;

```

Table 29-2: Members of USB\_DEV\_DESC\_T

Member	Description
bLength	Size of the descriptor in bytes
bDescriptorType	DEVICE descriptor type (0x01)
bcdUSB	USB specification release number in BCD format
bDeviceClass	Device class code
bDeviceSubclass	Device subclass code
bDeviceProtocol	Protocol code
bMaxPacketSize0	Maximum packet size for endpoint zero
idVendor	Vendor ID
idProduct	Product ID
iManufacturer	Device release number in BCD format
iProduct	Index of string descriptor describing product
iSerialNumber	Index of string descriptor describing the serial number
bNumConfigurations	Number of possible configurations

You may have found that the definition of **USB\_DEV\_DESC\_T** is fully compliant to the definition of device descriptor defined in USB 1.1 specification. In fact, the USB Driver acquires the device descriptor and fills it into this structure without making any modifications.

```

/* Configuration descriptor information.. */
typedef struct usb_config_descriptor
{
    __packed UINT8  bLength;
    __packed UINT8  bDescriptorType;
    __packed UINT16 wTotalLength;

```

```

__packed UINT8    bNumInterfaces;
__packed UINT8    bConfigurationValue;
__packed UINT8    iConfiguration;
__packed UINT8    bmAttributes;
__packed UINT8    MaxPower;
USB_IF_T  *interface;
UINT8      *extra;
INT         extralen;
} USB_CONFIG_DESC_T;

```

Table 29-3: Members of USB\_CONFIG\_DESC\_T

Member	Description
bLength	Size of the descriptor in bytes
bDescriptorType	CONFIGURATION descriptor type (0x02)
wTotalLength	The total length of data returned for this descriptor
bNumInterfaces	Number of interface supported by this configuration
bConfigurationValue	Value to use as an argument to the SetConfiguration() request to select the active configuration
iConfiguration	Index of string descriptor describing this configuration
bmAttributes	Bitmap describing the configuration characteristics
MaxPower	Maximum power consumption of the USB device from the bus in this specific configuration when the device is fully operational (in mA)
interface	Refer to the interface descriptor list (recorded in USB_IF_DESC_T structure format) returned by this configuration
extra	Refer to the memory buffer preserve the raw data of this configuration descriptor itself
extralen	The length of the <extra> memory buffer

The **dev->config** refers to a list of configurations supported by this device. Client software can access any configuration by indexing the configuration, for example, dev->config[0] is referred to the first configuration of this device. While <**config**> of **USB\_DEV\_T** refers to the configuration list, <**actconfig**> refers to the currently activated configuration. There can be only one configuration activated at the same time.

The structure members from <**bLength**> to <**MaxPower**> are fully compliant to that defined in USB 1.1 specification. The <**interface**> refers to a list of interfaces supported by this configuration. In addition, USB Driver keeps the interface descriptor itself in a dynamically allocated memory buffer, which is referred to by <**extra**>, and the length of this memory buffer is <**extralen**>.

An interface may contain several alternate settings. Each alternate setting has its own set of endpoints. USB Driver creates a single **USB\_IF\_DESC\_T** structure for each alternate interface setting and links them in the order that they presented in the returned data of a configuration descriptor.

```

/* Interface descriptor */

```

```

typedef struct usb_interface_descriptor
{
    __packed UINT8  bLength;
    __packed UINT8  bDescriptorType;
    __packed UINT8  bInterfaceNumber;
    __packed UINT8  bAlternateSetting;
    __packed UINT8  bNumEndpoints;
    __packed UINT8  bInterfaceClass;
    __packed UINT8  bInterfaceSubClass;
    __packed UINT8  bInterfaceProtocol;
    __packed UINT8  iInterface;
    USB_EP_DESC_T *endpoint;
    UINT8  *extra;
    INT     extralen;
} USB_IF_DESC_T;

```

Table 29-4: Members of USB\_IF\_DESC\_T

Member	Description
bLength	Size of the descriptor in bytes
bDescriptorType	INTERFACE descriptor type (0x04)
bInterfaceNumber	Number of interface. Zero-based value identifying the index in the array of concurrent interfaces supported by this configuration.
bAlternateSetting	Value used to select alternate setting for this interface
bNumEndpoints	Number of endpoints used by this interface (excluding endpoint zero)
bInterfaceClass	Class code
bInterfaceSubClass	Subclass code
bInterfaceProtocol	Protocol code
iInterface	Index of string descriptor describing this interface
endpoint	Refer to the endpoint descriptor list (recorded in USB_EP_DESC_T structure format) of this interface returned by this configuration
extra	Refer to the memory buffer preserve the raw data of this interface descriptor itself
extralen	The length of the <extra> memory buffer

The **dev->config[n]->interface** refers to a list of interfaces supported by configuration n. The structure members from **<bLength>** to **<iInterface>** are fully compliant to that defined in USB 1.1 specification. The **<endpoint>** refers to a list of endpoints supported by this interface. In addition, USB Driver keeps the interface descriptor itself in a dynamically allocated memory buffer, which is referred to by **<extra>**, and the length of this memory buffer is **<extralen>**.

```

/* Endpoint descriptor */
typedef struct usb_endpoint_descriptor
{
    __packed UINT8  bLength;
    __packed UINT8  bDescriptorType;
    __packed UINT8  bEndpointAddress;
    __packed UINT8  bmAttributes;
    __packed UINT16 wMaxPacketSize;
    __packed UINT8  bInterval;
    __packed UINT8  bRefresh;
    __packed UINT8  bSynchAddress;
    UINT8  *extra;
    INT     extralen;
} USB_EP_DESC_T;

```

Table 29-5: Members of USB\_EP\_DESC\_T

Member	Description
bLength	Size of the descriptor in bytes
bDescriptorType	ENDPOINT descriptor type (0x05)
bEndpointAddress	The address of this endpoint
bmAttributes	Transfer type of this endpoint
wMaxPacketSize	The maximum packet size this endpoint is capable of sending or receiving
bInterval	Interval for polling endpoint for data transfers (in milliseconds)
bRefresh	Audio extensions to the endpoint descriptor
bSynchAddress	Audio extensions to the endpoint descriptor
extra	Refer to the memory buffer preserve the raw data of this endpoint descriptor itself
extralen	The length of the <extra> memory buffer

**DEV\_REQ\_T**

**DEV\_REQ\_T** is used to represent the eight bytes device request in a control transfer. All device requests, including standard device requests, class-specific device requests, and vendor-specific device requests, are written in the **DEV\_REQ\_T** structure, which is also a member of a URB, and transferred to device through the control pipe.

```
typedef struct
{
    __packed UINT8  requesttype;
    __packed UINT8  request;
    __packed UINT16 value;
    __packed UINT16 index;
    __packed UINT16 length;
} DEV_REQ_T;
```

Table 29-6: Members of DEV\_REQ\_T

Member	Description
requesttype	Characteristics of request
request	Specific request
value	Word-sized field that varies according to request
index	Word-sized field that varies according to request
length	Number of bytes to transfer if there is a DATA stage



## ***USB\_DEV\_ID\_T***

When the USB System Software detects a device being attached, it must find out the corresponding device driver for each of its interface from the registered driver list. It can try to invoke the ***probe()*** routine of each registered device driver for each device interface, but this is not efficient and time-consuming. If the USB System Software can make some simple judgment before trying invoking a device driver, it will be better. This is the purpose of ***USB\_DEV\_ID\_T***. The USB Library employ device ID to identify the appropriate device drivers.

When a device driver is registered to USB Driver, it may provide a device ID table, which is structured in ***USB\_DEV\_ID\_T*** format. In the device ID table, driver can specify the characteristics of the USB device interface that the driver would serve. If a driver does not provide a device ID table, then the USB Driver will always try to invoke it when a new device is detected.

The device driver can use device ID table to specify several checks of characteristics, including vendor ID, device ID, release number, device class, device subclass, device protocol, interface class, interface subclass, and interface protocol. The device driver can specify one or more checks. The more checks are specified; the more specific device interface can be identified. Table 2-7 lists the entries of device ID table.

```
typedef struct usb_device_id
{
    UINT16  match_flags;
    UINT16  idVendor;
    UINT16  idProduct;
    UINT16  bcdDevice_lo;
    UINT16  bcdDevice_hi;
    UINT8   bDeviceClass;
    UINT8   bDeviceSubClass;
    UINT8   bDeviceProtocol;
    UINT8   bInterfaceClass;
    UINT8   bInterfaceSubClass;
    UINT8   bInterfaceProtocol;
    UINT32  driver_info;
} USB_DEV_ID_T;
```

Table 29-7: Members of DEV\_REQ\_T

Member	Description
matchflag	A bitmask of flags, used to determine which of the following items are to be used for matching
idVendor	Used to compare the vendor ID recorded in device descriptor
idProduct	Used to compare the product ID recorded in device descriptor

bcdDevice_lo	Specify the low limit of device release number
bcdDevice_hi	Specify the high limit of device release number
bDeviceClass	Used to compare the class code in device descriptor
bDeviceSubClass	Used to compare the subclass code in device descriptor
bDeviceProtocol	Used to compare the protocol code in device descriptor
bInterfaceClass	Used to compare the class code in interface descriptor
bInterfaceSubClass	Used to compare the subclass code in interface descriptor
bInterfaceProtocol	Used to compare the protocol code in interface descriptor

There are 10 check items can be used to identify a specific type of device. To select which of these check items should be used to identify a device type is controlled by the **<matchflag>** member, which is a 16bits bit-mask flag. Each bit of **< matchflag >** is corresponding to one of these check items. The bit-map definition of **< matchflag >** is defined as the followings:

```
#define USB_DEVICE_ID_MATCH_VENDOR      0x0001
#define USB_DEVICE_ID_MATCH_PRODUCT     0x0002
#define USB_DEVICE_ID_MATCH_DEV_LO      0x0004
#define USB_DEVICE_ID_MATCH_DEV_HI      0x0008
#define USB_DEVICE_ID_MATCH_DEV_CLASS   0x0010
#define USB_DEVICE_ID_MATCH_DEV_SUBCLASS 0x0020
#define USB_DEVICE_ID_MATCH_DEV_PROTOCOL 0x0040
#define USB_DEVICE_ID_MATCH_INT_CLASS    0x0080
#define USB_DEVICE_ID_MATCH_INT_SUBCLASS 0x0100
#define USB_DEVICE_ID_MATCH_INT_PROTOCOL 0x0200
```

For convenience of driver implementation, the USB library also provides some useful macros that facilitate the development of device driver. These macros are all listed in the followings, you can also define your own macros:

```
/* Some useful macros */
#define USB_DEVICE(vend,prod) \
    { USB_DEVICE_ID_MATCH_DEVICE, vend, prod, 0, 0, \
      0, 0, 0, 0, 0, 0 }

#define USB_DEVICE_VER(vend,prod,lo,hi) \
    { USB_DEVICE_ID_MATCH_DEVICE_AND_VERSION, vend, \
      prod, lo, hi, 0, 0, 0, 0, 0, 0 }
```

```

#define USB_DEVICE_INFO(cl,sc,pr) \
    { USB_DEVICE_ID_MATCH_DEV_INFO, 0, 0, 0, 0, cl, \
      sc, pr, 0, 0, 0, 0 }

#define USB_INTERFACE_INFO(cl,sc,pr) \
    { USB_DEVICE_ID_MATCH_INT_INFO, 0, 0, 0, 0, 0, \
      0, 0, cl, sc, pr, 0 }

```

### ***USB\_DRIVER\_T***

The USB library has defined a generalized structure for all USB device drivers. To implement a USB device driver based on this library, you must create such a structure and register it to the USB Driver. Once you have registered your device driver, the USB Driver can determine whether to launch your driver when a new device is attached.

As we will give detail introduction to the implementation of USB device driver, we only briefly describe the members of ***USB\_DRIVER\_T*** as following:

```

typedef struct usb_device_id
{
    UINT16  match_flags;
    UINT16  idVendor;
    UINT16  idProduct;
    UINT16  bcdDevice_lo;
    UINT16  bcdDevice_hi;
    UINT8   bDeviceClass;
    UINT8   bDeviceSubClass;
    UINT8   bDeviceProtocol;
    UINT8   bInterfaceClass;
    UINT8   bInterfaceSubClass;
    UINT8   bInterfaceProtocol;
    UINT32  driver_info;
} USB_DEV_ID_T;

```

Table 29-8: Members of DEV\_REQ\_T

Member	Description
matchflag	A bitmask of flags, used to determine which of the following items are to be used for matching

idVendor	Used to compare the vendor ID recorded in device descriptor
idProduct	Used to compare the product ID recorded in device descriptor
bcdDevice_lo	Specify the low limit of device release number
bcdDevice_hi	Specify the high limit of device release number
bDeviceClass	Used to compare the class code in device descriptor
bDeviceSubClass	Used to compare the subclass code in device descriptor
bDeviceProtocol	Used to compare the protocol code in device descriptor
bInterfaceClass	Used to compare the class code in interface descriptor
bInterfaceSubClass	Used to compare the subclass code in interface descriptor
bInterfaceProtocol	Used to compare the protocol code in interface descriptor

## ***URB\_T***

USB specification has defined four transfer type: control, bulk, interrupt, and isochronous. In the USB library, all these four transfer types are accomplished by URB (USB Request Block). Please refer to Chapter 3 for details about the implementation of each transfer type by using URB.

## ***Data Transfer***

USB specification defines four transfer types, control, bulk, interrupt, and isochronous. The USB device driver performs data transfers by preparing an URB and transfer it to the underlying USB system software. The URBs are designed to be accommodated with all four transfer types. By configuring the URB, USB device driver can specify the destination device interface and endpoint, the data buffer and data length to be transferred, the callback routine on completion, and other detail information. USB device driver passed the URB to the underlying USB system software, which will interpret the URB and accomplish the data transfers by initiating USB transactions between W90X900 Host Controller and the target device endpoint.

URB has been designed to be accommodated with all four USB data transfer types. Due to the characteristics of different transfer types, various requirements must be satisfied to fulfill the transfer. For example, URB contains **<setup\_packet>** for control transfer, **<interval>** for interval transfer, **<start\_frame>** and **<number\_of\_packets>** for isochronous transfer, and **<transfer\_buffer>** for all transfers. To implement a USB device driver, the programmers use URBs to accomplish all data transfers to all of the various endpoints.

For a specific endpoint, after delivering a URB to the underlying USB system software, the USB device driver must not deliver another URB to the same endpoint until the current transfer was done by the USB system software. That is, the driver must be blocked in waiting completion of the URB. URB includes a **<complete>** function pointer to solve the block waiting issue. The USB device driver provided a callback function and have **<complete>** pointer being referred to the callback function. On completion of this URB, the USB system software will invoke the callback function. Thus, the USB device driver was notified with the completion event, and can stop waiting. Note that the callback functions are invoked from an HISR, the execution time must be as short as possible.

## ***Pipe Control***

Before delivering an URB, the USB device driver must determine which device and which endpoint the URB will operate on. This destination device and endpoint is determined by **<pipe>** of URB. **<pipe>** is actually a 32-bits unsigned integer. The USB library defined pipe structure

with a 32-bits unsigned integer. The USB library has defined several useful macros for pipe control. The pipe is defined as the followings:

31	30	29	28	27	26	25	24
Pipe Type		Reserved			Speed	Reserved	
23	22	21	20	19	18	17	16
Reserved				Data0/1	Endpoint		
15	14	13	12	11	10	9	8
	Device						
7	6	5	4	3	2	1	0
Direction	Reserved					Max Size	

Table 29-9: Members of Pipe Control

Member	Description
Max Size [1 .. 0]	The maximum packet size. This field has been obsoleted. Now the maximum packet size is recorded in <code>&lt;epmaxpacketin&gt;</code> and <code>&lt;epmaxpacketout&gt;</code> fields of <code>USB_DEV_T</code> .
Direction[7]	Direction of data transfer. 0 = Host-to-Device [out]; 1 = Device-to-Host [in]
Device[8 .. 14]	Device number. This is the unique device address, which is assigned by Host Controller driver by <b>SET_ADDRESS</b> standard request. With this unique device number, the USB device driver can correctly locate the target device.
Endpoint[15 .. 18]	Endpoint number. This is the endpoint number on the target device, that the pipe is created with. By definition, a pipe corresponds to a unique endpoint on a unique device. By determining the device number and endpoint number, USB device driver can uniquely identify a specific endpoint of a specific device.
Data0/1[19]	Data toggle Data0/Data1. This bit is used to record the current data toggle condition.
Speed[26]	Endpoint transfer speed. 1 = Low speed; 0 = Full speed.
Pipe Type[30 .. 31]	Transfer type. 00 = isochronous; 01 = interrupt; 10 = control; 11 = bulk.

The USB library has provided a lot of macros facilities for USB device driver designer. The device driver can use the facilities to rescuer the trouble of managing bit fields. These macros are listed in the followings:

### Transfer Type

#define PIPE_ISOCHRONOUS	0
#define PIPE_INTERRUPT	1
#define PIPE_CONTROL	2
#define PIPE_BULK	3
#define usb_pipetype(pipe)	((pipe) >> 30) & 3)

```
#define usb_pipecontrol(pipe) (usb_pipetype((pipe)) == PIPE_CONTROL)
#define usb_pipebulk(pipe)    (usb_pipetype((pipe)) == PIPE_BULK)
#define usb_pipeint(pipe)     (usb_pipetype((pipe)) == PIPE_INTERRUPT)\
#define usb_pipeisoc(pipe)    (usb_pipetype((pipe)) == PIPE_ISOCHRONOUS
```

### **Maximum Packet Size**

```
#define usb_maxpacket(dev, pipe, out)    (out          \
      ? (dev)->epmaxpacketout[usb_pipeendpoint(pipe)] \
      : (dev)->epmaxpacketin [usb_pipeendpoint(pipe)] )
```

### **Direction**

```
#define usb_packetid(pipe) (((pipe) & USB_DIR_IN) ?      \
                           USB_PID_IN : USB_PID_OUT)
#define usb_pipeout(pipe) (((pipe) >> 7) & 1) ^ 1)
#define usb_pipein(pipe)  (((pipe) >> 7) & 1)
```

### **Device Number**

```
#define usb_pipedevice(pipe)    (((pipe) >> 8) & 0x7f)
#define usb_pipe_endpdev(pipe)  (((pipe) >> 8) & 0x7ff)
```

### **Endpoint Number**

```
#define usb_pipe_endpdev(pipe)  (((pipe) >> 8) & 0x7ff)
#define usb_pipeendpoint(pipe)  (((pipe) >> 15) & 0xf)
```

### **Data Toggle**

```
#define usb_pipedata(pipe)      (((pipe) >> 19) & 1)
#define usb_gettoggle(dev, ep, out)          \
      (((dev)->toggle[out] >> ep) & 1)
#define usb_dotoggle(dev, ep, out)          \
      ((dev)->toggle[out] ^= (1 << ep))
#define usb_settoggle(dev, ep, out, bit)     \
      ((dev)->toggle[out] =
```

```
((dev->toggle[out] & ~(1 << ep)) | \
((bit) << ep))
```

### **Speed**

```
#define usb_pipeslow(pipe)      (((pipe) >> 26) & 1)
```

### **Pipe Creation**

```
static __inline UINT32 __create_pipe(USB_DEV_T *dev, UINT32 endpoint)
{
    return (dev->devnum << 8) | (endpoint << 15) | (dev->slow << 26);
}

static __inline UINT32 __default_pipe(USB_DEV_T *dev)
{
    return (dev->slow << 26);
}

/* Create various pipes... */
#define usb_sndctrlpipe(dev,endpoint) \
    (0x80000000 | __create_pipe(dev,endpoint))
#define usb_rcvctrlpipe(dev,endpoint) \
    (0x80000000 | __create_pipe(dev,endpoint) | USB_DIR_IN)
#define usb_sndisocpipe(dev,endpoint) \
    (0x00000000 | __create_pipe(dev,endpoint))
#define usb_rcvisocpipe(dev,endpoint) \
    (0x00000000 | __create_pipe(dev,endpoint) | USB_DIR_IN)
#define usb_sndbulkpipe(dev,endpoint) \
    (0xC0000000 | __create_pipe(dev,endpoint))
#define usb_rcvbulkpipe(dev,endpoint) \
    (0xC0000000 | __create_pipe(dev,endpoint) | USB_DIR_IN)
#define usb_sndintpipe(dev,endpoint) \
    (0x40000000 | __create_pipe(dev,endpoint))
#define usb_rcvintpipe(dev,endpoint) \
```

```

        (0x40000000 | __create_pipe(dev,endpoint) | USB_DIR_IN)
#define usb_snddefctrl(dev)                \
        (0x80000000 | __default_pipe(dev))
#define usb_rcvdefctrl(dev)                \
        (0x80000000 | __default_pipe(dev) | USB_DIR_IN)

```

## Control Transfer

IN this section, we will introduce how to make control transfers by URBs. A control transfer is accomplished by sending a device request to the control endpoint of the target device. Depend on the request sent to device, there may be data stage or not.

The URB provided a **<setup\_packet>** field to accommodate the device request command. The USB device driver must have the **<setup\_packet>** of its URB being referred to an **<unsigned char>** array, which contained the device request command to be transferred. Note that **<setup\_packet>** is designed to be used with control transfer.

If a device request included data stage, the data to be transferred must be referred to by the **<transfer\_buffer>** pointer of URB. If the device request required data to be sent from Host to Device, the USB device driver must prepare a DMA buffer (non-cacheable) and fill the data to be transferred into this buffer. Then, the USB device driver have **<transfer\_buffer>** pointer refer to this buffer, and specify the length of the buffer with **<transfer\_buffer\_length>** of the URB. If the device request requires data to be sent from Device to Host, the USB device driver must prepare a DMA buffer to receive the data from Device. Again, the USB device driver used **<transfer\_buffer>** and **<Transfer\_buffer\_length>** to describe its DMA buffer. The **<actual\_length>** is written by USB system software to tell the device driver how many bytes are actually transferred.

The USB device driver also has to prepare a callback function to be invoked by the USB system software. The callback function will be invoked on the completion of URB, in spite of success or fail. Generally, the callback function is responsible for waking up the task that delivered the URB. The callback function may also check the status of the URB to determine the transfer is successful or not. The following is an example of control transfer.

```

static VOID  ctrl_callback(URB_T *urb)
{
    PEGASUS_T  *pegasus = urb->context;

    switch ( urb->status )
    {
        case USB_ST_NOERROR:
            if (pegasus->flags & ETH_REGS_CHANGE)
            {
                pegasus->flags &= ~ETH_REGS_CHANGE;
            }
        }
    }

```



```

        pegasus->flags |= ETH_REGS_CHANGED;
        update_eth_regs_async(pegasus);
        return;
    }
    break;
case USB_ST_URB_PENDING:
    return;
case USB_ST_URB_KILLED:
    break;
default:
    printf("Warning - status %d\n", urb->status);
}
pegasus->flags &= ~ETH_REGS_CHANGED;
if (pegasus->flags & CTRL_URB_SLEEP)
{
    pegasus->flags &= ~CTRL_URB_SLEEP;
    NU_Set_Events(&pegasus->events, 1, NU_OR); /* set event */
}
}

static INT get_registers(PEGASUS_T *pegasus, UINT16 indx, UINT16 size, VOID *data)
{
    INT ret;
    UINT8 *dma_data;

    while (pegasus->flags & ETH_REGS_CHANGED)
    {
        pegasus->flags |= CTRL_URB_SLEEP;
        USB_printf("ETH_REGS_CHANGED waiting...\n");
        NU_Retrieve_Events(&pegasus->events, 1, NU_AND,
                        (unsigned long *)&ret, NU_SUSPEND);
    }
}

```

```

dma_data = (UINT8 *)USB_malloc(size, BOUNDARY_WORD);
if (!dma_data)
    return -ENOMEM;

pegasus->dr->requesttype = PEGASUS_REQT_READ;
pegasus->dr->request = PEGASUS_REQ_GET_REGS;
#ifdef LITTLE_ENDIAN
    pegasus->dr->value = 0;
    pegasus->dr->index = indx;
    pegasus->dr->length = size;
#else
    pegasus->dr->value = USB_SWAP16(0);
    pegasus->dr->index = USB_SWAP16(indx);
    pegasus->dr->length = USB_SWAP16(size);
#endif

pegasus->ctrl_urb.transfer_buffer_length = size;

FILL_CONTROL_URB(&pegasus->ctrl_urb, pegasus->usb,
                usb_rcvctrlpipe(pegasus->usb,0),
                (UINT8 *)pegasus->dr,
                dma_data, size, ctrl_callback, pegasus );

pegasus->flags |= CTRL_URB_SLEEP;
NU_Set_Events(&pegasus->events, 0, NU_AND); /* clear event */
USB_SubmitUrb(&pegasus->ctrl_urb);
NU_Retrieve_Events(&pegasus->events, 1, NU_AND,
                  (unsigned long *)&ret, NU_SUSPEND);
memcpy(data, dma_data, size);
out:
USB_free(dma_data);
return  ret;
}

```

In the above example, the device driver first prepares the device request command in *<pegasus-*

>dr>, which was later referred to by <urb->setup\_packet>. It request a buffer for DMA transfer by **USB\_malloc()**. Note that **USB\_malloc()** will allocate a non-cacheable memory buffer. It then created a Control-In pipe by using **usb\_rcvctrlpipe** macro, and the endpoint number is 0. The device driver the use the **FILL\_CONTROL\_URB** macro facility to fill the URB. The callback function is **ctrl\_callback()**, which is provided by the device driver itself. After submitting the URB, the caller task suspends on waiting the <pegasus->events> event set. On completion of this URB, the USB system software will invoke **ctrl\_callback()**, and **ctrl\_callback()** will set the <pegasus->events> event to wake up the caller task.

## Bulk Transfer

IN this section, we will introduce how to make bulk transfers by URBs. The URB provided <transfer\_buffer> and <transfer\_buffer\_length> to accommodate data to be transferred to or from device. The direction of transfer is determined by the direction bit of bulk pipe. The transfer length is unlimited. If you are familiar with OpenHCI specification, you may understand that the maximum transfer size of a bulk transfer is 4096 bytes. If the transfer length of your URB exceeds 4096 bytes, the USB system software will split it into several transfer units smaller than 4096 bytes. Thus, you can specify unlimited transfer buffer length, only the physical memory can limit the size.

The transfer buffer must be non-cacheable. A designer can use **USB\_malloc()** to acquire a block of non-cacheable memory.

The USB device driver also has to prepare a callback function to be invoked by the USB system software. The callback function will be invoked on the completion of URB, in spite of success or fail. Generally, the callback function is responsible for waking up the task that delivered the URB. The callback function may also check the status of the URB to determine the transfer is successful or not. The following is an example of bulk transfer

```
/* In Host Controller HISR context */
static VOID write_bulk_callback(URB_T *urb)
{
    PEGASUS_T      *pegasus = urb->context;
    STATUS         previous_int_value;
    DV_DEVICE_ENTRY *device;

    _PegasusDevice->tx_ready = 1;
    /* Get a pointer to the device. */
    device = DEV_Get_Dev_By_Name("Pegasus");

    /* Lock out interrupts. */
    previous_int_value = NU_Control_Interrupts(NU_DISABLE_INTERRUPTS);
    DEV_Recover_TX_Buffers(device);

    /* If there is another item on the list, transmit it. */
}
```

```

        if (device->dev_transq.head)
        {
            /* Re-enable interrupts */
            NU_Control_Interrupts(previous_int_value);
            /* Transmit the next packet. */
            PegasusTransmit(device, device->dev_transq.head);
        }
        /* Re-enable interrupts. */
        NU_Control_Interrupts(previous_int_value);

        if (urb->status)
            USB_printf("write_bulk_callback - TX error status: %d\n",
                       urb->status);
    }

STATUS PegasusTransmit(DV_DEVICE_ENTRY *dev, NET_BUFFER *netBuffer)
{
    INT      ret, wait=0;
    UINT8    *buf_ptr;
    INT      totalLength = 0;

    while (!_PegasusDevice->tx_ready)
    {
        NU_Sleep(1);                /* wait on any outgoing Tx */
        if (wait++ > NU_PLUS_Ticks_Per_Second)
        {
            USB_printf("Can't transmit packet!\n");
            return NU_IO_ERROR;
        }
    }

    buf_ptr = _PegasusDevice->tx_buff + 2;

```

```

do
{
    memcpy(buf_ptr, netBuffer->data_ptr, netBuffer->data_len);
    totalLength += netBuffer->data_len;
    buf_ptr += netBuffer->data_len;

    /* Move on to the next buffer. */
    netBuffer = netBuffer->next_buffer;
} while (netBuffer != 0);

/* The first two bytes record the packet length. */
buf_ptr = _PegasusDevice->tx_buff;
buf_ptr[0] = totalLength & 0xff;
buf_ptr[1] = (totalLength >> 8) & 0xff;

FILL_BULK_URB(&_PegasusDevice->tx_urb, _PegasusDevice->usb,
              usb_sndbulkpipe(_PegasusDevice->usb, 2),
              (CHAR *)buf_ptr, PEGASUS_MAX_MTU,
              write_bulk_callback, _PegasusDevice);

_PegasusDevice->tx_urb.transfer_buffer_length =
    ((totalLength+2) & 0x3f) ? totalLength+2 : totalLength+3;
_PegasusDevice->tx_ready = 0;
USB_SubmitUrb(&_PegasusDevice->tx_urb);
return NU_SUCCESS;
}

```

### ***Interrupt Transfer***

IN this section, we will introduce how to make interrupt transfers by URBs. The URB provided **<transfer\_buffer>** and **<transfer\_buffer\_length>** to accommodate data to be transferred to or from device, and **<interval>** to specify polling interval of the interrupt transfer. The direction of transfer is determined by the direction bit of interrupt pipe. The transfer length is dependent on target interrupt endpoint.

The transfer buffer must be non-cacheable. A designer can use **USB\_malloc()** to acquire a block of non-cacheable memory.

The USB device driver also has to prepare a callback function to be invoked by the USB system software. The callback function will be invoked if there's data received in one of the interrupt interval. In the callback function, USB device driver can read **<transfer\_buffer>** to retrieve received interrupt data. The USB device driver have not to modify URB or resend URB. The USB library will resend the interrupt URB after callback. The interrupt URB will not stop until hardware failure or explicitly deleted by the USB device driver.

```
static VOID  intr_callback(URB_T *urb)
{
    PEGASUS_T *pegasus = urb->context;
    UINT8      *d;

    if (!pegasus)
        return;

    switch (urb->status)
    {
        case USB_ST_NOERROR:
            break;
        case USB_ST_URB_KILLED:
            return;
        default:
            break;
    }

    d = urb->transfer_buffer;
    if (d[2] & 0x1)
        UART_printf("Rx error - overflow!!\n");
}

FILL_INT_URB(&_PegasusDevice->intr_urb, _PegasusDevice->usb,
             usb_rcvintpipe(_PegasusDevice->usb, 3),
             (CHAR *)&_PegasusDevice->intr_buff[0], 8,
             intr_callback, _PegasusDevice,
             _PegasusDevice->intr_interval);
```

```

res = USB_SubmitUrb(&_PegasusDevice->intr_urb);
if (res)
UART_printf("pegasus_open - failed intr_urb %d\n", res);

```

## 29.3 USB CORE LIBRARY API

### ***InitUsbSystem***

#### **Synopsis**

INT InitUsbSystem (VOID)

#### **Description**

Initialize the USB hardware and USB core library. This function must be invoked before any other functions. The USB library will scan device at this time, but the device will not be activated until the corresponding device driver was registered by USB\_RegisterDriver().

#### **Parameter**

None

#### **Return Value**

0 – Success

Otherwise – Failure

#### **Example**

```

/*
Initialize NVTFAT FAT file system, USB core system, and USB mass storage driver
*/
fsInitFileSystem();
InitUsbSystem();
UMAS_InitUmasDriver();

```

### ***UMAS\_InitUmasDriver***

#### **Synopsis**

INT UMAS\_InitUmasDriver (VOID)

#### **Description**

Initialize the USB mass storage driver. fsInitFileSystem() and InitUsbSystem() must be called prior to this API. Once an USB mass storage device detected, USB

core library will initialize it and mount it to NVTFAT file system automatically.

**Parameter**

None

**Return Value**

0 – Success

Otherwise – Failure

**Example**

```
/*  
Initialize NVTFAT FAT file system, USB core system, and USB mass storage driver  
*/  
fsInitFileSystem();  
InitUsbSystem();  
UMAS_InitUmasDriver();
```

## ***USB\_RegisterDriver***

**Synopsis**

INT USB\_RegisterDriver (USB\_DRIVER\_T \*driver)

**Description**

Register a device driver with the USB library. In this function, USB library will also try to associate the newly registered device driver with all connected USB devices that have no device driver associated with it. Note that a connected USB device can be detected by USB library but may not work until it was associated with its corresponding device driver.

**Parameter**

driver                      The USB device driver to be registered with USB core library

**Return Value**

0 – Success

Otherwise – Failure

**Example**

```
static USB_DRIVER_T  usblp_driver =  
{  
    "usblp",  
    usblp_probe,
```



```

        usblp_disconnect,
        {NULL,NULL},
        {0},
        NULL,
        usblp_ids,
        NULL,
        NULL
    };

    INT  UsbPrinter_Init() {
        if (USB_RegisterDriver(&usblp_driver)) return -1;
        return 0;
    }

```

### ***USB\_DeregisterDriver***

#### **Synopsis**

```
VOID  USB_DeregisterDriver(USB_DRIVER_T *driver)
```

#### **Description**

Deregister a device driver.

#### **Parameter**

driver                      The device driver to be deregistered

#### **Return Value**

0 – Success

Otherwise – Failure

#### **Example**

```

VOID  UsbPrinter_Exit()
{
    USB_DeregisterDriver(&usblp_driver);
}

```

### ***USB\_AllocateUrb***

#### **Synopsis**

URB\_T \*USB\_AllocateUrb(INT iso\_packets)

**Description**

Creates an urb for the USB driver to use and returns a pointer to it. The driver should call USB\_FreeUrb() when it is finished with the urb

**Parameter**

iso\_packets            The number of isochronous frames in a single URB.  
For other transfer types, this value must be zero.

**Return Value**

NULL            - Failure  
Otherwise    - A pointer to the newly allocated URB

**Example**

```
_W99683_Camera->sbuf[i].urb = USB_AllocateUrb(FRAMES_PER_DESC);  
if (_W99683_Camera->sbuf[i].urb == NULL)  
{  
    UART_printf("%s - USB_AllocateUrb(%d.) failed.\n", proc,  
                FRAMES_PER_DESC);  
    Return -1;  
};
```

***USB\_FreeUrb***

**Synopsis**

VOID USB\_FreeUrb(URB\_T \*urb)

**Description**

Frees the memory used by a urb.

**Parameter**

None

**Return Value**

None

**Example**

None

***USB\_SubmitUrb***

### Synopsis

INT USB\_SubmitUrb(URB\_T \*urb)

### Description

Submit a URB for executing data transfer

### Parameter

urb            Pointer to the URB to be serviced.

### Return Value

0 – Success

Otherwise – Failure

### Example

```
/* prepare URB */
FILL_BULK_URB(&_PegasusDevice->tx_urb, _PegasusDevice->usb,
              usb_sndbulkpipe(_PegasusDevice->usb, 2),(CHAR *)buf_ptr,
PEGASUS_MAX_MTU,
              write_bulk_callback, _PegasusDevice);

/* set the data length to be transferred */
_PegasusDevice->tx_urb.transfer_buffer_length =
((totalLength+2) & 0x3f) ? totalLength+2 :
totalLength+3;
_PegasusDevice->tx_ready = 0;

/* submit URB */
if (USB_SubmitUrb(&_PegasusDevice->tx_urb) != 0)
{
    UART_printf("Warning - failed tx_urb %d\n", ret);
    return NU_IO_ERROR;
}
```

## **USB\_UnlinkUrb**

### Synopsis

INT USB\_UnlinkUrb(URB\_T \*urb)

### Description

Unlink a URB which has been submitted but not finished

Parameter

urb      pointer to the URB to be unlinked

Return Value

0 – Success

Otherwise – Failure

Example

```
INT PegasusClose()
{
    _PegasusDevice->flags &= ~PEGASUS_RUNNING;

    if (!(_PegasusDevice->flags & PEGASUS_UNPLUG))
        disable_net_traffic(_PegasusDevice);

    USB_UnlinkUrb(&_PegasusDevice->rx_urb);
    USB_UnlinkUrb(&_PegasusDevice->tx_urb);
    USB_UnlinkUrb(&_PegasusDevice->ctrl_urb);
#ifdef PEGASUS_USE_INTR
    USB_UnlinkUrb( &_PegasusDevice->intr_urb );
#endif
    return 0;
}
```

## ***USB\_SendBulkMessage***

### **Synopsis**

```
INT USB_SendBulkMessage(USB_DEV_T *dev,
                        UINT32 pipe,
                        VOID *data,
                        INT len,
                        INT *actual_length,
                        INT timeout)
```

### **Description**

Builds a bulk urb, sends it off and waits for completion. This function sends a simple bulk message to a specified endpoint and waits for the message to

complete, or timeout. Don't use this function from within an interrupt context.

#### Parameter

dev	pointer to the usb device to send the message to
pipe	endpoint "pipe" to send the message to
data	pointer to the data to send
len	length in bytes of the data to send
actual_length	pointer to a location to put the actual length transferred in bytes
timeout	time to wait for the message to complete before timing out
	(if 0 the wait is forever)

#### Return Value

0 – Success  
Otherwise – Failure

#### Example

```
if (!pb->pipe)
    pipe = usb_rcvbulkpipe (s->usbdev, 2);
else
    pipe = usb_sndbulkpipe (s->usbdev, 2);
ret = USB_SendBulkMessage(s->usbdev, pipe, pb->data, pb->size,
&actual_length, 100);
if (ret<0) {
    err("dabusb: usb_bulk_msg failed(%d)",ret);
    if (usb_set_interface (s->usbdev, _DABUSB_IF, 1) < 0) {
        err("set_interface failed");
        return -EINVAL;
    }
}
```

## ***USB\_malloc***

#### Synopsis

```
VOID *USB_malloc(INT wanted_size,
                  INT boundary)
```

#### Description

Allocate a non-cacheable memory block started from assigned boundary. The total size of the USB library managed memory block is 256KB.

#### Parameter

wanted\_size      The wanted size of non-cacheable memory block

boundary      The start address boundary of the memory block.

It can be BOUNDARY\_BYTE, BOUNDARY\_HALF\_WORD, BOUNDARY\_WORD, BOUNDARY32, BOUNDARY64, BOUNDARY128, BOUNDARY256, BOUNDARY512, BOUNDARY1024, BOUNDARY2048, BOUNDARY4096.

#### Return Value

NULL      Failed, there is not enough memory or USB library is not started

Otherwise      pointer to the newly allocated memory block

#### Example

```
UINT8  *dma_data;

dma_data = USB_malloc(len, BOUNDARY_WORD);
if (dma_data == NULL) {
    NU_printf("usblp_ctrl_msg - Memory not enough!\n");
    return -1;
}

retval = USB_SendControlMessage(usblp->dev,
    dir ? usb_rcvctrlpipe(usblp->dev, 0) : usb_sndctrlpipe(usblp->dev, 0),
    request, USB_TYPE_CLASS | dir | recip, value, usblp->ifnum, dma_data,
    len, HZ * 5);

    memcpy(buf, dma_data, len);

    USB_free(dma_data);
```

### ***USB\_free***

#### Synopsis

```
VOID  USB_free(VOID *alloc_addr)
```

#### Description

Free the memory block allocated by USB\_malloc().

#### Parameter

alloc\_addr      pointer to the USB\_malloc() allocated memory block

to be freed.

**Return Value**

None

**Example**

Same as USB\_malloc()

## **30 VIDEOIN LIBRARY**


### **30.1 FEATURES**

The VIDEOIN Library has the following features:

- Programmable sensor input format YCbCr422/RGB565.
- Programmable output packet format YCbCr422/RGB565/RGB555/Y-only to frame buffer.
- Programmable output planar format YUV422/YUV420/macro block YUV420 to frame buffer
- Support to enable or disable planar and packet pipes for encode and preview respectively.
- Programmable different downscale factor for planar and packet pipes.
- Support cropping image.
- Programmable CCIR601 and CCIR656 input interface.
- Programmable input polarity of pixel clock, h-sync and v-sync.
- Support indoor motion detection.
- Max support 2 sensor ports.

### **30.2 VIDEOIN LIBRARY DESCRIPTION**





To initialize this sensor, just call the I2C library. However, programmer has to enable sensor clock before initialize sensor through I2C bus.

### 30.3 VIDEOLIN LIBRARY API

#### *register\_vin\_device*

##### Synopsis

```
INT32 register_vin_device(UINT32 u32port, VINDEV_T* pVinDev );
```

##### Description

The function has to be called before calling other videoIn APIs. It gets back a instant base on the specified port. All of the API functions will be operation base on the instant.

##### Parameter

u32Port	1: Capture port 1
	2: Capture port 2

##### Return Value

-1 or Successful

#### Example

```
VINDEV_T Vin;
VINDEV_T* pVin;
INT32 i32ErrCode;
i32ErrCode = register_vin_device(1, &Vin); /* Register capture 1 */
if(i32ErrCode<0){
    sysprintf("Register vin 0 device fail\n");
    return -1;
}
pVin = &Vin;
pVin->Init(TRUE, eSYS_UPLL, 24000, eVIDEOIN_SNR_CCIR601);
```

### Init

#### Synopsis

```
void (*Init)(BOOL blsEnableSnrClock,
              IDEOIN_SNR_SRC eSnrSrc,
              NT32 u32SensorFreqKHz,
              VIDEOIN_DEV_TYPE eDevType)
```

#### Description

The function has to be called before calling other videoIn APIs exception function-**register\_vin\_device()**. It enables sensor clock. So before initialize sensor, the sensor clock has to be also enabled. It is also specified the multiple pin function for the specified device type.

#### Parameter

blsEnableSnrClock	TRUE to enable sensor clock. FALSE to disable sensor clock.
eSnrSrc	eSYS_UPLL or eSYS_ALL
u32SensorFreq	Speciofied the senor clock to be initialized by I2C.
Unit: KHz	
eDevType	Input device type. Please refer Table 30-1: Input device multiple function pins

Table 30-1: Input device multiple function pins

eDevType	Value	Description
----------	-------	-------------

eVIDEOIN_SNR_CCIR656	0	Sensor input CCIR665 format. The device type is only used if capture port 1. Sensor interface is through GPIOB port.
eVIDEOIN_SNR_CCIR601	1	Sensor input CCIR601 format. The device type is only used if capture port 1. Sensor interface is through GPIOB port.
eVIDEOIN_TVD_CCIR656	2	TV decoder input CCIR656. The device type is only used if capture port 1. Sensor interface is through GPIOB port.
eVIDEOIN_TVD_CCIR601	3	TV decoder input CCIR601. The device type is only used if capture port 1. Sensor interface is through GPIOB port.
eVIDEOIN_2ND_SNR_CCIR656	4	Sensor input CCIR665 format. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPE port.
eVIDEOIN_2ND_SNR_CCIR601	5	Sensor input CCIR601 format. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPE port.
eVIDEOIN_2ND_TVD_CCIR656	6	TV decoder input CCIR656. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPE port.
eVIDEOIN_2ND_TVD_CCIR601	7	TV decoder input CCIR601. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPE port..
eVIDEOIN_3RD_SNR_CCIR656	8	Sensor input CCIR665 format. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPD port.
eVIDEOIN_3RD_SNR_CCIR601	9	Sensor input CCIR601 format. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPD port.
eVIDEOIN_3RD_TVD_CCIR656	10	TV decoder input CCIR656. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPD port.
eVIDEOIN_3RD_TVD_CCIR601	11	TV decoder input CCIR601. The device type is only used if capture port 2. Sensor interface is through GPIOC/GPA/GPD port.

#### Return Value

None

#### Example

```

VINDEV_T Vin;
VINDEV_T* pVin;
INT32 i32ErrCode;

i32ErrCode = register_vin_device(1, &Vin);          /* Register capture 1 */
if(i32ErrCode<0){
    sysprintf("Register vin 0 device fail\n");
}

```

```

        return -1;
    }
    pVin = &Vin;
    pVin->Init(TRUE, eSYS_UPLL, 24000, eVIDEOIN_SNR_CCIR601);

```

## ***Open***

### **Synopsis**

```

INT32 (*Open)(UINT32 u32EngFreqKHz,
               UINT32 u32SensorFreqKHz)

```

### **Description**

Open videoin device.

### **Parameter**

u32EngFreqKHz	It is useless.
u32SensorFreq	Sensor works frequency. Unit: KHz

### **Return Value**

0 – Success

### **Example**

```

VINDEV_T Vin;
VINDEV_T* pVin;
INT32 i32ErrCode;
i32ErrCode = register_vin_device(1, &Vin);          /* Register capture 1 */
if(i32ErrCode<0){
    sysprintf("Register vin 0 device fail\n");
    return -1;
}
pVin = &Vin;
pVin->Init(TRUE, eSYS_UPLL, 24000, eVIDEOIN_SNR_CCIR601);
pVin->Open(48000, 24000); /* Sensor clock 24MHz */

```

## ***Close***

### **Synopsis**

```

void (*Close)(void)

```

**Description**

Close videoIn device.

**Parameter**

None

**Return Value**

None

**Example**

```

VINDEV_T Vin;
VINDEV_T* pVin;
INT32 i32ErrCode;
i32ErrCode = register_vin_device(1, &Vin);          /* Register capture 1 */
if(i32ErrCode<0){
    sysprintf("Register vin 0 device fail\n");
    return -1;
}
pVin = &Vin;
pVin->Init(TRUE, eSYS_UPLL, 24000, eVIDEOIN_SNR_CCIR601);
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
.....
pVin->Close();

```

***SetPipeEnable*****Synopsis**

```

void (*SetPipeEnable)(BOOL bEngEnable, E_VIDEOIN_PIPE
ePipeEnable)

```

**Description**

Enable or disable engine and specified which pipes is enabled or disabled

**Parameter**

bEngEnable TRUE: Enable VideoIn engine

FALSE: Disable VideoIn engine

ePipeEnable Pipes enable or disable. Please refer Table 30-2: Pipes Type

Table 30-2: Pipes Type

eDevType	Value	Description
----------	-------	-------------

eVIDEOIN_BOTH_PIPE_DISABLE	0	Both planar and packet pipes are disabled
eVIDEOIN_PLANAR	1	Enable planar pipe only
eVIDEOIN_PACKET	2	Enable packet pipe only
eVIDEOIN_BOTH_PIPE_ENABLE	3	Both planar and packet pipes are enabled

### Return Value

None

### Example

```

VINDEV_T Vin;
VINDEV_T* pVin;
INT32 i32ErrCode;

i32ErrCode = register_vin_device(1, &Vin);          /* Register capture 1 */
if(i32ErrCode<0){
    sysprintf("Register vin 0 device fail\n");
    return -1;
}

pVin = &Vin;
pVin->Init(TRUE, eSYS_UPLL, 24000, eVIDEOIN_SNR_CCIR601);
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->SetPipeEnable(TRUE, /* Engine enable */
                    eVIDEOIN_BOTH_PIPE_ENABLE); /* Both pipes enable */

.....

pVin->Close();

```

## InstallCallback

### Synopsis

```

INT32 (*InstallCallback)(E_VIDEOIN_INT_TYPE eIntType,
                        PFN_VIDEOIN_CALLBACK pfnCallback,
                        PFN_VIDEOIN_CALLBACK *pfnOldCallback)

```

### Description

Install call back function for user layer. The function let the videoIn library call back to upper lay to inform user the frame end event. And pass some information to user layer.

### Parameter

eIntType Interrupt type. Please refer Table 30-3: Interrupt type

Table 30-3: Interrupt type

eIntType	Value	Description
eVIDEOIN_MDINT	0x100000	Motion Detection Interrupt
eVIDEOIN_ADDRMINT	0x80000	Address match interrupt. It is only support packet pip
eVIDEOIN_MEINT	0x20000	Memory Error.
eVIDEOIN_VINT	0x10000	Frame end interrupt

pfnCallback Function pointer for callback function.

pfnOldCallback Old callback function.

### Return Value

Successful or E\_VIDEOIN\_INVALID\_INT.

### Example

```
/* Install call back function for frame end */
void VideoIn_InterruptHandler(UINT8 u8PacketBufID,
                             UINT8 u8PlanarBufID,
                             UINT8 u8FrameRate,
                             UINT8 u8Filed)

{
    //Frame end
    ....
}

.....
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)VideoIn_InterruptHandler,
                    &pfnOldCallback ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->SetPipeEnable(TRUE, /* Engine enable */
                   eVIDEOIN_BOTH_PIPE_ENABLE); /* Both pipes enable */

.....
pVin->Close();
```

## ***EnableInt***

### **Synopsis**

INT32 (\*EnableInt)(E\_VIDEOIN\_INT\_TYPE eIntType)

### **Description**

Enable specified interrupt type.

### **Parameter**

eIntType    Reference    [Please refer Table 30-3: Interrupt type](#)

Table 30-3: Interrupt type

### **Return Value**

Successful or E\_VIDEOIN\_INVALID\_INT

### **Example**

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)VidIoIn_InterruptHandler,
                        &pfnOldCallback    ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->SetPipeEnable(TRUE, /* Engine enable */
                    eVIDEOIN_BOTH_PIPE_ENABLE); /* Both pipes enable */

.....
pVin->Close();
```

## ***DisableInt***

### **Synopsis**

INT32 (\*DisableInt)(E\_VIDEOIN\_INT\_TYPE eIntType)

### **Description**

Disable specified interrupt type.

### **Parameter**

eIntType    Reference    [Please refer Table 30-3: Interrupt type](#)

Table 30-3: Interrupt type

### **Return Value**

Successful or E\_VIDEOIN\_INVALID\_INT



### Example

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,
                        &pfnOldCallback ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT); /* Enable motion detection interrupt */
pVin->SetPipeEnable(TRUE, /* Engine enable */
                    eVIDEOIN_BOTH_PIPE_ENABLE); /* Both pipes enable */
.....
pVin->DisableInt(eVIDEOIN_MDINT); /* Enable motion detection interrupt */
```

## SetInputType

### Synopsis

```
void (*SetInputType)(UINT32 u32FieldEnable,
                     E_VIDEOIN_TYPE eInputType,
                     BOOL bFieldSwap)
```

### Description

Specified the input device type. It also specified which fields enable and fields swap if need in TV decoder input type.

### Parameter

u32FieldEnable 0, 1, 2 or 3. It is only useful if TV decoder.

0: both field disable. 1: field one enable.

2: field two enable. 3: noth fields enable.

eInputType Input device type. Please refer Table 30-4: Inpu Device Type

bFieldSwap Both field swap. It is only useful if TV decoder.

TRUE: swap

FALSE: unswap

Table 30-4: Inpu Device Type

eIntType	Value	Description
eVIDEOIN_TYPE_CCIR601	0	Input device is CCIR601
eVIDEOIN_TYPE_CCIR656	1	Input device is CCIR656

**Return Value**

None

**Example**

```

pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)VideIn_InterruptHandler,
                        &pfnOldCallback ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT); /* Enable motion detection interrupt */
pVin->SetInputType(3,
                  eVIDEOIN_TYPE_CCIR656,
                  FALSE);
pVin->SetPlanarFormat(eVIDEOIN_PLANAR_YUV422); /* planar YUV422 */
pVin->SetPipeEnable(TRUE, /* Engine enable */
                  eVIDEOIN_BOTH_PIPE_ENABLE); /* Both pipes enable */

```

***SetSensorPolarity*****Synopsis**

```

void (*SetSensorPolarity)(BOOL bVsync,
                          BOOL bHsync,
                          BOOL bPixelClk)

```

**Description**

Specified the polarity for vertical synchronization, horizontal synchronization and pixel clock signals.

**Parameter**

bVsync	TRUE: Vertical synchronization period is high level FALSE: Vertical synchronization period is low level
bHsync	TRUE: Horizontal synchronization period is high level FALSE: Horizontal synchronization period is low level
bPixelClk	TRUE: Latch data in rising edge FALSE: Latch data in falling edge

**Example**

```

pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->SetSensorPolarity(FALSE,
                        FALSE,
                        TRUE);
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)VideIn_InterruptHandler,
                        &pfnOldCallback ); /* Installed callback */

```

## SetDataFormatAndOrder

### Synopsis

```

void (*SetDataFormatAndOrder)(E_VIDEOIN_ORDER eInputOrder,
                              E_VIDEOIN_IN_FORMAT eInputFormat,
                              E_VIDEOIN_OUT_FORMAT eOutputFormat);

```

### Description

Specified the sensor input format and input order. And specified the packet output format

### Parameter

eInputOrder	Sensor data input order. Please refer Table 30-5:Input Order
eInputFormat	Sensor data format. Please refer Table 30-6:Input Format
eOutputFormat	Packet pipe output format. Please refer Table 30-7:Packet Output Format

Table 30-5:Input Order

eInputOrder	Value	Description
eVIDEOIN_IN_UYVY	0	Input order is UYVYUYVY...
eVIDEOIN_IN_YUYV	1	Input order is YUYVYUYV...
eVIDEOIN_IN_VYUY	2	Input order is VYUYVYUY...
eVIDEOIN_IN_YVYU	3	Input order is YVYUYVYU...

Table 30-6:Input Format

eInputOrder	Value	Description
eVIDEOIN_IN_YUV422	0	YUV422 format

eVIDEOIN_IN_RGB565	1	RGB565 format
--------------------	---	---------------

Table 30-7:Packet Output Format

eInputOrder	Value	Description
eVIDEOIN_OUT_YUV422	0	Packet YUV422
eVIDEOIN_OUT_ONLY_Y	1	Packet Y only
eVIDEOIN_OUT_RGB555	2	Packet RGB555
eVIDEOIN_OUT_RGB565	3	Packet RGB565

#### Example

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->SetSensorPolarity(FALSE,
                        FALSE,
                        TRUE);
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,
                        &pfnOldCallback ); /* Installed callback */
```

### SetCropWinSize

#### Synopsis

```
void (*SetCropWinSize)(UINT32 u32height, UINT32 u32width)
```

#### Description

Specified the cropping size

#### Parameter

u32height The height of cropping window.

The values should less than or equal to height of sensor dimension.

u32width The width of cropping window.

The values should less than or equal to width of sensor dimension.

#### Return Value

None

#### Example

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
```

```

pVin->InstallCallback(eVIDEOIN_VINT,      /* Frame end interrupt */
    (PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,
    &pfnOldCallback    ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT); /* Enable motion detection interrupt */
pVin->SetCropWinSize(480,
    640);
pVin->SetCropWinStartAddr(0, /* VerticalStart start position*/
    0); /* HorizontalStart start position*/

```

### ***SetCropWinStartAddr***

#### **Synopsis**

```

void (*SetCropWinStartAddr)(UINT32 u32VerticalStart,
    UINT32 u32HorizontalStart)

```

#### **Description**

Specified the cropping start position

#### **Parameter**

u32VerticalStart            The start position of Y axis.  
u32HorizontalStart The start position of X axis.

#### **Return Value**

None

#### **Example**

```

pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */
    (PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,
    &pfnOldCallback    ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT); /* Enable motion detection interrupt */
pVin->SetCropWinSize(480,
    640);
pVin->SetCropWinStartAddr(0, /* VerticalStart start position*/

```

```
0);    /* HorizontalStart start position*/
```

## ***PreviewPipeSize***

### **Synopsis**

```
void (*PreviewPipeSize)( UINT16 u16height,  
                          UINT16 u16width)
```

### **Description**

Specified the packet pipe dimension for preview

### **Parameter**

u16height	The height of packet pipe.
u16width	The width of packet pipe.

### **Return Value**

None

### **Example**

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */  
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */  
  
(PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,  
                        &pfnOldCallback    ); /* Installed callback */  
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */  
pVin->EnableInt(eVIDEOIN_MDINT);/* Enable motion detection interrupt */  
pVin->SetCropWinSize(960,  
                    1280);  
pVin->SetCropWinStartAddr(0, /* VerticalStart start position*/  
                          0); /* HorizontalStart start position*/  
pVin->PreviewPipeSize(480,  
                    640);  
pVin->EncodePipeSize(960,  
                    1280);
```

## ***EncodePipeSize***

### **Synopsis**

```
void (*EncodePipeSize)( UINT16 u16height,
```

UINT16 u16width)

#### Description

Specified the planar pipe dimension for encoding.

#### Parameter

u16height	The height of planar pipe.
u16width	The width of planar pipe.

#### Return Value

None

#### Example

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT,      /* Frame end interrupt */
    (PFN_VIDEOIN_CALLBACK)VideoIn_InterruptHandler,
    &pfnOldCallback); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT); /* Enable motion detection interrupt */
pVin->SetCropWinSize(960,
    1280);
pVin->SetCropWinStartAddr(0,              /* VerticalStart start position*/
    0); /* HorizontalStart start position*/
pVin->PreviewPipeSize(480,
    640);
pVin->EncodePipeSize(960,
    1280);
```

### ***SetStride***

#### Synopsis

```
void (*SetStride)(UINT32 u32packetstride,
    UINT32 u32planarstride)
```

#### Description

Specified the stride of packet and planar pipes.

#### Parameter

u32packetstride	The stride of packet.
u32planarstride	The stride of planar.

**Return Value**

None

**Example**

```
pVin->SetCropWinSize(960,
                     1280);
pVin->SetCropWinStartAddr(0,          /* VerticalStart start position*/
                          0);         /* HorizontalStart start position*/
pVin->PreviewPipeSize(480,
                     640);
pVin->EncodePipeSize(960,
                    1280);
pVin->SetStride(640, 1280);
```

**GetStride****Synopsis**

```
void (*GetStride)(PUINT32 pu32packetstride,
                  PUINT32 pu32planarstride)
```

**Description**

Get the stride of packet and planar pipes.

**Parameter**

pu32packetstride	The stride of packet.
pu32planarstride	The stride of planar.

**Return Value**

None

**Example**

```
UINT32 u32PacketStride, u32PlanarStride;
pVin->SetCropWinSize(960,
                     1280);
pVin->SetCropWinStartAddr(0,          /* VerticalStart start position*/
                          0);         /* HorizontalStart start position*/
pVin->PreviewPipeSize(480,
                     640);
pVin->EncodePipeSize(960,
                    1280);
```



```
pVin->GetStride(&u32PacketStride, &u32PlanarStride);
pVin->SetStride(u32PacketStride, 1280);
```

## SetPlanarFormat

### Synopsis

```
void (*SetPlanarFormat)(E_VIDEOIN_PLANAR_FORMAT
ePlanarFmt)
```

### Description

Specified the planar format.

### Parameter

ePlanarFmt      Planar format. Please reference Table 30-8 Planar Format  
Table 30-8 Planar Format

eIntType	Value	Description
eVIDEOIN_PLANAR_YUV422	0	Planar YUV422
eVIDEOIN_PLANAR_YUV420	1	Planar YUV420
eVIDEOIN_MACRO_PLANAR_YUV420	2	Planar macro block YUV420

### Return Value

None

### Example

```
/* Disable frame end interrupt */
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,
                        &pfnOldCallback ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT); /* Enable motion detection interrupt */
pVin->SetPlanarFormat(eVIDEOIN_PLANAR_YUV422); /* planar YUV422 */
pVin->SetPipeEnable(TRUE, /* Engine enable */
                    eVIDEOIN_BOTH_PIPE_ENABLE); /* Both pipes enable */
.....
```

```
pVin->DisableInt(eVIDEOIN_MDINT);    /*Enable motion detection interrupt*/
```

## SetBaseStartAddress

### Synopsis

```
INT32 (*SetBaseStartAddress)(E_VIDEOIN_PIPE ePipe,
                             E_VIDEOIN_BUFFER eBuf,
                             UINT32 u32BaseStartAddr)
```

### Description

Specified planar and packet buffer base address.

### Parameter

**ePipe**                                      eVIDEOIN\_PLANAR or eVIDEOIN\_PACKET.

Please refer Table 30-2: Pipes Type

**eBuf**                                      **Buffer number. Please refer [Table 30-9:Buffer Number](#)**

**u32BaseStartAddr**                      **Buffer base address.**

Table 30-9:Buffer Number

eIntType	Value	Description
eVIDEOIN_BUF0	0	Planar Y Buffer
eVIDEOIN_BUF1	1	Planar U Buffer
eVIDEOIN_BUF2	2	Planar V Buffer

### Example

```
/* Disable frame end interrupt */
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,
                    &pfnOldCallback    ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT);    /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT);    /* Enable motion detection interrupt */
pVin->SetPlanarFormat(eVIDEOIN_PLANAR_YUV422); /* planar YUV422 */
pVin->SetPipeEnable(TRUE, /* Engine enable */
                    eVIDEOIN_BOTH_PIPE_ENABLE); /* Both pipes enable */
```

```

/* Specified Packet Buffer */
pVin->SetBaseStartAddress(eVIDEOIN_PACKET,
                          0,
                          (UINT32)((UINT32)pu8FrameBuffer0);

/* Specified Planar Y/U/V Buffer */
pVin->SetBaseStartAddress(eVIDEOIN_PLANAR,
                          0,      /* 0 means Y Buffer */
                          (UINT32)u8PlanarFrameBuffer);

pVin->SetBaseStartAddress(eVIDEOIN_PLANAR,
                          1,      /* 1 means U Buffer */
                          (UINT32)u8PlanarFrameBuffer+

OPT_ENCODE_WIDTH*OPT_ENCODE_HEIGHT);

pVin->SetPlanarFormat(eVIDEOIN_PLANAR_YUV422);

pVin->SetBaseStartAddress(eVIDEOIN_PLANAR,
                          2,      /* 2 means V Buffer */
                          (UINT32)u8PlanarFrameBuffer+

OPT_ENCODE_WIDTH*OPT_ENCODE_HEIGHT+

OPT_ENCODE_WIDTH*OPT_ENCODE_HEIGHT/2);

```

## ***SetOperationMode***

### **Synopsis**

```
void (*SetOperationMode)( BOOL blsOneSutterMode)
```

### **Description**

Videoln engine works in one shutter mode or continuous mode.

### **Parameter**

blsOneSutterModeVideoln engine operation mode

TRUE: One shutter mode.

FALSE: Continuous mode.

### **Return Value**

None

#### Example

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
....
        pVin->SetOperationMode(TRUE);                                /* Take one frame */
while(pVin->SetOperationMode()==TRUE);/* VideoIn engine still keeps working*/
        /* VideoIn engine is stopped here */

/* Fed frame buffer to JPEG codec engine*/
....
/* Restart VideoIn engine */
pVin->SetPipeEnable(TRUE, eVIDEOIN_BOTH_PIPE_ENABLE);
```

### ***GetOperationMode***

#### Synopsis

BOOL (\*GetOperationMode)( void)

#### Description

Check VideoIn engine is stopped after set it into one shutter mde. It is only valid after set VideoIn engine into one shutter mode. If VideoIn engine operation in continuous mode, it is invalid.

#### Parameter

None

#### Return Value

TRUE: VideoIn is still keeping working

FALSE: VideoIn engine is stopped after one shutter.

#### Example

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */
....
        pVin->SetOperationMode(TRUE);                                /* Take one frame */
while(pVin->SetOperationMode()==TRUE);/* VideoIn engine still keeps working*/
        /* VideoIn engine is stopped here */

/* Fed frame buffer to JPEG codec engine*/
....
/* Restart VideoIn engine */
```

```
pVin->SetPipeEnable(TRUE, eVIDEOIN_BOTH_PIPE_ENABLE);
```

## ***SetColorEffect***

### **Synopsis**

```
INT32 (*SetColorEffect)( E_VIDEOIN_CEF eColorMode);
```

### **Description**

Set color effect mode.

### **Parameter**

eColorMode      Color effect mode

### **Return Value**

Successful

### **Example**

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */  
pVin->SetColorEffect(eVIDEOIN_CEF_POSTERIZE);  
pVin->SetColorEffectParameter(0xFC, 0xFC, 0xFC);
```

## ***SetColorEffectParameter***

### **Synopsis**

```
INT32 (*SetColorEffectParameter)(UINT8 u8YComp,  
                                  UINT8 u8UComp,  
                                  UINT8 u8VComp);
```

### **Description**

Set color effect parameter.

### **Parameter**

u8YComp Y component  
u8UComp U Component  
u8VComp V Component

### **Return Value**

Successful or E\_VIDEOIN\_WRONG\_COLOR\_PARAMETER

### **Example**

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */  
pVin->SetColorEffect(eVIDEOIN_CEF_POSTERIZE);
```

```
pVin->SetColorEffectParameter(0xFC, 0xFC, 0xFC);
```

## ***SetMotionDet***

### **Synopsis**

```
INT32 (*SetMotionDet)( BOOL bEnable,  
                        BOOL bBlockSize,  
                        BOOL bSaveMode)
```

### **Description**

Enable motion detection and set relate parameter.

### **Parameter**

bEnable	Enable or disable motion detection TRUE: Enable FALSE: Disable
bBlockSize	Block size TRUE: Block size 8x8 FALSE: Block size 16x16
bSaveMode	Save format for motion detection TRUE: 1 bit DIFF + 7 Y differential FALSE: 1 bit Diff only

### **Return Value**

None

### **Example**

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */  
/* Enable motion detection with block size 8x8 and 1 bit DIFF+7 Y differential */  
pVin-> SetMotionDet(TRUE, TRUE, TRUE);  
/* Threshold = 0x20 */  
/* Output DIFF buffer in address 2MB */  
/* Temp Y buffer in address 2.5MB */  
pVin-> SetMotionDetEx(0x20, 0x200000, 0x280000);
```

## ***SetMotionDetEx***

### **Synopsis**

```
INT32 (*SetMotionDetEx)( UINT32 u32Threshold,
```

UINT32 u32OutBuffer  
UINT32 u32LumBuffer)

#### Description

Set motion detection relate parameter.

#### Parameter

u32Threshold	Threshold between 2 motion detection frames
u32OutBuffer	DIFF output buffer address
u32LumBuffer address	Motion detection temporary Y component output buffer address

#### Return Value

None

#### Example

```
pVin->Open(48000, 24000); /* Sensor clock 24MHz */  
/* Enable motion detection with block size 8x8 and 1 bit DIFF+7 Y differential */  
pVin->SetMotionDet(TRUE, TRUE, TRUE);  
/* Threshold = 0x20 */  
/* Output DIFF buffer in address 2MB */  
/* Temporary Y buffer in address 2.5MB */  
pVin->SetMotionDetEx(0x20, 0x200000, 0x280000);
```

### ***SetStandardCCIR656***

#### Synopsis

```
void (*SetStandardCCIR656)( (BOOL blsStandard)
```

#### Description

The fuction is only used for Hinx HI-702 sensor CCIR656 mode. Because it is not standard CCIR656.

#### Parameter

blsStandard	Input device support standard CCIR656 mode or not.
TRUE:	Support standard CCIR656 mode
FALSE:	Support Hi-702 CCIR656 mide

#### Return Value

None

#### Example

```

pVin->Open(48000, 24000); /* Sensor clock 24MHz */

/* Support standard CCIR656 */

pVin-> SetStandardCCIR656 (TRUE);

```

## ***SetShadowRegister***

### **Synopsis**

```
void (*SetShadowRegister)( void)
```

### **Description**

Some register can not be updated in capturing image such as downscale, cropping start position and cropping window size and buffer start address. For the reason, there are some shadow register for those register as mention above. After update those register as above, set shadow register bit will update those registers in frame end.

### **Parameter**

None

### **Return Value**

None

### **Example**

```

pVin->Open(48000, 24000); /* Sensor clock 24MHz */
pVin->InstallCallback(eVIDEOIN_VINT, /* Frame end interrupt */

(PFN_VIDEOIN_CALLBACK)Videoin_InterruptHandler,

                                &pfnOldCallback ); /* Installed callback */
pVin->EnableInt(eVIDEOIN_VINT); /* Enable frame end interrupt */
pVin->EnableInt(eVIDEOIN_MDINT); /*Enable motion detection interrupt*/
pVin->SetCropWinSize(960,
                                1280);
pVin->SetCropWinStartAddr(0, /* VerticalStart start position*/
                                0); /* HorizontalStart start position*/
pVin->PreviewPipeSize(480,
                                640);
pVin->EncodePipeSize(960,
                                1280);
pVin->SetShadowRegister();

```



## 30.4 ERROR CODE TABLE

Code Name	Value	Description
E_VIDEOIN_INVALID_INT	0xFFFF1001	Invalid interrupt channel
E_VIDEOIN_INVALID_BUF	0xFFFF1002	Invalid buffer
E_VIDEOIN_INVALID_PIPE	0xFFFF1003	Invalid pipe
E_VIDEOIN_INVALID_COLOR_MODE	0xFFFF1004	Invalid color mode
E_VIDEOIN_WRONG_COLOR_PARAMETER	0xFFFF1005	Invalid color parameter


# 31 VPE LIBRARY

## 31.1 FEATURES

The VPE Library has the following features:

- Support format conversion
- Input format
- Y only
- Planar YUV420
- Planar YUV411
- Planar YUV422
- Planar YUV422 Transpose
- Planar YUV444
- Packet YUV422
- Packet RGB555
- Packet RGB565
- Packet RGB888
- Output format
- Packet YUV422
- Packet RGB555
- Packet RGB565
- Packet RGB888
- Support rotation
- Normal
- Right
- Left
- Upside down
- Horizontal mirror
- 180 degree
- Support MMU or Non-MMU mode.
- MMU.
- Block base mode with better memory usage.
- Non-MMU mode
- Line base mode with better performance.
- Support source and destination line offset
- Support limited on the fly mode with codec.

31.2 VPE LIBRARY DESCRIPTION



31.3 VPE LIBRARY API

*vpeOpen*

**Synopsis**

ERRCODE  
vpeOpen(void)

**Description**

Open VPE library.

**Parameter**

None

**Return Value**

Successful or error code.

**Example**

```
vpeOpen ();          /* Enable VPE clock and interrupt */
```

***vpeClose*****Synopsis**

ERRCODE vpeClose (void)

**Description**

Close VPE library.

**Parameter**

None

**Return Value**

None

**Example**

```
vpeOpen();  
...  
vpeClose();
```

***vpeInstallCallback*****Synopsis**

ERRCODE vpeInstallCallback(E\_VPE\_INT\_TYPE eIntType,  
 PFN\_VPE\_CALLBACK  
 pfnCallback,  
 PFN\_VPE\_CALLBACK\*  
 pfnOldCallback)

**Description**

Install call back function for user layer. The function let the VPE library call back to upper lay to inform user for registered interrupt event. However, page fault and page missing will be handled in library. Upper layer can ignore both

**Parameter**

eIntType Interrupt type.

Table 31-1: Interrupt type

eIntType	Value	Description
VPE_INT_COMP	0x0	Conversion complete
VPE_INT_PAGE_FAULT	0x1	Page fault if MMU on.
VPE_INT_PAGE_MISS	0x2	Page miss if MMU on.
VPE_INT_MB_COMP	0x3	Macro block complete if on the fly with codec.
VPE_INT_MB_ERR	0x4	Macro block error if on the fly with codec.
VPE_INT_DMA_ERR	0x5	DMA target abort if MMU on. The interrupt occurrence is only the page table is retrieved by OS and VPE is working. If the interrupt occurrence may memory is destroyed by VPE engine. So the application must write a signal handler for stopping the vpe engine.

pfnCallback      Function pointer for callback function.

pfnOldCallback    Old callback function.

#### Return Value

Successful or error code.

#### Example

```
/* Install call back function for conversion done */
vpeOpen();
vpeInstallCallback(VPE_INT_COMP,
                  vpeCompleteCallback,
                  &OldVpeCallback);
vpeEnableInt(VPE_INT_COMP);
vpeEnableInt(VPE_INT_PAGE_FAULT);
vpeEnableInt(VPE_INT_PAGE_MISS);
```

### ***vpeEnableInt***

#### Synopsis

ERRCODE vpeEnableInt(E\_VPE\_INT\_TYPE eIntType)

#### Description

Enable specified interrupt type.

#### Parameter

eIntType    Reference    [Please refer Table 30-3: Interrupt type](#)

Table 30-3: Interrupt type

**Return Value**

Successful or error code

**Example**

```
/* Enable frame end interrupt */  
vpeEnableInt(VPE_INT_COMP);  
vpeEnableInt(VPE_INT_PAGE_FAULT);  
vpeEnableInt(VPE_INT_PAGE_MISS);
```

***vpeDisableInt*****Synopsis**

ERRCODE vpeDisableInt(E\_VPE\_INT\_TYPE eIntType)

**Description**

Disable specified interrupt type.

**Parameter**

eIntType    Reference    [Please refer Table 30-3: Interrupt type](#)

Table 30-3: Interrupt type

**Return Value**

Successful or error code

**Example**

```
/* Disable frame end interrupt */  
vpeDisableInt(VPE_INT_COMP);
```

***vpeloctl*****Synopsis**

ERRCODE vpeloctl (UINT32 u32Cmd,

UINT32 u32Element,

UINT32 u32Arg0,

UINT32 u32Arg1)

**Description**

VPE IO control function. The function is used to set some parameters for VPE hardware IP.

**Parameter**

u32Cmd

Reference

Table 31-2: IO Control table

VPE_IOCTL_TRIGGER	(Useless)	(Useless)	(Useless)	Trigger VPE
VPE_IOCTL_CHECK_TRIGGER	(Useless)	(Useless)	(Useless)	Check VPE complete Return 0, meaning VPE complete
VPE_IOCTL_SET_MMU_ENTRY	TRUE: Enable MMU operation	TLB entry.	(Useless)	Enable VPE MMU operation.
VPE_IOCTL_SET_TLB_ENTRY	Component entry: 0~7 0 and 4: For packet or Y component 1 and 5: For U component 2 and 6: For V component 3 and 7: For destination image	(Useless)	(Useless)	Specified the component entry if page fault. <b>It has been handled by library</b>

u32Element      Reference

Table 31-2: IO Control table

VPE_IOCTL_TRIGGER	(Useless)	(Useless)	(Useless)	Trigger VPE
VPE_IOCTL_CHECK_TRIGGER	(Useless)	(Useless)	(Useless)	Check VPE complete Return 0, meaning VPE complete
VPE_IOCTL_SET_MMU_ENTRY	TRUE: Enable MMU operation	TLB entry.	(Useless)	Enable VPE MMU operation.
VPE_IOCTL_SET_TLB_ENTRY	Component entry: 0~7 0 and 4: For packet or Y component 1 and 5: For U component 2 and 6: For V component 3 and 7: For destination image	(Useless)	(Useless)	Specified the component entry if page fault. <b>It has been handled by library</b>

u32Arg0

Reference



Table 31-2: IO Control table

VPE_IOCTL_TRIGGER	(Useless)	(Useless)	(Useless)	Trigger VPE
VPE_IOCTL_CHECK_TRIGGER	(Useless)	(Useless)	(Useless)	Check VPE complete Return 0, meaning VPE complete
VPE_IOCTL_SET_MMU_ENTRY	TRUE: Enable MMU operation	TLB entry.	(Useless)	Enable VPE MMU operation.
VPE_IOCTL_SET_TLB_ENTRY	Component entry: 0~7 0 and 4: For packet or Y component 1 and 5: For U component 2 and 6: For V component 3 and 7: For destination image	(Useless)	(Useless)	Specified the component entry if page fault. <b>It has been handled by library</b>

u32Arg1

Reference

Table 31-2: IO Control table

VPE_IOCTL_TRIGGER	(Useless)	(Useless)	(Useless)	Trigger VPE
VPE_IOCTL_CHECK_TRIGGER	(Useless)	(Useless)	(Useless)	Check VPE complete Return 0, meaning VPE complete
VPE_IOCTL_SET_MMU_ENTRY	TRUE: Enable MMU operation	TLB entry.	(Useless)	Enable VPE MMU operation.
VPE_IOCTL_SET_TLB_ENTRY	Component entry: 0~7 0 and 4: For packet or Y component 1 and 5: For U component 2 and 6: For V component 3 and 7: For destination image	(Useless)	(Useless)	Specified the component entry if page fault. <b>It has been handled by library</b>

u32Cmd	u32Arg0	u32Arg1	u32Arg2	Description
VPE_IOCTL_SET_SRCBUF_ADDR	Source packet buffer start address or planar Y buffer address	Source planar U buffer start address	Source planar V buffer start address	Specified the source buffer base address
VPE_IOCTL_SET_DESTBUF_ADDR	Destination packet buffer start address.	(Useless)	(Useless)	Specified the input order, input format and output format
VPE_IOCTL_SET_SRC_OFFSET	Left offset for source image	Right offset for source image	(Useless)	Specified the left and right offset for source image.
VPE_IOCTL_SET_SRC_DIMENSION	Width of source image	Height of source image	(Useless)	Specified the dimension of source image.
VPE_IOCTL_SET_DEST_DIMENSION	Width of destination image	Height of destination image	(Useless)	Specified the dimension of destination image.
VPE_IOCTL_SET_COLOR_RANGE	Source format color range. TRUE: Y 16~235, U and V 16~240. FALSE: source format is full range.	Destination format color range. TRUE: Conversion to Y 16~235. U and V 16~240. FALSE: Full range for destination format	(Useless)	Specified color range
VPE_IOCTL_SET_FILTER	VPE_SCALE_DDA: Directly drop algorithm VPE_SCALE_BILINEAR: Bilinear algorithm	(Useless)	(Useless)	Specified upscale or downscale algorithm
VPE_IOCTL_SET_FORMAT	Source format	Destination format	(Useless)	Specified the source format and destination format

VPE_IOCTL_SET_MACRO_BLOCK	Y macro block if on the fly	X macro block if on the fly	(Useless)	It is useful if on the fly with codec.
VPE_IOCTL_HOST_OP	VPE_HOST_FRAME: Block bas mode VPE_HOST_VDEC_LINE: Line base mode	Rotation direction.	(Useless)	Specified the operation mode and ration direction.

Table 31-2: IO Control table

VPE_IOCTL_TRIGGER	(Useless)	(Useless)	(Useless)	Trigger VPE
VPE_IOCTL_CHECK_TRIGGER	(Useless)	(Useless)	(Useless)	Check VPE complete Return 0, meaning VPE complete
VPE_IOCTL_SET_MMU_ENTRY	TRUE: Enable MMU operation	TLB entry.	(Useless)	Enable VPE MMU operation.
VPE_IOCTL_SET_TLB_ENTRY	Component entry: 0~7 0 and 4: For packet or Y component 1 and 5: For U component 2 and 6: For V component 3 and 7: For destination image	(Useless)	(Useless)	Specified the component entry if page fault. <b>It has been handled by library</b>

**Return Value**

None.

**Example**

```

/* Setup hardware IP through IO ctrol */
vpelctl(VPE_IOCTL_SET_MMU_ENTRY,
        TRUE,                      // MMU Enable
        (UINT32)_mmuSectionTable, // TLB Entry
        0x0);

vpelctl(VPE_IOCTL_HOST_OP,
        VPE_HOST_FRAME,
        VPE_OP_NORMAL,
        NULL);

vpelctl(VPE_IOCTL_SET_SRCBUF_ADDR,
        (UINT32)pi8Y, /* They are virtual address if MMU on */
        (UINT32)pi8U,
        (UINT32)pi8V);

vpelctl(VPE_IOCTL_SET_FMT,
        VPE_SRC_PLANAR_YUV420, /* Src Format */
        VPE_DST_PACKET_RGB565, /* Dst Format */
        0);

vpelctl(VPE_IOCTL_SET_SRC_OFFSET,

```

```

        0,      /* Src Left offset */
        0,      /* Src right offset */
        NULL);

vpelocI(VPE_IOCTL_SET_DST_OFFSET,
        0,      /* Dst Left offset */
        0,      /* Dst right offset */
        NULL);

vpelocI(VPE_IOCTL_SET_SRC_DIMENSION,
        2048,
        1536,
        NULL);

vpelocI(VPE_IOCTL_SET_DST_DIMENSION,
        640,
        480,
        NULL);

vpelocI(VPE_IOCTL_SET_COLOR_RANGE,
        FALSE,      /* Source image is full range */
        FALSE,      /* Destination image is full range */
        NULL);

vpelocI(VPE_IOCTL_SET_FILTER,
        VPE_SCALE_BILINEAR,
        NULL,
        NULL);

vpelocI(VPE_IOCTL_SET_DST_OFFSET,
        0,          //left offset
        0,          //Right offset
        NULL);

vpelocI(VPE_IOCTL_SET_DSTBUF_ADDR,
        piDstAddr,
        NULL,
        NULL);

vpelocI(VPE_IOCTL_TRIGGER,

```

```
        NULL,  
        NULL,  
        NULL);  
do{  
    ERRCODE errcode;  
    errcode = vpeioctl(VPE_IOCTL_CHECK_TRIGGER,  
        NULL,  
        NULL,  
        NULL);  
  
    if(errcode==0)  
        break;  
}while(1);
```

## 31.4 ERROR CODE TABLE

Code Name	Value	Description
ERR_VPE_OPEN	0xFFFF1B01	VPE has been opened
ERR_VPE_CLOSE	0xFFFF1002	VPE has been closed.
ERR_VPE_SRC_FMT	0xFFFF1003	Invalid source format
ERR_VPE_DST_FMT	0xFFFF1004	Invalid destination format
ERR_VPE_OP	0xFFFF1005	Invalid operation mode
ERR_VPE_IOCTL	0xFFFF1006	Invalid ioctl
E_VPE_INVALID_INT	0xFFFF1007	Invalid interrupt

## 32 VPOST

### 32.1 VPOST OVERVIEW


#### Display Interface Controller VPOST

The VPOST consists of LCD and TV encoder controller and is used to display the video/image data to LCD device or to generate the composite signal to the TV system. The LCD timing can be synchronized with TV (NTSC/PAL non-interlace timing) or set by the LCD timing control register. The video/image data source may be come from the frame buffer, color bar or register setting. In general, the frame buffer which is stored in system memory is used as the image source.


#### How to build VPOST library

There are several panels can be supported by the VPOST library. If the current driver cannot support the selected panel, the user can add the desired one in the following procedure.


1. Prepare two functions, i.e., “vpostLCMInit\_PanelName()” and “vpostLCMDeInit\_PanelName()” in the desired panel driver.
2. In N9H26\_VPOST.c, please add the statement “vpostLCMInit\_PanelName();” and “vpostLCMDeInit\_PanelName();” to functions of vpostLCMInit () and vpostLCMDeInit(), respectively.
3. Add the panel project to the VPOST multi-project library.



4. Add the preprocessor symbol of “\_\_HAVE\_PanelName\_\_” in the panel project.



5. Give the output name for the panel.



According to above procedure, the user can create the desired library for selected panel.



## 32.2 API ENUMERATION

Name	Value	Description
E_DRVVPOST_TIMING_TYPE		
eDRVVPOST_SYNC_TV	0x0	LCD timing sync with TV
eDRVVPOST_ASYNC_TV	0x1	LCD timing not sync with TV
E_DRVVPOST_IMAGE_SOURCE		
eDRVVPOST_RESERVED	0x0	Reserved for LC source
eDRVVPOST_FRAME_BUFFER	0x1	LCD source from Frame buffer
eDRVVPOST_REGISTER_SETTING	0x2	LCD source from Register setting color
eDRVVPOST_COLOR_BAR	0x3	LCD source from internal color bar
E_DRVVPOST_IMAGE_SCALING		
eDRVVPOST_DUPLICATED	0x0	Duplicate for TV Line buffer scaling
eDRVVPOST_INTERPOLATION	0x1	Interpolation for TV line buffer scaling
E_DRVVPOST_LCM_TYPE		
eDRVVPOST_HIGH_RESOLUTINO_SYNC	0x0	High resolution LCD device type
eDRVVPOST_SYNC	0x1	Sync-type TFT LCD
eDRVVPOST_MPU	0x3	MPU-type LCD
E_DRVVPOST_MPU_TYPE		
eDRVVPOST_I80	0x0	80-series MPU interface
eDRVVPOST_M68	0x1	68-series MPU interface
E_DRVVPOST_8BIT_SYNCLCM_INTERFACE		
eDRVVPOST_SRGB_YUV422	0x0	YUV422(CCIR601) for 8bit LCD data interface
eDRVVPOST_SRGB_RGBDUMMY	0x1	RGB dummy serial for 8 bit LCD data interface
eDRVVPOST_SRGB_CCIR656	0x2	CCIR656 for 8 bit LCD data interface
eDRVVPOST_SRGB_RGBTHROUGH	0x3	Serial RGB for 8 bit LCD data interface
E_DRVVPOST_CCIR656_MODE		
eDRVVPOST_CCIR656_360	0x0	720Y 360CbCr mode for CCIR656 horizontal active width
eDRVVPOST_CCIR656_320	0x1	640Y 320CbCr mode for CCIR656 horizontal active width
E_DRVVPOST_ENDIAN		
eDRVVPOST_YUV_BIG_ENDIAN	0x0	Big Endian for YCbCr
eDRVVPOST_YUV_LITTLE_ENDIAN	0x1	Little Endian for YCbCr
E_DRVVPOST_SERAIL_SYNCLCM_COLOR_ORDER		
eDRVVPOST_SRGB_RGB	0x0	Data in RGB order
eDRVVPOST_SRGB_BGR	0x1	Data in BGR order

eDRVVPOST_SRGB_GBR	0x2	Data in GBR order
eDRVVPOST_SRGB_RBG	0x3	Data in RBG order
E_DRVVPPOST_PARALLEL_SYNCLCM_INTERFACE		
eDRVVPOST_PRGB_16BITS	0x0	16 pin parallel RGB data bus
eDRVVPOST_PRGB_18BITS	0x1	18 pin parallel RGB data bus
eDRVVPOST_PRGB_24BITS	0x2	24 pin parallel RGB data bus
E_DRVVPPOST_SYNCLCM_DATABUS		
eDRVVPOST_SYNC_8BITS	0x0	8 bit sync-type LCD
eDRVVPOST_SYNC_9BITS	0x1	9 bit sync-type LCD
eDRVVPOST_SYNC_16BITS	0x2	16 bit sync-type LCD
eDRVVPOST_SYNC_18BITS	0x3	18 bit sync-type LCD
eDRVVPOST_SYNC_24BITS	0x4	24 bit sync-type LCD
E_DRVVPPOST_MPULCM_DATABUS		
eDRVVPOST_MPU_8_8	0x0	Transfer in 8-8 format for 16 bit color in 8 bit bus width
eDRVVPOST_MPU_2_8_8	0x1	Transfer in 2-8-8 format for 18 bit color in 8 bit bus width
eDRVVPOST_MPU_6_6_6	0x2	Transfer in 6-6-6 format for 18 bit color in 8 bit bus width
eDRVVPOST_MPU_8_8_8	0x3	Transfer in 8-8-8 format for 24 bit color in 8 bit bus width
eDRVVPOST_MPU_9_9	0x4	Transfer in 9-9 format for 18 bit color in 9 bit bus width
eDRVVPOST_MPU_16	0x5	Transfer in 16 format for 16 bit color in 16 bit bus width
eDRVVPOST_MPU_16_2	0x6	Transfer in 16-2 format for 18 bit color in 16 bit bus width
eDRVVPOST_MPU_2_16	0x7	Transfer in 2-16 format for 18 bit color in 16 bit bus width
eDRVVPOST_MPU_16_8	0x8	Transfer in 16-8 format for 24 bit color in 16 bit bus width
eDRVVPOST_MPU_18	0x9	Transfer in 18 format for 18 bit color in 18 bit bus width
eDRVVPOST_MPU_18_6	0xA	Transfer in 18-6 format for 124 bit color in 18 bit bus width
eDRVVPOST_MPU_24	0xB	Transfer in 24 format for 24 bit color in 24 bit bus width
E_DRVVPPOST_FRAME_DATA_TYPE		
eDRVVPOST_FRAME_RGB555	0x0	RGB555 Frame buffer data format
eDRVVPOST_FRAME_RGB565	0x1	RGB565 Frame buffer data format
eDRVVPOST_FRAME_RGBX888	0x2	RGB_Dummy888 Frame buffer data format

eDRVVPOST_FRAME_RGB888X	0x3	RGB888_Dummy Frame buffer data format
eDRVVPOST_FRAME_CBYCRY	0x4	Cb0Y0Cr0Y1 Frame buffer data format
eDRVVPOST_FRAME_YCBYCR	0x5	Y0Cb0Y1Cr0 Frame buffer data format
eDRVVPOST_FRAME_CRYCBY	0x6	Cr0Y0Cb0Y1 Frame buffer data format
eDRVVPOST_FRAME_YCRYCB	0x7	Y0Cr0Y1Cb0 Frame buffer data format
E_DRVVPPOST_DATABUS		
eDRVVPOST_DATA_8BITS	0x0	8 bits data bus
eDRVVPOST_DATA_9BITS	0x1	9 bits data bus
eDRVVPOST_DATA_16BITS	0x2	16 bits data bus
eDRVVPOST_DATA_18BITS	0x3	18 bits data bus
eDRVVPOST_DATA_24BITS	0x4	24 bits data bus
E_DRVVPPOST_OSD_DATA_TYPE		
eDRVVPOST_OSD_RGB555	0x8	RGB555 OSD data format
eDRVVPOST_OSD_RGB565	0x9	RGB565 OSD data format
eDRVVPOST_OSD_RGBx888	0xA	RGB_Dummy888 OSD data format
eDRVVPOST_OSD_RGB888x	0xB	RGB_888Dummy OSD data format
eDRVVPOST_OSD_ARGB888	0xC	RGB_Alfa888 OSD data format
eDRVVPOST_OSD_CB0Y0CR0Y1	0x0	CB0Y0CR0Y1 OSD data format
eDRVVPOST_OSD_Y0CB0Y1CR0	0x1	Y0CB0Y1CR0 OSD data format
eDRVVPOST_OSD_CR0Y0CB0Y1	0x2	CR0Y0CB0Y1 OSD data format
eDRVVPOST_OSD_Y0CR0Y1CB0	0x3	Y0CR0Y1CB0 OSD data format
eDRVVPOST_OSD_Y1CR0Y0CB0	0x4	Y1CR0Y0CB0 OSD data format
eDRVVPOST_OSD_CR0Y1CB0Y0	0x5	CR0Y1CB0Y0 OSD data format
eDRVVPOST_OSD_Y1CB0Y0CR0	0x6	Y1CB0Y0CR0 OSD data format
eDRVVPOST_OSD_CB0Y1CR0Y0	0x7	CB0Y1CR0Y0 OSD data format
E_DRVVPPOST_OSD_TRANSPARENT_DATA_TYPE		
eDRVVPOST_OSD_TRANSPARENT_RGB565	0x0	RGB565 transparent color format
eDRVVPOST_OSD_TRANSPARENT_YUV	0x1	YUV transparent color format
eDRVVPOST_OSD_TRANSPARENT_RGB888	0x2	RGB888 transparent color format

### 32.3 API STRUCTURE

Table 32-1: LCDFORMAT\_EX structure

Field	Type	Description
ucVASrcFormat	UINT32	User input Display source format

nScreenWidth	UINT32	Driver output LCD width
nScreenHeight	UINT32	Driver output LCD height
nFrameBufferSize	UINT32	Driver output Frame buffer size
ucROT90	UINT8	Rotate 90 degree or not

Table 32-2: S\_DRVVPPOST\_SYNCLCM\_HTIMING structure

Field	Type	Description
u8PulseWidth	UINT8	Horizontal sync pulse width
u8BackPorch	UINT8	Horizontal back porch
u8FrontPorch	UINT8	Horizontal front porch

Table 32-3: S\_DRVVPPOST\_SYNCLCM\_VTIMING structure

Field	Type	Description
u8PulseWidth	UINT8	Vertical sync pulse width
u8BackPorch	UINT8	Vertical back porch
u8FrontPorch	UINT8	Vertical front porch

Table 32-4: S\_DRVVPPOST\_SYNCLCM\_WINDOW structure

Field	Type	Description
u16ClockPerLine	UINT16	Specify the number of pixel clock in each line or row of screen
u16LinePerPanel	UINT16	Specify the number of active lines per screen
u16PixelPerLine	UINT16	Specify the number of pixel in each line or row of screen

Table 32-5: S\_DRVVPPOST\_SYNCLCM\_POLARITY structure

Field	Type	Description
blsVsyncActiveLow	BOOL	Vsync polarity
blsHsyncActiveLow	BOOL	Hsync polarity
blsVDenActiveLow	BOOL	VDEN polarity
blsDClockRisingEdge	BOOL	Clock polarity

Table 32-6: S\_DRVVPPOST\_MPULCM\_WINDOW structure

Field	Type	Description
u16LinePerPanel	BOOL	Specify the number of active lines per screen
u16PixelPerLine	BOOL	Specify the number of pixel in each line or row of screen

Table 32-7: S\_DRVPOST\_MPULCM\_WINDOW structure

Field	Type	Description
u8CSnF2DCt	UINT8	CSn fall edge to Data change clock counter
u8WRnR2CSnRt	UINT8	WRn rising edge to CSn rising clock counter
u8WRnLWt	UINT8	WR Low pulse clock counter
u8CSnF2WRnFt	UINT8	Csn fall edge To WR falling edge clock counter

Table 32-8: S\_DRVPOST\_MPULCM\_TIMING structure

Field	Type	Description
blsSyncWithTV	BOOL	MPU timing sync with TV
blsVsyncSignalOut	BOOL	Specify MPU FrameMark pin as input or output pin
blsFrameMarkSignalIn	BOOL	Frame Mark detection disable or enable
eSource	E_DRVPOST_IMAGE_SOURCE	Specify the image source
eType	E_DRVPOST_LCM_TYPE	Specify the LCM type
eMPUType	E_DRVPOST_MPU_TYPE	Specify the MPU type
eBus	E_DRVPOST_MPULCM_DATABUS	Specify the MPU data bus
psWindow	S_DRVPOST_MPULCM_WINDOW*	Specify MPU window
psTiming	S_DRVPOST_MPULCM_TIMING*	Specify MPU timing

Table 32-9: S\_DRVPOST\_OSD\_SIZE structure

Field	Type	Description
u16VSize	UINT16	Specify OSD vertical size
u16HSize	UINT16	Specify OSD horizontal size

Table 32-10: S\_DRVPOST\_OSD\_POS structure

Field	Type	Description
u16VStart_1 <sup>st</sup>	UINT16	Specify 1 <sup>st</sup> OSD bar vertical start position

u16VEnd_1 <sup>st</sup>	UINT16	Specify 1 <sup>st</sup> OSD bar vertical end position
u16VOffset_2 <sup>nd</sup>	UINT16	Specify 2 <sup>nd</sup> OSD bar vertical offset position (2nd_Start – 1st_End)
u16HStart_1 <sup>st</sup>	UINT16	Specify 1 <sup>st</sup> OSD bar horizontal start position
u16HEnd_1 <sup>st</sup>	UINT16	Specify 1 <sup>st</sup> OSD bar horizontal end position
u16HOffset_2 <sup>nd</sup>	UINT16	Specify 2 <sup>nd</sup> OSD bar horizontal offset position (2nd_Start – 1st_End)

Table 32-11: S\_DRVPOST\_OSD\_CTRL structure

Field	Type	Description
blsOSDEnabled	BOOL	Specify OSD to be enabled or disabled
u32Address	UINT32	Specify the beginning address of OSD buffer
eType	E_DRVPOST_OSD_DATA_TYPE	Specify OSD data type
psSize	S_DRVPOST_OSD_SIZE*	Specify the data pointer of OSD size
psPos	S_DRVPOST_OSD_POS*	Specify the data pointer of OSD position

## 32.4 API FUNCTIONS

### ***vpostGetFrameBuffer***

#### **Synopsis**

```
void *vpostGetFrameBuffer (void);
```

#### **Description**

Get the display frame buffer address

#### **Parameter**

None

#### **Return Value**

Display frame buffer address.

#### **Example**

None.

### ***vpostSetFrameBuffer***

#### **Synopsis**

```
void vpostSetFrameBuffer (  
    UINT32 pFramebuf
```

);

**Description**

Set the display frame buffer address

**Parameter**

UINT32 pFramebuf

Given frame buffer address

**Return Value**

None.

**Example**

None.

***vpostLCMInit***

**Synopsis**

INT32

vpostLCMInit (

PLCDFORMATEX plcdformatex,

UINT32 \*pFramebuf

);

**Description**

Initialize the VPOST display device

**Parameter**

**plcdformatex [in]**

Input the lcd format information to initialize.

**pFramebuf [in]**

Input the frame buffer address

**Return Value**

Successful: Success

ERRCODE: Error

**Example**

```
__align(32) UINT8 Vpost_Frame[480*272*2];  
lcdFormat.ucVASrcFormat = DRVVPOST_FRAME_RGB565;  
lcdFormat.nScreenWidth = 480;  
lcdFormat.nScreenHeight = 272;
```

```
vpostLCMInit(&lcdFormat, (UINT32*)Vpost_Frame);
```

### ***vpostLCMDeinit***

#### **Synopsis**

INT32  
vpostLCMDeinit (void);

#### **Description**

The function will stop VPOST operation and turn off VPOST clock.

#### **Parameter**

None

#### **Return Value**

Successful: Success  
ERRCODE: Error

#### **Example**

None.

### ***vpostEnaBacklight***

#### **Synopsis**

void vpostEnaBacklight (void);

#### **Description**

The function enables the backlight led.

#### **Parameter**

None

#### **Return Value**

None

#### **Example**

None

### ***vpostSetOSD\_Enable***

#### **Synopsis**

void vpostSetOSD\_Enable (void);

#### **Description**

The function enables the OSD feature.



**Parameter**

None

**Return Value**

None

**Example**

None

***vpostSetOSD\_Disable*****Synopsis**

```
void vpostSetOSD_Disable (void);
```

**Description**

The function disables the OSD feature.

**Parameter**

None

**Return Value**

None

**Example**

None

***vpostSetOSD\_Size*****Synopsis**

```
void vpostSetOSD_Size (  
    S_DRVPOST_OSD_SIZE* psSize  
);
```

**Description**

The function sets the OSD size.

**Parameter**

**psSize [in]**

Input the OSD size pointer.

**Return Value**

None

**Example**

None

### ***vpostSetOSD\_Pos***

#### **Synopsis**

```
void vpostSetOSD_Pos (  
    S_DRVVPOST_OSD_POS* psPos  
);
```

#### **Description**

The function sets the OSD position.

#### **Parameter**

**psPos [in]**  
Input the OSD position pointer.

#### **Return Value**

None

#### **Example**

None

### ***vpostSetOSD\_DataType***

#### **Synopsis**

```
void vpostSetOSD_DataType (  
    E_DRVVPOST_OSD_DATA_TYPE eType  
);
```

#### **Description**

The function sets the OSD data type.

#### **Parameter**

**eType [in]**  
Set the OSD data type.

#### **Return Value**

None

#### **Example**

None

### ***vpostSetOSD\_Transparent\_Enable***

#### **Synopsis**

```
void vpostSetOSD_Transparent_Enable (void);
```

**Description**

The function enables the OSD transparent feature.

**Parameter**

None

**Return Value**

None

**Example**

None

***vpostSetOSD\_Transparent\_Disable*****Synopsis**

```
void vpostSetOSD_Transparent_Disable (void);
```

**Description**

The function disables the OSD transparent feature.

**Parameter**

None

**Return Value**

None

**Example**

None

***vpostSetOSD\_Transparent*****Synopsis**

```
void vpostSetOSD_Transparent (  
    E_DRVPOST_OSD_TRANSPARENT_DATA_TYPE eType  
    UINT32 u32Pattern  
);
```

**Description**

The function sets the OSD transparent data type and pattern.

**Parameter**

**eType [in]**

Set the OSD transparent data type.

**u32Pattern [in]**

Given the transparent pattern.

**Return Value**

None

**Example**

None

***vpostSetOSD\_BaseAddress*****Synopsis**

```
void vpostSetOSD_BaseAddress (  
    UINT32 u32BaseAddress  
);
```

**Description**

The function sets the OSD buffer base address.

**Parameter**

**u32BaseAddress [in]**

Given the OSD base address.

**Return Value**

None

**Example**

None

**32.5 ERROR CODE TABLE**

Code Name	Value	Description
ERR_NULL_BUF	0xFFF06004	memory location error
ERR_NO_DEVICE	0xFFF06005	No device error
ERR_BAD_PARAMETER	0xFFF06006	Bad parameter error
ERR_POWER_STATE	0xFFF06007	Power state control error

**33 REVISION HISTORY**

Version	Date	Description
V1.0	May , 2018	<ul style="list-style-type: none"><li>Created</li></ul>

### **Important Notice**

**Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, “Insecure Usage”.**

**Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.**

**All Insecure Usage shall be made at customer’s risk, and in the event that third parties lay claims to Nuvoton as a result of customer’s Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.**

---

*Please note that all data and specifications are subject to change without notice.  
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*