

# Python, R, MATLAB, Scilab & GNU Octave API for GNATS Linux Distribution

Updated: 04.20, 2022

## GNATSClient API

No.	Type	Method and Description
1	EntityInterface	<b>getEntityInterface()</b> Returns a reference to the EntityInterface.
2	EnvironmentInterface	<b>getEnvironmentInterface()</b> Returns a reference to the EnvironmentInterface.
3	EquipmentInterface	<b>getEquipmentInterface()</b> Returns a reference to the EquipmentInterface.
4	RiskMeasuresInterface	<b>getRiskMeasuresInterface()</b> Returns a reference to the RiskMeasuresInterface.
5	RiskMeasuresInterface	<b>getRiskMInterface()</b> Returns a reference to the RiskMeasuresInterface, an alias for Scilab platform (Due to syntax restrictions).
6	SimulationInterface	<b>getSimulationInterface()</b> Returns a reference to the SimulationInterface.
7	GNATSClient	<b>start()</b> Initialize GNATS Client and returns an instance.
8	void	<b>Stop()</b> Stop GNATS Client functionality.

## SimulationInterface API

No.	Type	Method and Description
1	void	<b>clear_trajectory()</b> Cleanup the trajectory data.
2	float	<b>get_curr_sim_time()</b> Get the current simulation timestamp.
3	long	<b>get_sim_id()</b> Get the simulation id.
4	int	<b>get_runtime_sim_status()</b> Get the runtime status of the trajectory propagation. Value definition: GNATS_SIMULATION_STATUS_READY = 0 GNATS_SIMULATION_STATUS_START = 1 GNATS_SIMULATION_STATUS_PAUSE = 2 GNATS_SIMULATION_STATUS_RESUME = 3 GNATS_SIMULATION_STATUS_STOP = 4 GNATS_SIMULATION_STATUS_ENDED = 5 When the trajectory propagation finishes, the status will be changed to GNATS_SIMULATION_STATUS_ENDED.
5	void	<b>pause()</b> Pause the trajectory propagation process. This function is disabled in real-time simulation mode.
6	void	<b>resume()</b>

		Resume the trajectory propagation process.
7	void	<b>resume(long t_duration)</b> Resume the trajectory propagation process and process data for a specified time duration (in seconds).
8	int	<b>setupSimulation(int t_total_propagation_period, int t_step)</b> Setup the trajectory propagation process.  Description of the arguments: t_total_propagation_period: Total period of time of propagation in integer seconds. t_step: Time step (in integer seconds).
9	int	<b>setupSimulation(float t_total_propagation_period, float t_step)</b> Setup the trajectory propagation process.  Description of the arguments: t_total_propagation_period: Total period of time of propagation in decimal seconds. t_step: Time step in decimal seconds.
10	int	<b>setupSimulation(int t_total_propagation_period, int t_step_surface, int t_step_terminal, int t_step_airborne)</b> Setup the trajectory propagation process.  Description of the arguments: t_total_propagation_period: Total period of time of propagation in integer seconds. t_step_surface: Time step for trajectory propagation on the surface (origin/destination airports) in integer seconds. t_step_terminal: Time step for terminal area (from airport altitude to 10000 feet) trajectory propagation in integer seconds. t_step_surface: Time step for airborne (altitude above 10000 feet) trajectory propagation in integer seconds.
11	int	<b>setupSimulation(float t_total_propagation_period, float t_step_surface, float t_step_terminal, float t_step_airborne)</b> Setup the trajectory propagation process.  Description of the arguments: t_total_propagation_period: Total period of time of propagation in decimal seconds. t_step_surface: Time step for trajectory propagation on the surface (origin/destination airports) in decimal seconds. t_step_terminal: Time step for terminal area (from airport altitude to 10000 feet) trajectory propagation in decimal seconds. t_step_surface: Time step for airborne (altitude above 10000 feet) trajectory propagation in decimal seconds.
12	void	<b>start()</b>

		Start the trajectory propagation process.
13	void	<b>start(long t_duration)</b> Start the trajectory propagation process for specified duration, in seconds.
14	void	<b>startRealTime()</b> Start the real-time trajectory propagation.  GNATS Server runs trajectory propagation with 30-second time step, synchronized with real-time clock.
15	void	<b>startRealTime_singleUser()</b> Start the real-time trajectory propagation while in single-user mode.  GNATS Server runs trajectory propagation with a 30-second time step, synchronized with real-time clock. Aircraft state data can be imported from an external aircraft simulator to the GNATS Server. Please refer to the <i>XPlane™</i> simulation example for the details.
16	void	<b>stop()</b>  Stop the trajectory propagation process.
17	void	<b>write_trajectories(String output_file)</b> Write trajectory data into a file. File formats supported: .csv, .kml, .xml
18	void	<b>request_aircraft(String ac_id)</b> Request aircraft from GNATS Server which is the administrator for multi-user simulation. The aircraft corresponding to the callsign given in the argument ac_id will be assigned to the client based on First-Come-First-Served policy.
19	void	<b>request_groundVehicle(String gv_id)</b> Request ground vehicles from GNATS Server which is the administrator for multi-user simulation. The ground vehicle corresponding to the identification given in the argument gv_id will be assigned to the client based on First-Come-First-Served policy. This function will not work due to absence of the CIFP file downloaded from the Federal Aviation Administration.
20	void	<b>externalAircraft_create_trajectory_profile(</b> <b>String ac_id,</b> <b>String ac_type,</b> <b>String origin_airport,</b> <b>String destination_airport,</b> <b>float cruise_altitude_ft,</b> <b>float cruise_tas_knots,</b> <b>double latitude_deg,</b> <b>double longitude_deg,</b> <b>double altitude_ft,</b> <b>double rocd_fps,</b> <b>double tas_knots,</b> <b>double course_deg,</b> <b>String flight_phase)</b>

		Create the trajectory profile and set the initial state of an external aircraft in GNATS.
21	void	<b>externalAircraft_inject_trajectory_state_data(</b> String ac_id, double latitude_deg, double longitude_deg, double altitude_ft, double rocd_fps, double tas_knots, double course_deg, String flight_phase, long timestamp_utc_millisec)  Send external aircraft state data from the client to the server.

#### Simulation Status Enum Values

Values
<b>GNATS_SIMULATION_STATUS_READY</b> <b>GNATS_SIMULATION_STATUS_START</b> <b>GNATS_SIMULATION_STATUS_PAUSE</b> <b>GNATS_SIMULATION_STATUS_RESUME</b> <b>GNATS_SIMULATION_STATUS_STOP</b> <b>GNATS_SIMULATION_STATUS_ENDED</b>

#### EquipmentInterface API

No.	Type	Method and Description
1	AircraftInterface	<b>getAircraftInterface()</b> Returns a reference to the AircraftInterface.
2	GroundVehicleInterface	<b>getGroundVehicleInterface()</b> Returns a reference to the GroundVehicleInterface.
3	CNSInterface	<b>getCNSInterface()</b> Returns a reference to the CNSInterface. (Communication & Navigation Systems)
4	ADBDDataInterface	<b>getADBDDataInterface()</b> Returns a reference to the ADBDataInterface. (Aircraft Database)

#### AircraftInterface API

No.	Type	Method and Description
1	int	<b>load_aircraft(String trx_file, String mfl_file)</b> Load aircraft data.
2	boolean	<b>validate_flight_plan_record(String string_track, String string_fp_route, int mfl_ft)</b> Validator of flight plan record.
3	int	<b>release_aircraft()</b>

		Cleanup aircraft data.
4	String[]	<b>getAircraftIds(float minLatitude, float maxLatitude, float minLongitude, float maxLongitude, float minAltitude_ft, float maxAltitude_ft)</b> Get IDs of all aircraft within the min/max range of latitude, longitude and/or altitude ranges.
5	String[]	<b>getAllAircraftId()</b> Get the complete list of all aircraft IDs in the GNATS simulation.
6	Aircraft	<b>select_aircraft(String aircraft_id)</b> Get an aircraft object with aircraft ID.
7	int	<b>synchronize_aircraft_to_server(Aircraft aircraft)</b> Push aircraft object to the server and synchronize the data. The return value indicates the server operation response: 0 is success. 1 indicates error.

#### Aircraft Instance API

No.	Type	Method and Description
1	int	<b>delay_departure(int seconds)</b> Postpone the departure time of the current aircraft by certain seconds. If the aircraft has already departed, the departure time will not be changed.
2	String	<b>getAcid()</b> Get aircraft ID. Example: UA555
3	float	<b>getAltitude_ft()</b> Get the current altitude in feet.
4	float	<b>getCruise_alt_ft()</b> Get the cruise altitude in feet.
5	float	<b>getCruise_tas_knots()</b> Get cruise speed.
6	float	<b>getDeparture_time_sec()</b> Get departure time in seconds.
7	float	<b>getDestination_airport_elevation_ft()</b> Get the elevation of the destination airport.
8	int	<b>getFlight_phase()</b> Get the current flight phase. Flight phase is presented as an integer in the range 1-25. Please refer to “Flight Phase Enum Values” for the definition of each phase.
9	float[]	<b>getFlight_plan_latitude_array()</b> Get the latitude array of the flight plan.
10	int	<b>getFlight_plan_length()</b> Get the number of records in the flight plan.
11	float[]	<b>getFlight_plan_longitude_array()</b> Get the longitude array of the flight plan.
12	String[]	<b>getFlight_plan_waypoint_name_array()</b> Get the array of waypoint names in the flight plan.
13	String[]	<b>getFlight_plan_alt_desc_array()</b> Get the array of flight plan altitude constraints description. Refer to ARINC 424-18 Section 5.29 for details.
14	double[]	<b>getFlight_plan_alt_1_array()</b>

		Get the array of flight plan altitude first bound. Refer to ARINC 424-18 Section 5.30 for details.
15	double[]	<b>getFlight_plan_alt_2_array()</b> Get the array of flight plan altitude second bound. Refer to ARINC 424-18 Section 5.30 for details.
16	double[]	<b>getFlight_plan_speed_limit_array()</b> Get the array of flight plan speed limits. Refer to ARINC 424-18 Section 5.72 for details.
17	String[]	<b>getFlight_plan_speed_limit_desc_array()</b> Get the array of flight plan speed limit constraints description. Refer to ARINC 424-18 Section 5.261 for details.
18	float	<b>getFpa_rad()</b> Get the current flight path angle, radians.
19	float	<b>getCourse_rad()</b> Get the current course angle, radians.
20	int	<b>getLanded_flag()</b> Get the flag value indicating whether the aircraft has landed.
21	float	<b>getLatitude_deg()</b> Get the current latitude, degrees.
22	float	<b>getLongitude_deg()</b> Get the current longitude, degrees.
23	float	<b>getOrigin_airport_elevation_ft()</b> Get the elevation of the origin airport, feet.
24	float	<b>getRocd_fps()</b> Get the rate of climb or descent in feet per second.
25	int	<b>getSector_index()</b> Get the current sector index.
26	int	<b>getTarget_waypoint_index()</b> Get the array index of the target waypoint in the flight plan
27	String	<b>getTarget_waypoint_name()</b> Get the target waypoint name.
28	float	<b>getTas_knots()</b> Get the current speed.
29	int	<b>getToc_index()</b> Get the flight plan array index of the top-of-climb waypoint.
30	int	<b>getTod_index()</b> Get the flight plan array index of the top-of-descent waypoint.
31	void	<b>setAltitude_ft(float altitude_ft)</b> Set a new value of altitude in feet.
32	void	<b>setCruise_alt_ft(float cruise_alt_ft)</b> Set a new value of cruise altitude in feet.
33	void	<b>setCruise_tas_knots(float cruise_tas_knots)</b> Set a new value of cruise speed.
34	void	<b>setFlight_plan_latitude_deg(int index, float latitude_deg)</b> Set the latitude of the n-th waypoint.
35	void	<b>setFlight_plan_longitude_deg(int index, float longitude_deg)</b>

		Set the longitude of the n-th waypoint.
36	void	<b>setCourse_rad(float course_rad)</b> Set a new value of course angle.
37	void	<b>setLatitude_deg(float latitude_deg)</b> Set a new value of latitude.
38	void	<b>setLongitude_deg(float longitude_deg)</b> Set a new value of longitude.
39	void	<b>setRocd_fps(float rocd_fps)</b> Set a new value of rate of climb or descent in feet per second.
40	void	<b>setTarget_waypoint_latitude_deg(float latitude_deg)</b> Set a new value for the target (Next) waypoint latitude.
41	void	<b>setTarget_waypoint_longitude_deg(float longitude_deg)</b> Set a new value for the target (next) waypoint longitude.
42	void	<b>setTas_knots(float tas_knots)</b> Set a new value for speed, in knots.

#### GroundVehicle Interface API

No.	Type	Method and Description
1	int	<b>load_groundVehicle(String trx_file)</b> Load all the ground vehicles from the TRX file. This function will not work for airports outside the continental US.
2	int	<b>release_groundVehicle()</b> Clear all ground vehicle drive plan data. This function will not work for airports outside continental US.
3	String[]	<b>getAllGroundVehicleIds()</b> Get callsigns of all ground vehicles loaded in GNATS. This function will not work for airports outside continental US.
4	GroundVehicle	<b>select_groundVehicle(String groundVehicleId)</b> Get GroundVehicle object for a given vehicle callsign. This function will not work for airports outside continental US.
5	String[]	<b>GetAssignedGroundVehicleIds()</b> Get IDs of ground vehicles which are assigned to current session user. This function will not work for airports outside continental US.
6	String[]	<b>getAssignedGroundVehicleIds(String username)</b> Get IDs of ground vehicles which are assigned to the user. This function will not work for airports outside continental US.
7	int	<b>externalGroundVehicle_create_trajectory_profile(String groundVehicleId, String aircraft, String airport, float latitude, float longitude, float speed, float course)</b> Create profile of an external ground vehicle. This function will not work for airports outside continental US.
8	int	<b>externalGroundVehicle_inject_trajectory_state_data(String groundVehicleId, String aircraftInService, float latitude, float longitude, float speed, float course)</b> Update profile of an existing external ground vehicle. This function will not work for airports outside continental US.

## GroundVehicle Instance API

No.	Type	Method and Description
1	String	<b>getGvid()</b> Get ground vehicle ID. This function will not work for airports outside continental US.
2	String	<b>getAirportId()</b> Get airport ICAO code of the ground vehicle. This function will not work for airports outside continental US.
3	String	<b>getAircraftInService()</b> Get aircraft ID being serviced by ground vehicle. This function will not work for airports outside continental US.
4	boolean	<b>getFlag_external_groundvehicle()</b> Get the flag to determine if the ground vehicle is external. TRUE if the ground vehicle is external. This function will not work for airports outside continental US.
5	String	<b>getAssigned_user()</b> Get the assigned user. This function will not work for airports outside continental US.
6	float	<b>getLatitude()</b> Get the current latitude, degrees. This function will not work for airports outside continental US.
7	void	<b>setLatitude(float latitude)</b> Set the new value to current latitude, degrees. This function will not work for airports outside continental US.
8	float	<b>getLongitude()</b> Get the current longitude, degrees. This function will not work for airports outside continental US.
9	void	<b>setLongitude(float longitude)</b> Set the new value to current longitude, degrees. This function will not work for airports outside continental US.
10	float	<b>getAltitude()</b> Get the current altitude in feet. This function will not work for airports outside continental US.
11	float	<b>getSpeed()</b> Get the current speed. This function will not work for airports outside continental US.
12	void	<b>setSpeed(float speed)</b> Set the current speed. This function will not work for airports outside continental US.
13	float	<b>getCourse()</b> Get the current course. This function will not work for airports outside continental US.
14	void	<b>setCourse(float course)</b> Set the new value to the current course angle. This function will not work for airports outside continental US.
15	float	<b>getDeparture_time()</b> Get the departure time. This function will not work for airports outside



		continental US.
16	float[]	<b>getDrive_plan_latitude_array()</b> Get the array of latitude of the drive plan. This function will not work for airports outside continental US.
17	float[]	<b>getDrive_plan_longitude_array()</b> Get the array of longitude of the drive plan. This function will not work for airports outside continental US.
18	int	<b>getDrive_plan_length()</b> Get the number of records in the drive plan. This function will not work for airports outside continental US.
19	String[]	<b>getDrive_plan_waypoint_name_array()</b> Get the array of waypoint names of the drive plan. This function will not work for airports outside continental US.
20	int	<b>getTarget_waypoint_index()</b> Get the array index of the drive plan data corresponding to the target waypoint. This function will not work for airports outside continental US.
21	String	<b>getTarget_waypoint_name()</b> Get the name of the drive plan data corresponding to the target waypoint. This function will not work for airports outside continental US.
22	void	<b>setDrive_plan_latitude(int index, float latitude)</b> Set the latitude of the n-th drive plan waypoint, degrees. This function will not work for airports outside continental US.
23	void	<b>setDrive_plan_longitude(int index, float longitude)</b> Set the longitude of the n-th drive plan waypoint, degrees. This function will not work for airports outside continental US.

#### CNSInterface API

No.	Type	Method and Description
1	double[]	<b>getLineOfSight(double observerLat, double observerLon, double observerAlt, double targetLat, double targetLon, double targetAlt)</b> Computes the line of sight between source and target, returns range, azimuth, and elevation along with any masking due to terrain or earth's curvature. observerLat: Latitude at the observer's location, degrees. observerLon: Longitude of observer's location, degrees. observerAlt: Observer's altitude, feet. targetLat: Latitude at the target's location, feet. targetLon: Longitude of target's position, feet. targetAlt: Altitude of target, feet. Array as (Range (ft), Azimuth (degree), Elevation(degree), Masking (boolean)) of target relative to the observer. The Masking boolean can assume values: 0: No Masking, 1: Terrain Masking, 2: Masking due to the curvature of Earth.
2	int	<b>setNavigationLocationError(String aircraftId, String parameter, double bias, double drift, double scaleFactor, double noiseVariance, int scope)</b> Sets Latitude/Longitude navigation errors for aircraft Navigation System. parameter: String containing "LATITUDE" or "LONGITUDE". bias: Bias to be applied to the original value.

		<p>drift: Drift to be applied to original value multiplied by flight time.</p> <p>scaleFactor: scale factor error that would lead to erroneous instrument values.</p> <p>noiseVariance: Variance of noise to be applied, assuming zero mean Gaussian distribution.</p> <p>scope: 0 for errors to reflect on flight deck systems only, 1 to include errors in the ADS-B transmission of the aircraft states.</p>
3	int	<p><b>setNavigationAltitudeError(String aircraftId, double bias, double noiseVariance, int scope)</b></p> <p>Sets altitude errors in the aircraft Navigation System.</p> <p>bias: Bias to be applied to the original value.</p> <p>noiseVariance: Variance of noise to be applied, assuming zero mean Gaussian distribution.</p> <p>scope: 0 for errors to reflect on flight deck systems only, 1 to include errors in the ADS-B transmission of the aircraft altitude.</p>
4	int	<p><b>setRadarError(String airportId, String parameter, double originalValue, double bias, double noiseVariance, int scope)</b></p> <p>Applies range, elevation, azimuth errors to the ground radar at an airport.</p> <p>airportId: ICAO code of airport</p> <p>parameter: String containing RANGE, ELEVATION, or AZIMUTH</p> <p>originalValue: The initial true value of the parameter</p> <p>bias: Bias to be applied to the original value.</p> <p>noiseVariance: Variance of noise to be applied, assuming zero mean Gaussian distribution.</p> <p>scope: 0 for errors in the ground systems only, 1 to include transmission to aircraft.</p>

#### ADBDDataInterface API

No.	Type	Method and Description
1	double	<p><b>getADB_cruiseTas(String ac_type, double altitude_ft)</b></p> <p>Get cruise speed.</p>
2	double	<p><b>getADB_climbRate_fpm(String ac_type, double flight_level, String adb_mass)</b></p> <p>Get climb rate in feet per minute.</p>
3	double	<p><b>getADB_climbTas(String ac_type, double altitude_ft)</b></p> <p>Get climb speed.</p>
4	double	<p><b>GetADB_descentRate_fpm(String ac_type, double flight_level, String adb_mass)</b></p> <p>Get descent rate in feet per minute.</p>
5	double	<p><b>getADB_descentTas(String ac_type, double altitude_ft)</b></p> <p>Get descent speed.</p>
6	String[]	<p><b>getADB_aircraftTypesAvailable()</b></p> <p>Get a string array of aircraft under ADB (depending on if ULI or Open version of GNATS)</p>

## Flight Phase Enum Values

### Values

**FLIGHT\_PHASE\_ORIGIN\_GATE**

**FLIGHT\_PHASE\_PUSHBACK**

**FLIGHT\_PHASE\_RAMP\_DEPARTING**

**FLIGHT\_PHASE\_TAXI\_DEPARTING**

**FLIGHT\_PHASE\_RUNWAY\_THRESHOLD\_DEPARTING**

**FLIGHT\_PHASE\_TAKEOFF**

**FLIGHT\_PHASE\_CLIMBOUT**

**FLIGHT\_PHASE\_HOLD\_IN\_DEPARTURE\_PATTERN**

**FLIGHT\_PHASE\_CLIMB\_TO\_CRUISE\_ALTITUDE**

**FLIGHT\_PHASE\_TOP\_OF\_CLIMB**

**FLIGHT\_PHASE\_CRUISE**

**FLIGHT\_PHASE\_HOLD\_IN\_ENROUTE\_PATTERN**

**FLIGHT\_PHASE\_TOP\_OF\_DESCENT**

**FLIGHT\_PHASE\_INITIAL\_DESCENT**

**FLIGHT\_PHASE\_HOLD\_IN\_ARRIVAL\_PATTERN**

**FLIGHT\_PHASE\_APPROACH**

**FLIGHT\_PHASE\_FINAL\_APPROACH**

**FLIGHT\_PHASE\_GO\_AROUND**

**FLIGHT\_PHASE\_TOUCHDOWN**

**FLIGHT\_PHASE\_LAND**

**FLIGHT\_PHASE\_EXIT\_RUNWAY**

**FLIGHT\_PHASE\_TAXI\_ARRIVING**

**FLIGHT\_PHASE\_RUNWAY\_CROSSING**

**FLIGHT\_PHASE\_RAMP\_ARRIVING**

**FLIGHT\_PHASE\_DESTINATION\_GATE**

**FLIGHT\_PHASE\_LANDED**

#### EnvironmentInterface API

No.	Type	Method and Description
1	void	<b>load_rap(String wind_dir)</b> Load wind RAP file. RAP: NOAA Rapid Refresh wind data
2	int	<b>release_rap()</b> Clean up the RAP data.
3	AirportInterface	<b>getAirportInterface()</b> Returns a reference to the AirportInterface.
4	TerrainInterface	<b>getTerrainInterface()</b> Returns a reference to the TerrainInterface.
5	TerminalAreaInterface	<b>getTerminalAreaInterface()</b> Returns a reference to the TerminalAreaInterface.
6	WeatherInterface	<b>getWeatherInterface()</b> Returns a reference to the WeatherInterface.
7	String[]	<b>getCenterCodes()</b> Returns a String array of all center codes.
8	String	<b>getCurrentCenter(String aircraftId)</b> Returns the Air Traffic Control Center (ARTCC) where the given aircraft is located.
9	String[]	<b>getFixesInCenter(String centerId)</b> Returns a String array of all fixes in a center.

#### AirportInterface API

No.	Type	Method and Description
1	Airport	<b>select_airport(String airport_code)</b> Get an Airport object instance by a given airport code. This function will not work for airports outside continental US.
2	String	<b>getArrivalAirport(String acid)</b> Get the arrival airport of the requested aircraft. This function will not work for airports outside continental US.
3	String	<b>getDepartureAirport(String acid)</b> Get the departure airport for the requested aircraft. This function will not work for airports outside continental US.
4	double[]	<b>getLocation(String airport_code)</b> Get the latitude and longitude of the requested airport. Return an array containing the latitude and longitude. This function will not work for airports outside continental US.
5	String	<b>getClosestAirport(double latitude, double longitude)</b> Get the code of the airport closest to the given position. This function will not work for airports outside continental US.
6	String[]	<b>getAirportsWithinMiles(double lat_deg, double lon_deg, double miles)</b> Get all the airports within “miles” range of the given latitude-longitude location. This function will not work for airports outside continental US.

7	String	<b>getFullName(String airportid)</b> Get the full name corresponding to the given airport code. This function will not work for airports outside continental US.
8	Object[]	<b>getAllRunways(String airport_code)</b> Get all the runways at a given airport. The returned data is an array. Each element of the array consists of: - Runway name - Waypoint ID This function will not work for airports outside continental US.
9	String[]	<b>getRunwayExits(String airport_code, String runway_id)</b> Get all the exits at a given runway ID, at a given airport code. This function will not work for airports outside continental US.
10	Object[]	<b>getLayout_node_map(String airport_code)</b> Get the mapping of nodes and the sequence numbers of the surface traffic network at a given airport.  The returned data is an array. Each array element consists of: - Waypoint node ID - Node sequence number This function will not work for airports outside continental US.
11	Object[]	<b>getLayout_node_data(String airport_code)</b> Get the waypoint node data at a given airport.  The returned data is an array. Each array element consists of: - Node sequence number - Latitude - Longitude This function will not work for airports outside continental US.
12	Object[]	<b>getLayout_links(String airport_code)</b> Get links joining the waypoint nodes representing ground layout (runways, taxiways, ramps, and gates) of a given airport which represents the connection of routes between them.  The returned data is an array. Each array element consists of: - Node 1 sequence number - Node 2 sequence number This function will not work for airports outside continental US.
13	String[]	<b>getSurface_taxi_plan(String acid, String airport_code)</b> Get the surface taxi plan of a given aircraft ID at an airport code. Returns an array of all the waypoint IDs in sequential order. This function will not work for airports outside continental US.
14	int	<b>generate_surface_taxi_plan(String acid, String airport_code, String startNode_waypoint_id, String endNode_waypoint_id, String runway_name)</b> Generate taxi plan and load it in GNATS. The function arguments are: acid: Aircraft ID

		airport_code: Airport code startNode_waypoint_id: Starting waypoint ID endNode_waypoint_id: Ending waypoint ID runway_name: Name of runway Important Note: This function does need the users to specify the V2 for departing aircraft or the touchdown point for arriving aircraft.  Return value: 0 means success. 1 means error. This function will not work for airports outside continental US.
15	int	<b>setUser_defined_surface_taxi_plan(String acid, String airport_code, String[] user_defined_waypoint_ids)</b> Set user-defined surface taxi plan and load it into GNATS. Return value: 0 means success. 1 means error. This function will not work for airports outside continental US.
16	String[]	<b>get_taxi_route_from_A_To_B(String acid, String airport_code, String startNode_waypoint_id, String endNode_waypoint_id)</b> Generate a taxi route from waypoint A to the waypoint B. Note that this function only returns an array of waypoint IDs. This function will not work for airports outside continental US.
17	String	<b>getDepartureRunway(String acid)</b> Get the departure runway of the given aircraft. If a departure taxi plan does not exist for the aircraft, no result will be returned. This function will not work for airports outside continental US.
18	String	<b>getArrivalRunway(String acid)</b> Get the arrival runway of the given aircraft. If an arrival taxi plan does not exist, no result will be returned. This function will not work for airports outside continental US.
19	double	<b>getTaxi_tas_knots(String acid)</b> Get the surface taxi speed of the given aircraft, knots. This function will not work for airports outside continental US.
20	void	<b>setTaxi_tas_knots(String acid, double tas_knots)</b> Set the surface taxi speed of the given aircraft, knots. This function will not work for airports outside continental US.
21	String[]	<b>getAllAirportCodesInGNATS()</b> Get ICAO codes for all 57 airports modeled in GNATS. This function will not work for airports outside continental US.
22	String[]	<b>getRunwayEnds(String airportId, String runwayId)</b> Get runway end node waypoints for given airport. This function will not work for airports outside continental US.

#### Airport Instance API

No.	Type	Method and Description
1	String	<b>getCode()</b> Get the airport code. This function will not work for airports outside continental US.
2	float	<b>getElevation()</b>

		Get the elevation of the airport in feet. This function will not work for airports outside continental US.
3	float	<b>getLatitude()</b> Get the latitude of the airport. This function will not work for airports outside continental US.
4	float	<b>getLongitude()</b> Get the longitude of the airport. This function will not work for airports outside continental US.
5	String	<b>getName()</b> Get the full name of the airport. This function will not work for airports outside continental US.

#### TerminalAreaInterface API

No.	Type	Method and Description
1	String[]	<b>getAllApproaches(String airport_code)</b> Get all the Approach Procedures available at the given airport. This function will not work without the FAA CIFP file.
2	String[]	<b>getAllSids(String airport_code)</b> Get all the Standard Instrument Departure (SID) Procedures at the given airport. This function will not work without the FAA CIFP file. For International airports, SID procedures can be found at GNATS_Server/share/procedureData/SID.csv
3	String[]	<b>getAllStars(String airport_code)</b> Get all the Standard Terminal Arrival (STAR) Procedures at the given airport. This function will not work without the FAA CIFP file. For International airports, sample STAR procedures can be found at GNATS_Server/share/procedureData/STAR.csv
4	String	<b>getCurrentApproach(String acid)</b> Get the current Approach Procedure at the given airport for the given flight. This function will not work without the FAA CIFP file.
5	String	<b>getCurrentSid(String acid)</b> Get the current SID Procedure at the given airport for the given flight. This function will not work without the FAA CIFP file.
6	String	<b>getCurrentStar(String acid)</b> Get the current STAR procedure at the given airport for the given aircraft flight. This function will not work without the FAA CIFP file.
7	String[]	<b>getProcedure_leg_names(String proc_type, String proc_name, String airport_code)</b> Get the leg names at the given airport code, procedure type and procedure name. The arguments are: proc_type: Procedure type. The valid values are limited to "SID", "STAR" and "APPROACH". proc_name: Name of the procedure. airport_code: Airport code. This function will not work without the FAA CIFP file.
8	String[]	<b>getWaypoints_in_procedure_leg(String proc_type, String proc_name, String airport_code, String proc_leg_name)</b> Get the waypoints at the given airport code, procedure type, procedure name and leg name.

		<p>Arguments:</p> <p>proc_type: Procedure type. The valid values are limited to "SID", "STAR" and "APPROACH".</p> <p>proc_name: Name of the procedure.</p> <p>airport_code: Airport code.111</p> <p>proc_leg_name: Name of the procedure leg.</p> <p>This function will not work without the FAA CIFP file.</p>
9	double[]	<p><b>getWaypoint_Latitude_Longitude_deg(String waypoint_name)</b></p> <p>Get the latitude and longitude (in degrees) of a given waypoint.</p> <p>This function will not work without the FAA CIFP file.</p>
10	double	<p><b>getProcedure_alt_1(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</b></p> <p>Get the alt 1 value at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.30 for details.</p> <p>This function will not work without the FAA CIFP file.</p>
11	double	<p><b>getProcedure_alt_2(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</b></p> <p>Get the alt 2 value at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.30 for details.</p> <p>This function will not work without the FAA CIFP file.</p>
12	double	<p><b>getProcedure_speed_limit(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</b></p> <p>Get the speed limit at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.72 for details.</p> <p>This function will not work without the FAA CIFP file.</p>
13	String	<p><b>getProcedure_alt_desc(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</b></p> <p>Get the altitude description at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.29 for details.</p> <p>This function will not work without the FAA CIFP file.</p>
14	String	<p><b>getProcedure_speed_limit_desc(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</b></p> <p>Get the speed limit description at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.261 for details.</p> <p>This function will not work without the FAA CIFP file.</p>

#### TerrainInterface API

No.	Type	Method and Description
1	double	<p><b>getElevation(double latDeg, double lonDeg)</b></p> <p>Returns the terrain elevation (in feet above sea level) at the specified latitude and longitude (degrees). Terrain data from USGS is being used for this</p>



		function. It has a horizontal resolution of 0.001 degree of latitude/longitude, and vertical resolution of 100ft. If no access is available to USGS Data, custom terrain data can be integrated with GNATS. Refer to Terrain Data Integration.pdf under Documentation/ directory for details.
2	double[]	<b>getElevationAreaStats(double minLatDeg, double maxLatDeg, double minLonDeg, double maxLonDeg)</b> Returns an array of statistical information calculated from using terrain elevation data for the specified region. minLatDeg: The lower latitude of the rectangular bounding region (degrees) maxLatDeg: The upper latitude of the rectangular bounding region (degrees) minLonDeg: The lower longitude of the rectangular bounding region (degrees) maxLonDeg: The upper longitude of the rectangular bounding region (degrees) Returns { min, max, mean, variance, stddev } (in feet)
3	double[][]	<b>getElevationMapBounds()</b> Returns the minimum and maximum latitude and longitude bounds of the data used to interpolate elevation data.
4	int	<b>setTerrainProfile(double startLat, double endLat, double startLon, double endLon, double resolution)</b> Sets terrain profile information when working with custom terrain data. startLat The start latitude of the region (degrees) endLat The end latitude of the region (degrees) startLon The start longitude of the region (degrees) endLon The end longitude of the region (degrees) resolution Increment of latitude/longitude return 0 for success, 1 for failure

#### WeatherInterface API

No.	Type	Method and Description
1	int	<b>DownloadWeatherFiles()</b> Download aviation weather files. Metar, Sigmet, Pirep files will be downloaded to GNATS_Server/share/tg/weather directory from NOAA.
2	float[]	<b>getWind(float timestamp_sec, float latitude_deg, float longitude_deg, float altitude_ft)</b> Get wind data. Returned data is an array of float value. The first element is wind_north vector value. The second element is wind_east vector value.
3	Weather Polygon []	<b>getWeatherPolygons(String ac_id, double lat_deg, double lon_deg, double alt_ft, double nauticalMile_radius)</b> Get weather polygons. Returned data is an array of weather polygons.  Notice. This function can only be executed during pause status of simulation. This function will not work without the FAA CIPF file.

**RiskMeasuresInterface API**

No.	Type	Method and Description
1	Object	<b>getFlightsInRange(String aircraftID, float minLatitude, float maxLatitude, float minLongitude, float maxLongitude, float minAltitude_ft, float maxAltitude_ft)</b> This function takes-in the reference aircraft callsign as the input. It then forms a bounding box around the aircraft within which potential hazards or other phenomena of interest may exist. The aircraft callsigns are filtered to find the ones that lie within this box. These flights are then analyzed for their position and velocity relative to the reference aircraft, which are then returned to the user. The returned object is in the following format: [[aircraftCallsign, relativeVelocity, altitudeDifference, bearingAngle, distance], [.....], .....]
2	double	<b>getDistanceToRunwayThreshold(String aircraftId)</b> For an aircraft in its takeoff or landing phases, this function calculates the distance to the threshold of the runway from the present position.
3	double	<b>getDistanceToRunwayEnd(String aircraftId)</b> For an aircraft in its takeoff or landing phases, this function calculates the distance to the end of the runway from the present position.
4	double	<b>getVelocityAlignmentWithRunway(String aircraftId, String procedure)</b> For an aircraft either in landing or takeoff phases, this function computes the alignment of the velocity vector relative to the runway centerline. The procedure parameter can have values: ARRIVAL, DEPARTURE, FINALAPPROACH
5	int	<b>getPassengerCount(String aircraftType)</b> This function returns the number of passengers occupying a particular aircraft, assuming 100% load factor. This data is available for all the aircraft types in the ADB database.
6	double	<b>getAircraftCost(String aircraftType)</b> This function returns the cost (in millions of US Dollars, 2019 base year) for a new aircraft of the aircraft type. This data is provided for all the aircraft types in the ADB database, and is derived from the Internet.
7	Object	<b>getFlightsInWakeVortexRange(String refAircraftId, float envelopeStartWidth, float envelopeStartThickness, float envelopeEndWidth, float envelopeEndThickness, float envelopeRange, float envelopeAltitudeDrop)</b> This function models a wake vortex hazard envelope to determine wake encounter hazards for trailing flights. The wake generating aircraft is assumed to be located at the center of a rectangular, divergent, descending tube with two wingspan breadth and one wingspan thickness at the aircraft, expanding as a linear function of the in-trail distance. The function takes in the following parameters:  refAircraftId: The callsign of aircraft which is producing the wake vortex. envelopeStartWidth: The width (in feet) of the envelope at start of wake. (typically twice the aircraft wingspan)

		<p>envelopeStartThickness: The Thickness (in feet) of the envelope at start of the wake. (typically one wingspan of the aircraft)</p> <p>envelopeEndWidth: The width (in feet) of the envelope at end of the wake vortex hazard.</p> <p>envelopeEndThickness: The thickness (in feet) of the envelope at end of the wake vortex hazard.</p> <p>envelopeRange: Influence range(in miles) of the vortex envelope. (4 to 15 nm, depending on the weight class of the aircraft: Super, Heavy, Large)</p> <p>envelopeAltitudeDrop: Drop (in feet) of the envelope base relative to the wake generating aircraft.</p> <p>Return Object type for this function is: [[aircraftCallsign, relativeVelocity, altitudeDifference, CourseAngle, distance], [.....], .....]</p> <p>An illustration on the use of this function is available at GNATS_Client/sample/WakeVortexEnvelope.png</p>
8	int	<p><b>setAircraftBookValue(float aircraftBookValue)</b></p> <p>Set the book value of the aircraft in million US\$. This is specific to the aircraft instance, and not for an aircraft type.</p>
9	float	<p><b>getAircraftBookValue()</b></p> <p>Get the book value of the aircraft in million US\$. This is specific to the aircraft instance for a flight in simulation, and not for an aircraft type. To get aircraft cost based on manufacturer model, refer to getAircraftCost() function within <b>RiskMeasuresInterface</b>.</p>
10	int	<p><b>setCargoWorth(float cargoWorth)</b></p> <p>Set the value of the cargo in the aircraft, in million US\$.</p>
11	float	<p><b>getCargoWorth()</b></p> <p>Get the value of the cargo in the aircraft, in million US\$.</p>
12	int	<p><b>setPassengerLoadFactor(float paxLoadFactor)</b></p> <p>Set load factor for (passenger occupancy relative to the total number of seats) in an aircraft instance. paxLoadFactor ranges from 0 to 1, 0 being an empty aircraft and 1 being fully occupied.</p>
13	float	<p><b>getPassengerLoadFactor()</b></p> <p>Get load factor for passenger occupancy in an aircraft instance.</p>
14	int	<p><b>setTouchdownPointOnRunway(String aircraftId, double latitude, double longitude)</b></p> <p>Set aircraft touch down point on runway for landing. This would override the touchdown point calculated by the simulation.</p>
15	double[]	<p><b>getTouchdownPointOnRunway(String aircraftId)</b></p> <p>Get aircraft touch down point on runway for landing.</p>
16	int	<p><b>setTakeOffPointOnRunway(String aircraftId, double latitude, double longitude)</b></p> <p>Set aircraft take off point on runway for liftoff. This would override the take off point calculated by the simulation model in GNATS.</p>
17	double[]	<p><b>getTakeOffPointOnRunway(String aircraftId)</b></p>

		Get aircraft take off point on runway for liftoff.
18	double	<b>getL1Distance(String airportId, String aircraftId1, String aircraftId2)</b> Get L1 distance between two aircraft during surface movements if there is a point of intersection between them in their taxi plans. If there is no possibility of aircraft contact, L1 distance is not defined and the function would return -1. This function will not work for airports outside continental US.
19	double	<b>getDistanceToPavementEdge(String airportId, String aircraftId)</b> Get distance between aircraft current position and the edge of the pavement in the present direction of travel. This can be used to check if an aircraft might potentially run off of the pavement during taxi, take-off, or ramp operations.  This function will not work for airports outside continental US.
20	Double	<b>getL2Distance(String airportId, String vehicle1, String vehicle2)</b> Get L2 distance between two vehicles during surface movements if there is a point of intersection between in their taxi/drive plans. If there is no possibility of aircraft contact, L2 distance is not defined and the function would return -1. This function would work only for Gate and Ramp phases at arrival/departure airports.
21	double	<b>getTimeToObjectOfInterest(String airportId, String vehicle1, float latitude, float longitude)</b> Get time-to-go for the vehicle to come in contact with an object of interest (latitude, longitude) during surface movements if there is a point of potential contact between them.
22	double	<b>getDistanceToObjectOfInterest(String airportId, String vehicle1, float latitude, float longitude)</b> Get L1/L2 (based on flight phase) distance between vehicle and an object of interest (latitude, longitude) during surface movements if there is a point of potential contact between them. If not, returns -1.
23	double	<b>getTimeToVehicleContact(String vehicle1, String vehicle2)</b> Get time-to-go to come in contact with another vehicle based on the distance-to-go and the closing rate between them.
24	double	<b>getTimeToPavementEdge(String vehicleId)</b> Get the time-to-go to the pavement edge for the given vehicleId. Calculated based on as distance-to-go and the closing rate.
25	double	<b>getRateOfLineOfSightChange(String aircraftID1, String aircraftID2)</b> This function returns the rate of change of line-of-sight angle between aircraftID2 with respect to aircraftID1. If the rate of change becomes zero and the distance between the two aircraft is converging, a potential for collision exists.

26	double[] []	<b>getRegionOfInterest()</b> This function can be used to set the region of interest with the input parameter as a double array of the latitude-longitude bounds of the region. The return data is a flag indicating success or failure.
27	int	<b>setRegionOfInterest(double[] regionBounds)</b> This function can be used to get the region of interest. The returned data is a nested double array of the latitude-longitude bounds of the region.
28	String[]	<b>getAircraftInRegionOfRegard(String aircraft)</b> Returns the list of aircraft IDs for the aircraft within the region of regard of the given aircraft.
29	double[] []	<b>getRegionOfRegard(String aircraft)</b> Returns a list of all the regions of regard set for the particular flight.
30	int	<b>setRegionOfRegard(String aircraft, double[minLat, minLon, maxLat, maxLon, minAlt, maxAlt] regionBounds)</b> Adds a region of regard for the given aircraft. If a region of regard already exists for the aircraft, then this new region of regard will replace the previous one. Default value for region regard is: 1000 ft at gate/ramp, 2000 ft on taxiway, 2 nm * 1000 ft on runway, 6 nm on climb, 10 nm for 18000ft+ till cruise, 20 nm to cruise. These values are applied in reverse order for landing aircraft.
31	double	<b>getRateOfApproachToPavementEdge(String aircraftID, int timesteps)</b> Returns the rate of distance covered based on the distance-to-go to the runway pavement edge. It is calculated over a particular number of timesteps. ((current distance to-go minus the previous) / timesteps).
32	double	<b>getRateOfApproachToVehicle(String vehicle1ID, String vehicle2ID, int timesteps)</b> Returns the rate of change of L1/L2 (based on flight phase) distance based on the distance-to-go to another vehicle. It is calculated over a particular number of timesteps. ((current distance to-go minus the previous) / timesteps).
33	double	<b>getRateOfApproachToVehicle(String vehicle1ID, String vehicle2ID, int timesteps)</b> Returns the rate of change of L1/L2 (based on flight phase) distance based on the distance-to-go to another vehicle. It is calculated over a particular number of timesteps. ((current distance to-go minus the previous) / timesteps).
34	double	<b>getRateOfApproachToWaypoint(String aircraftID, String Waypoint, int timesteps)</b> Returns the rate of approach to a specified named waypoint. Also, there's another version called getRateOfApproachToWaypoint(String aircraftID, float waypointLatitude, waypointLongitude, int timestep).
35	double	<b>getRateOfApproachToEvent(String aircraftID, String eventCenterLatitude, String eventCenterLongitude, int timesteps)</b> Returns the rate of approach to the center of a given situation/event. This is a

		generic version of the function to address rate of change of proximity to any identified adverse event. It is calculated over a specified number of timesteps. $((\text{current distance to-go minus the previous}) / \text{timesteps})$ .
36	double	<b>getRateOfApproachToWeatherEvent(String aircraftID, [WeatherBounds])</b> Returns the rate of approach of given aircraft to a severe weather event within the specified region of regard. It is calculated over a specified number of timesteps. $((\text{current distance-to-go minus the previous}) / \text{timesteps})$ .
37	double	<b>getRateOfApproachToWakeVortex(String leadingAircraftID, String trailingAircraftID)</b> Returns the rate of approach of trailing aircraft to the center of the wake envelope of leading aircraft. It is calculated over a specified number of timesteps. $((\text{current distance to-go minus the previous}) / \text{timesteps})$ .
38	double	<b>getRateOfVelocityAlignmentToRunway(String aircraftID, String procedure, int timesteps)</b> Returns the rate of change of the aircraft velocity vector alignment with respect to the runway based on flight phase (departure/arrival, Final Approach). It is calculated over a specified number of timesteps. $((\text{current distance-to-go minus the previous}) / \text{timesteps})$ .
39	double	<b>getRateOfApproachToRunwayEnd(String aircraftID, int timesteps)</b> Returns the rate of approach based on the distance-to-go to the runway end when landing or takeoff. It is calculated over a specified number of timesteps. $((\text{Current distance-to-go minus the previous}) / \text{timesteps})$ .
40	double	<b>getRateOfApproachToRunwayThreshold(String aircraftID, int timesteps)</b> Returns the rate of approach based on the distance-to-go to the runway threshold during landing. It is calculated over a specified number of timesteps. $((\text{current distance to-go minus the previous}) / \text{timesteps})$ .
41	double[]	<b>calculateRisk(String flightData)</b> Returns the parameters and risk details about the Aviation Occurrence Category that might have been detected based on the flight data from the In-Time Risk Assessment simulation cycle.

#### EntityInterface API

No.	Type	Method and Description
1	ControllerInterface	<b>getControllerInterface()</b> Returns a reference to the ControllerInterface.
2	PilotInterface	<b>getPilotInterface()</b> Returns a reference to the PilotInterface.
3	GroundOperatorInterface	<b>getGroundOperatorInterface()</b> Returns a reference to the GroundOperatorInterface.

#### ControllerInterface API

No.	Type	Method and Description
1	int	<b>setDelayPeriod(String acid, AircraftClearance</b>

		<b>aircraft_clearance, float seconds)</b> Set delay in providing clearance to an aircraft, period in seconds
2	int	<b>int setActionRepeat(String aircraftID, String repeatParameter)</b> The controller makes the pilot repeat an action, based on the repeatParameter value. The repeatParameter can have following values: 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
3	int	<b>int skipFlightPhase(String aircraftID, String flightPhase)</b> The controller skips issuing clearance to an aircraft to the next required flight phase. The flightPhase can have any of the Flight Phase Enum Values. Eg. FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE
4	int	<b>int setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)</b> Instead of clearing the aircraft to the value of one parameter, the controller erroneously clears the aircraft to another value. For example, the controller can assign the magnitude of airspeed (170 kts) as the course angle (170 degrees) and viceversa. These are following pairs of parameters that can be mutually interchanged: 1. AIRSPEED – COURSE 2. FLIGHT_LEVEL – AIRSPEED 3. COURSE – FLIGHT_LEVEL
5	int	<b>int setActionReversal(String aircraftID, String changeParameter)</b> Controller issues clearance to perform reverse of the intended action, by reversing the value of the changeParameter.  The changeParameter can have following values: 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
6	int	<b>int setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)</b> Clears the aircraft to execute only a portion of a required action, by providing the original target value of the parameter, and a percentage of its value to be executed.  The changeParameter can have following values: 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
7	int	<b>int skipChangeAction(String aircraftID, String skipParameter)</b> Omits issuing the clearance by the controller, resulting in the pilot continuing

		<p>to maintain current value for the skipParameter. The skipParameter can have following values:</p> <ol style="list-style-type: none"> <li>1. AIRSPEED</li> <li>2. VERTICAL_SPEED</li> <li>3. COURSE</li> </ol>
8	int	<p><b>int setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)</b></p> <p>Controller issues lagged clearances lagging the aircraft action. Following are the parameters: The lagParameter (Parameter to be lagged) can have following values:</p> <ol style="list-style-type: none"> <li>1. AIRSPEED</li> <li>2. VERTICAL_SPEED</li> <li>3. COURSE</li> </ol> <p>lagTimeConstant: To be specified in seconds. 10 seconds, for instance. percentageError: Error percentage for the lag. For example, if 95% of the action is to be executed, percentage error would be 0.05. parameterTarget: Original parameter value to be reached.</p>
9	int	<p><b>setControllerAbsence(String aircraftID, int timeSteps)</b></p> <p>Controller advisories can be absent for a given time period, requiring the aircraft to execute default plans while waiting for the controller to provide updates. Parameter timeSteps denotes number of steps that aircraft would be flying without controller advisories.</p>
10	Int	<p><b>releaseAircraftHold(String aircraftID, String approachProcedure, String targetWaypoint)</b></p> <p>The Controller releases the aircraft from the holding pattern and inserts it into the arrival stream. The controller may clear the aircraft to an approach procedure that may be different from the original flight plan, and a waypoint in that approach. This is the waypoint that the aircraft would intercept to begin approach. For releasing hold pattern in phases other than approach, such as en-route or departure, the approachProcedure parameter needs to be "" (Empty String). The aircraft would get out of the hold and head to the targetWaypoint.</p>
11	void	<p><b>enableConflictDetectionAndResolution(boolean flag)</b></p> <p>Enable built-in conflict detection and resolution capability in GNATS if boolean_flag = TRUE. Disable GNATS built-in conflict detection and resolution capability if boolean_flag = FALSE. Log file is generated in GNATS_Server/log directory.</p>
12	void	<p><b>setCDR_initiation_distance_ft_surface(float distance)</b></p> <p>Set the initiation distance in feet, for Conflict Detection and Resolution of the surface traffic.</p>
13	void	<p><b>setCDR_initiation_distance_ft_terminal(float distance)</b></p> <p>Set the initiation distance in feet for Conflict Detection and Resolution for aircraft flying in the terminal area.</p>
14	void	<p><b>setCDR_initiation_distance_ft_enroute(float distance)</b></p> <p>Set the initiation distance in feet, for Conflict Detection and Resolution of en-route air traffic.</p>



15	void	<b>setCDR_separation_distance_ft_surface(float distance)</b> Set the required separation distance in feet for Conflict Detection and Resolution on the surface.
16	void	<b>setCDR_separation_distance_ft_terminal(float distance)</b> Set the required separation distance in feet for Conflict Detection and Resolution in the terminal area.
17	void	<b>setCDR_separation_distance_ft_enroute(float distance)</b> Set the required separation distance in feet for Conflict Detection and Resolution in the en-route airspace.
18	void	<b>EnableStrategicWeatherAvoidance()</b> Enable/disable the built-in strategic weather avoidance capability during simulation. If enabled, the GNATS computational engine checks if any of the flight plans traverse through the adverse weather zone, and creates alternate routes to avoid it. However, if an alternative route is not possible, the aircraft will be held in a pattern at its current location. The strategic weather avoidance logic is executed on an hourly basis. If enabled, GNATS simulation will experience significant rise in system resource usage due to the increased computational requirements. The simulation will also require higher amounts of execution time.
19	void	<b>setWeather_polygonFile(String pathFilename)</b>  Manually set the severe weather polygon file used in strategic weather avoidance. If this function is not used during simulation, GNATS engine will choose the latest file. If pathFilename is an empty string "", GNATS engine will choose the latest file. If pathFilename is "NONE", polygon file will be disabled.
20	void	<b>setWeather_sigmetFile(String pathFilename)</b> Manually set sigmet file for strategic weather avoidance. If this function is not used during simulation, the GNATS engine will choose the latest available file. If pathFilename is an empty string "", GNATS engine will choose the latest file. If pathFilename is "NONE", sigmet file will be disabled.
21	int	<b>setTacticalWeatherAvoidance(String waypoint_name, float duration_sec)</b> Set waypoint name and duration (in seconds) for weather avoidance. These waypoints are considered to be influenced by the weather so they will be avoided. For setting multiple weather waypoints to avoid, call this function with each waypoint name.
22	void	<b>enableMergingAndSpacingAtMeterFix(String airportId, String meterFix, String trailAttribute, float timeInTrail/distanceInTrail)</b> Enable merging and spacing at a meter fix waypoint on the arrival stream of aircraft. This helps to space out flights for safety reasons both in air and on ground. The function takes in the following parameters: 1. airportId: The ICAO code for the airport.

		<p>2. meterFix: The meter fix point where the spacing needs to be enabled.</p> <p>3. trailAttribute: String, with permitted values being “TIME” or “DISTANCE”. This defines whether the float input for the last parameter is distance or time for aircraft spacing.</p> <p>4. timeInTrail/distanceInTrail: The minimum separation distance or time between aircraft. This input should be consistent with the selection for trailAttribute parameter. timeInTrails is to be supplied in minutes, and distanceInTrail is to be supplied in miles.</p> <p>This function will not work for airports outside continental US.</p>
23	void	<p><b>disableMergingAndSpacingAtMeterFix(String airportId, String meterFix)</b></p> <p>Enable merging and spacing at a meter fix waypoint for the aircraft arrival stream. This will space aircraft for flow metering in air and on ground. The function takes in the following parameters:</p> <p>1. airportId: The ICAO code for the airport.</p> <p>2. meterFix: The meter fix point where the spacing needs to be enabled.</p> <p>This function will not work for airports outside continental US.</p>
24	Object[][]	<p><b>getCDR_status()</b></p> <p>Get current status of CD&amp;R conflicting events</p> <p>Result data: An array of CD&amp;R status.</p> <p>Each array element is formatted in the form of an array. The content are:</p> <p>aircraft ID of the held aircraft, aircraft ID of the conflicting aircraft, seconds of holding of the held aircraft</p> <p>Format type: [[String, String, float]]</p> <p>Example: [["AC1", "AC_conflicting_with_AC1", heldSeconds_AC1], ["AC2", "AC_conflicting_with_AC2", heldSeconds_AC2]]</p>

#### PilotInterface API

No.	Type	Method and Description
1	int	<p><b>int setActionRepeat(String aircraftID, String repeatParameter)</b></p> <p>Repeat pilot action, based on the repeatParameter value.</p> <p>The repeatParameter can have following values:</p> <p>1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE</p>
2	int	<p><b>int skipFlightPhase(String aircraftID, String flightPhase)</b></p> <p>Ignore the required flight phase transition,. The flightPhase parameter can have any of the Flight Phase Enum Values. Eg. <u>FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE</u></p>
3	int	<p><b>int setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)</b></p> <p>Erroneously set the value of a parameter to another. For example, the pilot can erroneously set the magnitude of the airspeed to 170 kts instead of setting the course</p>

		<p>angle to 170 degrees. The following pairs of parameters can be mutually interchanged:</p> <ol style="list-style-type: none"> <li>1. AIRSPEED – COURSE</li> <li>2. FLIGHT_LEVEL – AIRSPEED</li> <li>3. COURSE – FLIGHT_LEVEL</li> </ol>
4	int	<p><b>int setActionReversal(String aircraftID, String changeParameter)</b></p> <p>This function can be used to model an erroneous pilot action of reversing an action, by reversing the value of changeParameter.</p> <p>changeParameter can have following values:</p> <ol style="list-style-type: none"> <li>1. AIRSPEED</li> <li>2. VERTICAL_SPEED</li> <li>3. COURSE</li> </ol>
5	int	<p><b>int setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)</b></p> <p>This function can be used to model the pilot error of executing only a part of an action, by providing the original target value of the parameter, and percentage of it to be performed by pilot, for the changeParameter.</p> <p>The changeParameter can have following values:</p> <ol style="list-style-type: none"> <li>1. AIRSPEED</li> <li>2. VERTICAL_SPEED</li> <li>3. COURSE</li> </ol>
6	int	<p><b>int skipChangeAction(String aircraftID, String skipParameter)</b></p> <p>This function can be used to model the pilot error of skipping a required change to a flight control parameter. Omit a parameter change by continuing to maintain the current value for the skipParameter.</p> <p>The skipParameter can have following values:</p> <ol style="list-style-type: none"> <li>1. AIRSPEED</li> <li>2. VERTICAL_SPEED</li> <li>3. COURSE</li> </ol>
7	int	<p><b>int setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)</b></p> <p>This function is used to model the pilot lag in responding to a controller advisory or a required control action to follow the flight plan. Lag in pilot action, by specifying a certain percent of the execution to be completed within a given time period.</p> <p>Following are the parameters:</p> <p>The lagParameter can have following values:</p> <ol style="list-style-type: none"> <li>1. AIRSPEED</li> <li>2. VERTICAL_SPEED</li> <li>3. COURSE</li> </ol> <p>lagTimeConstant: To be specified in seconds. 10 seconds, as an example.</p> <p>percentageError: Error percentage for the lag. For example, if 95% of the action is to be executed in the lag time constant, percentage error would be 0.05.</p>

		parameterTarget: Original parameter value to be reached.
8	int	<b>int setFlightPlanReadError(String aircraftID, String errorParameter, float correctValue)</b> If the simulation has not started, the flight plan read from the TRX file can be changed using this function. This models an error made by the pilot in entering the flight plan into the flight management system. Following are the parameters: errorParameter: Parameter with erroneous data. It can have any of the following values: 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE  correctValue: This is the data according to the flight that should have been read.

#### GroundOperator Interface API

No.	Type	Method and Description
1	int	<b>setGroundOperatorAbsence(String groundVehicleId, int timeSteps)</b>  Ground operators can be absent for a given time period, requiring the vehicle to stop while waiting for the operator to take back control. groundVehicleId: The <u>callsign</u> of the vehicle that the operator is in-charge of. timeSteps: Number of time steps for which operator is absent.  This function will not work for airports outside continental US.
2	int	<b>setActionRepeat(String groundVehicleId, String repeatParameter)</b>  The ground operator repeats an action, based on the repeatParameter value. groundVehicleId: The <u>callsign</u> of the aircraft repeatParameter: Ground vehicle parameter for which action is to be repeated.  This function will not work for airports outside continental US.
3	int	<b>setVehicleContact(String groundVehicleId)</b>  Ground operators collides the ground vehicle into another object (Potentially building/aircraft/automobile/person) groundVehicleId: The <u>callsign</u> of the vehicle that the operator is in-charge of.  This function will not work for airports outside continental US.
4	int	<b>setWrongAction(String groundVehicleId, String originalChangeParameter, String wrongChangeParameter)</b> Instead of acting to change value of one parameter, the ground operator erroneously changes another. groundVehicleId: The <u>callsign</u> of the ground vehicle originalChangeParameter: Original parameter to be changed due to ground operator action wrongChangeParameter: Erroneous parameter to be changed due to ground

		operator action This function will not work for airports outside continental US.
5	int	<b>setActionReversal(String groundVehicleId, String changeParameter)</b> Ground operator erroneously executes part of the originally intended action. groundVehicleId: The <u>callsign</u> of the ground vehicle changeParameter: Ground Vehicle parameter for which action is to be partially performed originalTarget: <u>Original</u> value for parameter percentage Percentage of action to be executed This function will not work for airports outside continental US.
6	int	<b>setPartialAction(String groundVehicleId, String changeParameter, float originalTarget, float percentage)</b>  Ground operator executes part of the originally intended action. groundVehicleId: The <u>callsign</u> of the ground vehicle changeParameter: Ground Vehicle parameter for which action is to be partially performed originalTarget: <u>Original</u> value for parameter percentage: Percentage of action to be executed This function will not work for airports outside continental US.
7	int	<b>setActionLag(String groundVehicleId, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)</b>  Ground operator introduces a lag in vehicle control action, thereby only a certain percent of the execution gets completed within a given time period. groundVehicleId The callsign of the ground vehicle lagParameter: Flight parameter for which action is to be lagged lagTimeConstant: To be specified in seconds. 10 seconds, as an example. percentageError: Error percentage for the lag. For example, if 95% of the action is to be executed in the lag time constant, percentage error would be 0.05. parameterTarget: Original parameter value to be reached. This function will not work for airports outside continental US.

#### WeatherPolygon Instance API

No.	Type	Method and Description
1	double[ ]	<b>getX_data()</b>  Get longitude values of vertices in the polygon.
2	double[ ]	<b>getY_data()</b>  Get latitude values of vertices in the polygon.
3	int	<b>getNum_vertices()</b>  Get number of vertices in the polygon.

4	boolean	<b>getCcw_flag()</b>  Get boolean value indicating whether the vertices are created counter-clockwise in the polygon.
5	double	<b>getXmin()</b>  Get minimum longitude value of all vertices in the polygon.
6	double	<b>getXmax()</b>  Get maximum longitude value of all vertices in the polygon.
7	double	<b>getYmin()</b>  Get minimum latitude value of all vertices in the polygon.
	double	<b>getYmax()</b>  Get maximum latitude value of all vertices in the polygon.
	double	<b>getX_centroid()</b>  Get longitude value of the centroid point in the polygon.
	double	<b>getY_centroid()</b>  Get latitude value of the centroid point in the polygon.
	String	<b>getPoly_type()</b>  Get polygon type.
	int	<b>getStart_hr()</b>  Get starting hour of the polygon.
	int	<b>getEnd_hr()</b>  Get ending hour of the polygon.

#### AircraftClearance Enum Values

Values
<b>AIRCRAFT_CLEARANCE_PUSHBACK</b>
<b>AIRCRAFT_CLEARANCE_TAXI_DEPARTING</b>
<b>AIRCRAFT_CLEARANCE_TAKEOFF</b>
<b>AIRCRAFT_CLEARANCE_ENTER_ARTC</b>
<b>AIRCRAFT_CLEARANCE_DESCENT_FROM_CRUISE</b>
<b>AIRCRAFT_CLEARANCE_ENTER_TRACON</b>
<b>AIRCRAFT_CLEARANCE_APPROACH</b>
<b>AIRCRAFT_CLEARANCE_TOUCHDOWN</b>

**AIRCRAFT\_CLEARANCE\_TAXI\_LANDING**

**AIRCRAFT\_CLEARANCE\_RAMP\_LANDING**

WeatherPolygon Instance API

No.	Type	Method and Description
1	String	<b>convertLatLonDeg_to_degMinSecString(String degStr)</b> Convert latitude/longitude degree string to degree-minute-second format.

# Application of GNATS Client API Functions

**Function:** getEntityInterface()

**Return Type:** EntityInterface

**Purpose:** To access the APIs in the Entities group(Pilots, Controllers, ground vehicle operators)

**Example:**

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
entityInterface = gnatsClient.getEntityInterface()
```

**Function:** getEnvironmentInterface()

**Return Type:** EnvironmentInterface

**Purpose:** To access the APIs in the Environment group(Atmosphere, Airports, Arrival/Departure Procedures)

**Example:**

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
environmentInterface = gnatsClient.getEnvironmentInterface()
```

**Function:** getEquipmentInterface()

**Return Type:** EquipmentInterface

**Purpose:** To access the APIs in the Equipment group(Aircraft, Ground Vehicles, Communication & navigation Systems)

**Example:**

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
equipmentInterface = gnatsClient.getEquipmentInterface()
```

**Function:** getRiskMeasureInterface()

**Return Type:** RiskMeasuresInterface

**Example:**

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface()
```

**Function:** getRiskMInterface ()

**Return Type:** RiskMeasuresInterface

**Example:**

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
riskMInterface = gnatsClient.getRiskMInterface()
```

**Function:** getSimulationInterface()

**Return Type:** SimulationInterface

**Example:**

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
```



```
simulationInterface = gnatsClient. GetSimulationInterface()
```

**Function:** disconnect()

**Return Type:** void

**Example:**

```
GNATSCClientFactory = JClass('GNATSCClientFactory')
gnatsClient = GNATSCClientFactory.getGNATSCClient()
gnatsClient.disconnect()
```

**Function:** login(String authenticationID)

**Return Type:** void

**Example:**

```
GNATSCClientFactory = JClass('GNATSCClientFactory')
gnatsClient = GNATSCClientFactory.getGNATSCClient()
gnatsClient.login("ABCD1234")
```

## SimulationInterface API

**Function:** clear\_trajectory()

**Return Type:** void

**Purpose:**

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()
simulationInterface.clear_trajectory()
```

**Function:** get\_curr\_sim\_time()

**Return Type:** float

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()
currentTime = simulationInterface.get_curr_sim_time()
```

**Function:** get\_sim\_id()

**Return Type:** long

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()
simulation_id = simulationInterface.get_sim_id()
```

**Function:** get\_runtime\_sim\_status()

**Return Type:** int

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()
currentRuntimeStatus = simulationInterface.get_runtime_sim_status()
```

**Function:** pause()

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()
simulationInterface.pause()
```

**Function:** resume()

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.resume()
```

**Function:** resume(long timeDuration)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.resume(1000)
```

**Function:** resume(float timeDuration)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.resume(1000.5)
```

**Function:** setupSimulation(int propagationTime, int timeStep)

**Return Type:** int

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (10000, 5)
```

**Function:** setupSimulation(float propagationTime, float timeStep)

**Return Type:** int

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (100.7, 15.5)
```

**Function:** setupSimulation(int propagationTime, int timeStep, int terminalTimeStep, int airborneTimeStep)

**Return Type:** int

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (1000, 3, 4, 5)
```

**Function:** setupSimulation(float propagationTime, float timeStep, float terminalTimeStep, float airborneTimeStep)

**Return Type:** int

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (1000.0, 3.5, 7.5, 10.3)
```

**Function:** start()

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.start()
```

**Function:** start(long timeDuration)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.start(1200)
```

**Function:** start(float timeDuration)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.start(150.65)
```

**Function:** startRealTime()

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.startRealTime()
```

**Function:** startRealTime\_singleUser()

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.startRealTime_singleUser()
```

**Function:** stop()

**Return Type:** void

**Example:** simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.stop()

**Function:** write\_trajectories(String outputFile)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.write_trajectories ("SimulationTrajectory.csv")
```

**Function:** request\_aircraft(String ac\_id)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.request_aircraft("ABC123")
```

**Function:** request\_groundVehicle(String gv\_id)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.request_groundVehicle("BUS123")
```

**Function:** externalAircraft\_create\_trajectory\_profile(  
    String ac\_id,  
    String ac\_type,  
    String origin\_airport,  
    String destination\_airport,  
    float cruise\_altitude\_ft,  
    float cruise\_tas\_knots,  
    double latitude\_deg,  
    double longitude\_deg,  
    double altitude\_ft,  
    double rocd\_fps,  
    double tas\_knots,  
    double course\_deg,  
    String flight\_phase)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.externalAircraft_create_trajectory_profile(  
"ABC173", "B733", "KPHX",  
"KSFO", 33000.0, 430.0, 37.2, -122.4, 2500.0, 215.0, 240.0, 318.2,  
"FLIGHT_PHASE_CRUISE")
```

**Function:** externalAircraft\_inject\_trajectory\_state\_data(String ac\_id,  
double latitude\_deg, double longitude\_deg,  
double altitude\_ft, double rocd\_fps,  
double tas\_knots, double course\_deg, String flight\_phase,  
long timestamp\_utc\_millisec)

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.externalAircraft_inject_trajectory_state_data("AB  
C123", 32.61, -122.39, 3200,  
30, 250, 50, "FLIGHT_PHASE_CRUISE", 1541784961725)
```

**Function:** requestDownloadTrajectoryFile()

**Return Type:** void

**Example:**

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.requestDownloadTrajectoryFile()
```

## EquipmentInterface API

**Function:** getAircraftInterface()

**Return Type:** AircraftInterface

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()
```

**Function:** getGroundVehicleInterface()

**Return Type:** GroundVehicleInterface

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getGroundVehicleInterface ()
```

**Function:** getCNSInterface()

**Return Type:** CNSInterface

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getCNSInterface()
```

**Function:** getADBDDataInterface()

**Return Type:** ADBInterface

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
ADBDDataInterface = equipmentInterface.getADBDDataInterface()
```

## **AircraftInterface API**

**Function:** load\_aircraft(String trx\_file, String mfl\_file)

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraftInterface.load_aircraft("share/tg/trx/  
TRX_DEMO_SFO_PHX_GateToGate.trx",  
"share/tg/trx/TRX_DEMO_SFO_PHX_mfl.trx")
```

**Function:** validate\_flight\_plan\_record(String string\_track, String string\_fp\_route, int mfl\_ft)

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
result = aircraftInterface.validate_flight_plan_record("TRACK SWA1897  
B733 373628.6 1222248.0 0 0.13 280 ZOA ZOA46", "FP_ROUTE  
KSFO./RW01R.SSTIK4.LOSHN..BOILE..BLH.HYDRR1.I07R.RW07R.<>.KPHX",  
37000)
```

**Function:** release\_aircraft()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraftInterface.release_aircraft()
```

**Function:** getAircraftIds(float minLatitude, float maxLatitude, float minLongitude, float maxLongitude, float minAltitude\_ft, float maxAltitude\_ft)

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraftsIds = aircraftInterface.getAircraftId(28.5, 30.7, 72.8, 74.9, 15000.0, 20000.9)
```

**Function:** getAllAircraftId()

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraftsIds = aircraftInterface.getAllAircraftId()
```

**Function:** select\_aircraft(String aircraft\_id)

**Return Type:** Aircraft (Aircraft Instance API)

**Example:** equipmentInterface = gnatsClient.getEquipmentInterface()

aircraftInterface = equipmentInterface.getAircraftInterface()

aircraft = aircraftInterface.select\_aircraft('ULI-SFD235')

**Function:** synchronize\_aircraft\_to\_server(Aircraft aircraft)

**Return Type:** int

**Example:**

equipmentInterface = gnatsClient.getEquipmentInterface()

aircraftInterface = equipmentInterface.getAircraftInterface()

aircraft = aircraftInterface.select\_aircraft('ULI-SFD235')

synchronize\_aircraft\_to\_server(aircraft)

## AircraftInstance API

**Function:** delay\_departure(int delayTimeSeconds)

**Return Type:** int

**Example:**

equipmentInterface = gnatsClient.getEquipmentInterface()

aircraftInterface = equipmentInterface.getAircraftInterface()

aircraft = aircraftInterface.select\_aircraft('ULI-SFD235')

aircraft.delay\_departure(20)

**Function:** getAcid()

**Return Type:** String

**Example:**

equipmentInterface = gnatsClient.getEquipmentInterface()

aircraftInterface = equipmentInterface.getAircraftInterface()

aircraft = aircraftInterface.select\_aircraft('ULI-SFD235')

aircraftId = aircraft.getAcid()

**Function:** getAltitude\_ft()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraftAltitude = aircraft.getAltitude_ft ()
```

**Function:** getCruise\_alt\_ft()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraftCruiseAltitude = aircraft.getCruise_alt_ft()
```

**Function:** getCruise\_tas\_knots()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraftCruiseAirspeed = aircraft.getCruise_tas_knots()
```

**Function:** getDeparture\_time\_sec()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightDepartureTime = aircraft.getDeparture_time_sec()
```

**Function:** getDestination\_airport\_elevation\_ft()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
destinationAirportElevation =  
aircraft.getDestination_airport_elevation_ft()
```

**Function:** getFlight\_phase()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightPhase = aircraft.getFlight_phase()
```

**Function:** getFlight\_plan\_latitude\_array()

**Return Type:** float[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightLatitudeArray = aircraft.getFlight_plan_latitude_array()
```

**Function:** getFlight\_plan\_length()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightPlanLength = aircraft.getFlight_plan_length()
```

**Function:** getFlight\_plan\_longitude\_array()

**Return Type:** float[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightLongitudeArray = aircraft.getFlight_plan_longitude_array()
```

**Function:** getFlight\_plan\_waypoint\_name\_array()

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightWaypointNameArray = aircraft.getFlight_plan_waypoint_name_array()
```

**Function:** getFlight\_plan\_alt\_desc\_array()

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightAltitudeDescriptionArray = aircraft.getFlight_plan_alt_desc_array()
```

**Function:** getFlight\_plan\_alt\_1\_array()

**Return Type:** double[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightPlanAltitude1Array = aircraft.getFlight_plan_alt_1_array()
```

**Function:** getFlight\_plan\_alt\_2\_array()

**Return Type:** double[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
```



```
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightPlanAltitude2Array = aircraft.getFlight_plan_alt_2_array()
```

**Function:** getFlight\_plan\_speed\_limit\_array()

**Return Type:** double[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightPlanSpeedLimitArray = aircraft.getFlight_plan_speed_limit_array()
```

**Function:** getFlight\_plan\_speed\_limit\_desc\_array()

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightSpeedLimitDescriptionArray =
aircraft.getFlight_plan_speed_limit_desc_array()
```

**Function:** getFpa\_rad()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightPathAngle = aircraft.getFpa_rad()
```

**Function:** getCourse\_rad()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
courseAngle = aircraft.getCourse_rad()
```

**Function:** getLanded\_flag()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightLandedFlag = aircraft.getLanded_flag()
```

**Function:** getLatitude\_deg()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightCurrentLatitude = aircraft.getLatitude_deg()
```

**Function:** getLongitude\_deg()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightCurrentLongitude= aircraft.getLongitude_deg()
```

**Function:** getOrigin\_airport\_elevation\_ft()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
originAirportElevation = aircraft.getOrigin_airport_elevation_ft()
```

**Function:** getRocd\_fps()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
rateOfClimbOrDescent = aircraft.getRocd_fps()
```

**Function:** getSector\_index()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
sectorIndex = aircraft.getSector_index()
```

**Function:** getTarget\_altitude\_ft()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
targetAltitude = aircraft.getTarget_altitude_ft()
```

**Function:** getTarget\_waypoint\_index()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
targetWaypointIndex = aircraft.getTarget_waypoint_index()
```

**Function:** getTarget\_waypoint\_name()

**Return Type:** String

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
targetWaypointName = aircraft.getTarget_waypoint_name()
```

**Function:** getTas\_knots()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
currentAirspeed = aircraft.getTas_knots()
```

**Function:** getToc\_index()

**Return Type:** int

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
topOfClimbIndex = aircraft.getToc_index()
```

**Function:** getTod\_index()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
topOfDescentIndex = aircraft.getTod_index()
```

**Function:** setAltitude\_ft(float altitude\_ft)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setAltitude_ft(27500.8)
```

**Function:** setCruise\_alt\_ft(float cruise\_alt\_ft)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setCruise_alt_ft(35000.7)
```

**Function:** setCruise\_tas\_knots(float cruise\_tas\_knots)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
```

```
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setCruise_tas_knots(455.5)
```

**Function:** setFlight\_phase(int flight\_phase)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setFlight_phase(2)
```

**Function:** setFlight\_plan\_latitude\_deg(int index, float latitude\_deg)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setFlight_plan_latitude_deg(5, 34.50)
```

**Function:** setFlight\_plan\_longitude\_deg(int index, float longitude\_deg)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setFlight_plan_longitude_deg(5, -122.63)
```

**Function:** setLatitude\_deg(float latitude\_deg)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setLatitude_deg(26.58)
```

**Function:** setLongitude\_deg(float longitude\_deg)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setLongitude_deg (-122.36)
```

**Function:** setRocd\_fps(float rocd\_fps)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
```

```
aircraft.setRocd_fps(-50.1)
```

**Function:** setTarget\_altitude\_ft(float target\_altitude\_ft)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setTarget_altitude_ft(35000.5)
```

**Function:** setTarget\_waypoint\_latitude\_deg(float latitude\_deg)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setTarget_waypoint_latitude_deg(35.63)
```

**Function:** setTarget\_waypoint\_longitude\_deg(float longitude\_deg)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setTarget_waypoint_longitude_deg(-118.25)
```

**Function:** setTas\_knots(float tas\_knots)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setTas_knots(400)
```

## GroundVehicleInterface API

**Function:** load\_groundVehicle(String trx\_file)

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicleInterface.load_aircraft('share/tg/trx/  
TRX_GroundVehicles.trx')
```

**Function:** release\_groundVehicle()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicleInterface.release_groundVehicle()
```

**Function:** getAssignedGroundVehicleIds()

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
assignedGroundVehicles =
groundVehicleInterface.getAssignedGroundVehicleIds()
```

**Function:** getAssignedGroundVehicleIds(String username)

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
assignedGroundVehicles =
groundVehicleInterface.getAssignedGroundVehicleIds(username)
```

**Function:** getAllGroundVehicleIds()

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
listGroundVehicle = groundVehicleInterface.getAllGroundVehicleIds()
```

**Function:** select\_groundVehicle(String groundVehicleId),

**Return Type:** GroundVehicle

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
```

**Function:** externalGroundVehicle\_create\_trajectory\_profile(String groundVehicleId, String aircraftInService, String airport, float latitude, float longitude, float speed, float course)

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicleInterface.groundVehicleInterface.externalGroundVehicle_create_trajectory_profile('NEW123', 'DWA1897', 'KSFO', 37, -122, 15, 28)
```

**Function:** externalGroundVehicle\_inject\_trajectory\_state\_data(String groundVehicleId, String aircraftInService, float latitude, float longitude, float speed, float course)

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicleInterface.externalGroundVehicle_inject_trajectory_state_
data('NEW123', 'DWA1897', 37, -122, 15, 28)
```

## GroundVehicleInstance API

**Function:** getGvid()

**Return Type:** String

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleId = groundVehicle.getGvid()
```

**Function:** getAirportId()

**Return Type:** String

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleAirportId = groundVehicle.getAirportId()
```

**Function:** getAircraftInService()

**Return Type:** String

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
aircraftInService = groundVehicle.getAircraftInService()
```

**Function:** getFlag\_external\_groundvehicle()

**Return Type:** Boolean,

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
isExternalGroundVehicle =
groundVehicle.getFlag_external_groundvehicle()
```

**Function:** getAssigned\_user()

**Return Type:** String

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
user = groundVehicle.getAssigned_user()
```

**Function:** getLatitude()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
latitude = groundVehicle.getLatitude()
```

**Function:** setLatitude(float latitude)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicle.setLatitude(37.8959)
```

**Function:** getLongitude()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
longitude = groundVehicle.getLongitude()
```

**Function:** setLongitude(float longitude)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicle.setLongitude(-112.8594)
```

**Function:** getAltitude()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
```



```
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
altitude = groundVehicle.getAltitude()
```

**Function:** getSpeed()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleSpeed = groundVehicle.getSpeed()
```

**Function:** setSpeed(float speed)

**Return Type:** void,

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicle.setSpeed(25)
```

**Function:** getCourse()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleCourse = groundVehicle.getCourse()
```

**Function:** setCourse(float course)

**Return Type:** void,

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicle.setCourse(1.5)
```

**Function:** getDeparture\_time()

**Return Type:** float

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleDepartureTime = groundVehicle.getDeparture_time()
```

**Function:** getDrive\_plan\_latitude\_array()

**Return Type:** float[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleDrivePlanLatitudeArray =
groundVehicle.getDrive_plan_latitude_array()
```

**Function:** getDrive\_plan\_longitude\_array()

**Return Type:** float[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleDrivePlanLongitudeArray =
groundVehicle.getDrive_plan_longitude_array()
```

**Function:** getDrive\_plan\_length()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleDrivePlanLength = groundVehicle.getDrive_plan_length()
```

**Function:** getDrive\_plan\_waypoint\_name\_array()

**Return Type:** String[]

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleDrivePlanWaypointNames =
groundVehicle.getDrive_plan_waypoint_name_array()
```

**Function:** getTarget\_waypoint\_index()

**Return Type:** int

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleTargetWaypointIndex =
groundVehicle.getTarget_waypoint_index()
```

**Function:** getTarget\_waypoint\_name()

**Return Type:** String

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleTargetWaypointName =
groundVehicle.getTarget_waypoint_name()
```

**Function:** setDrive\_plan\_latitude(int index, float latitude)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicle.setDrive_plan_latitude(2, 37.2518)
```

**Function:** setDrive\_plan\_longitude(int index, float longitude)

**Return Type:** void

**Example:**

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicle.setDrive_plan_longitude(2, -112.8155)
```

## CNSInterface API

**Function:** getLineOfSight(double observerLat, double observerLon, double observerAlt, double targetLat, double targetLon, double targetAlt)

**Return Type:** double[]

**Example:**

```
cnsInterface = equipmentInterface.getCNSInterface()
cnsInterface.getLineOfSight(33.440903, -111.992862, 1135, 33.274183, -112.147879, 1500)
```

**Function:** setNavigationLocationError(String aircraftId, String parameter, double bias, double drift, double scaleFactor, double noiseVariance, int scope)

**Return Type:** int

**Example:**

```
cnsInterface = equipmentInterface.getCNSInterface()
cnsInterface.setNavigationLocationError('SWA1897', 'LATITUDE', 0.00005, 0.00000001, 0.9, 0.2, 1)
```

```
cnsInterface.setNavigationLocationError('SWA1897', 'LONGITUDE',  
0.00005, 0.00000001, 0.9, 0.2, 1)
```

**Function:** setNavigationAltitudeError(String aircraftId, double bias, double noiseVariance, int scope)

**Return Type:** int

**Example:**

```
cnsInterface = equipmentInterface.getCNSInterface()  
cnsInterface.setNavigationAltitudeError('SWA1897', .00005, 0.2, 0)
```

**Function:** setRadarError(String airportId, String parameter, double originalValue, double bias, double noiseVariance, int scope)

**Return Type:** int

**Example:**

```
cnsInterface = equipmentInterface.getCNSInterface()  
cnsInterface.setRadarError('KSFO', 'RANGE', 25, 0.0000005, 0.2, 1)  
cnsInterface.setRadarError('KSFO', 'AZIMUTH', 30, 0.0000005, 0.2, 1)  
cnsInterface.setRadarError('KSFO', 'ELEVATION', 2500, 0.0000005, 0.2, 1)
```

## ADBDDataInterface API

**Function:** getADB\_cruiseTas(String ac\_type, double altitude\_ft)

**Return Type:** double

**Example:**

```
adbDataInterface = equipmentInterface.getADBDDataInterface()  
adbDataInterface.getADB_cruiseTas('B733', 15000)
```

**Function:** getADB\_climbRate\_fpm(String ac\_type, double flt\_level, String adb\_mass)

**Return Type:** double

**Example:**

```
adbDataInterface = equipmentInterface.getADBDDataInterface()  
adbDataInterface.getADB_climbRate_fpm('B733', 150, 'NOMINAL')
```

**Function:** getADB\_climbTas(String ac\_type, double altitude\_ft)

**Return Type:** double

**Example:**

```
adbDataInterface = equipmentInterface.getADBDDataInterface()  
adbDataInterface.getADB_climbTas('B733', 15000)
```

**Function:** getADB\_descentRate\_fpm(String ac\_type, double flight\_level, String adb\_mass)

**Return Type:** double

**Example:**

```
adbDataInterface = equipmentInterface.getADBDDataInterface()  
adbDataInterface.getADB_descentRate_fpm('B733', 150, 'NOMINAL')
```

**Function:** getADB\_descentTas(String ac\_type, double altitude\_ft)

**Return Type:** double

**Example:**

```
adbDataInterface = equipmentInterface.getADBDataInterface()  
adbDataInterface.getADB_descentTas('B733', 15000)
```

**Function:** getADB\_aircraftTypesAvailable()

**Return Type:** String[]

**Example:**

```
adbDataInterface = equipmentInterface.getADBDataInterface()  
adbDataInterface.getADB_aircraftTypesAvailable()
```

## EnvironmentInterface API

**Function:** load\_rap(String windDirectory)

**Return Type:** void

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.load_rap("share/tg/rap")
```

**Function:** release\_rap()

**Return Type:** int

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.release_rap()
```

**Function:** getAirportInterface()

**Return Type:** AirportInterface

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()
```

**Function:** getTerrainInterface()

**Return Type:** TerrainInterface

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainInterface = environmentInterface.getTerrainInterface()
```

**Function:** getTerminalAreaInterface()

**Return Type:** TerminalAreaInterface

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface = environmentInterface.getTerminalAreaInterface()
```

**Function:** getWeatherInterface()

**Return Type:** WeatherInterface

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
weatherInterface = environmentInterface.getWeatherInterface()
```

**Function:** getCenterCodes()

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.getCenterCodes()
```

**Function:** getCurrentCenter(String aircraftId)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.getCurrentCenter('SWA1897')
```

**Function:** getFixesInCenter(String centerId)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.getFixesInCenter('KZOA')
```

## AirportInterface API

**Function:** select\_airport(String airport\_code)

**Return Type:** Airport

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airport = airportInterface.select_airport("KPHX")
```

**Function:** getArrivalAirport(String acid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
arrivalAirport = airportInterface.getArrivalAirport('ULI-SFD235')
```

**Function:** getDepartureAirport(String acid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
departureAirport = airportInterface.getDepartureAirport('ULI-SFD235')
```

**Function:** getLocation(String airport\_code)

**Return Type:** double[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airportLocation = airportInterface.getLocation('KLAX')
```

**Function:** getClosestAirport(double latitude, double longitude)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
```

```
airportInterface = environmentInterface.getAirportInterface()
closestAirport = airportInterface.getClosestAirport(35.2, -118.6)
```

**Function:** getAirportsWithinMiles(double lat\_deg, double lon\_deg, double miles)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airports = airportInterface.getAirportsWithinMiles(35.2, -118.6,
22.5)
```

**Function:** getFullName(String airportid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportFullName = airportInterface.getFullName('KJFK')
```

**Function:** getAllRunways(String airport\_code)

**Return Type:** Object[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportRunways = airportInterface.getAllRunways('PANC')
```

**Function:** getAllGates(String airport\_code)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportGates = airportInterface.getAllGates('PANC')
```

**Function:** getRunwayExits(String airport\_code, String runway\_id)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
runwayExits = airportInterface.getRunwayExits('KSFO', 'RW28R')
```

**Function:** getLayout\_node\_map(String airport\_code)

**Return Type:** Object[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportLayoutNodeMap = airportInterface.getLayout_node_map('PHNL')
```

**Function:** getLayout\_node\_data(String airport\_code)

**Return Type:** Object[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportLayoutNodeData = airportInterface .getLayout_node_data('PHNL')
```

**Function:** getLayout\_links(String airport\_code)

**Return Type:** Object[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportLayoutLinks = airportInterface.getLayout_links('PHNL')
```

**Function:** getSurface\_taxi\_plan(String acid, String airport\_code)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
surfaceTaxiPlan = airportInterface.getSurface_taxi_plan('ULI-SFD235', 'KSF0')
```

**Function:** generate\_surface\_taxi\_plan(String acid, String airport\_code, String startNode\_waypoint\_id, String endNode\_waypoint\_id, String runway\_name)

**Return Type:** int

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
generatedTaxiPlan = airportInterface.generate_surface_taxi_plan('ULI-SFD235', 'KSF0',
'Gate_01_001', 'Rwy_02_001', 'RW06L')
```

**Function:** setUser\_defined\_surface\_taxi\_plan(String acid, String airport\_code, String[] user\_defined\_waypoint\_ids)

**Return Type:** int

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
generatedTaxiPlan =
airportInterface.setUser_defined_surface_taxi_plan('ULI-SFD235',
'KSF0',
['Gate_01_001', 'Ramp_01_001', 'Txy_01_001', 'Txy_01_002',
'Rwy_02_001'])
```

**Function:** get\_taxi\_route\_from\_A\_To\_B(String acid, String airport\_code, String startNode\_waypoint\_id, String endNode\_waypoint\_id)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
taxiPlanAtoB = airportInterface.get_taxi_route_from_A_To_B('ULI-SFD235', 'KSF0', 'Gate_01_001', 'Rwy_02_001')
```



**Function:** getDepartureRunway(String acid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
departureRunway = airportInterface.getDepartureRunway('ULI-SFD235').
```

**Function:** getArrivalRunway(String acid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
arrivalRunway = airportInterface.getArrivalRunway('ULI-SFD235')
```

**Function:** getTaxi\_tas\_knots(String acid)

**Return Type:** double

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
taxiSpeed = airportInterface.getTaxi_tas_knots('ULI-SFD235')
```

**Function:** setTaxi\_tas\_knots(String acid, double tas\_knots)

**Return Type:** void

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportInterface.setTaxi_tas_knots('ULI-SFD235', 25.0)
```

**Function:** getAllAirportCodesInGNATS()

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportList = airportInterface.getAllAirportCodesInGNATS()
```

**Function:** getRunwayEnds(String airportId, String runwayId)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportList = airportInterface.getRunwayEnds("KSFO", "RW28R")
```

## AirportInstance API

**Function:** getCode()

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
```

```
airportInterface = environmentInterface.getAirportInterface()  
airport = airportInterface.select_airport("KORD")  
airportCode = airport.getCode()
```

**Function:** getElevation()

**Return Type:** float

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airport = airportInterface.select_airport("KORD")  
airportElevation = airport.getElevation()
```

**Function:** getLatitude()

**Return Type:** float

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airport = airportInterface.select_airport("KORD")  
airportLatitude = airport.getLatitude()
```

**Function:** getLongitude()

**Return Type:** float

**Example:**

```
airportInterface = environmentInterface.getAirportInterface()  
airport = airportInterface.select_airport("KORD")  
airportLongitude = airport.getLongitude()
```

**Function:** getName()

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airport = airportInterface.select_airport("KORD")  
airportName = airport.getName()
```

## TerminalAreaInterface API

**Function:** getAllApproaches(String airport\_code)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface =  
environmentInterface.getTerminalAreaInterface()  
approaches = terminalAreaInterface.getAllApproaches('KORD')
```

**Function:** getAllSids(String airport\_code)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
sids = terminalAreaInterface.getAllSids('KORD')
```

**Function:** getAllStars(String airport\_code)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
stars = terminalAreaInterface.getAllStars('KORD')
```

**Function:** getCurrentApproach(String acid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
currentApproach = terminalAreaInterface.getCurrentApproach('ULI-
SFD235')
```

**Function:** getCurrentSid(String acid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
currentSid = terminalAreaInterface.getCurrentSid('ULI-SFD235')
```

**Function:** getCurrentStar(String acid)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
currentStar = terminalAreaInterface.getCurrentStar('ULI-SFD235')
```

**Function:** getProcedure\_leg\_names(String proc\_type, String proc\_name, String airport\_code)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
sidLegNames = terminalAreaInterface.getProcedure_leg_names("SID",
"SSTIK3", "KSFO")
```

**Function:** getWaypoints\_in\_procedure\_leg(String proc\_type, String proc\_name, String airport\_code, String proc\_leg\_name)

**Return Type:** String[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
waypointNames = terminalAreaInterface.getWaypoints_in_procedure_leg("SID",
"SSTIK3", "KSFO",
"PORTE")
```

**Function:** getClosestWaypoint(float[][] waypointOptions, float[] targetWaypoint)

**Return Type:** int

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
closestWaypointIndex =
terminalAreaInterface.getClosestWaypoint([[37.61, -122.3], [42.9, -
75.61]], [43.9, -77.6])
```

**Function:** calculateWaypointDistance(float latx, float lonx, float laty, float lony)

**Return Type:** double

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
waypointDistance =
terminalAreaInterface.calculateWaypointDistance(37.61, -122.3, 42.9, -
75.61)
```

**Function:** getWaypoint\_Latitude\_Longitude\_deg(String waypoint\_name)

**Return Type:** double[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
waypointLocation =
terminalAreaInterface.getWaypoint_Latitude_Longitude_deg('BOILE')
```

**Function:** getProcedure\_alt\_1(String proc\_type, String proc\_name, String airport\_code, String proc\_leg\_name, String proc\_wp\_name)

**Return Type:** double

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureAlt1 = terminalAreaInterface.getProcedure_alt_1("SID",
"SSTIK3", "KSFO", "PORTE",
"KAYEX")
```

**Function:** getProcedure\_alt\_2(String proc\_type, String proc\_name, String airport\_code, String proc\_leg\_name, String proc\_wp\_name)

**Return Type:** double

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureAlt2 = terminalAreaInterface.getProcedure_alt_2("SID",
"SSTIK3", "KSFO", "PORTE", "KAYEX")
```

**Function:** getProcedure\_speed\_limit(String proc\_type, String proc\_name, String airport\_code, String proc\_leg\_name, String proc\_wp\_name)

**Return Type:** double

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureSpeedLimit =
terminalAreaInterface.getProcedure_speed_limit("SID", "SSTIK3",
"KSFO", "PORTE", "KAYEX")
```

**Function:** getProcedure\_alt\_desc(String proc\_type, String proc\_name, String airport\_code, String proc\_leg\_name, String proc\_wp\_name)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureAltitudeDesc =
terminalAreaInterface.getProcedure_alt_desc("SID", "SSTIK3", "KSFO",
"PORTE", "KAYEX")
```

**Function:** getProcedure\_speed\_limit\_desc(String proc\_type, String proc\_name, String airport\_code, String proc\_leg\_name, String proc\_wp\_name)

**Return Type:** String

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureSpeedLimitDesc =
terminalAreaInterface.getProcedure_speed_limit_desc ("SID", "SSTIK3",
"KSFO", "PORTE", "KAYEX")
```

## **TerrainInterface API**

**Function:** `getElevation(double latDeg, double lonDeg)`

**Return Type:** `double`

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
elevation = terrainAreaInterface.getElevation(34.5, -122.23)
```

**Function:** `getElevationAreaStats(double minLatDeg, double maxLatDeg, double minLonDeg, double maxLonDeg)`

**Return Type:** `double[]`

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
elevationAreaStats = terrainAreaInterface.getElevationAreaStats(34.5,  
-122.23, 36.8, -121.9)
```

**Function:** `getElevationMapBounds()`

**Return Type:** `double[][]`

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
elevationMapBounds = terrainAreaInterface.getElevationMapBounds()
```

**Function:** `setTerrainProfile(double startLat, double endLat, double startLon, double endLon, double resolution)`

**Return Type:** `int`

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
success = terrainAreaInterface.setTerrainProfile(-56, 75, -180, 180,  
0.1)
```

## EntityInterface API

**Function:** `getControllerInterface()`

**Return Type:** `ControllerInterface`

**Example:**

```
entityInterface = gnatsClient.getEntityInterface()  
controllerInterface = entityInterface.getControllerInterface()
```

**Function:** `getPilotInterface()`

**Return Type:** `PilotInterface`

**Example:**

```
entityInterface = gnatsClient.getEntityInterface()  
pilotInterface = entityInterface.getPilotInterface()
```

**Function:** getGroundOperatorInterface()

**Return Type:** GroundOperatorInterface

**Example:**

```
entityInterface = gnatsClient.getEntityInterface()
```

```
groundOperatorInterface = entityInterface.getGroundOperatorInterface ()
```

## WeatherInterface API

**Function:** DownloadWeatherFiles()

**Return Type:** int

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
```

```
weatherInterface = environmentInterface.getWeatherInterface()
```

```
weatherInterface.DownloadWeatherFiles()
```

**Function:** getWind(float timestamp\_sec,  
float latitude\_deg,  
float longitude\_deg,  
float altitude\_ft)

**Return Type:** float[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
```

```
weatherInterface = environmentInterface.getWeatherInterface()
```

```
windValue = weatherInterface.getWind(6600.0, 40.0, -73.0, 20000.0)
```

**Function:** getWeatherPolygons(String ac\_id, double lat\_deg, double lon\_deg, double alt\_ft, double nauticalMile\_radius)

**Return Type:** WeatherPolygon[]

**Example:**

```
environmentInterface = gnatsClient.getEnvironmentInterface()
```

```
weatherInterface = environmentInterface.getWeatherInterface()
```

```
windValue = weatherInterface.getWeatherPolygons("UA123", 48.0, -120.0, 33000.0, 100.0)
```

## ControllerInterface API

**Function:** setDelayPeriod(String acid, AircraftClearance aircraft\_clearance, int seconds)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
setDelayPeriod = controllerInterface.setDelayPeriod('ULI-SFD235',  
AIRCRAFT_CLEARANCE_TAXI_DEPARTING, 10)
```

**Function:** setActionRepeat(String aircraftID, String repeatParameter)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
controllerInterface.setActionRepeat('ULI-SFD235', 'COURSE')
```

**Function:** skipFlightPhase(String aircraftID, String flightPhase)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.skipFlightPhase('ULI-SFD235',  
'FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE')
```

**Function:** setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setWrongAction('ULI-SFD235', 'COURSE',  
'AIRSPEED')
```

**Function:** setActionReversal(String aircraftID, String changeParameter)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setActionReversal('ULI-SFD235', 'COURSE')
```

**Function:** setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setPartialAction('ULI-SFD235', 'VERTICAL_SPEED',  
200, 25)
```

**Function:** skipChangeAction(String aircraftID, String skipParameter)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.skipChangeAction('ULI-SFD235', 'COURSE')
```

**Function:** setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setActionLag('ULI-SFD235', 'COURSE', 10, 0.05, 30)
```

**Function:** setControllerAbsence(string aircraftID, int timeSteps)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setControllerAbsence ('ULI-SFD235', 5)
```



**Function:** releaseAircraftHold(String aircraftID, String approach, String targetWaypoint)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.releaseAircraftHold('ULI-SFD235', 'I07L',  
'FFIXA')
```

**Function:** enableConflictDetectionAndResolution(boolean flag)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.enableConflictDetectionAndResolution(True)
```

**Function:** setCDR\_initiation\_distance\_ft\_surface(float distance)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_initiation_distance_ft_surface(50000.0)
```

**Function:** setCDR\_initiation\_distance\_ft\_terminal(float distance)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_initiation_distance_ft_terminal(50000.0)
```

**Function:** setCDR\_initiation\_distance\_ft\_enroute(float distance)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_initiation_distance_ft_enroute(50000.0)
```

**Function:** setCDR\_separation\_distance\_ft\_surface(float distance)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_separation_distance_ft_surface(50000.0)
```

**Function:** setCDR\_separation\_distance\_ft\_terminal(float distance)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_separation_distance_resolve_ft_terminal(50  
000.0)
```

**Function:** setCDR\_separation\_distance\_resolve\_ft\_enroute(float distance)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_separation_distance_ft_enroute(50000.0)
```

**Function:** enableStrategicWeatherAvoidance()

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
controllerInterface.enableStrategicWeatherAvoidance()
```

**Function:** setWeather\_polygonFile(String pathFilename)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
controllerInterface.setWeather_polygonFile("share/rg/polygons/  
xxxx.dat")
```

**Function:** setWeather\_sigmetFile(String pathFilename)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
controllerInterface.setWeather_sigmetFile("share/tg/weather/  
xxxx.sigmet")
```

**Function:** setTacticalWeatherAvoidance(String waypoint\_name, float duration\_sec)

**Return Type:** int

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
flag = controllerInterface.setTacticalWeatherAvoidance("ABCDE", 100)
```

**Function:** enableMergingAndSpacingAtMeterFix(String airportId, String meterFix, String trailAttribute, float timeInTrail/distanceInTrail)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
controllerInterface.enableMergingAndSpacingAtMeterFix("KPHX",  
"GEELA", "DISTANCE", 4.5)
```

**Function:** disableMergingAndSpacingAtMeterFix(String airportId, String meterFix)

**Return Type:** void

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
controllerInterface.enableMergingAndSpacingAtMeterFix("KPHX", "GEELA")
```

**Function:** getCDR\_status()

**Return Type:** Object[][]

**Example:**

```
controllerInterface = entityInterface.getControllerInterface()
```

```
cdrStatus = controllerInterface.getCDR_status()
```

## **RiskMeasuresInterface API**

**Function:** getFlightsInRange(String aircraftID, float minLatitude, float maxLatitude, float minLongitude, float maxLongitude, float minAltitude\_ft, float maxAltitude\_ft)

**Return Type:** Object

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()
flightsInRange = riskMeasuresInterface.getFlightsInRange('ULI-SFD235',
37, 38, -122, -121, 3000, 4000)
```

**Function:** getDistanceToRunwayThreshold(String aircraftID)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()
distance = riskMeasuresInterface.getDistanceToRunwayThreshold ('ULI-SFD235')
```

**Function:** getDistanceToRunwayEnd(String aircraftID)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()
distance = riskMeasuresInterface.getDistanceToRunwayEnd ('ULI-SFD235')
```

**Function:** getVelocityAlignmentWithRunway(String aircraftID, String procedure)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()
alignmentAngle = riskMeasuresInterface.
GetVelocityAlignmentWithRunway ('ULI-SFD235', 'DEPARTURE')
```

**Function:** getPassengerCount(String aircraftType)

**Return Type:** int

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()
passengerCount = riskMeasuresInterface.getPassengerCount ('A306')
```

**Function:** getAircraftCost(String aircraftID)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()
flightsInRange = riskMeasuresInterface.getAircraftCost ('A306')
```

**Function:** getFlightsInWakeVortexRange(String refAircraftId, float envelopeStartLength, float envelopeStartBreadth, float envelopeEndLength, float envelopeEndBreadth, float envelopeRange, float envelopeAltitudeDrop)

**Return Type:** Object

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()
riskMeasuresInterface.getFlightsInWakeVortexRange('SWA1897', 200,
150, 400, 350, 2, 50)
```

**Function:** setAircraftBookValue(String aircraftId, float aircraftBookValue)

**Return Type:** int

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setAircraftBookValue('SWA1897', 5.6)
```

**Function:** setCargoWorth(String aircraftId, float cargoWorth)

**Return Type:** int

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setCargoWorth('SWA1897', 1.2)
```

**Function:** setPassengerLoadFactor(String aircraftId, float paxLoadFactor)

**Return Type:** int

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setPassengerLoadFactor('SWA1897', 0.72)
```

**Function:** getAircraftBookValue(String aircraftId)

**Return Type:** float

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
aircraftBookValue =  
riskMeasuresInterface.getAircraftBookValue('SWA1897')
```

**Function:** getCargoWorth(String aircraftId)

**Return Type:** float

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
cargoWorth = riskMeasuresInterface.getCargoWorth('SWA1897')
```

**Function:** getPassengerLoadFactor(String aircraftId)

**Return Type:** float

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
paxLoadFactor =  
riskMeasuresInterface.getPassengerLoadFactor('SWA1897')
```

**Function:** setTouchdownPointOnRunway(String aircraftId, float latitude, float longitude)

**Return Type:** float

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setTouchdownPointOnRunway('SWA1897', 32.423, -  
123.123)
```

**Function:** getTouchdownPointOnRunway(String aircraftId)

**Return Type:** float

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
print riskMeasuresInterface.getTouchdownPointOnRunway('SWA1897')
```

**Function:** setTakeOffPointOnRunway(String aircraftId, float latitude, float longitude)

**Return Type:** float

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setTakeOffPointOnRunway('SWA1897', 37.625735, -  
122.368191)
```

**Function:** getTakeOffPointOnRunway(String aircraftId)

**Return Type:** float

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
print riskMeasuresInterface.getTakeOffPointOnRunway('SWA1897')
```

**Function:** getL1Distance(String airportId, String aircraftId1, String aircraftId2)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getL1Distance('KSFO', 'SWA1897', 'SWA1898')
```

**Function:** getDistanceToPavementEdge(String airportId, String aircraftId)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getDistanceToPavementEdge('KSFO', 'SWA1897')
```

**Function:** getL2Distance(String airportId, String vehicle1, String vehicle2)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getL2Distance('KLAX', 'CAR123', 'SWA1897')
```

**Function:** getTimeToObjectOfInterest(String airportId, String vehicle1, float latitude, float longitude)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getTimeToObjectOfInterest('KLAX', 'CAR123', 37,  
-122)
```

**Function:** getDistanceToObjectOfInterest(String airportId, String vehicle1, float latitude, float longitude)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getDistanceToObjectOfInterest('KLAX', 'CAR123',  
37, -122)
```

**Function:** getTimeToVehicleContact(String vehicle1, String vehicle2)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getTimeToVehicleContact('SWA1897', 'TRUCK123')
```

**Function:** getTimeToPavementEdge(String vehicleId)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getTimeToPavementEdge('SWA1897')
```

**Function:** getRateOfLineOfSightChange(String aircraftID1, String aircraftID2)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfLineOfSightChange('SWA1897',  
'SWA1898')
```

**Function:** getRegionOfInterest()

**Return Type:** double[][]

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRegionOfInterest()
```

**Function:** setRegionOfInterest(double[] regionBounds)

**Return Type:** int

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setRegionOfInterest([37, 38, -122, -121])
```

**Function:** getAircraftInRegionOfRegard(String aircraft)

**Return Type:** String[]

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getAircraftInRegionOfRegard('SWA1897')
```

**Function:** getRegionOfRegard(String aircraft)

**Return Type:** double[][]

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRegionOfRegard('SWA1897')
```

**Function:** setRegionOfRegard(String aircraft, double[minLat, minLon, maxLat, maxLon, minAlt, maxAlt] regionBounds)

**Return Type:** int

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setRegionOfRegard('ULI-SFD235', 37, 38, -122, -  
121, 3000, 4000)
```

**Function:** getRateOfApproachToPavementEdge(String aircraftID, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToPavementEdge('SWA1897', 7)
```

**Function:** getRateOfApproachToVehicle(String vehicle1ID, String vehicle2ID, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToVehicle('SWA1897', 'BUS123',  
7)
```

**Function:** getRateOfApproachToVehicle(String vehicle1ID, String vehicle2ID, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToVehicle('SWA1897', 'BUS123',  
7)
```

**Function:** getRateOfApproachToWaypoint(String aircraftID, String Waypoint, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToWaypoint('SWA1897', 'DUMBA',  
7)
```

**Function:** getRateOfApproachToEvent(String aircraftID, String eventCenterLatitude, String eventCenterLongitude, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToEvent('SWA1897', 37, -121,  
7)
```

**Function:** getRateOfApproachToWeatherEvent(String aircraftID, [WeatherBounds])

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToWeatherEvent('SWA1897', [37,  
38, -122, -121])
```

**Function:** getRateOfApproachToWakeVortex(String leadingAircraftID, String trailingAircraftID)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToWakeVortex('SWA1897',  
'SWA1898')
```

**Function:** getRateOfVelocityAlignmentToRunway(String aircraftID, String procedure, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfVelocityAlignmentToRunway('SWA1897',  
'HYDDR1', 7)
```

**Function:** getRateOfApproachToRunwayEnd(String aircraftID, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToRunwayEnd('SWA1897', 7)
```

**Function:** getRateOfApproachToRunwayThreshold(String aircraftID, int timesteps)

**Return Type:** double

**Example:**

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getRateOfApproachToRunwayThreshold('SWA1897',  
7)
```

## PilotInterface API

**Function:** setActionRepeat(String aircraftID, String repeatParameter)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setActionRepeat('ULI-SFD235', 'COURSE')
```

**Function:** skipFlightPhase(String aircraftID, String flightPhase)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.skipFlightPhase('ULI-SFD235',  
'FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE')
```



**Function:** setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setWrongAction('ULI-SFD235', 'COURSE', 'AIRSPEED');
```

**Function:** setActionReversal(String aircraftID, String changeParameter)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setActionReversal('ULI-SFD235', 'COURSE')
```

**Function:** setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setPartialAction('PLEASE_ENTER_AIRCRAFT_CALLSIGN_HERE',  
, 'VERTICAL_SPEED', 200, 25);
```

**Function:** skipChangeAction(String aircraftID, String skipParameter)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.skipChangeAction('ULI-SFD235', 'COURSE')
```

**Function:** setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setActionLag('ULI-SFD235', 'COURSE', 10, 0.05, 30)
```

**Function:** setFlightPlanReadError(String aircraftID, String errorParameter, float updatedValue)

**Return Type:** int

**Example:**

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setFlightPlanReadError('ULI-SFD235', 'VERTICAL_SPEED',  
398.0)
```

## GroundOperatorInterface API

**Function:** setGroundOperatorAbsence(String groundVehicleId, int timeSteps)

**Return Type:** int

**Example:**

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()
```

groundOperatorInterface.setGroundOperatorAbsence('BUS123', 4)

**Function:** setActionRepeat(String groundVehicleId, String repeatParameter)

**Return Type:** int

**Example:**

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setActionRepeat('BUS123', 'SPEED')
```

**Function:** setVehicleContact(String groundVehicleId)

**Return Type:** int

Interface:GroundOperatorInterface

**Example:**

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setVehicleContact('BUS123')
```

**Function:** setActionReversal(String groundVehicleId, String changeParameter)

**Return Type:** int

**Example:**

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setActionReversal('BUS123', 'COURSE')
```

**Function:** setPartialAction(String groundVehicleId, String changeParameter, float originalTarget, float percentage),

**Return Type:** int

**Example:**

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setPartialAction('BUS123', 'SPEED', 8, 50)
```

**Function:** setActionLag(String groundVehicleId, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)

**Return Type:** int

**Example:**

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setActionLag('BUS123', 'SPEED', 10, 0.5, 30)
```

## WeatherPolygon API

**Function:** getX\_data()

**Return Type:** double[]

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()
```

```
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
x_data_array = weatherPolygons[0].getX_data()
```

**Function:** getY\_data()

**Return Type:** double[]

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
y_data_array = weatherPolygons[0].getY_data()
```

**Function:** getNum\_vertices()

**Return Type:** int

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getNum_vertices()
```

**Function:** getCcw\_flag()

**Return Type:** boolean

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getCcw_flag()
```

**Function:** getXmin()

**Return Type:** double

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getXmin()
```

**Function:** getXmax()

**Return Type:** double

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getXmax()
```

**Function:** getYmin()

**Return Type:** double

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)
```

```
weatherPolygons[0].getYmin()
```

**Function:** getYmax()

**Return Type:** double

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getYmax()
```

**Function:** getX\_centroid()

**Return Type:** double

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getX_centroid()
```

**Function:** getY\_centroid()

**Return Type:** double

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getY_centroid()
```

**Function:** getPoly\_type()

**Return Type:** String

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getPoly_type()
```

**Function:** getStart\_hour()

**Return Type:** int

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getStart_hour()
```

**Function:** getEnd\_hour()

**Return Type:** int

**Example:**

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getEnd_hour()
```