

Python, R, MATLAB, Scilab & GNU Octave API for GNATS

Linux and Windows 10 Distribution

Updated: 11.11, 2020

GNATSClient API

No.	Type	Method and Description
1	EntityInterface	getEntityInterface() Returns a reference to the EntityInterface.
2	EnvironmentInterface	getEnvironmentInterface() Returns a reference to the EnvironmentInterface.
3	EquipmentInterface	getEquipmentInterface() Returns a reference to the EquipmentInterface.
4	RiskMeasuresInterface	getRiskMeasuresInterface() Returns a reference to the RiskMeasuresInterface.
5	RiskMeasuresInterface	getRiskMInterface() Returns a reference to the RiskMeasuresInterface, an alias for Scilab platform (Due to syntax restrictions).
6	SimulationInterface	getSimulationInterface() Returns a reference to the SimulationInterface.
7	GNATSClient	start() Initialize GNATS Client and returns an instance.
8	void	Stop() Stop GNATS Client functionality.

SimulationInterface API

No.	Type	Method and Description
1	void	clear_trajectory() Cleanup the trajectory data.
2	float	get_curr_sim_time() Get the current simulation timestamp.
3	long	get_sim_id() Get the simulation id.
4	int	get_runtime_sim_status() Get the runtime status of the trajectory propagation. Value definition: GNATS_SIMULATION_STATUS_READY = 0 GNATS_SIMULATION_STATUS_START = 1 GNATS_SIMULATION_STATUS_PAUSE = 2 GNATS_SIMULATION_STATUS_RESUME = 3 GNATS_SIMULATION_STATUS_STOP = 4 GNATS_SIMULATION_STATUS_ENDED = 5 When the trajectory propagation finishes, the status will be changed to GNATS_SIMULATION_STATUS_ENDED.
5	void	pause() Pause the trajectory propagation process. This function is disabled in real-time simulation mode.

6	void	resume() Resume the trajectory propagation process.
7	void	resume(long t_duration) Resume the trajectory propagation process and process data for a specified duration of time (in seconds).
8	int	setupSimulation(int t_total_propagation_period, int t_step) Setup the trajectory propagation process. Description of the arguments: t_total_propagation_period: Total period of time of propagation in integer seconds. t_step: Time step in integer seconds.
9	int	setupSimulation(float t_total_propagation_period, float t_step) Setup the trajectory propagation process. Description of the arguments: t_total_propagation_period: Total period of time of propagation in decimal seconds. t_step: Time step in decimal seconds.
10	int	setupSimulation(int t_total_propagation_period, int t_step_surface, int t_step_terminal, int t_step_airborne) Setup the trajectory propagation process. Description of the arguments: t_total_propagation_period: Total period of time of propagation in integer seconds. t_step_surface: Time step for surface(origin/destination airports) propagation in integer seconds. t_step_terminal: Time step for terminal area(from airport altitude to 10000 feet) propagation in integer seconds. t_step_surface: Time step for airborne(altitude above 10000 feet) propagation in integer seconds.
11	int	setupSimulation(float t_total_propagation_period, float t_step_surface, float t_step_terminal, float t_step_airborne) Setup the trajectory propagation process. Description of the arguments: t_total_propagation_period: Total period of time of propagation in decimal seconds. t_step_surface: Time step for surface(origin/destination airports) propagation in decimal seconds. t_step_terminal: Time step for terminal area(from airport altitude to 10000 feet) propagation in decimal seconds. t_step_surface: Time step for airborne(altitude above 10000 feet) propagation in

		decimal seconds.
12	void	start () Start the trajectory propagation process.
13	void	start (long t_duration) Start the trajectory propagation process for specified duration, in seconds.
14	void	startRealTime () Start the real-time trajectory propagation. GNATS Server runs trajectory propagation with 30-second time step, synchronized with real-time clock.
15	void	startRealTime_singleUser () Start the real-time trajectory propagation while in single-user mode. GNATS Server runs trajectory propagation with 30-second time step, synchronized with real-time clock. Aircraft state data can be imported from an external aircraft simulator to the GNATS Server. Please refer to the <i>XPlane</i> simulation example for the details.
16	void	stop () Stop the trajectory propagation process.
17	void	write_trajectories (String output_file) Write trajectory data into a file. File format supported: .csv, .kml, .xml
18	void	request_aircraft (String ac_id) Request aircrafts from GNATS Server which is the administrator for multi-user simulation. The aircraft pertaining to the callsign given in the argument ac_id will be assigned to the client based on First-Come-First-Serve policy.
19	void	request_groundVehicle (String gv_id) Request ground vehicles from GNATS Server which is the administrator for multi-user simulation. The ground vehicle pertaining given in the argument gv_id will be assigned to the client based on First-Come-First-Serve policy. This function won't work due to absence of CIFP file.
20	void	externalAircraft_create_trajectory_profile (String ac_id, String ac_type, String origin_airport, String destination_airport, float cruise_altitude_ft, float cruise_tas_knots, double latitude_deg, double longitude_deg, double altitude_ft, double rocd_fps, double tas_knots,)

		<pre>double course_deg, String flight_phase)</pre> <p>Create the trajectory profile and set the initial state of an external aircraft in GNATS.</p>
21	void	<pre>externalAircraft_inject_trajectory_state_data(String ac_id, double latitude_deg, double longitude_deg, double altitude_ft, double rocd_fps, double tas_knots, double course_deg, String flight_phase, long timestamp_utc_millisec)</pre> <p>Send external aircraft state data from the client to the server.</p>

Simulation Status Enum Values

Values
GNATS_SIMULATION_STATUS_READY
GNATS_SIMULATION_STATUS_START
GNATS_SIMULATION_STATUS_PAUSE
GNATS_SIMULATION_STATUS_RESUME
GNATS_SIMULATION_STATUS_STOP
GNATS_SIMULATION_STATUS_ENDED

EquipmentInterface API

No.	Type	Method and Description
1	AircraftInterface	getAircraftInterface() Returns a reference to the AircraftInterface.
2	GroundVehicleInterface	getGroundVehicleInterface() Returns a reference to the GroundVehicleInterface.
3	CNSInterface	getCNSInterface() Returns a reference to the CNSInterface.
4	ADBDDataInterface	getADBDDataInterface() Returns a reference to the ADBDataInterface.

AircraftInterface API

No.	Type	Method and Description
1	int	load_aircraft(String trx_file, String mfl_file) Load aircraft data.
2	boolean	validate_flight_plan_record(String string_track, String string_fp_route, int mfl_ft)

		Validator of flight plan record.
3	int	release_aircraft() Cleanup aircraft data.
4	String[]	getAircraftIds(float minLatitude, float maxLatitude, float minLongitude, float maxLongitude, float minAltitude_ft, float maxAltitude_ft) Get IDs of all aircraft within the min/max range of latitude, longitude and/or altitude ranges.
5	String[]	getAllAircraftId() Get the complete list of all aircraft IDs in the GNATS simulation.
6	Aircraft	select_aircraft(String aircraft_id) Get an aircraft object with aircraft ID.
7	int	synchronize_aircraft_to_server(Aircraft aircraft) Push aircraft object to the server and synchronize the data. Return value indicates the server operation response: 0 is success. 1 indicates error.

Aircraft Instance API

No.	Type	Method and Description
1	int	delay_departure(int seconds) Postpone the departure time of the current aircraft by certain seconds. If the aircraft has already departed, the departure time will not be changed.
2	String	getAcid() Get aircraft ID. Example: UA555
3	float	getAltitude_ft() Get the current altitude in feet.
4	float	getCruise_alt_ft() Get the cruise altitude in feet.
5	float	getCruise_tas_knots() Get cruise speed.
6	float	getDeparture_time_sec() Get departure time in seconds.
7	float	getDestination_airport_elevation_ft() Get the elevation of the destination airport.
8	int	getFlight_phase() Get current flight phase. Flight phase is presented as an integer in the range 1-25. Please refer to “Flight Phase Enum Values” for the definition of each phase.
9	float[]	getFlight_plan_latitude_array() Get the latitude array of the flight plan.
10	int	getFlight_plan_length() Get the number of records in the flight plan.
11	float[]	getFlight_plan_longitude_array() Get the longitude array of the flight plan.
12	String[]	getFlight_plan_waypoint_name_array() Get the array of waypoint names in the flight plan.
13	String[]	getFlight_plan_alt_desc_array() Get the array of flight plan altitude constraint description. Refer to ARINC 424-

		18 Section 5.29 for details.
14	double[]	getFlight_plan_alt_1_array() Get the array of flight plan altitude first bound. Refer to ARINC 424-18 Section 5.30 for details.
15	double[]	getFlight_plan_alt_2_array() Get the array of flight plan altitude second bound. Refer to ARINC 424-18 Section 5.30 for details.
16	double[]	getFlight_plan_speed_limit_array() Get the array of flight plan speed limits. Refer to ARINC 424-18 Section 5.72 for details.
17	String[]	getFlight_plan_speed_limit_desc_array() Get the array of flight plan speed limit constraint description. Refer to ARINC 424-18 Section 5.261 for details.
18	float	getFpa_rad() Get the current flight path angle, radians.
19	float	getCourse_rad() Get the current course, radians.
20	int	getLanded_flag() Get the flag value indicating if the aircraft has landed.
21	float	getLatitude_deg() Get the current latitude, degrees.
22	float	getLongitude_deg() Get the current longitude, degrees.
23	float	getOrigin_airport_elevation_ft() Get the elevation of the origin airport, feet.
24	float	getRocd_fps() Get the rate of climb or descent in feet per second.
25	int	getSector_index() Get the current sector index.
26	int	getTarget_waypoint_index() Get the array index of the target waypoint in the flight plan
27	String	getTarget_waypoint_name() Get the target waypoint name.
28	float	getTas_knots() Get the current speed.
29	int	getToc_index() Get the flight plan array index of the top-of-climb waypoint.
30	int	getTod_index() Get the flight plan array index of the top-of-descent waypoint.
31	void	setAltitude_ft(float altitude_ft) Set a new value of altitude in feet.
32	void	setCruise_alt_ft(float cruise_alt_ft) Set a new value of cruise altitude in feet.
33	void	setCruise_tas_knots(float cruise_tas_knots) Set a new value of cruise speed.
34	void	setFlight_plan_latitude_deg(int index, float latitude_deg)

		Set the latitude of the n-th waypoint.
35	void	setFlight_plan_longitude_deg(int index, float longitude_deg) Set the longitude of the n-th waypoint.
36	void	setCourse_rad(float course_rad) Set a new value of course.
37	void	setLatitude_deg(float latitude_deg) Set a new value of latitude.
38	void	setLongitude_deg(float longitude_deg) Set a new value of longitude.
39	void	setRocd_fps(float rocd_fps) Set a new value of rate of climb or descent in feet per second.
40	void	setTarget_waypoint_latitude_deg(float latitude_deg) Set a new value for the target (Next) waypoint latitude..
41	void	setTarget_waypoint_longitude_deg(float longitude_deg) Set a new value for the target (next) waypoint longitude.
42	void	setTas_knots(float tas_knots) Set a new value for speed, in knots.

GroundVehicle Interface API

No.	Type	Method and Description
1	int	load_groundVehicle(String trx_file) Load all the ground vehicles from the TRX file. This function won't work for airports outside continental US.
2	int	release_groundVehicle() Clear all ground vehicle drive plan data. This function won't work for airports outside continental US.
3	String[]	getAllGroundVehicleIds() Get callsigns of all ground vehicles loaded in GNATS. This function won't work for airports outside continental US.
4	GroundVehicle	select_groundVehicle(String groundVehicleId) Get GroundVehicle object for a given vehicle callsign. This function won't work for airports outside continental US.
5	String[]	GetAssignedGroundVehicleIds() Get IDs of ground vehicles which are assigned to current session user. This function won't work for airports outside continental US.
6	String[]	getAssignedGroundVehicleIds(String username) Get IDs of ground vehicles which are assigned to the user. This function won't work for airports outside continental US.
7	int	externalGroundVehicle_create_trajectory_profile(String groundVehicleId, String aircraft, String airport, float latitude, float longitude, float speed, float course) Create profile of an external ground vehicle. This function won't work for airports outside continental US.
8	int	externalGroundVehicle_inject_trajectory_state_data(String groundVehicleId, String aircraftInService, float latitude, float

		longitude, float speed, float course) Update profile of an existing external ground vehicle. This function won't work for airports outside continental US.
--	--	--

GroundVehicle Instance API

No.	Type	Method and Description
1	String	getGvid() Get ground vehicle ID. This function won't work for airports outside continental US.
2	String	getAirportId() Get airport ICAO code of the ground vehicle. This function won't work for airports outside continental US.
3	String	getAircraftInService() Get aircraft ID being serviced by ground vehicle. This function won't work for airports outside continental US.
4	boolean	getFlag_external_groundvehicle() Get the flag to determine if the ground vehicle is external. TRUE if the ground vehicle is external. This function won't work for airports outside continental US.
5	String	getAssigned_user() Get the assigned user. This function won't work for airports outside continental US.
6	float	getLatitude() Get the current latitude, degrees. This function won't work for airports outside continental US.
7	void	setLatitude(float latitude) Set the new value to current latitude, degrees. This function won't work for airports outside continental US.
8	float	getLongitude() Get the current longitude, degrees. This function won't work for airports outside continental US.
9	void	setLongitude(float longitude) Set the new value to current longitude, degrees. This function won't work for airports outside continental US.
10	float	getAltitude() Get the current altitude in feet. This function won't work for airports outside continental US.
11	float	getSpeed() Get the current speed. This function won't work for airports outside continental US.
12	void	setSpeed(float speed) Set the current speed. This function won't work for airports outside continental US.
13	float	getCourse() Get the current course. This function won't work for airports outside continental US.
14	void	setCourse(float course)

		Set the new value to the current course. This function won't work for airports outside continental US.
15	float	getDeparture_time() Get the departure time. This function won't work for airports outside continental US.
16	float[]	getDrive_plan_latitude_array() Get the array of latitude of the drive plan. This function won't work for airports outside continental US.
17	float[]	getDrive_plan_longitude_array() Get the array of longitude of the drive plan. This function won't work for airports outside continental US.
18	int	getDrive_plan_length() Get the number of records in the drive plan. This function won't work for airports outside continental US.
19	String[]	getDrive_plan_waypoint_name_array() Get the array of waypoint names of the drive plan. This function won't work for airports outside continental US.
20	int	getTarget_waypoint_index() Get the array index of the drive plan data corresponding to the target waypoint. This function won't work for airports outside continental US.
21	String	getTarget_waypoint_name() Get the name of the drive plan data corresponding to the target waypoint. This function won't work for airports outside continental US.
22	void	setDrive_plan_latitude(int index, float latitude) Set the latitude of the n-th drive plan waypoint, degrees. This function won't work for airports outside continental US.
23	void	setDrive_plan_longitude(int index, float longitude) Set the longitude of the n-th drive plan waypoint, degrees. This function won't work for airports outside continental US.

CNSInterface API

No.	Type	Method and Description
1	double[]	getLineOfSight(double observerLat, double observerLon, double observerAlt, double targetLat, double targetLon, double targetAlt) Computes the line of sight between source and target, returns range, azimuth, and elevation along with masking due to terrain or earth's curvature. observerLat: Latitude at the observer's location, degrees. observerLon: Longitude of observer's location, degrees. observerAlt: Observer's altitude, feet. targetLat: Latitude at the target's location, feet. targetLon: Longitude of target's position, feet. targetAlt: Altitude of target, feet. Array as (Range (ft), Azimuth (degree), Elevation(degree), Masking (boolean)) of target relative to the observer. The Masking boolean can assume values: 0: No Masking, 1: Terrain Masking, 2: Masking due to the curvature of Earth.
2	int	setNavigationLocationError(String aircraftId, String

		parameter, double bias, double drift, double scaleFactor, double noiseVariance, int scope) Sets Latitude/Longitude navigation errors for aircraft Navigation System. parameter: String containing "LATITUDE" or "LONGITUDE". bias: Bias to be applied to original value. drift: Drift to be applied to original value multiplied by flight time. scaleFactor: scale factor error that would lead to erroneous instrument values. noiseVariance: Variance of noise to be applied, assuming zero mean Gaussian distribution. scope: 0 for errors to reflect on flight deck systems only, 1 to include errors in the ADS-B transmission of the aircraft states.
3	int	setNavigationAltitudeError(String aircraftId, double bias, double noiseVariance, int scope) Sets altitude errors in the aircraft Navigation System. bias: Bias to be applied to original value. noiseVariance: Variance of noise to be applied, assuming zero mean Gaussian distribution. scope: 0 for errors to reflect on flight deck systems only, 1 to include errors in the ADS-B transmission of the aircraft altitude.
4	int	setRadarError(String airportId, String parameter, double originalValue, double bias, double noiseVariance, int scope) Applies range, elevation, azimuth errors to the ground radar at an airport. airportId: ICAO code of airport parameter: String containing RANGE, ELEVATION, or AZIMUTH originalValue: The initial true value of the parameter bias: Bias to be applied to original value. noiseVariance: Variance of noise to be applied, assuming zero mean Gaussian distribution. scope: 0 for errors in the ground systems only, 1 to include transmission to aircraft.

ADBDDataInterface API

No.	Type	Method and Description
1	double	getADB_cruiseTas(String ac_type, double altitude_ft) Get cruise speed.
2	double	getADB_climbRate_fpm(String ac_type, double flight_level, String adb_mass) Get climb rate in feet per minute.
3	double	getADB_climbTas(String ac_type, double altitude_ft) Get climb speed.
4	double	GetADB_descentRate_fpm(String ac_type, double flight_level, String adb_mass) Get descent rate in feet per minute.
5	double	getADB_descentTas(String ac_type, double altitude_ft) Get descent speed.

Flight Phase Enum Values

Values

FLIGHT_PHASE_ORIGIN_GATE

FLIGHT_PHASE_PUSHBACK

FLIGHT_PHASE_RAMP_DEPARTING

FLIGHT_PHASE_TAXI_DEPARTING

FLIGHT_PHASE_RUNWAY_THRESHOLD_DEPARTING

FLIGHT_PHASE_TAKEOFF

FLIGHT_PHASE_CLIMBOUT

FLIGHT_PHASE_HOLD_IN_DEPARTURE_PATTERN

FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE

FLIGHT_PHASE_TOP_OF_CLIMB

FLIGHT_PHASE_CRUISE

FLIGHT_PHASE_HOLD_IN_ENROUTE_PATTERN

FLIGHT_PHASE_TOP_OF_DESCENT

FLIGHT_PHASE_INITIAL_DESCENT

FLIGHT_PHASE_HOLD_IN_ARRIVAL_PATTERN

FLIGHT_PHASE_APPROACH

FLIGHT_PHASE_FINAL_APPROACH

FLIGHT_PHASE_GO_AROUND

FLIGHT_PHASE_TOUCHDOWN

FLIGHT_PHASE_LAND

FLIGHT_PHASE_EXIT_RUNWAY

FLIGHT_PHASE_TAXI_ARRIVING

FLIGHT_PHASE_RUNWAY_CROSSING

FLIGHT_PHASE_RAMP_ARRIVING

FLIGHT_PHASE_DESTINATION_GATE

FLIGHT_PHASE LANDED

EnvironmentInterface API

No.	Type	Method and Description
1	void	load_rap(String wind_dir) Load wind RAP file. RAP: NOAA Rapid Refresh wind data
2	int	release_rap() Clean up the RAP data.
3	AirportInterface	getAirportInterface() Returns a reference to the AirportInterface.
4	TerrainInterface	getTerrainInterface() Returns a reference to the TerrainInterface.
5	TerminalAreaInterface	getTerminalAreaInterface() Returns a reference to the TerminalAreaInterface.
6	WeatherInterface	getWeatherInterface() Returns a reference to the WeatherInterface.
7	String[]	getCenterCodes() Returns a String array of all center codes.
8	String	getCurrentCenter(String aircraftId) Returns the center where the given aircraft is located.
9	String[]	getFixesInCenter(String centerId) Returns a String array of all fixes in a center.

AirportInterface API

No.	Type	Method and Description
1	Airport	select_airport(String airport_code) Get an Airport object instance by a given airport code. This function won't work for airports outside continental US.
2	String	getArrivalAirport(String acid) Get the arrival airport of the requested aircraft. This function won't work for airports outside continental US.
3	String	getDepartureAirport(String acid) Get the departure airport for the requested aircraft. This function won't work for airports outside continental US.
4	double[]	getLocation(String airport_code)

		Get the latitude and longitude of the requested airport. Return an array containing the latitude and longitude. This function won't work for airports outside continental US.
5	String	getClosestAirport(double latitude, double longitude) Get the code of the airport closest to the given position. This function won't work for airports outside continental US.
6	String[]	getAirportsWithinMiles(double lat_deg, double lon_deg, double miles) Get all the airports within “miles” range of the given latitude-longitude location. This function won't work for airports outside continental US.
7	String	getFullName(String airportid) Get the full name corresponding to the given airport code. This function won't work for airports outside continental US.
8	Object[]	getAllRunways(String airport_code) Get all the runways at a given airport. The returned data is an array. Each element of the array consists of: - Runway name - Waypoint ID This function won't work for airports outside continental US.
9	String[]	getRunwayExits(String airport_code, String runway_id) Get all the exits at a given runway ID, at a given airport code. This function won't work for airports outside continental US.
10	Object[]	getLayout_node_map(String airport_code) Get the mapping of nodes and the sequence numbers of the surface traffic network at a given airport. The returned data is an array. Each array element consists of: - Waypoint node ID - Node sequence number This function won't work for airports outside continental US.
11	Object[]	getLayout_node_data(String airport_code) Get the waypoint node data at a given airport. The returned data is an array. Each array element consists of: - Node sequence number - Latitude - Longitude This function won't work for airports outside continental US.
12	Object[]	getLayout_links(String airport_code) Get links joining the waypoint nodes representing ground layout (runways, taxiways, ramps, and gates) of a given airport which represents the connection of routes between them. The returned data is an array. Each array element consists of: - Node 1 sequence number - Node 2 sequence number This function won't work for airports outside continental US.

13	String[]	getSurface_taxi_plan(String acid, String airport_code) Get the surface taxi plan of a given aircraft ID at an airport code. Returns an array of all the waypoint IDs in sequential order. This function won't work for airports outside continental US.
14	int	generate_surface_taxi_plan(String acid, String airport_code, String startNode_waypoint_id, String endNode_waypoint_id, String runway_name) Generate taxi plan and load it in GNATS. The function arguments are: acid: Aircraft ID airport_code: Airport code startNode_waypoint_id: Starting waypoint ID endNode_waypoint_id: Ending waypoint ID runway_name: Name of runway Important Note: This function does need the users to specify the V2 for departing aircraft or the touchdown point for arriving aircraft. Return value: 0 means success. 1 means error. This function won't work for airports outside continental US.
15	int	setUser_defined_surface_taxi_plan(String acid, String airport_code, String[] user_defined_waypoint_ids) Set user-defined surface taxi plan and load it into GNATS. Return value: 0 means success. 1 means error. This function won't work for airports outside continental US.
16	String[]	get_taxi_route_from_A_To_B(String acid, String airport_code, String startNode_waypoint_id, String endNode_waypoint_id) Generate a taxi route from waypoint A to the waypoint B. Note that this function only returns an array of waypoint IDs. This function won't work for airports outside continental US.
17	String	getDepartureRunway(String acid) Get the departure runway of the given aircraft. If a departure taxi plan does not exist for the aircraft, no result will be returned. This function won't work for airports outside continental US.
18	String	getArrivalRunway(String acid) Get the arrival runway of the given aircraft. If an arrival taxi plan does not exist, no result will be returned. This function won't work for airports outside continental US.
19	double	getTaxi_tas_knots(String acid) Get the surface taxi speed of the given aircraft, knots. This function won't work for airports outside continental US.
20	void	setTaxi_tas_knots(String acid, double tas_knots) Set the surface taxi speed of the given aircraft, knots. This function won't work for airports outside continental US.
21	String[]	getAllAirportCodesInGNATS()

		Get ICAO codes for all 57 airports modeled in GNATS. This function won't work for airports outside continental US.
22	String[]	getRunwayEnds(String airportId, String runwayId) Get runway end node waypoints for given airport. This function won't work for airports outside continental US.

Airport Instance API

No.	Type	Method and Description
1	String	getCode() Get the airport code. This function won't work for airports outside continental US.
2	float	getElevation() Get the elevation of the airport in feet. This function won't work for airports outside continental US.
3	float	getLatitude() Get the latitude of the airport. This function won't work for airports outside continental US.
4	float	getLongitude() Get the longitude of the airport. This function won't work for airports outside continental US.
5	String	getName() Get the full name of the airport. This function won't work for airports outside continental US.

TerminalAreaInterface API

No.	Type	Method and Description
1	String[]	getAllApproaches(String airport_code) Get all the Approach Procedures available at the given airport. This function won't work without FAA CIFP file.
2	String[]	getAllSids(String airport_code) Get all the Standard Instrument Departure (SID) Procedures at the given airport. This function won't work without FAA CIFP file. For International airports, SID procedures can be found at GNATS_Server/share/procedureData/SID.csv
3	String[]	getAllStars(String airport_code) Get all the Standard Terminal Arrival (STAR) Procedures at the given airport. This function won't work without FAA CIFP file. For International airports, STAR procedures can be found at GNATS_Server/share/procedureData/STAR.csv
4	String	getCurrentApproach(String acid) Get the current Approach Procedure at the given airport for the given flight. This function won't work without FAA CIFP file.
5	String	getCurrentSid(String acid) Get the current SID Procedure at the given airport for the given flight. This function won't work without FAA CIFP file.
6	String	getCurrentStar(String acid) Get the current STAR procedure at the given airport for the given aircraft flight. This function won't work without FAA CIFP file.
7	String[]	getProcedure_leg_names(String proc_type, String proc_name, String airport_code)

		<p>Get the leg names at the given airport code, procedure type and procedure name. The arguments are:</p> <p>proc_type: Procedure type. The valid values are limited to "SID", "STAR" and "APPROACH".</p> <p>proc_name: Name of the procedure.</p> <p>airport_code: Airport code. This function won't work without FAA CIFP file.</p>
8	String[]	<p>getWaypoints_in_procedure_leg(String proc_type, String proc_name, String airport_code, String proc_leg_name)</p> <p>Get the waypoints at the given airport code, procedure type, procedure name and leg name. Arguments:</p> <p>proc_type: Procedure type. The valid values are limited to "SID", "STAR" and "APPROACH".</p> <p>proc_name: Name of the procedure.</p> <p>airport_code: Airport code.111</p> <p>proc_leg_name: Name of the procedure leg.</p> <p>This function won't work without FAA CIFP file.</p>
9	double[]	<p>getWaypoint_Latitude_Longitude_deg(String waypoint_name)</p> <p>Get the latitude and longitude (in degrees) of a given waypoint.</p> <p>This function won't work without FAA CIFP file.</p>
10	double	<p>getProcedure_alt_1(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</p> <p>Get the alt 1 value at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.30 for details.</p> <p>This function won't work without FAA CIFP file.</p>
11	double	<p>getProcedure_alt_2(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</p> <p>Get the alt 2 value at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.30 for details.</p> <p>This function won't work without FAA CIFP file.</p>
12	double	<p>getProcedure_speed_limit(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</p> <p>Get the speed limit at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.72 for details.</p> <p>This function won't work without FAA CIFP file.</p>
13	String	<p>getProcedure_alt_desc(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)</p> <p>Get the altitude description at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.29 for details.</p> <p>This function won't work without FAA CIFP file.</p>
14	String	<p>getProcedure_speed_limit_desc(String proc_type,</p>

		String proc_name, String airport_code, String proc_leg_name, String proc_wp_name) Get the speed limit description at the given airport code, procedure type, procedure name, leg name and waypoint name. Refer to ARINC 424-18 Section 5.261 for details. This function won't work without FAA CIFP file.
--	--	--

TerrainInterface API

No.	Type	Method and Description
1	double	getElevation(double latDeg, double lonDeg) Returns the terrain elevation (in feet above sea level) at the specified latitude and longitude (degrees). Terrain data from USGS is being used for this function. It has a horizontal resolution of 0.001 degree of latitude/longitude, and vertical resolution of 100ft.
2	double[]	getElevationAreaStats(double minLatDeg, double maxLatDeg, double minLonDeg, double maxLonDeg) Returns an array of statistical information calculated from using terrain elevation data for the specified region. minLatDeg: The lower latitude of the rectangular bounding region (degrees) maxLatDeg: The upper latitude of the rectangular bounding region (degrees) minLonDeg: The lower longitude of the rectangular bounding region (degrees) maxLonDeg: The upper longitude of the rectangular bounding region (degrees) Returns { min, max, mean, variance, stddev } (in feet)
3	double[][]	getElevationMapBounds() Returns the minimum and maximum latitude and longitude bounds of the data used to interpolate elevation data.
4	int	setTerrainProfile(double startLat, double endLat, double startLon, double endLon, double resolution) Sets terrain profile information when working with custom terrain data. startLat The start latitude of the region (degrees) endLat The end latitude of the region (degrees) startLon The start longitude of the region (degrees) endLon The end longitude of the region (degrees) resolution Increment of latitude/longitude return 0 for success, 1 for failure

WeatherInterface API

No.	Type	Method and Description
1	int	DownloadWeatherFiles() Download aviation weather files. Metar, Sigmet, Pirep files will be downloaded to GNATS_Server/share/tg/weather directory from NOAA.
2	float[]	getWind(float timestamp_sec, float latitude_deg, float longitude_deg, float altitude_ft) Get wind data.

		Returned data is an array of float value. The first element is wind_north vector value. The second element is wind_east vector value.
3	Weather Polygon []	getWeatherPolygons(String ac_id, double lat_deg, double lon_deg, double alt_ft, double nauticalMile_radius) Get weather polygons. Returned data is an array of weather polygons. Notice. This function can only be executed during pause status of simulation. This function won't work without FAA CIPF file.

RiskMeasuresInterface API

No.	Type	Method and Description
1	Object	getFlightsInRange(String aircraftID) This function takes-in the reference aircraft callsign as the input. It then forms a bounding box around the aircraft within which a potential hazard may exist. The aircraft callsigns are filtered to find the ones that lie within this box, +/- 2000 ft in altitude of the reference aircraft. These flights are then analyzed for their position and velocity relative to the reference aircraft, which are then returned to the user. The returned object is in the following format: [[aircraftCallsign, relativeVelocity, altitudeDifference, bearingAngle, distance], [.....],]
2	double	getDistanceToRunwayThreshold(String aircraftId) For an aircraft in its takeoff or landing phases, this function calculates the distance to the threshold of the runway from the present position.
3	double	getDistanceToRunwayEnd(String aircraftId) For an aircraft in its takeoff or landing phases, this function calculates the distance to the end of the runway from the present position.
4	double	getVelocityAlignmentWithRunway(String aircraftId, String procedure) For an aircraft either in landing or takeoff phases, this function computes the alignment of the velocity vector relative to the runway centerline. The procedure parameter can have values: 1. ARRIVAL, or 2. DEPARTURE
5	int	getPassengerCount(String aircraftType) This function returns the number of passengers occupying a particular aircraft, assuming 100% load factor. This data is available for all the aircraft types in the ADB database.
6	double	getAircraftCost(String aircraftType) This function returns the cost (in millions of US Dollars) for a new aircraft of the aircraft type. This data is available for all the aircraft types in the ADB database.
7	Object	getFlightsInWakeVortexRange(String refAircraftId, float envelopeStartWidth, float envelopeStartThickness, float envelopeEndWidth, float envelopeEndThickness, float envelopeRange, float envelopeAltitudeDrop)

		<p>This function models a wake vortex hazard envelope to determine wake encounter hazards for trailing flights. The wake generating aircraft is assumed to be located in the center of a rectangular, divergent, descending tube with two wingspan initial breadth and one wingspan thickness. The function takes in the following parameters:</p> <p>refAircraftId: The callsign of aircraft which is producing the wake vortex. envelopeStartWidth: The width (in feet) of the envelope at start of wake. (typically twice the aircraft wingspan) envelopeStartThickness: The Thickness (in feet) of the envelope at start of the wake. (typically one wingspan of the aircraft) envelopeEndWidth: The width (in feet) of the envelope at end of the wake vortex hazard. envelopeEndThickness: The thickness (in feet) of the envelope at end of the wake vortex hazard. envelopeRange: Influence range(in miles) of the vortex envelope. (4 to 15 nm, depending on the weight class of the aircraft: Super, Heavy, Large) envelopeAltitudeDrop: Drop (in feet) of the envelope end relative to the wake generating aircraft.</p> <p>Return Object type for this function is: [[aircraftCallsign, relativeVelocity, altitudeDifference, CourseAngle, distance], [.....],]</p> <p>An illustration on the use of this function is available at GNATS_Client/sample/WakeVortexEnvelope.png</p>
8	int	<p>setAircraftBookValue(float aircraftBookValue) Set the book value of the aircraft in million US\$. This is specific to the aircraft instance, and not for an aircraft type.</p>
9	float	<p>getAircraftBookValue() Get the book value of the aircraft in million US\$. This is specific to the aircraft instance for a flight in simulation, and not for an aircraft type. To get aircraft cost based on manufacturer model, refer to getAircraftCost() function within RiskMeasuresInterface.</p>
10	int	<p>setCargoWorth(float cargoWorth) Set the value of the cargo in the aircraft, in million US\$.</p>
11	float	<p>getCargoWorth() Get the value of the cargo in the aircraft, in million US\$.</p>
12	int	<p>setPassengerLoadFactor(float paxLoadFactor) Set load factor for (passenger occupancy relative to the total number of seats) in an aircraft instance. paxLoadFactor ranges from 0 to 1, 0 being an empty aircraft and 1 being fully occupied.</p>
13	float	<p>getPassengerLoadFactor() Get load factor for passenger occupancy in an aircraft instance.</p>
14	int	<p>setTouchdownPointOnRunway(String aircraftId, double latitude, double longitude) Set aircraft touch down point on runway for landing. This would override the</p>

		touchdown point calculated by the simulation.
15	double[]	getTouchdownPointOnRunway(String aircraftId) Get aircraft touch down point on runway for landing.
16	int	setTakeOffPointOnRunway(String aircraftId, double latitude, double longitude) Set aircraft take off point on runway for liftoff. This would override the take off point calculated by the simulation.
17	double[]	getTakeOffPointOnRunway(String aircraftId) Get aircraft take off point on runway for liftoff.
18	double	getL1Distance(String airportId, String aircraftId1, String aircraftId2) Get L1 distance between two aircraft during surface movements if there is a point of potential contact between them in their taxi plans. If there is no possibility of aircraft contact, L1 distance is not defined and the function would return -1. This function won't work for airports outside continental US.
19	double	getDistanceToPavementEdge(String airportId, String aircraftId) Get distance between aircraft current position and the edge of the pavement in the present direction of travel. This can be used to check if an aircraft might potentially run off of the pavement during taxi, take-off, or ramp operations. This function won't work for airports outside continental US.

EntityInterface API

No.	Type	Method and Description
1	ControllerInterface	getControllerInterface() Returns a reference to the ControllerInterface.
2	PilotInterface	getPilotInterface() Returns a reference to the PilotInterface.
3	GroundOperatorInterface	getGroundOperatorInterface() Returns a reference to the GroundOperatorInterface.

ControllerInterface API

No.	Type	Method and Description
1	int	setDelayPeriod(String acid, AircraftClearance aircraft_clearance, float seconds) Set delay period in seconds, for providing clearance to an aircraft.
2	int	int setActionRepeat(String aircraftID, String repeatParameter)

		<p>The controller makes the pilot repeat an action, based on the repeatParameter value.</p> <p>The repeatParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
3	int	<p>int skipFlightPhase(String aircraftID, String flightPhase)</p> <p>The controller skips issuing clearance to an aircraft to the next required flight phase. The flightPhase can have any of the Flight Phase Enum Values. Eg. FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE</p>
4	int	<p>int setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)</p> <p>Instead of clearing the aircraft to the value of one parameter, the controller erroneously clears the aircraft to another value. For example, the controller can assign the magnitude of airspeed (170 kts) as course angle (170 degrees) and viceversa.</p> <p>These are following pairs of parameters that can be mutually interchanged:</p> <ol style="list-style-type: none"> 1. AIRSPEED – COURSE 2. FLIGHT_LEVEL – AIRSPEED 3. COURSE – FLIGHT_LEVEL
5	int	<p>int setActionReversal(String aircraftID, String changeParameter)</p> <p>Controller issues clearance to perform reverse of the intended action, by reversing the value of the changeParameter.</p> <p>The changeParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
6	int	<p>int setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)</p> <p>Clears the aircraft to execute only a part of a required action, by providing the original target value of the parameter, and a percentage of its value to be executed.</p> <p>The changeParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
7	int	<p>int skipChangeAction(String aircraftID, String skipParameter)</p> <p>Omits issuing the clearance by the controller, resulting in the pilot continuing to maintain current value for the skipParameter.</p> <p>The skipParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED

		2. VERTICAL_SPEED 3. COURSE
8	int	int setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget) Controller issues lagged clearances lagging the aircraft action. Following are the parameters: The lagParameter (Parameter to be lagged) can have following values: 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE lagTimeConstant: To be specified in seconds. 10 seconds, for instance. percentageError: Error percentage for the lag. For example, if 95% of the action is to be executed, percentage error would be 0.05. parameterTarget: Original parameter value to be reached.
9	int	setControllerAbsence(String aircraftID, int timeSteps) Controller advisories can be absent for a given time period, requiring the aircraft to execute default plans while waiting for the controller to provide updates. Parameter timeSteps denotes number of steps that aircraft would be flying without controller intervention.
10	Int	releaseAircraftHold(String aircraftID, String approachProcedure, String targetWaypoint) The Controller releases the aircraft from the holding pattern and inserts it into the arrival stream. The controller may clear the aircraft to an approach procedure that may be different from the original flight plan, and a waypoint in that approach. This is the waypoint that the aircraft would intercept to begin approach. For releasing hold pattern in phases other than approach, such as en-route or departure, the approachProcedure parameter needs to be "" (Empty String). The aircraft would get out of the hold and head to the targetWaypoint.
11	void	enableConflictDetectionAndResolution(boolean flag) Enable built-in conflict detection and resolution capability in GNATS if boolean_flag = TRUE. Disable GNATS built-in conflict detection and resolution capability if boolean_flag = FALSE. Log file is generated in GNATS_Server/log directory.
12	void	setCDR_initiation_distance_ft_surface(float distance) Set the initiation distance in feet, for Conflict Detection and Resolution of the surface traffic.
13	void	setCDR_initiation_distance_ft_terminal(float distance) Set the initiation distance in feet for Conflict Detection and Resolution for aircraft flying in the terminal area.
14	void	setCDR_initiation_distance_ft_enroute(float distance) Set the initiation distance in feet, for Conflict Detection and Resolution of en-route air traffic.
15	void	setCDR_separation_distance_ft_surface(float distance) Set the required separation distance in feet for Conflict Detection and Resolution on

		the surface.
16	void	setCDR_separation_distance_ft_terminal(float distance) Set the required separation distance in feet for Conflict Detection and Resolution in the terminal area.
17	void	setCDR_separation_distance_ft_enroute(float distance) Set the required separation distance in feet for Conflict Detection and Resolution in the en-route airspace.
18	void	EnableStrategicWeatherAvoidance() Enable/disable the strategic weather avoidance capability during simulation. If enabled, the GNATS engine checks if any of the flight plans traverse through the adverse weather zone, and creates alternate routes to avoid it. However, if an alternative route is not possible, the aircraft will be held at its current location. The strategic weather avoidance logic is executed on an hourly basis. If enabled, GNATS simulation will experience significant rise in system resource usage. The simulation will also require higher amounts of execution time.
19	void	setWeather_polygonFile(String pathFilename) Manually set the severe weather polygon file used in strategic weather avoidance. If this function is not used during simulation, GNATS engine will choose the latest file. If pathFilename is an empty string "", GNATS engine will choose the latest file. If pathFilename is "NONE", polygon file will be disabled.
20	void	setWeather_sigmetFile(String pathFilename) Manually set sigmet file for strategic weather avoidance. If this function is not used during simulation, GNATS engine will choose the latest available file. If pathFilename is an empty string "", GNATS engine will choose the latest file. If pathFilename is "NONE", sigmet file will be disabled.
21	int	setTacticalWeatherAvoidance(String waypoint_name, float duration_sec) Set waypoint name and duration seconds for weather avoidance. These waypoints are considered to be influenced by the weather so they will be avoided. For setting multiple weather waypoints to avoid, call this function in each waypoint name.
22	void	enableMergingAndSpacingAtMeterFix(String airportId, String meterFix, String trailAttribute, float timeInTrail/distanceInTrail) Enable merging and spacing at a meter fix waypoint on the arrival stream of aircraft. This helps to space out flights for safety reasons both in air and on ground. The function takes in the following parameters: 1. airportId: The ICAO code for the airport. 2. meterFix: The meter fix point where the spacing needs to be enabled.

		<p>3. trailAttribute: String, with permitted values being “TIME” or “DISTANCE”. This defines whether the float input for the last parameter is distance or time for aircraft spacing.</p> <p>4. timeInTrail/distanceInTrail: The minimum separation distance or time between aircraft. This input should be consistent with the selection for trailAttribute parameter. timeInTrails is to be supplied in minutes, and distanceInTrail is to be supplied in miles.</p> <p>This function won't work for airports outside continental US.</p>
23	void	<p>disableMergingAndSpacingAtMeterFix(String airportId, String meterFix)</p> <p>Enable merging and spacing at a meter fix waypoint on the arrival stream of aircraft. This helps to space out flights for safety reasons both in air and on ground.</p> <p>The function takes in the following parameters:</p> <ol style="list-style-type: none"> 1. airportId: The ICAO code for the airport. 2. meterFix: The meter fix point where the spacing needs to be enabled. <p>This function won't work for airports outside continental US.</p>
24	Object[][]	<p>getCDR_status()</p> <p>Get current status of CD&R conflicting events</p> <p>Result data: An array of CD&R status.</p> <p>Each array element is formatted in the form of an array. The content are:</p> <ul style="list-style-type: none"> aircraft ID of the held aircraft, aircraft ID of the conflicting aircraft, seconds of holding of the held aircraft <p>Format type: [[String, String, float]]</p> <p>Example: [["AC1", "AC_conflicting_with_AC1", heldSeconds_AC1], ["AC2", "AC_conflicting_with_AC2", heldSeconds_AC2]]</p>

PilotInterface API

No.	Type	Method and Description
1	int	<p>int setActionRepeat(String aircraftID, String repeatParameter)</p> <p>Repeat pilot action, based on the repeatParameter value.</p> <p>The repeatParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
2	int	<p>int skipFlightPhase(String aircraftID, String flightPhase)</p> <p>Ignore the required flight phase transition,. The flightPhase parameter can have any of the Flight Phase Enum Values. Eg. FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE</p>
3	int	<p>int setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)</p> <p>Erroneously set the value of a parameter to another. For example, the pilot can set</p>

		<p>magnitude of the airspeed (170 kts) as course angle (170 degrees). The following pairs of parameters can be mutually interchanged:</p> <ol style="list-style-type: none"> 1. AIRSPEED – COURSE 2. FLIGHT_LEVEL – AIRSPEED 3. COURSE – FLIGHT_LEVEL
4	int	<p>int setActionReversal(String aircraftID, String changeParameter)</p> <p>Reverse a pilot action, by reversing the value of changeParameter. changeParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
5	int	<p>int setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)</p> <p>Execute only a part of an action, by providing the original target value of the parameter, and percentage of it to be performed by pilot, for the changeParameter. The changeParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
6	int	<p>int skipChangeAction(String aircraftID, String skipParameter)</p> <p>Omit a parameter change by continuing to maintain the current value for the skipParameter. The skipParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE
7	int	<p>int setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)</p> <p>Lag in pilot action, by specifying a certain percent of the execution to be completed within a given time period. Following are the parameters: The lagParameter can have following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE <p>lagTimeConstant: To be specified in seconds. 10 seconds, as an example. percentageError: Error percentage for the lag. For example, if 95% of the action is to be executed in the lag time constant, percentage error would be 0.05. parameterTarget: Original parameter value to be reached.</p>
8	int	<p>int setFlightPlanReadError(String aircraftID, String errorParameter, float correctValue)</p> <p>If the simulation has not started, the flight plan read from the TRX file can be</p>

		<p>changed using this function. This constitutes an error in entering the flight plan into the flight management system.</p> <p>Following are the parameters:</p> <p>errorParameter: Parameter with erroneous data. It can have any of the following values:</p> <ol style="list-style-type: none"> 1. AIRSPEED 2. VERTICAL_SPEED 3. COURSE <p>correctValue: This is the data according to the flight that should have been read.</p>
--	--	--

GroundOperator Interface API

No.	Type	Method and Description
1	int	<p>setGroundOperatorAbsence(String groundVehicleId, int timeSteps)</p> <p>Ground operators can be absent for a given time period, requiring the vehicle to stop while waiting for the operator to take back control. groundVehicleId: The <u>callsign</u> of the vehicle that the operator is in-charge of. timeSteps: Number of time steps for which operator is absent.</p> <p>This function won't work for airports outside continental US.</p>
2	int	<p>setActionRepeat(String groundVehicleId, String repeatParameter)</p> <p>The ground operator repeats an action, based on the repeatParameter value. groundVehicleId: The <u>callsign</u> of the aircraft repeatParameter: Ground vehicle parameter for which action is to be repeated.</p> <p>This function won't work for airports outside continental US.</p>
3	int	<p>setVehicleContact(String groundVehicleId)</p> <p>Ground operators collides the ground vehicle into another object (Potentially building/aircraft/automobile/person) groundVehicleId: The <u>callsign</u> of the vehicle that the operator is in-charge of.</p> <p>This function won't work for airports outside continental US.</p>
4	int	<p>setWrongAction(String groundVehicleId, String originalChangeParameter, String wrongChangeParameter)</p> <p>Instead of acting to change value of one parameter, the ground operator erroneously changes another. groundVehicleId: The <u>callsign</u> of the ground vehicle originalChangeParameter: Original parameter to be changed due to ground operator action wrongChangeParameter: Erroneous parameter to be changed due to ground operator action</p> <p>This function won't work for airports outside continental US.</p>
5	int	<p>setActionReversal(String groundVehicleId, String</p>

		changeParameter) Ground operator executes part of the originally intended action. groundVehicleId: The <u>callsign</u> of the ground vehicle changeParameter: Ground Vehicle parameter for which action is to be partially performed originalTarget: <u>Original</u> value for parameter percentage Percentage of action to be executed This function won't work for airports outside continental US.
6	int	setPartialAction(String groundVehicleId, String changeParameter, float originalTarget, float percentage) Ground operator executes part of the originally intended action. groundVehicleId: The <u>callsign</u> of the ground vehicle changeParameter: Ground Vehicle parameter for which action is to be partially performed originalTarget: <u>Original</u> value for parameter percentage: Percentage of action to be executed This function won't work for airports outside continental US.
7	int	setActionLag(String groundVehicleId, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget) Ground operator lags vehicle action, thereby a certain percent of the execution getting completed within a given time period. groundVehicleId The callsign of the ground vehicle lagParameter: Flight parameter for which action is to be lagged lagTimeConstant: To be specified in seconds. 10 seconds, as an example. percentageError: Error percentage for the lag. For example, if 95% of the action is to be executed in the lag time constant, percentage error would be 0.05. parameterTarget: Original parameter value to be reached. This function won't work for airports outside continental US.

WeatherPolygon Instance API

No.	Type	Method and Description
1	double[]	getX_data() Get longitude values of vertices in the polygon.
2	double[]	getY_data() Get latitude values of vertices in the polygon.
3	int	getNum_vertices() Get number of vertices in the polygon.
4	boolean	getCcw_flag()

		Get boolean value indicating whether the vertices are created counter-clockwise in the polygon.
5	double	getXmin() Get minimum longitude value of all vertices in the polygon.
6	double	getXmax() Get maximum longitude value of all vertices in the polygon.
7	double	getYmin() Get minimum latitude value of all vertices in the polygon.
	double	getYmax() Get maximum latitude value of all vertices in the polygon.
	double	getX_centroid() Get longitude value of the centroid point in the polygon.
	double	getY_centroid() Get latitude value of the centroid point in the polygon.
	String	getPoly_type() Get polygon type.
	int	getStart_hr() Get starting hour of the polygon.
	int	getEnd_hr() Get ending hour of the polygon.

AircraftClearance Enum Values

Values
AIRCRAFT_CLEARANCE_PUSHBACK
AIRCRAFT_CLEARANCE_TAXI_DEPARTING
AIRCRAFT_CLEARANCE_TAKEOFF
AIRCRAFT_CLEARANCE_ENTER_ARTC
AIRCRAFT_CLEARANCE_DESCENT_FROM_CRUISE
AIRCRAFT_CLEARANCE_ENTER_TRACON
AIRCRAFT_CLEARANCE_APPROACH
AIRCRAFT_CLEARANCE_TOUCHDOWN

AIRCRAFT_CLEARANCE_TAXI_LANDING

AIRCRAFT_CLEARANCE_RAMP_LANDING

WeatherPolygon Instance API

No.	Type	Method and Description
1	String	convertLatLonDeg_to_degMinSecString(String degStr) Convert latitude/longitude degree string to degree-minute-second format.

Detailed Descriptions of Functions

GNATS Client API

Function: `getEntityInterface()`

Return Type: `EntityInterface`

Purpose: To access the APIs in the Entities group (Pilots, Controllers, ground vehicle operators)

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
entityInterface = gnatsClient.getEntityInterface()
```

Function: `getEnvironmentInterface()`

Return Type: `EnvironmentInterface`

Purpose: To access the APIs in the Environment group (Atmosphere, Airports, Arrival/Departure Procedures)

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
environmentInterface = gnatsClient.getEnvironmentInterface()
```

Function: `getEquipmentInterface()`

Return Type: `EquipmentInterface`

Purpose: To access the APIs in the Equipment group (Aircraft, Ground Vehicles, Communication & navigation Systems)

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
equipmentInterface = gnatsClient.getEquipmentInterface()
```

Function: `getRiskMeasureInterface()`

Return Type: `RiskMeasuresInterface`

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface()
```

Function: `getRiskMInterface ()`

Return Type: `RiskMeasuresInterface`

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
riskMInterface = gnatsClient.getRiskMInterface()
```

Function: `getSimulationInterface()`

Return Type: `SimulationInterface`

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
simulationInterface = gnatsClient.GetSimulationInterface()
```

Function: disconnect()

Return Type: void

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
gnatsClient.disconnect()
```

Function: login(String authenticationID)

Return Type: void

Example:

```
GNATSClientFactory = JClass('GNATSClientFactory')
gnatsClient = GNATSClientFactory.getGNATSClient()
gnatsClient.login("ABCD1234")
```

SimulationInterface API

Function: clear_trajectory()

Return Type: void

Purpose:

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()
simulationInterface.clear_trajectory()
```

Function: get_curr_sim_time()

Return Type: float

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()
currentTime = simulationInterface.get_curr_sim_time()
```

Function: get_sim_id()

Return Type: long

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()
simulation_id = simulationInterface.get_sim_id()
```

Function: get_runtime_sim_status()

Return Type: int

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()
currentRuntimeStatus = simulationInterface.get_runtime_sim_status()
```

Function: pause()

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.pause()
```

Function: resume()

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.resume()
```

Function: resume(long timeDuration)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.resume(1000)
```

Function: resume(float timeDuration)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.resume(1000.5)
```

Function: setupSimulation(int propagationTime, int timeStep)

Return Type: int

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (10000, 5)
```

Function: setupSimulation(float propagationTime, float timeStep)

Return Type: int

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (100.7, 15.5)
```

Function: setupSimulation(int propagationTime, int timeStep, int terminalTimeStep, int airborneTimeStep)

Return Type: int

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (1000, 3, 4, 5)
```

Function: setupSimulation(float propagationTime, float timeStep, float terminalTimeStep, float airborneTimeStep)

Return Type: int

Example:


```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.setupSimulation (1000.0, 3.5, 7.5, 10.3)
```

Function: start()

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.start()
```

Function: start(long timeDuration)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.start(1200)
```

Function: start(float timeDuration)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.start(150.65)
```

Function: startRealTime()

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.startRealTime()
```

Function: startRealTime_singleUser()

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.startRealTime_singleUser()
```

Function: stop()

Return Type: void

Example: simulationInterface = gnatsClient.getSimulationInterface()
simulationInterface.stop()

Function: write_trajectories(String outputFile)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.write_trajectories ("SimulationTrajectory.csv")
```

Function: request_aircraft(String ac_id)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.request_aircraft("ABC123")
```

Function: request_groundVehicle(String gv_id)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.request_groundVehicle("BUS123")
```

Function: externalAircraft_create_trajectory_profile(
 String ac_id,
 String ac_type,
 String origin_airport,
 String destination_airport,
 float cruise_altitude_ft,
 float cruise_tas_knots,
 double latitude_deg,
 double longitude_deg,
 double altitude_ft,
 double rocd_fps,
 double tas_knots,
 double course_deg,
 String flight_phase)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.externalAircraft_create_trajectory_profile(  
    "ABC173", "B733", "KPHX",  
    "KSFO", 33000.0, 430.0, 37.2, -122.4, 2500.0, 215.0, 240.0, 318.2,  
    "FLIGHT_PHASE_CRUISE")
```

Function: externalAircraft_inject_trajectory_state_data(String ac_id,
 double latitude_deg, double longitude_deg,
 double altitude_ft, double rocd_fps,
 double tas_knots, double course_deg, String flight_phase,
 long timestamp_utc_millisec)

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.externalAircraft_inject_trajectory_state_data("AB  
C123", 32.61, -122.39, 3200,  
30, 250, 50, "FLIGHT_PHASE_CRUISE", 1541784961725)
```

Function: requestDownloadTrajectoryFile()

Return Type: void

Example:

```
simulationInterface = gnatsClient.getSimulationInterface()  
simulationInterface.requestDownloadTrajectoryFile()
```

EquipmentInterface API

Function: getAircraftInterface()

Return Type: AircraftInterface

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()
```

Function: getGroundVehicleInterface()

Return Type: GroundVehicleInterface

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getGroundVehicleInterface ()
```

Function: getCNSInterface()

Return Type: CNSInterface

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getCNSInterface()
```

Function: getADBDataInterface()

Return Type: ADBInterface

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
ADBDataInterface = equipmentInterface.getADBDataInterface()
```

AircraftInterface API

Function: load_aircraft(String trx_file, String mfl_file)

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraftInterface.load_aircraft("share/tg/trx/TRX_DEMO_SFO_PHX_GateTo  
Gate.trx", "share/tg/trx/TRX_DEMO_SFO_PHX_mfl.trx")
```

Function: validate_flight_plan_record(String string_track, String
string_fp_route, int mfl_ft)

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()
```

```
result = aircraftInterface.validate_flight_plan_record("TRACK SWA1897  
B733 373628.6 1222248.0 0 0.13 280 ZOA ZOA46", "FP_ROUTE  
KSFO./.RW01R.SSTIK4.LOSHN..BOILE..BLH.HYDRR1.I07R.RW07R.<>.KPHX",  
37000)
```

Function: `release_aircraft()`

Return Type: `int`

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraftInterface.release_aircraft()
```

Function: `getAircraftIds(float minLatitude, float maxLatitude, float minLongitude, float maxLongitude, float minAltitude_ft, float maxAltitude_ft)`

Return Type: `String[]`

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraftsIds = aircraftInterface.getAircraftId(28.5, 30.7, 72.8, 74.9, 15000.0, 20000.9)
```

Function: `getAllAircraftId()`

Return Type: `String[]`

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraftsIds = aircraftInterface.getAllAircraftId()
```

Function: `select_aircraft(String aircraft_id)`

Return Type: `Aircraft` (Aircraft Instance API)

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
```

Function: `synchronize_aircraft_to_server(Aircraft aircraft)`

Return Type: `int`

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
synchronize_aircraft_to_server(aircraft)
```

AircraftInstance API

Function: `delay_departure(int delayTimeSeconds)`

Return Type: `int`

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.delay_departure(20)
```

Function: getAcid()

Return Type: String

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraftId = aircraft.getAcid()
```

Function: getAltitude_ft()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraftAltitude = aircraft.getAltitude_ft ()
```

Function: getCruise_alt_ft()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraftCruiseAltitude = aircraft.getCruise_alt_ft()
```

Function: getCruise_tas_knots()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraftCruiseAirspeed = aircraft.getCruise_tas_knots()
```

Function: getDeparture_time_sec()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightDepartureTime = aircraft.getDeparture_time_sec()
```

Function: getDestination_airport_elevation_ft()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
```

```
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
destinationAirportElevation =
aircraft.getDestination_airport_elevation_ft()
```

Function: getFlight_phase()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightPhase = aircraft.getFlight_phase()
```

Function: getFlight_plan_latitude_array()

Return Type: float[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightLatitudeArray = aircraft.getFlight_plan_latitude_array()
```

Function: getFlight_plan_length()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightPlanLength = aircraft.getFlight_plan_length()
```

Function: getFlight_plan_longitude_array()

Return Type: float[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightLongitudeArray = aircraft.getFlight_plan_longitude_array()
```

Function: getFlight_plan_waypoint_name_array()

Return Type: String[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
flightWaypointNameArray = aircraft.getFlight_plan_waypoint_name_array()
```

Function: getFlight_plan_alt_desc_array()

Return Type: String[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
```

```
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightAltitudeDescriptionArray = aircraft.getFlight_plan_alt_desc_array()
```

Function: getFlight_plan_alt_1_array()

Return Type: double[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightPlanAltitude1Array = aircraft.getFlight_plan_alt_1_array()
```

Function: getFlight_plan_alt_2_array()

Return Type: double[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightPlanAltitude2Array = aircraft.getFlight_plan_alt_2_array()
```

Function: getFlight_plan_speed_limit_array()

Return Type: double[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightPlanSpeedLimitArray = aircraft.getFlight_plan_speed_limit_array()
```

Function: getFlight_plan_speed_limit_desc_array()

Return Type: String[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightSpeedLimitDescriptionArray =  
aircraft.getFlight_plan_speed_limit_desc_array()
```

Function: getFpa_rad()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightPathAngle = aircraft.getFpa_rad()
```

Function: getCourse_rad()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
courseAngle = aircraft.getCourse_rad()
```

Function: getLanded_flag()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightLandedFlag = aircraft.getLanded_flag()
```

Function: getLatitude_deg()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightCurrentLatitude = aircraft.getLatitude_deg()
```

Function: getLongitude_deg()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
flightCurrentLongitude= aircraft.getLongitude_deg()
```

Function: getOrigin_airport_elevation_ft()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
originAirportElevation = aircraft.getOrigin_airport_elevation_ft()
```

Function: getRocd_fps()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
rateOfClimbOrDescent = aircraft.getRocd_fps()
```

Function: getSector_index()

Return Type: int

Example:


```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
sectorIndex = aircraft.getSector_index()
```

Function: getTarget_altitude_ft()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
targetAltitude = aircraft.getTarget_altitude_ft()
```

Function: getTarget_waypoint_index()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
targetWaypointIndex = aircraft.getTarget_waypoint_index()
```

Function: getTarget_waypoint_name()

Return Type: String

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
targetWaypointName = aircraft.getTarget_waypoint_name()
```

Function: getTas_knots()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
currentAirspeed = aircraft.getTas_knots()
```

Function: getToc_index()

Return Type: int

Example: equipmentInterface = gnatsClient.getEquipmentInterface()

aircraftInterface = equipmentInterface.getAircraftInterface()

aircraft = aircraftInterface.select_aircraft('ULI-SFD235')

topOfClimbIndex = aircraft.getToc_index()

Function: getTod_index()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
topOfDescentIndex = aircraft.getTod_index()
```

Function: setAltitude_ft(float altitude_ft)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setAltitude_ft(27500.8)
```

Function: setCruise_alt_ft(float cruise_alt_ft)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setCruise_alt_ft(35000.7)
```

Function: setCruise_tas_knots(float cruise_tas_knots)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setCruise_tas_knots(455.5)
```

Function: setFlight_phase(int flight_phase)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setFlight_phase(2)
```

Function: setFlight_plan_latitude_deg(int index, float latitude_deg)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setFlight_plan_latitude_deg(5, 34.50)
```

Function: setFlight_plan_longitude_deg(int index, float longitude_deg)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setFlight_plan_longitude_deg(5, -122.63)
```

Function: setLatitude_deg(float latitude_deg)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setLatitude_deg(26.58)
```

Function: setLongitude_deg(float longitude_deg)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setLongitude_deg (-122.36)
```

Function: setRocd_fps(float rocd_fps)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setRocd_fps(-50.1)
```

Function: setTarget_altitude_ft(float target_altitude_ft)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setTarget_altitude_ft(35000.5)
```

Function: setTarget_waypoint_latitude_deg(float latitude_deg)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
aircraftInterface = equipmentInterface.getAircraftInterface()  
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')  
aircraft.setTarget_waypoint_latitude_deg(35.63)
```

Function: setTarget_waypoint_longitude_deg(float longitude_deg)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setTarget_waypoint_longitude_deg(-118.25)
```

Function: setTas_knots(float tas_knots)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
aircraftInterface = equipmentInterface.getAircraftInterface()
aircraft = aircraftInterface.select_aircraft('ULI-SFD235')
aircraft.setTas_knots(400)
```

GroundVehicleInterface API

Function: load_groundVehicle(String trx_file)

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicleInterface.load_aircraft('share/tg/trx/TRX_GroundVehicles
.trx')
```

Function: release_groundVehicle()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicleInterface.release_groundVehicle()
```

Function: getAssignedGroundVehicleIds()

Return Type: String[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
assignedGroundVehicles =
groundVehicleInterface.getAssignedGroundVehicleIds()
```

Function: getAssignedGroundVehicleIds(String username)

Return Type: String[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
```

```
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
assignedGroundVehicles =  
groundVehicleInterface.getAssignedGroundVehicleIds(username)
```

Function: getAllGroundVehicleIds()

Return Type: String[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
listGroundVehicle = groundVehicleInterface.getAllGroundVehicleIds()
```

Function: select_groundVehicle(String groundVehicleId),

Return Type: GroundVehicle

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
```

Function: externalGroundVehicle_create_trajectory_profile(String groundVehicleId, String aircraftInService, String airport, float latitude, float longitude, float speed, float course)

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicleInterface.groundVehicleInterface.externalGroundVehicle_c  
reate_trajectory_profile('NEW123', 'DWA1897', 'KSFO', 37, -122, 15,  
28)
```

Function: externalGroundVehicle_inject_trajectory_state_data(String groundVehicleId, String aircraftInService, float latitude, float longitude, float speed, float course)

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicleInterface.externalGroundVehicle_inject_trajectory_state_  
data('NEW123', 'DWA1897', 37, -122, 15, 28)
```

GroundVehicleInstance API

Function: getGvid()

Return Type: String

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleId = groundVehicle.getGvid()
```

Function: getAirportId()

Return Type: String

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleAirportId = groundVehicle.getAirportId()
```

Function: getAircraftInService()

Return Type: String

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
aircraftInService = groundVehicle.getAircraftInService()
```

Function: getFlag_external_groundvehicle()

Return Type: Boolean,

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
isExternalGroundVehicle =  
groundVehicle.getFlag_external_groundvehicle()
```

Function: getAssigned_user()

Return Type: String

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
user = groundVehicle.getAssigned_user()
```

Function: getLatitude()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()
```

```
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
latitude = groundVehicle.getLatitude()
```

Function: setLatitude(float latitude)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicle.setLatitude(37.8959)
```

Function: getLongitude()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
longitude = groundVehicle.getLongitude()
```

Function: setLongitude(float longitude)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicle.setLongitude(-112.8594)
```

Function: getAltitude()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
altitude = groundVehicle.getAltitude()
```

Function: getSpeed()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
```

```
groundVehicleSpeed = groundVehicle.getSpeed()
```

Function: setSpeed(float speed)

Return Type: void,

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicle.setSpeed(25)
```

Function: getCourse()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleCourse = groundVehicle.getCourse()
```

Function: setCourse(float course)

Return Type: void,

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicle.setCourse(1.5)
```

Function: getDeparture_time()

Return Type: float

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
groundVehicleDepartureTime = groundVehicle.getDeparture_time()
```

Function: getDrive_plan_latitude_array()

Return Type: float[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
groundVehicleInterface =
equipmentInterface.getGroundVehicleInterface()
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')
```



```
groundVehicleDrivePlanLatitudeArray =  
groundVehicle.getDrive_plan_latitude_array()
```

Function: getDrive_plan_longitude_array()

Return Type: float[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleDrivePlanLongitudeArray =  
groundVehicle.getDrive_plan_longitude_array()
```

Function: getDrive_plan_length()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleDrivePlanLength = groundVehicle.getDrive_plan_length()
```

Function: getDrive_plan_waypoint_name_array()

Return Type: String[]

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleDrivePlanWaypointNames =  
groundVehicle.getDrive_plan_waypoint_name_array()
```

Function: getTarget_waypoint_index()

Return Type: int

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleTargetWaypointIndex =  
groundVehicle.getTarget_waypoint_index()
```

Function: getTarget_waypoint_name()

Return Type: String

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()
```

```
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicleTargetWaypointName =  
groundVehicle.getTarget_waypoint_name()
```

Function: setDrive_plan_latitude(int index, float latitude)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicle.setDrive_plan_latitude(2, 37.2518)
```

Function: setDrive_plan_longitude(int index, float longitude)

Return Type: void

Example:

```
equipmentInterface = gnatsClient.getEquipmentInterface()  
groundVehicleInterface =  
equipmentInterface.getGroundVehicleInterface()  
groundVehicle = groundVehicleInterface.select_groundVehicle('BUS123')  
groundVehicle.setDrive_plan_longitude(2, -112.8155)
```

CNSInterface API

Function: getLineOfSight(double observerLat, double observerLon, double observerAlt, double targetLat, double targetLon, double targetAlt)

Return Type: double[]

Example:

```
cnsInterface = equipmentInterface.getCNSInterface()  
cnsInterface.getLineOfSight(33.440903, -111.992862, 1135, 33.274183,  
-112.147879, 1500)
```

Function: setNavigationLocationError(String aircraftId, String parameter, double bias, double drift, double scaleFactor, double noiseVariance, int scope)

Return Type: int

Example:

```
cnsInterface = equipmentInterface.getCNSInterface()  
cnsInterface.setNavigationLocationError('SWA1897', 'LATITUDE',  
0.00005, 0.00000001, 0.9, 0.2, 1)  
cnsInterface.setNavigationLocationError('SWA1897', 'LONGITUDE',  
0.00005, 0.00000001, 0.9, 0.2, 1)
```

Function: setNavigationAltitudeError(String aircraftId, double bias, double noiseVariance, int scope)

Return Type: int

Example:

```
cnsInterface = equipmentInterface.getCNSInterface()
cnsInterface.setNavigationAltitudeError('SWA1897', .00005, 0.2, 0)
```

Function: setRadarError(String airportId, String parameter, double originalValue, double bias, double noiseVariance, int scope)

Return Type: int

Example:

```
cnsInterface = equipmentInterface.getCNSInterface()
cnsInterface.setRadarError('KSFO', 'RANGE', 25, 0.0000005, 0.2, 1)
cnsInterface.setRadarError('KSFO', 'AZIMUTH', 30, 0.0000005, 0.2, 1)
cnsInterface.setRadarError('KSFO', 'ELEVATION', 2500, 0.0000005, 0.2, 1)
```

ADBDDataInterface API

Function: getADB_cruiseTas(String ac_type, double altitude_ft)

Return Type: double

Example:

```
adbDataInterface = equipmentInterface.getADBDDataInterface()
adbDataInterface.getADB_cruiseTas('B733', 15000)
```

Function: getADB_climbRate_fpm(String ac_type, double flt_level, String adb_mass)

Return Type: double

Example:

```
adbDataInterface = equipmentInterface.getADBDDataInterface()
adbDataInterface.getADB_climbRate_fpm('B733', 150, 'NOMINAL')
```

Function: getADB_climbTas(String ac_type, double altitude_ft)

Return Type: double

Example:

```
adbDataInterface = equipmentInterface.getADBDDataInterface()
adbDataInterface.getADB_climbTas('B733', 15000)
```

Function: getADB_descentRate_fpm(String ac_type, double flight_level, String adb_mass)

Return Type: double

Example:

```
adbDataInterface = equipmentInterface.getADBDDataInterface()
adbDataInterface.getADB_descentRate_fpm('B733', 150, 'NOMINAL')
```

Function: getADB_descentTas(String ac_type, double altitude_ft)

Return Type: double

Example:

```
adbDataInterface = equipmentInterface.getADBDDataInterface()
adbDataInterface.getADB_descentTas('B733', 15000)
```

EnvironmentInterface API

Function: load_rap(String windDirectory)

Return Type: void

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.load_rap("share/tg/rap")
```

Function: release_rap()

Return Type: int

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.release_rap()
```

Function: getAirportInterface()

Return Type: AirportInterface

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()
```

Function: getTerrainInterface()

Return Type: TerrainInterface

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainInterface = environmentInterface.getTerrainInterface()
```

Function: getTerminalAreaInterface()

Return Type: TerminalAreaInterface

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface = environmentInterface.getTerminalAreaInterface()
```

Function: getWeatherInterface()

Return Type: WeatherInterface

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
weatherInterface = environmentInterface.getWeatherInterface()
```

Function: getCenterCodes()

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.getCenterCodes()
```

Function: getCurrentCenter(String aircraftId)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.getCurrentCenter('SWA1897')
```

Function: getFixesInCenter(String centerId)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
environmentInterface.getFixesInCenter('KZOA')
```

AirportInterface API

Function: select_airport(String airport_code)

Return Type: Airport

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airport = airportInterface.select_airport("KPHX")
```

Function: getArrivalAirport(String acid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
arrivalAirport = airportInterface.getArrivalAirport('ULI-SFD235')
```

Function: getDepartureAirport(String acid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
departureAirport = airportInterface.getDepartureAirport('ULI-SFD235')
```

Function: getLocation(String airport_code)

Return Type: double[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airportLocation = airportInterface.getLocation('KLAX')
```

Function: getClosestAirport(double latitude, double longitude)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
closestAirport = airportInterface.getClosestAirport(35.2, -118.6)
```

Function: getAirportsWithinMiles(double lat_deg, double lon_deg, double miles)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airports = airportInterface.getAirportsWithinMiles(35.2, -118.6,
22.5)
```

Function: getFullName(String airportid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportFullName = airportInterface.getFullName('KJFK')
```

Function: getAllRunways(String airport_code)

Return Type: Object[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportRunways = airportInterface.getAllRunways('PANC')
```

Function: getAllGates(String airport_code)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportGates = airportInterface.getAllGates('PANC')
```

Function: getRunwayExits(String airport_code, String runway_id)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
runwayExits = airportInterface.getRunwayExits('KSFO', 'RW28R')
```

Function: getLayout_node_map(String airport_code)

Return Type: Object[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportLayoutNodeMap = airportInterface.getLayout_node_map('PHNL')
```

Function: getLayout_node_data(String airport_code)

Return Type: Object[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportLayoutNodeData = airportInterface.getLayout_node_data('PHNL')
```

Function: getLayout_links(String airport_code)

Return Type: Object[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airportLayoutLinks = airportInterface.getLayout_links('PHNL')
```

Function: getSurface_taxi_plan(String acid, String airport_code)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
surfaceTaxiPlan = airportInterface.getSurface_taxi_plan('ULI-SFD235', 'KSFO')
```

Function: generate_surface_taxi_plan(String acid, String airport_code, String startNode_waypoint_id, String endNode_waypoint_id, String runway_name)

Return Type: int

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
generatedTaxiPlan = airportInterface.generate_surface_taxi_plan('ULI-SFD235', 'KSFO',
'Gate_01_001', 'Rwy_02_001', 'RW06L')
```

Function: setUser_defined_surface_taxi_plan(String acid, String airport_code, String[] user_defined_waypoint_ids)

Return Type: int

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
generatedTaxiPlan =
airportInterface.setUser_defined_surface_taxi_plan('ULI-SFD235',
'KSFO',
['Gate_01_001', 'Ramp_01_001', 'Txy_01_001', 'Txy_01_002',
'Rwy_02_001'])
```

Function: get_taxi_route_from_A_To_B(String acid, String airport_code, String startNode_waypoint_id, String endNode_waypoint_id)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
taxiPlanAtoB = airportInterface.get_taxi_route_from_A_To_B('ULI-SFD235', 'KSFO', 'Gate_01_001', 'Rwy_02_001')
```

Function: getDepartureRunway(String acid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
departureRunway = airportInterface.getDepartureRunway('ULI-SFD235').
```

Function: getArrivalRunway(String acid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
arrivalRunway = airportInterface.getArrivalRunway('ULI-SFD235')
```

Function: getTaxi_tas_knots(String acid)

Return Type: double

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
taxiSpeed = airportInterface.getTaxi_tas_knots('ULI-SFD235')
```

Function: setTaxi_tas_knots(String acid, double tas_knots)

Return Type: void

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airportInterface.setTaxi_tas_knots('ULI-SFD235', 25.0)
```

Function: getAllAirportCodesInGNATS()

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airportList = airportInterface.getAllAirportCodesInGNATS()
```

Function: getRunwayEnds(String airportId, String runwayId)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
airportInterface = environmentInterface.getAirportInterface()  
airportList = airportInterface.getRunwayEnds("KSFO", "RW28R")
```

AirportInstance API

Function: getCode()

Return Type: String

Example:


```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airport = airportInterface.select_airport("KORD")
airportCode = airport.getCode()
```

Function: getElevation()

Return Type: float

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airport = airportInterface.select_airport("KORD")
airportElevation = airport.getElevation()
```

Function: getLatitude()

Return Type: float

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airport = airportInterface.select_airport("KORD")
airportLatitude = airport.getLatitude()
```

Function: getLongitude()

Return Type: float

Example:

```
airportInterface = environmentInterface.getAirportInterface()
airport = airportInterface.select_airport("KORD")
airportLongitude = airport.getLongitude()
```

Function: getName()

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
airportInterface = environmentInterface.getAirportInterface()
airport = airportInterface.select_airport("KORD")
airportName = airport.getName()
```

TerminalAreaInterface API

Function: getAllApproaches(String airport_code)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
approaches = terminalAreaInterface.getAllApproaches('KORD')
```

Function: getAllSids(String airport_code)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
sids = terminalAreaInterface.getAllSids('KORD')
```

Function: getAllStars(String airport_code)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
stars = terminalAreaInterface.getAllStars('KORD')
```

Function: getCurrentApproach(String acid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
currentApproach = terminalAreaInterface.getCurrentApproach('ULI-SFD235')
```

Function: getCurrentSid(String acid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
currentSid = terminalAreaInterface.getCurrentSid('ULI-SFD235')
```

Function: getCurrentStar(String acid)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
currentStar = terminalAreaInterface.getCurrentStar('ULI-SFD235')
```

Function: getProcedure_leg_names(String proc_type, String proc_name, String airport_code)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
```

```
sidLegNames = terminalAreaInterface.getProcedure_leg_names("SID",  
"SSTIK3", "KSFO")
```

Function: getWaypoints_in_procedure_leg(String proc_type, String proc_name, String airport_code,String proc_leg_name)

Return Type: String[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface =  
environmentInterface.getTerminalAreaInterface()  
waypointNames = terminalAreaInterface.getWaypoints_in_procedure_leg("SID",  
"SSTIK3", "KSFO",  
"PORTE")
```

Function: getClosestWaypoint(float[][] waypointOptions, float[] targetWaypoint)

Return Type: int

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface =  
environmentInterface.getTerminalAreaInterface()  
closestWaypointIndex =  
terminalAreaInterface.getClosestWaypoint([[37.61,-122.3],[42.9,-  
75.61]], [43.9,-77.6])
```

Function: calculateWaypointDistance(float latx, float lonx, float laty, float lony)

Return Type: double

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface =  
environmentInterface.getTerminalAreaInterface()  
waypointDistance =  
terminalAreaInterface.calculateWaypointDistance(37.61,-122.3,42.9,-  
75.61)
```

Function: getWaypoint_Latitude_Longitude_deg(String waypoint_name)

Return Type: double[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface =  
environmentInterface.getTerminalAreaInterface()  
waypointLocation =  
terminalAreaInterface.getWaypoint_Latitude_Longitude_deg('BOILE')
```

Function: getProcedure_alt_1(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)

Return Type: double

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureAlt1 = terminalAreaInterface.getProcedure_alt_1("SID",
"SSTIK3", "KSFO", "PORTE",
"KAYEX")
```

Function: getProcedure_alt_2(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)

Return Type: double

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureAlt2 = terminalAreaInterface.getProcedure_alt_2("SID",
"SSTIK3", "KSFO", "PORTE", "KAYEX")
```

Function: getProcedure_speed_limit(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)

Return Type: double

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
terminalAreaInterface =
environmentInterface.getTerminalAreaInterface()
procedureSpeedLimit =
terminalAreaInterface.getProcedure_speed_limit("SID", "SSTIK3",
"KSFO", "PORTE", "KAYEX")
```

Function: getProcedure_alt_desc(String proc_type, String proc_name, String airport_code, String proc_leg_name, String proc_wp_name)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
```

```
terminalAreaInterface =  
environmentInterface.getTerminalAreaInterface()  
procedureAltitudeDesc =  
terminalAreaInterface.getProcedure_alt_desc("SID", "SSTIK3", "KSFO",  
"PORTE", "KAYEX")
```

Function: getProcedure_speed_limit_desc(String proc_type, String
proc_name, String airport_code,
String proc_leg_name, String proc_wp_name)

Return Type: String

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terminalAreaInterface =  
environmentInterface.getTerminalAreaInterface()  
procedureSpeedLimitDesc =  
terminalAreaInterface.getProcedure_speed_limit_desc ("SID", "SSTIK3",  
"KSFO", "PORTE", "KAYEX")
```

TerrainInterface API

Function: getElevation(double latDeg, double lonDeg)

Return Type: double

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
elevation = terrainAreaInterface.getElevation(34.5, -122.23)
```

Function: getElevationAreaStats(double minLatDeg, double maxLatDeg,
double minLonDeg, double maxLonDeg)

Return Type: double[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
elevationAreaStats = terrainAreaInterface.getElevationAreaStats(34.5,  
-122.23, 36.8, -121.9)
```

Function: getElevationMapBounds()

Return Type: double[][]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
elevationMapBounds = terrainAreaInterface.getElevationMapBounds()
```

Function: setTerrainProfile(double startLat, double endLat, double
startLon, double endLon, double resolution)

Return Type: int

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
terrainAreaInterface = environmentInterface.getTerrainInterface()  
success = terrainAreaInterface.setTerrainProfile(-56, 75, -180, 180,  
0.1)
```

EntityInterface API

Function: getControllerInterface()

Return Type: ControllerInterface

Example:

```
entityInterface = gnatsClient.getEntityInterface()  
controllerInterface = entityInterface.getControllerInterface()
```

Function: getPilotInterface()

Return Type: PilotInterface

Example:

```
entityInterface = gnatsClient.getEntityInterface()  
pilotInterface = entityInterface.getPilotInterface()
```

Function: getGroundOperatorInterface()

Return Type: GroundOperatorInterface

Example:

```
entityInterface = gnatsClient.getEntityInterface()  
groundOperatorInterface = entityInterface.getGroundOperatorInterface ()
```

WeatherInterface API

Function: DownloadWeatherFiles()

Return Type: int

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
weatherInterface = environmentInterface.getWeatherInterface()  
weatherInterface.DownloadWeatherFiles()
```

Function: getWind(float timestamp_sec,
float latitude_deg,
float longitude_deg,
float altitude_ft)

Return Type: float[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()  
weatherInterface = environmentInterface.getWeatherInterface()  
windValue = weatherInterface.getWind(6600.0, 40.0, -73.0, 20000.0)
```

Function: getWeatherPolygons(String ac_id, double lat_deg, double lon_deg, double alt_ft, double nauticalMile_radius)

Return Type: WeatherPolygon[]

Example:

```
environmentInterface = gnatsClient.getEnvironmentInterface()
weatherInterface = environmentInterface.getWeatherInterface()
windValue = weatherInterface.getWeatherPolygons("UA123", 48.0,
-120.0, 33000.0, 100.0)
```

ControllerInterface API

Function: setDelayPeriod(String acid, AircraftClearance aircraft_clearance, int seconds)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()
setDelayPeriod = controllerInterface.setDelayPeriod('ULI-SFD235',
AIRCRAFT_CLEARANCE_TAXI_DEPARTING, 10)
```

Function: setActionRepeat(String aircraftID, String repeatParameter)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()
controllerInterface.setActionRepeat('ULI-SFD235', 'COURSE')
```

Function: skipFlightPhase(String aircraftID, String flightPhase)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()
controllerInterface.skipFlightPhase('ULI-SFD235',
'FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE')
```

Function: setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()
controllerInterface.setWrongAction('ULI-SFD235', 'COURSE',
'AIRSPED')
```

Function: setActionReversal(String aircraftID, String changeParameter)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()
controllerInterface.setActionReversal('ULI-SFD235', 'COURSE')
```

Function: setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setPartialAction('ULI-SFD235', 'VERTICAL_SPEED',  
200, 25)
```

Function: skipChangeAction(String aircraftID, String skipParameter)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.skipChangeAction('ULI-SFD235', 'COURSE')
```

Function: setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setActionLag('ULI-SFD235', 'COURSE', 10,0.05, 30)
```

Function: setControllerAbsence(string aircraftID, int timeSteps)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setControllerAbsence ('ULI-SFD235', 5)
```

Function: releaseAircraftHold(String aircraftID, String approach, String targetWaypoint)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.releaseAircraftHold('ULI-SFD235', 'I07L',  
'FFIXA')
```

Function: enableConflictDetectionAndResolution(boolean flag)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.enableConflictDetectionAndResolution(True)
```

Function: setCDR_initiation_distance_ft_surface(float distance)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_initiation_distance_ft_surface(50000.0)
```

Function: setCDR_initiation_distance_ft_terminal(float distance)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_initiation_distance_ft_terminal(50000.0)
```

Function: setCDR_initiation_distance_ft_enroute(float distance)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_initiation_distance_ft_enroute(50000.0)
```

Function: setCDR_separation_distance_ft_surface(float distance)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_separation_distance_ft_surface(50000.0)
```

Function: setCDR_separation_distance_ft_terminal(float distance)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_separation_distance_resolve_ft_terminal(50000.0)
```

Function: setCDR_separation_distance_resolve_ft_enroute(float distance)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setCDR_separation_distance_ft_enroute(50000.0)
```

Function: enableStrategicWeatherAvoidance()

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.enableStrategicWeatherAvoidance()
```

Function: setWeather_polygonFile(String pathFilename)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setWeather_polygonFile("share/rg/polygons/xxxx.dat")
```

Function: setWeather_sigmetFile(String pathFilename)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.setWeather_sigmetFile("share/tg/weather/xxxx.sigmet")
```

Function: setTacticalWeatherAvoidance(String waypoint_name, float duration_sec)

Return Type: int

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
flag = controllerInterface.setTacticalWeatherAvoidance("ABCDE", 100)
```

Function: enableMergingAndSpacingAtMeterFix(String airportId, String meterFix, String trailAttribute, float timeInTrail/distanceInTrail)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.enableMergingAndSpacingAtMeterFix("KPHX",  
"GEELA", "DISTANCE", 4.5)
```

Function: disableMergingAndSpacingAtMeterFix(String airportId, String meterFix)

Return Type: void

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
controllerInterface.disableMergingAndSpacingAtMeterFix("KPHX", "GEELA")
```

Function: getCDR_status()

Return Type: Object[][]

Example:

```
controllerInterface = entityInterface.getControllerInterface()  
cdrStatus = controllerInterface.getCDR_status()
```

RiskMeasuresInterface API

Function: getFlightsInRange(String aircraftID)

Return Type: Object

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
flightsInRange = riskMeasuresInterface.getFlightsInRange('ULI-SFD235')
```

Function: getDistanceToRunwayThreshold(String aircraftID)

Return Type: double

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
distance = riskMeasuresInterface.getDistanceToRunwayThreshold ('ULI-SFD235')
```

Function: `getDistanceToRunwayEnd(String aircraftID)`

Return Type: `double`

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
distance = riskMeasuresInterface. getDistanceToRunwayEnd ('ULI-SFD235')
```

Function: `getVelocityAlignmentWithRunway(String aircraftID, String procedure)`

Return Type: `double`

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
alignmentAngle = riskMeasuresInterface.  
GetVelocityAlignmentWithRunway ('ULI-SFD235', 'DEPARTURE')
```

Function: `getPassengerCount(String aircraftType)`

Return Type: `int`

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
passengerCount = riskMeasuresInterface. getPassengerCount ('A306')
```

Function: `getAircraftCost(String aircraftID)`

Return Type: `double`

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
flightsInRange = riskMeasuresInterface.getAircraftCost ('A306')
```

Function: `getFlightsInWakeVortexRange(String refAircraftId, float envelopeStartLength, float envelopeStartBreadth, float envelopeEndLength, float envelopeEndBreadth, float envelopeRange, float envelopeAltitudeDrop)`

Return Type: `Object`

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getFlightsInWakeVortexRange('SWA1897', 200,  
150, 400, 350, 2, 50)
```

Function: `setAircraftBookValue(String aircraftId, float aircraftBookValue)`

Return Type: `int`

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setAircraftBookValue('SWA1897', 5.6)
```

Function: `setCargoWorth(String aircraftId, float cargoWorth)`

Return Type: `int`

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setCargoWorth('SWA1897', 1.2)
```

Function: setPassengerLoadFactor(String aircraftId, float paxLoadFactor)

Return Type: int

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setPassengerLoadFactor('SWA1897', 0.72)
```

Function: getAircraftBookValue(String aircraftId)

Return Type: float

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
aircraftBookValue =  
riskMeasuresInterface.getAircraftBookValue('SWA1897')
```

Function: getCargoWorth(String aircraftId)

Return Type: float

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
cargoWorth = riskMeasuresInterface.getCargoWorth('SWA1897')
```

Function: getPassengerLoadFactor(String aircraftId)

Return Type: float

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
paxLoadFactor =  
riskMeasuresInterface.getPassengerLoadFactor('SWA1897')
```

Function: setTouchdownPointOnRunway(String aircraftId, float latitude, float longitude)

Return Type: float

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setTouchdownPointOnRunway('SWA1897', 32.423,  
-123.123)
```

Function: getTouchdownPointOnRunway(String aircraftId)

Return Type: float

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
print riskMeasuresInterface.getTouchdownPointOnRunway('SWA1897')
```

Function: setTakeOffPointOnRunway(String aircraftId, float latitude, float longitude)

Return Type: float

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.setTakeOffPointOnRunway('SWA1897', 37.625735,  
-122.368191)
```

Function: getTakeOffPointOnRunway(String aircraftId)

Return Type: float

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
print riskMeasuresInterface.getTakeOffPointOnRunway('SWA1897')
```

Function: getL1Distance(String airportId, String aircraftId1, String aircraftId2)

Return Type: double

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getL1Distance('KSFO', 'SWA1897', 'SWA1898')
```

Function: getDistanceToPavementEdge(String airportId, String aircraftId)

Return Type: double

Example:

```
riskMeasuresInterface = gnatsClient.getRiskMeasuresInterface ()  
riskMeasuresInterface.getDistanceToPavementEdge('KSFO', 'SWA1897')
```

PilotInterface API

Function: setActionRepeat(String aircraftID, String repeatParameter)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setActionRepeat('ULI-SFD235', 'COURSE')
```

Function: skipFlightPhase(String aircraftID, String flightPhase)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.skipFlightPhase('ULI-SFD235',  
'FLIGHT_PHASE_CLIMB_TO_CRUISE_ALTITUDE')
```

Function: setWrongAction(String aircraftID, String originalChangeParameter, String wrongChangeParameter)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setWrongAction('ULI-SFD235', 'COURSE', 'AIRSPEED');
```

Function: setActionReversal(String aircraftID, String changeParameter)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()  
pilotInterface.setActionReversal('ULI-SFD235', 'COURSE')
```

Function: setPartialAction(String aircraftID, String changeParameter, float originalTarget, float percentage)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()
pilotInterface.setPartialAction('PLEASE_ENTER_AIRCRAFT_CALLSIGN_HERE'
, 'VERTICAL_SPEED', 200, 25);
```

Function: skipChangeAction(String aircraftID, String skipParameter)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()
pilotInterface.skipChangeAction('ULI-SFD235', 'COURSE')
```

Function: setActionLag(String aircraftID, String lagParameter, float lagTimeConstant, float percentageError, float parameterTarget)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()
pilotInterface.setActionLag('ULI-SFD235', 'COURSE', 10, 0.05, 30)
```

Function: setFlightPlanReadError(String aircraftID, String errorParameter, float updatedValue)

Return Type: int

Example:

```
pilotInterface = entityInterface.getPilotInterface()
pilotInterface.setFlightPlanReadError('ULI-SFD235', 'VERTICAL_SPEED',
398.0)
```

GroundOperatorInterface API

Function: setGroundOperatorAbsence(String groundVehicleId, int timeSteps)

Return Type: int

Example:

```
groundOperatorInterface =
entityInterface.getGroundOperatorInterface()
groundOperatorInterface.setGroundOperatorAbsence('BUS123', 4)
```

Function: setActionRepeat(String groundVehicleId, String repeatParameter)

Return Type: int

Example:

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setActionRepeat('BUS123', 'SPEED')
```

Function: setVehicleContact(String groundVehicleId)

Return Type: int

Interface:GroundOperatorInterface

Example:

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setVehicleContact('BUS123')
```

Function: setActionReversal(String groundVehicleId, String
changeParameter)

Return Type: int

Example:

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setActionReversal('BUS123', 'COURSE')
```

Function: setPartialAction(String groundVehicleId, String
changeParameter, float originalTarget, float percentage),

Return Type: int

Example:

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setPartialAction('BUS123', 'SPEED', 8, 50)
```

Function: setActionLag(String groundVehicleId, String lagParameter,
float lagTimeConstant, float percentageError, float parameterTarget)

Return Type: int

Example:

```
groundOperatorInterface =  
entityInterface.getGroundOperatorInterface()  
groundOperatorInterface.setActionLag('BUS123', 'SPEED', 10, 0.5, 30)
```

WeatherPolygon API

Function: getX_data()

Return Type: double[]

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
x_data_array = weatherPolygons[0].getX_data()
```

Function: getY_data()

Return Type: double[]

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
y_data_array = weatherPolygons[0].getY_data()
```

Function: getNum_vertices()

Return Type: int

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getNum_vertices()
```

Function: getCcw_flag()

Return Type: boolean

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getCcw_flag()
```

Function: getXmin()

Return Type: double

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getXmin()
```

Function: getXmax()

Return Type: double

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getXmax()
```

Function: getYmin()

Return Type: double

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()  
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,  
-120.0, 33000.0, 100.0)  
weatherPolygons[0].getYmin()
```

Function: getYmax()

Return Type: double

Example:


```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getYmax()
```

Function: getX_centroid()

Return Type: double

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getX_centroid()
```

Function: getY_centroid()

Return Type: double

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getY_centroid()
```

Function: getPoly_type()

Return Type: String

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getPoly_type()
```

Function: getStart_hour()

Return Type: int

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getStart_hour()
```

Function: getEnd_hour()

Return Type: int

Example:

```
weatherInterface = environmentInterface.getWeatherInterface()
weatherPolygons = weatherInterface.getWeatherPolygons('UA123', 48.0,
-120.0, 33000.0, 100.0)
weatherPolygons[0].getEnd_hour()
```