



The output MOSFET is connected to RSTOUT\_LOW on the MCU, which needs to be programmed with the ISP tool to be low after reset. This way the load stays off when the MCU is starting up.

Rev: 1  
Id: 1/1