

PLCnext Technology - MQTT Client

Date	Version
25.05.2019	1.1.1

IMPORTANT NOTE

Installing or uninstalling this Function Extension will automatically restart the PLC.

Description

MQTT GDS Connector is a PLCnext Technology component that exchanges data between Global Data Space (GDS) ports and MQTT server topics.

	Name	Type	Usage	
▼ Subscription				
	SubLoadTestInt8SINT	SINT	IN Port	Subscriptions are mapped to GDS In Ports
	SubLoadTestInt64LD	LINT	IN Port	
	SubLoadTestInt64LDT	LDATE_AND_TI...	IN Port	
	SubLoadTestInt16INT	INT	IN Port	
	SubLoadTestBool	BOOL	IN Port	
	SubLoadTestInt32DINT	DINT	IN Port	
	Enter variable name here			
▼ Publish				
	PubLoadTestBool	BOOL	OUT Port	GDS Out Ports are mapped to the publish topic and cyclically updated
	PubLoadTestInt8SINT	SINT	OUT Port	
	PubLoadTestInt64LD	LINT	OUT Port	
	PubLoadTestInt64LDT	LDATE_AND_TI...	OUT Port	
	PubLoadTestInt16INT	INT	OUT Port	
	PubLoadTestInt32DINT	DINT	OUT Port	
	Enter variable name here			
▼ Status				
	MQTT_Broker_Status	BOOL	IN Port	The (optional) status information is mapped to a GDS In Port. It is true when the given configuration is valid and the MQTT Client is connected with the MQTT Broker.

The component is configured with the file `mqtt_gds.settings.json` which is stored locally on the device.

```
{ "brokers":[{
  "host": "tcp://test.mosquitto.org:1883",
  "client_name": "MQTT_Test_App",
  "status_port": "Arp.Plc.Eclr/TestBench1.MQTT_Broker_Status",
  "connect_options":{
    "will_options":{
      "topic": "last_will_topic",
      "payload": "auf wiedersehen"
    }
  },
  "publish_data":[{
    "port" : "Arp.Plc.Eclr/TestBench1.PubLoadTestBool",
    "qos": 0,
    "retained": false,
    "topics" :[
      "LoadTestBool"
    ]
  }
],
  "subscribe_data":[{
    "topic" : "LoadTestBool",
    "ports" :[
      "Arp.Plc.Eclr/TestBench1.SubLoadTestBool"
    ]
  }
]
}]
}
```

The entries in this file must conform to the defined JSON schema (please refer for more details the chapter "configuration").

Note: Every invalid configuration (invalid schema or missing mandatory field) leads to a stop of the app. Debug information will appear in the Output.log file of the PLC.

</opt/plcnext/logs/output.log>

Requirements

- AXC F 2152 with minimum firmware version 2019.3
- Valid account for the PLCnext Store with payment credentials (not needed for the trial version)
- The PLCnext Control must be connected to the internet and must be registered in the PLCnext Store

Features

- The MQTT Client app is compatible with MQTT version 3.1 and 3.1.1
- Support of TCP and Websockets over an unencrypted or an encrypted (SSL/TLS) connection
- Automatic reconnect to the MQTT Broker
- Easy handling due to GDS port mapping, no further configuration effort
- Cyclic update of Publish Topics, individually adjustable (minimum 500ms)
- Support of the following data types* (Bool, Int8, Int16, Int32, Int64, UInt8, UInt16, UInt32, UInt64, Real32, Real64, String**, DateTime)

**The named data types are representing the C++ conventions, please refer the PLCnext Technology Handbook (available in the [PLCnext Community](#)) for the corresponding representation in IEC 61131-3 or in Matlab™ Simulink.*

***String data is always published with a terminating NULL character. When subscribing to String data, incoming message payloads must always include a terminating NULL character.*

Quick start

This example exchanges data between a PLC (MQTT Client) and an iPhone* or iPad* (both MQTT Clients) via a public MQTT broker, over an unencrypted connection. It requires a PLC that is connected to the internet, and a PC with access to both the PLC and the internet. For this example, the PC must have PLCnext Engineer software installed.

**There are many other free MQTT Test Clients for Android, Windows or Linux available*

1. Make sure that your AXC F 2152 has a firmware ≥ 2019.3 and that it has an internet connection
2. Register yourself and your AXC F 2152 in the PLCnext Store (www.plcnextstore.com) - not necessary when the app is installed manually
3. Deploy the app via the PLCnext Store (recommend) or manually
4. Create an IEC 61131 project in PLCnext Engineer version 2019.3, with the following configuration:
 - One AXC F 2152 PLC with firmware version ≥ 2019.0
 - one program called "Main"
 - one program OUT port called "PubMessage" of type STRING
 - one program IN port called "SubMessage" of type STRING
 - one instance of the Main program, called "MainInstance"
5. Download the PLCnext Engineer project to the PLC.
6. Go online to the PLC and change the value of the "PubMessage" variable in the "MainInstance" program instance.
7. Install the [MQTTTool app](#) on an iPhone or iPad.
8. Open the MQTTTool app and connect to the public Mosquitto test broker (test.mosquitto.org, port 1883).

9. On a PC, create a text file named `mqtt_gds.settings.json`, containing the following configuration:

```
{
  "brokers": [{
    "host": "tcp://test.mosquitto.org:1883",
    "client_name": "MyPLCnext",
    "connect_options": {
      "will_options": {
        "topic": "last_will_topic",
        "payload": "auf wiedersehen"
      }
    }
  },
  "publish_data": [{
    "port" : "Arp.Plc.Eclr/MainInstance.PubMessage",
    "qos" : 0,
    "retained": false,
    "topics" : [
      "MyPubTopic"
    ]
  }],
  "subscribe_data": [{
    "topic" : "MySubTopic",
    "ports" : [
      "Arp.Plc.Eclr/MainInstance.SubMessage"
    ]
  }],
  }]
```

In the configuration file, change the `client_name` property to a value that is likely to be unique on a public server.

Change the publish and subscribe `topic` properties to values that are likely to be unique on a public server.

10. Using WinSCP (Windows) or `scp` (Linux), copy the `mqtt_gds.settings.json` file to the following directory on the PLC: `/opt/plcnext/projects/MqttClient/`. Create this directory on the PLC if it does not exist already.

The default login credentials for the PLC are:

- User name : admin
- Password : <printed on the PLC housing>

11. Restart the PLC.

12. In the MQTTTool app on the iPhone or iPad, subscribe to the topic name that was entered in the `publish_data` section of the configuration file (e.g. "MyPubTopic").

13. The messages received on the iPhone or iPad now show the value of the PubMessage variable in the PLC.

14. On the iPhone or iPad, publish a message to the topic that was entered in the `subscribe_data` section of the configuration file (e.g. "MySubTopic"). This message now appears as the value of the SubMessage variable in the PLC.

Configuration reference

The MQTT GDS Client is configured with the file `mqtt_gds.settings.json`. This file must be located in the following directory on the PLC:

`/opt/plcnext/projects/MqttClient/`

This directory must be created on the PLC if it does not exist already.

For encrypted connections, a server certificate, client certificate and client private key may be required. These files should be copied to the PLC using WinSCP (Windows) or scp (Linux). The user is free to place these files anywhere on the PLC file system. The absolute path to these files must then be specified in the relevant `ssl_options` configuration fields.

All changes to the configuration will only take effect after a restart of the PLC.

Configuration schema

The configuration file `mqtt_gds.settings.json` must comply with the JSON schema defined in the file `mqtt_gds.schema.json`. This schema file must be located in the following directory on the PLC:

`/opt/plcnext/apps/60002172000048/`

Note: Every invalid configuration (invalid configuration or missing mandatory field) leads to a stop of the app. Debug information will appear in the `Output.log` file of the PLC.

`/opt/plcnext/logs/Output.log`

Broker properties

A valid configuration consists of an array of MQTT Broker objects. Each broker object represents one MQTT client-broker connection.

Note: The MQTT Client version 1.1 only supports one MQTT Broker connection.

Name	Required	JSON type	Description
host	Yes	string	The address of the server to connect to, specified as a URI. ¹
clientId	Yes	string	A client identifier that is unique on the server being connected to.
status_port	No	string	The name of a boolean GDS port that will receive the client connection status. ²
connect_options	Yes	object	The connection options. See table below.
publish_data	No	array of objects	MQTT publish information. See table below.

Name	Required	JSON type	Description
subscribe_data	No	array of objects	MQTT subscribe information. See table below.

Note:

1. The host *must* be specified in the following format:

protocol://host:port

... where *protocol* must be *tcp*, *ssl*, *ws* or *wss*. For *host*, you can specify either an IP address or a domain name.

2. Ports on PLCnext Engineer programs must be specified in the following format:

Arp.Plc.Eclr/ProgramInstance.PortName

... where *ProgramInstance* must be the name of the program instance in the PLCnext Engineer project, and *PortName* must be the name of a port variable defined in that program.

connect_options

Name	Required	JSON type	Default value	Description
username	No	string	NULL	The user name to use for the connection.
password	No	string	NULL	The password to use for the connection.
mqtt_version	No	integer	0	The version of MQTT to be used on the connect. ¹
will_options	Yes	object		The LWT options to use for the connection. See table below.
ssl_options	No	object		The SSL options to use for the connection. See table below.

Note:

1. mqtt_version:
 - 0 = default: start with 3.1.1, and if that fails, fall back to 3.1
 - 3 = only try version 3.1
 - 4 = only try version 3.1.1

will_options

Name	Required	JSON type	Description
topic	Yes	string	The LWT message is published to the this topic.
payload	Yes	string	The message that is published to the Will Topic.
qos	No	integer	The message Quality of Service.
retained	No	boolean	Tell the broker to keep the LWT message after send to subscribers.

ssl_options

The ssl option is only needed when encrypted ssl/ communication is used. Depending on the MQTT Broker policies, different configurations may be needed.

Name	Required	JSON type	Description
trust_store	Yes	string	The filename containing the public digital certificates trusted by the client.
key_store	No	string	The filename containing the public certificate chain of the client.
private_key	No	string	The filename containing the client's private key.
private_key_password	No	string	The password to load the client's privateKey (if encrypted).
enabled_cipher_suites	No	string	The list of cipher suites that the client will present to the server during the SSL handshake.
enable_server_cert_auth	No	boolean	Enable verification of the server certificate.

Broker configuration example

The following examples show two broker configurations. One is a simple unencrypted connection to the Mosquitto MQTT test broker and the other is an encrypted connection.

```
{ "brokers": [{
  "host": "tcp://test.mosquitto.org:1883",
  "client_name": "MQTT_Test_App",
  "status_port": "Arp.Plc.Eclr/TestBench1.MQTT_Broker_Status",
  "connect_options": {
    "will_options": {
      "topic": "last_will_topic",
      "payload": "auf wiedersehen"
    }
  }
}]
}
```

Configuration example for an unencrypted connection

```
{ "brokers": [{
  "host": "ssl://test.mosquitto.org:8883",
  "client_name": "MQTT_Test_App",
  "status_port": "Arp.Plc.Eclr/TestBench1.MQTT_Broker_Status",
  "connect_options": {
    "will_options": {
      "topic": "last_will_topic",
      "payload": "auf wiedersehen"
    }
  },
  "ssl_options": {
    {
      "trust_store":
"/opt/plcnext/projects/MqttClient/mosquitto.org.crt",
      "key_store": "/opt/plcnext/projects/MqttClient/client.crt",
      "private_key": "/opt/plcnext/projects/MqttClient/client.key",
      "private_key_password": "dont_tell",
      "enabled_cipher_suites": "",
      "enable_server_cert_auth": true
    }
  }
}]
}
```

Configuration example for an encrypted connection

publish_data

Publish_data must be an array of objects with the following properties:

Name	Required	JSON type	Description
port	Yes	string	The 'OUT' port from which data will be published ¹ .
period	No	integer	The publish frequency in seconds (max 86,400). If not specified, period=500ms.
qos	Yes	integer	The message Quality of Service ² .
retained	Yes	boolean	Tell the broker to keep messages after send to subscribers ³ .
topics	Yes	array of strings	Message are published to all these topics.

Note:

1. Ports published from PLCnext Engineer projects must be specified in the following format:

Arp.Plc.Eclr/ProgramInstance.PortName

... where *ProgramInstance* must be the name of the program instance in the PLCnext Engineer project, and *PortName* must be the name of an OUT port variable defined in that program.

2. The MQTT app version 1.1 does only support QoS 0
3. The MQTT app version 1.1 does not support 'retained'.

publish_data configuration example

The following example shows a valid configuration.

Note: Make sure that the assigned GDS port exists and that the data type is correct. An incorrect configuration will prevent the app from starting.

```
"publish_data": [{
  "port"    : "Arp.Plc.Eclr/TestBench1.PubLoadTestBool",
  "qos": 0,
  "retained": false,
  "topics" : [
    "LoadTestBool"
  ]
}]
```

subscribe_data

subscribe_data must be an array of objects with the following properties:

Name	Required	JSON type	Description
topic	Yes	string	This topic is subscribed Message are published to all these topics.
ports	Yes	array of strings	The 'IN' ports to which subscription data will be written ¹ .

Note:

1. Ports in PLCnext Engineer projects that subscribe to MQTT topics must be specified in the following format:

Arp.Plc.Eclr/ProgramInstance.PortName

... where *ProgramInstance* must be the name of the program instance in the PLCnext Engineer project, and *PortName* must the name of an IN port variable defined in that program.

subscribe_data configuration example

The following example shows a valid configuration.

Note: Make sure that the assigned GDS port exists and that the data type is correct. An incorrect configuration will prevent the app from starting.

```
"subscribe_data": [{
  "topic" : "LoadTestBool",
  "ports" : [
    "Arp.Plc.Eclr/TestBench1.SubLoadTestBool"
  ]
}]
```

Configuration examples

A complete configuration example can be found [here](#).

Remember that your own configuration file must **always** be named `mqtt_gds.settings.json`.

Known issues and limitations

- Only one client, and one concurrent server connection, is currently supported
- When the network connection to the broker is lost and restored, and a manual or automatic reconnect is triggered, the MQTT Client will block for precisely the number of milliseconds specified by the broker "timeout" property (default: 300 seconds).
- Complex data types (including Arrays and Structures) are not currently supported.
- Only QoS 0 is supported
- The app checks the assigned GDS port in terms of availability and type during the start-up process. Any changes to GDS ports (delete, rename or type) during operation (e.g. if a modified PLCnext Engineer project is downloaded without stopping the PLC) can lead to an undefined behaviour!

Error handling

The app logs the complete startup, connection and error history into the Output.log file (`/opt/plcnext/logs/Output.log`) of the PLC which gives the user a reliable indication of the current state of the app. In addition, a status port can be configured (please refer the chapter 'broker properties'). The value *true* indicates that the app was successfully started (configuration correct) and that connection to the configured MQTT Broker could be established. The value goes to *false* when the app could not be started (wrong configuration) or when the connection to the MQTT Broker could not be established or is interrupted.

Note: Phoenix Contact strongly recommend the usage of the "status_port".

Diagnostic Log

This chapter explains the most important diagnostic messages and is intended to support troubleshooting the MQTT app.

All diagnostics are printed in the output.log file (`/opt/plcnext/logs/Output.log`).

In the following is a positive start up of the app logged and described.

```
PxceTcs.Mqtt.GdsConnectorComponent    INFO - Loaded configuration from
file: /opt/plcnext/projects/MqttClient/mqtt_gds.settings.json
PxceTcs.Mqtt.GdsConnectorComponent    INFO - Loaded configuration schema.
```

The configuration was loaded successfully, no schema violations were detected.

Note: Every schema violation (missing json separators or missing mandatory fields) will lead to an error at this position. The message indicates the kind of the error.

```

PxceTcs.Mqtt.GdsConnectorComponent    INFO - No reconnect port has been
specified.
PxceTcs.Mqtt.GdsConnectorComponent    INFO - Created MQTT Client with ID:
56022
PxceTcs.Mqtt.GdsConnectorComponent    INFO - No MQTT SSL/TLS Options
provided. Defaults will be used.
PxceTcs.MqttClient.MqttClientManager  INFO - Connecting to MQTT server
PxceTcs.MqttClient.MqttClientManager  INFO - Connected
PxceTcs.Mqtt.GdsConnectorComponent    INFO - Connected to MQTT Client
56022

```

After the configuration was loaded, generates the MQTT client a random client ID and tries to connect with the defined MQTT Broker.

Note: Connection or certification problems will lead to an error at this position.

```

PxceTcs.Mqtt.GdsConnectorComponent    INFO - Subscribed to MQTT topic
LoadTestBool
PxceTcs.Mqtt.GdsConnectorComponent    INFO - Subscribed to MQTT topic
LoadTestBool1
PxceTcs.Mqtt.GdsConnectorComponent    INFO - SetupConfig(): Worker thread
has been started.

```

As soon as the connection is valid, the MQTT Client will start to publish and subscribe the configured topics. The cyclic update is performed with a worker thread (500ms). The app is now running.

Source code

This Function Extension uses two PLCnext Technology components. The source code for these components is available on Github:

- [MQTT Client](#)
- [MQTT GDS Connector](#)

Community contributions to these open-source projects are welcome.

How to get support

The MQTT Client app is supported in the forum of the [PLCnext Community](#). Please raise an issue with a detailed error description and paste always the Output.log file.

Copyright © 2019 Phoenix Contact Electronics GmbH

All rights reserved. This program and the accompanying materials are made available under the terms of the [MIT License](#) which accompanies this distribution.

This code uses:

1. [JSON for Modern C++](#)

Copyright (c) 2013-2019 [Niels Lohmann](#)

Licensed under the [MIT License](#) which accompanies this distribution.

The class contains the UTF-8 Decoder from Bjoern Hoehrmann which is licensed under the [MIT License](#) (see above). Copyright © 2008-2009 [Björn Hoehrmann](#) bjoern@hoehrmann.de

The class contains a slightly modified version of the Grisu2 algorithm from Florian Loitsch which is licensed under the [MIT License](#) (see above). Copyright © 2009 [Florian Loitsch](#)

2. [valijson](#)

Copyright (c) 2016, Tristan Penman

Copyright (c) 2016, Akamai Technologies, Inc.

All rights reserved.

Licensed under the [Simplified BSD License](#) which accompanies this distribution.