

| | | | | | | |
|--|----------------|--|--|--|--|--|
| Welcome! | | | | | | |
| Message | | | | | | |
| This document contains information about all the classes in the Python-POD_API. Each class has its own sheet which describes the class's origin, parent and child classes, imports, global and instance variables, and all methods with details about its parameters, returns, and exceptions. | | | | | | |
| Classes | | | | | | |
| Name | | | | | | |
| Setup_PodDevices | | | | | | |
| Setup_Interface | | | | | | |
| Setup_8206HR | | | | | | |
| POD_8206HR | | | | | | |
| POD_8401HR | | | | | | |
| POD_Basics | | | | | | |
| POD_Packets | | | | | | |
| POD_Commands | | | | | | |
| COM_io | | | | | | |
| Definitions | | | | | | |
| Word | Context | Definition | | | | |
| Parent | Class | Class that another class inherits from. | | | | |
| Child | Class | Class that inherits from another class. Children can overwrite/reimplement methods from the parent. | | | | |
| Local | Import origin | The imported program file that is directly accessible from the user's computer, often in the same or nearby directory. | | | | |
| Environment | Import origin | The imported program was installed into the user's python environment. | | | | |
| Class | Variable scope | The variable is global to the class, meaning all class instantiations have the same variable. Changing this variable affects all class instances. | | | | |
| Instance | Variable scope | The variable is specific to the class instance. All class instances have this variable, but the value can be different. Changing the value of this variable in one class does not affect others. | | | | |
| Dunder | Methods type | "Dunder" comes from "double underscore" in reference to methods surrounded by two underscores. They allow a class to use the built-in functions and operators of Python. | | | | |
| Instance | Methods type | Method that can only be called on an instantiated class object. Ex: MyClassObejct = MyClass(); MyClassObejct.InstanceMethod(). Instance methods have "self" as the first parameter. | | | | |
| Static | Methods type | Method that does not need an instantiated object to be called. Ex: StaticMethodReturnValue = ClassName.StaticMethod() | | | | |
| Parameter | Methods | Variables in a function declaration. Ex: MyFunction(parameter1, parameter 2,...) | | | | |
| Return | Methods | The value stored when a function returns to the caller. | | | | |

| Class | | | | | | |
|----------------------|---------------------|---|--|--|--|--|
| Name | File | Description | Parent | Child | Author | |
| Setup_PodDevices | Setup_PodDevices.py | Setup_PodDevices allows a user to set up and stream from any number of POD devices. The streamed data is saved to a file | N/A | N/A | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| time | Environment | For timing the duration of methods | | | | |
| os | Environment | Used for file handling | | | | |
| Thread | Environment | Used to stream from multiple POD devices and ask for user input concurrently. | threading | | | |
| floor | Environment | For rounding numbers | math | | | |
| Setup_8206HR | Local | For managing active 8206HR POD devices | Setup_8206HR | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| _setupPodDevices | Instance | Dictionary containing the Setup_Interface subclasses for each POD device. | { '8206-HR' : Setup_8206HR() } | | | |
| _saveFileName | Instance | String containing the path, filename, and file extension to a file to save streaming data to. The filename will be extended with "<DEVICE NAME>_<DEVICE NUMBER>" for each device. | Set by user | | | |
| _options | Instance | Dictionary listing the different options for the user to complete | { 1 : 'Start Streaming.', 2 : 'Show current settings.', 3 : 'Edit save file path.', 4 : 'Edit POD device parameters.', 5 : 'Connect a new POD device.', 6 : 'Reconnect current POD devices.', 7 : 'Generate initialization code.', 8 : 'Quit.' } | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| __init__ | Dunder | Initializes the class. Sets the default values of the class instance variables. Calls functions to complete the class setup. | saveFile:str None=None podParametersDict:dict[str,dict None] None={'8206-HR':None} | String describing the directory path and filename with an extension Dictionary of POD devices and their respective initialization dictionaries. | N/A | N/A |
| __del__ | Dunder | Deletes all POD device setup objects | N/A | N/A | N/A | N/A |
| GetPODparametersDict | Instance | Gets the POD device initialization dictionaries for all device types | N/A | N/A | Dictionary whose keys are the POD device name, and value the setup dictionary. | N/A |
| GetSaveFileName | Instance | Gets the name of the class object's save file | N/A | N/A | String of the save file name and path (_saveFileName) | N/A |
| GetOptions | Instance | Gets the dictionary of setup options | N/A | N/A | Dictionary listing the different options for the user to complete (_options) | N/A |
| SetupPODparameters | Instance | Sets up each POD device type. Used in initialization. | podParametersDict:dict[str,dict None] None={'8206-HR':None} | Dictionary of all POD devices initialization. The keys are the device name and the entries are the initialization dictionaries. | N/A | N/A |
| SetupSaveFile | Instance | Gets the path/file name from the user and stores it. Used in initialization. | saveFile:str None=None | String of the save file, which includes the directory path, filename, and file extension | N/A | N/A |
| Run | Instance | Prints the options and asks the user what to do. Loops until 'Quit' is chosen. | N/A | N/A | N/A | N/A |
| _PrintOptions | Instance | Prints options available for user | N/A | N/A | N/A | N/A |
| _AskOption | Instance | Asks user which option to do | N/A | N/A | Integer number representing an option key | User input must be an integer that is a key in the options dictionary. |
| _DoOption | Instance | Performs the methods associated with the user selected option | choice: int | Integer number representing an option key | N/A | N/A |
| _Stream | Instance | Streams data from all POD devices and prints the execution time. | N/A | N/A | Float of the execution time in seconds | N/A |
| _ShowCurrentSettings | Instance | Displays the POD device settings for all devices, and then prints the save file name | N/A | N/A | N/A | N/A |
| _EditSaveFilePath | Instance | Asks the user for a new file name and path, then sets the value to the POD devices. | N/A | N/A | N/A | N/A |
| _EditCheckConnect | Instance | Displays the POD devices parameters, asks the user to edit the device, and then reconnects the device for each POD device type. | N/A | N/A | N/A | N/A |
| _ConnectNewDevice | Instance | Asks the user for the POD device type, then it sets up that device | N/A | N/A | N/A | N/A |
| _Reconnect | Instance | Reconnects all POD devices | N/A | N/A | Bool that is true if all devices were successfully connected. False otherwise | N/A |
| _PrintInitCode | Instance | Prints code that can be used to initialize and run SetupPodDevices with the current parameters. | N/A | N/A | N/A | N/A |

| | | | | | | |
|------------------------------|----------|--|--|---|--|--|
| _PrintSaveFile | Instance | Prints the file path and name that data is saved to. Note that the device name and number will be appended to the end of the filename, | N/A | N/A | N/A | N/A |
| _CheckFileExt | Static | Checks for valid file extension | f | file name or extension | True if extension is in goodExt list, False otherwise | N/A |
| | | | fileExt:bool=True | Boolean flag that is true if f is an extension, false otherwise | | |
| | | | goodExt:list[str]=['.csv','.txt','.edf'] | List of valid file extensions | | |
| | | | printErr:bool=True | Boolean flag that, when true, will print an error statement | | |
| _GetFilePath | Static | Asks user for a path and filename to save streaming data to. | N/A | N/A | String of the file path, name, and extension. | Filename must end in .csv, .txt, or .edf |
| _GetFileName | Static | Asks the user for a filename | N/A | N/A | String of the file name and extension | Filename must end in .csv, .txt, or .edf |
| _SetFilenameToDevices | Instance | Sets the filename to each POD device type | N/A | N/A | N/A | N/A |
| _StreamAllDevices | Instance | Streams data from all the devices. User is asked to click enter to stop streaming. Data is saved to file. Uses threading. | N/A | N/A | N/A | N/A |
| _AskToStopStream | Instance | Asks user to press enter to stop streaming. The program will then prompt all POD devices to end stream. | N/A | N/A | N/A | N/A |
| _TimeFunc | Static | Runs a function and gets the calculated execution time | func: 'function' | function/method name | Float of the execution time in seconds rounded to 3 decimal places | N/A |

| Class | | | | | | |
|---------------------------------|-----------------------|---|---|--|---|-----------|
| Name | File | Description | Parent | Child | Author | |
| Setup_Interface | Setup_PodInterface.py | Setup_Interface provides the basic interface of required methods for subclasses to implement. SetupPodDevices.py is designed to handle any of these children. | N/A | Setup_8206HR | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| os | Environment | For file path handling. | | | | |
| EdfWriter | Environment | For writing to EDF files. | pyedflib | | | |
| Thread | Environment | For streaming from multiple POD devices. | threading | | | |
| IOBase | Environment | For return annotations for text file operations. | io | | | |
| COM_io | Local | For getting available COM ports. | SerialCommunication | | | |
| POD_Basics | Local | For annotating POD devices as function parameters. | BasicPodProtocol | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| __NAME | Class | Device name, should be overwritten by child subclasses. | 'GENERIC' | | | |
| __PORTKEY | Class | Dictionary key for the COM port. | 'Port' | | | |
| __podDevices | Instance | Dict of pod device objects. MUST have keys as device# | {} | | | |
| __podParametersDict | Instance | dictionary of device information. MUST have keys as device#, and each value must have {'__PORTKEY': str, ...other values...} | {} | | | |
| __saveFileName | Instance | string filename: <path>/file.ext. The device name and number will be appended to the filename | .. | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| __GetParam_onePODdevice | Instance | (Interface) Prompts the user to input all device setup parameters | forbiddenNames: list[str] | List of port names that are already used. | Dictionary of the device parameters. | N/A |
| __DisplayPODdeviceParameters | Instance | (Interface) Display all the pod device parameters in a table | N/A | N/A | N/A | N/A |
| __ConnectPODdevice | Instance | (Interface) Write setup commands to initialize the POD device with the user's parameters | deviceNum: int deviceParams: dict | Integer key for the device# dictionary of the device parameters. | True for successful connection, false otherwise | N/A |
| __StreamThreading | Instance | (Interface) Stream data and save data to a file. Each POD device has its own thread | N/A | N/A | dictionary with the key as the device# and value as the thread object | N/A |
| __StopStream | Instance | (Interface) Tell POD devices to stop streaming | N/A | N/A | N/A | N/A |
| __OpenSaveFile_TXT | Static | (Interface) Open a text file and write column names | fname: str | String file name | opened file object IOBase | |
| __OpenSaveFile_EDF | Instance | (Interface) Create an EDF file and write all channel information. | fname: str devNum: int | String file name Integer of the device# | EdfWriter file object | N/A |
| __Init__ | Dunder | Initializes the class instance variables | N/A | N/A | N/A | N/A |
| __del__ | Dunder | Disconnects all POD devices. | N/A | N/A | N/A | N/A |
| SetFileName | Instance | Sets the filename to save data to. Note that the device name and number will be appended to the end. | fileName: str | String file name | N/A | N/A |
| GetPODparametersDict | Instance | Gets a dictionary whose keys are the device number and the value is the device parameters dict. | N/A | N/A | N/A | N/A |
| SetupPODparameters | Instance | Sets the parameters for the POD devices. | podParametersDict: dict[int,dict] None=None | dictionary of the device parameters for all devices. | N/A | N/A |
| __SetNumberOfDevices | Instance | Asks the user for how many devices they want to setup | name: str | Name of the POD device type. | N/A | N/A |
| __ConnectAllPODdevices | Instance | Connects all POD devices | N/A | N/A | True if all devices are successfully connected, false otherwise. | N/A |
| __DisconnectAllPODdevices | Instance | Disconnects all POD devices by deleting all POD objects. | N/A | N/A | N/A | N/A |
| __AddPODdevice | Instance | Asks the user for the parameters for the new device. A new device# is generated. | N/A | N/A | N/A | N/A |
| __SetParam_allPODdevices | Instance | First gets the number of POD devices, then asks the user for the information for each device. | N/A | N/A | N/A | N/A |
| __ChoosePort | Static | Asks the user to select a COM port. | forbidden:list[str]=[] | List of port names that are already used. | String name of the port. | N/A |
| __GetPortsList | Static | Gets the names of all available ports. | forbidden:list[str]=[] | List of port names that are already used. | List of port names | N/A |
| __ValidateParams | Instance | Displays a table of the parameters of all devices, then asks the user if everything is correct. The user can then edit the parameters of a device. | N/A | N/A | N/A | N/A |
| __EditParams | Instance | Asks the user which device to edit, and then asks them to re-input the device parameters | N/A | N/A | N/A | N/A |
| __SelectPODdeviceFromDictToEdit | Instance | Asks the user to select a valid device number. The input must be an integer number of an existing device. | N/A | N/A | Integer for the device# | N/A |
| __GetForbiddenNames | Instance | Generates a list of port names used by the active pod devices. There is an option to exclude an additional name from the list. | key:str='Port' exclude:str None=None | String key to access the __podParametersDict String port name to exclude from the returned list | list of string names of ports in use. | N/A |
| __PrintDeviceNumber | Instance | Prints a title with the device# | num: int | Integer of the device# | N/A | N/A |
| __OpenSaveFile | Instance | Opens a save file for a given device | devNum: int | Integer of the device# | Open IOBase for a text file, or EdfWriter for EDF file. | N/A |

| | | | | | | |
|----------------------------------|----------|--|-----------------|--------------------------------|---|-------------------------|
| _BuildFileName | Instance | Appends the device name and number to the end of the file name. | devNum: int | Integer of the device# | String file name. | N/A |
| _Stream | Instance | Tests that all devices are connected then starts streaming data | N/A | N/A | Dictionary with integer device# keys and Thread values. | Test connection failed. |
| _TestDeviceConnection | Instance | Writes a PING packet, then reads the response. A connection is successful if PING is read back | pod: POD_Basics | POD device | True for successful connection, false otherwise | N/A |
| _TestDeviceConnection_All | Instance | Tests the connection of all POD devices | N/A | N/A | True when all devices are successfully connected, false otherwise | N/A |
| _AskYN | Static | Asks the user a yes or no question | question: str | String containing the question | True for yes, false otherwise. | N/A |

| Class | | | | | | |
|-----------------------------|-----------------|--|--|--|---|---|
| Name | File | Description | Parent | Child | Author | |
| Setup_8206HR | Setup_8206HR.py | Setup_8206HR provides the setup functions for an 8206-HR POD device. | Setup_Interface | N/A | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | As | | |
| texttable | Enviornment | For displaying the parameters in a table. | | | | |
| os | Enviornment | For file name handling. | | | | |
| numpy | Enviornment | For arrays. | | np | | |
| Thread | Enviornment | For streaming from multiple devices simultaneously. | threading | | | |
| EdfWriter | Enviornment | For writing to EDF files. | pyedflib | | | |
| IOBase | Enviornment | For return annotations for text files. | io | | | |
| Setup_Interface | Local | For inheritance. | | | | |
| POD_8206HR | Local | For communicating with 8206-HR POD devices | | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| _PARAMKEYS | Class | List of dictionary keys for device parameters | {Setup_Interface._PORTKEY, 'Sample Rate', 'Preamplifier Gain', 'Low Pass'} | | | |
| _LOWPASSKEYS | Class | List of dictionary keys for the Low Pass parameter. | ['EEG1', 'EEG2', 'EEG3/EMG'] | | | |
| _PHYSICAL_BOUND_uV | Class | Physical max/-min stream value in uV | 4069 | | | |
| _NAME | Class | Name of the POD device. Overwritten from Parent | '8206-HR' | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| _ConnectPODdevice | Instance | Creates a POD_8206HR object and write the setup parameters to it. | deviceNum: int deviceParams: dict[str, (str int dict[str, int])] | Integer of the device# Dictionary of the device#'s parameters | True of connection was successful, false otherwiae. | N/A |
| _GetParam_onePODdevice | Instance | Asks the user to input all the device parameters | forbiddenNames: list[str] | List of port names already used by other devices | Dictionary of device parameters | N/A |
| _ChooseSampleRate | Static | Asks user for the sample rate. | N/A | N/A | Integer number between 100-2000 Hz for the sample rate | Sample rate must be an integer between 100-2000 |
| _ChoosePreampGain | Static | Asks user for the preamplifier gain of their POD device | N/A | N/A | Integer 10 or 100 for the preamplifier gain | Gain must be an integer value of 10 or 100 |
| _ChooseLowpass | Static | Builds dictionary of all lowpass filters | N/A | N/A | Dictionary containing lowpass filters (EEG1, EEG2, EEG3/EMG) | N/A |
| _ChooseLowpassForEEG | Static | Asks user for lowpass value for a given EEG | eeg: str | String describing the current EEG (EEG1, EEG2, EEG3/EMG) | Integer number between 11-500 Hz for EEG | User input must be an integer between 11-500 |
| _DisplayPODdeviceParameters | Instance | Prints a table containing the parameters for all POD devices | N/A | N/A | N/A | N/A |
| _OpenSaveFile_TXT | Static | Opens a text file and write the column names | fname: str | String filename | Opened file | N/A |
| _OpenSaveFile_EDF | Instance | Opens EDF file and write header | fname: str devNum: int | String filename Integer device number | Opened file | N/A |
| _WriteDataToFile_TXT | Static | Writes data to an open text file | file: IOBase data: list[np.ndarray] sampleRate: int t: float | opened write file List of 3 items, one for each channel Integer sample rate in Hz integer time (in seconds) corresponding to the data | N/A | N/A |
| _WriteDataToFile_EDF | Static | Writes data to an open EDF file | file: EdfWriter data: list[np.ndarray] | opened EDF file List of 3 items, one for each channel | N/A | N/A |
| _StreamThreading | Instance | Opens a save file, then creates a thread for each device to stream and write data from. | N/A | N/A | Dictionary with keys as the device# and values as the started Thread. | N/A |
| _StreamUntilStop | Instance | Streams data from a POD device and saves data to file. Stops looking when a stop stream command is read. | pod: POD_8206HR file: IOBase EdfWriter sampleRate: int | POD device open file Integer sample rate in Hz | N/A | N/A |
| _StopStream | Instance | Write a command to stop streaming data to all POD devices | N/A | N/A | N/A | N/A |
| _uV | Static | Converts volts to microVolts, rounded to 6 decimal places | voltage: float int | number of volts | number of uV | N/A |

| Class | | | | | | |
|---------------------------|---------------------|--|------------------------------------|--|--|--|
| Name | File | Description | Parent | Child | Author | |
| POD_8206HR | PodDevice_8206HR.py | Handles communication using an 8206HR POD device. | POD_Basics | N/A | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| POD_Basics | Local | For inheritance | BasicPodProtocol | | | |
| POD_Packets | Local | For handling POD packets | PodPacketHandling | | | |
| POD_Commands | Local | For command constants | PodCommands | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| __B4LENGTH | Class | Constant containing the number of bytes for a full Binary4 packet | 16 | | | |
| __B4BINARYLENGTH | Class | Constant containing the number of bytes for binary data in a Binary4 packet | 8 | | | |
| __preampGain | Instance | Preamplifier gain | 10 or 100 | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| __init__ | Dunder | Runs when an instance is constructed. It runs the parent's initialization. Then it updates the __commands to contain the appropriate commands for an 8306HR POD device. | port baudrate=9600 | String of the serial port to be opened. Used when initializing the COM_io instance. Integer baud rate of the opened serial port. Used when initializing the COM_io instance. | N/A | N/A |
| UnpackPODpacket_Binary | Static | Overwrites the parent's method. Separates the components of a binary4 packet into a dictionary. | msg | Bytes string containing a complete binary4 Pod packet: STX (1 byte) + command (4 bytes) + packet number (1 bytes) + TTL (1 byte) + ch0 (2 bytes) + ch1 (2 bytes) + ch2 (2 bytes) + checksum (2 bytes) + ETX (1 byte) | A dictionary containing 'Command Number', 'Packet #', 'TTL', 'Ch0', 'Ch1', and 'Ch2' in bytes. | An exception is raised if (1) the packet does not have the minimum number of bytes, (2) does not begin with STX, or (3) does not end with ETX. |
| TranslatePODpacket_Binary | Static | Overwrites the parent's method. Unpacks the binary4 POD packet and converts the values of the ASCII-encoded bytes into integer values and the values of binary-encoded bytes into integers. Channel values are given in Volts. | msg | Bytes string containing a complete binary4 Pod packet: STX (1 byte) + command (4 bytes) + packet number (1 bytes) + TTL (1 byte) + ch0 (2 bytes) + ch1 (2 bytes) + ch2 (2 bytes) + checksum (2 bytes) + ETX (1 byte) | A dictionary containing 'Command Number', 'Packet #', 'TTL', 'Ch0', 'Ch1', and 'Ch2' as numbers. | N/A |
| TranslatePODpacket | Instance | Overwrites the parent's method. Determines if the packet is standard or binary, and translates accordingly. Adds a check for the 'GET TTL PORT' command. | | Bytes string containing either a standard or binary packet | A dictionary containing the unpacked message in numbers | N/A |
| __TranslateTTLbyte_ASCII | Static | Separates the bits of each TTL (0-3) from a byte. | tTlByte | One Byte string for the TTL (ASCII encoded) | Tuple of the integer TTLs (0-3). 1 when input, 0 when output. | N/A |
| __TranslateTTLbyte_Binary | Static | Separates the bits of each TTL (0-3) from a byte. | tTlByte | One Byte string for the TTL (binary encoded) | Tuple of the integer TTLs (0-3). 1 when input, 0 when output. | N/A |
| __BinaryBytesToVoltage | Instance | Converts a binary bytes value read from POD device and converts it to the real voltage value at the preamplifier input | value | Bytes string containing voltage measurement | A number containing the voltage in Volts [V]. | N/A |
| __Read_Binary | Instance | After receiving the prePacket, it reads the 8 bytes(TTL+channels) and then reads to ETX (checksum+ETX). | prePacket validateChecksum=True | Bytes string containing the beginning of a POD packet: STX (1 byte) + command number (4 bytes) Set to True to validate the checksum. Set to False to skip validation | Byte string for a binary4 POD packet. | N/A |

| Class | | | | | | |
|-------------------------------------|---------------------|--|---|---|---|--|
| Name | File | Description | Parent | Child | Author | |
| POD_8401HR | PodDevice_8401HR.py | Handles communication using an 8401HR POD device. | POD_Basics | N/A | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| POD_Basics | Local | For inheritance | BasicPodProtocol | | | |
| POD_Packets | Local | For handling POD packets | PodPacketHandling | | | |
| POD_Commands | Local | For command constants | PodCommands | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| __B5LENGTH | Class | number of bytes for a Binary 5 packet | 31 | | | |
| __B5BINARYLENGTH | Class | number of binary bytes for a Binary 5 packet | 23 | | | |
| __channelMap | Instance | Dictionary of the channel lables | Set by __GetChannelMapping(). Dictionary keys are ['A','B','C','D'] | | | |
| __ssGain | Instance | Dictionary of the second stage gain for all four channels | 1, 5, or None. Dictionary keys are ['A','B','C','D'] | | | |
| __preampGain | Instance | Dictionary of the preamplifier gain for all four channels. | 10, 100, or None. Dictionary keys are ['A','B','C','D'] | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| __init__ | Dunder | Runs when an instance is constructed. It runs the parent's initialization. Then it updates the __commands to contain the appropriate commands for an 8401HR POD device. Sets the __channelMap, __ssGain, and __preampGain. | port | String of the serial port to be opened. Used when initializing the COM_io instance. | N/A | An exception is raised if (1) the ssGain or preampGain have improper keys, (2) the device/sensor does not exist, (3) the ssGain was given bad values, or (4) the preampGain was given bad values |
| | | | deviceName | String of the corresponding device/sensor name | | |
| | | | ssGain={'A':None,'B':None,'C':None,'D':None} | Dictionary of the secondary stage gain | | |
| | | | preampGain={'A':None,'B':None,'C':None,'D':None} | Dictionary of the preamplifier gain | | |
| | | | baudrate=9600 | Integer baud rate of the opened serial port. Used when initializing the COM_io instance. | | |
| UnpackPODpacket_Binary | Static | Overwrites the parent's method. Separates the components of a binary5 packet into a dictionary. | msg | Bytes string containing a complete binary5 Pod packet: STX (1 byte) + command (4) + packet number (1) + status (1) + channels (9) + analog inputs (12) + checksum (2) + ETX (1) | A dictionary containing 'Command Number', 'Packet #', 'Status', 'Channels', 'Analog EXT0', 'Analog EXT1', 'Analog TTL1', 'Analog TTL2', 'Analog TTL3', 'Analog TTL4', in bytes. | An exception is raised if (1) the packet does not have the minimum number of bytes, (2) does not begin with STX, or (3) does not end with ETX. |
| TranslatePODpacket_Binary | Instance | Overwrites the parent's method. Unpacks the binary5 POD packet and converts the values of the ASCII-encoded bytes into integer values and the values of binary-encoded bytes into integers. The channels and analogs are converted to volts (V). | msg | Bytes string containing a complete binary5 Pod packet: STX (1 byte) + command (4) + packet number (1) + status (1) + channels (9) + analog inputs (12) + checksum (2) + ETX (1) | A dictionary containing 'Command Number', 'Packet #', 'Status', 'CH3', 'CH2', 'CH1', 'CH0', 'Analog EXT0', 'Analog EXT1', 'Analog TTL1', 'Analog TTL2', 'Analog TTL3', 'Analog TTL4', as numbers. | N/A |
| GetChannelMapping | Static | Get the channel mapping (channel labels for A,B,C,D) for a given device. | deviceName | String for the device/sensor name. | Dictionary with keys A,B,C,D with values of the channel names. Returns None if the device name does not exist. | N/A |
| __Voltage_PrimaryChannels | Static | Converts a value to a voltage for a primary channel. | value | Value to be converted to voltage | Number of the voltage in volts [V]. Returns value if no gain is given (no-connect). | N/A |
| | | | ssGain=None | Second stage gain | | |
| | | | PreampGain=None | Preamplifier gain | | |
| __Voltage_PrimaryChannels_EEGEMG | Static | Converts a value to a voltage for an EEG/EMG primary channel. | value | Value to be converted to voltage | Number of the voltage in volts [V]. | N/A |
| | | | ssGain | Second stage gain | | |
| | | | PreampGain | Preamplifier gain | | |
| __Voltage_PrimaryChannels_Biosensor | Static | Converts a value to a voltage for a biosensor primary channel. | value | Value to be converted to voltage | Number of the voltage in volts [V]. | N/A |
| | | | ssGain | Second stage gain | | |
| __Voltage_SecondaryChannels | Static | Converts a value to a voltage for a secondary channel. | value | Value to be converted to voltage | Number of the voltage in volts [V]. | N/A |
| __Read_Binary | Instance | After receiving the prePacket, it reads the 23 bytes (binary data) and then reads to ETX (checksum+ETX). | prePacket | Bytes string containing the beginning of a POD packet: STX (1 byte) + command number (4 bytes) | Byte string for a binary5 POD packet. | N/A |
| | | | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | | |

| Class | | | | | | |
|-------------------------|----------------------|---|-----------------|--|--|--|
| Name | File | Description | Parent | Child | Author | |
| POD_Packets | PodPacketHandling.py | Collection of methods for creating and interpreting POD packets | N/A | N/A | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| N/A | N/A | N/A | N/A | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| STX | Static | Get STX in bytes. STX marks the starting byte of a POD Packet | N/A | N/A | Bytes for STX (0x02) | N/A |
| ETX | Static | Get ETX in bytes. ETX marks the end byte of a POD Packet | N/A | N/A | Bytes for ETX(0x03) | N/A |
| IntToAsciiBytes | Static | Converts an integer value into ASCII-encoded bytes. First, it converts the integer value into a usable uppercase hexadecimal string. Then it converts the ASCII code for each character into bytes. Lastly, it ensures that the final message is the desired length. Example: if value=2 and numBytes=4, the returned ASCII will show b'0002', which is '0x30 0x30 0x30 0x32' in bytes. | value | Integer value to be converted into ASCII-encoded bytes | Bytes that are ASCII-encoded conversions of the value parameter. | N/A |
| | | | numBytes | Number bytes to be the length of the ASCII-encoded message. | | |
| AsciiBytesToInt | Static | Converts a ASCII-encoded bytes message into an integer. It does this using a base-16 conversion. | msg_b | Bytes message to be converted to an integer. The bytes must be base-16 or the conversion will fail. | Integer result from the ASCII-encoded byte conversion. | N/A |
| BinaryBytesToInt | Static | Converts binary-encoded bytes into an integer | msg | Bytes message holding binary information to be converted into an integer. | Integer result from the binary-encoded bytes message. | N/A |
| | | | byteorder='big' | Ordering of bytes. 'big' for big endian and 'little' for little endian. | | |
| | | | signed=False | Boolean flag to mark if the msg is signed (True) or unsigned (False) | | |
| ASCIlbytesToInt_Split | Static | Converts a specific bit range in an ASCII-encoded bytes object to an integer. | msg | Bytes message holding binary information to be converted into an integer. | Integer result from the ASCII-encoded bytes message in a given bit range. | N/A |
| | | | keepTopBits | Integer position of the msb of desired bit range | | |
| | | | cutBottomBits | Integer number of lsb to remove | | |
| BinaryBytesToInt_Split | Static | Converts a specific bit range in a binary-encoded bytes object to an integer | msg | Bytes message holding binary information to be converted into an integer. | Integer result from the binary-encoded bytes message in a given bit range. | N/A |
| | | | keepTopBits | Integer position of the msb of desired bit range | | |
| | | | cutBottomBits | Integer number of lsb to remove | | |
| | | | byteorder='big' | Ordering of bytes. 'big' for big endian and 'little' for little endian. | | |
| | | | signed=False | Boolean flag to mark if the msg is signed (True) or unsigned (False) | | |
| Checksum | | Calculates the checksum of a given bytes message. This is achieved by summing each byte in the message, inverting, and taking the last byte. | bytesIn | Bytes message containing POD packet data | Two ASCII-encoded bytes containing the checksum for bytesIn | N/A |
| BuildPODpacket_Standard | | Builds a standard POD packet -- STX (1 byte) + command number (4 bytes) + optional packet (? bytes) + checksum (2 bytes) + ETX (1 bytes) -- as bytes. | commandNumber | Integer representing the command number. This will be converted into a 4 byte long ASCII-encoded bytes string. | Bytes string of a complete standard POD packet | N/A |
| | | | payload=None | bytes string containing the payload | | |
| PayloadToBytes | Static | Converts a payload into a bytes string | payload | Integer, bytes, or tuple containing the payload | Bytes string of the payload | Raises an Exception when the payload argument is an incorrect type or formatted incorrectly. |
| | | | argSizes | Tuple of the argument sizes | | |

| Class | | | | | | |
|-----------------------------|---------------------|---|-----------------------|---|---|---|
| Name | File | Description | Parent | Child | Author | |
| POD_Basics | BasicPodProtocol.py | Handle basic communication with a POD device, including reading and writing packets and packet interpretation. | N/A | POD_8206HR | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| COM_io | Local | For opening and connecting serial COM ports | SerialCommunication | | | |
| POD_Packets | Local | For handling POD packets | PodPacketHandling | | | |
| POD_Commands | Local | Used to contain all POD commands in the class instance | PodCommands | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| __numPod | Class | Integer equal to the number of POD_Basics class instances. Incremented on construction and decremented on destruction | 0 | | | |
| __MINSTANDARDLENGTH | Class | Integer minimum number of bytes in a standard POD packet | 8 | | | |
| __MINBINARYLENGTH | Class | Integer minimum number of bytes in a binary POD packet | 15 | | | |
| _port | Instance | Open serial port via COM_io class instance | COM_io | | | |
| _commands | Instance | Command handler POD_Commands class instance | POD_Commands | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| __init__ | Dunder | Runs when an instance of POD_Basics is constructed. It initializes the instance variable for the COM port communication (_port) and for the command handler (_commands). It also increments the POD device counter (_NUMPOD). | port | String of the serial port to be opened. Used when initializing the COM_io instance. | N/A | N/A |
| | | | baudrate=9600 | Integer baud rate of the opened serial port. Used when initializing the COM_io instance. | | |
| __del__ | Dunder | Runs when an instance is destructed. It decrements the POD device counter (_NUMPOD) | N/A | N/A | N/A | N/A |
| GetNumberOfPODDevices | Static | Get the POD device counter | N/A | N/A | Integer of the number of class instances (_NUMPOD). | N/A |
| UnpackPODpacket_Standard | Static | Converts a standard POD packet into a dictionary containing the command number and payload (if applicable) in bytes. | msg | Bytes message containing a standard POD packet: STX (1 byte) + command number (4 bytes) + optional packet (? bytes) + checksum (2 bytes) + ETX (1 bytes) | A dictionary containing the POD packet's 'Command Number' and 'Payload' (if applicable) in bytes. | An exception is raised if (1) the msg does not have the minimum number of bytes in a standard pod packet, (2) does not begin with STX, and (3) does not end with ETX. |
| UnpackPODpacket_Binary | Static | Converts a variable-length binary packet into a dictionary containing the command number, binary packet length, and binary data in bytes. | msg | Bytes message containing a variable-length POD packet: STX (1 byte) + command number (4 bytes) + length of binary (4 bytes) + checksum (2 bytes) + ETX (1 bytes) * binary (LENGTH bytes) + checksum (2 bytes) + ETX (1 bytes) | A dictionary containing the 'Command Number', 'Binary Packet Length', and 'Binary Data' in bytes. | An exception is raised if (1) the msg does not have the minimum number of bytes in a standard pod packet, (2) does not begin with STX, (3) does not end with ETX, and (4) does not have an ETX after standard packet. |
| TranslatePODpacket_Standard | Instance | Unpacks the standard POD packet and converts the ASCII-encoded bytes values into integer values. | msg | Bytes message containing a standard POD packet | A dictionary containing the POD packet's 'Command Number' and 'Payload' (if applicable) in integers. | N/A |
| TranslatePODpacket_Binary | Static | Unpacks the variable-length binary POD packet and converts the values of the ASCII-encoded bytes into integer values and leaves the binary-encoded bytes as is. | msg | Bytes message containing a variable-length POD packet | A dictionary containing the 'Command Number' and 'Binary Packet Length' in integers, and 'Binary Data' in bytes. | N/A |
| _ValidateChecksum | Static | Validates the checksum of a given POD packet. The checksum is valid if the calculated checksum from the data matches the checksum written in the packet. | msg | Bytes message containing a POD packet: STX (1 bytes) + data (? bytes) + checksum (2 bytes) + ETX (1 byte). | Returns True if the checksum is correct, false otherwise. | An exception is raised if the msg does not begin with STX or end with ETX. |
| GetDeviceCommands | Instance | Gets the dictionary containing the class instance's available POD commands. | N/A | N/A | Dictionary containing the available commands and their information. Formatted as key(command number) : value([command name, number of argument ASCII bytes, number of return bytes, binary flag]) | N/A |
| SetBaudrateOfDevice | Instance | If the port is open, it will change the baud rate to the parameter's value | baudrate | Integer baud rate to set for the open serial port. | True if successful at setting the baud rate, false otherwise | N/A |
| UnpackPODpacket | Static | Determines if the packet is standard or binary, and unpacks accordingly. | msg | Bytes string containing either a standard or binary packet | A dictionary containing the unpacked message in bytes | N/A |
| TranslatePODpacket | Instance | Determines if the packet is standard or binary, and translates accordingly. | msg | Bytes string containing either a standard or binary packet | A dictionary containing the unpacked message in numbers | N/A |
| WriteRead | Instance | Writes a command with optional payload to POD device, then reads (once) the device response. | cmd | An integer representing the command number. | Bytes string containing a POD packet beginning with STX and ending with ETX. This may be a standard packet, binary packet, or an unformatted packet (STX+something+ETX). | N/A |
| | | | payload=None | None when there is no payload. If there is a payload, set to an integer value or a bytes string. | | |
| | | | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | | |
| | | Builds a POD packet and writes it to a POD device via | cmd | An integer representing the command number. | | An exception is raised if (1) the command does not |

| | | | | | | |
|---------------------------------|----------|---|-----------------------|---|--|---|
| GetPODpacket | Instance | Builds a POD packet and writes it to a POD device via COM port. If an integer payload is given, the method will convert it into a bytes string of the length expected by the command. If a bytes payload is given, it must be the correct length. | payload=None | None when there is no payload. If there is a payload, set to an integer value, bytes string, or tuple | Returns the bytes string of the POD packet. | exist for the instance, (2) a payload is not given when the command expects one, (3) the payload (given in bytes) is the size not expected by the command, or (4) the payload is given as a type other than integer or bytes. |
| WritePacket | Instance | Builds a POD packet and writes it to the POD device. | cmd | An integer representing the command number. | Returns the bytes string that was written to the POD device | N/A |
| | | | payload=None | None when there is no payload. If there is a payload, set to an integer value, bytes string, or tuple | | |
| ReadPODpacket | Instance | Reads a complete POD packet, either in standard or binary format, beginning with STX and ending with ETX. Reads first STX and then starts recursion. | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | Bytes string containing a POD packet beginning with STX and ending with ETX. This may be a standard packet, binary packet, or an unformatted packet (STX+something+ETX). | N/A |
| _ReadPODpacket_Recursive | Instance | Reads the command number. If the command number ends in ETX, the packet is returned. Next, it checks if the command is allowed. Then, it checks if the command is standard or binary and reads accordingly, then returns the packet. | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | Bytes string containing a POD packet beginning with STX and ending with ETX. This may be a standard packet, binary packet, or an unformatted packet (STX+something+ETX). | N/A |
| _Read_GetCommand | Instance | Reads one byte at a time up to 4 bytes to get the ASCII-encoded bytes command number. For each byte read, it can (1) start the recursion over if an STX is found, (2) returns if ETX is found, or (3) continue building the command number. | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | 4 byte long string containing the ASCII-encoded command number. | An exception is raised if the command number is not allowed for the POD device |
| _Read_ToETX | Instance | Reads one byte at a time until an ETX is found. It will restart the recursive read if an STX is found anywhere. | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | Bytes string ending with ETX | N/A |
| _Read_Standard | Instance | Reads the payload, checksum, and ETX. Then it builds the complete standard POD packet in bytes. | prePacket | Bytes string containing the beginning of a POD packet: STX (1 byte) + command number (4 bytes) | Bytes string for a complete standard POD packet | An exception is raised if the checksum is invalid (only if validateChecksum=True) |
| | | | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | | |
| _Read_Binary | Instance | Reads the remaining part of the variable-length binary packet. It first reads the standard packet (prePacket+payload+checksum+ETX). Then it determines how long the binary packet is from the payload of the standard POD packet and reads that many bytes. It then reads to ETX to get the checksum+ETX. | prePacket | Bytes string containing the beginning of a POD packet: STX (1 byte) + command number (4 bytes) | Bytes string for a variable-length binary POD packet | An exception is raised if the checksum is invalid (only if validateChecksum=True) |
| | | | validateChecksum=True | Set to True to validate the checksum. Set to False to skip validation | | |

| Class | | | | | | |
|-----------------------|----------------|--|-----------------|--|---|-----------|
| Name | File | Description | Parent | Child | Author | |
| POD_Commands | PodCommands.py | Manages a dictionary containing available commands for a POD device. | N/A | N/A | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| N/A | N/A | N/A | N/A | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| __NAME | Class | index key for the command name for __commands list values | 0 | | | |
| __ARGUMENTS | Class | index key for the number of bytes in an argument for __commands list values | 1 | | | |
| __RETURNS | Class | index key for the number of bytes in the return for __commands list values | 2 | | | |
| __BINARY | Class | index key for the binary flag for __commands list values | 3 | | | |
| __NOVALUE | Class | Integer used to mark when a list item in __commands means 'no value' or undefined. | -1 | | | |
| __U8 | Class | Number of bytes for an unsigned 8-bit value | 2 | | | |
| __U16 | Class | Number of bytes for an unsigned 16-bit value | 4 | | | |
| __commands | Instance | Dictionary containing the available commands for a POD device. Each entry is formatted as { key(command number) : value([command name, number of argument ASCII bytes, number of return bytes, binary flag]) } | { key : value } | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| __init__ | Dunder | Runs when an instance is constructed. It sends the commands dictionary to the basic command set. | N/A | N/A | N/A | N/A |
| NoValue | Static | Gets value of __NOVALUE | N/A | N/A | Value of __NOVALUE | N/A |
| U8 | Static | Gets value of __U8 | N/A | N/A | Value of __U8 | N/A |
| U16 | Static | Gets value of __U16 | N/A | N/A | Value of __U16 | N/A |
| GetBasicCommands | Static | Creates a dictionary containing the basic POD command set (0,1,2,3,4,5,6,7,8,9,10,11,12) | N/A | N/A | N/A | N/A |
| GetCommands | Instance | Gets the contents of the current command dictionary (__commands) | N/A | N/A | N/A | N/A |
| RestoreBasicCommands | Instance | Sets the current commands (__commands) to the basic POD command set. | N/A | N/A | N/A | N/A |
| AddCommand | Instance | Adds a command entry to the current commands dictionary (__commands) if the command does not exist | commandNumber | Integer of the command number | True if the command was successfully added, False if the command could not be added because it already exists. | N/A |
| | | | commandName | String of the command's name | | |
| | | | argumentBytes | Integer of the number of bytes in the argument | | |
| | | | returnBytes | Integer of the number of bytes in the return | | |
| | | | isBinary | Boolean flag to mark if the command is binary (True) or standard (False) | | |
| RemoveCommand | Instance | Removes the entry for a given command in __commands dictionary. | cmd | integer command number or string command name. | True if the command was successfully removed, False if the command does not exist. | N/A |
| CommandNumberFromName | Instance | Gets the command number from the command dictionary using the command's name | name | string of the command's name | Integer representing the command number. If the command could not be found, return None. | N/A |
| ArgumentBytes | Instance | Gets the tuple for the number of bytes in the argument for a given command. | cmd | integer command number or string command name. | Tuple representing the number of bytes in the argument for cmd. If the command could not be found, return None. | N/A |
| ReturnBytes | Instance | Gets the tuple for the number of bytes in the return for a given command. | cmd | integer command number or string command name. | Tuple representing the number of bytes in the return for cmd. If the command could not be found, return None. | N/A |
| IsCommandBinary | Instance | Gets the binary flag for a given command | cmd | integer command number or string command name. | Boolean flag that is True if the command is binary and False if standard. If the command could not be found, return None. | N/A |
| DoesCommandExist | Instance | Checks if a command exists in the __commands dictionary | cmd | integer command number or string command name. | True if the command exists, false otherwise. | N/A |

| Class | | | | | | |
|-------------------------|------------------------|---|-----------------------|---|---|---|
| Name | File | Description | Parent | Child | Author | |
| COM_io | SerialCommunication.py | Handle serial communication (read/write) using COM ports. | N/A | N/A | Thresa Kelly | |
| Imports | | | | | | |
| Name | Origin | Description | From | | | |
| serial.tools.list_ports | Environment | For accessing the COM ports on the computer | N/A | | | |
| Variables | | | | | | |
| Name | Scope | Description | Value | | | |
| __serialInst | Instance | Serial object to set the port and baud rate to. It can be opened or closed. | Serial | | | |
| Methods | | | | | | |
| Name | Type | Description | Parameter Name | Parameter Purpose | Return | Exception |
| GetCOMportsList | Static | Finds all the available COM ports on the user's computer and appends them to an accessible list. | N/A | N/A | List containing the names of available COM ports | N/A |
| __init__ | Dunder | Runs when the object is constructed. It initialized the __serialInst to a given COM port with a set baudrate. | port baudrate=9600 | String of the serial port to be opened. Integer baud rate of the opened serial port. | N/A | N/A |
| __del__ | Dunder | Runs when the object is destructed. It closes the serial port, if open. | N/A | N/A | N/A | N/A |
| __BuildPortName | Instance | Converts the port parameter into the "COM"<number> format | port | String name of a COM port. Can be an integer or string. | N/A | N/A |
| IsSerialOpen | Instance | Returns True if the serial instance port is open, false otherwise | N/A | N/A | N/A | N/A |
| IsSerialClosed | Instance | Returns False if the serial instance port is open, True otherwise | N/A | N/A | N/A | N/A |
| CloseSerialPort | Instance | Closes the instance serial port if it is open. | N/A | N/A | N/A | N/A |
| OpenSerialPort | Instance | First, it closes the serial port if it is open. Then, it opens a serial port with a set baud rate. | port baudrate=9600 | String of the serial port to be opened. Integer baud rate of the opened serial port. | N/A | Raises an exception if the given port does not exist. |
| SetBaudrate | Instance | If the port is open, it will change the baud rate to the parameter's value | baudrate | Integer baud rate to set for the open serial port. | True if successful at setting the baud rate, false otherwise | N/A |
| GetPortName | Instance | Gets the name of the open port. | N/A | N/A | If the serial port is open, it will return a string of the port's name. If the port is closed, it will return None. | N/A |
| Read | Instance | Reads a specified number of bytes from the open serial port. | numBytes | Integer number of bytes to read | If the serial port is open, it will return a set number of read bytes. If it is closed, it will return None. | N/A |
| ReadLine | Instance | Reads until a new line ('\n') from the open serial port. | N/A | N/A | If the serial port is open, it will return a complete read line. If closed, it will return None. | N/A |
| ReadUntil | Instance | Reads until a set character from the open serial port. | eol | end-of-line character | If the serial port is open, it will return a read line ending in eol. If closed, it will return None. | N/A |
| Write | Instance | Write a set message to the open serial port. | message | byte string containing the message to write | N/A | N/A |