

# MCAL User Manual for Crc

## 32-bit TriCore™ AURIX™ TC3xx microcontroller

### About this document

#### Scope and purpose

This User Manual is intended to enable users to integrate the Microcontroller Abstraction Layer (MCAL) software for the TriCore™ AURIX™ family of 32-bit microcontrollers.

This document describes responsibilities of integrator in-charge of integrating MCAL software with the basic software (BSW) stack. This document also provides detailed information on safety, configuration and functions along with examples of usage of significant features.

*Note: Detailed information about package installation, safety and other generic information that are common across all modules are provided in MCAL User Manual General.*

#### Intended audience

This document is intended for anyone using the Crc module of the TC3xx MCAL software.

#### Document conventions

**Table 1** Conventions

Convention	Explanation
<b>Bold</b>	Emphasizes heading levels, column headings, table and figure captions, screen names, windows, dialog boxes, menus, sub-menus
<i>Italics</i>	Denotes variable(s) and reference(s)
Courier	Denotes APIs, functions, interrupt handlers, events, data types, error handlers, file/folder names, directories, command line inputs, code snippets
New	
>	Indicates that a cascading sub-menu opens when you select a menu item
[cover parentID=<alpha numeric value>]	Used for traceability completeness. Reader should ignore these.

#### Reference documents

This User Manual should be read in conjunction with the following documents:

- AURIX™ TC3xx MCAL User Manual General
- Specification of CRC Driver, AUTOSAR\_SWS\_CRC\_Driver, AUTOSAR Release 4.2.2
- Specification of CRC Driver, AUTOSAR\_SWS\_CRC\_Driver, AUTOSAR Release 4.4.0

---

**Table of contents**
**Table of contents**

	<b>About this document</b> .....	1
	<b>Table of contents</b> .....	2
<b>1</b>	<b>CRC driver</b> .....	5
1.1	User information .....	5
1.1.1	Description .....	5
1.1.2	Hardware-software mapping .....	5
1.1.2.1	FCE: Primary hardware peripheral .....	6
1.1.2.2	SCU: dependent hardware peripheral .....	6
1.1.2.3	DMA: dependent hardware peripheral .....	6
1.1.2.4	SRC: dependent hardware peripheral .....	7
1.1.3	File structure .....	7
1.1.3.1	C file structure .....	7
1.1.3.2	Code generator plugin files .....	9
1.1.4	Integration hints .....	9
1.1.4.1	Integration with AUTOSAR stack .....	10
1.1.4.2	Multicore and Resource Manager .....	12
1.1.4.3	MCU support .....	12
1.1.4.4	Port support .....	13
1.1.4.5	DMA support .....	13
1.1.4.6	Interrupt connections .....	14
1.1.4.7	Example usage .....	15
1.1.5	Key architectural considerations .....	19
1.1.5.1	AUTOSAR modes of operation .....	19
1.1.5.2	CPU CRCN instruction .....	19
1.1.5.3	DMA based operation .....	20
1.2	Assumptions of Use (AoU) .....	21
1.3	Reference information .....	22
1.3.1	Configuration interfaces .....	22
1.3.1.1	Container: Crc .....	22
1.3.1.2	Container: CrcGeneral .....	22
1.3.1.2.1	Crc16ARCMODE .....	23
1.3.1.2.2	Crc16ARCReturnErrorValue .....	23
1.3.1.2.3	Crc16MODE .....	24
1.3.1.2.4	Crc16ReturnErrorValue .....	24
1.3.1.2.5	Crc32MODE .....	25
1.3.1.2.6	Crc32P4MODE .....	25
1.3.1.2.7	Crc32P4ReturnErrorValue .....	26
1.3.1.2.8	Crc32ReturnErrorValue .....	26
1.3.1.2.9	Crc64MODE .....	27

---

**Table of contents**

1.3.1.2.10	Crc64ReturnErrorValue .....	27
1.3.1.2.11	Crc8H2FMode .....	28
1.3.1.2.12	Crc8H2FReturnErrorValue .....	28
1.3.1.2.13	Crc8Mode .....	29
1.3.1.2.14	Crc8ReturnErrorValue .....	29
1.3.1.2.15	CrcDma16bitApi .....	30
1.3.1.2.16	CrcDma32P4bitApi .....	30
1.3.1.2.17	CrcDma32bitApi .....	31
1.3.1.2.18	CrcDma8bitApi .....	31
1.3.1.2.19	CrcRuntimeApiMode .....	32
1.3.1.2.20	CrcSafetyEnable .....	33
1.3.1.2.21	CrcVersionInfoApi .....	33
1.3.1.3	Container: CrcPublishedInformation .....	34
1.3.1.3.1	CrcInitialValue16 .....	34
1.3.1.3.2	CrcInitialValue16ARC .....	34
1.3.1.3.3	CrcInitialValue32 .....	35
1.3.1.3.4	CrcInitialValue32P4 .....	35
1.3.1.3.5	CrcInitialValue64 .....	36
1.3.1.3.6	CrcInitialValue8 .....	36
1.3.1.3.7	CrcInitialValue8H2F .....	37
1.3.1.4	Container: CommonPublishedInformation .....	37
1.3.1.4.1	ARPatchVersion .....	37
1.3.1.4.2	ArMajorVersion .....	38
1.3.1.4.3	ArMinorVersion .....	38
1.3.1.4.4	ModuleId .....	39
1.3.1.4.5	SwMajorVersion .....	39
1.3.1.4.6	SwMinorVersion .....	39
1.3.1.4.7	SwPatchVersion .....	40
1.3.1.4.8	VendorId .....	40
1.3.1.5	Container: CrcChannelConfig .....	41
1.3.1.5.1	CrcChannelId .....	41
1.3.1.5.2	CrcDmaChannel .....	42
1.3.1.5.3	CrcErrorNotification .....	42
1.3.1.5.4	CrcResultNotification .....	43
1.3.2	Functions - Type definitions .....	43
1.3.2.1	Crc_ChannelConfigType .....	44
1.3.2.2	Crc_DmaReturnType .....	44
1.3.2.3	Crc_ErrNotificationPtrType .....	45
1.3.2.4	Crc_ResNotificationPtrType .....	45
1.3.3	Functions - APIs .....	46
1.3.3.1	Crc_CalculateCRC8 .....	46
1.3.3.2	Crc_CalculateCRC8H2F .....	47

---

**Table of contents**

1.3.3.3	Crc_CalculateCRC16 .....	48
1.3.3.4	Crc_CalculateCRC16ARC .....	49
1.3.3.5	Crc_CalculateCRC32 .....	50
1.3.3.6	Crc_CalculateCRC32P4 .....	51
1.3.3.7	Crc_CalculateCRC64 .....	52
1.3.3.8	Crc_DmaCalculateCRC8 .....	53
1.3.3.9	Crc_DmaCalculateCRC16 .....	54
1.3.3.10	Crc_DmaCalculateCRC32 .....	56
1.3.3.11	Crc_DmaCalculateCRC32P4 .....	57
1.3.3.12	Crc_GetVersionInfo .....	58
1.3.4	Notifications and Callbacks .....	59
1.3.4.1	Crc_DmaErrorIsr .....	59
1.3.4.2	Crc_DmaTransferIsr .....	60
1.3.5	Scheduled functions .....	61
1.3.6	Interrupt service routines .....	61
1.3.7	Callout .....	61
1.3.8	Errors Handling .....	61
1.3.9	Deviations and limitations .....	62
1.3.9.1	Deviations .....	62
1.3.9.1.1	Software specification deviations .....	62
1.3.9.1.2	AMDC Violations .....	63
1.3.9.1.3	VSMD Violations .....	63
1.3.9.2	Limitations .....	63
	<b>Revision history</b> .....	64
	<b>Disclaimer</b> .....	65

## 1 CRC driver

# 1 CRC driver


## 1.1 User information

### 1.1.1 Description

The CRC driver provides APIs to calculate the CRC for 8-bit, 16-bit, 32-bit and 64-bit polynomials, prescribed by AUTOSAR. The CRC driver performs CRC calculations by using hardware, runtime, table and DMA modes. It uses the Tricore hardware instructions and FCE hardware to perform the CRC calculation. The CRC driver is developed as a pre-compile variant.

### 1.1.2 Hardware-software mapping

This section describes the system view of the CRC driver and peripherals administered by it.



**Figure 1 Mapping of hardware-software interfaces**

---

**1 CRC driver****1.1.2.1 FCE: Primary hardware peripheral****Hardware functional features**

For DMA based operations, the CRC driver uses the FCE IP for calculating CRC.

CRC driver shall support the following polynomials provided by the FCE engine.

- CRC8
- CRC16
- CRC32
- CRC32P4

For DMA based operations, FCE IP is used. Each polynomial has a kernel to support the CRC calculation.

DMA channel will be exploited to transfer the input data to FCE register.

The unsupported feature of the FCE IP are:

- Automatic signature check
- Register protection and monitoring

**Users of the hardware**

The CRC driver exclusively utilizes the FCE IP for DMA operations.

**Hardware diagnostic features**

Not applicable.

**Hardware events**

Hardware events from the FCE IP like transient error detection or checksum failure are not used by the FCE driver.

**1.1.2.2 SCU: dependent hardware peripheral****Hardware functional features**

The CRC driver depends on the SCU IP for the clock functionality. The driver requires fSPB clock signal for functioning.

**Users of the hardware**

The SCU IP supplies clock for all the peripherals and the MCU driver is responsible for configuring the clock tree. To avoid conflicts due to simultaneous writes, update to all the ENDINIT protected registers is performed using the MCALLIB APIs.

**Hardware diagnostic features**

The SMU alarms configured for the SCU IP are not monitored by the CRC driver.

**Hardware events**

Hardware events from the SCU are not used by the CRC driver.

**1.1.2.3 DMA: dependent hardware peripheral****Hardware functional features**

The CRC driver depends on the DMA IP for transferring the data to the FCE IR register.

---

## 1 CRC driver

Each core is assigned with only one of the DMA channels which are linked to one of the FCE channels.

### Users of the hardware

The DMA channels used for the CRC driver must be reserved and configured by the application through configurations provided by RM and DMA. The reserved DMA channels are exclusively used by CRC.

DMA based CRC APIs shall re-configure DMA channel settings during runtime based on the input parameters. The DMA source address shall be the address of the passed data pointer, DMA destination address shall be the address of the linked FCE channel's IR register and the DMA transfer width shall be the width of the polynomial being calculated.

### Hardware diagnostic features

- SMU alarms configured for the DMA are not monitored by the CRC driver

### Hardware events

- DMA error interrupt is enabled during data transmission and routed to the CRC driver by the DMA driver.
- DMA's successful transfer completion interrupts for the reserved channel is routed to the CRC driver by the DMA driver.

## 1.1.2.4 SRC: dependent hardware peripheral

### Hardware functional features

The CRC driver depends on the interrupt router for raising an interrupt to the CPU or DMA based on data transfer which indicates the status of data transfer.

### Users of the hardware

- The interrupt router is configured either by the IRQ driver or the user software.

### Hardware diagnostic features

- The SMU alarms configured for the interrupt router are not monitored by the CRC driver.

### Hardware events


- The interrupt events raised by the interrupt router are serviced by the CPU or DMA. The CRC driver provides interrupt handlers as software interfaces, which must be invoked from the ISR.

## 1.1.3 File structure

### 1.1.3.1 C file structure

This section provides details of the C files of the CRC driver.

### 1 CRC driver



**Figure 2** Crc\_C\_File\_Structure-1.png

**Table 2** C file structure

File name	Description
Compiler.h	Provides abstraction from compiler-specific keywords
Crc.c	Contains the implementation of the CRC feature.
Crc.h	Provides the functional prototypes and access to the CRC driver function. This file exports only the necessary interfaces for upper layer.
Crc_Cbk.h	Result notification ISR on the completion of CRC and error notification ISR are declared.
Crc_Cfg.c	Generated header file containing configuration data of the user.
Crc_Cfg.h	Provides the specific parameters of FCE.
Crc_MemMap.h	File (Static) containing the memory section definitions used by the CRC driver.
Dma.h	Header file (static) defining prototypes of data structures and APIs
IfxFce_reg.h	SFR header file for FCE
IfxFce_regdef.h	SFR header file for FCE
Mcallib.h	Static header file defining prototypes of data structure and APIs exported by the MCALLIB.
Mcallib_OsStub.h	Mcallib_OsStub.h provides macros to support user mode of Tricore. This shall be included by other drivers to call OS APIs.
Mcal_Compiler.h	Header file providing abstraction for TriCore™-intrinsic instruction.




## 1 CRC driver

**Table 2** C file structure (continued)

File name	Description
Mcal_SafetyError.h	Header file containing the prototype of the API for reporting safety-related errors
Platform_Types.h	Platform-specific type declaration file as defined by AUTOSAR
Std_Types.h	Standard type declaration file as defined by AUTOSAR. It is independent of compiler or platform.

### 1.1.3.2 Code generator plugin files

This section provides details of the code generator plugin files of the CRC driver.



**Figure 3** Crc\_Code\_Generator\_Plugin\_Files-1.png

**Table 3** Code generator plugin files

File name	Description
Crc.bmd	Code template macro file for CRC driver.
Crc.m	Code template macro file for CRC driver.
Crc.xdm	Tresos format XML data model schema file.
Crc_Bswmd.arxml	AUTOSAR format module description file.
Crc_Catalog.xml	AUTOSAR format catalog file
MANIFEST.MF	Tresos plugin support file containing the metadata for CRC driver
anchors.xml	AUTOSAR format module description file
plugin.properties	Tresos plugin support file for the CRC driver
plugin.xml	Tresos plugin support file for the CRC driver

### 1.1.4 Integration hints

This section lists the key points that an integrator or user of the CRC driver must consider.

---

**1 CRC driver****1.1.4.1 Integration with AUTOSAR stack**

This section lists the modules, which are not part of the MCAL, but are required to integrate the CRC driver.

- **EcuM**

EcuM module is not required for the integration of the CRC driver.

- **Memory mapping**

Memory mapping is a concept from AUTOSAR that allows relocation of text, variables, constants and configuration data to user-specific memory regions. To achieve this, all the relocatable elements of the driver are encapsulated in different memory-section macros. These macros are defined in the `Crc_MemMap.h` file.

The `Crc_MemMap.h` file is provided in the MCAL package as a stub code. The integrator must place appropriate compiler pragmas within the memory-section macros. The pragmas ensure that the elements

## 1 CRC driver

are relocated to the correct memory region. A sample implementation listing the memory-section macros is shown as follows.

```
#if defined CRC_START_SEC_CONST_ASIL_B_GLOBAL_8
/*****User pragmas here for PFlash*****/
#undef CRC_START_SEC_CONST_ASIL_B_GLOBAL_8
#undef MEMMAP_ERROR

#elif defined CRC_STOP_SEC_CONST_ASIL_B_GLOBAL_8
/*****User pragmas here for default section*****/
#undef CRC_STOP_SEC_CONST_ASIL_B_GLOBAL_8
#undef MEMMAP_ERROR

#elif defined CRC_START_SEC_CODE_ASIL_B_GLOBAL
/*****User pragmas here for PFlash*****/
#undef CRC_START_SEC_CODE_ASIL_B_GLOBAL
#undef MEMMAP_ERROR

#elif defined CRC_STOP_SEC_CODE_ASIL_B_GLOBAL
/*****User pragmas here for default section*****/
#undef CRC_STOP_SEC_CODE_ASIL_B_GLOBAL
#undef MEMMAP_ERROR

#elif defined CRC_START_SEC_VAR_INIT_ASIL_B_GLOBAL_8
/*****User pragmas here for non-cached LMU*****/
#undef CRC_START_SEC_VAR_INIT_ASIL_B_GLOBAL_8
#undef MEMMAP_ERROR

#elif defined CRC_STOP_SEC_VAR_INIT_ASIL_B_GLOBAL_8
/*****User pragmas here for default section*****/
#undef CRC_STOP_SEC_VAR_INIT_ASIL_B_GLOBAL_8
#undef MEMMAP_ERROR

#endif

#if defined MEMMAP_ERROR
#error "Crc_MemMap.h, wrong pragma command"
#endif
```

- **DET**

DET module is not required for the integration of the CRC driver.

- **DEM**

DEM module is not required for the integration of the CRC driver.

- **Safety errors**

The CRC driver will report all the detected safety errors through the `Mca1_ReportSafetyError` API .

The driver performs only detection and reporting of the safety errors. The handling of the reported errors shall be done by the user. The `Mca1_ReportSafetyError` API is provided in the files `Mca1_SafetyError.c` and `Mca1_SafetyError.h` as a stub code, and must be updated by the integrator to handle the reported errors.

- **Notifications and callbacks**

## 1 CRC driver

The CRC driver implements notification functions `Crc_DmaTransferIsr` and `Crc_DmaErrorIsr` for notifying the completion of successful data transfer and for notifying the RP error occurred during the data transfer respectively.

These notification functions can be configured by the user in the EB Tresos tool in the DMA configuration.

- **Operating system**


Enabling and disabling of interrupts must be managed by the OS or application.

OS files provided by MCAL package are only an example code and must be updated by the integrator with the actual OS files for the desired function.

### 1.1.4.2 Multicore and Resource Manager

The CRC driver supports execution of its APIs simultaneously from all CPU cores. Each core shall be assigned with only one of the DMA channels which shall be linked to one of the FCE channels in the CRC configuration. The user shall allocate for each core a unique DMA channel for the CRC module in DMA configuration and FCE channel in CRC configuration.

Image below shows the allocation of a DMA resource to a core.



**Figure 4 Configuration of DMA resource in the Resource Manager.**

The following are the key points to be considered with respect to multicore in the driver:

Locating constants and variables to correct memory space should be done by the user. Memory sections are marked as GLOBAL (common to all cores). The following should be considered by the user to ensure better performance of the driver:

**Code section:**

The executable code of the CRC driver is placed under single MemMap section. It can be relocated to any PFlash region.

**Data section:**

The sections marked as global should be relocated to the non-cached LMU region.

**Constants:**

The sections marked as global should be relocated to the PFlash of the master core.

*Note: Relocating code, data or constants to a distant memory region would impact execution timings.*

### 1.1.4.3 MCU support

The CRC driver is dependent on MCU driver for clock configuration. The APIs of the CRC driver must be started only after completion of MCU initialization.

### 1 CRC driver

#### 1.1.4.4 Port support


CRC driver does not use any services provided by the PORT driver.

#### 1.1.4.5 DMA support


The CRC driver is dependent on the DMA IP for transferring the data to the FCE IR register. DMA channels should be configured when one/all of the DMA based CRC API is/are enables. The maximum number of required DMA channels by the CRC module depends on the number of available cores in the variant. Once the DMA channel is assigned to the CRC module, these channels must be reserved only for the CRC module and cannot be reused.

##### Configurations of the DMA module

1. In the DMA, in the General configuration section, enable DmaMESourceErrorInterrupt and DmaMEDestinationErrorInterrupt for receiving the move engine errors as show in Figure 5. Enable other configuration items as required by the application.
2. Add the DMA channel and configure the notification function pointers (Refer Figure 6). No other configurations are required in DMA. Transaction control set configurations for DMA are handled in CRC module and does not need any configuration in the DMA module.



**Figure 5** Enable Move engine parameter



**Figure 6** DMA Resource configuration

*Note: If the DmaChannelNotification and DmaErrorNotification are not configured with the correct function pointers, this will result in a Codegen error.*

#### ESM - DMA Error handling and Supervision

The following are the safety measure for the user, while using the DMA based CRC APIs:

In the event of a DMA error, the error call back function will be invoked for that CPU core. The user shall determine the DMA channel, since the DMA channel is assigned exclusively to a CPU core.

The sequence of CRC calculation would be as follows, considering the error scenario:

1. A CRC request using DMA is initiated by the user.
2. If a DMA error occurs, user shall reinitialize the DMA channel using Dma\_ChInit API.

## 1 CRC driver


3. The same CRC request can be retrIGGERED by the user.

### 1.1.4.6 Interrupt connections

The interrupt connections of the CRC driver are described in this section.

DMA would trigger a interrupt at the end of the successful channel transmission or the failed transmission. The notification and error function pointer configured during the DMA configuration will be invoked by the DMA module.

Priority should be set for the DMA channel assigned across the cores. The user shall ensure that the interrupt priority for Crc\_DmaErrorIsr ISR is configured as higher than the Crc\_DmaTransferIsr ISR.




**Figure 7** DMA Channel priority set in the IRQ configuration

### 1 CRC driver

#### 1.1.4.7 Example usage


##### Configuration for AUTOSAR APIs

Each CRC polynomial can be set to any one of the given three modes with the exception of Crc32P4Mode and Crc64Mode which has only two modes. Refer the image below.




**Figure 8 Mode selection for CRC calculation**

For getting the expected error value on the failure of the successful CRC calculation make sure the CrcSafetyEnable is enabled and the return value is configured. If it is OFF, the error value parameters are disabled. The default value is zero.



**Figure 9 CrcSafetyEnable is enabled**

### 1 CRC driver



**Figure 10** CrcSafetyEnable is disabled

#### Using the APIs

The code snippet shows an example of CRC calculation with 8-bit polynomial (0x1D).

*Note: The type of each parameter varies for calculating CRC result for 8-bit, 16-bit, 32-bit, 64-bit and for the return value.*

```
*Calling the CRC8 with polynomial = 0x1D */
Crc8Result = Crc_CalculateCRC8(Crc_DataPtr, Crc_Length, Crc_StartValue8,
Crc_IsFirstCall);
```

The usage of the parameters are as follows:

- Crc\_DataPtr is the pointer to the start of the block.
- Crc\_Length is the size of the block array.
- Crc\_StartValue8 is the start value to be used by algorithm.
- Crc\_IsFirstCall selects the start value for CRC calculation. TRUE will select default initial value for the particular polynomial as start value for CRC calculation. FALSE will select the start value provided as argument as start value for CRC calculation.

#### Configuration for DMA based APIs

CRC calculation can also be obtained by invoking the DMA based CRC APIs. These APIs execute in the hardware mode where the FCE kernels are invoked for producing the desired result. DMA channels are exploited for transferring the user data input to the FCE engine for the CRC calculation.

The FCE engine has the support for the following polynomials:

- CRC8
- CRC16
- CRC32
- CRC32P4

The DMA based APIs mode can be enabled in the Tresos configuration. Following are the pre-requisite for CRC Calculation using DMA based APIs:

*Note: Refer to integration hints of CRC driver and add all the dependent modules required for the configuration.*




### 1 CRC driver

#### 1. Enable the DMA based API:

Enable the switch of the required bit calculation in the CRC module configuration under General configuration container.

- CrcDma8bitApi is for enabling CRC8
- CrcDma16bitApi is for enabling CRC16
- CrcDma32bitApi is for enabling CRC32
- CrcDma32P4bitApi is for enabling CRC32P4

The image below shows the API for CRC8 polynomial is enabled by enabling the CrcDma8bitApi.



**Figure 11 CrcDma8bitApi is enabled**

#### 2. Configure the DMA channel in the DMA configuration for the CRC module.

Refer the DMA support in the integration hint to configure the DMA channel for the CRC module.

#### 3. Set the priority of the DMA channel allocated to the CRC in the IRQ configuration.

Refer the Interrupt support in the integration hint to configure the priority of the DMA channels.

#### 4. Allocate the assigned DMA channels across the cores.

Below points shall be followed while assigning the DMA resources to the core in the Resource Manager.


- Assign only those channel in the Resource Manager which are allocated to the CRC module.
- Each core should have only one DMA channel assigned to it.

Refer the Multicore and Resource Manager in the integration hint to allocated the DMA resource in the Resource Manager.

#### 5. Configure the FCE resource in the CRC configuration and assign the DMA channel to the FCE channel.

Configure the FCE resource under the container CrcChannelConfig as shown in the figure below

### 1 CRC driver




**Figure 12 FCE resource allocation in the CRC configuration**

Configure the `CrcResultNotification` and `CrcErrorNotification` with the user defined callback function pointer for notification of the available result and for the notification of any error occurred during the CRC calculation.

*Note: If the `CrcResultNotification` and `CrcErrorNotification` are not configured with the correct function pointers, this will result in a Codegen error.*

When none of the DMA based API is enabled, the `CrcChannelConfig` container will be disabled for editing. Make sure the container is empty when it is disabled. If the `CrcChannelConfig` container the FCE resource and all the DMA based API is disabled, this will result in a Codegen error as this is a wastage of the DMA resource, hence unallocate all the DMA resource allocated to the CRC module in the DMA module and remove them from the `CrcChannelConfig` container.

The below image shows `CrcChannelConfig` configuration, when none of the DMA based API is enabled.



**Figure 13 Empty CrcChannelConfig container**

6. Once all the configurations are done successfully in the Tresos, Following the below sequence in the application code before invoking the DMA based APIs:

1. Initialize the MCU and clock using the `Mcu_Init` API.
2. Initialize the DMA driver using the `Dma_init` API.

## 1 CRC driver

3. Initialize the IRQ for dependent modules using the IrqDma\_Init API.

```
#if (CRC_DMA_MAX_CHANNELS > 0U)
extern const Mcu_ConfigType Mcu_Config;
extern const Dma_ConfigType Dma_Config;
#endif
void core0_main (void)
{
    /*your code */
    #if (CRC_DMA_MAX_CHANNELS > 0U)
    /*MCU initialization*/
    Mcu_Init(&Mcu_Config);
    Mcu_InitClock(0U);
    Mcu_DistributePllClock();
    /*IRQ initialization*/
    IrqDma_Init();
    /*DMA initialization*/
    Dma_Init(&Dma_Config);
    /*Enable the interrupt*/
    SRC_DMACH0.U |= 0x400U;
    #endif
    /*your code */
}
```

### 1.1.5 Key architectural considerations

#### 1.1.5.1 AUTOSAR modes of operation

Following polynomials shall support only Runtime and Table method since there is no support for equivalent CPU instruction:

- CRC32P4
- CRC64

CRC module supports Hardware, Table and Runtime mode for the following polynomial:

- CRC8
- CRC8H2F
- CRC16
- CRC16ARC
- CRC32

The mode of the above polynomials shall always use the hardware mode internally (CPU instruction). The above modes of operation simplifies the design and ensures the efficient use of hardware access.

#### 1.1.5.2 CPU CRCN instruction

The following polynomials use CPU instruction to calculate CRC:

- CRC8
- CRC8H2F
- CRC16

---

**1 CRC driver**

- CRC16ARC
- CRC32

CRC8, CRC8H2F, CRC16, and CRC16ARC use CRCN CPU instruction and CRC32 uses CRC32.B instruction for CRC calculation.

CPU instructions do not have support for CRC32P4 polynomial.

**1.1.5.3 DMA based operation**

FCE engine supports CRC calculation for following polynomials:

- CRC16
- CRC32
- CRC32P4

Each core is assigned with only one of the DMA channels which are linked to one of the FCE channels. DMA the channel is exploited to transfer data to the linked FCE channel's input register.

The user shall allocate for each core a unique DMA channel for the CRC module in DMA configuration and FCE channel in CRC configuration.

In DMA configuration apart from the allocation of DMA channels to the CRC module and the callback notifications (Crc\_DmaTransferIsr and Crc\_DmaErrorIsr), the rest of the DMA channel configurations are ignored. Callback notification to the CRC user is configured in the CRC configuration.

DMA based CRC APIs shall re-configure DMA channel settings during runtime based on the input parameters.

The DMA source address shall be the address of the passed data pointer, DMA destination address shall be the address of the linked FCE channel's IR register and the DMA transfer width shall be the width of the polynomial being calculated.

---

**1 CRC driver****1.2 Assumptions of Use (AoU)**

The AoU for the CRC driver are as follows:

- **Error value return**

When the safety switch is ON, if the result returned by the AUTOSAR API is the configured error value and no safety error is reported, then the result is valid.

[cover parentID CRC={6AADA8A0-78EB-4432-A6AD-4862A186D2AD}]

- **FCE register protection**

User shall not modify any FCE-related register.

[cover parentID CRC={68DA99F3-38B9-47b7-BF82-BC9F32BB485B}]

- **DMA initialization for using the DMA feature**

The user shall ensure that the DMA module is initialized before using the DMA based APIs.

[cover parentID CRC={2D019E9F-173A-4e28-A7AA-993138CCBB35}]

## 1 CRC driver

### 1.3 Reference information

#### 1.3.1 Configuration interfaces




Figure 14 Container hierarchy along with their configuration parameters

##### 1.3.1.1 Container: Crc

Configuration of the CRC driver.

Post-Build Variant Multiplicity: -

Multiplicity Configuration Class: -

##### 1.3.1.2 Container: CrcGeneral

General configuration of the CRC driver

Post-Build Variant Multiplicity: -

Multiplicity Configuration Class: -

## 1 CRC driver

### 1.3.1.2.1 Crc16ARCMODE

**Table 4 Specification for Crc16ARCMODE**

<b>Name</b>	Crc16ARCMODE		
<b>Description</b>	Switch to select one of the available CRC 16-bit (0x8005h) calculation methods.		
<b>Multiplicity</b>	0..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_16_ARC_HARDWARE: Hardware based CRC16ARC calculation. CRC_16_ARC_RUNTIME: Runtime based CRC16ARC calculation. CRC_16_ARC_TABLE: Table based CRC16ARC calculation.		
<b>Default value</b>	CRC_16_ARC_HARDWARE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	FALSE
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	IFX FOR AS4.2.2 VARIANT AND AUTOSAR_ECUC FOR AS4.4.0 VARIANT	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.2 Crc16ARCReturnErrorValue

**Table 5 Specification for Crc16ARCReturnErrorValue**

<b>Name</b>	Crc16ARCReturnErrorValue		
<b>Description</b>	The error value to be returned by the AUTOSAR API Crc_Calculate16ARC for the polynomial CRC16ARC instead of CRC value if safety check is enabled and in case of an incorrect input parameter. The default value of the parameter is the minimum value.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 65535		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	CrcSafetyEnable		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

## 1 CRC driver

### 1.3.1.2.3 Crc16Mode

**Table 6 Specification for Crc16Mode**

<b>Name</b>	Crc16Mode		
<b>Description</b>	Switch to select one of the available CRC 16-bit (CCITT) calculation methods.		
<b>Multiplicity</b>	0..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_16_HARDWARE: Hardware based CRC16 calculation. CRC_16_RUNTIME: Runtime based CRC16 calculation. CRC_16_TABLE: Table based CRC16 calculation.		
<b>Default value</b>	CRC_16_HARDWARE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	FALSE
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	AUTOSAR_ECUC	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.4 Crc16ReturnErrorValue

**Table 7 Specification for Crc16ReturnErrorValue**

<b>Name</b>	Crc16ReturnErrorValue		
<b>Description</b>	The error value to be returned by the AUTOSAR API Crc_CalculateCRC16 for the polynomial CRC16 instead of CRC value if safety check is enabled and in case of an incorrect input parameter. The default value of the parameter is the minimum value.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 65535		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	CrcSafetyEnable		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		



## 1 CRC driver

### 1.3.1.2.5 Crc32Mode

**Table 8 Specification for Crc32Mode**

<b>Name</b>	Crc32Mode		
<b>Description</b>	Switch to select one of the available CRC 32-bit (IEEE-802.3 CRC32 ethernet standard) calculation methods.		
<b>Multiplicity</b>	0..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_32_HARDWARE: Hardware based CRC32 calculation. CRC_32_RUNTIME: Runtime based CRC32 calculation. CRC_32_TABLE: Table based CRC32 calculation.		
<b>Default value</b>	CRC_32_HARDWARE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	FALSE
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	AUTOSAR_ECUC	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.6 Crc32P4Mode

**Table 9 Specification for Crc32P4Mode**

<b>Name</b>	Crc32P4Mode		
<b>Description</b>	Switch to select one of the available CRC 32-bit E2E profile 4 calculation methods. <i>Note: CRC32P4 does not provide support for hardware mode (CRC_32P4_HARDWARE) in the configuration parameter. CRC for CRC32P4 in hardware mode is supported through DMA bases CRC API.</i>		
<b>Multiplicity</b>	0..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_32P4_RUNTIME: Runtime based CRC32P4 calculation. CRC_32P4_TABLE: Table based CRC32P4 calculation.		
<b>Default value</b>	CRC_32P4_TABLE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	FALSE
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	AUTOSAR_ECUC	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		

## 1 CRC driver

**Table 9 Specification for Crc32P4Mode (continued)**

<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.
------------------------	--

### 1.3.1.2.7 Crc32P4ReturnErrorValue

**Table 10 Specification for Crc32P4ReturnErrorValue**

<b>Name</b>	Crc32P4ReturnErrorValue		
<b>Description</b>	The error value to be returned by the AUTOSAR API Crc_CalculateCRC32P4 for the polynomial CRC32P4 instead of CRC value if safety check is enabled and in case of an incorrect input parameter. The default value of the parameter is the minimum value.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 4294967295		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	CrcSafetyEnable		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.8 Crc32ReturnErrorValue

**Table 11 Specification for Crc32ReturnErrorValue**

<b>Name</b>	Crc32ReturnErrorValue		
<b>Description</b>	The error value to be returned by the AUTOSAR API Crc_CalculateCRC32 for the polynomial CRC32 instead of CRC value if safety check is enabled and in case of an incorrect input parameter. The default value of the parameter is the minimum value.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 4294967295		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	CrcSafetyEnable		

## 1 CRC driver

**Table 11 Specification for Crc32ReturnErrorValue (continued)**

<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.
------------------------	--

### 1.3.1.2.9 Crc64Mode

**Table 12 Specification for Crc64Mode**

<b>Name</b>	Crc64Mode		
<b>Description</b>	Switch to select one of the available CRC 64-bit calculation methods. <i>Note: CRC64 does not support CRC calculation in the hardware mode (CRC_64_HARDWARE) as the current FCE engine does not provide the kernel for CRC64.</i>		
<b>Multiplicity</b>	0..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_64_RUNTIME: Runtime based CRC64 calculation. CRC_64_TABLE: Table based CRC64 calculation.		
<b>Default value</b>	CRC_64_TABLE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	FALSE
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	IFX FOR AS4.2.2 VARIANT AND AUTOSAR_ECUC FOR AS4.4.0 VARIANT	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.10 Crc64ReturnErrorValue

**Table 13 Specification for Crc64ReturnErrorValue**

<b>Name</b>	Crc64ReturnErrorValue		
<b>Description</b>	The error value to be returned by the AUTOSAR API Crc_CalculateCRC64 for the polynomial CRC64 instead of CRC value if safety check is enabled and in case of an incorrect input parameter. The default value of the parameter is the minimum value.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 9223372036854775807		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-

## 1 CRC driver

**Table 13 Specification for Crc64ReturnErrorValue (continued)**

<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	CrcSafetyEnable		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.11 Crc8H2FMode

**Table 14 Specification for Crc8H2FMode**

<b>Name</b>	Crc8H2FMode		
<b>Description</b>	Switch to select one of the available CRC 8-bit (2Fh polynomial) calculation methods.		
<b>Multiplicity</b>	0..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_8H2F_HARDWARE: Hardware based CRC8H2F calculation. CRC_8H2F_RUNTIME: Runtime based CRC8H2F calculation. CRC_8H2F_TABLE: Table based CRC8H2F calculation.		
<b>Default value</b>	CRC_8H2F_HARDWARE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	FALSE
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	AUTOSAR_ECUC	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.12 Crc8H2FReturnErrorValue

**Table 15 Specification for Crc8H2FReturnErrorValue**

<b>Name</b>	Crc8H2FReturnErrorValue		
<b>Description</b>	The error value to be returned by the AUTOSAR API Crc_CalculateCRC8H2F for the polynomial CRC8H2F instead of CRC value if safety check is enabled and in case of an incorrect input parameter. The default value of the parameter is the minimum value.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-

## 1 CRC driver

**Table 15 Specification for Crc8H2FReturnErrorValue (continued)**

<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	CrcSafetyEnable		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.13 Crc8Mode

**Table 16 Specification for Crc8Mode**

<b>Name</b>	Crc8Mode		
<b>Description</b>	Switch to select one of the available CRC 8-bit (SAE J1850) calculation methods.		
<b>Multiplicity</b>	0..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_8_HARDWARE: Hardware based CRC8 calculation. CRC_8_RUNTIME: Runtime based CRC8 calculation. CRC_8_TABLE: Table based CRC8 calculation.		
<b>Default value</b>	CRC_8_HARDWARE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	FALSE
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	AUTOSAR_ECUC	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.14 Crc8ReturnErrorValue

**Table 17 Specification for Crc8ReturnErrorValue**

<b>Name</b>	Crc8ReturnErrorValue		
<b>Description</b>	The error value to be returned by the AUTOSAR API Crc_CalculateCRC8 for polynomial the CRC8 instead of CRC value if safety check is enabled and in case of an incorrect input parameter. The default value of the parameter is the minimum value.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-

## 1 CRC driver

**Table 17 Specification for Crc8ReturnErrorValue (continued)**

<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	CrcSafetyEnable		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.15 CrcDma16bitApi

**Table 18 Specification for CrcDma16bitApi**

<b>Name</b>	CrcDma16bitApi		
<b>Description</b>	Pre-processor switch to enable / disable CrcDma16bitApi for the polynomial CRC16. True: Crc_DmaCalculateCRC16 API enable. False: Crc_DmaCalculateCRC16 API disable. The optional APIs are disabled by default to minimize the executable code size.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucBooleanParamDef
<b>Range</b>	TRUE FALSE		
<b>Default value</b>	FALSE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.16 CrcDma32P4bitApi

**Table 19 Specification for CrcDma32P4bitApi**

<b>Name</b>	CrcDma32P4bitApi		
<b>Description</b>	Pre-processor switch to enable / disable CrcDma32P4bitApi for the polynomial CRC32P4. True: Crc_DmaCalculateCRC32P4 API enable. False: Crc_DmaCalculateCRC32P4 API disable. The optional APIs are disabled by default to minimize the executable code size.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucBooleanParamDef

## 1 CRC driver

**Table 19 Specification for CrcDma32P4bitApi (continued)**

<b>Range</b>	TRUE FALSE		
<b>Default value</b>	FALSE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.17 CrcDma32bitApi

**Table 20 Specification for CrcDma32bitApi**

<b>Name</b>	CrcDma32bitApi		
<b>Description</b>	Pre-processor switch to enable / disable CrcDma32bitApi for the polynomial CRC32. True: Crc_DmaCalculateCRC32 API enable. False: Crc_DmaCalculateCRC32 API disable. The optional APIs are disabled by default to minimize the executable code size.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucBooleanParamDef
<b>Range</b>	TRUE FALSE		
<b>Default value</b>	FALSE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.18 CrcDma8bitApi

**Table 21 Specification for CrcDma8bitApi**

<b>Name</b>	CrcDma8bitApi
-------------	---------------

**1 CRC driver**
**Table 21 Specification for CrcDma8bitApi (continued)**

<b>Description</b>	Pre-processor switch to enable / disable CrcDma8bitApi for the polynomial CRC8. True: Crc_DmaCalculateCRC8 API enable. False: Crc_DmaCalculateCRC8 API disable. The optional APIs are disabled by default to minimize the executable code size.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucBooleanParamDef
<b>Range</b>	TRUE FALSE		
<b>Default value</b>	FALSE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

**1.3.1.2.19 CrcRuntimeApiMode**
**Table 22 Specification for CrcRuntimeApiMode**

<b>Name</b>	CrcRuntimeApiMode		
<b>Description</b>	This configuration parameter gives the mode in which the runtime APIs of the CRC driver will be used. Since the CRC driver accesses the SFRs, it is more efficient to operate the CRC driver in supervisor mode. Hence, the default mode of operation is the supervisor mode.  <i>Note: CrcRuntimeApiMode will be available only when at least one of the DMA based APIs is enabled, otherwise the parameter is editable false.</i>		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucEnumerationParamDef
<b>Range</b>	CRC_MCAL_SUPERVISOR: Operating mode used is Supervisor. CRC_MCAL_USER1: Operating mode used is USER1.		
<b>Default value</b>	MCAL_SUPERVISOR		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		



## 1 CRC driver

**Table 22 Specification for CrcRuntimeApiMode (continued)**

<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.
------------------------	--

### 1.3.1.2.20 CrcSafetyEnable

**Table 23 Specification for CrcSafetyEnable**

<b>Name</b>	CrcSafetyEnable		
<b>Description</b>	Switch to enable/disable the safety check and reporting. TRUE: enables safety check and reporting FALSE: disables safety check and reporting The detection of safety related errors is enabled by default to ensure that safety issues are addressed during the product lifecycle.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucBooleanParamDef
<b>Range</b>	TRUE FALSE		
<b>Default value</b>	TRUE		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.2.21 CrcVersionInfoApi

**Table 24 Specification for CrcVersionInfoApi**

<b>Name</b>	CrcVersionInfoApi		
<b>Description</b>	Pre-processor switch to enable / disable the API to read out the driver version information. True: Version info API enabled. False: Version info API disabled. The optional APIs are disabled by default to minimize the executable code size.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucBooleanParamDef
<b>Range</b>	TRUE FALSE		
<b>Default value</b>	FALSE		

## 1 CRC driver

**Table 24 Specification for CrcVersionInfoApi (continued)**

<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.3 Container: CrcPublishedInformation

Post-Build Variant Multiplicity: -

Multiplicity Configuration Class: -

#### 1.3.1.3.1 CrcInitialValue16

**Table 25 Specification for CrcInitialValue16**

<b>Name</b>	CrcInitialValue16		
<b>Description</b>	Initial Value for this CRC calculation as specified by Autosar.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	65535 - 65535		
<b>Default value</b>	65535		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

#### 1.3.1.3.2 CrcInitialValue16ARC

**Table 26 Specification for CrcInitialValue16ARC**

<b>Name</b>	CrcInitialValue16ARC		
<b>Description</b>	Initial Value for this CRC calculation as specified by Autosar.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 0		

## 1 CRC driver

**Table 26 Specification for CrcInitialValue16ARC (continued)**

<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.3.3 CrcInitialValue32

**Table 27 Specification for CrcInitialValue32**

<b>Name</b>	CrcInitialValue32		
<b>Description</b>	Initial Value for this CRC calculation as specified by Autosar.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	4294967295 - 4294967295		
<b>Default value</b>	4294967295		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.3.4 CrcInitialValue32P4

**Table 28 Specification for CrcInitialValue32P4**

<b>Name</b>	CrcInitialValue32P4		
<b>Description</b>	Initial Value for this CRC calculation as specified by Autosar.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	4294967295 - 4294967295		
<b>Default value</b>	4294967295		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-

## 1 CRC driver

**Table 28 Specification for CrcInitialValue32P4 (continued)**

<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.3.5 CrcInitialValue64

**Table 29 Specification for CrcInitialValue64**

<b>Name</b>	CrcInitialValue64		
<b>Description</b>	Initial Value for this CRC calculation as specified by Autosar.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	18446744073709551615 - 18446744073709551615		
<b>Default value</b>	18446744073709551615		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.3.6 CrcInitialValue8

**Table 30 Specification for CrcInitialValue8**

<b>Name</b>	CrcInitialValue8		
<b>Description</b>	Initial Value for this CRC calculation as specified by Autosar.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	255 - 255		
<b>Default value</b>	255		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL

## 1 CRC driver

**Table 30 Specification for CrcInitialValue8 (continued)**

<b>Dependency</b>	-
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.1.3.7 CrcInitialValue8H2F

**Table 31 Specification for CrcInitialValue8H2F**

<b>Name</b>	CrcInitialValue8H2F		
<b>Description</b>	Initial Value for this CRC calculation as specified by Autosar.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	255 - 255		
<b>Default value</b>	255		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.4 Container: CommonPublishedInformation

Post-Build Variant Multiplicity: -

Multiplicity Configuration Class: -

#### 1.3.1.4.1 ARPatchVersion

**Table 32 Specification for ARPatchVersion**

<b>Name</b>	ARPatchVersion		
<b>Description</b>	Patch version number of the AUTOSAR specification.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	As per the AUTOSAR version		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-

## 1 CRC driver

**Table 32 Specification for ARPatchVersion (continued)**

<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.4.2 ArMajorVersion

**Table 33 Specification for ArMajorVersion**

<b>Name</b>	ArMajorVersion		
<b>Description</b>	Major version number of the AUTOSAR specification.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	As per the AUTOSAR version		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.4.3 ArMinorVersion

**Table 34 Specification for ArMinorVersion**

<b>Name</b>	ArMinorVersion		
<b>Description</b>	Minor version number of the AUTOSAR specification.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	As per the AUTOSAR version		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

## 1 CRC driver

### 1.3.1.4.4 ModuleId

**Table 35 Specification for ModuleId**

<b>Name</b>	ModuleId		
<b>Description</b>	This macro gives the Crc driver module ID as described by AUTOSAR.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 65535		
<b>Default value</b>	201 (0xC9)		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.4.5 SwMajorVersion

**Table 36 Specification for SwMajorVersion**

<b>Name</b>	SwMajorVersion		
<b>Description</b>	Major version number of the driver.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	As per driver version		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.4.6 SwMinorVersion

**Table 37 Specification for SwMinorVersion**

<b>Name</b>	SwMinorVersion		
<b>Description</b>	Minor version number of the driver.		

## 1 CRC driver

**Table 37 Specification for SwMinorVersion (continued)**

<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	As per driver version		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.4.7 SwPatchVersion

**Table 38 Specification for SwPatchVersion**

<b>Name</b>	SwPatchVersion		
<b>Description</b>	Patch level version number of the driver. The patch version is incremented if the driver is still upwards and downwards compatible (for example, bug fix).		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 255		
<b>Default value</b>	As per driver version		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.4.8 VendorId

**Table 39 Specification for VendorId**

<b>Name</b>	VendorId		
<b>Description</b>	Vendor ID of Infineon Technologies.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 65535		
<b>Default value</b>	17		



## 1 CRC driver

**Table 39 Specification for VendorId (continued)**

<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Published-Information	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.5 Container: CrcChannelConfig

This container has the FCE channel configuration.

Lower multiplicity is 0 and upper multiplicity depends on the number of cores available.

*Note 1: The CrcChannelConfig container is available for update only when at least one of the DMA based APIs is enabled, otherwise the container is editable false.*

*Note 2: When the DMA based API is enabled and none of the channel is configured in the container, code gen error will be generated.*

Post-Build Variant Multiplicity: -

Multiplicity Configuration Class: -

#### 1.3.1.5.1 CrcChannelId

**Table 40 Specification for CrcChannelId**

<b>Name</b>	CrcChannelId		
<b>Description</b>	Select one of the available FCE channels.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucIntegerParamDef
<b>Range</b>	0 - 7		
<b>Default value</b>	0		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

## 1 CRC driver

### 1.3.1.5.2 CrcDmaChannel

**Table 41 Specification for CrcDmaChannel**

<b>Name</b>	CrcDmaChannel		
<b>Description</b>	Select the DMA resource allocated to the CRC module in the DMA configuration.		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucReferenceDef
<b>Range</b>	Reference to Node: DmaChannelConfig		
<b>Default value</b>	NULL		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	Pre-Compile
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.5.3 CrcErrorNotification

**Table 42 Specification for CrcErrorNotification**

<b>Name</b>	CrcErrorNotification		
<b>Description</b>	<p>The CrcErrorNotification is used by the CRC driver to invoke user-defined function for error notification purpose. The parameter can be a name or the address (numeric value) of the notification function.</p> <p>Pointer to notification function should be of the type:</p> <pre>void Function_Name ( void )</pre> <p><i>Note1: By default, the notification parameter will be NULL.</i></p> <p><i>Note2: The CRC driver does not validate the configured function name or address for correctness and the responsibility falls on the user.</i></p>		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucFunctionNameDef
<b>Range</b>	String		
<b>Default value</b>	NULL_PTR		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-

## 1 CRC driver

**Table 42 Specification for CrcErrorNotification (continued)**

<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.1.5.4 CrcResultNotification

**Table 43 Specification for CrcResultNotification**

<b>Name</b>	CrcResultNotification		
<b>Description</b>	<p>The CrcResultNotification is used by the CRC driver to invoke the user-defined function for result notification purpose. The parameter can be a name or the address (numeric value) of the notification function.</p> <p>Pointer to notification function should be of the type:</p> <pre>void Function_Name ( uint32 CrcResult )</pre> <p><i>Note1: By default, the notification parameter will be NULL.</i></p> <p><i>Note2: The CRC driver does not validate the configured function name or address for the correctness and the responsibility falls on the user.</i></p> <p><i>Note3: For 8-bit and 16-bit CRC calculation, only LSB should be read from the result passed as a parameter in the user defined notification function (value in rest of the bits are undefined).</i></p>		
<b>Multiplicity</b>	1..1	<b>Type</b>	EcucFunctionNameDef
<b>Range</b>	String		
<b>Default value</b>	NULL_PTR		
<b>Post-build variant value</b>	FALSE	<b>Post-build variant multiplicity</b>	-
<b>Value configuration class</b>	Pre-Compile	<b>Multiplicity configuration class</b>	-
<b>Origin</b>	IFX	<b>Scope</b>	LOCAL
<b>Dependency</b>	-		
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.		

### 1.3.2 Functions - Type definitions

This section lists all the data type of the CRC driver.

## 1 CRC driver

### 1.3.2.1 Crc\_ChannelConfigType

**Table 44 Specification for Crc\_ChannelConfigType**

<b>Syntax</b>	Crc_ChannelConfigType	
<b>Type</b>	Structure	
<b>File</b>	Crc.h	
<b>Range</b>	uint8 Dma_Channel	DMA channel number in the range[0-127].
	Crc_ErrNotificationPtrType ErrNotificationPtr	Holds the address of the error notification callback function configured by the user.
	uint8 Fce_Channel	FCE channel number in the range[0-7].
	Crc_ResNotificationPtrType ResNotificationPtr	Holds the address of the Result notification callback function configured by the user.
<b>Description</b>	This structure holds the configuration of the FCE resources allocated in CRC configuration.	
<b>Source</b>	IFX	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

### 1.3.2.2 Crc\_DmaReturnType

**Table 45 Specification for Crc\_DmaReturnType**

<b>Syntax</b>	Crc_DmaReturnType	
<b>Type</b>	Enumeration	
<b>File</b>	Crc.h	
<b>Range</b>	0x01 - CRC_CHANNEL_BUSY	Return value from the DMA based APIs if the DMA channel assigned to the executing core is busy.
	0x02 - CRC_INVALID_ADDRESS	Return value from the DMA based APIs if the data pointer does not align to 16-bit address or 32-bit address while calculation CRC for 16-bit or 32-bit respectively.
	0x03 - CRC_INVALID_LENGTH	Return value from the DMA based APIs in the following cases: a. If the length of the input data is zero. b. If the 8-bit, 16-bit or 32-bit aligned input data length exceeds 16383. c. If the input data stream is not aligned to the 16-bit word boundary or 32-bit word boundary while calculating CRC for 16-bit and 32-bit respectively.

## 1 CRC driver

**Table 45 Specification for Crc\_DmaReturnType (continued)**

	0x04 - CRC_INVALID_POINTER	Return value from the DMA based APIs if the data pointer is NULL.
	0x00 - CRC_OK	Return value from the DMA based APIs if all the checks are successful.
	0x05 - CRC_INVALID_CORE	Return value from the DMA based APIs when none of the FCE or the DMA channel (only channels allocated to the CRC module in the DMA configuration) is assigned to the current executing core. <i>Note: The Crc_ChannelConfig structure would be NULL for such core.</i>
<b>Description</b>	Enumeration to hold the return values from DMA APIs.	
<b>Source</b>	IFX	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

### 1.3.2.3 Crc\_ErrNotificationPtrType

**Table 46 Specification for Crc\_ErrNotificationPtrType**

<b>Syntax</b>	Crc_ErrNotificationPtrType
<b>Type</b>	Pointer to a function of type void Function_Name ( void )
<b>File</b>	Crc.h
<b>Description</b>	This function pointer holds the function configured by the user in CRC module, which needs to be invoked if there an error event from the move engine.
<b>Source</b>	IFX
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.2.4 Crc\_ResNotificationPtrType

**Table 47 Specification for Crc\_ResNotificationPtrType**

<b>Syntax</b>	Crc_ResNotificationPtrType
<b>Type</b>	Pointer to a function of type void Function_Name ( const uint32 CrcResult )
<b>File</b>	Crc.h
<b>Description</b>	This function pointer type would hold the address of the function configured by the user in CRC module, which has to be invoked when there is a successful completion of data by DMA channel.
<b>Source</b>	IFX
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

## 1 CRC driver

### 1.3.3 Functions - APIs

This section lists all the APIs of the CRC driver.

#### 1.3.3.1 Crc\_CalculateCRC8

**Table 48** Specification for Crc\_CalculateCRC8 API

<b>Syntax</b>	<pre>uint8 Crc_CalculateCRC8 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint8 Crc_StartValue8,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x01	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue8 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue8. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue8 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	uint8	8-bit result of CRC calculation
<b>Description</b>	This AUTOSAR API makes a CRC8 calculation on the number of data bytes specified by the API parameter Crc_Length with initial value as 0xFF. The API uses SAE J1850 polynomial for CRC calculation. This API supports both single-core and multi-core operations. Refer to the AUTOSAR SWS for further details.	
<b>Source</b>	AUTOSAR	
<b>Error handling</b>	CRC_E_PARAM_LENGTH, CRC_E_PARAM_POINTER	
<b>Configuration dependencies</b>	Crc8Mode	
<b>User hints</b>	-	
<b>SFR accessed</b>	-	

## 1 CRC driver

**Table 48 Specification for Crc\_CalculateCRC8 API (continued)**

<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.
------------------------	--

### 1.3.3.2 Crc\_CalculateCRC8H2F

**Table 49 Specification for Crc\_CalculateCRC8H2F API**

<b>Syntax</b>	<pre>uint8 Crc_CalculateCRC8H2F (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint8 Crc_StartValue8H2F,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x05	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue8H2F Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue8H2F. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue8H2F is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	uint8	8-bit result of CRC calculation
<b>Description</b>	This AUTOSAR API makes a CRC8 calculation on the number of data bytes specified by the API parameter Crc_Length with initial value as 0xFF. The API uses 0x2F polynomial for CRC calculation. This API supports both single-core and multi-core operations. Refer to the AUTOSAR SWS for further details.	
<b>Source</b>	AUTOSAR	
<b>Error handling</b>	CRC_E_PARAM_LENGTH, CRC_E_PARAM_POINTER	
<b>Configuration dependencies</b>	Crc8H2FMode	
<b>User hints</b>	-	

## 1 CRC driver

**Table 49 Specification for Crc\_CalculateCRC8H2F API (continued)**

<b>SFR accessed</b>	-
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.3.3 Crc\_CalculateCRC16

**Table 50 Specification for Crc\_CalculateCRC16 API**

<b>Syntax</b>	<pre>uint16 Crc_CalculateCRC16 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint16 Crc_StartValue16,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x02	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue16 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue16. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue16 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	uint16	16-bit result of CRC calculation
<b>Description</b>	This AUTOSAR API makes a CRC16 calculation on the number of data bytes specified by the API parameter Crc_Length with initial value as 0xFFFF. The API uses CCITT-FALSE CRC16 Standard for CRC calculation. This API supports both single-core and multi-core operations. Refer to the AUTOSAR SWS for further details.	
<b>Source</b>	AUTOSAR	
<b>Error handling</b>	CRC_E_PARAM_LENGTH, CRC_E_PARAM_POINTER	
<b>Configuration dependencies</b>	Crc16Mode	



## 1 CRC driver

**Table 50 Specification for Crc\_CalculateCRC16 API (continued)**

<b>User hints</b>	-
<b>SFR accessed</b>	-
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.3.4 Crc\_CalculateCRC16ARC

**Table 51 Specification for Crc\_CalculateCRC16ARC API**

<b>Syntax</b>	<pre>uint16 Crc_CalculateCRC16ARC (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint16 Crc_StartValue16,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x08	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue16 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore Crc_StartValue16. FALSE: Subsequent call in a call sequence. Crc_StartValue16 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	uint16	16-bit result of CRC calculation
<b>Description</b>	This AUTOSAR API makes a CRC16ARC calculation on the number of data bytes specified by the API parameter Crc_Length with initial value as 0x0000. It uses 0x8005 polynomial for CRC calculation. It supports both single-core and multi-core operations. Refer to the AUTOSAR SWS for further details.	
<b>Source</b>	IFX for AS4.2.2 variant and AUTOSAR for AS4.4.0 variant	
<b>Error handling</b>	CRC_E_PARAM_POINTER, CRC_E_PARAM_LENGTH	
<b>Configuration dependencies</b>	Crc16ARCMode	

## 1 CRC driver

**Table 51 Specification for Crc\_CalculateCRC16ARC API (continued)**

<b>User hints</b>	-
<b>SFR accessed</b>	-
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.3.5 Crc\_CalculateCRC32

**Table 52 Specification for Crc\_CalculateCRC32 API**

<b>Syntax</b>	<pre>uint32 Crc_CalculateCRC32 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint32 Crc_StartValue32,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x03	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue32 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue32. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue32 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	uint32	32-bit result of CRC calculation
<b>Description</b>	This AUTOSAR API makes a CRC32 calculation on the number of data bytes specified by the API parameter Crc_Length with initial value as 0xFFFFFFFF. The API uses IEEE-802.3 CRC32 Ethernet Standard for CRC calculation. This API supports both single-core and multi-core operations. Refer to the AUTOSAR SWS for further details.	
<b>Source</b>	AUTOSAR	
<b>Error handling</b>	CRC_E_PARAM_LENGTH, CRC_E_PARAM_POINTER	

## 1 CRC driver

**Table 52 Specification for Crc\_CalculateCRC32 API (continued)**

<b>Configuration dependencies</b>	Crc32Mode
<b>User hints</b>	-
<b>SFR accessed</b>	-
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.3.6 Crc\_CalculateCRC32P4

**Table 53 Specification for Crc\_CalculateCRC32P4 API**

<b>Syntax</b>	<pre>uint32 Crc_CalculateCRC32P4 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint32 Crc_StartValue32,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x06	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue32 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue32. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue32 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	uint32	32-bit result of CRC calculation
<b>Description</b>	This AUTOSAR API makes a CRC32P4 calculation on the number of data bytes specified by the API parameter Crc_Length with initial value as 0xFFFFFFFF. The API uses 0xF4ACFB13 polynomial for CRC calculation. This API supports both single-core and multi-core operations. Refer to the AUTOSAR SWS for further details.	
<b>Source</b>	AUTOSAR	

## 1 CRC driver

**Table 53 Specification for Crc\_CalculateCRC32P4 API (continued)**

<b>Error handling</b>	CRC_E_PARAM_LENGTH, CRC_E_PARAM_POINTER
<b>Configuration dependencies</b>	Crc32P4Mode
<b>User hints</b>	-
<b>SFR accessed</b>	-
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.3.7 Crc\_CalculateCRC64

**Table 54 Specification for Crc\_CalculateCRC64 API**

<b>Syntax</b>	<pre>uint64 Crc_CalculateCRC64 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint64 Crc_StartValue64,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x07	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue64 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore Crc_StartValue64. FALSE: Subsequent call in a call sequence. Crc_StartValue64 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	uint64	64 bit result of CRC calculation.
<b>Description</b>	This AUTOSAR API makes a CRC64 calculation on the number of data bytes specified by the API parameter Crc_Length with initial value as 0xFFFFFFFFFFFFFFFF. The API uses 0x42F0E1EBA9EA3693 polynomial for CRC calculation. This API supports both single-core and multi-core operations. Refer to the AUTOSAR SWS for further details.	
<b>Source</b>	IFX for AS4.2.2 variant and AUTOSAR for AS4.4.0 variant	

## 1 CRC driver

**Table 54 Specification for Crc\_CalculateCRC64 API (continued)**

<b>Error handling</b>	CRC_E_PARAM_POINTER, CRC_E_PARAM_LENGTH
<b>Configuration dependencies</b>	Crc64Mode
<b>User hints</b>	-
<b>SFR accessed</b>	-
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.3.8 Crc\_DmaCalculateCRC8

**Table 55 Specification for Crc\_DmaCalculateCRC8 API**

<b>Syntax</b>	<pre>Crc_DmaReturnType Crc_DmaCalculateCRC8 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint8 Crc_StartValue8,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x1A	
<b>Sync/Async</b>	Asynchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Non Reentrant for same channel	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue8 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue8. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue8 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	Crc_DmaReturnType	CRC_INVALID_CORE: If the current executing core is not allocated with any FCE and DMA channel (only channels allocated to the CRC module in the DMA configuration). CRC_INVALID_POINTER: If the data pointer is NULL CRC_INVALID_LENGTH: In case, a. If the length of the input data is zero. b. If the 8-bit aligned input data length exceeds 16383 bytes.

## 1 CRC driver

**Table 55 Specification for Crc\_DmaCalculateCRC8 API (continued)**

		CRC_CHANNEL_BUSY: If the channel is busy. CRC_OK: If all the checks are successful.
<b>Description</b>	This Non AUTOSAR API makes use of DMA and FCE hardware to calculate CRC8 on the number of data bytes specified by the Crc_Length. The calculation is done asynchronously and the value is provided by the callback function from the CRC module to the user. It uses 0x2F polynomial for CRC calculation. It supports both single-core and multi-core operations.	
<b>Source</b>	IFX	
<b>Error handling</b>	-	
<b>Configuration dependencies</b>	CrcDma8bitApi	
<b>User hints</b>	-	
<b>SFR accessed</b>	CPU_CORE_ID(r), DMA_CH_ADICR(rw), DMA_CH_CHCFGR(w), DMA_CH_CHCSR(w), DMA_CH_DADR(w), DMA_CH_RDCRCR(w), DMA_CH_SADR(w), DMA_CH_SDCRCR(w), DMA_CH_SHADR(rw), DMA_TSR(r), FCE_CLC(w), FCE_IN_CFG(w), FCE_IN_CRC(w), FCE_IN_IR(w) <i>Note : The list includes all the SFRs accessed in the context of the API. It lists the SFRs accessed by the driver and called interfaces from other drivers. During runtime, the SFRs accessed from this list may vary based on configuration and execution context.</i>	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

### 1.3.3.9 Crc\_DmaCalculateCRC16

**Table 56 Specification for Crc\_DmaCalculateCRC16 API**

<b>Syntax</b>	<pre> Crc_DmaReturnType Crc_DmaCalculateCRC16 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint16 Crc_StartValue16,     const boolean Crc_IsFirstCall )           </pre>	
<b>Service ID</b>	0x1B	
<b>Sync/Async</b>	Asynchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Non Reentrant for same channel	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue16 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue16.

**1 CRC driver**
**Table 56 Specification for Crc\_DmaCalculateCRC16 API (continued)**

		FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue16 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	Crc_DmaReturnType	<p>CRC_INVALID_CORE: If the current executing core is not allocated with any FCE and DMA channel (only channels allocated to the CRC module in the DMA configuration).</p> <p>CRC_INVALID_POINTER: If the data pointer is NULL.</p> <p>CRC_INVALID_LENGTH: In case,</p> <ol style="list-style-type: none"> <li>If the length of the input data is zero.</li> <li>If the 16-bit aligned input data length exceeds 16383 half words (1 half word = 2bytes).</li> <li>If the input data stream is not aligned to 16-bit word boundary.</li> </ol> <p>CRC_INVALID_ADDRESS: If the address of the data pointer does not align to 16-bit address boundary.</p> <p>CRC_CHANNEL_BUSY: If the channel is busy.</p> <p>CRC_OK: If all the checks are done successful.</p>
<b>Description</b>	<p>This Non AUTOSAR API makes use of DMA and FCE hardware to calculate CRC16 on the number of data bytes specified by the Crc_Length. The calculation is done asynchronously and the value is provided by the callback function from the CRC module to the user.</p> <p>It uses CCITT-FALSE CRC16 Standard polynomial CRC calculation.</p> <p>It supports both single-core and multi-core operations.</p>	
<b>Source</b>	IFX	
<b>Error handling</b>	-	
<b>Configuration dependencies</b>	CrcDma16bitApi	
<b>User hints</b>	-	
<b>SFR accessed</b>	<p>CPU_CORE_ID(r), DMA_CH_ADICR(rw), DMA_CH_CHCFGR(w), DMA_CH_CHCSR(w), DMA_CH_DADR(w), DMA_CH_RDCRCR(w), DMA_CH_SADR(w), DMA_CH_SDCRCR(w), DMA_CH_SHADR(rw), DMA_TSR(r), FCE_CLC(w), FCE_IN_CFG(w), FCE_IN_CRC(w), FCE_IN_IR(w)</p> <p><i>Note : The list includes all the SFRs accessed in the context of the API. It lists the SFRs accessed by the driver and called interfaces from other drivers. During runtime, the SFRs accessed from this list may vary based on configuration and execution context.</i></p>	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

## 1 CRC driver

### 1.3.3.10 Crc\_DmaCalculateCRC32

**Table 57 Specification for Crc\_DmaCalculateCRC32 API**

<b>Syntax</b>	<pre> Crc_DmaReturnType Crc_DmaCalculateCRC32 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint32 Crc_StartValue32,     const boolean Crc_IsFirstCall ) </pre>	
<b>Service ID</b>	0x1C	
<b>Sync/Async</b>	Asynchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Non Reentrant for same channel	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue32 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue32. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue32 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	Crc_DmaReturnType	CRC_INVALID_CORE: If the current executing core is not allocated with any FCE and DMA channel (only channels allocated to the CRC module in the DMA configuration). CRC_INVALID_POINTER: If the data pointer is NULL. CRC_INVALID_LENGTH: In case, a. If the length of the input data is zero. b. If the 32-bit aligned input data length exceeds 16383 words(1 word = 4 bytes). c. If the input data stream is not aligned to 32-bit word boundary. CRC_INVALID_ADDRESS: If the address of the data pointer does not align to 32-bit address boundary. CRC_CHANNEL_BUSY: If the channel is busy. CRC_OK: If all the checks are successful.
<b>Description</b>	This Non AUTOSAR API makes use of DMA and FCE hardware to calculate CRC32 on the number of data bytes specified by the Crc_Length. The calculation is done asynchronously and the value is provided by the callback function from the CRC module to the user. It uses IEEE-802.3 CRC32 Ethernet Standard for CRC calculation. It supports both single-core and multi-core operations.	



## 1 CRC driver

**Table 57 Specification for Crc\_DmaCalculateCRC32 API (continued)**

<b>Source</b>	IFX
<b>Error handling</b>	-
<b>Configuration dependencies</b>	CrcDma32bitApi
<b>User hints</b>	-
<b>SFR accessed</b>	CPU_CORE_ID(r), DMA_CH_ADICR(rw), DMA_CH_CHCFGR(w), DMA_CH_CHCSR(w), DMA_CH_DADR(w), DMA_CH_RDCRCR(w), DMA_CH_SADR(w), DMA_CH_SDCRCR(w), DMA_CH_SHADR(rw), DMA_TSR(r), FCE_CLC(w), FCE_IN_CFG(w), FCE_IN_CRC(w), FCE_IN_IR(w)  <i>Note : The list includes all the SFRs accessed in the context of the API. It lists the SFRs accessed by the driver and called interfaces from other drivers. During runtime, the SFRs accessed from this list may vary based on configuration and execution context.</i>
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.

### 1.3.3.11 Crc\_DmaCalculateCRC32P4

**Table 58 Specification for Crc\_DmaCalculateCRC32P4 API**

<b>Syntax</b>	<pre>Crc_DmaReturnType Crc_DmaCalculateCRC32P4 (     const uint8 * const Crc_DataPtr,     const uint32 Crc_Length,     const uint32 Crc_StartValue32,     const boolean Crc_IsFirstCall )</pre>	
<b>Service ID</b>	0x1D	
<b>Sync/Async</b>	Asynchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Non Reentrant for same channel	
<b>Parameters (in)</b>	Crc_DataPtr Crc_Length Crc_StartValue32 Crc_IsFirstCall	Pointer to start address of data block to be calculated. Length of data block to be calculated in bytes. Start value when the algorithm starts. TRUE: First call in a sequence or individual CRC calculation. Start from initial value, ignore the parameter Crc_StartValue32. FALSE: Subsequent call in a call sequence. The parameter Crc_StartValue32 is interpreted to be the return value of the previous function call.
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-

**1 CRC driver**
**Table 58 Specification for Crc\_DmaCalculateCRC32P4 API (continued)**

<b>Return</b>	Crc_DmaReturnType	<p>CRC_INVALID_CORE: If the current executing core is not allocated with any FCE and DMA channel (only channels allocated to the CRC module in the DMA configuration).</p> <p>CRC_INVALID_POINTER: If the data pointer is NULL.</p> <p>CRC_INVALID_LENGTH: In case,</p> <ul style="list-style-type: none"> <li>a. If the length of the input data is zero.</li> <li>b. If the 32-bit aligned input data length exceeds 16383 words(1 word = 4 bytes).</li> <li>c. If the input data stream is not aligned to 32-bit word boundary.</li> </ul> <p>CRC_INVALID_ADDRESS: If the address of the data pointer does not align to 32-bit address boundary.</p> <p>CRC_CHANNEL_BUSY: If the channel is busy.</p> <p>CRC_OK: If all the checks are successful.</p>
<b>Description</b>	<p>This Non AUTOSAR API makes use of DMA and FCE hardware to calculate CRC32P4 on the number of data bytes specified by the Crc_Length. The calculation is done asynchronously and the value is provided by the callback function from the CRC module to the user.</p> <p>It uses 0xF4ACFB13 polynomial for CRC calculation.</p> <p>It supports both single-core and multi-core operations.</p>	
<b>Source</b>	IFX	
<b>Error handling</b>	-	
<b>Configuration dependencies</b>	CrcDma32P4bitApi	
<b>User hints</b>	-	
<b>SFR accessed</b>	<p>CPU_CORE_ID(r), DMA_CH_ADICR(rw), DMA_CH_CHCFGR(w), DMA_CH_CHCSR(w), DMA_CH_DADR(w), DMA_CH_RDCRCR(w), DMA_CH_SADR(w), DMA_CH_SDCRCR(w), DMA_CH_SHADR(rw), DMA_TSR(r), FCE_CLC(w), FCE_IN_CFG(w), FCE_IN_CRC(w), FCE_IN_IR(w)</p> <p><i>Note : The list includes all the SFRs accessed in the context of the API. It lists the SFRs accessed by the driver and called interfaces from other drivers. During runtime, the SFRs accessed from this list may vary based on configuration and execution context.</i></p>	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

**1.3.3.12 Crc\_GetVersionInfo**
**Table 59 Specification for Crc\_GetVersionInfo API**

<b>Syntax</b>	<pre>void Crc_GetVersionInfo (     Std_VersionInfoType * const Versioninfo )</pre>
<b>Service ID</b>	0x04

## 1 CRC driver

**Table 59 Specification for Crc\_GetVersionInfo API (continued)**

<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Reentrant	
<b>Parameters (in)</b>	-	-
<b>Parameters (out)</b>	Versioninfo	Pointer where the version information of this driver is stored.
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	void	-
<b>Description</b>	This service returns the version information of the CRC driver. This API supports both single core and multi core operations.	
<b>Source</b>	AUTOSAR	
<b>Error handling</b>	CRC_E_PARAM_POINTER	
<b>Configuration dependencies</b>	CrcVersionInfoApi	
<b>User hints</b>	-	
<b>SFR accessed</b>	-	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

### 1.3.4 Notifications and Callbacks

This section lists all the notification and callbacks of the CRC driver.

#### 1.3.4.1 Crc\_DmaErrorIsr

**Table 60 Specification for Crc\_DmaErrorIsr API**

<b>Syntax</b>	<pre>void Crc_DmaErrorIsr (     const uint8 Channel,     const uint32 Event )</pre>	
<b>Service ID</b>	0x1F	
<b>Sync/Async</b>	Synchronous	
<b>ASIL Level</b>	B	
<b>Re-entrancy</b>	Non Reentrant	
<b>Parameters (in)</b>	Channel Event	Channel number of DMA which completed the transfer Flags indicating the event which triggered the ISR

## 1 CRC driver

**Table 60 Specification for Crc\_DmaErrorIsr API (continued)**

<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	void	-
<b>Description</b>	<p>This callback function is called from the DMA module on detecting a move engine error during DMA transfer.</p> <p>While configuring the function in the DMA Tresos configuration, the parameter can be the name or the address (numeric value) of the notification function.</p> <p><i>Note1: By default, the notification parameter will be NULL in the DMA Tresos configuration.</i></p> <p><i>Note2: The CRC driver does not validate the configured function name or address for the correctness and the responsibility falls on the user.</i></p> <p><i>Note3: User shall configure the callback function in the DMA configuration in the channel allocated to CRC to avoid codegen error.</i></p> <p><i>Note4: In the event of a DMA error, the associated DMA channel is stopped and deinitialized in the Crc_DmaErrorIsr ISR, by invoking the Dma_ChStopTransfer API.</i></p>	
<b>Source</b>	IFX	
<b>Error handling</b>	CRC_E_NOT_CONFIGURED	
<b>Configuration dependencies</b>	CrcChannelConfig	
<b>User hints</b>	-	
<b>SFR accessed</b>	CPU_CORE_ID(r), DMA_TSR(rw) <i>Note : The list includes all the SFRs accessed in the context of the API. It lists the SFRs accessed by the driver and called interfaces from other drivers. During runtime, the SFRs accessed from this list may vary based on configuration and execution context.</i>	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

### 1.3.4.2 Crc\_DmaTransferIsr

**Table 61 Specification for Crc\_DmaTransferIsr API**

<b>Syntax</b>	<pre>void Crc_DmaTransferIsr (     const uint8 Channel,     const uint32 Event )</pre>
<b>Service ID</b>	0x1E
<b>Sync/Async</b>	Synchronous
<b>ASIL Level</b>	B
<b>Re-entrancy</b>	Non Reentrant

## 1 CRC driver

**Table 61 Specification for Crc\_DmaTransferIsr API (continued)**

<b>Parameters (in)</b>	Channel Event	Channel number of DMA which completed the transfer Flags indicating the event which triggered the ISR
<b>Parameters (out)</b>	-	-
<b>Parameters (in - out)</b>	-	-
<b>Return</b>	void	-
<b>Description</b>	<p>This is the callback function invoked by the DMA at the end of the channel transmission. While configuring the function in the DMA Tresos configuration, the parameter can be the name or the address (numeric value) of the notification function.</p> <p><i>Note1: By default, the notification parameter will be NULL in the DMA Tresos configuration.</i></p> <p><i>Note2: The CRC driver does not validate the configured function name or address for the correctness and the responsibility falls on the user.</i></p> <p><i>Note3: User shall configure the callback function in the DMA configuration in the channel allocated to CRC to avoid codegen error.</i></p>	
<b>Source</b>	IFX	
<b>Error handling</b>	CRC_E_INVALID_ISR, CRC_E_NOT_CONFIGURED	
<b>Configuration dependencies</b>	CrcChannelConfig	
<b>User hints</b>	-	
<b>SFR accessed</b>	CPU_CORE_ID(r), FCE_IN_RES(r) <i>Note : The list includes all the SFRs accessed in the context of the API. It lists the SFRs accessed by the driver and called interfaces from other drivers. During runtime, the SFRs accessed from this list may vary based on configuration and execution context.</i>	
<b>Autosar Version</b>	Applicable for Autosar versions 4.2.2 and 4.4.0.	

### 1.3.5 Scheduled functions

The CRC module does not provide any scheduled functions.

### 1.3.6 Interrupt service routines

The CRC driver does not provide any interrupt handlers.

### 1.3.7 Callout

The CRC driver does not provide any callout.

### 1.3.8 Errors Handling

This section describes the various errors reported by the CRC driver.

## 1 CRC driver

AUTOSAR CRC library functions do not provide any error classification. CRC recalculation and comparison must be done by each module in the upper layer.

As per the safety measures added in CRC, any failure detected in the range check for the input parameters shall be reported to the upper layer as an error value.

Error Name: Description	Source	Error ID (AS422)	Type (AS422)	Error ID (AS440)	Type (AS440)
<b>CRC_E_INVALID_ISR:</b> Error ID for invalid event of the DMA channel. This is implemented as MCAL safety error.	IFX	0xCC	SAFETY	0xCC	SAFETY
<b>CRC_E_NOT_CONFIGURED:</b> Error ID for the invalid channel received in the ISR. This is implemented as MCAL safety error.	IFX	0xCB	SAFETY	0xCB	SAFETY
<b>CRC_E_PARAM_LENGTH:</b> Error ID for zero length check. This is implemented as MCAL safety error.	IFX	0xC9	SAFETY	0xC9	SAFETY
<b>CRC_E_PARAM_POINTER:</b> Error ID for NULLPTR check. This is implemented as MCAL safety error.	IFX	0xC8	SAFETY	0xC8	SAFETY

### 1.3.9 Deviations and limitations

The section describes the deviations and limitations of the CRC driver.

#### 1.3.9.1 Deviations

The section describes the deviations from software specification.

##### 1.3.9.1.1 Software specification deviations

This section describes the deviations from software specification.

**Table 62** known deviations

Reference	Deviations
Autosar SWS: Ecuc_Crc_00034	Crc64Mode for 64-bit CRC calculation can not be configured in the Hardware mode due to FCEhardware limitation.
Autosar SWS: Ecuc_Crc_00032	Crc32P4Mode for 32-bit CRC calculation can not be configured in the Hardware mode. The 32-bit CRC for the polynomial "0xF4ACFB13" in the hardware mode can be achieved by DMA based API by enabling CrcDma32P4bitApi in the Tresos.

---

**1 CRC driver****1.3.9.1.2 AMDC Violations**

The CRC driver does not have any AMDC violations.

**1.3.9.1.3 VSMD Violations**

The CRC driver does not have any VSMD violations.

**1.3.9.2 Limitations**

The section describes the limitations of the CRC driver.

**Table 63 Known limitations**

Reference	Limitation
Autosar SWS: Ecuc_Crc_00034	Hardware mode is not available for usage in CRC 64-bit computation using 0x42F0E1EBA9EA3693 polynomial due to hardware limitation. However, runtime and table methods are supported.
Crc_CalculateCRC64 API	While configuring the initial value for the API Crc_CalculateCRC64 in the Tresos, the Tresos generates warning due to its limitation to represent 64-bit data. The allowed range is [0-9223372036854775807].
Occurrence of safety error CRC_E_INVALID_ISR from Crc_DmaTransferIsr.	In the event of a DMA error, the Crc_DmaErrorIsr will stop and deinitialize the DMA channel being used. If the DMA channel transfer interrupt gets triggered before this channel gets stopped, the CRC_E_INVALID_ISR will get reported from Crc_DmaErrorIsr. This is expected as the DMA ME continues the transfer, inspite of the error, as documented in the DMA driver user manual (Reference: Known Limitations 'Multiple ME interrupts for source and destination errors').

---

**Revision history**

## Revision history

**Table 64**                      **Revision History**

Date	Version	Description
2021-03-04	3.0	- Released
2021-03-01	2.1	- Removed CRC64 polynomial limitation.
2020-11-30	2.0	- Released
2020-11-30	1.2	- Limitation section updated for CRC64 polynomial. - Crc_DmaCalculateCRC32, Crc_DmaCalculateCRC32P4 and Crc_DmaCalculateCRC16 API's return type description updated.
2020-10-13	1.1	- Section 1.1.4.5 updated for error handling and supervision. - Section 1.1.4.6 updated for ISR priority information. - Limitation section updated for safety error CRC_E_INVALID_ISR.
2020-08-14	1.0	- Released
2020-08-13	0.1	- Initial version. - Crc driver chapter moved from MCISAR_TC3xx_UM_Basic to this document. - Integration hint update for Multicore and Resource Manager for DMA resources. - DMA support updated for DMA channel allocation - Example usage updated for DMA based API. - Key architecture consideration updated. - Crc_DmaTransferIsr and Crc_DmaErrorIsr added in Notifications and Callbacks section. - Limitation and deviations updated.



## Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

**Edition 2021-03-04**

**Published by**

**Infineon Technologies AG**  
**81726 Munich, Germany**

**© 2021 Infineon Technologies AG**  
**All Rights Reserved.**

**Do you have a question about any aspect of this document?**

**Email:** [erratum@infineon.com](mailto:erratum@infineon.com)

**Document reference**  
**IFX-ocr1484806431059**

## IMPORTANT NOTICE

The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics ("Beschaffenhheitsgarantie").

With respect to any examples, hints or any typical values stated herein and/or any information regarding the application of the product, Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights of any third party.

In addition, any information given in this document is subject to customer's compliance with its obligations stated in this document and any applicable legal requirements, norms and standards concerning customer's products and any use of the product of Infineon Technologies in customer's applications.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

## WARNINGS

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.