



Elektrobit

# EB tresos<sup>®</sup> ECU Configuration Wizard documentation

product release 8.7.1





Elektrobit Automotive GmbH  
Am Wolfsmantel 46  
91058 Erlangen, Germany  
Phone: +49 9131 7701 0  
Fax: +49 9131 7701 6333  
Email: [info.automotive@elektrobit.com](mailto:info.automotive@elektrobit.com)

## Technical support

<https://www.elektrobit.com/support>

## Legal disclaimer

Confidential and proprietary information

ALL RIGHTS RESERVED. No part of this publication may be copied in any form, by photocopy, microfilm, retrieval system, or by any other means now known or hereafter invented without the prior written permission of Elektrobit Automotive GmbH.

All brand names, trademarks and registered trademarks are property of their rightful owners and are used only for description.

Copyright 2019, Elektrobit Automotive GmbH.

# Table of Contents

1. Overview of EB tresos ECU Configuration Wizard documentation .....	6
2. ECU Configuration Wizard release notes .....	7
2.1. Overview .....	7
2.2. Scope of the release .....	7
2.2.1. Configuration tool .....	7
2.2.2. AUTOSAR modules .....	7
2.2.3. EB (Elektrobit) modules .....	7
2.2.4. MCAL modules and EB tresos AutoCore OS .....	8
2.3. Module release notes .....	8
2.3.1. Configurators module release notes .....	8
2.3.1.1. Change log .....	8
2.3.1.2. New features .....	34
2.3.1.3. EB-specific enhancements .....	34
2.3.1.4. Deviations .....	34
2.3.1.5. Limitations .....	35
2.3.1.6. Open-source software .....	38
3. ECU Configuration Wizard user's guide .....	39
3.1. Overview .....	39
3.2. Background information .....	39
3.3. Common mapping aspects .....	39
3.3.1. Naming rules .....	39
3.3.1.1. Name mangling algorithm for importers .....	39
3.3.1.2. Name prefixing .....	40
3.3.1.3. Instance handling .....	40
3.3.2. Signal offsets .....	42
3.3.3. Rx NM PDUs .....	42
3.3.4. Duplication of Tx N-PDU configuration containers .....	43
3.3.5. PDU routing .....	43
3.4. Importer parameter mappings for AUTOSAR 4.0 modules .....	43
3.4.1. Overview .....	43
3.4.2. Can .....	44
3.4.2.1. CanObjectId configuration .....	47
3.4.3. CanIf .....	48
3.4.4. CanNm .....	53
3.4.5. CanSM .....	58
3.4.6. CanTp .....	59
3.4.7. CanTSyn .....	62
3.4.8. Com .....	66
3.4.8.1. Configuration for partial networking ERA and EIRA PDUs and signals .....	78

3.4.8.2. Configuration for partial networking IRA signals .....	79
3.4.9. ComM .....	80
3.4.10. Dcm .....	84
3.4.10.1. Configuration of subservices for Diagnostic Session Control .....	107
3.4.10.2. Configuration of subservices for Diagnostic Security Access .....	108
3.4.10.3. Configuration of subservices for Diagnostic Read Data By Identifier .....	108
3.4.10.4. Configuration of subservices for Diagnostic Write Data By Identifier .....	109
3.4.10.5. Configuration of subservices for Diagnostic IOControl .....	109
3.4.10.6. Configuration of subservices for Diagnostic Write Memory By Address .....	109
3.4.10.7. Configuration of subservices for Diagnostic Read Memory By Address .....	110
3.4.10.8. Configuration of subservices for Diagnostic Routine Control .....	110
3.4.10.9. Configuration of subservices for Diagnostic Read Data By Periodic Identifier..	110
3.4.10.10. Configuration of subservices for Diagnostic Dynamically Define Data Identifi- er .....	111
3.4.10.11. Configuration of subservices for Diagnostic Clear Diagnostic Information .....	111
3.4.10.12. Configuration of subservices for Diagnostic Read DTC Information .....	112
3.4.10.13. Configuration of diagnostic subservices EcuReset .....	112
3.4.10.14. Configuration of diagnostic subservices ComControl .....	113
3.4.10.15. Configuration of subservices for Diagnostic RequestOnBoardMonitor- ingTestResults .....	114
3.4.10.16. Configuration of subservices for Diagnostic RequestVehicleInfo .....	114
3.4.10.17. Configuration of subservices for Diagnostic RequestDownload .....	114
3.4.10.18. Configuration of subservices for Diagnostic RequestUpload .....	115
3.4.10.19. Configuration of subservices for Diagnostic DataTransfer .....	115
3.4.10.20. Configuration of subservices for Diagnostic RequestTransferExit .....	115
3.4.10.21. Configuration of diagnostic subservices ControlDTCSetting .....	116
3.4.10.22. Determining the access permissions for diagnostic service instances .....	116
3.4.10.23. Determining the type for a routine signal .....	116
3.4.10.24. Configuration of DcmProcessingConditions .....	117
3.4.10.25. Configuration of DcmDspPid .....	117
3.4.10.25.1. Configuration of DcmDspPidData .....	117
3.4.10.25.2. Configuration of DcmDspPidDataSupportInfo .....	118
3.4.10.25.3. Configuration of DcmDspPidService01 .....	118
3.4.10.25.4. Configuration of DcmDspPidSupportInfo .....	118
3.4.11. Dem .....	119
3.4.12. DoIP .....	127
3.4.13. EcuC .....	130
3.4.14. Eth .....	133
3.4.15. EthIf .....	134
3.4.16. EthSM .....	136
3.4.17. EthSwt .....	136
3.4.18. EthTSyn .....	140

3.4.19. FiM .....	143
3.4.20. Fr .....	145
3.4.21. FrArTp .....	147
3.4.22. FrIf .....	150
3.4.23. FrNm .....	155
3.4.24. FrSM .....	160
3.4.25. FrTp .....	160
3.4.26. FrTSyn .....	164
3.4.27. IpduM .....	167
3.4.28. LdCom .....	174
3.4.29. Lin .....	176
3.4.30. LinIf .....	176
3.4.31. LinSM .....	183
3.4.32. LinTp .....	183
3.4.33. Nm .....	185
3.4.34. PduR .....	188
3.4.35. Sd .....	190
3.4.36. SecOC .....	196
3.4.37. SoAd .....	200
3.4.37.1. PDU types without transmission support on SoAdSocketConnectionGroup level .....	209
3.4.37.2. SocketConnOrSocketConnBundleRef .....	209
3.4.38. SomelpTp .....	210
3.4.39. StbM .....	212
3.4.40. Tcplp .....	214
3.4.41. UdpNm .....	218
3.4.42. Xcp .....	222
4. Bibliography .....	223



# 1. Overview of EB tresos ECU Configuration Wizard documentation

Welcome to the EB tresos ECU Configuration Wizard (ECU Configuration Wizard) product documentation.

This document provides:

- ▶ [Chapter 2, “ECU Configuration Wizard release notes”](#): release notes for the ECU Configuration Wizard module
- ▶ [Chapter 3, “ECU Configuration Wizard user's guide”](#): containing background information and instructions

## 2. ECU Configuration Wizard release notes

### 2.1. Overview

This chapter provides the ECU Configuration Wizard product specific release notes. General release notes that are applicable to all products are provided in the EB tresos AutoCore Generic documentation. Refer to the general release notes in addition to the product release notes documented here.

### 2.2. Scope of the release

#### 2.2.1. Configuration tool

Your release of EB tresos AutoCore is compatible with the release of the EB tresos Studio configuration tool:

- ▶ EB tresos Studio: 26.2.0 b191017-0938

#### 2.2.2. AUTOSAR modules

The following table lists the AUTOSAR modules that are part of this ECU Configuration Wizard release.

Module name	AUTOSAR version and revision	SWS version and revision	Module version	Supplier
No AUTOSAR modules available				

Table 2.1. Hardware-Independent Modules specified by the AUTOSAR standard

#### 2.2.3. EB (Elektrobit) modules

The following table lists all modules which are part of this release but are not specified by the AUTOSAR standard. These modules include tooling developed by EB or they may hold files shared by all other modules.

Module name	Module version	Supplier
<a href="#">Configurators</a>	2.8.20	Elektrobit Automotive GmbH

Table 2.2. Modules not specified by the AUTOSAR standard

## 2.2.4. MCAL modules and EB tresos AutoCore OS

For information about MCAL modules and OS, refer to the respective documentation, which is available as PDF at `$TRESOS_BASE/doc/3.0_EB_tresos_AutoCore_OS` and `$TRESOS_BASE/doc/5.0_MCAL_modules`<sup>1</sup>. It is also available in the online help in EB tresos Studio. Browse to the folders `EB tresos AutoCore OS` and `MCAL modules`.

## 2.3. Module release notes

### 2.3.1. Configurators module release notes

- ▶ Module version: 2.8.20.B271942
- ▶ Supplier: Elektrobit Automotive GmbH

#### 2.3.1.1. Change log

This chapter lists the changes between different versions.

##### Module version 2.8.20

2019-10-11

- ▶ Extended Transformer for `SomeIpTp` to support `SomeIpTpChannel` entities
- ▶ Extended Transformer for `TcpIp` to configure `TcpIpTcpKeepAliveEnabled`, extended Transformer for `SoAd` to configure `SoAdSocketTcpKeepAlive`
- ▶ Extended Transformer for `StbM` to support parameters `StbMOffsetCorrectionAdaptionInterval`, `StbMOffsetCorrectionJumpThreshold`, `StbMRateCorrectionMeasurementDuration` and `StbMRateCorrectionsPerMeasurementDuration`
- ▶ Extended Transformer for `LinIf` to prevent the configuration of `LinFrame` elements that the configured Ecu Instance sends or receives via `LinSlave` communication controllers

##### Module version 2.8.19

2019-09-06

---

<sup>1</sup>`$TRESOS_BASE` is the location at which you installed EB tresos Studio.



- ▶ ASCCONFIGURATORS-1064 Fixed known issue: Transformer for SoAd does not create Pdu Routes for dynamically configured local IP addresses

### Module version 2.8.18

2019-07-12

- ▶ Support array types for the `DcmDspRoutineSignalType`
- ▶ ASCCONFIGURATORS-1055 Fixed known issue: Transformers for Com, ComM issue a `NullPointerException` if PNC vector is missing

### Module version 2.8.17

2019-06-14

- ▶ Remove prefix for names of `DcmDspData` elements
- ▶ Extended Transformer for `ComM` to configure `ComMNmVariant` as `NONE` if the configured Ecu Instance does not send or receive PDUs on the `ComMChannel`
- ▶ Extended Transformers for `EcuC`, `CanNm`, `FrNm`, `UdpNm`, `PduR` and `Com` to configure received Nm User Data PDUs even if the signals contained in the Nm PDUs have no signal port assigned
- ▶ Extended Transformer for `SoAd` to configure `GeneralPurposeIPdu` elements of category `Dlt_TP` and `Dlt_IF`
- ▶ Extended Transformer for `SoAd` to configure `SoAdTxPduCollectionSemantics`
- ▶ ASCCONFIGURATORS-1041 Fixed known issue: During the import of the Diagnostic Extract, the creation of a configuration container in Dem throws an exception. This exception is caused by an illegal container short name

### Module version 2.8.16

2019-05-17

- ▶ Extended Transformer for `SoAd` to support Service Oriented Communication of System Description .arxml files
- ▶ Extended Transformer for `StbM` to configure `StbMIsSystemWideGlobalTimeMaster` for abstract Global Time Domains
- ▶ ASCCONFIGURATORS-1035 Fixed known issue: Transformer for `LinIf` configures `LinIfCollisionResolvingRef` incorrectly
- ▶ ASCCONFIGURATORS-1038 Fixed known issue: Dcm importer wrongly configures the `SessionRefs` and `SecurityLevelRefs` for the `ServiceInstance` value of `AccessPermissionValidity`

### Module version 2.8.15

2019-04-18

- ▶ Extended Transformer for `Dem` to support the configuration of the `DemOBDSupport` and the `DemOBDSupportKind` parameters
- ▶ Adapted Transformer for `TcpIp` to skip the configuration of `TcpIpStaticIpAddressConfig` containers if the parent `TcpIpLocalAddr` container has been created for a multicast address that is configured at runtime by `Sd`
- ▶ Adapted Transformer documentation for `Dcm` to correctly reflect the information for DiagnosticComControl (0x28) service
- ▶ Adapted Transformer for `Dcm` to fill the Data Access Interface by the DEXT importer
- ▶ Adapted Transformer documentation for `Dcm` to write `VARIABLE-SIZE` instead of `VARIABLE-LENGTH`
- ▶ Extended Transformer for `CanNm` to resolve short name collisions in the case that `NmPdu` elements are transmitted in different CAN networks using identical CAN Ids or CAN Id ranges
- ▶ Adapted Transformer for `Dcm` to also take into account `MAPPED-FLAT-SWC-SERVICE-DEPENDENCY` when configuring the `DcmDspRoutineUsePort`
- ▶ Extended Transformer for `Com` to configure `ComSignalDirection` and `ComSignalGroupDirection`
- ▶ Extended Transformers to support the reception of one and the same PDU via different networks

### Module version 2.8.13

2019-03-14

- ▶ ASCCONFIGURATORS-1006 Fixed known issue: Transformer for `Xcp` erroneously adds non-`Xcp` PDUs

### Module version 2.8.12

2019-02-15

- ▶ Extended Transformer for `Dcm` to configure the `DcmDspRequestRoutineResultsIn` container inside the `Dsp` container, only if the `REQUESTS` tag exists inside the `DiagnosticExtract`
- ▶ Extended Transformer for `IpduM` to configure `IpduMContainerQueueSize` by using `ContainerIPdu.minimumRxContainerQueueSize` and `ContainerIPdu.minimumTxContainerQueueSize`
- ▶ Extended Transformer for `StbM`, `EthTSyn`, `CanTSyn`, and `FrTSyn` to support configuration via AUTOSAR 4.4 `GlobalTimeDomain` elements
- ▶ Extended Transformer for `IpduM` to configure `IpduMContainerTxTriggerMode` of `IpduMContainerTxPdu` to `IPDUM_DIRECT`, if the `IpduMContainerTxPdu` is itself contained in a `SecuredIPdu`, i.e. a PDU that is processed in `SecOC`

- ▶ Extended Transformer for `ComM` to take the `PncMapping` references to `PhysicalChannel` elements into account for setting up the `ComMPnc` lists
- ▶ Extended Transformer for `ComM` to support the configuration of managed `ComMChannel` containers

#### Module version 2.8.11

2019-02-05

- ▶ ASCCONFIGURATORS-996 Fixed known issue: `DiagnosticEventHandler` issues `NullPointerException` on Event that is not mapped onto an operation Cycle
- ▶ Extended Transformer for `Dem` to configure the `DiagnosticDemProvidedDataMapping.DataProvider` with the standardized values
- ▶ Extended Transformer for `IpduM` to configure `IpduMContainedTxPduPriority`

#### Module version 2.8.10

2019-01-25

- ▶ Extended configuration of `CanTSynGlobalTimeFollowUpTimeout` in Transformer for `CanTSyn`
- ▶ Extended Transformer for `ComM` to configure `ComMPncEthIfSwitchPortGroupRef`
- ▶ Extended Transformers to allow execution in EB tresos Studio 26 and to support transformation of ASR 4.4 system description files
- ▶ Extended Transformers for `CanIf` and `FrIf` to configure `PduR` as upper layer for routed N-PDUs
- ▶ Extended Transformer for `Dem` to configure the `DemDtcStatusAvailabilityMask` parameter inside the `DemGeneral` container

#### Module version 2.8.9

2018-12-13

- ▶ ASCCONFIGURATORS-977 Fixed known issue: Transformer for `EcuC` stops with an error if a sent PDU undergoes a tx fanout before `SecOC/IpduM` and before `<Bus<If` at the same time
- ▶ Extended Transformer for `Dcm` to configure the `DcmDspRoutineFixedLength` parameter of a `DcmDspRoutine`
- ▶ Extended Transformer for `Dem` to configure the `DemEventSignificance` parameter inside the `DemEventClass` container
- ▶ ASCCONFIGURATORS-980 Fixed known issue: Transformer for `SoAd` configures `SomeIpTp` N-PDUs as TP API PDUs instead of as IF API PDUs

- ▶ Extended Transformers for `IpduM`, `SecOC`, and `PduR` to support transmission of cryptographic PDUs in container PDUs and routing of cryptographic PDUs
- ▶ Extended Transformer for `Dem` to configure the `DemEventDestination` parameter inside the `DemEventClass` container
- ▶ Extended Transformer for `IpduM` to configure `IpduMContainerQueueSize`

### Module version 2.8.8

2018-10-26

- ▶ ASCCONFIGURATORS-964 Fixed known issue: Transformer for `EcuC` does not configure Routing-only Applicative TP SDUs
- ▶ Extended Transformers for `Com` and `LdCom` to support the configuration of `Tp` API for PDUs that are sent or received via `SomeIpTp`
- ▶ Extended Transformer for `ComM` to configure `ComMPncComSignal` entries as ERA if they are associated with a `COMM_GATEWAY_TYPE_PASSIVE` `ComMChannel`
- ▶ ASCCONFIGURATORS-971 Fixed known issue: Transformer for `FrTSyn` does not configure `FrTSynGlobalTimeSyncDataIDList` correctly

### Module version 2.8.7

2018-09-28

- ▶ Extended Transformer for `SoAd` to support use of "0.0.0.0" IPV4 addresses as dynamic remote IP addresses
- ▶ Extended Transformer for `IPduM` to support parameter `IpduMUnusedAreasDefault` in `IpduMContainerTxPduS`
- ▶ ASCCONFIGURATORS-957 Fixed known issue: Transformer for `SecOC` does not process cryptographic PDUs

### Module version 2.8.6

2018-08-24

- ▶ Removed configuration of `EthSwtPortSpeed` from Transformer for `EthSwt`

### Module version 2.8.5

2018-07-31

- ▶ Extended Transformer for `StbM`: Added support for the configuration of `StbMSynchronizedTime-BaseIdentifier`
- ▶ Extended Transformers to ignore Frames, PDUs, and Signals that are sent or received via `LinSlave` elements
- ▶ Extended Transformer for `LdCom` to support the configuration of a received PDU irrespective of its `min-imumDelay`, `transmissionModeTrueTiming` and `transmissionModeCondition`
- ▶ Extended Transformer for `Com` to implement OEM specific fallback for configuration of `ComSignalType`
- ▶ Extended Transformer for `EcuC` to exclude secured PDUs and Pcus contained in a secured PDU from the Meta-Data handling
- ▶ Extended Transformer for `Dcm` to configure `DiagnosticDataTransfer`
- ▶ ASCCONFIGURATORS-951 Fixed known issue: Transformer for `IPduM` creates duplicated Contained Rx PDUs

#### Module version 2.8.4

2018-06-22

- ▶ Removed creation of `IPV4` limited broadcast address entries in Transformer for `TcpIp`
- ▶ Extended Transformer for `PduR` to configure `PduRRoutingGroup` containers
- ▶ Extended Transformer for `SecOC` to support the configuration of distinct Secured and Cryptographic PDU containers
- ▶ Extended Transformer for `EcuC` to configure Meta-Data for Ethernet PDUs that are received or sent by server components
- ▶ Extended Transformer for `EthSwt` to configure modified parameter `EthSwtPortPhysicalLayerType` and new parameter `EthSwtPortMacLayerType` in `EthSwtPort`

#### Module version 2.8.3

2018-05-25

- ▶ Extended Transformer for `Com` to configure `ISignalIPduGroup` elements that refer to `NmPdu` elements
- ▶ Extended Transformers for `Com`, `SecOC`, `IpduM`, `PduR`, and `EcuC` to support tx fan-out in between these modules
- ▶ Extended Transformers for `Com` and `SomeIP` to support sending and receiving of `ComIPdu` elements via TP API
- ▶ Extended Transformer for `CanIf` to support `CAN_TSYN` as value for `CanIfRxPduUserRxIndicationUL` and `CanIfTxPduUserTxConfirmationUL`
- ▶ Extended Transformer for `Dcm` to configure custom sub-services for `DiagnosticEcuReset`

- ▶ ASCCONFIGURATORS-922 Fixed known issue: `EthIfCtrlMtu` is configured incorrectly
- ▶ Changed Transformer for `EthIf`: Length of VLAN tag is no longer subtracted from `EthIfCtrlMtu`
- ▶ Extended Transformer for `IPduM` to configure the `offset` and `updateIndicationBitPosition` parameters in `IpduMContained[Rx|Tx]Pdu`, added support for `ContainerIPduHeaderTypeEnum.no-Header`
- ▶ Extended Transformer for `LdCom` to support the configuration of a received PDU irrespective of its `transferProperty`
- ▶ Extended Transformer for `DoIp` to support `IPV6` during configuration of `VehicleAnnouncement` container
- ▶ Extended Transformer for `PduR` to configure `PduRTpThreshold` only if the `PduRRoutingPath` container holds exactly one `PduRDest` subcontainer
- ▶ Extended Transformer for `FrTSyn` to configure `FrTSynGlobalTimeSequenceCounterJumpWidth` in the context of a `FrTSynGlobalTimeSlave` container
- ▶ ASCCONFIGURATORS-921 Fixed known issue: `CanIfRxPduDlc` is configured incorrectly
- ▶ Extended Transformer for `SoAd` to configure `SoAdSocketTcpInitiate` only in `Tcplp SoAdSocketConnectionGroup` containers that contain exactly one `SoAdSocketConnection` sub container

### Module version 2.8.2

2018-04-20

- ▶ ASCCONFIGURATORS-904 Fixed known issue: `MultiplexedIPdus` that are sent and received at the same time are configured incorrectly
- ▶ Extended Transformer for `Dcm` to configure references `DcmDspReadMemoryRangeSecurityLevelRef` in `DcmDspReadMemoryRangeInfo` and `DcmDspReadMemoryRangeByLabelInfo`, `DcmDspWriteMemoryRangeSecurityLevelRef` in `DcmDspWriteMemoryRangeInfo` and `DcmDspWriteMemoryRangeByLabelInfo`
- ▶ Extended Transformer for `Dcm` to configure `DiagnosticRequestOnBoardMonitoringTestResults`
- ▶ Extended Transformer for `Com` to configure `ComIPduGroupRef` only for `ComPduGroup` containers whose direction is not opposite to the referencing PDU
- ▶ Extended Transformer for `Dcm` to configure `DiagnosticRequestVehicleInfo`

### Module version 2.8.1

2018-03-16

- ▶ ASCCONFIGURATORS-890 Adapted Transformer for `Dcm` to enable the `DcmProcessingConditions` container only in the case when a `DcmModeCondition` or a `DcmModeRule` exists

- ▶ Extended Transformer for `Dcm` to configure the `OBDMode_0x0A` (`DiagnosticRequestEmissionRelatedDTCPermanentStatus`) service
- ▶ Extended Transformer for `ComM` to configure the parameter `ComMPncPrepareSleepTimer`
- ▶ Extended Transformers for `Nm`, `UdpNm`, `CanNm`, and `FrNm` to configure the parameters `NmRepeatMsgIndEnabled`, `NmNodeDetectionEnabled`, `NmNodeIdEnabled` either by using the `NmCluster` data or by using the `NmEcu` data as a fallback
- ▶ Extended Transformer for `SecOC` to configure parameters `SecOCSecured[Rx|Tx]PduOffset` and `SecOCSecured[Rx|Tx]PduLength` in `SecOCRxPduSecuredArea`
- ▶ Extended Transformer for `StbM` to support the configuration of `StbMSynchronizedTimeBase` container for `GlobalTimeDomains` that are not linked to any network
- ▶ Extended Transformer for `SecOC` to configure parameter `SecOCAuthenticationBuildAttempts` in `SecOCRxPduProcessing` and `SecOCTxPduProcessing`
- ▶ Extended Transformer for `Dcm` to support the configuration of `DcmDspMemory` container for the `DiagnosticWriteMemoryByAddress` and `DiagnosticReadMemoryByAddress` services.
- ▶ Extended Transformer for `ComM` to also take routed PDUs into account for setting up the PNC to `ComM-Channel` references

## Module version 2.8.0

2018-02-16

- ▶ Extended Transformers for `DoIP` and `PduR` to not configure `DoIP` SDUs that are either sent and have their `DiagPduType` field set to `DiagRequest` or that are received and have their `DiagPduType` field set to `DiagResponse`
- ▶ Extended Transformer for `FrTSyn` to configure `FrTSynGlobalTimeOfsDataIDList` and `FrTSynGlobalTimeSyncDataIDList` configuration containers
- ▶ Extended Transformer for `Dem` to configure the `DemInternalDataElementClass` and `DemExternalCSDDataElementClass` choices of the `DemDataElementClass ChoiceContainer`
- ▶ ASCCONFIGURATORS-878 Fix configuration of `DcmDsdSubServiceId` for the `DiagnosticComControl`
- ▶ ASCCONFIGURATORS-879 Fix configuration of Data Access Interface in the case of a `DiagnosticIOControlService`
- ▶ Extended Transformer for `Dcm` to configure `DiagnosticRequestDownload`, `DiagnosticRequestUpload`, `DiagnosticRequestTransferExit`
- ▶ Extended Transformer for `StbM` to configure parameters `StbMTimeLeapFutureThreshold`, `StbMTimeLeapPastThreshold`, and `StbMClearTimeleapCount`
- ▶ Extended Transformer for `SecOC` to configure parameters `SecOCAuthDataFreshnessLen`, `SecOCAuthDataFreshnessStartPosition`, `SecOCUseAuthDataFreshness`, and `SecOCSecuredRxPduVerification`

- ▶ Added Transformer for `SomeIpTp`
- ▶ Transformers for `EcuC`, `CanNm`, `FrNm`, `UdpNm`, `PduR`, `Com`, and `ComM` now configure PNC ERA PDUs and signals for ACTIVE as well as PASSIVE PNC gateways
- ▶ Adapted Transformer for `CanTSyn` to configure the `CanTSynGlobalTimeSequenceCounterJumpWidth` parameter in `CanTSynGlobalTimeSlave`

### Module version 2.7.11

2018-01-19

- ▶ Internal module improvement. This module version update does not affect module functionality

### Module version 2.7.10

2017-12-15

- ▶ Extended Transformer for `Dcm` to support `DcmDspPid` configuration
- ▶ Extended Transformer for `Dcm` to configure the `OBDMODE_0x02` (`DiagnosticRequestPowertrainFreezeFrameData`) service
- ▶ Extended Transformer for `Dcm` to configure the `OBDMODE_0x01` (`DiagnosticRequestCurrentPowertrainDiagnosticData`) service
- ▶ Extended Transformer for `Dcm` to configure the `OBDMODE_0x04` (`DiagnosticClearResetEmissionRelatedInfo`) service
- ▶ Extended `DcmTransformer` for `DcmDspComControl` to configure the `DcmDspComControlSubNode` sub-container
- ▶ Extended Transformer for `SecOC` to configure the `SecOCPduType` parameter for authentic PDUs
- ▶ ASCCONFIGURATORS-859 Fixed known issue: `ComTransferProperty` is configured incorrectly for `SignalGroups`
- ▶ Extended Transformer for `CanNm` to configure the `CanNmNodeIdEnabled` parameter for `NmEcus`
- ▶ ASCCONFIGURATORS-864 Fixed known issue: `ComTimeout` and `ComFirstTimeout` are configured incorrectly for `SignalGroups`

### Module version 2.7.9

2017-11-17

- ▶ Extended Transformer for `EthSwt` to also accept value of `CouplingPort.VlanMembership.defaultPriority` if all `defaultPriority` values of a `CouplingPort` are identical



- ▶ Modified the import of the Variable-size DID signals.
- ▶ Extend the DcmTransformer in order to also configure the DcmDspRequestResultsRoutineSupported and DcmDspStopRoutineSupported
- ▶ Adapted Transformer for IpduM: IpduMContainedRxInContainerPduRef is only configured if RxAcceptedContainedIPdu of the associated ContainerIPDU is set to ACCEPT-CONFIGURED
- ▶ Adapted Transformer for SoAd: SoAdSocketRemoteIpAddress is now explicitly configured if Ipv4Configuration/ipv4Address or Ipv6Configuration/ipv6Address is set to ANY
- ▶ Extended Transformer for Dcm to configure the OBDMODE\_0x08 (RequestControlOfOnBoardDevice) service
- ▶ Support fragmentation of PDU size bigger than MTU in SoAdTransformer and TcpIpTransformer

### Module version 2.7.8

2017-10-20

- ▶ Extended Transformer for Dcm to configure the OBDMODE\_0x03 and OBDMODE\_0x07 services
- ▶ Improved handling of ConsumedServiceInstance elements linked to ProvidedServiceInstance elements which in turn are not connected to any SocketConnection or SocketConnectionBundle
- ▶ Modified the configuration of DcmDspDidInfo and of its subcontainers: DcmDspDidControl, DcmDspDidRead and DcmDspDidWrite

### Module version 2.7.7

2017-09-22

- ▶ Removed workaround in the configuration of IpduMContainerTxTriggerMode that was required by a SecOC restriction which has been resolved in the meantime
- ▶ Added support for the configuration of ContainerIPdu elements that are sent and received by the same EcuInstance
- ▶ Extended Transformers for CanTSyn, FrTSyn and EthTSyn to support AUTOSAR RFC 75119
- ▶ Extended Transformer for Com to configure the ComTransferProperty of an I-SIGNAL-GROUP by taking the ComTransferProperty values of the contained I-SIGNAL elements into account
- ▶ Extended Transformer for CanTSyn to configure time domain specific data-ID lists
- ▶ Extended Transformer for SecOC to reflect the SecOC parameter changes in ACG 8.3 and ACG 8.4
- ▶ Adapted Transformers for CanNm, FrNm, UdpNm and Nm to reflect that several parameters in the modules have been moved from the general containers to the Nm channel related containers
- ▶ ASCCONFIGURATORS-818 Fixed known issue: Validation error for DcmDspRoutineInfo if no signal is configured

- ▶ **Extended DcmTransformer for DcmDspComControl to configure the DcmDspComControlAllChannel and DcmDspComControlSpecificChannel subcontainers**

#### **Module version 2.7.6**

2017-08-24

- ▶ **ASCCONFIGURATORS-808 Fixed known issue: Incomplete import of Diagnostic configuration for DcmDspDataType, DcmDspDataSize, and DcmDspRoutineSignalType**
- ▶ **ASCCONFIGURATORS-815 Fixed known issue: Received SecuredIPdus with rxSecurityVerification set to false are not routed via Gateway**
- ▶ **ASCCONFIGURATORS-814 Fixed known issue: Configuration of one and the same PDU for sending and receiving on the same VLAN does not work**

#### **Module version 2.7.4**

2017-07-28

- ▶ **Extended Transformer for PduR to support the fan-out of PDUs on different VLANs of the same Ethernet network**
- ▶ **Extended Transformer for Com to support the configuration of 64-bit signed/unsigned signal datatypes**
- ▶ **Modified Transformer to correctly create and configure DcmDspDidInfo for DiagnosticIoControlService**
- ▶ **Extended Transformer for DcmProcessingCondition to configure DcmModeRule and DcmModeCondition**
- ▶ **Extended Transformer for Can to make instance suffix creation robust against invalid RxIdentifierRanges**
- ▶ **ASCCONFIGURATORS-805 Fixed known issue: Received SecuredIPdu in ContainerIPDU with rxSecurityVerification set to false causes error during configuration import**
- ▶ **ASCCONFIGURATORS-807 Fixed known issue: Importer stops with an error if VLANs of Switch Ports are not connected to Ecu Instance**
- ▶ **Modified DemTransformer (DiagnosticExtendedDataRecordHandler and DiagnosticEnableConditionGroupHandler) to reduce the number of configured DemExtendedDataClass and DemEnableConditionGroup containers**

#### **Module version 2.7.3**

2017-06-29

- ▶ Extended Transformer for ComM to configure `ComMPncComSignalChannelRef` in ERA `ComMPncComSignal` containers
- ▶ Extended Transformer for EthIf to support `MaximumTransmissionUnit` from `EthernetCommunicationConnector` as well as from `EthernetCommunicationController`
- ▶ Extended Transformer for SecOC to support the configuration of `GeneralPurposeIPdu` elements in `SecOCTxAutenticPduLayer` or `SecOCRxAutenticPduLayer` containers
- ▶ Extended Transformer for PduR to support the fanout of sent `SecuredIPdu` elements
- ▶ Extended Transformer for EthIf and EthSwt to support managed switching of switch ports

### Module version 2.7.2

2017-06-02

- ▶ Extended Transformer for Dcm to configure `DiagnosticPeriodicID`
- ▶ Extended Transformer for PduR to support the configuration of routing-only multiplexed PDUs and the configuration of multiplexed PDUs that contain routing-only demultiplexed PDUs
- ▶ Extended Transformer for PduR, CanIf, FrIf, and LinIf to support the configuration of routed Xcp PDUs
- ▶ Modified `DiagnosticDIDHandler`, `DiagnosticDynamicallyDefineDataIdentifierHandler`, and `DiagnosticIOControl` to reduce the number of configured `DcmDspDidInfo` containers
- ▶ Extended Transformer for SecOC to support `SecureCommunicationFreshnessProps` and `SecureCommunicationAuthenticationProps` for the configuration of SecOC PDUs
- ▶ Extended Transformer for IpduM to support the configuration of `IpduMContainerTxTriggerMode`
- ▶ Extended Transformers for CanTSyn and FrTSyn to support `GlobalTimeDomain.globalTimePduTriggering` as well as `GlobalTimeDomain.globalTimePdu`

### Module version 2.7.1

2017-05-05

- ▶ Modified `DemTransformer` to reduce the number of configured `DemFreezeFrameClass` and `DemFreezeFrameRecNumClass` elements
- ▶ Configured `DemDTCClass` to support DTC of type `DiagnosticTroubleCodeObd`
- ▶ Changed the way how the `DcmDspDataType` is configured based on Byte Array Signals
- ▶ Extended Transformer for Dcm to configure `DcmDslBuffer`
- ▶ Improved the configuration of `DiagnosticOperationCycles` and `DiagnosticAgingCycles`
- ▶ Extended `DcmTransformer` to set the `DcmDslProtocolSessionRef` reference to every `DcmDslProtocolRow`

### Module version 2.7.0

2017-03-31

- ▶ Extended Transformer for Dcm to configure `ClearDiagnosticInformation`
- ▶ Extended Transformer for Dcm to configure `DiagnosticWriteMemoryByAddress` services
- ▶ Extended Transformer for Dcm to configure `DiagnosticReadMemoryByAddress` services
- ▶ Extended Transformers for CanNm, FrNm, and UdpNm to configure `<Bus>NmPnResetTime`
- ▶ Extended Transformer for Dem to configure property `<Bus>DemAgingCycleRef` from the `DemEventClass`
- ▶ Extended Transformers for UdpNm and Nm to support `UdpNmChannels` associated with `EthernetPhysicalChannels/VLANs`
- ▶ Extended Transformer for Com to take `ISignal.iSignalType` into account for the calculation of signal data types
- ▶ Extended Transformer for LinIf to support the configuration of `AssignNad`, `AssignFrameId`, and `UnassignFrameId` frames using AUTOSAR 4.3.0 `LinSlaveConfig` entities
- ▶ Extended Transformer for Com to support the configuration of `ComSignal/ComFirstTimeout`
- ▶ Extended Transformers for CanTSyn and FrTSyn to support the configuration of data-ID lists
- ▶ Extended Transformer for EthTSyn to support the configuration of data-ID lists and `EthTSynFramePrio`
- ▶ Extended Transformers for Com and SoAd to support the IPV4 and IPV6 address value `ANY`
- ▶ Extended Transformer for UdpNm to support the configuration of `UdpNmImmediateNmCycleTime` and `UdpNmImmediateNmTransmissions`
- ▶ Extended Transformers for CanNm, FrNm, UdpNm, and Nm to use `NmCluster.nmPncParticipation` for the configuration of `<Bus>NmComUserDataSupport` and `<Bus>NmPnEnabled`
- ▶ Extended Dcm to support `DcmDslProtocolPriority`
- ▶ Added Transformer for `Fim`
- ▶ Set the `DiagnosticPeriodicRate` category in the `DiagnosticPeriodicTransmission` field in the `DcmDsp` container

### Module version 2.6.10

2017-03-03

- ▶ Extended Transformer for Dcm to configure `DiagnosticIOControl`
- ▶ Configured `DcmDsdSidTabSubfuncAvail` parameter for `DiagnosticEcuReset`, `DiagnosticRoutineControl` and `DiagnosticReadDTCInformation` services
- ▶ Added Transformer for `Xcp`
- ▶ Modified Dem and Dcm configurators to not create an additional `configSet` container if one already exists

- ▶ ASCCONFIGURATORS-666 Fixed known issue: The `DcmRteUsage` is configured based on other parameters `DcmDspDataUsePort` and `DcmDspRoutineUsePort`
- ▶ Added support for IPV6 IP addresses to Transformers for `Tcplp` and `SoAd`
- ▶ Moved the available subfunction for diagnostic service `DynamicallyDefineDataIdentifier` from the configuration of the `DataIdentifier` (DID) to the configuration of the diagnostic service
- ▶ ASCCONFIGURATORS-652 Fixed known issue: Dcm importer wrongly adds session and security levels for a `DiagnosticService`
- ▶ ASCCONFIGURATORS-719 Fixed known issue: Dem configuration generates an error if `DiagnosticDataIdentifier` and `DiagnosticDataElement` have the same `ShortName`

### Module version 2.6.9

2017-02-03

- ▶ ASCCONFIGURATORS-651 Fixed known issue: Fixed Dcm error if a DID and one of its aggregated `DiagnosticDataElement` have the same `SHORT-NAME`
- ▶ ASCCONFIGURATORS-662 The `DcmDsdSubServiceSecurityLevelRefs` for the `SubServices` of `DiagnosticSecurityAccess` will not be configured.
- ▶ Extended Transformer for `SecOC` to support the configuration of secured PDUs of type `DcmIPdu`
- ▶ Extended Transformer for `SecOC` to support the configuration of secured PDUs for which `IPduPort.rxSecurityVerification` is set to `false`
- ▶ Extended Transformer for `ComM` to check whether a given PNC ID actually lies within the specified PNC vector
- ▶ Extended Transformer for `Tcplp` to add limited broadcast address entries if they are needed for DHCP
- ▶ Created ECU parameter configuration in the `Bsw` module `Dcm` for UDS service `ReadDataByPeriodicIdentifier` from information contained in the diagnostic extract
- ▶ Extended `Dcm` to configure the `DcmDspDataUsePort` parameter concerning the cases described by `ServiceNeeds/DiagnosticValueNeeds.processingStyle`
- ▶ ASCCONFIGURATORS-665 Fixed known issue: Fixed Dem configurator to configure the `DemEventPriority` parameter
- ▶ Extended Transformer for `Dcm` to configure `DynamicallyDefineDataIdentifier`

### Module version 2.6.8

2017-01-05

- ▶ ASCCONFIGURATORS-652 Fixed known issue: Fixed Dcm importer wrongly adds session and security levels for a `DiagnosticService`

- ▶ Extended Transformer for Can: Add support for the configuration of `CanObjectId` in multi-CanController scenarios
- ▶ Extended Transformer for EthIf to support `EthIfController`, `EthIfPhysController`, and `EthIfSwitch` configuration containers

#### Module version 2.6.7

2016-12-02

- ▶ ASCCONFIGURATORS-654 Fixed known issue: Transformer for DoIP does not configure all `DoIPTcpConnection` containers
- ▶ Extended Transformer for Dcm to configure `ControlDTCSetting`
- ▶ Extended Transformer for IpduM to support multiplexed PDUs and secured PDUs In container PDUs
- ▶ Added Transformer for SecOC

#### Module version 2.6.6

2016-11-04

- ▶ Added Transformer for FrArTp
- ▶ Extended Transformers for Com and PduR to support bidirectional routing of PDUs and signals
- ▶ Extended Transformer for SoAd: `ProvidedServiceInstance` and `ConsumedEventGroup` elements are considered for the configuration of `SoAdSocketFramePriority`

#### Module version 2.6.5

2016-10-21

- ▶ ASCCONFIGURATORS-606 Fixed known issue: The parameter `DcmDspDataInfoRef` is not set and its container `DcmDspData` is not referenced by DIDs, if no Base Data Type can be determined
- ▶ Extended Transformer for Dcm to configure `DiagnosticEcuReset`
- ▶ ASCCONFIGURATORS-607 Fixed known issue: The parameter `DcmDspRoutineSignalLength` is not configured if the `DiagnosticDataElement` evaluates to a non-array element
- ▶ ASCCONFIGURATORS-608 Fixed known issue: Import ECU configuration erroneously configures `SubServices` for the Dcm RoutineControl service
- ▶ Extended Transformer for TcpIp to configure `TcpIpAssignmentPriority`
- ▶ Adapted Transformer for Nm: `NmChannelId` is not configured any more
- ▶ Adapted Transformer for TcpIp to support AUTOSAR 4.2.2 parameter structure

- ▶ Extended Transformers for PduR and SoAd to support PDU routing between <Bus>Tp and SoAd
- ▶ Extended Transformer for Sd to support AUTOSAR RFC 73286
- ▶ Added Transformer for EthSwt
- ▶ Extended Transformer for Dem to configure `DiagnosticExtendedDataRecord`

#### Module version 2.6.4

2016-09-09

- ▶ ASCCONFIGURATORS-614 Fixed known issue: Transformer for Dcm configures `DcmDslProtocolRxTesterSourceAddr` incorrectly
- ▶ Extended Transformer for DoIP to support configurations without `DiagnosticConnections` in the imported system model
- ▶ Added Transformers for CanTSyn and FrTSyn
- ▶ Added Transformer for AUTOSAR 4.0 Dem: Added support for configuring `DiagnosticTroubleCode`, `DiagnosticTroubleCodeGroup`, `DiagnosticEvent`, `DiagnosticEnableCondition`, `DiagnosticEnableConditionGroup` and `DiagnosticIndicator` into Dem
- ▶ Extended Transformer for Dem to configure `DiagnosticDataElements` and `DiagnosticFreezeFrames`
- ▶ Extended Transformer for Dcm to configure `DiagnosticReadDTCInformation`
- ▶ Extended Transformer for Dcm to configure `/DcmDspRoutine/DcmDspRoutineUsePort`

#### Module version 2.6.3

2016-08-05

- ▶ ASCCONFIGURATORS-604 Fixed known issue: Configuration of vehicle announcement in DoIP assumes incorrect remote IP address
- ▶ ASCCONFIGURATORS-599 Fixed known issue: Default Buffer Assignment does not support CAN 2.0 and CAN FD PDUs with identical CAN Ids

#### Module version 2.6.2

2016-07-01

- ▶ ASCCONFIGURATORS-594 Fixed known issue: Upper layer of `UserDefinedIPdus` and `GeneralPurposeIPdus` is configured incorrectly in <Bus>If modules
- ▶ Extended Transformer for Tcp to configure at least one `TcpIpAddrAssignment` container for each `TcpIpLocalAddr` entry

### Module version 2.6.1

2016-05-25

- ▶ Extended Transformer for SoAd to support `SoAdSocketConnection` elements without `shortLabel` attribute
- ▶ Extended Transformer for Can, Eth, Fr, Lin to support the configuration parameter set defined by the AUTOSAR 4.2.2 standard
- ▶ Extended Transformer for Dcm to configure `DiagnosticRoutineControl`

### Module version 2.6.0

2016-04-29

- ▶ ASCCONFIGURATORS-569 Fixed known issue: Upper Layer for UUDT DcmIPdus is configured incorrectly in CanIf, LinIf, and FrIf

### Module version 2.5.5

2016-04-01

- ▶ ASCCONFIGURATORS-557 Fixed known issue: Creation of the Dcm configuration from system description does not calculate the value of `DcmDspDataSize` correctly for non-array data instances
- ▶ Extended Transformers for Can and CanIf to create dedicated HOHs for CAN-FD Frames

### Module version 2.5.4

2016-03-04

- ▶ ASCCONFIGURATORS-558 Fixed known issue: Transformer for LinIf does not support `LinSlaveConfig` elements without `LinSlaveConfigIdent`
- ▶ Extended Transformer for SoAd to configure `SoAdSocketTcpKeepAliveProbesMax`, `SoAdSocketTcpKeepAliveInterval`, and `SoAdSocketTcpKeepAliveTime`
- ▶ Extended Transformer for ComM to configure `ComMPNCGatewayType`

### Module version 2.5.3

2016-02-05

- ▶ Added input data validity checks to Transformer for Dcm



### Module version 2.5.2

2016-01-15

- ▶ ASCCONFIGURATORS-533 Fixed known issue: Transformer for Com configures ComSignalDataInvalidValue and ComSignalInitValue for UINT8\_N signals incorrectly
- ▶ ASCCONFIGURATORS-534 Fixed known issue: Transformer for Sd creates unnecessary SdConsumedMethods and SdProvidedMethods configuration containers
- ▶ ASCCONFIGURATORS-537 Fixed known issue: Transformer for ComM configures ComMChannelId incorrectly
- ▶ Extended Transformer for LinIf: Add support for LinSlaveConfig elements
- ▶ ASCCONFIGURATORS-506 Fixed known issue: Transformers for PduR and Com do not conform to TPS\_SYST\_01056
- ▶ Extended Transformers: Resolved naming conflicts for PDUs received with the same CAN ID on different busses
- ▶ ASCCONFIGURATORS-535 Fixed known issue: Transformer for CanIf does not support CAN FD PDU configuration according to Autosar 4.2.2

### Module version 2.5.1

2015-11-06

- ▶ ASCCONFIGURATORS-518 Fixed known issue: Configuration import into Com incorrectly reports error on inconsistent endianness in group signals
- ▶ Removed Transformers for ComXf, SomelpXf, E2EXf
- ▶ Adapted Transformer for PduR: Add routing paths for UserDefinedIPdus and GeneralPurposeIPdus
- ▶ ASCCONFIGURATORS-525 Fixed known issue: ComM channel retrieval for Multiplexer PDUs leads to internal assertion failure
- ▶ Adapted Transformer for DoIp: Adaptations according to DoIP related changes in AUTOSAR 4.2.2 system model
- ▶ Added Transformer for Dcm

### Module version 2.5.0

2015-10-09

- ▶ Adapted Transformer for CanNm, UdpNm: Nm PDU user data byte length is now calculated by subtracting the non user data byte length from the total PDU byte length, removed support for obsolete parameter UdpNmBusLoadReductionEnabled

- ▶ Adapted Transformer for CanIf: Extended support for CAN Id range reception according to AUTOSAR RFC 66324
- ▶ Added support for Com datatype retrieval for DataTypePolicy "transformingISignal"
- ▶ Adapted Transformer for EthTSyn, StbM: Added support for the configuration of EthTSynGlobalTimeTx-Period, StbMOffsetTimeBase
- ▶ Adapted Transformer for CanNm: Implemented parameter mapping of CanNmCarWakeUpFilterEnabled, nmCarWakeUpRxEnabled according to AUTOSAR RFC 65423

#### **Module version 2.4.4**

2015-08-14

- ▶ Adapted Transformer for TcpIp: TcpIpAddressType is now also configured for TcpIpLocalAddr entries that have TcpIpStaticIpAddressConfig/TcpIpStaticIpAddress set to ANY
- ▶ Adapted Transformer for UdpNm: UdpNmChannelConfig container is only configured for VLANs on which Nm PDUs are sent
- ▶ Adapted Transformer for SoAd: SoAdSocketConnectionGroup/SoAdPduHeaderEnable is set to true if at least one transmitted PDU is associated with a valid header id
- ▶ Added proxy UdpNm Transformer to package dreisof.tresos.comimporter.api.transformer.asr41 since the extension of the UdpNm module expects the Transformer to reside in that package
- ▶ Adapted Transformer for Sd: SdInstance containers are only created for VLANs in which the configured ECU executes at least one Client Service or Server Service
- ▶ Adapted Transformer for ComXf, SomeIPXf, E2EXf: Transformer technologies that contain either "1" or "1.0.0" as version number are processed now

#### **Module version 2.4.3**

2015-06-19

- ▶ Adapted Transformers for SoAd and Sd to support seamless service migration/AUTOSAR RFC 61738

#### **Module version 2.4.2**

2015-05-22

- ▶ Update Transformer for Nm according to changes in AUTOSAR RFC 61777
- ▶ ASCCONFIGURATORS-467 Fixed known issue: Transformer for Com issues "zero length BigInteger" error message
- ▶ Added Transformers for EthTSyn, StbM

- ▶ Implemented ComDataType retrieval in Transformer for Com according to AUTOSAR RFC 65384
- ▶ ASCCONFIGURATORS-469 Fixed known issue: Transformer for IpduM configures IpduMSelectorFieldPosition in MostSignificantByteFirst selector fields incorrectly
- ▶ Added Transformer for E2EXf
- ▶ Added Transformer for ComXf
- ▶ Extended Transformers for Com, IPduM, PduR, CanIf, FrIf, SoAd, EcuC to support Container/Contained PDUs

#### **Module version 2.4.1**

2015-02-20

- ▶ Transformer for LinIf now configures LinIfComMNetworkHandleRef
- ▶ Transformer for FrIf now configures FrNm fan-in PDU according to FlexRay slot number, base cycle and cycle repetition parameters
- ▶ Transformers for Com and ComM now configure sent PNC IRA signals
- ▶ Transformers for EcuC, CanNm, FrNm, UdpNm, PduR, Com, ComM now configure PNC ERA PDUs and signals only for ACTIVE PNC gateways
- ▶ Added Transformer for SomelpXf

#### **Module version 2.4.0**

2015-01-07

- ▶ ASCCONFIGURATORS-430 Fixed known issue: Transformer for Com configures initial values and invalid values of UINT8\_N signals incorrectly
- ▶ ASCCONFIGURATORS-440 Fixed known issue: Transformers stop with an error if direct Tp SDU of FrTpConnection is not available
- ▶ Added support for 1..\* cardinality of CanNmRxpdu containers in Transformer for CanNm
- ▶ Added support for PNC ERA PDU configuration in Transformers for EcuC, CanNm, FrNm, UdpNm, PduR, Com, ComM
- ▶ Added support for PNC Identifier configuration according to AUTOSAR RFC 52483 in Transformer for ComM

#### **Module version 2.3.0**

2014-10-03

- ▶ Made Sd Transformer robust against duplicated routing groups
- ▶ ASCCONFIGURATORS-423 Fixed known issue: Transformer for Com generates wrong ComSignalType for signals assigned to "Array" SwBaseType
- ▶ Extended Transformers to support AUTOSAR 4.2.1 system model files as input
- ▶ Added support for dynamic length signals in Com

### **Module version 2.2.2**

2014-09-05

- ▶ Added Transformers for CanSM, FrSM, LinSM and EthSM
- ▶ Added Transformer for DoIP
- ▶ Added Transformer for LdCom

### **Module version 2.2.1**

2014-08-07

- ▶ Adapt configuration of SdClientServiceActivationRef, SdServerServiceActivationRef according to AUTOSAR 4.1.3 Upstream Mapping
- ▶ Adapt Transformer for Eth so that the MAC address is configured according to AUTOSAR
- ▶ Added Transformer for UdpNm
- ▶ Transformer for Sd now configures Sd Control PDUs
- ▶ Transformer for PduR handles routing of Diagnosis PDUs according to AUTOSAR RFC 63555
- ▶ Transformer for Com now supports dataTypePolicy values other than "legacy"
- ▶ ASCCONFIGURATORS-387 Fixed known issue: FrTpTransformer configures FrTpRxPduPoolRef and FrTpTxPduPoolRef incorrectly
- ▶ ASCCONFIGURATORS-393 Fixed known issue: Transformer for CanTp configures identical symbolic names for received N-PDUs used for Data and FC at the same time
- ▶ ASCCONFIGURATORS-394 Fixed known issue: Transformer for FrIf configures incorrect PDU references to EcuC
- ▶ ASCCONFIGURATORS-391 Fixed known issue: PNC ISignalIPduGroups are only considered if the configured ECU instance directly references them
- ▶ Transformer for Sd now supports the configuration of combined Tcp/Udp services
- ▶ ASCCONFIGURATORS-399 Fixed known issue: Transformer for ComM sets ComMNMVariant to "NONE" for LIN Clusters

- ▶ ASCCONFIGURATORS-395 Fixed known issue: Transformers create User Data PDU containers for Nm PDUs containing signals that are not processed by the ECU
- ▶ Transformers for CanNm, FrNm, and UdpNm now configure the links to the associated ComM channels
- ▶ Transformers for ComM now configures ComMChannelId
- ▶ ASCCONFIGURATORS-396 Fixed known issue: Transformer for Nm does not configure NmComUserDataSupport
- ▶ Transformer for Com now configures ComGWMMapping entries for group signals

### Module version 2.2.0

2014-04-25

- ▶ ASCCONFIGURATORS-349 Fixed known issue: Transformer for PduR sets up incorrect routing paths for reversed FlexRay Tp SDUs
- ▶ ASCCONFIGURATORS-355 Fixed known issue: Transformer for Com does not create gateway mapping entries for signal groups
- ▶ ASCCONFIGURATORS-346 Fixed known issue: Transformer for LinIf configures AssignNad frame incorrectly
- ▶ ASCCONFIGURATORS-354 Fixed known issue: Transformer for LinIf reports an error if it encounters AssignFrameIdRange schedule table entries without PID
- ▶ Extended Transformers to support AUTOSAR 4.1.2 system model files as input; added Transformer for Sd

### Module version 2.1.10

2014-01-17

- ▶ Integrated handling for CanTp N-PDUs assigned to multiple CanTp connections
- ▶ Integrated AUTOSAR 4.0 ComM Transformer

### Module version 2.1.9

2013-10-11

- ▶ Internal module improvement. This module version update does not affect module functionality

### Module version 2.1.8

2013-09-13

- ▶ Removed configuration of PN ERA PDUs which are not yet supported by CanNm and FrNm

### Module version 2.1.7

2013-06-14

- ▶ ASCCONFIGURATORS-296 Fixed known issue: The configuration of one and the same CanNm PDU for sending and receiving results in a naming conflict
- ▶ Added support for `CONTAINED-I-SIGNAL-I-PDU-GROUP-REF` to detect PNC-enabled NmClusters
- ▶ Added support for routed-only Tp-SDUs in PduR
- ▶ Added configuration of `CanNmPnFilterMaskByte` in CanNm
- ▶ Added support for configuration of `ComTxModeTrue` for sent PDUs without PDU Timing in Com

### Module version 2.1.6

2013-05-10

- ▶ ASCCONFIGURATORS-277 Fixed known issue: Com Transformer restricts signals to be contained at most once per FlexRay frame
- ▶ ASCCONFIGURATORS-279 Fixed known issue: CanNm Transformer issues exception if handed over Can Network contains Rx Nm PDUs but no CAN Frame Triggerings
- ▶ ASCCONFIGURATORS-276 Fixed known issue: If a PDU is sent and received at the same time and fan-out takes place for the sent PDU, the received PDU instance is configured incorrectly
- ▶ ASCCONFIGURATORS-283 Fixed known issue: LinTp Transformer produces name clashes when importing from AUTOSAR 3.x LinTp configurations
- ▶ ASCCONFIGURATORS-286 Fixed known issue: CanTp Transformer cannot handle `CAN-TP-CONNECTIONS` without `TP-SDU-REF`

### Module version 2.1.5

2013-02-08

- ▶ ASCCONFIGURATORS-230 Fixed known issue: Transformer for AUTOSAR 4.0 Com configures signal invalid values and signal init values  $> 2^{53}-1$  incorrectly
- ▶ ASCCONFIGURATORS-250 Fixed known issue: `ComTxModeNumberOfRepetition` is not configured correctly for AUTOSAR 4.0.3 Com configurations
- ▶ ASCCONFIGURATORS-254 Fixed known issue: LinIf Transformer uses wrong set of PDUs for retrieval of TxPdu fan-out information

- ▶ ASCCONFIGURATORS-256 Fixed known issue: PduR Transformer cannot handle <any bus>-PDU to Ethernet-PDU gateway mappings
- ▶ ASCCONFIGURATORS-258 Fixed known issue: FrIf Transformer does not configure FrIfCluster.gdBit according to upstream mapping
- ▶ Implemented support for TP-SDUs referenced by multiple PDU triggerings
- ▶ Removed configuration of <Net>NmPnFilterMaskByte due to unclear upstream mapping rule
- ▶ Added pure gateway routing support

#### Module version 2.1.4

2012-10-12

- ▶ AUTOSAR 4.0 FrIf/FrNm: Added support for FrNm Rx PDU fan-in
- ▶ ASCCONFIGURATORS-230 Fixed known issue: Transformer for Com does not create GroupSignal if SignalTriggering is missing

#### Module version 2.1.3

2012-09-14

- ▶ AUTOSAR 4.0 Com: Added support for Com Rx Signal DataFilters
- ▶ AUTOSAR 4.0 Com: Adapted ComSignalType configuration: Special handling of type BOOLEAN

#### Module version 2.1.2

2012-08-17

- ▶ AUTOSAR 4.0 Com: User-defined prefix is added to group signal containers
- ▶ AUTOSAR 4.0 SoAd: Adapted according to configuration changes
- ▶ AUTOSAR 4.0 Nm: Adapted according to configuration changes
- ▶ AUTOSAR 4.0 Com: Adapted configuration of parameter ComSignalType according to AUTOSAR 4.-0 Rev 3 System Template

#### Module version 2.1.1

2012-06-15

- ▶ AUTOSAR 4.0 SoAd: Implemented configuration of SoAdSocketConnectionGroup containers

- ▶ AUTOSAR 4.0 Transformers: PDU Router fan-out support has been added

#### **Module version 2.1.0**

2012-05-16

- ▶ AUTOSAR 4.0 CanIf, CanTp: Adapted parameter configuration according to configuration changes in AUTOSAR 4.0 Rev 3

#### **Module version 2.0.6**

2012-04-13

- ▶ AUTOSAR 4.0 SoAd: Adaptation due to removed/obsolete parameter `SoAdPduHeaderEnable`

#### **Module version 2.0.5**

2012-03-27

- ▶ Added support for the configuration of partial networks for AUTOSAR 4.0 FrNm
- ▶ Integrated AUTOSAR 4.0 Transformers for modules SoAd, EthIf, Eth, TcpIp
- ▶ ASCCONFIGURATORS-187 Fixed known issue: AUTOSAR 4.0 Com: Fixed signal data type calculation algorithm

#### **Module version 2.0.4**

2012-02-17

- ▶ Removed obsolete AUTOSAR 3.x Transformers
- ▶ Added support for the configuration of partial networks for AUTOSAR 4.0 CanNm

#### **Module version 2.0.3**

2012-01-20

- ▶ Integrated AUTOSAR 4.0 Transformers for modules Lin, LinIf, and LinTp
- ▶ Added User Data Nm PDU support to the involved AUTOSAR 4.0 Transformers EcuC, PduR, Com, and CanNm, FrNm



### Module version 2.0.2

2011-10-12

- ▶ Integrated AUTOSAR 4.0 Transformers for modules Fr, FrIf, CanTp, CanNm, FrTp, FrNm, Nm
- ▶ ASCCONFIGURATORS-138 Fixed known issue: FrNm: Fixed Rx/Tx Nm PDU handling

### Module version 2.0.0

2011-09-02

- ▶ ASCCONFIGURATORS-86 Fixed known issue: IpduM: Transformer for AUTOSAR 3.x IpduM configures `IPduMTxSelectorValue`
- ▶ ASCCONFIGURATORS-85 Fixed known issue: IpduM, EcuC: Containers for Demultiplexed PDUs are only created if the Com module actually processes them
- ▶ Integrated AUTOSAR 4.0 Transformers for modules EcuC, Can, CanIf, IpduM, PduR, and Com

### Module version 1.1.2

2011-04-08

- ▶ ASCCONFIGURATORS-51 Fixed known issue: LinIf: Fixed references to EcuC PDU collection
- ▶ Improvement CanTp: Support configuration of multicast CanTp connection channels

### Module version 1.1.1

2011-03-11

- ▶ Improvement CanTp, CanIf, EcuC: Duplication of CanTp Tx N-PDUs has been introduced
- ▶ Improvement LinIf: Transformer configures `LinIfFramePriority` if provided via LDF importer
- ▶ Transformer for generic Nm was added
- ▶ Improvement Com: Support for zero bitsize signals has been added

### Module version 1.1.0

2011-02-03

- ▶ Requirements tracing: Resolve unmapped tests, unmapped requirements
- ▶ Improvement CanNm, FrNm, CanIf, LinIf, Com: Transformers use new Meta-Model 6/AUTOSAR 3.1.4 System parameters for module configuration

- ▶ Improvement CanIf, Can: Transformers use better naming schema for configuring HOH containers

#### **Module version 1.0.2**

2010-11-18

- ▶ ASCCONFIGURATORS-28 Fixed known issue: AUTOSAR 2.1/3.x Com: Com data types calculated correctly from integral system model data types with open ranges

#### **Module version 1.0.1**

2010-10-08

- ▶ Improvement AUTOSAR 3.x LinIf: Conditional frames obtain `LinIfInternalPdu` as `LinIfPduDirection` during com imports
- ▶ ASCCONFIGURATORS-22 Fixed known issue: AUTOSAR 2.1/3.x Com: Bit offsets and length parameters of signal groups are correctly exported

#### **Module version 1.0.0**

2010-09-10

- ▶ First implementation of Configurators

### **2.3.1.2. New features**

- ▶ No new features have been added since the last release.

### **2.3.1.3. EB-specific enhancements**

This module is not part of the AUTOSAR specification.

### **2.3.1.4. Deviations**

This module is not part of the AUTOSAR specification.

### 2.3.1.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

- ▶ `ComSignalInitValue/ComSignalDataInvalidValue` when importing from FIBEX

**Description:**

When importing from FIBEX, initial and invalid values that have been defined as bit pattern that represent `FLOAT` values are interpreted as integral values and written to `ComSignalInitValue/ComSignalDataInvalidValue` as such.

**Rationale:**

Initial and invalid values are defined as `INTERNAL-CONSTRS` in FIBEX, which requires these values to be integral values.

- ▶ `CanTpChannel/CanTpChannelMode` when importing from FIBEX

**Description:**

When importing from FIBEX, only elements of `CanTpChannel` that contain a single `CanTpRxNSdu/CanTpTxNSdu` are created. Also, the `CanTpChannelMode` of these elements `CanTpChannel` is always set to `CANTP_MODE_HALF_DUPLEX`.

**Rationale:**

FIBEX 3.x only supports a single `TP-CONNECTION` per `TP-CHANNEL`.

- ▶ `ISignal.dataTypePolicy:networkRepresentationFromComSpec` requires either a `SenderReceiverToSignalMapping` or a `SenderReceiverToSignalGroupMapping`

**Description:**

An `ISignal` that has `dataTypePolicy` set to `networkRepresentationFromComSpec` requires a `SenderReceiverToSignalMapping` or a `SenderReceiverToSignalGroupMapping`. These mapping elements reference a `PortPrototype` which contains a `PortComSpec` that defines the `NetworkRepresentation`. A `DataMapping` other than `SenderReceiverToSignalMapping` or `SenderReceiverToSignalGroupMapping` is not supported.

- ▶ `ISignal.dataTypePolicy: Data type retrieval via networkRepresentationFromComSpec` and `ImplementationDataType` is only supported for plain `ISignal` elements

**Description:**

In the AUTOSAR System Template 4.2 Rev 2, [TPS\_SYST\_02006] and [TPS\_SYST\_02079] describe the data type retrieval via `ImplementationDataType` in the case that no `SenderComSpec` or `Receiver-`

`ComSpec` is available. This is currently only implemented for plain signals, not for `ISignals` that represent group signals.

- ▶ `ComIPdu/ComIPduCounter` is not configured

Description:

`ComIPdu/ComIPduCounter` configuration containers are not configured even if the imported AUTOSAR System Description file contains `SIGNAL-I-PDU-COUNTER` elements.

Rationale:

The ACG Com module does not support `ComIPdu/ComIPduCounter` configuration containers.

- ▶ `ComIPdu/ComIPduReplication` is not configured

Description:

`ComIPdu/ComIPduReplication` configuration containers are not configured even if the imported AUTOSAR System Description file contains `SIGNAL-I-PDU-REPLICATION` elements.

Rationale:

The ACG Com module does not support `ComIPdu/ComIPduReplication` configuration containers.

- ▶ `ComIPdu` containers are not configured for TP SDUs

Description:

`ComIPdu` configuration containers are only configured for `SIGNAL-I-PDU` elements which are either related to `FRAME` elements or to `SOCKET-CONNECTION` elements. If an `SIGNAL-I-PDU` element is only related to `TP-CONNECTION` elements, it won't be configured in Com.

Rationale:

The ACG Com module does not support the processing of TP SDUs.

- ▶ `ComSignal/ComDataInvalidAction` and `ComSignalGroup/ComDataInvalidAction` are not configured

Description:

`ComSignal/ComDataInvalidAction` and `ComSignalGroup/ComDataInvalidAction` are not configured even if the imported system model contains `INVALIDATION-POLICY` elements.

Rationale:

The ACG Com module does not require `ComSignal/ComDataInvalidAction` or `ComSignalGroup/ComDataInvalidAction` for configuration code generation.

- ▶ `ComSignal/ComRxDataTimeoutAction` and `ComSignalGroup/ComRxDataTimeoutAction` are not configured

Description:

`ComSignal/ComRxDataTimeoutAction` and `ComSignalGroup/ComRxDataTimeoutAction` are not configured even if the imported system model contains `HANDLE-TIMEOUT-TYPE` elements.

Rationale:

The imported system model can contain two or more `HANDLE-TIMEOUT-TYPE` elements that are related to one and the same `ComSignal/ComRxDataTimeoutAction` or `ComSignalGroup/ComRxDataTimeoutAction` parameter. Since these `HANDLE-TIMEOUT-TYPE` elements may contain different values, a configuration is not possible.

- ▶ `FrController/FrFiFo` is not configured

Description:

`FrController/FrFiFo` configuration containers are not configured even if the imported AUTOSAR System Description file contains `FLEXRAY-FIFO-CONFIGURATION` elements.

Rationale:

Not all types of FlexRay communication controllers can be configured using the parameters provided in `FrController/FrFiFo`. It is therefore required to configure `FrController/FrFiFo` by hand, while taking into account the type of FlexRay communication controller that is in use.

- ▶ No support for tx fan-out of PDUs that are contained in `CONTAINER-I-PDU` elements

Description:

While the AUTOSAR System Template 4.2 Rev 1 indicates that PDUs contained in `CONTAINER-I-PDU` elements can be subject to a tx fan-out in the PduR module, the Transformer for PduR currently does not support this feature.

Rationale:

The tx fan-out support for contained PDUs requires a dedicated extension of the Transformer for PduR which has not yet been implemented.

- ▶ `AssignNAD` frames referencing Lin slave nodes which are not declared in the imported LDF file lead to import errors

Description:

During LDF imports, it is required that all `AssignNAD` frames in the LDF file reference Lin slave nodes which are also present in the file. If this is not the case, an error is issued.

Rationale:

The AUTOSAR System Model, which serves as internal data storage during the import, does not provide the possibility to store an `AssignNAD` frame without referencing the related slave node at the same time. Since the EB tresos Studio importer framework is built on top of the AUTOSAR System Model, this parameter cannot be configured.

### 2.3.1.6. Open-source software

Configurators does not use open-source software.

## 3. ECU Configuration Wizard user's guide

### 3.1. Overview

A configuration import consists of two steps. In the first step, one or more configuration files representing a system model - or an ECU extract thereof - are imported into the EB tresos Studio system model representation. In the second step the user selects one of the ECUs of the imported model for configuring a number of AUTOSAR modules in the EB tresos Studio project. Subsequently, the ECU relevant aspects of the imported system model are translated into AUTOSAR module configurations.

This part of the documentation describes the second importer step in more detail. For a description of the first importer step, see the EB tresos Studio user's guide.

- ▶ [Section 3.3, “Common mapping aspects”](#) describes general information that applies to the mapping between system model and AUTOSAR module configurations.
- ▶ [Section 3.4, “Importer parameter mappings for AUTOSAR 4.0 modules”](#) describes the mappings that are made between the system model and the respective AUTOSAR module configurations.

### 3.2. Background information

The chapter *Introduction* and the subchapter *Scope* in [\[3\]](#) provide the background information on the configuration of AUTOSAR modules out of a system model.

### 3.3. Common mapping aspects

This section contains some general information that applies to the mapping between system model and AUTOSAR module configurations.

#### 3.3.1. Naming rules

##### 3.3.1.1. Name mangling algorithm for importers

In AUTOSAR configuration files container names must be valid C-Identifiers and must have a length of at most 32 characters. The names of the containers must be unique within the context of the parent containers. In

order to ensure that all containers created during an import comply to the conditions above, object names are mangled.

Any characters violating the rules for valid C-Identifiers are replaced by underscores (`_`). In case a name exceeds 30 characters it is cut off and an underscore followed by a unique index is added so that the resulting name has a length of at most 30 characters and is unique. Since AUTOSAR allows a length of at most 32 characters, the importers can add prefixes which are at most two characters long without violating AUTOSAR naming rules, e.g. `SG` is added to normal signals, `NW` is added to network signals.

Examples:

- ▶ `TestName9012345678901234567890Foo` becomes `TestName90123456789012345678_1`
- ▶ `Test-Name9012345678901234567890Bar` becomes `TestName90123456789012345678_2`

---

#### NOTE



#### Automatic modification of the container names

If the check for the maximum container name length is disabled, the container names are mangled to 110 characters instead of 30. For further information on how to check the maximum container name length, see the EB tresos Studio documentation.

To avoid that your container name is modified automatically, enable the check for the maximum container name length. For further information on how to check the maximum container name length, see the EB tresos Studio documentation.

---

### 3.3.1.2. Name prefixing

Prior to import a prefix can be defined which is added to the `ShortName` of every imported container. The prefix menu line may be left empty if you do not wish a prefix.

The entered prefix is referred to as `<PREFIX>` in this document.

### 3.3.1.3. Instance handling

In AUTOSAR module configurations, instances of frames, PDUs, and signals are handled in different ways, depending on the network. Whereas for CAN and LIN configurations there is usually a one-to-one relationship between prototype and instance, this is usually not the case for FlexRay configurations:

FlexRay frames can be transmitted in multiple communication slots over the bus. One PDU may reside in more than one FlexRay frame. The `FlexRay Interface (FrIf)` handles this one-to-many relationship by always passing the same PDU to the upper layer (e.g. to the `PDU Router, PduR`) even if the PDU is received in different FlexRay communication slots and/or in different frames.

If an upper layer issues a transmit request for a PDU, the `FrIf` sends it in the next FlexRay communication slot that is assigned to a FlexRay frame, which contains the requested PDU.



FlexRay N-PDUs, i.e. PDUs that are processed by the `FlexRay Transport Layer (FrTp)`, must be handled differently by the `FrIf`. If a FlexRay N-PDU is transmitted in multiple frames and/or in multiple FlexRay communication slots, the `FrIf` processes each of the resulting PDU instances as an individual PDU.

If one and the same PDU is received on a given CAN network via two or more different CAN-IDs, the `CanIf` is set up to receive the PDU via a CAN-ID range that contains all the CAN-IDs via which the PDU is received. Since the `CanIf` does not support *standard* and *extended* CAN-IDs in one and the same CAN-ID range, an error is issued if such a configuration is imported. However, the range reception described here does not apply to N-PDUs or NM-PDUs.

Since every instance container of a configuration needs its unique name, and unique names are usually only provided for prototypes, the problem arises how to obtain unique container names for instances of the same prototype. EB tresos Studio provides an option by which the instance names are generated by appending a suffix to the name of the prototype. This guarantees that the instance name is unique.

FlexRay frames obtain different instance suffixes depending on whether they contain FlexRay N-PDUs or not. FlexRay N-PDUs obtain different suffixes than other FlexRay PDUs do. In the following text this is described in detail:

For FlexRay frames that contain N-PDUs, the following information is added to instances of frames:

- ▶ FlexRay identifier (1..2047)
- ▶ Channel information (A|B)
- ▶ Base cycle (0..63)
- ▶ Cycle repetition (1|2|4|8|16|32|64)
- ▶ Transmission direction information (T|R)

An instance of a frame *TestFrame*, received in slot 123, base cycle 10, cycle repetition 32 on channel A would therefore be called `TestFrame_123A1032R`.

If a FlexRay frame does not contain any N-PDU, only the transmission direction information is appended as suffix, e.g. The *TestFrame* above would be called `TestFrame_R`.

For CAN frames, the following information is added to instances of frames:

- ▶ CAN identifier (0..2<sup>29</sup>-1)
- ▶ Transmission direction information (T|R)

An instance of a frame *TestFrame*, received with CAN-ID 123 would therefore be called `TestFrame_123R`.

For LIN frames, the following information is added to instances of frames:

- ▶ LIN identifier (0..63)
- ▶ Transmission direction information (T|R)

Although a LIN frame/PDU can be sent or received in multiple schedule tables or even multiple times in the same schedule, the layer above only sees one instance of this frame/PDU. Therefore the schedule table and the entry position information has been left out in the instance suffix. An instance of a frame `TestFrame`, received with LIN-ID 23 would therefore be called `TestFrame_23R`.

The naming scheme for frame instances can also be applied to PDU instances. The instance of PDU `TestPdu`, which is sent in the frame instance `TestFrame_123R`, is named `TestPdu_123R`.

The naming scheme for signal instances adopts the naming scheme from the I-PDU instance in which it is contained. A signal instance of `TestSignal` transmitted in the PDU instance `TestPdu_123R` is called `TestSignal_123R`.

For an import run, add instance suffixes by checking the **Instance suffix for Frames, PDUs and Signals** checkbox.

If you import FlexRay networks, check the option checkbox to ensure that configuration containers obtain unique names. Since there is usually a one-to-one relationship between prototype and instance in CAN and LIN networks, an instance suffix is not required to obtain unique configuration container names. Uncheck the option checkbox if you import CAN and/or LIN networks to obtain short configuration container names.

Also note that the length of the container names grows considerably if the option is turned on. This usually makes it necessary to turn off the check for the maximum container name length. For instructions on how this check is turned off, see the EB tresos Studio user's guide.

The suffix is referred to by `<INSTSUFFIX>` in this document.

### 3.3.2. Signal offsets

Signals can be packed into PDUs either in big-endian or little-endian format. The endianness information, together with the signal offset parameter defines the bitset within the PDU which is occupied by a signal. Whereas the endianness of a signal within its enclosing PDU is an agreed upon notion, virtually every document format developed its own peculiar definition of the notion signal offset making an implicit offset conversion during import runs necessary.

For information on how the signal offset is defined, see the external document format specification and the AUTOSAR System Template specification.

### 3.3.3. Rx NM PDUs

If Rx NM PDUs are used, only the PDU which has the lowest CAN-ID is considered (per cluster) by the AUTOSAR 3.0/3.1 modules `CanIf`, `EcuC`, and `CanNm`.

### 3.3.4. Duplication of Tx N-PDU configuration containers

If the same outgoing N-PDU is used simultaneously by two `CanTp` connections, i.e. as data N-PDU by an outgoing connection and as flow-control N-PDU by an incoming connection, two configuration containers are created for this N-PDU in the AUTOSAR 3.0/3.1 modules `CanIf`, `EcuC`, and `CanTp`.

The name of the second N-PDU container is suffixed with `_D` and corresponds to the data N-PDU which is used by the outgoing `CanTp` connection.

### 3.3.5. PDU routing

An ECU routes a source PDU to one or more target PDUs if there is a gateway mapping which defines the routing paths from the source PDU to the target PDUs.

In this case, the source PDU is configured as an Rx PDU, and the target PDUs are configured as Tx PDUs in the modules `CanIf`, `FrIf`, `LinIf`, `SoAd`, `CanTp`, `FrTp`, `LinTp`, `DoIP`, `SecOC`, `IpduM`, and `EcuC`. The actual routing from source to destination PDUs is configured in the `PduR` module.

A PDU that is configured as a target PDU in a gateway mapping is not configured in any upper layer BSW module of the `PduR`. A sent `ISignalIPdu`, for instance, is not configured in `Com` if it is configured as a target PDU in a gateway mapping. The reason for that is that the `PduR` only allows one single source for the transmission of a PDU. The source can either be a local transmission request of any upper layer BSW module, e.g. `Com`, or it can be a received source PDU, the content of which is forwarded using the target PDU.

If there is a gateway mapping for a PDU that is related to a *cryptographic* PDU as described in [Section 3.4.36, "SecOC"](#), this gateway mapping either applies to the payload PDU or to the authenticated PDU, i.e. the PDU which `SecOC` exchanges with its upper layer module. If there is a gateway mapping for the *cryptographic* PDU as well, the payload PDU is configured to be routed. If there is no gateway mapping for the *cryptographic* PDU, the authenticated PDU is routed.

## 3.4. Importer parameter mappings for AUTOSAR 4.0 modules

### 3.4.1. Overview

The following chapters explain how system model parameters are mapped into AUTOSAR modules. For more in-depth information on how to invoke the importers for the different network communication formats, see the EB tresos Studio user's guide.

## ECU Extract to AUTOSAR parameter mapping

The **System Description Importer** of EB tresos Studio creates configurations for each of the following AUTOSAR modules.

For detailed configuration parameter descriptions, see the EB tresos AutoCore module references.

### 3.4.2. Can

Configuration parameters	Mapping description
CanConfigSet/Can-Controller	<p>For every CAN-COMMUNICATION-CONTROLLER that is connected to a CAN-CLUSTER and to the imported ECU-INSTANCE, a <b>CanController</b> container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the CAN-COMMUNICATION-CONTROLLER.</p> <p><b>CanControllerDefaultBaudrate</b> references the <b>CanControllerBaudrateConfig</b> container created for the CAN-COMMUNICATION-CONTROLLER. <b>CanControllerId</b> is configured in such a way that each <b>CanController</b> container obtains a unique <b>CanControllerId</b> value and the set of all <b>CanControllerId</b> values is zero-based and dense.</p>
CanConfigSet/Can-Controller/CanControllerBaudrateConfig	<p><b>CanControllerBaudRate</b> is set to BAUDRATE / 1000, as defined in the CAN-CLUSTER of the CAN-COMMUNICATION-CONTROLLER. If BAUDRATE is not available, <b>CanControllerBaudRate</b> is set to SPEED.</p> <p>The following parameters are set as defined in the CAN-CONTROLLER-CONFIGURATION of the CAN-COMMUNICATION-CONTROLLER:</p> <p><b>CanControllerPropSeg</b> is set to PROP-SEG.</p> <p><b>CanControllerSeg1</b> is set to TIME-SEG-1.</p> <p><b>CanControllerSeg2</b> is set to TIME-SEG-2.</p> <p><b>CanControllerSyncJumpWidth</b> is set to SYNC-JUMP-WIDTH.</p>
CanConfigSet/Can-Controller/CanControllerFdBaudrateConfig	<p>The container <b>CanControllerFdBaudrateConfig</b> is only created if CAN-FD-BAUDRATE contains a valid value. <b>CanControllerFdBaudRate</b> is set to CAN-FD-BAUDRATE / 1000, as defined in the CAN-CLUSTER of the CAN-COMMUNICATION-CONTROLLER.</p> <p>The following parameters are set as defined in the CAN-CONTROLLER-FD-ATTRIBUTES of the CAN-COMMUNICATION-CONTROLLER:</p> <p><b>CanControllerPropSeg</b> is set to PROP-SEG.</p>

Configuration parameters	Mapping description
	<p>CanControllerSeg1 is set to TIME-SEG-1.</p> <p>CanControllerSeg2 is set to TIME-SEG-2.</p> <p>CanControllerSyncJumpWidth is set to SYNC-JUMP-WIDTH.</p> <p>CanControllerTrcvDelayCompensationOffset [ns] is set to TRCV-DELAY-COMPENSATION-OFFSET [s].</p> <p>CanControllerTxBitRateSwitch is set to TX-BIT-RATE-SWITCH.</p>
CanConfigSet/Can-Controller/CanFilterMask	<p>CanFilterMask containers are only created for Can modules that conform to the AUTOSAR 4.0.3 standard.</p> <p>Two CanFilterMask containers are created for each CanController, named AcceptAllStd and AcceptAllExt. CanFilterMaskValue of theses containers is set to zero per default.</p> <p>If a parameter tag named canfiltermask.dontcarebit exists in the module's comtransformer extension point, which has its value attribute set to 1, CanFilterMaskValue is set to 0x7ff (AcceptAllStd) and 0xffffffff (AcceptAllExt) instead of zero.</p> <p>If a parameter tag named canfiltermask.std.shiftleft is defined in the module's comtransformer extension point, CanFilterMaskValue of AcceptAllStd is shifted left by the value defined in the value attribute.</p> <p>If a parameter tag named canfiltermask.ext.shiftleft is defined in the module's comtransformer extension point, CanFilterMaskValue of AcceptAllExt is shifted left by the value defined in the value attribute.</p>
CanConfigSet/Can-HardwareObject	<p>If <b>Buffer Assignment in Can/CanIf</b> was set to <b>Create default buffer assignment</b> during the import, CanHardwareObject containers are created for each CAN-COMMUNICATION-CONTROLLER connected to a CAN-CLUSTER of the imported ECU-INSTANCE. The container name depends on CAN-FRAME-RX-BEHAVIOR/CAN-FRAME-TX-BEHAVIOR and on CAN-ADDRESSING-MODE of the FRAME-TRIGGERING associated with the PDU which the ECU-INSTANCE sends or receives. The naming schema for every combination is displayed in <a href="#">Table 3.1, "Rx HOH container names depending on CAN-FRAME-RX-BEHAVIOR and CAN-ADDRESSING-MODE"</a> and <a href="#">Table 3.2, "Tx HOH container names depending on CAN-FRAME-TX-BEHAVIOR and CAN-ADDRESSING-MODE"</a>.</p> <p>CanIdType is set depending on the CAN-ADDRESSING-MODE of the FRAME-TRIGGERING elements the HOH containers have been created for. If CAN-AD-</p>

Configuration parameters	Mapping description
	<p>DRESSING-MODE is set to STANDARD or &lt;undefined&gt;, CanIdType is set to STANDARD. If CAN-ADDRESSING-MODE is set to EXTENDED, CanIdType is set to EXTENDED.</p> <p>CanObjectType is set depending on whether the ECU-INSTANCE sends or receives the FRAME-TRIGGERING elements for which the HOH containers were created. If FRAME-TRIGGERING elements are received, CanObjectType is set to RECEIVE. If FRAME-TRIGGERING elements are sent, CanObjectType is set to TRANSMIT.</p> <p>CanControllerRef references the CanController container created for the CAN-COMMUNICATION-CONTROLLER of the HOH.</p> <p>The CanFilterMaskRef reference parameter is only configured for Can modules that conform to the AUTOSAR 4.0.3 standard. It references a CanFilterMask container depending on the CAN-ADDRESSING-MODE of the FRAME-TRIGGERING for which the HOH containers have been created. HOH containers created for CAN-ADDRESSING-MODE STANDARD/&lt;undefined&gt; reference AcceptAllStd, HOH containers created for CAN-ADDRESSING-MODE EXTENDED reference AcceptAllExt.</p> <p>CanObjectId is configured according to <a href="#">Section 3.4.2.1, "CanObjectId configuration"</a>.</p> <p>CanHandleType is set to BASIC for all HOHs.</p> <p>CanFdPaddingValue is only configured for Can modules that conform to the AUTOSAR 4.2.2 standard. The value is set to CAN-COMMUNICATION-CONTROLLER/CAN-COMMUNICATION-CONTROLLER-VARIANTS/CAN-COMMUNICATION-CONTROLLER-CONDITIONAL/CAN-CONTROLLER-ATTRIBUTES/CAN-CONTROLLER-CONFIGURATION/CAN-CONTROLLER-FD-ATTRIBUTES/PADDING-VALUE or, if this parameter is not present, to CAN-COMMUNICATION-CONTROLLER/CAN-COMMUNICATION-CONTROLLER-VARIANTS/CAN-COMMUNICATION-CONTROLLER-CONDITIONAL/CAN-CONTROLLER-ATTRIBUTES/CAN-CONTROLLER-CONFIGURATION/CAN-CONTROLLER-FD-REQUIREMENTS/PADDING-VALUE.</p>
CanConfigSet/Can-HardwareObject/Can-HwFilter	<p>The CanHwFilter container is only created for Can modules that conform to the AUTOSAR 4.2.2 standard.</p> <p>CanHwFilterCode is configured to 0. CanHwFilterMask is configured to the filter mask value that allows that all CAN-IDs are received. The description of</p>

Configuration parameters	Mapping description
	CanConfigSet/CanController/CanFilterMask in <a href="#">Section 3.4.2, “Can”</a> provides the calculation formulas of these filter mask values.

CAN-ADDRESSING-MODE	STANDARD or <undefined>	EXTENDED
CAN-FRAME-RX-BEHAVIOR		
CAN-20 or <undefined>	HOH_0_<controller name>	HOH_1_<controller name>
CAN-FD	HOH_0_<controller name>	HOH_1_<controller name>
CAN-ANY	HOH_0_<controller name>	HOH_1_<controller name>

Table 3.1. Rx HOH container names depending on CAN-FRAME-RX-BEHAVIOR and CAN-ADDRESSING-MODE

CAN-ADDRESSING-MODE	STANDARD or <undefined>	EXTENDED
CAN-FRAME-TX-BEHAVIOR		
CAN-20 or <undefined>	HOH_2_<controller name>	HOH_3_<controller name>
CAN-FD	HOH_4_<controller name>	HOH_5_<controller name>

Table 3.2. Tx HOH container names depending on CAN-FRAME-TX-BEHAVIOR and CAN-ADDRESSING-MODE

### 3.4.2.1. CanObjectId configuration

The CanObjectId handle ID parameters of all CanHardwareObject containers are configured in such a way that each CanHardwareObject obtains a unique CanObjectId value and the set of all values is zero-based and dense. Moreover, the values are distributed in increasing order to the following:

- ▶ RECEIVE CanHardwareObject containers that reference the CanCommunicationController which has its CanControllerId set to 0.
- ▶ RECEIVE CanHardwareObject containers that reference the CanCommunicationController which has its CanControllerId set to 1.
- ▶ ...
- ▶ RECEIVE CanHardwareObject containers that reference the CanCommunicationController which has its CanControllerId set to <n - 1>.
- ▶ TRANSMIT CanHardwareObject containers that reference the CanCommunicationController which has its CanControllerId set to 0.
- ▶ TRANSMIT CanHardwareObject containers that reference the CanCommunicationController which has its CanControllerId set to 1.
- ▶ ...

- TRANSMIT CanHardwareObject containers that reference the CanCommunicationController which has its CanControllerId set to <n - 1>.

### 3.4.3. CanIf

Configuration parameters	Mapping description
CanIfCtrlDrvCfg	<p>If no CanIfCtrlDrvCfg container exists, a new one named &lt;PREFIX&gt;_CanIfCtrlDrvCfg is created. Otherwise the first existing container is used and the following parameters are set:</p> <p>CanIfCtrlDrvNameRef references the CanGeneral container in the Can driver module configuration.</p> <p>CanIfCtrlDrvInitHohConfigRef references the CanIfInitHohCfg container created during this import.</p>
CanIfCtrl- DrvCfg/CanIfCtrlCfg	<p>For every CAN-COMMUNICATION-CONTROLLER connected to a CAN-CLUSTER of the imported ECU-INSTANCE, a CanIfCtrlCfg container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the CAN-COMMUNICATION-CONTROLLER.</p> <p>CanIfCtrlCanCtrlRef references the corresponding CanController container in the Can driver module configuration.</p>
CanIfInitCfg	<p>If no CanIfInitCfg container exists, a new one named CanIfInitCfg is created. Otherwise the first existing container is used and the following sub containers are added:</p>
CanIfInitCfg/ CanIfInitHohCfg	<p>CanIfInitRefCfgSet references the CanConfigSet container in the Can driver module configuration.</p>
CanIfInitCfg/ CanIfInitHoh- Cfg/CanIfHrhCfg	<p>If <b>Buffer Assignment in Can/CanIf</b> has been set to <b>Create default buffer assignment</b> during the import, CanIfHrhCfg containers are created for each CAN-COMMUNICATION-CONTROLLER connected to a CAN-CLUSTER of the imported ECU-INSTANCE. The container name depends on the CAN-FRAME-RX-BEHAVIOR and on the CAN-ADDRESSING-MODE of the FRAME-TRIGGERING associated with the PDU which the ECU-INSTANCE receives. The naming schema for every combination is displayed in <a href="#">Table 3.1, "Rx HOH container names depending on CAN-FRAME-RX-BEHAVIOR and CAN-ADDRESSING-MODE"</a>.</p> <p>CanIfHrhCanCtrlIdRef references the CanIfCtrlCfg container created for the CAN-COMMUNICATION-CONTROLLER of the HOH.</p>



Configuration parameters	Mapping description
	CanIfHrhIdSymRef references the corresponding CanHardwareObject container in the Can driver module configuration.
CanIfInitCfg/ CanIfInitHohCfg/CanIfHthCfg	<p>If <b>Buffer Assignment in Can/CanIf</b> has been set to <b>Create default buffer assignment</b> during the import, CanIfHthCfg containers are created for each CAN-COMMUNICATION-CONTROLLER connected to a CAN-CLUSTER of the imported ECU-INSTANCE. The container name depends on the CAN-FRAME-TX-BEHAVIOR and on the CAN-ADDRESSING-MODE of the FRAME-TRIGGERING associated with the PDU which the ECU-INSTANCE sends. The naming schema for every combination is displayed in <a href="#">Table 3.2, “Tx HOH container names depending on CAN-FRAME-TX-BEHAVIOR and CAN-ADDRESSING-MODE”</a>.</p> <p>CanIfHthCanCtrlIdRef references the CanIfCtrlCfg container created for the CAN-COMMUNICATION-CONTROLLER of the HOH.</p> <p>CanIfHthIdSymRef references the corresponding CanHardwareObject container in the Can driver module configuration.</p>
CanIfInitCfg/ CanIfRxPduCfg	<p>For every PDU received or routed (see <a href="#">Section 3.3.5, “PDU routing”</a>) by the imported ECU-INSTANCE a CanIfRxPduCfg container is created.</p> <p>The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>The following kinds of PDUs are excluded from CanIfRxPduCfg container creation:</p> <ul style="list-style-type: none"> <li>▶ PDUs that are referenced in DYNAMIC-PARTS or STATIC-PARTS of MULTIPLEXED-I-PDU elements.</li> <li>▶ PDUs that are received within CONTAINER-I-PDU elements.</li> </ul> <p>If multiple NM-PDU elements are received via one CAN-CLUSTER, a CanIfRxPduCfg container is only created for the PDU with the lowest CAN-ID (defined either as IDENTIFIER or via RX-IDENTIFIER-RANGE). The range of CAN-IDs of all these NM-PDU elements is stored under CanIfRxPduCanIdRange.</p> <p>If the FRAME-TRIGGERING to which the PDU belongs defines an RX-IDENTIFIER-RANGE or the PDU is received via different FRAME-TRIGGERING elements yielding two or more CAN-ID values, a CanIfRxPduCanIdRange container is created as well.</p> <p>CanIfRxPduCanId is set to the CAN-ID of the PDU for which this CanIfRxPduCfg container has been created, if no CanIfRxPduCanIdRange contain-</p>

Configuration parameters	Mapping description
	<p>er has been created in the previous step. Otherwise this parameter is not configured.</p> <p>CanIfRxPduCanIdType is set depending on the values of CAN-ADDRESSING-MODE and CAN-FRAME-RX-BEHAVIOR. If CAN-FRAME-RX-BEHAVIOR is not available, CAN-20 is assumed as default value:</p> <ul style="list-style-type: none"> <li>▶ STANDARD_NO_FD_CAN for STANDARD and CAN-20</li> <li>▶ EXTENDED_NO_FD_CAN for EXTENDED and CAN-20</li> <li>▶ STANDARD_FD_CAN for STANDARD and CAN-FD</li> <li>▶ EXTENDED_FD_CAN for EXTENDED and CAN-FD</li> <li>▶ STANDARD_CAN for STANDARD and ANY</li> <li>▶ EXTENDED_CAN for EXTENDED and ANY</li> </ul> <p>CanIfRxPduHrhIdRef references the CanIfHrhCfg container created for CAN-FRAME-TRIGGERING elements with these CAN-ADDRESSING-MODE and CAN-FRAME-RX-BEHAVIOR values (see <a href="#">Section 3.4.2, “Can”</a>, CanHardware-Object).</p> <p>If CAN-ADDRESSING-MODE is undefined, CanIfRxPduHrhIdRef is not configured either.</p> <p>CanIfRxPduRef references the corresponding container in the EcuC module configuration.</p> <p>CanIfRxPduUserRxIndicationUL is set depending on the type of PDU:</p> <ul style="list-style-type: none"> <li>▶ CAN_NM for NM-PDU elements.</li> <li>▶ CAN_TP for N-PDU elements that are not routed via gateway.</li> <li>▶ CAN_TSYN for GENERAL-PURPOSE-PDU elements with its CATEGORY parameter set to GLOBAL_TIME.</li> <li>▶ PDUR for I-SIGNAL-PDU elements, MULTIPLEXED-I-PDU elements, CONTAINER-I-PDU elements, GENERAL-PURPOSE-I-PDU elements, DCM-I-PDU elements, for USER-DEFINED-I-PDU elements, which either have a CATEGORY other than XCP or are routed, and for N-PDU elements that are routed (see <a href="#">Section 3.3.5, “PDU routing”</a>).</li> <li>▶ XCP for XCP-PDU elements.</li> <li>▶ CDD for received USER-DEFINED-I-PDU elements that have their CATEGORY set to XCP and for all other PDU types.</li> </ul>

Configuration parameters	Mapping description
CanIfInitCfg/ CanIfRxPduCfg/ CanIfRxPduCanIdRange	<p>CanIfRxPduCanIdRangeLowerCanId is set to the CAN-ID of the PDU for which this CanIfRxPduCfg container has been created, or to LOWER-CAN-ID of the RX-IDENTIFIER-RANGE.</p> <p>CanIfRxPduCanIdRangeUpperCanId is set to the highest CAN-ID of all NM-PDU elements received via the CAN-CLUSTER, or to UPPER-CAN-ID of the RX-IDENTIFIER-RANGE.</p> <p>For CanIfRxPduCanIdRange elements created for received NM-PDU elements a consistency check is performed:</p> <p>In case a CAN-NM-NODE belonging to the imported ECU-INSTANCE exists, which defines a different range via CAN-NM-RANGE-CONFIG, this range overrides the range determined via the NM-PDU elements. If this range is narrower than the range as determined via the NM-PDU elements, a warning is reported.</p>
CanIfInitCfg/ CanIfTxPduCfg	<p>For every PDU sent or routed (see <a href="#">Section 3.3.5, "PDU routing"</a>) by the imported ECU-INSTANCE a CanIfTxPduCfg container is created.</p> <p>The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>The following kinds of PDUs are excluded from CanIfTxPduCfg container creation:</p> <ul style="list-style-type: none"> <li>► PDUs that are referenced in DYNAMIC-PARTS or STATIC-PARTS of MULTIPLEXED-I-PDU elements.</li> <li>► PDUs that are sent within CONTAINER-I-PDU elements.</li> </ul> <p>If a sent N-PDU is referenced by two CAN-TP-CONNECTION elements, a second CanIfTxPduCfg container is created. The Tx CAN-TP-CONNECTION must reference this N-PDU via DATA-PDU-REF, the Rx CAN-TP-CONNECTION via FLOW-CONTROL-PDU-REF. The direction of the CAN-TP-CONNECTION is determined by the PDU referenced by TP-SDU-REF. The container name of the second CanIfTxPduCfg container is &lt;PREFIX&gt;&lt;name&gt;_D&lt;INSTSUFFIX&gt;.</p> <p>CanIfTxPduDlc is set to the LENGTH of the PDU in bytes.</p> <p>CanIfTxPduCanId is set to the CAN-ID of the PDU for which this CanIfTxPduCfg container has been created.</p>

Configuration parameters	Mapping description
	<p><code>CanIfTxPduCanIdType</code> is set depending on the values of <code>CAN-ADDRESSING-MODE</code> and <code>CAN-FRAME-TX-BEHAVIOR</code>. If <code>CAN-FRAME-TX-BEHAVIOR</code> is not available, <code>CAN-20</code> is assumed as default value:</p> <p><code>CanIfTxPduBufferRef</code> references the <code>CanIfBufferCfg</code> container created for <code>CAN-FRAME-TRIGGERING</code> elements with these <code>CAN-ADDRESSING-MODE</code> and <code>CAN-FRAME-TX-BEHAVIOR</code> values.</p> <ul style="list-style-type: none"> <li>▶ <code>STANDARD_CAN</code> for <code>STANDARD</code> and <code>CAN-20</code></li> <li>▶ <code>EXTENDED_CAN</code> for <code>EXTENDED</code> and <code>CAN-20</code></li> <li>▶ <code>STANDARD_FD_CAN</code> for <code>STANDARD</code> and <code>CAN-FD</code></li> <li>▶ <code>EXTENDED_FD_CAN</code> for <code>EXTENDED</code> and <code>CAN-FD</code></li> </ul> <p><code>CanIfTxPduHthIdRef</code> references the <code>CanIfHthCfg</code> container created for <code>CAN-FRAME-TRIGGERING</code> elements with these <code>CAN-ADDRESSING-MODE</code> and <code>CAN-FRAME-TX-BEHAVIOR</code> values (see <a href="#">Section 3.4.2, “Can”</a>, <code>CanHardware-Object</code>).</p> <p>If <code>CAN-ADDRESSING-MODE</code> is undefined, <code>CanIfTxPduHthIdRef</code> is not configured either.</p> <p><code>CanIfTxPduRef</code> references the corresponding container in the <code>EcuC</code> module configuration.</p> <p><code>CanIfTxPduUserTxConfirmationUL</code> is set depending on the type of PDU:</p> <ul style="list-style-type: none"> <li>▶ <code>CAN_NM</code> for <code>NM-PDU</code> elements.</li> <li>▶ <code>CAN_TP</code> for <code>N-PDU</code> elements that are not routed via gateway.</li> <li>▶ <code>CAN_TSYN</code> for <code>GENERAL-PURPOSE-PDU</code> elements with its <code>CATEGORY</code> parameter set to <code>GLOBAL_TIME</code>.</li> <li>▶ <code>PDUR</code> for <code>I-SIGNAL-PDU</code> elements, <code>MULTIPLEXED-I-PDU</code> elements, <code>CONTAINER-I-PDU</code> elements, <code>GENERAL-PURPOSE-I-PDU</code> elements, <code>DCM-I-PDU</code> elements, for <code>USER-DEFINED-I-PDU</code> elements, which either have a <code>CATEGORY</code> other than <code>XCP</code> or are routed, and for <code>N-PDU</code> elements that are routed. For more information, see <a href="#">Section 3.3.5, “PDU routing”</a>.</li> <li>▶ <code>CDD</code> for sent <code>USER-DEFINED-I-PDU</code> elements that have their <code>CATEGORY</code> set to <code>XCP</code> and for all other PDU types.</li> </ul>
<code>CanIfInitCfg/CanIf-BufferCfg</code>	<p>If <b>Buffer Assignment in Can/CanIf</b> was set to <b>Create default buffer assignment</b> during the import, <code>CanIfBufferCfg</code> containers are created for each <code>CAN-COMMUNICATION-CONTROLLER</code> connected to a <code>CAN-CLUSTER</code> of the im-</p>

Configuration parameters	Mapping description
	<p>ported ECU-INSTANCE. The container name depends on the CAN-FRAME-TX-BEHAVIOR and on the CAN-ADDRESSING-MODE of the FRAME-TRIGGERING associated with the PDU which the ECU-INSTANCE sends. The naming schema for every combination is displayed in <a href="#">Table 3.2, "Tx HOH container names depending on CAN-FRAME-TX-BEHAVIOR and CAN-ADDRESSING-MODE"</a>.</p> <p>CanIfBufferHthRef references the CanIfInitHohCfg/CanIfHthCfg container created for the CAN-FRAME-TRIGGERING elements with these CAN-ADDRESSING-MODE and CAN-FRAME-TX-BEHAVIOR values.</p>

### 3.4.4. CanNm

Configuration parameters	Mapping description
CanNmGlobalConfig	<p>CanNmComUserDataSupport is set to true if CanNmRxUserDataPduRef or CanNmTxUserDataPduRef is set for any CanNmChannelConfig, or if any CAN-NM-CLUSTER linked to the imported ECU-INSTANCE has its NM-PNC-PARTICIPATION either not defined or set to true. Otherwise CanNmComUserDataSupport is set to false.</p> <p>CanNmPnResetTime is set to PN-RESET-TIME of the configured ECU-INSTANCE.</p> <p>The following parameters are set using the first NM-ECU of the imported ECU-INSTANCE:</p> <p>CanNmUserDataEnabled is set to NM-USER-DATA-ENABLED.</p> <p>CanNmRemoteSleepIndEnabled is set to NM-REMOTE-SLEEP-IND-ENABLED.</p> <p>CanNmBusSynchronizationEnabled is set to NM-BUS-SYNCHRONIZATION-ENABLED.</p> <p>CanNmStateChangeIndEnabled is set to NM-STATE-CHANGE-IND-ENABLED.</p> <p>CanNmPassiveModeEnabled is set to NM-PASSIVE-MODE-ENABLED. If this parameter is not available, CanNmPassiveModeEnabled is set depending on NM-PASSIVE-MODE-ENABLED of all NM-NODES belonging to the imported ECU-INSTANCE:</p>

Configuration parameters	Mapping description
	<p> <ul style="list-style-type: none"> <li>▶ false if at least one NM-NODE has NM-PASSIVE-MODE-ENABLED set to false.</li> <li>▶ true if all NM-NODE elements have NM-PASSIVE-MODE-ENABLED set to true.</li> </ul> </p> <p>Otherwise CanNmPassiveModeEnabled is not set.</p> <p>CanNmPduRxIndicationEnabled is set to NM-PDU-RX-INDICATION-ENABLED.</p> <p>CanNmComControlEnabled is set to NM-COM-CONTROL-ENABLED.</p> <p>CanNmMainFunctionPeriod is set to NM-CYCLETIME-MAIN-FUNCTION.</p> <p>If inconsistencies are detected among parameters of multiple NM-ECU elements, a warning is reported.</p> <p>The following parameters are set using the first CAN-NM-CLUSTER-COUPLING of all CAN-NM-CLUSTER elements connected to the imported ECU-INSTANCE:</p> <p>CanNmBusLoadReductionEnabled is set to NM-BUS-LOAD-REDUCTION-ENABLED.</p> <p>CanNmImmediateRestartEnabled is set to NM-IMMEDIATE-RESTART-ENABLED.</p> <p>If inconsistencies are detected among parameters of multiple CAN-NM-CLUSTER-COUPLING elements, a warning is reported.</p> <p>If a CAN-NM-CLUSTER configured as partial networking cluster (PNC) (see <a href="#">Section 3.4.13, "EcuC"</a>) belongs to the imported ECU-INSTANCE, the following parameters are set:</p> <p>CanNmPnEiraRxNSduRef references the corresponding container in the EcuC module configuration.</p> <p>CanNmPnEiraCalcEnabled is set to true.</p> <p>CanNmPnInfo/CanNmPnInfoOffset is set to PNC-VECTOR-OFFSET. If PNC-VECTOR-OFFSET is not defined, a warning is issued and CanNmPnInfoOffset is not set.</p>

Configuration parameters	Mapping description
	<p>CanNmPnInfo/CanNmPnInfoLength is set to PNC-VECTOR-LENGTH. If PNC-VECTOR-LENGTH is not defined, a warning is issued and CanNmPnInfoLength is not set.</p> <p>The values for CanNmPnFilterMaskByte are calculated as follows:</p> <p>In a first step the PNC-WAKEUP-DATA-MASK values of all CAN-COMMUNICATION-CONNECTOR elements that belong to the imported ECU-INSTANCE and a PHYSICAL-CHANNEL of the CAN-NM-CLUSTER's CAN-CLUSTER are retrieved. In the PNC vector which is a 64 bit entity, all bits that lie on any collected PNC-WAKEUP-DATA-MASK position are set to true, while all other bits are set to false. The resulting value is shifted to the right by PNC-VECTOR-OFFSET * 8 bit positions and thus removing the leading empty bits in the PNC vector. Finally, the value is converted into an n-byte byte array, (n corresponding to PNC-VECTOR-LENGTH).</p> <p>A CanNmPnFilterMaskByte container is created for each byte. CanNmPnFilterMaskByteValue is set to the value of the byte and CanNmPnFilterMaskByteIndex to the position of the byte within the array. In this array CanNmPnFilterMaskByteIndex of the PNC vector LSB is set to 0 and the CanNmPnFilterMaskByteIndex of the MSB is set to PNC-VECTOR-LENGTH - 1.</p>
CanNmChannelConfig	<p>For every CAN-NM-CLUSTER which belongs to the imported ECU-INSTANCE, and over which at least one NM-PDU is sent or received, a CanNmChannelConfig container is created.</p> <p>The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the CAN-NM-CLUSTER.</p> <p>A CAN-NM-CLUSTER belongs to the imported ECU-INSTANCE if at least one of its CAN-NM-NODE elements references a CAN-COMMUNICATION-CONTROLLER of this ECU-INSTANCE.</p> <p>The NM-ECU used for configuring some of the CanNmChannelConfig parameters is the NM-ECU which the first CAN-NM-NODE references via NM-IF-ECU-REF.</p> <p>In case the ECU-INSTANCE does not send or receive any NM-PDU on the CAN-NM-CLUSTER, or it sends multiple NM-PDU elements on the CAN-NM-CLUSTER, a warning is reported.</p>

Configuration parameters	Mapping description
	<p>CanNmNodeDetectionEnabled is set to NM-CLUSTER/NM-NODE-DETECTION-ENABLED, or to NM-ECU/NM-NODE-DETECTION-ENABLED if NM-CLUSTER/NM-NODE-DETECTION-ENABLED is not available.</p> <p>CanNmNodeIdEnabled is set to NM-CLUSTER/NM-NODE-ID-ENABLED, or to NM-ECU/NM-NODE-ID-ENABLED if NM-CLUSTER/NM-NODE-ID-ENABLED is not available.</p> <p>CanNmRepeatMsgIndEnabled is set to NM-CLUSTER/NM-REPEAT-MSG-IND-ENABLED, or to NM-ECU/NM-REPEAT-MSG-IND-ENABLED if NM-CLUSTER/NM-REPEAT-MSG-IND-ENABLED is not available.</p> <p>CanNmBusLoadReductionActive is set to NM-BUSLOAD-REDUCTION-ACTIVE.</p> <p>CanNmTimeoutTime is set to NM-NETWORK-TIMEOUT.</p> <p>CanNmWaitBusSleepTime is set to NM-WAIT-BUS-SLEEP-TIME.</p> <p>CanNmRepeatMessageTime is set to NM-REPEAT-MESSAGE-TIME.</p> <p>CanNmRemoteSleepIndTime is set to NM-REMOTE-SLEEP-INDICATION-TIME.</p> <p>CanNmUserDataLength is calculated by the formula <math>NM-PDU/LENGTH - \langle NonUserDataLength \rangle</math> where <math>\langle NonUserDataLength \rangle</math> denotes the byte length of the non-user data part of the NM-PDU which is calculated by <math>\max(CAN-NM-CLUSTER/NM-CBV-POSITION, CAN-NM-CLUSTER/NM-NID-POSITION) + 1</math>. If neither CAN-NM-CLUSTER/NM-CBV-POSITION nor CAN-NM-CLUSTER/NM-NID-POSITION are defined, <math>\langle NonUserDataLength \rangle</math> is zero.</p> <p>CanNmMsgCycleTime is set to NM-MSG-CYCLE-TIME.</p> <p>CanNmMsgTimeoutTime is set to NM-MESSAGE-TIMEOUT-TIME.</p> <p>CanNmImmediateNmTransmissions is set to NM-IMMEDIATE-NM-TRANSMISSIONS.</p> <p>CanNmImmediateNmCycleTime is set to NM-IMMEDIATE-NM-CYCLE-TIME.</p> <p>CanNmComMNetworkHandleRef references the ComMChannel container that is created for the COMMUNICATION-CLUSTER referenced in COMMUNICATION-CLUSTER-REF.</p> <p>CanNmPduNidPosition is set depending on the value of NM-NID-POSITION:</p>



Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ <code>CANNM_PDU_BYTE_0</code> for 0.</li> <li>▶ <code>CANNM_PDU_BYTE_1</code> for 1.</li> <li>▶ <code>CANNM_PDU_OFF</code> for any other value.</li> </ul> <p><code>CanNmPduCbvPosition</code> is set depending on the value of <code>NM-CBV-POSITION</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>CANNM_PDU_BYTE_0</code> for 0.</li> <li>▶ <code>CANNM_PDU_BYTE_1</code> for 1.</li> <li>▶ <code>CANNM_PDU_OFF</code> for any other value.</li> </ul> <p><code>CanNmRxPdu/&lt;EcuC container name&gt;/CanNmRxPduRef</code> references the container in the <code>EcuC</code> module which has been created for the <code>NM-PDU</code> referenced via <code>RX-NM-PDU-REFS/RX-NM-PDU-REF</code>, which has the lowest <code>CAN-ID</code> assigned. <code>&lt;EcuC container name&gt;</code> is the name of the referenced <code>EcuC</code> container.</p> <p>If an <code>NmUserDataPdu</code> container has been created for the received <code>NM-PDU</code> in the <code>EcuC</code> module configuration (see <a href="#">Section 3.4.13, "EcuC"</a>), <code>CanNmUserDataRxPdu/CanNmRxUserDataPduRef</code> references this container. The name of <code>CanNmUserDataRxPdu</code> is set to the name of the referenced <code>EcuC</code> container.</p> <p><code>CanNmTxPdu/CanNmTxPduRef</code> references the container in the <code>EcuC</code> module which has been created for the first <code>NM-PDU</code> referenced via <code>TX-NM-PDU-REFS/TX-NM-PDU-REF</code>. The name of <code>CanNmTxPdu</code> is set to the name of the referenced <code>EcuC</code> container.</p> <p>If an <code>NmUserDataPdu</code> container has been created for the sent <code>NM-PDU</code> in the <code>EcuC</code> module configuration, see <a href="#">Section 3.4.13, "EcuC"</a>, <code>CanNmUserDataTxPdu/CanNmTxUserDataPduRef</code> references this container. The name of <code>CanNmUserDataTxPdu</code> is set to the name of the referenced <code>EcuC</code> container.</p> <p>If no Rx or Tx <code>NM-PDU</code> elements are referenced, or if multiple Tx <code>NM-PDU</code> elements are referenced, a warning is reported.</p> <p>If an ERA PDU container has been created for the <code>CAN-NM-CLUSTER</code> in the <code>EcuC</code> module (see <a href="#">Section 3.4.13, "EcuC"</a>), <code>CanNmPnEraRxNSduRef</code> references the <code>EcuC</code> container and <code>CanNmPnEraCalcEnabled</code> is set to <code>true</code>.</p> <p>The following parameters are set using the first <code>NM-NODE</code> of the <code>CAN-NM-CLUSTER</code> connected to the imported <code>ECU-INSTANCE</code>. If inconsistencies are detected among parameters of multiple <code>NM-NODE</code> elements, a warning is reported.</p>

Configuration parameters	Mapping description
	<p><code>CanNmMsgCycleOffset</code> is set to <code>NM-MSG-CYCLE-OFFSET</code>.</p> <p><code>CanNmMsgReducedTime</code> is set to <code>NM-MSG-REDUCED-TIME</code>.</p> <p><code>CanNmNodeId</code> is set to <code>NM-NODE-ID</code>.</p> <p><code>CanNmPnEnabled</code> is set to <code>true</code> if the <code>CAN-NM-CLUSTER</code> is PNC-enabled, or if it has its <code>NM-PNC-PARTICIPATION</code> either not defined or set to <code>true</code>. Otherwise <code>CanNmPnEnabled</code> is set to <code>false</code>.</p> <p>If the <code>CAN-NM-CLUSTER</code> is PNC-enabled, the following parameters are set:</p> <p><code>CanNmCarWakeUpRxEnabled</code> is set to <code>NM-CAR-WAKE-UP-RX-ENABLED</code>.</p> <p><code>CanNmCarWakeUpFilterEnabled</code> is set to <code>NM-CAR-WAKE-UP-FILTER-ENABLED</code>.</p> <p><code>CanNmCarWakeUpFilterNodeId</code> is set to <code>NM-CAR-WAKE-UP-FILTER-NODE-ID</code>.</p> <p><code>CanNmCarWakeUpBitPosition</code> is set to <code>NM-CAR-WAKE-UP-BIT-POSITION mod 8</code>.</p> <p><code>CanNmCarWakeUpBytePosition</code> is set to <code>NM-CAR-WAKE-UP-BIT-POSITION div 8</code>.</p>

### 3.4.5. CanSM

Configuration parameters	Mapping description
<code>CanSMConfiguration/CanSMManagerNetwork</code>	<p>For every <code>CAN-CLUSTER</code> which belongs to the imported <code>ECU-INSTANCE</code>, a <code>CanSMManagerNetwork</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>CAN-CLUSTER</code>.</p> <p><code>CanSMComMNetworkHandleRef</code> references the <code>ComMChannel</code> container in the <code>ComM</code> module configuration, which has been created for the <code>CAN-CLUSTER</code>.</p>
<code>CanSMConfiguration/CanSMManagerNetwork/CanSMController</code>	<p>For every <code>CAN-COMMUNICATION-CONTROLLER</code> that is connected to the <code>CAN-CLUSTER</code> and to the imported <code>ECU-INSTANCE</code>, a <code>CanSMController</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>CAN-COMMUNICATION-CONTROLLER</code>.</p>

Configuration parameters	Mapping description
	CanSMControllerId references the CanIfCtrlCfg container in the CanIf module configuration, which has been created for the CAN-COMMUNICATION-CONTROLLER.

### 3.4.6. CanTp

Configuration parameters	Mapping description
CanTpConfig	CanTpMainFunctionPeriod is set to CYCLE-TIME-MAIN-FUNCTION of the first CAN-TP-ECU which belongs to the imported ECU-INSTANCE. If inconsistencies are detected among the CYCLE-TIME-MAIN-FUNCTION values of multiple CAN-TP-ECU elements of the imported ECU-INSTANCE, a warning is reported.
CanTpConfig/CanTpChannel	<p>For each CAN-TP-CHANNEL referenced by a CAN-TP-CONNECTION which belongs to the imported ECU-INSTANCE, a CanTpChannel container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the CAN-TP-CHANNEL. A CAN-TP-CONNECTION belongs to the imported ECU-INSTANCE if at least one transmitting or receiving CAN-TP-NODE of this CAN-TP-CONNECTION references a COMMUNICATION-CONNECTOR which is also referenced by the imported ECU-INSTANCE.</p> <p>CanTpChannelMode is set depending on the value of CHANNEL-MODE:</p> <ul style="list-style-type: none"> <li>▶ CANTP_MODE_FULL_DUPLEX for FULLDUPLEXMODE.</li> <li>▶ CANTP_MODE_HALF_DUPLEX for HALFDUPLEXMODE.</li> </ul>
CanTpConfig/CanTpChannel/CanTpRxNSdu	<p>For every CAN-TP-CONNECTION referencing the current CAN-TP-CHANNEL, a CanTpRxNSdu container is created, if the PDU referenced via TP-SDU-REF is received or routed (see <a href="#">Section 3.3.5, "PDU routing"</a>) by the imported ECU-INSTANCE. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the referenced PDU.</p> <p>CanTpRxNSduRef references the container in the EcuC module configuration, created for the referenced PDU.</p> <p>CanTpNTa/CanTpNTa is set to TP-ADDRESS of the CAN-TP-ADDRESS referenced via MULTICAST-REF. If no MULTICAST-REF exists, the CAN-TP-ADDRESS of the first CAN-TP-NODE (if more than one exists, a warning is issued) referenced via RECEIVER-REFS is used. Furthermore, CanTpNTa is only set if ADDRESSING-FORMAT of the CAN-TP-CONNECTION is set to EXTENDED.</p>

Configuration parameters	Mapping description
	<p>CanTpNSa/CanTpNSa is set to TP-ADDRESS of the CAN-TP-ADDRESS referenced by the CAN-TP-NODE referenced via TRANSMITTER-REF. CanTpNSa is only set if ADDRESSING-FORMAT of the CAN-TP-CONNECTION is set to EXTENDED.</p> <p>CanTpNAe/CanTpNAe is set to TP-ADDRESS-EXTENSION-VALUE of the CAN-TP-ADDRESS referenced via MULTICAST-REF. If no MULTICAST-REF exists, the CAN-TP-ADDRESS of the first CAN-TP-NODE referenced via RECEIVER-REFS is used. Additionally the same TP-ADDRESS-EXTENSION-VALUE must exist for the CAN-TP-NODE referenced via TRANSMITTER-REF. Otherwise a warning is issued and the parameter is not set. This parameter is only configured if ADDRESSING-FORMAT of the CAN-TP-CONNECTION is set to MIXED.</p> <p>CanTpRxPaddingActivation is set to CANTP_ON if PADDING-ACTIVATION is set to true, or to CANTP_OFF if PADDING-ACTIVATION is set to false.</p> <p>CanTpRxTaType is set depending on the value of TA-TYPE:</p> <ul style="list-style-type: none"> <li>▶ CANTP_FUNCTIONAL for CANTP-FUNCTIONAL.</li> <li>▶ CANTP_PHYSICAL for CANTP-PHYSICAL.</li> </ul> <p>If TA-TYPE is not available CanTpRxTaType is set to CANTP_FUNCTIONAL if a CAN-TP-ADDRESS referenced via MULTICAST-REF exists, or if more than one CAN-TP-CONNECTION elements references the same PDU via TP-SDU-REF. In all other cases, it is set to CANTP_PHYSICAL.</p> <p>CanTpRxAddressingFormat is set depending on the value of ADDRESSING-FORMAT:</p> <ul style="list-style-type: none"> <li>▶ CANTP_STANDARD for STANDARD.</li> <li>▶ CANTP_EXTENDED for EXTENDED.</li> <li>▶ CANTP_MIXED for MIXED.</li> </ul> <p>CanTpBs is set to MAX-BLOCK-SIZE.</p> <p>CanTpNbr is set to TIMEOUT-BR.</p> <p>CanTpNcr is set to TIMEOUT-CR.</p> <p>If no MULTICAST-REF exists, and if exactly one CAN-TP-NODE is referenced via RECEIVER-REFS, the following parameters are set using this CAN-TP-NODE.</p>

Configuration parameters	Mapping description
	<p>CanTpRxWftMax is set to MAX-FC-WAIT.</p> <p>CanTpNar is set to TIMEOUT-AR.</p> <p>CanTpSTmin is set to ST-MIN .</p>
CanTpConfig/CanTpChannel/CanTpRxNSdu/CanTpRxNPdu	<p>A CanTpRxNPdu container is created for the N-PDU referenced via DATA-PDU-REF. If no DATA-PDU-REF exists, a warning is issued. The name of CanTpRxNPdu is set to &lt;SDU name&gt;_&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;SDU name&gt; is the name of the parent CanTpRxNSdu container and &lt;name&gt; is the SHORT-NAME of the N-PDU.</p> <p>CanTpRxNPduRef references the corresponding container in the EcuC module configuration.</p>
CanTpConfig/CanTpChannel/CanTpRxNSdu/CanTpTxFcNPdu	<p>A CanTpTxFcNPdu container is created for the N-PDU referenced via FLOW-CONTROL-PDU-REF. The name of CanTpTxFcNPdu is set to &lt;SDU name&gt;_&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;SDU name&gt; is the name of the parent CanTpRxNSdu container and &lt;name&gt; is the SHORT-NAME of the N-PDU.</p> <p>CanTpTxFcNPduRef references the corresponding container in the EcuC module configuration.</p>
CanTpConfig/CanTpChannel/CanTpTxNSdu	<p>For every CAN-TP-CONNECTION referencing the current CAN-TP-CHANNEL, a CanTpTxNSdu container is created, if the PDU referenced via TP-SDU-REF is sent or routed (see <a href="#">Section 3.3.5, “PDU routing”</a>) by the imported ECU-INSTANCE. The container name is &lt;SDU name&gt;_&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;SDU name&gt; is the name of the parent CanTpTxNSdu container and &lt;name&gt; is the SHORT-NAME of the referenced PDU.</p> <p>In case multiple CAN-TP-CONNECTION elements refer to the same PDU via TP-SDU-REF, only one CanTpTxNSdu container is created and the following parameters of the CAN-TP-CONNECTION are checked for consistency: DATA-PDU-REF, FLOW-CONTROL-PDU-REF, ADDRESSING-FORMAT, PADDING-ACTIVATION, TRANSMITTER-REF. If inconsistencies are detected a warning is issued and the first CAN-TP-CONNECTION is used for the subsequent operations.</p> <p>CanTpTxNSduRef: see CanTpRxNSdu/CanTpRxNSduRef.</p> <p>CanTpNTa: see CanTpRxNSdu/CanTpNTa. If multiple CAN-TP-CONNECTION elements refer to the same PDU via TP-SDU-REF, and the TP-ADDRESS values of the first CAN-TP-NODE of each CAN-TP-CONNECTION referenced via RECEIVER-REF differ, CanTpNTa is not set.</p>

Configuration parameters	Mapping description
	<p>CanTpNSa: <b>see</b> CanTpRxNSdu/CanTpNSa.</p> <p>CanTpNAe: <b>see</b> CanTpRxNSdu/CanTpNAe.</p> <p>CanTpTxPaddingActivation: <b>see</b> CanTpRxNSdu/CanTpRxPaddingActivation.</p> <p>CanTpTxTaType: <b>see</b> CanTpRxNSdu/CanTpRxTaType.</p> <p>CanTpNbs is set to TIMEOUT-BS.</p> <p>CanTpNcs is set to TIMEOUT-CS.</p> <p>CanTpTc is set to CANCELLATION.</p> <p>CanTpNas is set to TIMEOUT-AS of the CAN-TP-NODE referenced via TRANSMITTER-REF.</p>
CanTpConfig/CanTpChannel/CanTpTxNSdu/CanTpTxNPdu	<p><b>See</b> CanTpRxNSdu/CanTpRxNPdu.</p> <p>In case a received N-PDU is referenced by two CAN-TP-CONNECTION elements of the imported ECU-INSTANCE (either via DATA-PDU-REF by the CAN-TP-CONNECTION referencing a Tx PDU via TP-SDU-REF, or via FLOW-CONTROL-PDU-REF by the CAN-TP-CONNECTION referencing an Rx PDU via TP-SDU-REF), CanTpTxNPduRef references the duplicate container in the EcuC module configuration (container name: &lt;PREFIX&gt;&lt;name&gt;_D&lt;INSTSUFFIX&gt;).</p>
CanTpConfig/CanTpChannel/CanTpTxNSdu/CanTpRxFcNPdu	<p><b>See</b> CanTpRxNSdu/CanTpTxFcNPdu.</p>

### 3.4.7. CanTSyn

Configuration parameters	Mapping description
CanTSynGlobalTimeDomain	<p><b>One</b> CanTSynGlobalTimeDomain container is created for each GLOBAL-TIME-DOMAIN that contains a GLOBAL-TIME-CAN-MASTER or a GLOBAL-TIME-CAN-SLAVE element that references a CAN-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the GLOBAL-TIME-DOMAIN.</p> <p>CanTSynGlobalTimeDomainId is set to DOMAIN-ID.</p>

Configuration parameters	Mapping description									
	<p>CanTSynSynchronizedTimeBaseRef references the corresponding StbMSynchronizedTimeBase container in the StbM module. If the GLOBAL-TIME-DOMAIN is a subdomain of a parent GLOBAL-TIME-DOMAIN, CanTSynSynchronizedTimeBaseRef references the StbMSynchronizedTimeBase container that has been created for the parent GLOBAL-TIME-DOMAIN. For further information about the configuration of the StbM module, see <a href="#">Section 3.4.39, “StbM”</a>.</p>									
CanTSynGlobalTimeDomain/CanTSynGlobalTimeFupDataIDList, CanTSynGlobalTimeDomain/CanTSynGlobalTimeOfnsDataIDList, CanTSynGlobalTimeDomain/CanTSynGlobalTimeOfsDataIDList, CanTSynGlobalTimeDomain/CanTSynGlobalTimeSyncDataIDList	<p>The CAN-GLOBAL-TIME-DOMAIN-PROPS element of the CAN GLOBAL-TIME-DOMAIN entity is used to retrieve the following subelements to configure container lists:</p> <ul style="list-style-type: none"><li>▶ FUP-DATA-ID-LIST</li><li>▶ OFNS-DATA-ID-LIST</li><li>▶ OFS-DATA-ID-LIST</li><li>▶ SYNC-DATA-ID-LIST</li></ul> <p>The configured container lists are the following:</p> <ul style="list-style-type: none"><li>▶ CanTSynGlobalTimeDomain/CanTSynGlobalTimeFupDataIDList/CanTSynGlobalTimeFupDataIDListElement</li><li>▶ CanTSynGlobalTimeDomain/CanTSynGlobalTimeOfnsDataIDList/CanTSynGlobalTimeOfnsDataIDListElement</li><li>▶ CanTSynGlobalTimeDomain/CanTSynGlobalTimeOfsDataIDList/CanTSynGlobalTimeOfsDataIDListElement</li><li>▶ CanTSynGlobalTimeDomain/CanTSynGlobalTimeSyncDataIDList/CanTSynGlobalTimeSyncDataIDListElement</li></ul> <p>In each container list, one subcontainer is created per element named Element_&lt;idx&gt;, where &lt;idx&gt; is the zero-based index of the element within the list. In each of these lists, one index parameter and one value parameter are configured. The index parameter represents the zero-based index of the element in the list, the value parameter represents the actual value.</p> <table><tr><th>ID List</th><th>Index Parameter</th><th>Value Parameter</th></tr><tr><td>CanTSynGlobalTimeFupDataIDList</td><td>CanTSynGlobalTimeFupDataIDListIndex</td><td>CanTSynGlobalTimeFupDataIDListValue</td></tr><tr><td>CanTSynGlobalTimeOfnsDataIDList</td><td>CanTSynGlobalTimeOfnsDataIDListIndex</td><td>CanTSynGlobalTimeOfnsDataIDListValue</td></tr></table>	ID List	Index Parameter	Value Parameter	CanTSynGlobalTimeFupDataIDList	CanTSynGlobalTimeFupDataIDListIndex	CanTSynGlobalTimeFupDataIDListValue	CanTSynGlobalTimeOfnsDataIDList	CanTSynGlobalTimeOfnsDataIDListIndex	CanTSynGlobalTimeOfnsDataIDListValue
ID List	Index Parameter	Value Parameter								
CanTSynGlobalTimeFupDataIDList	CanTSynGlobalTimeFupDataIDListIndex	CanTSynGlobalTimeFupDataIDListValue								
CanTSynGlobalTimeOfnsDataIDList	CanTSynGlobalTimeOfnsDataIDListIndex	CanTSynGlobalTimeOfnsDataIDListValue								

Configuration parameters	Mapping description		
	ID List	Index Parameter	Value Parameter
	CanTSynGlobalTimeOfsDataIDList	CanTSynGlobalTimeOfsDataIDListIndex	CanTSynGlobalTimeOfsDataIDListValue
	CanTSynGlobalTimeSyncDataIDList	CanTSynGlobalTimeSyncDataIDListIndex	CanTSynGlobalTimeSyncDataIDListValue
CanTSynGlobalTimeDomain/CanTSynGlobalTimeMaster	<p><b>If the GLOBAL-TIME-CAN-MASTER of the GLOBAL-TIME-DOMAIN references a CAN-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE, a CanTSynGlobalTimeMaster container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the GLOBAL-TIME-CAN-MASTER.</b></p> <p>CanTSynGlobalTimeTxCrcSecured is set depending on the value of GLOBAL-TIME-CAN-MASTER/CRC-SECURED: CRC_SUPPORTED for CRC-SUPPORTED and CRC_NOT_SUPPORTED for CRC-NOT-SUPPORTED.</p> <p>CanTSynGlobalTimeTxFollowUpOffset is set to GLOBAL-TIME-CAN-MASTER/FOLLOW-UP-OFFSET.</p> <p>CanTSynGlobalTimeTxPeriod is set to GLOBAL-TIME-CAN-MASTER/SYNC-PERIOD.</p> <p>CanTSynMasterConfirmationTimeout is set to GLOBAL-TIME-CAN-MASTER/SYNC-CONFIRMATION-TIMEOUT.</p> <p>CanTSynCyclicMsgResumeTime is set to GLOBAL-TIME-CAN-MASTER/IMMEDIATE-RESUME-TIME.</p> <p>CanTSynGlobalTimeDebounceTime is set to GLOBAL-TIME-DOMAIN/DEBOUNCE-TIME.</p>		
CanTSynGlobalTimeDomain/CanTSynGlobalTimeMaster/CanTSynGlobalTimeMasterPdu	<p><b>A GLOBAL-TIME-DOMAIN is associated with a PDU if that PDU is a GENERAL-PURPOSE-PDU that has its CATEGORY set to GLOBAL_TIME and one of the conditions hold:</b></p> <ul style="list-style-type: none"> <li>▶ <b>The GLOBAL-TIME-DOMAIN references the PDU in GLOBAL-TIME-PDU-REF</b></li> <li>▶ <b>The GLOBAL-TIME-DOMAIN references a PDU-TRIGGERING either via GLOBAL-TIME-PDU-TRIGGERING-REF or via PDU-TRIGGERING-REF, and that PDU-TRIGGERING refers to the PDU</b></li> </ul>		



Configuration parameters	Mapping description
	<p>If the GLOBAL-TIME-DOMAIN is associated with a PDU, and if this is the PDU that the configured ECU-INSTANCE sends on the CAN-CLUSTER which the GLOBAL-TIME-DOMAIN references via COMMUNICATION-CLUSTER-REF, one CanTSynGlobalTimeMasterPdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>CanTSynGlobalTimePduRef references the EcuC container created for the PDU that is associated with the GLOBAL-TIME-DOMAIN.</p>
CanTSynGlobalTimeDomain/CanTSynGlobalTimeSlave	<p>If one of the GLOBAL-TIME-CAN-SLAVE elements of the GLOBAL-TIME-DOMAIN references a CAN-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE, a CanTSynGlobalTimeSlave container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the GLOBAL-TIME-CAN-SLAVE.</p> <p>CanTSynRxCrcValidated is set depending on the value of GLOBAL-TIME-CAN-SLAVE/CRC-VALIDATED: CRC_VALIDATED for CRC-VALIDATED, CRC_NOT_VALIDATED for CRC-NOT-VALIDATED, and CRC_IGNORED for CRC-IGNORED.</p> <p>CanTSynGlobalTimeFollowUpTimeout is set to GLOBAL-TIME-CAN-SLAVE/FOLLOW-UP-TIMEOUT-VALUE or to GLOBAL-TIME-DOMAIN/FOLLOW-UP-TIMEOUT-VALUE if GLOBAL-TIME-CAN-SLAVE/FOLLOW-UP-TIMEOUT-VALUE does not exist.</p> <p>CanTSynGlobalTimeSequenceCounterJumpWidth is set to GLOBAL-TIME-CAN-SLAVE/SEQUENCE-COUNTER-JUMP-WIDTH.</p>
CanTSynGlobalTimeDomain/CanTSynGlobalTimeSlave/CanTSynGlobalTimeSlavePdu	<p>If the GLOBAL-TIME-DOMAIN is associated with a PDU, and if this is the PDU that the configured ECU-INSTANCE and if this is the PDU that the configured ECU-INSTANCE receives on the CAN-CLUSTER which the GLOBAL-TIME-DOMAIN references via COMMUNICATION-CLUSTER-REF, one CanTSynGlobalTimeSlavePdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>CanTSynGlobalTimePduRef references the EcuC container created for the PDU that is associated with the GLOBAL-TIME-DOMAIN.</p>

## 3.4.8. Com

Configuration parameters	Mapping description
ComGeneral	ComEnableMDTForCyclicTransmission is set to COM-ENABLE-MDT-FOR-CYCLIC-TRANSMISSION.
ComConfig/ComIPdu	<p>For every PDU instance (see <a href="#">Section 3.3.1.3, “Instance handling”</a>) which represents an I-SIGNAL-I-PDU or an NM-PDU for which an NmUserDataPdu container has been created (see <a href="#">Section 3.4.13, “EcuC”</a>), a ComIPdu container is created, except if an LdCom module configuration is present in the current project and the conditions described in <a href="#">Section 3.4.28, “LdCom”</a> allow to process the PDU instance in the LdCom module. For I-SIGNAL-I-PDU elements the container name is PD&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL-I-PDU. For NM-PDU elements the container name is PD&lt;PREFIX&gt;&lt;name&gt;_NmComUserData&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the NM-PDU.</p> <p>The ComIPduSignalRef entries reference all ComSignal containers representing signal instances of the PDU instance which lie directly within the PDU (in contrast to group signals embedded in PDUs indirectly via signal groups). See also <a href="#">Section 3.3.1.3, “Instance handling”</a>.</p> <p>The ComIPduSignalGroupRef entries reference all ComSignalGroup containers which have been created for the signal group instances of the PDU instance.</p> <p>ComIPduDirection is set to SEND if the PDU instance is sent by the imported ECU-INSTANCE. Otherwise it is set to RECEIVE.</p> <p>ComIPduType is set to TP if one of the following conditions holds:</p> <ul style="list-style-type: none"> <li>▶ The I-SIGNAL-I-PDU is referenced by a CAN-TP-CONNECTION via TP-SDU-REF</li> <li>▶ The I-SIGNAL-I-PDU is referenced by a FLEXRAY-TP-CONNECTION via DIRECT-TP-SDU-REF or via REVERSED-TP-SDU-REF</li> <li>▶ The I-SIGNAL-I-PDU is referenced by a FLEXRAY-AR-TP-CONNECTION via DIRECT-TP-SDU-REF or via REVERSED-TP-SDU-REF</li> <li>▶ The I-SIGNAL-I-PDU is referenced by a LIN-TP-CONNECTION via LIN-TP-N-SDU-REF</li> <li>▶ The I-SIGNAL-I-PDU is referenced by a PDU-TRIGGERING, which in turn is referenced by a SOMEIP-TP-CONNECTION via TP-SDU-REF</li> </ul>

Configuration parameters	Mapping description
	<p>In all other cases <code>ComIPduType</code> is set to <code>NORMAL</code>.</p> <p>The <code>ComIPduGroupRef</code> entries reference all <code>ComIPduGroup</code> containers which have been created for the <code>I-SIGNAL-I-PDU-GROUP</code> elements that contain the PDU instance's <code>I-SIGNAL-I-PDU</code> or <code>NM-PDU</code>. A <code>ComIPduGroupRef</code> entry is added as long as the <code>COMMUNICATION-DIRECTION</code> of the <code>I-SIGNAL-I-PDU-GROUP</code> is not opposite to the <code>ComIPduDirection</code> of the referencing <code>I-SIGNAL-I-PDU</code>. In case the <code>I-SIGNAL-I-PDU</code> is not part of any <code>I-SIGNAL-I-PDU-GROUP</code>, a reference to the default <code>ComIPduGroup</code> (see <code>ComConfig/ComIPduGroup</code>) this PDU belongs to is added. <code>NM-PDU</code> elements always obtain a reference to the default <code>Nm ComIPduGroup</code>, since <code>I-SIGNAL-I-PDU-GROUP</code> elements cannot contain <code>NM-PDU</code> elements.</p> <p><code>ComIPduSignalProcessing</code> is set to <code>I-PDU-SIGNAL-PROCESSING</code> of the <code>I-PDU-PORT</code> that connects one of the <code>COMMUNICATION-CONNECTOR</code> elements of the <code>ECU-INSTANCE</code> to the <code>PDU-TRIGGERING</code> of the PDU instance.</p> <p><code>ComPduIdRef</code> references the container created for the <code>I-SIGNAL-I-PDU</code> in the <code>EcuC</code> module configuration. For <code>NM-PDU</code> elements it references the <code>NmUserDataPdu</code> container.</p>
<p><code>ComConfig/ComIPdu/ComTxIPdu</code></p>	<p>If the PDU instance is sent by the imported <code>ECU-INSTANCE</code>, a <code>ComTxIPdu</code> sub container is created.</p> <p><code>ComTxIPduUnusedAreasDefault</code> is set to <code>UNUSED-BIT-PATTERN</code>. If <code>UNUSED-BIT-PATTERN</code> does not lie within the interval <code>[0 .. 255]</code> a warning is reported and <code>ComTxIPduUnusedAreasDefault</code> is not configured.</p> <p><code>ComMinimumDelayTime</code> is set to <code>MINIMUM-DELAY</code> of the <code>I-SIGNAL-I-PDU</code>'s <code>I-PDU-TIMING</code>.</p>
<p><code>ComConfig/ComIPdu/ComTxIPdu/ComTxModeTrue/ComTxMode</code></p>	<p>For every sent PDU instance, a <code>ComTxModeTrue/ComTxMode</code> container is created. For <code>NM-PDU</code> elements and for <code>I-SIGNAL-I-PDU</code> elements without <code>TRANSMISSION-MODE-TRUE-TIMING</code>, <code>ComTxModeMode</code> is set to <code>NONE</code>.</p> <p>If <code>TRANSMISSION-MODE-TRUE-TIMING</code> exists for the PDU instance, <code>ComTxModeMode</code> is set depending on the existence of timings attached to the <code>TRANSMISSION-MODE-TRUE-TIMING</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>MIXED</code>, if both <code>CYCLIC-TIMING</code> and <code>EVENT-CONTROLLED-TIMING</code> exist.</li> <li>▶ <code>PERIODIC</code>, if only a <code>CYCLIC-TIMING</code> exists.</li> <li>▶ <code>DIRECT</code>, if only an <code>EVENT-CONTROLLED-TIMING</code> exists.</li> <li>▶ <code>NONE</code>, if no timing exists.</li> </ul>

Configuration parameters	Mapping description
	<p>For NM-PDU elements ComTxModeMode is always set to NONE.</p> <p>ComTxModeTimePeriod is set to TIME-PERIOD/VALUE of the CYCLIC-TIMING if ComTxModeMode is set to MIXED or PERIODIC.</p> <p>ComTxModeTimeOffset is set to TIME-OFFSET/VALUE of the CYCLIC-TIMING if ComTxModeMode is set to MIXED or PERIODIC.</p> <p>ComTxModeNumberOfRepetitions is set to (NUMBER-OF-REPETITIONS + 1) of the EVENT-CONTROLLED-TIMING if ComTxModeMode is set to MIXED or DIRECT. If NUMBER-OF-REPETITIONS equals 0, ComTxModeNumberOfRepetitions is also set to 0.</p> <p>ComTxModeRepetitionPeriod is set to REPETITION-PERIOD/VALUE of the EVENT-CONTROLLED-TIMING if ComTxModeMode is set to MIXED or DIRECT and if NUMBER-OF-REPETITIONS of the EVENT-CONTROLLED-TIMING is greater than zero.</p>
ComConfig/ComIPdu/ComTxIPdu/ComTxModeFalse/ComTxMode	<p>If a TRANSMISSION-MODE-FALSE-TIMING exists for the I-SIGNAL-I-PDU, a ComTxModeFalse/ComTxMode container is created.</p> <p>For the configuration of the container parameters see ComTxModeTrue/ComTxMode.</p>
ComConfig/ComSignal	<p>For every signal instance which represents an I-SIGNAL which is sent or received by the imported ECU-INSTANCE and which is not contained in any I-SIGNAL-GROUP, a ComISignal container is created. A signal instance is considered sent if there is an I-SIGNAL-PORT with COMMUNICATION-DIRECTION set to OUT that connects one of the COMMUNICATION-CONNECTOR elements of the imported ECU-INSTANCE to the I-SIGNAL-TRIGGERING of the signal instance. If COMMUNICATION-DIRECTION is set to IN, the signal instance is considered received. The container name is SG&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL. In special cases, dedicated IRA signal containers are added. The configuration of IRA signals is described in <a href="#">Section 3.4.8.2, "Configuration for partial networking IRA signals"</a>.</p> <p>ComTimeout is set to TIMEOUT of the I-SIGNAL-PORT that connects one of the COMMUNICATION-CONNECTOR elements of the ECU-INSTANCE to the I-SIGNAL-TRIGGERING of the signal instance.</p> <p>ComFirstTimeout is set to FIRST-TIMEOUT of the I-SIGNAL-PORT that connects one of the COMMUNICATION-CONNECTOR elements of the ECU-INSTANCE to the I-SIGNAL-TRIGGERING of the signal instance.</p>

Configuration parameters	Mapping description
	<p><code>ComUpdateBitPosition</code> is set to <code>UPDATE-INDICATION-BIT-POSITION</code> of the signal instance's <code>I-SIGNAL-TO-I-PDU-MAPPING</code>.</p> <p><code>ComTransferProperty</code> is set depending on the value of <code>I-SIGNAL-TO-I-PDU-MAPPING/TRANSFER-PROPERTY</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>PENDING</code> for <code>PENDING</code>.</li> <li>▶ <code>TRIGGERED</code> for <code>TRIGGERED</code>.</li> <li>▶ <code>TRIGGERED_ON_CHANGE</code> for <code>TRIGGERED-ON-CHANGE</code>.</li> <li>▶ <code>TRIGGERED_ON_CHANGE_WITHOUT_REPETITION</code> for <code>TRIGGERED-ON-CHANGE-WITHOUT-REPETITION</code>.</li> <li>▶ <code>TRIGGERED_WITHOUT_REPETITION</code> for <code>TRIGGERED-WITHOUT-REPETITION</code>.</li> </ul> <p>For <code>I-SIGNAL</code> elements of <code>NM-PDU</code> elements, <code>ComTransferProperty</code> is always set to <code>PENDING</code>.</p> <p><code>ComSystemTemplateSystemSignalRef</code> is set to the AUTOSAR path of the <code>I-SIGNAL-TO-I-PDU-MAPPING</code> of the signal instance.</p> <p><code>ComSignalInitValue</code> is set to <code>VALUE</code> of the <code>INIT-VALUE</code> of the <code>I-SIGNAL</code>.</p> <p>Depending on the type of <code>VALUE-SPECIFICATION</code> the <code>INIT-VALUE</code> must be converted first:</p> <ul style="list-style-type: none"> <li>▶ <code>NUMERICAL-VALUE-SPECIFICATION</code> <p>If the <code>ComSignalType</code> is <code>UINT8_N</code> or <code>UINT8_DYN</code>, the value provided in <code>NUMERICAL-VALUE-SPECIFICATION</code> is converted to a string which represents a byte array separated by spaces. If the value does not represent an integral value, a warning is issued and <code>ComSignalInitValue</code> is not set. Otherwise the value provided in <code>NUMERICAL-VALUE-SPECIFICATION</code> is configured without conversion.</p> </li> <li>▶ <code>ARRAY-VALUE-SPECIFICATION</code> <p>If the <code>ComSignalType</code> is <code>UINT8_N</code> or <code>UINT8_DYN</code>, the <code>ARRAY-VALUE-SPECIFICATION</code> is converted to a string which represents a byte array separated by spaces.</p> <p>Otherwise, the <code>ARRAY-VALUE-SPECIFICATION</code> is converted to an integral number where the number's most significant byte contains the first element of the <code>ARRAY-VALUE-SPECIFICATION</code>.</p> </li> </ul>

Configuration parameters	Mapping description
	<p>► TEXT-VALUE-SPECIFICATION</p> <p>If the <code>ComSignalType</code> is <code>UINT8_N</code> or <code>UINT8_DYN</code>, the <code>TEXT-VALUE-SPECIFICATION</code> is converted to a string which represents a byte array separated by spaces. Characters &gt; 255 are not supported and generate a warning.</p> <p>Otherwise, the characters of the string are converted to an integral number where the number's most significant byte contains the first byte of the <code>TEXT-VALUE-SPECIFICATION</code>. Characters &gt; 127 generate a warning. If the string has a length of more than eight characters, an error is issued.</p> <p>► CONSTANT-REFERENCE</p> <p>A <code>CONSTANT-REFERENCE</code> refers to a <code>CONSTANT-SPECIFICATION</code> which in turn contains a <code>VALUE-SPECIFICATION</code>. This <code>VALUE-SPECIFICATION</code> is taken as input for configuring <code>ComSignalInitValue</code>.</p> <p>Other <code>VALUE-SPECIFICATION</code> elements are not supported and result in a warning and <code>ComSignalInitValue</code> not being set.</p> <p><code>ComSignalDataInvalidValue</code> is set to <code>VALUE</code> of the <code>INVALID-VALUE</code> of the <code>I-SIGNAL</code>'s <code>NETWORK-REPRESENTATION-PROPS</code>.</p> <p>Depending on the type of <code>VALUE-SPECIFICATION</code> the <code>INVALID-VALUE</code> is converted first, see <code>ComSignalInitValue</code> for conversion rules.</p> <p><code>ComBitPosition</code> is set to <code>START-POSITION</code> of the signal instance's <code>I-SIGNAL-TO-I-PDU-MAPPING</code>.</p> <p>In case the <code>ComSignalType</code> determined for the <code>I-SIGNAL</code> is <code>UINT8_N</code> or <code>UINT8_DYN</code>, and the <code>PACKING-BYTE-ORDER</code> of the <code>I-SIGNAL-TO-I-PDU-MAPPING</code> is <code>MOST-SIGNIFICANT-BYTE-FIRST</code>, the <code>START-POSITION</code> needs to be converted to <code>MOST-SIGNIFICANT-BYTE-LAST</code> ("little endian"). If the converted position is not byte-aligned within the parent PDU, a warning is reported and the original value of <code>START-POSITION</code> is used.</p> <p>For <code>I-SIGNAL</code> elements of <code>NM-PDU</code> elements the resulting value of <code>START-POSITION</code> needs to be adjusted by the length of the non-user data (see <code>PduLength</code> in <a href="#">Section 3.4.13, "EcuC"</a>): <code>ComBitPosition = (converted) START-POSITION - &lt;length of non-user data [bytes]&gt; * 8</code>. If the value of <code>ComBitPosition</code> is less than zero, a warning is reported.</p>

Configuration parameters	Mapping description
	<p><code>ComSignalEndianness</code> is set depending on the value of <code>PACKING-BYTE-ORDER</code> of the signal instance's <code>I-SIGNAL-TO-I-PDU-MAPPING</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>BIG_ENDIAN</code> for <code>MOST-SIGNIFICANT-BYTE-FIRST</code>.</li> <li>▶ <code>LITTLE_ENDIAN</code> for <code>MOST-SIGNIFICANT-BYTE-LAST</code>.</li> </ul> <p>In case the <code>ComSignalType</code> determined for the <code>I-SIGNAL</code> is <code>UINT8_N</code> or <code>UINT8_DYN</code>, <code>ComSignalEndianness</code> is set to <code>OPAQUE</code>.</p> <p>The configuration of <code>ComBitSize</code> and <code>ComSignalLength</code> depends on what has been configured for <code>ComSignalType</code>:</p> <ul style="list-style-type: none"> <li>▶ If <code>ComSignalType</code> was set to <code>UINT8_N</code>, the value is taken from <code>BASE-TYPE-SIZE</code> of <code>SW-BASE-TYPE</code>. If <code>BASE-TYPE-SIZE</code> is not available, the <code>LENGTH</code> value of <code>I-SIGNAL</code> is taken.</li> <li>▶ In any other cases, the <code>LENGTH</code> value of <code>I-SIGNAL</code> is taken.</li> </ul> <p><code>ComBitSize</code> is set to the value calculated as described above. For <code>UINT8_N</code> or <code>UINT8_DYN</code> the parameter is only configured if it is a multiple of eight.</p> <p><code>ComSignalDirection</code> is set to <code>SEND</code> if the PDU instance is sent by the imported ECU-INSTANCE. Otherwise it is set to <code>RECEIVE</code>.</p> <p><code>ComSignalLength</code> is configured for <code>UINT8_N</code> or <code>UINT8_DYN</code> signals. If the value calculated as described above is divisible by eight without remainder, <code>ComSignalLength</code> is configured with the result of the division.</p>
ComConfig/ComSignal/ComFilter	<p>If a <code>TRANSMISSION-MODE-CONDITION</code> (<code>I-SIGNAL-I-PDU -&gt; I-PDU-TIMING -&gt; TRANSMISSION-MODE-DECLARATION -&gt; TRANSMISSION-MODE-CONDITION</code>) referring to the same <code>I-SIGNAL-TO-I-PDU-MAPPING</code> as the signal instance exists, and the signal instance is sent by the imported ECU-INSTANCE, a <code>ComFilter</code> container is created.</p> <p>If the <code>DATA-FILTER-TYPE</code> of the <code>TRANSMISSION-MODE-CONDITION</code>'s <code>DATA-FILTER</code> is set to <code>ALWAYS</code> and a <code>TRANSMISSION-MODE-TRUE-TIMING</code> exists for this <code>TRANSMISSION-MODE-CONDITION</code>, no <code>ComFilter</code> container is created. If in this case a <code>TRANSMISSION-MODE-FALSE-TIMING</code> exists for the <code>TRANSMISSION-MODE-CONDITION</code> as well, a warning is issued.</p> <p>If the <code>I-SIGNAL-TO-I-PDU-MAPPING</code> has already been referenced by another <code>TRANSMISSION-MODE-CONDITION</code>, a warning is issued and the <code>ComFilter</code> parameters are not exported a second time.</p>

Configuration parameters	Mapping description
	<p>A ComFilter container is also created for received signal instances, if a DATA-FILTER exists for the I-SIGNAL-PORT via which the I-SIGNAL is received by the imported ECU-INSTANCE, and if the I-SIGNAL's DATA-TYPE-POLICY is set to LEGACY.</p> <p>ComFilterAlgorithm is set depending on the value of DATA-FILTER-TYPE:</p> <ul style="list-style-type: none"> <li>▶ ALWAYS for ALWAYS.</li> <li>▶ NEVER for NEVER.</li> <li>▶ MASKED_NEW_EQUALS_X for MASKED-NEW-EQUALS-X.</li> <li>▶ MASKED_NEW_DIFFERS_MASKED_OLD for NEW-IS-DIFFERENT.</li> <li>▶ MASKED_NEW_DIFFERS_MASKED_OLD for MASKED-NEW-DIFFERS-MASKED-OLD.</li> <li>▶ MASKED_NEW_DIFFERS_X for MASKED-NEW-DIFFERS-X.</li> <li>▶ NEW_IS_WITHIN for NEW-IS-WITHIN.</li> <li>▶ NEW_IS_OUTSIDE for NEW-IS-OUTSIDE.</li> <li>▶ ONE_EVERY_N for ONE-EVERY-N.</li> </ul> <p>For other DATA-FILTER-TYPE values, ComFilterAlgorithm is not exported.</p> <p>ComFilterMask is set to MASK, if DATA-FILTER-TYPE is one of MASKED-NEW-DIFFERS-MASKED-OLD, MASKED-NEW-DIFFERS-X, MASKED-NEW-EQUALS-X or NEW-IS-DIFFERENT.</p> <p>ComFilterX is set to X, if DATA-FILTER-TYPE is MASKED-NEW-DIFFERS-X or MASKED-NEW-EQUALS-X.</p> <p>ComFilterMax is set to MAX, if DATA-FILTER-TYPE is NEW-IS-OUTSIDE or NEW-IS-WITHIN-X.</p> <p>ComFilterMin is set to MIN, if DATA-FILTER-TYPE is NEW-IS-OUTSIDE or NEW-IS-WITHIN-X.</p> <p>ComFilterOffset is set to OFFSET, if DATA-FILTER-TYPE is ONE-EVERY-N.</p> <p>ComFilterPeriod is set to PERIOD, if DATA-FILTER-TYPE is ONE-EVERY-N.</p>
ComConfig/ComSignal/ComSignalType	<p>In the first step it is determined whether the I-SIGNAL references any DATA-TRANSFORMATION elements via DATA-TRANSFORMATIONS or whether DATA-TYPE-POLICY is set to TRANSFORMING-I-SIGNAL. In these cases, ComSignalType is set to one of the following:</p>



Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ <code>UINT8_DYN</code> if the <code>I-SIGNAL</code> references a <code>SYSTEM-SIGNAL</code> that has <code>DYNAMIC-LENGTH</code> set to <code>true</code>.</li> <li>▶ <code>UINT8_N</code> if the <code>I-SIGNAL</code> references a <code>SYSTEM-SIGNAL</code> that has <code>DYNAMIC-LENGTH</code> not set or set to <code>false</code>.</li> </ul> <p>If the <code>I-SIGNAL</code> does not reference any <code>DATA-TRANSFORMATION</code>, the <code>SW-DATA-DEF-PROPS</code> to be used subsequently is retrieved depending on the <code>DATA-TYPE-POLICY</code> of the <code>I-SIGNAL</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>NETWORK-REPRESENTATION-FROM-COM-SPEC</code>: see table "DataTypePolicyEnum" in [1] and specification items [TPS_SYST_02006] and [TPS_SYST_02079] in [3].</li> <li>▶ <code>LEGACY, PORT-INTERFACE-DEFINITION</code> and <code>OVERRIDE</code>: <code>SW-DATA-DEF-PROPS</code> is retrieved via the <code>NETWORK-REPRESENTATION-PROPS</code> of the <code>I-SIGNAL</code>.</li> </ul> <p>In the next step the <code>SW-BASE-TYPE</code> referenced via <code>BASE-TYPE-REF</code> of the <code>SW-DATA-DEF-PROPS</code> is retrieved. <code>ComSignalType</code> is then calculated according to the table <i>SwBaseType to ComSignalType Mapping</i> in [4]. If <code>I-SIGNAL-TYPE</code> of the <code>I-SIGNAL</code> is not available, <code>PRIMITIVE</code> is assumed per default. If <code>BASE-TYPE-SIZE</code> is not available, the <code>I-SIGNAL</code>'s <code>LENGTH</code> is used as <code>BASE-TYPE-SIZE</code>. If <code>BASE-TYPE-ENCODING</code> is not available, <code>BOOLEAN</code> is assumed for 1 bit signals and <code>NONE</code> for any other signal bit length. <code>BASE-TYPE-SIZE</code> values are rounded up to 8, 16, 32, or 64 if the <code>BASE-TYPE-ENCODING</code> yields a value of 2C or <code>NONE</code>.</p> <p>If no <code>SW-BASE-TYPE</code> is available directly via <code>BASE-TYPE-REF</code>, the <code>IMPLEMENTATION-DATA-TYPE</code> is retrieved by recursively searching through <code>SW-DATA-DEF-PROPS -&gt; IMPLEMENTATION-DATA-TYPE -&gt; SW-DATA-DEF-PROPS...</code>, until an <code>IMPLEMENTATION-DATA-TYPE</code> with a <code>CATEGORY</code> other than <code>TYPE_REFERENCE</code> is found. If an <code>IMPLEMENTATION-DATA-TYPE</code>'s <code>CATEGORY</code> is <code>TYPE_REFERENCE</code>, its <code>SHORT-NAME</code> is <code>boolean</code>, and it references an <code>IMPLEMENTATION-DATA-TYPE</code> with <code>SHORT-NAME</code> set to <code>uint8</code>, <code>ComSignalType</code> is set to <code>BOOLEAN</code>.</p> <p>If no <code>SW-DATA-DEF-PROPS</code> or <code>IMPLEMENTATION-DATA-TYPE</code> was found in the previous steps, <code>ComSignalType</code> is calculated from the <code>I-SIGNAL</code>'s <code>LENGTH</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>&gt; 64</code>, or <code>LENGTH</code> not available -&gt; <code>UINT8_N</code></li> <li>▶ <code>[33 .. 64]</code> -&gt; <code>UINT64</code></li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ [17 .. 32] -&gt; UINT32</li> <li>▶ [9 .. 16] -&gt; UINT16</li> <li>▶ [2 .. 8] -&gt; UINT8</li> <li>▶ 1 -&gt; BOOLEAN</li> </ul> <p>If the CATEGORY of the found IMPLEMENTATION-DATA-TYPE is ARRAY or STRUCTURE, ComSignalType is set to UINT8_N.</p> <p>If no LOWER-LIMIT/@INTERVAL-TYPE or UPPER-LIMIT/@INTERVAL-TYPE is defined by the DATA-CONSTR referenced via DATA-CONSTR-REF, ComSignalType is calculated using the SW-BASE-TYPE referenced by the IMPLEMENTATION-DATA-TYPE, or the I-SIGNAL's LENGTH if the SW-BASE-TYPE is not available.</p> <p>If either LOWER-LIMIT/@INTERVAL-TYPE or UPPER-LIMIT/@INTERVAL-TYPE is INFINITE, ComSignalType is set to FLOAT32 or FLOAT64 (I-SIGNAL's LENGTH &gt; 32).</p> <p>If the BASE-TYPE-ENCODING as defined by the SW-BASE-TYPE referenced by the IMPLEMENTATION-DATA-TYPE via BASE-TYPE-REF equals IEEE754, ComSignalType is set to FLOAT32 or FLOAT64 (I-SIGNAL's LENGTH &gt; 32).</p> <p>LOWER-LIMIT/UPPER-LIMIT elements having INTERVAL-TYPE elements which are OPEN are converted to CLOSED first, i.e. ]-1 .. 8[ is converted to [0 .. 7]. Then ComSignalType is calculated from the bit length required to cover the value range LOWER-LIMIT/UPPER-LIMIT according to the lists below. Note that the BASE-TYPE-SIZE of a referenced SW-BASE-TYPE overrides this calculated bit length. If BASE-TYPE-ENCODING is available as well, ComSignalType is calculated according to the table "SwBaseType to ComSignalType Mapping" in [1].</p> <p>Bit length of UPPER-LIMIT (value of converted LOWER-LIMIT &gt;= 0):</p> <ul style="list-style-type: none"> <li>▶ &gt; 64 -&gt; UINT8_N</li> <li>▶ [33 .. 64] -&gt; UINT64</li> <li>▶ [17 .. 32] -&gt; UINT32</li> <li>▶ [9 .. 16] -&gt; UINT16</li> <li>▶ [2 .. 8] -&gt; UINT8</li> <li>▶ 1 -&gt; BOOLEAN</li> </ul>

Configuration parameters	Mapping description
	<p>Bit length of LOWER-LIMIT/UPPER-LIMIT (whichever is greater, value of converted LOWER-LIMIT &lt; 0):</p> <ul style="list-style-type: none"> <li>▶ &gt; 64 -&gt; UINT8_N</li> <li>▶ [33 .. 64] -&gt; SINT64</li> <li>▶ [17 .. 32] -&gt; SINT32</li> <li>▶ [9 .. 16] -&gt; SINT16</li> <li>▶ [2 .. 8] -&gt; SINT8</li> <li>▶ 1 -&gt; BOOLEAN</li> </ul>
ComConfig/ComSignalGroup	<p>For every signal instance which represents an I-SIGNAL-GROUP and which is sent or received by the imported ECU-INSTANCE, a ComSignalGroup container is created. The container name is GR&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL-GROUP.</p> <p>For the setting of ComTimeout, ComFirstTimeout, and ComUpdateBitPosition, see ComConfig/ComSignal.</p> <p>If the I-SIGNAL-GROUP is contained in an NM-PDU, ComTransferProperty is set to PENDING.</p> <p>If the I-SIGNAL-GROUP is contained in an I-SIGNAL-I-PDU, the algorithm collects all distinct and valid I-SIGNAL-TO-I-PDU-MAPPING/TRANSFER-PROPERTY values of all I-SIGNAL-TO-I-PDU-MAPPING elements that are associated with any I-SIGNAL element of the I-SIGNAL-GROUP. If the collection is empty, the I-SIGNAL-TO-I-PDU-MAPPING/TRANSFER-PROPERTY value of the I-SIGNAL-GROUP is used to configure the ComTransferProperty according to ComConfig/ComSignal.</p> <p>If the collection contains exactly one value, this TRANSFER-PROPERTY is used to configure the ComTransferProperty.</p> <p>If the collection contains two values and one of them is PENDING, the other value is used to configure the ComTransferProperty. In any other case an error is issued.</p> <p>ComSystemTemplateSignalGroupRef is set to the AUTOSAR path of the I-SIGNAL-TO-I-PDU-MAPPING of the signal instance.</p> <p>If the I-SIGNAL-GROUP references a DATA-TRANSFORMATION via COM-BASED-SIGNAL-GROUP-TRANSFORMATIONS/DATA-TRANSFORMATION-REF-CONDITIONAL/DATA-TRANSFORMATION-REF, ComSignalGroupArray-</p>

Configuration parameters	Mapping description
	<p>Access is set to <code>true</code>, otherwise <code>ComSignalGroupArrayAccess</code> is set to <code>false</code>.</p> <p>The <code>ComSignalGroupDirection</code> is set to <code>SEND</code> if the PDU instance is sent by the imported ECU-INSTANCE. Otherwise it is set to <code>RECEIVE</code>.</p>
<p><code>ComConfig/ComSignalGroup/ComGroupSignal</code></p>	<p>For every <code>SYSTEM-SIGNAL</code> which is part of the <code>I-SIGNAL-GROUP</code> ("GroupSignal"), a <code>ComGroupSignal</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>SYSTEM-SIGNAL</code>.</p> <p><code>PACKING-BYTE-ORDER</code> of the <code>GroupSignal</code>'s <code>I-SIGNAL-TO-I-PDU-MAPPING</code> must be the same for all <code>GroupSignals</code> of the <code>I-SIGNAL-GROUP</code>. Different <code>PACKING-BYTE-ORDER</code> values result in an error.</p> <p>For the setting of <code>ComSignalInitValue</code>, <code>ComSignalDataInvalidValue</code>, <code>ComBitPosition</code>, <code>ComSignalLength</code>, <code>ComSignalEndianness</code>, <code>ComBitSize</code> and <code>ComSignalType</code> see <code>ComConfig/ComSignal</code>.</p> <p><code>ComSystemTemplateSystemSignalRef</code> is set to the AUTOSAR path of the <code>I-SIGNAL-TO-I-PDU-MAPPING</code> of the signal instance of the <code>GroupSignal</code>.</p> <p><code>ComFilter</code> is set only for <code>GroupSignals</code> which are sent by the imported ECU-INSTANCE, see <code>ComSignal/ComFilter</code>.</p> <p><code>ComTransferProperty</code> is set depending on the value of the <code>GroupSignal</code>'s <code>I-SIGNAL-TO-I-PDU-MAPPING/TRANSFER-PROPERTY</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>PENDING</code> for <code>PENDING</code>.</li> <li>▶ <code>TRIGGERED_ON_CHANGE</code> for <code>TRIGGERED-ON-CHANGE</code>.</li> </ul> <p>For all other values a warning is issued and <code>ComTransferProperty</code> is not set.</p>
<p><code>ComConfig/ComIPduGroup</code></p>	<p>For every <code>I-SIGNAL-I-PDU-GROUP</code> associated with the imported ECU-INSTANCE, a <code>ComIPduGroup</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>I-SIGNAL-I-PDU-GROUP</code>. For <code>I-SIGNAL-I-PDU-GROUP</code> elements contained within other <code>I-SIGNAL-I-PDU-GROUP</code> elements references to the containers of the parent groups are set in the reference list <code>ComIPduGroupGroupRef</code>.</p> <p>If no <code>I-SIGNAL-I-PDU-GROUP</code> element exists that references an <code>I-SIGNAL-I-PDU</code> which is sent or received by the imported ECU-INSTANCE, two default <code>ComIPduGroup</code> elements are created, named <code>RXPBUS_GLOBAL</code> and <code>TXPDUS_GLOBAL</code>. Then for each <code>CAN-CLUSTER</code>, <code>FLEXRAY-CLUSTER</code>, <code>LIN-CLUSTER</code> and <code>ETHERNET-PHYSICAL-CHANNEL</code> to which the imported ECU-</p>

Configuration parameters	Mapping description
	<p>INSTANCE is connected, two ComIPduGroup elements are created named RG&lt;SHORT-NAME of CLUSTER or PHYSICAL-CHANNEL&gt; and TG&lt;SHORT-NAME of CLUSTER or PHYSICAL-CHANNEL&gt;. Via ComIPduGroupGroupRef a reference to the parent ComIPduGroup is set, RXPBUS_GLOBAL for all RG groups, TXPDUS_GLOBAL for all TG groups.</p> <p>If no I-SIGNAL-I-PDU-GROUP element exists that references an NM-PDU which is sent or received by the imported ECU-INSTANCE, two default ComIPduGroup elements are created, named RXNMPBUS_GLOBAL and TXNMPBUS_GLOBAL. Then for each CAN-CLUSTER, FLEXRAY-CLUSTER and ETHERNET-PHYSICAL-CHANNEL to which the imported ECU-INSTANCE is connected, two ComIPduGroup elements are created named RNG&lt;SHORT-NAME of COMMUNICATION-CLUSTER&gt; and TNG&lt;SHORT-NAME of COMMUNICATION-CLUSTER&gt;. Via ComIPduGroupGroupRef a reference to the parent ComIPduGroup is set, RXNMPBUS_GLOBAL for all RG groups, TXNMPBUS_GLOBAL for all TG groups. If no NM-PDU elements exist for one direction (Rx/Tx), no dedicated ComIPduGroup is created for this direction.</p>
ComConfig/ComTimeBase	<p>ComConfigurationGwTimeBase is set to COM-CONFIGURATION-GW-TIME-BASE.</p> <p>ComConfigurationRxTimeBase is set to COM-CONFIGURATION-RX-TIME-BASE.</p> <p>ComConfigurationTxTimeBase is set to COM-CONFIGURATION-TX-TIME-BASE.</p>
ComConfig/ComGwMapping	<p>For each received signal instance representing an I-SIGNAL or an I-SIGNAL-GROUP, which is referenced via a SOURCE-SIGNAL-REF -&gt; I-SIGNAL-TRIGGERING that belongs to an I-SIGNAL-MAPPING in the GATEWAY of the imported ECU-INSTANCE, a ComGwMapping container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL or the I-SIGNAL-GROUP.</p>
ComConfig/ComGwMapping/ComGwSource	<p>The choice container is always set to ComGwSignal.</p> <p>ComGwSignal/ComGwSignalRef references the corresponding ComSignal or ComSignalGroup container created for the signal instance used to create the ComGwMapping container.</p>
ComConfig/ComGwMapping/ComGwDestination	<p>For each sent signal instance representing an I-SIGNAL or an I-SIGNAL-GROUP, which is referenced via a TARGET-SIGNAL-REF -&gt; I-SIGNAL-TRIGGERING that belongs to an I-SIGNAL-MAPPING and, which also references the I-SIGNAL or I-SIGNAL-GROUP of the ComGwSource,</p>

Configuration parameters	Mapping description
	<p>a ComGwDestination container is created . The container name is GM&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL or the I-SIGNAL-GROUP.</p> <p>ComGwSignal/ComGwSignalRef references the corresponding ComSignal or ComSignalGroup container.</p>

### 3.4.8.1. Configuration for partial networking ERA and EIRA PDUs and signals

Configuration parameters	Mapping description
ComConfig/ComIPdu	<p>For every ERA and EIRA Pdu container created for PNC-enabled NM-CLUSTER elements in the EcuC module (see <a href="#">Section 3.4.13, "EcuC"</a>), a ComIPdu is created. The container name equals the name of the Pdu container in the EcuC module.</p> <p>The single ComIPduSignalRef entry references the ComSignal container also created for this PDU.</p> <p>ComIPduDirection is set to RECEIVE.</p> <p>The single ComIPduGroupRef entry references the ComIPduGroup also created for this PDU.</p> <p>ComPduIdRef references the Pdu container in the EcuC module.</p>
ComConfig/ComSignal	<p>For every created ComIPdu container, a corresponding ComSignal container is created. The container name is SG&lt;ComIPdu name&gt;.</p> <p>ComBitSize is set to PNC-VECTOR-LENGTH * 8.</p> <p>ComSignalLength is set to PNC-VECTOR-LENGTH.</p> <p>ComSignalInitValue is set to 0, converted to a space separated byte array where PNC-VECTOR-LENGTH defines the length of this byte array.</p> <p>If PNC-VECTOR-LENGTH is not defined, a warning is issued for ComBitSize, ComSignalLength, and ComSignalInitValue and these parameters are not set.</p> <p>ComBitPosition is set to 0.</p>

Configuration parameters	Mapping description
	<p><code>ComSignalDirection</code> is set to <code>SEND</code> if the PDU instance is sent by the imported ECU-INSTANCE. Otherwise it is set to <code>RECEIVE</code>.</p> <p><code>ComSignalEndianness</code> is set to <code>OPAQUE</code>.</p> <p><code>ComSignalType</code> is set to <code>UINT8_N</code>.</p> <p><code>ComNotification</code> is set to <code>ComM_COMCbk_&lt;ComSignal name&gt;</code>.</p>
<code>ComConfig/ComIPduGroup</code>	<p>For every created EIRA <code>ComIPdu</code> container, a corresponding <code>ComIPduGroup</code> container is created. The container name depends on the <code>EcuC Pdu</code> container for which the <code>ComIPdu</code> has been created:</p> <ul style="list-style-type: none"> <li>▶ <code>RNGEIRACanNm</code> for the <code>CanNmPnEiraRxNSdu</code> container. It references the global <code>ComIPduGroup</code> named <code>RXEIRAPDUS_GLOBAL</code>.</li> <li>▶ <code>RNGEIRAFrNm</code> for the <code>FlexRayNmPnEiraRxNSdu</code> container. It references the global <code>ComIPduGroup</code> named <code>RXEIRAPDUS_GLOBAL</code>.</li> <li>▶ <code>RNGEIRAUdpNm</code> for the <code>UdpNmPnEiraRxNSdu</code> container. It references the global <code>ComIPduGroup</code> named <code>RXEIRAPDUS_GLOBAL</code>.</li> </ul> <p>For every created ERA <code>ComIPdu</code> container, a corresponding <code>ComIPduGroup</code> container is created. The container name is <code>RNG&lt;name&gt;</code> for received PDUs, and <code>TNG&lt;name&gt;</code> for sent PDUs, where <code>&lt;name&gt;</code> is the mangled name of the <code>CAN-COMMUNICATION-CLUSTER</code>, <code>FLEXRAY-COMMUNICATION-CLUSTER</code>, or <code>ETHERNET-PHYSICAL-CHANNEL</code> on which the PDU is sent or received. The referenced parent <code>ComIPduGroup</code> is <code>RXNMPDUS_GLOBAL</code> for <code>ComIPduGroup</code> containers of received PDUs and <code>TXNMPDUS_GLOBAL</code> for <code>ComIPduGroup</code> containers of sent PDUs.</p>

### 3.4.8.2. Configuration for partial networking IRA signals

An *IRA* (internal request array) signal is represented by a `ComSignal` container that is associated with a `ComIPdu` container. This `ComIPdu` container has been created for an `NmUserDataPdu`, which the ECU-INSTANCE is sending in a PNC-enabled NM-CLUSTER. The bit area of an IRA signal covers the PNC vector which is defined by the `PNC-VECTOR-OFFSET` and `PNC-VECTOR-LENGTH` of the SYSTEM. If the NM-PDU that represents the `NmUserDataPdu` contains an I-SIGNAL, which completely covers the PNC vector, the signal is picked for IRA signal configuration.

If the NM-PDU does not contain such an I-SIGNAL, a dedicated `ComSignal` container is created. The container name is `<name>NmPnIraTxNSdu`, where `<name>` is the mangled name of the `CAN-COMMUNI-`

CATION-CLUSTER, FLEXRAY-COMMUNICATION-CLUSTER, or ETHERNET-PHYSICAL-CHANNEL on which the IRA signal is sent.

The following ComSignal parameters for IRA signals are configured as described for EIRA and ERA signals in [Section 3.4.8.1, “Configuration for partial networking ERA and EIRA PDUs and signals”](#):

- ▶ ComBitSize
- ▶ ComSignalDirection
- ▶ ComSignalLength
- ▶ ComSignalEndianness
- ▶ ComSignalType

ComBitOffset is set to  $(\text{PNC-VECTOR-OFFSET} - \text{<non user data area>}) * 8$ , where <non user data area> is the byte length of the non user data area of the NM-PDU as described in [Section 3.4.13, “EcuC”](#).

### 3.4.9. ComM

Configuration parameters	Mapping description
ComMGeneral	ComMPncGatewayEnabled is set to false if all COMMUNICATION-CONNECTOR elements of the imported ECU-INSTANCE have the parameter PNC-GATEWAY-TYPE set to NONE. Otherwise ComMPncGatewayEnabled is set to true. If PNC-GATEWAY-TYPE is undefined for any of the COMMUNICATION-CONNECTOR elements, ComMPncGatewayEnabled is not set and a warning is reported. ComMPncPrepareSleepTimer is set to PNC-PREPARE-SLEEP-TIMER.
ComMConfigSet	ComMPncEnabled is set to true if any PNC-enabled NM-CLUSTER (see <a href="#">Section 3.4.13, “EcuC”</a> ) exists. Otherwise ComMPncEnabled is not set.
ComMConfigSet/ComMChannel	<p>Then for each CAN-CLUSTER, FLEXRAY-CLUSTER, LIN-CLUSTER and ETHERNET-PHYSICAL-CHANNEL to which the imported ECU-INSTANCE is connected, a ComMChannel container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the COMMUNICATION-CLUSTER or ETHERNET-PHYSICAL-CHANNEL.</p> <p>A ComMChannel is considered to be a <i>managing</i> channel in the following cases</p> <ul style="list-style-type: none"> <li>▶ The ComMChannel is represented by an ETHERNET-PHYSICAL-CHANNEL and that ETHERNET-PHYSICAL-CHANNEL refers via MANAGED-PHYSICAL-CHANNEL-REF to one or more ETHERNET-PHYSICAL-CHANNEL elements or to PHYSICAL-CHANNEL elements that are contained in CAN-CLUSTER, FLEXRAY-CLUSTER, or LIN-CLUSTER elements which in turn represent the <i>managed</i> ComMChannel elements.</li> </ul>



Configuration parameters	Mapping description
	<p>► The ComMChannel is represented by a CAN-CLUSTER, FLEXRAY-CLUSTER, or LIN-CLUSTER and one or more of the PHYSICAL-CHANNEL elements of the cluster refer via MANAGED-PHYSICAL-CHANNEL-REF to one or more ETHERNET-PHYSICAL-CHANNEL elements or to PHYSICAL-CHANNEL elements that are contained in CAN-CLUSTER, FLEXRAY-CLUSTER, or LIN-CLUSTER elements which in turn represent the <i>managed</i> ComMChannel elements.</p> <p>ComMBusType is set depending on the type of the COMMUNICATION-CLUSTER or ETHERNET-PHYSICAL-CHANNEL:</p> <ul style="list-style-type: none"> <li>► COMM_BUS_TYPE_CAN for CAN-CLUSTER.</li> <li>► COMM_BUS_TYPE_FR for FLEXRAY-CLUSTER.</li> <li>► COMM_BUS_TYPE_ETH for ETHERNET-PHYSICAL-CHANNEL.</li> <li>► COMM_BUS_TYPE_LIN for LIN-CLUSTER.</li> <li>► For any other cluster type ComMBusType is not set and a warning is issued.</li> </ul> <p>ComMPncGatewayType is not configured if the ComMChannel is a <i>managed</i> ComMChannel. Otherwise ComMPncGatewayType is set depending on the PNC-GATEWAY-TYPE of the COMMUNICATION-CONNECTOR that connects the imported ECU-INSTANCE to the COMMUNICATION-CLUSTER or ETHERNET-PHYSICAL-CHANNEL:</p> <ul style="list-style-type: none"> <li>► COMM_GATEWAY_TYPE_ACTIVE for ACTIVE</li> <li>► COMM_GATEWAY_TYPE_PASSIVE for PASSIVE</li> </ul> <p>ComMPncGatewayType is not configured if PNC-GATEWAY-TYPE is not defined or set to NONE.</p> <p>If the ComMChannel is a <i>managed</i> ComMChannel, ComMManageReference is configured to refer to the corresponding <i>managing</i> ComMChannel container.</p> <p>ComMNetworkManagement/ComMNmVariant is set to LIGHT for <i>managed</i> ComMChannel containers, and to FULL for <i>managing</i> ComMChannel containers. If the ComMChannel is neither <i>managed</i> nor <i>managing</i> the following rules apply.</p> <ul style="list-style-type: none"> <li>► For LIN-CLUSTER elements, ComMNmVariant is set to LIGHT</li> <li>► If no NM-NODE exists that connects an NM-CLUSTER to the COMMUNICATION-CLUSTER, or if the NM-NODE does not reference any sent or received NM-PDU elements, ComMNmVariant is set to NONE unless ComMNm-</li> </ul>

Configuration parameters	Mapping description
	<p>Variant has been manually configured as LIGHT, in which case that value is left unchanged.</p> <ul style="list-style-type: none"> <li>▶ If an NM-NODE exists that connects a NM-CLUSTER to the COMMUNICATION-CLUSTER, and if the NM-NODE references at least one sent or received NM-PDU element, ComMNmVariant is set to PASSIVE if the NM-NODE's NM-PASSIVE-MODE-ENABLED is set to true. If NM-PASSIVE-MODE-ENABLED is not set or set to false, ComMNmVariant is set to FULL.</li> </ul>
ComMConfigSet/ComMPnc	<p>For every PNC-MAPPING for which a valid and unique Id can be calculated and which fulfills at least one of the following conditions:</p> <ul style="list-style-type: none"> <li>▶ The PNC-MAPPING is referencing an I-SIGNAL-I-PDU-GROUP which is also referenced by the imported ECU-INSTANCE via ASSOCIATED-COM-I-PDU-GROUP-REFS</li> <li>▶ The PNC-MAPPING is referencing at least one PHYSICAL-CHANNEL to which the configured ECU is connected as well</li> </ul> <p>, a ComMPnc container is created. Each ComMPnc is identified by its Id. The formula for calculating this Id depends on the AUTOSAR specification version that the ComM module implements.</p> <p>For ComM modules that implement AUTOSAR 4.1.0 or lower, the formula <math>Id := PNC-IDENTIFIER - (PNC-VECTOR-OFFSET * 8)</math> is applied, where PNC-VECTOR-OFFSET is defined at the SYSTEM to which the PNC-IDENTIFIER belongs. For ComM modules that implement AUTOSAR 4.1.1 or higher, <math>Id := PNC-IDENTIFIER</math> is applied.</p> <p>The container name of the ComMPnc is ComMPnc_&lt;Id&gt;. If Id cannot be calculated due to a missing PNC-IDENTIFIER or PNC-VECTOR-OFFSET, a warning is issued and no ComMPnc container is created.</p> <p>If multiple PNC-MAPPING elements exist that have the same PNC-IDENTIFIER, a warning is issued and only the first PNC-MAPPING is used.</p> <p>ComMPncId is set to Id.</p> <p>For every COMMUNICATION-CLUSTER or ETHERNET-PHYSICAL-CHANNEL through which either any of the I-SIGNAL-I-PDU-GROUP's PDU elements are sent, and/or received, and/or routed, or which is referenced via PNC-MAPPING/PHYSICAL-CHANNEL-REF, one ComMChannelPerPnc reference is created. This ComMChannelPerPnc references the ComMChannel that has been</p>

Configuration parameters	Mapping description
	<p>created for the <code>COMMUNICATION-CLUSTER</code> or <code>ETHERNET-PHYSICAL-CHANNEL</code>.</p> <p>If an <code>EthIfSwitchPortGroup</code> container has been created in the <code>EthIf</code> module for the <code>PNC-MAPPING</code>, <code>ComMPncEthIfSwitchPortGroupRef</code> is configured to refer to this container. <a href="#">Section 3.4.15, “EthIf”</a> describes the configuration of <code>EthIfSwitchPortGroup</code> containers in detail.</p>
<code>ComMCon-</code> <code>figSet/ComMP-</code> <code>nc/ComMPncComSignal</code>	<p>If a PNC-enabled <code>CAN-NM-CLUSTER</code> that sends/receives a PDU of the <code>PNC-MAPPING</code> exists, one <code>ComMPncComSignal</code> container named <code>CanNmP-nEiraRxNSdu</code> is created.</p> <p>If a PNC-enabled <code>UDP-NM-CLUSTER</code> that sends/receives a PDU of the <code>PNC-MAPPING</code> exists, one <code>ComMPncComSignal</code> container named <code>UdpNmP-nEiraRxNSdu</code> is created.</p> <p>If a PNC-enabled <code>FLEXRAY-NM-CLUSTER</code> that sends/receives a PDU of the <code>PNC-MAPPING</code> exists, one <code>ComMPncComSignal</code> container named <code>FlexRayNmPnEiraRxNSdu</code> is created.</p> <p>For every <code>ComSignal</code> container that has been set up in <code>Com</code> for an EIRA, ERA, or IRA signal that belongs to this <code>ComMPnc</code> container, one <code>ComMPncComSignal</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the signal. The creation of <code>ComSignal</code> containers for EIRA, ERA, and IRA signals is described in <a href="#">Section 3.4.8.1, “Configuration for partial networking ERA and EIRA PDUs and signals”</a> and in <a href="#">Section 3.4.8.2, “Configuration for partial networking IRA signals”</a>. For detailed information about the PNC Vector, see <a href="#">Section 3.4.4, “CanNm”</a>.</p> <p>The <i>IRA signal kind</i> of an IRA signals depends on the <code>PNC-GATEWAY-TYPE</code> of the <code>COMMUNICATION-CONNECTOR</code> that connects the imported <code>ECU-INSTANCE</code> to the <code>PHYSICAL-CHANNEL</code> on which the signal is sent. If the <code>PNC-GATEWAY-TYPE</code> is set to <code>PASSIVE</code>, the <i>IRA signal kind</i> of the IRA signal is ERA. For all other values, its <i>IRA signal kind</i> is EIRA.</p> <p>The following parameters of <code>ComMPncComSignal</code> are set:</p> <ul style="list-style-type: none"> <li>▶ <code>ComMPncComSignalDirection</code> is set to <code>RX</code> for ERA and EIRA signals, and to <code>TX</code> for IRA signals.</li> <li>▶ <code>ComMPncComSignalKind</code> is set to <code>EIRA</code> for EIRA and to <code>ERA</code> for ERA signals. For IRA signals, the <i>IRA signal kind</i> is configured.</li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ <b>ComMPncComSignalRef</b> references the corresponding <b>ComSignal</b> container in the <b>Com</b> module.</li> <li>▶ For ERA signals and for IRA signals having an <i>IRA signal kind</i> of ERA, <b>ComMPncComSignalChannelRef</b> references the <b>ComMChannel</b> container that has been created for the PNC-enabled NM-CLUSTER.</li> </ul>

### 3.4.10. Dcm

Configuration parameters	Mapping description
DcmConfigSet	Check if a <b>DcmConfigSet</b> container is created inside the module. If one already exists then an additional one is not created, otherwise a new <b>DcmConfigSet</b> container is created.
DcmConfigSet/DcmDsl/DcmDslProtocol/DcmDslProtocolRow	<p>For each <b>DIAGNOSTIC-SERVICE-TABLE</b> that is assigned to the configured <b>ECU-INSTANCE</b>, one <b>DcmDslProtocolRow</b> container is created.</p> <p>A <b>DIAGNOSTIC-CONNECTION</b> refers to a PDU sent or received by the configured <b>ECU-INSTANCE</b> in the following cases:</p> <ul style="list-style-type: none"> <li>▶ The <b>DIAGNOSTIC-CONNECTION</b> references a <b>PDU-TRIGGERING</b> via <b>PERIODIC-RESPONSE-UUDT-REF</b> which in turn references an outgoing <b>I-PDU-PORT</b> of the <b>ECU-INSTANCE</b>. Moreover, the <b>PDU-TRIGGERING</b> must reference a PDU of type <b>DCM-I-PDU</b>.</li> <li>▶ The <b>DIAGNOSTIC-CONNECTION</b> references a <b>TP-CONNECTION-IDENT</b> element via <b>FUNCTIONAL-REQUEST-REF</b>, <b>RESPONSE-REF</b>, <b>RESPONSE-ON-EVENT-REF</b>, or <b>PHYSICAL-REQUEST-REF</b> which in turn refers to one or more PDUs that are sent or received by the configured <b>ECU-INSTANCE</b>.</li> </ul> <p>A <b>TP-CONNECTION-IDENT</b> refers to a PDU in one of the following cases:</p> <ul style="list-style-type: none"> <li>▶ The <b>TP-CONNECTION-IDENT</b> is aggregated by a <b>CAN-TP-CONNECTION</b> which refers to the PDU via <b>TP-SDU-REF</b>.</li> <li>▶ The <b>TP-CONNECTION-IDENT</b> is aggregated by a <b>FLEXRAY-TP-CONNECTION</b> which refers to the PDU either via <b>DIRECT-TP-SDU-REF</b> or via <b>REVERSED-TP-SDU-REF</b>.</li> <li>▶ The <b>TP-CONNECTION-IDENT</b> is aggregated by a <b>LIN-TP-CONNECTION</b> which refers to the PDU via <b>LIN-TP-N-SDU-REF</b>.</li> </ul>

Configuration parameters	Mapping description
	<p>► The TP-CONNECTION-IDENT is aggregated by a DO-IP-TP-CONNECTION, which refers to the PDU via TP-SDU-REF.</p>
DcmDslProtocol-Row/DcmDslProtocolID	<p>Each DiagnosticProtocol refers to at most one DiagnosticServiceTable and to a collection of DiagnosticConnection elements. The DiagnosticProtocolID parameter is configured to a certain category based on specific conditions for each category:</p> <ul style="list-style-type: none"> <li>► If the reference DiagnosticConnection.periodicResponseTp exists and the reference TpConnectionIdent.ident belongs to a CanTpConnection, or the DiagnosticConnection.periodicResponseUdt is not empty and the PhysicalChannel belongs to AbstractCanPhysicalChannel, then the DcmDslProtocolID is set to the DCM_PERIODIC_TRANS_ON_CAN category.</li> <li>► If the reference DiagnosticConnection.periodicResponseTp exists and the reference TpConnectionIdent.ident belongs to a FlexRayTpConnection, or the DiagnosticConnection.periodicResponseUdt is not empty and the PhysicalChannel belongs to FlexrayPhysicalChannel, then the DcmDslProtocolID is set to the DCM_PERIODIC_ON_FLEXRAY category.</li> <li>► If the reference DiagnosticConnection.periodicResponseTp exists and the reference TpConnectionIdent.ident belongs to a SocketConnection, or the DiagnosticConnection.periodicResponseUdt is not empty and the PhysicalChannel belongs to EthernetPhysicalChannel, then the DcmDslProtocolID is set to the DCM_PERIODIC_ON_IP category.</li> <li>► If the reference DiagnosticConnection.responseOnEvent exists and the reference TpConnectionIdent.ident belongs to a CanTpConnection, then the DcmDslProtocolID is set to the DCM_ROE_ON_CAN category.</li> <li>► If the reference DiagnosticConnection.responseOnEvent exists and the reference TpConnectionIdent.ident belongs to a FlexRayTpConnection, then the DcmDslProtocolID is set to DCM_ROE_ON_FLEXRAY category.</li> <li>► If the reference DiagnosticConnection.responseOnEvent exists and the reference TpConnectionIdent.ident belongs to a SocketConnection, then the DcmDslProtocolID is set to the DCM_ROE_ON_IP category.</li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ If the reference <code>DiagnosticConnection.physicalRequest</code> exists and the reference <code>TpConnectionIdent.ident</code> belongs to a <code>CanTpConnection</code>, then the <code>DcmDslProtocolID</code> is set to the <code>DCM_UDS_ON_CAN</code> category.</li> <li>▶ If the reference <code>DiagnosticConnection.physicalRequest</code> exists and the reference <code>TpConnectionIdent.ident</code> belongs to a <code>FlexRayTpConnection</code>, then the <code>DcmDslProtocolID</code> is set to the <code>DCM_UDS_ON_FLEXRAY</code> category.</li> <li>▶ If the reference <code>DiagnosticConnection.physicalRequest</code> exists and the reference <code>TpConnectionIdent.ident</code> belongs to a <code>SocketConnection</code>, then the <code>DcmDslProtocolID</code> is set to the <code>DCM_UDS_ON_IP</code> category.</li> </ul>
<code>DcmDslProtocol-Row/DcmDslProtocol-Priority</code>	<p>Each <code>DiagnosticProtocol</code> refers to at most one <code>DiagnosticServiceTable</code> and to a collection of <code>DiagnosticConnection</code> elements.</p> <p>If the reference <code>DiagnosticProtocol.serviceTable</code> exists, and the value of <code>DiagnosticProtocol.protocolKind</code> is identical to the value of <code>DiagnosticServiceTable.protocolKind</code>, then the <code>DcmDslProtocolPriority</code> is set and it represents the priority of the diagnostic protocol in comparison to other diagnostic protocols.</p>
<code>DcmDslBuffer</code>	<p>A <code>DcmDslBuffer</code> is configured.</p> <p>The size of <code>DcmDslBuffer</code> is set to have the default value, 8.</p>
<code>DcmDslProtocol-Row/DcmDslProtocolSessionRef</code>	<p>For every <code>DcmDslProtocolRow</code> a <code>DcmDslProtocolSessionRef</code> reference is set.</p>
<code>DcmDslProtocol-Row/DcmDslResponseOnEvent</code>	<p>A <code>DcmDslResponseOnEvent</code> subcontainer is created if the <code>DIAGNOSTIC-CONNECTION</code> elements of the <code>DIAGNOSTIC-SERVICE-TABLE</code> refer to a PDU that the configured <code>ECU-INSTANCE</code> sends via <code>RESPONSE-ON-EVENT-REF</code>. The name of the container is set to <code>&lt;PREFIX&gt;&lt;name&gt;_ResponseOnEvent</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>DIAGNOSTIC-CONNECTION</code>.</p> <p><code>DcmDslRoeTxPduRef</code> is configured to refer to the <code>EcuC</code> container that was created for the sent PDU.</p>
<code>DcmDslProtocol-Row/DcmDslMainConnection</code>	<p>A <code>DcmDslMainConnection</code> subcontainer is created for a <code>DIAGNOSTIC-CONNECTION</code> of a <code>DIAGNOSTIC-SERVICE-TABLE</code> if the <code>DIAGNOSTIC-CONNECTION</code> refers via <code>FUNCTIONAL-REQUEST-REF</code>, <code>PHYSICAL-REQUEST-REF</code>, or <code>RESPONSE-REF</code> to one or more <code>TP-CONNECTION-IDENT</code> elements that are in turn contained in <code>TP-CONNECTION</code> elements via which the configured</p>

Configuration parameters	Mapping description
	<p>ECU-INSTANCE sends or receives PDUs. The name of the container is set to &lt;PREFIX&gt;&lt;name&gt;_Main, where &lt;name&gt; is the SHORT-NAME of the DIAGNOSTIC-CONNECTION.</p> <p>DcmDslProtocolRxTesterSourceAddr is set to the diagnostic address of the remote node. The retrieval of that address depends on the type of TP-CONNECTION instance that contains the TP-CONNECTION-IDENT. Any type of TP-CONNECTION that is not listed below is not supported.</p> <ul style="list-style-type: none"> <li>▶ CAN-TP-CONNECTION instances: If CAN-TP-CONNECTION/TRANSMITTER does not refer to the configured ECU-INSTANCE, CAN-TP-CONNECTION/TRANSMITTER represents the remote node. If CAN-TP-CONNECTION/TRANSMITTER represents the configured ECU-INSTANCE, the remote node can only be determined if the CAN-TP-CONNECTION sends its PDUs to a physical address. In that case, the remote node is the first CAN-TP-NODE referenced by CAN-TP-CONNECTION/RECEIVER. The tester address is retrieved by taking the TP-ADDRESS value of the CAN-TP-ADDRESS entry which the remote node refers to via TP-ADDRESS.</li> <li>▶ FLEXRAY-TP-CONNECTION instances: If FLEXRAY-TP-CONNECTION/TRANSMITTER does not refer to the configured ECU-INSTANCE, FLEXRAY-TP-CONNECTION/TRANSMITTER represents the remote node. If FLEXRAY-TP-CONNECTION/TRANSMITTER represents the configured ECU-INSTANCE, the remote node can only be determined if the FLEXRAY-TP-CONNECTION sends its PDUs to a physical address. In that case, the remote node is the first FLEXRAY-TP-NODE referenced by FLEXRAY-TP-CONNECTION/RECEIVER. The tester address is retrieved by taking the TP-ADDRESS/TP-ADDRESS value which the remote FLEXRAY-TP-NODE refers to via TP-ADDRESS.</li> <li>▶ DO-IP-TP-CONNECTION instances: If the TP-CONNECTION-IDENT is referenced via DIAGNOSTIC-CONNECTION/FUNCTIONAL-REQUEST or DIAGNOSTIC-CONNECTION/PHYSICAL-REQUEST, DO-IP-TP-CONNECTION/DO-IP-SOURCE-ADDRESS represents the address of the tester node. If the TP-CONNECTION-IDENT is referenced via DIAGNOSTIC-CONNECTION/RESPONSE, DO-IP-TP-CONNECTION/DO-IP-TARGET-ADDRESS represents the address of the tester node. The actual tester address value is taken from DO-IP-LOGIC-ADDRESS/ADDRESS.</li> </ul> <p>All diagnostic addresses are collected for all TP-CONNECTION-IDENT elements which the DIAGNOSTIC-CONNECTION references via FUNCTIONAL-REQUEST-REF, PHYSICAL-REQUEST-REF, or RESPONSE-REF. The first ele-</p>

Configuration parameters	Mapping description
	<p>ment of the resulting list of diagnostic addresses is used for the configuration of DcmDslProtocolRxTesterSourceAddr.</p> <p>If the DIAGNOSTIC-CONNECTION references a PDU via RESPONSE-ON-EVENT-REF, DcmDslROEConnectionRef is configured to reference the EcuC container that was created for that PDU.</p>
DcmDslProtocol-Row/DcmDslMainConnection/DcmDslProtocolTx	<p>A DcmDslProtocolTx subcontainer is created if the DIAGNOSTIC-CONNECTION refers to one or more PDUs that the configured ECU-INSTANCE sends via RESPONSE-REF. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the received PDU.</p> <p>DcmDslProtocolTxPduRef is configured to reference the EcuC container that was created for the sent PDU.</p>
DcmDslProtocol-Row/DcmDslMainConnection/DcmDslProtocolRx	<p>A DcmDslProtocolRx subcontainer is created if the DIAGNOSTIC-CONNECTION refers to one or more PDUs that the configured ECU-INSTANCE receives via FUNCTIONAL-REQUEST-REF or PHYSICAL-REQUEST-REF. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME name of the received PDU.</p> <p>DcmDslProtocolRxAddrType is set to DCM_PHYSICAL_TYPE if the received PDU is referenced by the DIAGNOSTIC-CONNECTION via PHYSICAL-REQUEST-REF. It is set to DCM_FUNCTIONAL_TYPE if the received PDU is referenced by the DIAGNOSTIC-CONNECTION via FUNCTIONAL-REQUEST-REF.</p> <p>DcmDslProtocolRxPduRef is configured to reference the EcuC container that was configured for the received PDU.</p> <p>If a ComMChannel container was created in the ComM for the COMMUNICATION-CLUSTER or the ETHERNET-PHYSICAL-CHANNEL via which the PDU is received, DcmDslProtocolRxComMChannelRef is configured to reference that ComMChannel container.</p>
DcmDslProtocol-Row/DcmDslPeriodicTransmission	<p>A DcmDslPeriodicTransmission subcontainer is created if the DIAGNOSTIC-CONNECTION elements of the DIAGNOSTIC-SERVICE-TABLE refer via PERIODIC-RESPONSE-UUDT-REF to one or more PDUs that the configured ECU-INSTANCE sends. The name of the container is set to &lt;PREFIX&gt;&lt;name&gt;_PeriodicTransmission, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-CONNECTION.</p> <p>For each PDU that the configured ECU-INSTANCE sends in the context of the DIAGNOSTIC-CONNECTION, one DcmDslPeriodicConnection container is created. Its name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME</p>



Configuration parameters	Mapping description
	name of the PDU. <code>DcmDslPeriodicTxPduRef</code> is configured to reference the <code>EcuC</code> container that was created for the sent PDU.
<code>DcmConfigSet/DcmDsp/DcmDspMemory</code>	A single <code>DcmDspMemory</code> sub container is created for all the DIAGNOSTIC-READ-MEMORY-BY-ADDRESS and all the DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS services referenced by a DIAGNOSTIC-SERVICE-TABLE for the current ECU.
<code>DcmConfigSet/DcmDsp/DcmDspMemory/DcmDspMemoryIdInfo</code>	For each different DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-READ-MEMORY-BY-ADDRESS or a DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS service, belonging to a DIAGNOSTIC-SERVICE-TABLE, a single <code>DcmDspMemoryIdInfo</code> is created.  <code>DcmDspMemoryIdValue</code> is set to the ID value of the DIAGNOSTIC-MEMORY-IDENTIFIER.
<code>DcmConfigSet/DcmDsp/DcmDspMemory/DcmDspMemoryIdInfo/DcmDspWriteMemoryRangeInfo</code>	A single <code>DcmDspWriteMemoryRangeInfo</code> subcontainer is created for each DIAGNOSTIC-MEMORY-IDENTIFIER that is referenced by a DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS.  <code>DcmDspWriteMemoryRangeHigh</code> is set to the MEMORY-HIGH-ADDRESS value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS service.  <code>DcmDspWriteMemoryRangeLow</code> is set to the MEMORY-LOW-ADDRESS value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS service.  <code>DcmDspWriteMemoryRangeSecurityLevelRef</code> references all the corresponding <code>DcmDspSecurity</code> containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS service.
<code>DcmConfigSet/DcmDsp/DcmDspMemory/DcmDspMemoryIdInfo/DcmDspReadMemoryRangeInfo</code>	A single <code>DcmDspReadMemoryRangeInfo</code> subcontainer is created for each DIAGNOSTIC-MEMORY-IDENTIFIER that is referenced by a DIAGNOSTIC-READ-MEMORY-BY-ADDRESS.  <code>DcmDspReadMemoryRangeHigh</code> is set to the MEMORY-HIGH-ADDRESS value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-READ-MEMORY-BY-ADDRESS service.  <code>DcmDspReadMemoryRangeLow</code> is set to the MEMORY-LOW-ADDRESS value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-READ-MEMORY-BY-ADDRESS service.

Configuration parameters	Mapping description
	DcmDspReadMemoryRangeSecurityLevelRef references all the corresponding DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-READ-MEMORY-BY-ADDRESS service.
DcmConfigSet/DcmDsp/DcmDspMemory/DcmDspMemoryIdInfo/DcmDspWriteMemoryRangeByLabelInfo	<p>A single DcmDspWriteMemoryRangeByLabelInfo subcontainer is created for each DIAGNOSTIC-MEMORY-IDENTIFIER that is referenced by a DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS.</p> <p>DcmDspWriteMemoryRangeByLabelHigh is set to the MEMORY-HIGH-ADDRESS-LABEL value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS service.</p> <p>DcmDspWriteMemoryRangeByLabelLow is set to the MEMORY-LOW-ADDRESS-LABEL value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS service.</p> <p>DcmDspWriteMemoryRangeSecurityLevelRef references all the corresponding DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS service.</p>
DcmConfigSet/DcmDsp/DcmDspMemory/DcmDspMemoryIdInfo/DcmDspReadMemoryRangeByLabelInfo	<p>A single DcmDspReadMemoryRangeByLabelInfo subcontainer is created for each DIAGNOSTIC-MEMORY-IDENTIFIER that is referenced by a DIAGNOSTIC-READ-MEMORY-BY-ADDRESS.</p> <p>DcmDspReadMemoryRangeByLabelHigh is set to the MEMORY-HIGH-ADDRESS-LABEL value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-READ-MEMORY-BY-ADDRESS service.</p> <p>DcmDspReadMemoryRangeByLabelLow is set to the MEMORY-LOW-ADDRESS-LABEL value of the DIAGNOSTIC-MEMORY-IDENTIFIER referenced by a DIAGNOSTIC-READ-MEMORY-BY-ADDRESS service.</p> <p>DcmDspReadMemoryRangeSecurityLevelRef references all the corresponding DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-READ-MEMORY-BY-ADDRESS service.</p>
DcmConfigSet/DcmDsp/DcmDspComCon-	A DcmDspComControlAllChannel container is created for every different DIAGNOSTIC-ALL-CHANNEL element of a DIAGNOSTIC-COM-CON-

Configuration parameters	Mapping description
trol/DcmDspComControlAllChannel	<p>TROL-CLASS of the current ECU. The container name is &lt;name&gt;&lt;SUFFIX&gt;, where &lt;name&gt; is derived from the short name of the DIAGNOSTIC-ALL-CHANNEL element and the &lt;SUFFIX&gt; is _AC_ and the number of the current container created.</p> <p>DcmDspAllComMChannelRef is set to DIAGNOSTIC-COM-CONTROL-CLASS/ALL-CHANNEL reference.</p>
DcmConfigSet/DcmDsp/DcmDspComControl/DcmDspComControlSpecificChannel	<p>A DcmDspComControlSpecificChannel container is created for every different pair of SPECIFIC-CHANNEL and SUBNET-NUMBER elements from a DIAGNOSTIC-COM-CONTROL-SPECIFIC-CHANNEL of a DIAGNOSTIC-COM-CONTROL-CLASS of the current ECU. The container name is &lt;name&gt;&lt;SUFFIX&gt;, where &lt;name&gt; is derived from the short name of the SPECIFIC-CHANNEL element and the &lt;SUFFIX&gt; is _SC_ and the number of the current container created.</p> <p>DcmDspSubnetNumber is set to the value of DIAGNOSTIC-COM-CONTROL-SPECIFIC-CHANNEL/SUBNET-NUMBER.</p> <p>DcmDspSpecificComMChannelRef is set to DIAGNOSTIC-COM-CONTROL-CLASS/SPECIFIC-CHANNEL reference.</p>
DcmConfigSet/DcmDsp/DcmDspComControl/DcmDspComControlSubNode	<p>A DcmDspComControlSubNode container is created for every different pair of SUBNODE-CHANNEL and SUBNODE-NUMBER elements from a DIAGNOSTIC-COM-CONTROL-SUBNODE-CHANNEL of a DIAGNOSTIC-COM-CONTROL-CLASS of the current ECU. The container name is &lt;name&gt;&lt;SUFFIX&gt;, where &lt;name&gt; is derived from the short name of the SUBNODE-CHANNEL element and the &lt;SUFFIX&gt; is _SubNode_ and the number of the current container created.</p> <p>DcmDspComControlSubNodeId is set to the value of DIAGNOSTIC-COM-CONTROL-SUBNODE-CHANNEL/SUBNODE-NUMBER.</p> <p>DcmDspComControlSubNodeComMChannelRef is set to DIAGNOSTIC-COM-CONTROL-SUBNODE-CHANNEL/SUBNODE-CHANNEL reference.</p>
DcmConfigSet/DcmDsp/DcmDspSession	<p>A DcmDspSession subcontainer is created for every DIAGNOSTIC-SESSION referenced by a DIAGNOSTIC-ACCESS-PERMISSION associated with any DiagnosticServiceInstance of the current ECU. For more information on how the DIAGNOSTIC-ACCESS-PERMISSION of a DiagnosticServiceInstance is retrieved, see <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>. The container name is DIAGNOSTIC-SESSION/SHORT-NAME of the DIAGNOSTIC-SESSION-CONTROL.</p>

Configuration parameters	Mapping description
	<p>DcmDspSessionForBoot is set to DIAGNOSTIC-SESSION/JUMP-TO-BOOT-LOADER.</p> <p>DcmDspSessionLevel is set to DIAGNOSTIC-SESSION/ID.</p> <p>DcmDspSessionP2ServerMax is set to DIAGNOSTIC-SESSION/P-2-SERVER-MAX.</p> <p>DcmDspSessionP2StarServerMax is set to DIAGNOSTIC-SESSION/P-2-STAR-SERVER-MAX.</p>
DcmConfigSet/DcmDsp/DcmDspSecurity	<p>A DcmDspSecurity subcontainer is created for every DIAGNOSTIC-SECURITY-ACCESS referenced by a DIAGNOSTIC-ACCESS-PERMISSION associated with any DiagnosticServiceInstance of the current ECU. For more information on how the DIAGNOSTIC-ACCESS-PERMISSION of a DiagnosticServiceInstance is retrieved, see <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>. The container name is DIAGNOSTIC-SECURITY-LEVEL/SHORT-NAME of the DIAGNOSTIC-SECURITY-ACCESS.</p> <p>DcmDspSecurityADRSIZE is set to DIAGNOSTIC-SECURITY-LEVEL/ACCESS-DATA-RECORD-SIZE.</p> <p>DcmDspSecurityDelayTimeOnBoot is set to DIAGNOSTIC-SECURITY-LEVEL/SECURITY-DELAY-TIME.</p> <p>DcmDspSecurityKeySize is set to DIAGNOSTIC-SECURITY-LEVEL/KEY-SIZE.</p> <p>DcmDspSecurityLevel is set to (DIAGNOSTIC-SECURITY-ACCESS/REQUEST-SEED-ID + 1) / 2.</p> <p>DcmDspSecurityNumAttDelay is set to DIAGNOSTIC-SECURITY-LEVEL/NUM-FAILED-SECURITY-ACCESS.</p> <p>DcmDspSecuritySeedSize is set to DIAGNOSTIC-SECURITY-LEVEL/SEED-SIZE.</p>
DcmConfigSet/DcmDsp/DcmDspDataUsePort	<p>A DcmDspDataUsePort subcontainer indicates the interface that shall be used to access the data.</p> <p>USE_DATA_ASYNC_CLIENT_SERVER if DiagnosticProcessingStyleEnum is equal to processingStyleAsynchronous. The DiagnosticProcessingStyleEnum is taken from the DiagnosticServiceSwMapping that has a SwcServiceDependency taken directly from</p>

Configuration parameters	Mapping description
	<p>MappedFlatSwcServiceDependency or indirectly from MappedSwcServiceDependency with a target value taken from the SwcServiceDependencyInCompositionRef.</p> <p>USE_DATA_ASYNC_FNC if DiagnosticServiceSwMapping has a BswServiceDependency and DiagnosticProcessingStyleEnum is equal to processingStyleAsynchronous.</p> <p>USE_DATA_SYNC_CLIENT_SERVER if DiagnosticProcessingStyleEnum is equal to processingStyleSynchronous. The DiagnosticProcessingStyleEnum is taken from the DiagnosticServiceSwMapping that has a SwcServiceDependency taken directly from MappedFlatSwcServiceDependency or indirectly from MappedSwcServiceDependency with a target value taken from the SwcServiceDependencyInCompositionRef.</p> <p>USE_DATA_SYNC_FNC if DiagnosticServiceSwMapping has a BswServiceDependency and DiagnosticProcessingStyleEnum is equal to processingStyleSynchronous.</p> <p>If USE_DATA_ASYNC_CLIENT_SERVER or USE_DATA_SYNC_CLIENT_SERVER is set on DcmDspDataUsePort then the value of the parameter /Dcm/DcmConfigSet/DcmGeneral/DcmRteUsage is set to true.</p>
DcmConfigSet/DcmDsp/DcmDspControlDTCSetting	<p>A DcmDspControlDTCSetting subcontainer is created for the first occurrence of DIAGNOSTIC-CONTROL-DTC-SETTING. The container name is set to DcmDspControlDTCSetting.</p> <p>DcmSupportDTCSettingControlOptionRecord is set to DIAGNOSTIC-CONTROL-DTC-SETTING-CLASS/CONTROL-OPTION-RECORD-PRESENT referenced by DIAGNOSTIC-CONTROL-DTC-SETTING.</p>
DcmConfigSet/DcmDsp/DcmDspData	<p>For every DIAGNOSTIC-DATA-IDENTIFIER/DIAGNOSTIC-PARAMETER/DIAGNOSTIC-DATA-ELEMENT referenced by DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER and DIAGNOSTIC-READ-DATA-BY-IDENTIFIER service instance which belongs to the imported ECU-INSTANCE, a DcmDspData container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;PREFIX&gt; is DspData_ + I where I is a counter and &lt;name&gt; is the DIAGNOSTIC-DATA-ELEMENT/SHORT-NAME.</p> <p>DcmDspDataType is set depending on SW-BASE-TYPE/BASE-TYPE-ENCODING and SW-BASE-TYPE/BASE-TYPE-SIZE:</p> <p>► UINT8 for BASE-TYPE-ENCODING NONE and BASE-TYPE-SIZE 8</p>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ <b>UINT16</b> for BASE-TYPE-ENCODING NONE and BASE-TYPE-SIZE 16</li> <li>▶ <b>UINT32</b> for BASE-TYPE-ENCODING NONE and BASE-TYPE-SIZE 32</li> <li>▶ <b>SINT8</b> for BASE-TYPE-ENCODING 2C and BASE-TYPE-SIZE 8</li> <li>▶ <b>SINT16</b> for BASE-TYPE-ENCODING 2C and BASE-TYPE-SIZE 16</li> <li>▶ <b>SINT32</b> for BASE-TYPE-ENCODING 2C and BASE-TYPE-SIZE 32</li> <li>▶ <b>BOOLEAN</b> for BASE-TYPE-ENCODING BOOLEAN and BASE-TYPE-SIZE 1 or BASE-TYPE-SIZE 8</li> </ul> <p>DcmDspDataSize is set depending on the ARRAY-SIZE-SEMANTICS if it is FIXED-SIZE. Then the BASE-TYPE-SIZE associated with the DIAGNOSTIC-DATA-ELEMENT is obtained and set to the value <math>\text{DIAGNOSTIC-DATA-ELEMENT}/\text{MAX-NUMBER-OF-ELEMENTS} * \text{BASE-TYPE-SIZE}</math>. If the ARRAY-SIZE-SEMANTICS value of the DIAGNOSTIC-DATA-ELEMENT is VARIABLE-SIZE, the DcmDspDataSize value is set to <math>\text{DIAGNOSTIC-DATA-ELEMENT}/\text{MAX-NUMBER-OF-ELEMENTS} * 8</math>. If DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS is missing then its value is considered 0. If ARRAY-SIZE-SEMANTICS is not set then the value of DcmDspDataSize is set to the size given by BASE-TYPE-SIZE. For example 8 for UINT8, 16 for UINT16. DcmDspDataInfoRef is set to DcmConfigSet/DcmDsp/DcmDspDataInfo/DcmDspDataInfo_0 if the ArraySizeSemantics value of the DiagnosticDataElement is FIXED-SIZE else it references DcmConfigSet/DcmDsp/DcmDspDataInfo/DcmDspDataInfo_1 if the ArraySizeSemantics value of the DiagnosticDataElement is VARIABLE-SIZE.</p>
DcmConfigSet/DcmDsp/DcmDspDidInfo	<p>For each different Diagnostic-Data-Identifier referenced by a DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER, DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER or DIAGNOSTIC-READ-DATA-BY-IDENTIFIER service instance which belongs to the imported ECU-INSTANCE a single DcmDspDidInfo is created if DcmDspDidDynamicallyDefined, DcmDspDDDIDMaxElements, and DcmDspDidAccess parameters are the same in every service instance. If the service instance is a DIAGNOSTIC-IO-CONTROL then the following parameters are also checked: FreezeCurrentState, ResetToDefault, and ShortTermAdjustment. If they are different, a new DcmDspDidInfo is created. If any two of the above service instances refers a different Diagnostic-Data-Identifier, however have the same AccessPermission then an extra check is done in order to see if there is already a matching DcmDspDidInfo that can be used or if a new one needs to be created. The information contained by DcmDspDidInfo will not be</p>

Configuration parameters	Mapping description
	<p>the same. The container name is set to <code>DcmDspDidInfo_&lt;suffix&gt;</code>, where the <code>&lt;suffix&gt;</code> is set to the number of the container created.</p> <p><code>DcmDspDidDynamicallyDefined</code> is set to true or false according to <code>DataIdentifier</code> from <code>DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER</code>.</p>
<p><code>DcmConfigSet/DcmDsp/DcmDspDidInfo/DcmDspDidAccess/DcmDspDidRead</code></p>	<p>If at least one <code>DIAGNOSTIC-READ-DATA-BY-IDENTIFIER</code> exists, a <code>DcmDspDidRead</code> container is created.</p> <p><code>DcmDspDidReadSecurityLevelRef</code> references all the corresponding <code>DcmDspSecurity</code> containers that correspond to the <code>DIAGNOSTIC-SECURITY-LEVEL</code> entities which the <code>DIAGNOSTIC-ACCESS-PERMISSION</code> associated with the <code>DIAGNOSTIC-READ-DATA-BY-IDENTIFIER</code> references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p> <p><code>DcmDspDidReadSessionRef</code> references all the associated <code>DcmDspSession</code> containers that correspond to the <code>DIAGNOSTIC-SESSION</code> entities which the <code>DIAGNOSTIC-ACCESS-PERMISSION</code> associated with the <code>DIAGNOSTIC-READ-DATA-BY-IDENTIFIER</code> references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p>
<p><code>DcmConfigSet/DcmDsp/DcmDspDidInfo/DcmDspDidAccess/DcmDspDidWrite</code></p>	<p>If at least one <code>DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER</code> exists, a <code>DcmDspDidWrite</code> container is created.</p> <p><code>DcmDspDidWriteSecurityLevelRef</code> references all the corresponding <code>DcmDspSecurity</code> containers that correspond to the <code>DIAGNOSTIC-SECURITY-LEVEL</code> entities which the <code>DIAGNOSTIC-ACCESS-PERMISSION</code> associated with the <code>DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER</code> references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p> <p><code>DcmDspDidWriteSessionRef</code> references all the associated <code>DcmDspSession</code> containers that correspond to the <code>DIAGNOSTIC-SESSION</code> entities which the <code>DIAGNOSTIC-ACCESS-PERMISSION</code> associated with the <code>DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER</code> references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p>
<p><code>DcmConfigSet/DcmDsp/DcmDspDid</code></p>	<p>For every <code>DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER</code> and <code>DIAGNOSTIC-READ-DATA-BY-IDENTIFIER</code> service instance which belongs to the imported <code>ECU-INSTANCE</code>, a <code>DcmDspDid</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;PREFIX&gt;</code> is <code>DspDid_</code> + I where I is a</p>

Configuration parameters	Mapping description
	<p>counter and &lt;name&gt; is set to DIAGNOSTIC-DATA-IDENTIFIER/SHORT-NAME of DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER and DIAGNOSTIC-READ-DATA-BY-IDENTIFIER.</p> <p>DcmDspDidIdentifier is set to DIAGNOSTIC-DATA-IDENTIFIER/ID.</p> <p>DcmDspDidInfoRef references the corresponding DcmDspDidInfo container.</p>
DcmConfigSet/DcmDsp/DcmDspDid/DcmDspDidSignal	<p>For every DIAGNOSTIC-DATA-IDENTIFIER/DIAGNOSTIC-PARAMETER referenced by DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER and DIAGNOSTIC-READ-DATA-BY-IDENTIFIER service instance which belongs to the imported ECU-INSTANCE, a DcmDspDidSignal container is created. The container name is DcmDspDidSignal_&lt;suffix&gt;, where &lt;suffix&gt; is set to the zero-based position index of the DIAGNOSTIC-PARAMETER within the DIAGNOSTIC-DATA-IDENTIFIER.</p> <p>DcmDspDidDataPos is set to DIAGNOSTIC-PARAMETER/BIT-OFFSET.</p> <p>DcmDspDidDataRef references the DcmDspDid created which was created to represent the DIAGNOSTIC-DATA-ELEMENT of the current DIAGNOSTIC-PARAMETER.</p>
DcmConfigSet/DcmDsp/DcmDspRoutine	<p>For every DIAGNOSTIC-ROUTINE-CONTROL service instance which belongs to the imported ECU-INSTANCE, a DcmDspRoutine container is created. The container name is set to DIAGNOSTIC-ROUTINE/SHORT-NAME of DIAGNOSTIC-ROUTINE-CONTROL.</p> <p>DcmDspRoutineIdentifier is set to DIAGNOSTIC-ROUTINE/ID.</p> <p>DcmDspRoutineInfoRef references the corresponding DcmDspRoutineInfo container.</p> <p>DcmDspRoutineUsePort is set to true if the DIAGNOSTIC-ROUTINE is configured for a SWC-SERVICE-DEPENDENCY based on a MAPPED-FLAT-SWC-SERVICE-DEPENDENCY or a MAPPED-SWC-SERVICE-DEPENDENCY via DIAGNOSTIC-SERVICE-SW-MAPPING. If at least one DcmDspRoutineUsePort is set to true, the value of the parameter /Dcm/DcmConfigSet/DcmGeneral/DcmRteUsage is set to true.</p> <p>Is set to true, if the DiagnosticRoutine has a DiagnosticRequestRoutineResults configured.</p> <p>Is set to true, if the DiagnosticRoutine has a DiagnosticStopRoutine configured.</p>



Configuration parameters	Mapping description
	DcmDspRoutineFixedLength is set to false if all the signals referenced by the DIAGNOSTIC-ROUTINE are of type VARIABLE_SIZE. Otherwise, the DcmDspRoutineFixedLength is set to true.
DcmConfigSet/DcmDsp/DcmDspRoutineInfo	For every DIAGNOSTIC-ROUTINE-CONTROL service instance which belongs to the imported ECU-INSTANCE, a DcmDspRoutineInfo container is created. The container name is set to DcmDspRoutineInfo_<suffix>, where <suffix> is set to DIAGNOSTIC-ROUTINE/ID of DIAGNOSTIC-ROUTINE-CONTROL.
DcmConfigSet/DcmDsp/DcmDspRoutineInfo/DcmDspRoutineAuthorization	<p>If at least one DIAGNOSTIC-ROUTINE-CONTROL exists, a DcmDspRoutineAuthorization container is created.</p> <p>DcmDspRoutineSecurityLevelRef references all the corresponding DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-ROUTINE-CONTROL references. For more information, see <a href="#">Section 3.4.10.22, "Determining the access permissions for diagnostic service instances"</a>.</p> <p>DcmDspRoutineSessionRef references all the associated DcmDspSession containers that correspond to the DIAGNOSTIC-SESSION entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-ROUTINE-CONTROL references. For more information, see <a href="#">Section 3.4.10.22, "Determining the access permissions for diagnostic service instances"</a>.</p>
DcmConfigSet/DcmDsp/DcmDspRoutineInfo/DcmDspStartRoutineIn/DcmDspStartRoutineInSignal	<p>For every request DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-ROUTINE/START a DcmDspStartRoutineInSignal container is created. The container name is set to DIAGNOSTIC-DATA-ELEMENT/SHORT-NAME aggregated by DIAGNOSTIC-PARAMETER</p> <p>DcmDspRoutineSignalLength is set depending on the ARRAY-SIZE-SEMANTICS if it is FIXED-SIZE. Then the BASE-TYPE-SIZE associated with the DIAGNOSTIC-DATA-ELEMENT is obtained and set to the value DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * BASE-TYPE-SIZE. If the ARRAY-SIZE-SEMANTICS value of the DIAGNOSTIC-DATA-ELEMENT is VARIABLE-SIZE, the DcmDspRoutineSignalLength value is set to DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS*8. If DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS is missing then its value is considered 0. If ARRAY-SIZE-SEMANTICS is not set then the value of DcmDspRoutineSignalLength is set to the size given by BASE-TYPE-SIZE.</p>

Configuration parameters	Mapping description
	<p>For example 8 for UINT8, 16 for UINT16 etc. See also <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a>.</p> <p>DcmDspRoutineSignalPos is set to DIAGNOSTIC-PARAMETER/BIT-OFFSET.</p> <p>DcmDspRoutineSignalType is set based on <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a>.</p>
DcmConfigSet/DcmDsp/DcmDspRoutineInfo/DcmDspStartRoutineOut/DcmDspStartRoutineOutSignal	<p>For every response DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-ROUTINE/START a DcmDspStartRoutineOutSignal container is created. The container name is set to DIAGNOSTIC-DATA-ELEMENT/SHORT-NAME aggregated by DIAGNOSTIC-PARAMETER</p> <p>DcmDspRoutineSignalLength is set depending on the ARRAY-SIZE-SEMANTICS if it is FIXED-SIZE. Then the BASE-TYPE-SIZE associated with the DIAGNOSTIC-DATA-ELEMENT is obtained and set to the value DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * BASE-TYPE-SIZE. If the ARRAY-SIZE-SEMANTICS value of the DIAGNOSTIC-DATA-ELEMENT is VARIABLE-SIZE, the DcmDspRoutineSignalLength value is set to DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS*8. If DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS is missing then its value is considered 0. If ARRAY-SIZE-SEMANTICS is not set then the value of DcmDspRoutineSignalLength is set to the size given by BASE-TYPE-SIZE. For example 8 for UINT8, 16 for UINT16 etc. See also <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a>.</p> <p>DcmDspRoutineSignalPos is set to DIAGNOSTIC-PARAMETER/BIT-OFFSET.</p> <p>DcmDspRoutineSignalType is set based on <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a>.</p>
DcmConfigSet/DcmDsp/DcmDspRoutineInfo/DcmDspRoutineStopIn/DcmDspRoutineStopInSignal	<p>For every request DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-ROUTINE/STOP a DcmDspRoutineStopInSignal container is created. The container name is set to DIAGNOSTIC-DATA-ELEMENT/SHORT-NAME aggregated by DIAGNOSTIC-PARAMETER</p> <p>DcmDspRoutineSignalLength is set depending on the ARRAY-SIZE-SEMANTICS if it is FIXED-SIZE. Then the BASE-TYPE-SIZE associated with the DIAGNOSTIC-DATA-ELEMENT is obtained and set to the value DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * BASE-TYPE-SIZE. If the ARRAY-SIZE-SEMANTICS value of the DIAGNOSTIC-DATA-ELEMENT</p>

Configuration parameters	Mapping description
	<p>is VARIABLE-SIZE, the DcmDspRoutineSignalLength value is set to DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS*8. If DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS is missing then its value is considered 0. If ARRAY-SIZE-SEMANTICS is not set then the value of DcmDspRoutineSignalLength is set to the size given by BASE-TYPE-SIZE. For example 8 for UINT8, 16 for UINT16 etc. See also <a href="#">Section 3.4.10.23, "Determining the type for a routine signal"</a>.</p> <p>DcmDspRoutineSignalPos is set to DIAGNOSTIC-PARAMETER/BIT-OFFSET.</p> <p>DcmDspRoutineSignalType is set based on <a href="#">Section 3.4.10.23, "Determining the type for a routine signal"</a>.</p>
DcmConfigSet/DcmDsp/DcmDspRoutineInfo/DcmDspRoutineStopOut/DcmDspRoutineStopOutSignal	<p>For every response DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-ROUTINE/STOP a DcmDspRoutineStopOutSignal container is created. The container name is set to DIAGNOSTIC-DATA-ELEMENT/SHORT-NAME aggregated by DIAGNOSTIC-PARAMETER</p> <p>DcmDspRoutineSignalLength is set depending on the ARRAY-SIZE-SEMANTICS if it is FIXED-SIZE. Then the BASE-TYPE-SIZE associated with the DIAGNOSTIC-DATA-ELEMENT is obtained and set to the value DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * BASE-TYPE-SIZE. If the ARRAY-SIZE-SEMANTICS value of the DIAGNOSTIC-DATA-ELEMENT is VARIABLE-SIZE, the DcmDspRoutineSignalLength value is set to DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS*8. If DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS is missing then its value is considered 0. If ARRAY-SIZE-SEMANTICS is not set then the value of DcmDspRoutineSignalLength is set to the size given by BASE-TYPE-SIZE. For example 8 for UINT8, 16 for UINT16 etc. See also <a href="#">Section 3.4.10.23, "Determining the type for a routine signal"</a>.</p> <p>DcmDspRoutineSignalPos is set to DIAGNOSTIC-PARAMETER/BIT-OFFSET.</p> <p>DcmDspRoutineSignalType is set based on <a href="#">Section 3.4.10.23, "Determining the type for a routine signal"</a>.</p>
DcmConfigSet/DcmDsp/DcmDspRoutineInfo/DcmDspRoutineRequestResIn/DcmDspRoutineRequestResInSignal	<p>If the REQUESTS tag exists inside the DiagnosticExtract, then for every request DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-ROUTINE/REQUEST-RESULT a DcmDspRoutineRequestResInSignal container is created. The container name is set to DIAGNOSTIC-DATA-ELEMENT/SHORT-NAME aggregated by DIAGNOSTIC-PARAMETER</p>

Configuration parameters	Mapping description
tineRequestResInSignal	<p>DcmDspRoutineSignalLength is set depending on the ARRAY-SIZE-SEMANTICS if it is FIXED-SIZE. Then the BASE-TYPE-SIZE associated with the DIAGNOSTIC-DATA-ELEMENT is obtained and set to the value DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * BASE-TYPE-SIZE. If the ARRAY-SIZE-SEMANTICS value of the DIAGNOSTIC-DATA-ELEMENT is VARIABLE-SIZE, the DcmDspRoutineSignalLength value is set to DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS*8. If DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS is missing then its value is considered 0. If ARRAY-SIZE-SEMANTICS is not set then the value of DcmDspRoutineSignalLength is set to the size given by BASE-TYPE-SIZE. For example 8 for UINT8, 16 for UINT16 etc. See also <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a>.</p> <p>DcmDspRoutineSignalPos is set to DIAGNOSTIC-PARAMETER/BIT-OFFSET.</p> <p>DcmDspRoutineSignalType is set based on <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a>.</p>
DcmConfigSet/DcmDsp/DcmDspRoutineInfo/DcmDspRoutineRequestResOut/DcmDspRoutineRequestResOutSignal	<p>For every response DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-ROUTINE/REQUEST-RESULT a DcmDspRoutineRequestResOutSignal container is created. The container name is set to DIAGNOSTIC-DATA-ELEMENT/SHORT-NAME aggregated by DIAGNOSTIC-PARAMETER</p> <p>DcmDspRoutineSignalLength is set depending on the ARRAY-SIZE-SEMANTICS if it is FIXED-SIZE. Then the BASE-TYPE-SIZE associated with the DIAGNOSTIC-DATA-ELEMENT is obtained and set to the value DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * BASE-TYPE-SIZE. If the ARRAY-SIZE-SEMANTICS value of the DIAGNOSTIC-DATA-ELEMENT is VARIABLE-SIZE, the DcmDspRoutineSignalLength value is set to DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS*8. If DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS is missing then its value is considered 0. If ARRAY-SIZE-SEMANTICS is not set then the value of DcmDspRoutineSignalLength is set to the size given by BASE-TYPE-SIZE. For example 8 for UINT8, 16 for UINT16 etc. See also <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a>.</p> <p>DcmDspRoutineSignalPos is set to DIAGNOSTIC-PARAMETER/BIT-OFFSET.</p>

Configuration parameters	Mapping description
	DcmDspRoutineSignalType is set based on <a href="#">Section 3.4.10.23, “Determining the type for a routine signal”</a> .
DcmConfigSet/DcmDsp/DcmDspVehInfo	<p>For every DIAGNOSTIC-REQUEST-VEHICLE-INFO service instance which belongs to the imported ECU-INSTANCE, a DcmDspVehInfo container is created. The container name is set to DcmDspVehInfo&lt;suffix&gt;, where &lt;suffix&gt; is an underscore followed by VEHICLE-INFO-TYPE/ID.</p> <p>DcmDspVehInfoInfoType is set with the value of VEHICLE-INFO-TYPE/ID.</p>
DcmConfigSet/DcmDsp/DcmDspVehInfo/DcmDspVehInfoData	<p>The DcmDspVehInfoData subcontainer is created for every request DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-REQUEST-VEHICLE-INFO. The name of DcmDspVehInfoData sub container is derived from the short name of the DIAGNOSTIC-DATA-ELEMENT aggregated by the DIAGNOSTIC-PARAMETER.</p> <p>DcmDspVehInfoDataOrder parameter will be take the value from DATA-ELEMENT/bitOffset that it is bellonged to DIAGNOSTIC-INFO-TYPE aggregated by the DIAGNOSTIC-REQUEST-VEHICLE-INFO .</p> <p>DcmDspVehInfoDataReadFnc parameter will take the value based on the DIAGNOSTIC-SERVICE-SW-MAPPING that has set the reference to a MAPPED-BSW-SERVICE-DEPENDENCY . The BSW-SERVICE-DEPENDENCY should have a ROLE-BASED-BSW-MODULE-ENTRY-ASSIGNMENT that in turn has attribute role set to Xxx_GetInfotypeValueData and points to a BSW-MODULE-ENTRY .</p> <p>DcmDspVehInfoDataSize parameter will take the value from DATA-ELEMENT/numberOfElements that it is bellonged to DIAGNOSTIC-INFO-TYPE aggregated by the DIAGNOSTIC-REQUEST-VEHICLE-INFO .</p> <p>DcmDspVehInfoDataUsePort parameter will be set to true if the reference DIAGNOSTIC-SERVICE-SW-MAPPING/mappedSwServiceDepenedecy exists or will be set to false if the reference DIAGNOSTIC-SERVICE-SW-MAPPING/mappedBswServiceDependency exists. The DIAGNOSTIC-SERVICE-SW-MAPPING shall have a link with a DIAGNOSTIC-DATA-ELEMENT that is aggregated by a DIAGNOSTIC-REQUEST-VEHICLE-INFO .</p>
DcmConfigSet/DcmDsp/DcmDspPeriodicTransmission	For every response DIAGNOSTIC-PARAMETER aggregated by DIAGNOSTIC-PERIODIC-TRANSMISSION a DcmDspPeriodicTransmission container is created.

Configuration parameters	Mapping description
	<p>DcmDspPeriodicTransmission is set depending on the category of the rate.</p> <p>DcmDspPeriodicTransmissionRate is set to PERIODIC-RATE-SLOW or PERIODIC-RATE-MEDIUM or PERIODIC-RATE-FAST.</p> <p>DcmDspPeriodicTransmissionPeriod is set accordingly.</p>
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService	<p><b>For every <i>first</i> occurrence of a</b> DIAGNOSTIC-READ-DATA-BY-IDENTIFIER, DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER, DIAGNOSTIC-SESSION-CONTROL, DIAGNOSTIC-SECURITY-ACCESS, DIAGNOSTIC-ROUTINE-CONTROL, DIAGNOSTIC-READ-DTC-INFORMATION, DIAGNOSTIC-ECU-RESET, DIAGNOSTIC-COM-CONTROL, DIAGNOSTIC-DIAGNOSTIC-REQUEST-DOWNLOAD, DIAGNOSTIC-REQUEST-UPLOAD, DIAGNOSTIC-DATA-TRANSFER, DIAGNOSTIC-REQUEST-TRANSFER-EXIT, DIAGNOSTIC-READ-DATA-BY-PERIODIC-IDENTIFIER, DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER, DIAGNOSTIC-IO-CONTROL, DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS, DIAGNOSTIC-READ-MEMORY-BY-ADDRESS, DIAGNOSTIC-REQUEST-CONTROL-OF-ON-BOARD-DEVICE DIAGNOSTIC-CLEAR-DIAGNOSTIC-INFORMATION, DIAGNOSTIC-REQUEST-POWERTRAIN_FREEZE-FRAME-DATA, DIAGNOSTIC-REQUEST-CURRENT-POWERTRAIN-DIAGNOSTIC-DATA, DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC-PERMANENT-STATUS, DIAGNOSTIC-CONTROL-DTC-SETTING, DIAGNOSTIC-REQUEST-ON-BOARD-MONITORING-TEST-RESULTS, DIAGNOSTIC-REQUEST-VEHICLE-INFO, DIAGNOSTIC-CLEAR-RESET-EMISSION-RELATED-INFO <b>service instance which belongs to the imported ECU-INSTANCE, a DcmDsdService container is created. The container name is set to one of the following:</b></p> <ul style="list-style-type: none"> <li>▶ DiagnosticReadDataByIdentifier <b>for</b> DIAGNOSTIC-READ-DATA-BY-IDENTIFIER.</li> <li>▶ DiagnosticWriteDataByIdentifier <b>for</b> DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER.</li> <li>▶ DiagnosticSessionControl <b>for</b> DIAGNOSTIC-SESSION-CONTROL.</li> <li>▶ DiagnosticSecurityAccess <b>for</b> DIAGNOSTIC-SECURITY-ACCESS.</li> <li>▶ DiagnosticRoutineControl <b>for</b> DIAGNOSTIC-ROUTINE-CONTROL.</li> <li>▶ DiagnosticReadDTCInformation <b>for</b> DIAGNOSTIC-READ-DTC-INFORMATION.</li> <li>▶ DiagnosticEcuReset <b>for</b> DIAGNOSTIC-ECU-RESET.</li> <li>▶ DiagnosticComControl <b>for</b> DIAGNOSTIC-COM-CONTROL.</li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ DiagnosticRequestVehicleInfo <b>for</b> DIAGNOSTIC-REQUEST-VEHICLE-INFO.</li> <li>▶ DiagnosticRequestOnBoardMonitoringTestResults <b>for</b> DIAGNOSTIC-REQUEST-ON-BOARD-MONITORING-TEST-RESULTS.</li> <li>▶ DiagnosticRequestDownload <b>for</b> DIAGNOSTIC-REQUEST-DOWNLOAD.</li> <li>▶ DiagnosticRequestUpload <b>for</b> DIAGNOSTIC-REQUEST-UPLOAD.</li> <li>▶ DiagnosticDataTransfer <b>for</b> DIAGNOSTIC-DATA-TRANSFER.</li> <li>▶ DiagnosticRequestTransferExit <b>for</b> DIAGNOSTIC-REQUEST-TRANSFER-EXIT.</li> <li>▶ DiagnosticReadDataByPeriodicIdentifier <b>for</b> DIAGNOSTIC-READ-DATA-BY-PERIODIC-IDENTIFIER.</li> <li>▶ DiagnosticWriteMemoryByAddress <b>for</b> DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS.</li> <li>▶ DiagnosticReadMemoryByAddress <b>for</b> DIAGNOSTIC-READ-MEMORY-BY-ADDRESS.</li> <li>▶ DiagnosticIOControl <b>for</b> DIAGNOSTIC-IO-CONTROL.</li> <li>▶ DiagnosticControlDTCSetting <b>for</b> DIAGNOSTIC-CONTROL-DTC-SETTING.</li> <li>▶ DiagnosticDynamicallyDefineDataIdentifier <b>for</b> DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER.</li> <li>▶ DiagnosticRequestControlOfOnBoardDevice <b>for</b> DIAGNOSTIC-REQUEST-CONTROL-OF-ON-BOARD-DEVICE.</li> <li>▶ DiagnosticClearDiagnosticInformation <b>for</b> DIAGNOSTIC-CLEAR-DIAGNOSTIC-INFORMATION.</li> <li>▶ DiagnosticRequestPowertrainFreezeFrameData <b>for</b> DIAGNOSTIC-REQUEST-POWERTRAIN_FREEZE-FRAME-DATA.</li> <li>▶ DiagnosticRequestCurrentPowertrainDiagnosticData <b>for</b> DIAGNOSTIC-REQUEST-CURRENT-POWERTRAIN-DIAGNOSTIC-DATA.</li> <li>▶ DiagnosticRequestEmissionRelatedDTCPermanentStatus <b>for</b> DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC-PERMANENT-STATUS.</li> <li>▶ DiagnosticClearResetEmissionRelatedInfo <b>for</b> DIAGNOSTIC-CLEAR-RESET-EMISSION-RELATED-INFO.</li> </ul>

Configuration parameters	Mapping description
	<p>For every <i>first</i> occurrence of a DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC service instance which belongs to the imported ECU-INSTANCE, two DcmDsdService containers are created. The containers name are set to the following:</p> <ul style="list-style-type: none"> <li>▶ DiagnosticRequestEmissionRelatedDTC_03 for DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC.</li> <li>▶ DiagnosticRequestEmissionRelatedDTC_07 for DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC.</li> </ul> <p>From the second occurrence onwards, only the configuration parameters DcmDsdSidTabSessionLevelRef and DcmDsdSidTabSecurityLevelRef are updated. If AccessPermissionValidity is set to ACCESS-PERMISSION-SERVICE-INSTANCE then DcmDsdSidTabSessionLevelRef and DcmDsdSidTabSecurityLevelRef are empty. The DcmDsdSidTabSessionLevelRef and DcmDsdSidTabSecurityLevelRef are configurable only from data identifiers (DIDs).</p> <p>DcmDsdSidTabServiceId is set to one of the following:</p> <ul style="list-style-type: none"> <li>▶ 0x10 for DIAGNOSTIC-SESSION-CONTROL.</li> <li>▶ 0x27 for DIAGNOSTIC-SECURITY-ACCESS.</li> <li>▶ 0x22 for DIAGNOSTIC-READ-DATA-BY-IDENTIFIER.</li> <li>▶ 0x2E for DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER.</li> <li>▶ 0x31 for DIAGNOSTIC-ROUTINE-CONTROL.</li> <li>▶ 0x19 for DIAGNOSTIC-READ-DTC-INFORMATION.</li> <li>▶ 0x11 for DIAGNOSTIC-ECU-RESET.</li> <li>▶ 0x28 for DIAGNOSTIC-COM-CONTROL.</li> <li>▶ 0x09 for DIAGNOSTIC-REQUEST-VEHICLE-INFO.</li> <li>▶ 0x06 for DIAGNOSTIC-REQUEST-ON-BOARD-MONITORING-TEST-RESULTS.</li> <li>▶ 0x34 for DIAGNOSTIC-REQUEST-DOWNLOAD.</li> <li>▶ 0x35 for DIAGNOSTIC-REQUEST-UPLOAD.</li> <li>▶ 0x36 for DIAGNOSTIC-DATA-TRANSFER.</li> <li>▶ 0x37 for DIAGNOSTIC-REQUEST-TRANSFER-EXIT.</li> <li>▶ 0x2A for DIAGNOSTIC-READ-DATA-BY-PERIODIC-IDENTIFIER.</li> </ul>



Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ 0x2F for DIAGNOSTIC-IO-CONTROL.</li> <li>▶ 0x3D for DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS.</li> <li>▶ 0x23 for DIAGNOSTIC-READ-MEMORY-BY-ADDRESS.</li> <li>▶ 0x85 for DIAGNOSTIC-CONTROL-DTC-SETTING.</li> <li>▶ 0x2C for DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER.</li> <li>▶ 0x14 for DIAGNOSTIC-CLEAR-DIAGNOSTIC-INFORMATION.</li> <li>▶ 0x08 for DIAGNOSTIC-REQUEST-CONTROL-OF-ON-BOARD-DEVICE.</li> <li>▶ 0x03 for DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC.</li> <li>▶ 0x07 for DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC.</li> <li>▶ 0x0A for DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC-PERMANENT-STATUS.</li> <li>▶ 0x02 for DIAGNOSTIC-REQUEST-POWERTRAIN_FREEZE-FRAME-DATA.</li> <li>▶ 0x01 for DIAGNOSTIC-REQUEST-CURRENT-POWERTRAIN-DIAGNOSTIC-DATA.</li> <li>▶ 0x04 for DIAGNOSTIC-CLEAR-RESET-EMISSION-RELATED-INFO.</li> </ul> <p>DcmDsdSidTabSessionLevelRef references the following:</p> <ul style="list-style-type: none"> <li>▶ Nothing for DIAGNOSTIC-SESSION-CONTROL diagnostic service instance.</li> <li>▶ All the DcmDspSession containers that correspond to the DIAGNOSTIC-SESSION entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the diagnostic service instance references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</li> </ul> <p>DcmDsdSidTabSecurityLevelRef references the following:</p> <ul style="list-style-type: none"> <li>▶ Nothing for DIAGNOSTIC-SECURITY-ACCESS.</li> <li>▶ All the DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the diagnostic service instance references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</li> </ul> <p><b>Important :</b> In the case that the DiagnosticServiceClass.accessPermissionValidity value is ACCESSPERMISSIONSERVICEINSTANCE and</p>

Configuration parameters	Mapping description
	<p>there are no DiagnosticSecurityLevel or DiagnosticSession entities referenced by the AccessPermission associated with the DiagnosticServiceInstance, then the corresponding DcmDsdSidTabSecurityLevelRef or DcmDsdSidTabSessionLevelRef for that DiagnosticServiceInstance and for all the DiagnosticServiceInstance's that reference the same DiagnosticServiceClass will be set to empty.</p> <p>DcmDsdSidTabSubfuncAvail is set to one the following:</p> <ul style="list-style-type: none"> <li>▶ Not set for DIAGNOSTIC-SESSION-CONTROL.</li> <li>▶ Not set for DIAGNOSTIC-SECURITY-ACCESS.</li> <li>▶ Set to false for DIAGNOSTIC-READ-DATA-BY-IDENTIFIER.</li> <li>▶ Set to false for DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER.</li> <li>▶ Set to true for DIAGNOSTIC-ROUTINE-CONTROL.</li> <li>▶ Set to true for DIAGNOSTIC-READ-DTC-INFORMATION.</li> <li>▶ Set to true for DIAGNOSTIC-ECU-RESET.</li> <li>▶ Set to true for DIAGNOSTIC-COM-CONTROL.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-ON-BOARD-MONITORING-TEST-RESULTS.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-VEHICLE-INFO.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-DOWNLOAD.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-UPLOAD.</li> <li>▶ Set to false for DIAGNOSTIC-DATA-TRANSFER.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-TRANSFER-EXIT.</li> <li>▶ Set to true for DIAGNOSTIC-CONTROL-DTC-SETTING.</li> <li>▶ Set to false for DIAGNOSTIC-READ-DATA-BY-PERIODIC-IDENTIFIER.</li> <li>▶ Set to true for DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER.</li> <li>▶ Set to false for DIAGNOSTIC-IO-CONTROL.</li> <li>▶ Set to false for DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS.</li> <li>▶ Set to false for DIAGNOSTIC-READ-MEMORY-BY-ADDRESS.</li> <li>▶ Set to false for DIAGNOSTIC-CLEAR-DIAGNOSTIC-INFORMATION.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-CONTROL-OF-ON-BOARD-DEVICE.</li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ Set to false for DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-EMISSION-RELATED-DTC-PERMANENT-STATUS.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-CURRENT-POWERTRAIN-DIAGNOSTIC-DATA.</li> <li>▶ Set to false for DIAGNOSTIC-REQUEST-POWERTRAIN_FREEZE-FRAME-DATA.</li> <li>▶ Set to false for DIAGNOSTIC-CLEAR-RESET-EMISSION-RELATED-INFO.</li> </ul>

### 3.4.10.1. Configuration of subservices for Diagnostic Session Control

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>For every DIAGNOSTIC-SESSION-CONTROL a DcmDsdSubService container is created. The container name is set to DIAGNOSTIC-SESSION/SHORT-NAME of DIAGNOSTIC-SESSION-CONTROL.</p> <p>DcmDsdSubServiceId is set to DIAGNOSTIC-SESSION/ID.</p> <p>DcmDsdSubServiceSessionLevelRef references all the associated DcmDspSession containers that correspond to the DIAGNOSTIC-SESSION entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-SESSION-CONTROL references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p> <p>DcmDsdSubServiceSecurityLevelRef references all the associated DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-SESSION-CONTROL references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p>

### 3.4.10.2. Configuration of subservices for Diagnostic Security Access

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>For every DIAGNOSTIC-SECURITY-ACCESS <b>two</b> DcmDsdSubService containers are created. The name for the first container is &lt;name&gt;_requestSeed, where &lt;name&gt; is set to DIAGNOSTIC-SECURITY-ACCESS/SHORT-NAME. The name for the second container is &lt;name&gt;_sendKey, where &lt;name&gt; is set to DIAGNOSTIC-SECURITY-ACCESS/SHORT-NAME.</p> <p>DcmDsdSubServiceId is set to DIAGNOSTIC-SECURITY-ACCESS/REQUEST-SEED-ID for the first DcmDsdService container. DcmDsdSubServiceId is set to DIAGNOSTIC-SECURITY-ACCESS/REQUEST-SEED-ID+1 for the second DcmDsdService container.</p> <p>DcmDsdSubServiceSessionLevelRef references all the associated DcmDspSession containers that correspond to the DIAGNOSTIC-SESSION entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-SECURITY-ACCESS references. For more information, see also <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p> <p>The DcmDsdSubServiceSecurityLevelRef will not be configured.</p>

### 3.4.10.3. Configuration of subservices for Diagnostic Read Data By Identifier

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>Subservices are not applicable for the DIAGNOSTIC-READ-DATA-BY-IDENTIFIER diagnostic service instance and hence DcmDsdSubService containers are not created.</p>

#### 3.4.10.4. Configuration of subservices for Diagnostic Write Data By Identifier

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	Subservices are not applicable for the <code>DIAGNOSTIC-WRITE-DATA-BY-IDENTIFIER</code> diagnostic service instance and hence <code>DcmDsdSubService</code> containers are not created.

#### 3.4.10.5. Configuration of subservices for Diagnostic IOControl

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	Subservices are not applicable for the <code>DIAGNOSTIC-IO-CONTROL</code> diagnostic service instance and hence <code>DcmDsdSubService</code> containers are not created.

#### 3.4.10.6. Configuration of subservices for Diagnostic Write Memory By Address

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	Subservices are not applicable for the <code>DIAGNOSTIC-WRITE-MEMORY-BY-ADDRESS</code> diagnostic service instance and hence <code>DcmDsdSubService</code> containers are not created.

### 3.4.10.7. Configuration of subservices for Diagnostic Read Memory By Address

Configuration parameters	Mapping description
DcmCon- figSet/DcmDsd/ DcmDsdService- eTable/DcmDsdSer- vice/DcmDsdSubSer- vice	Subservices are not applicable for the DIAGNOSTIC-READ-MEMORY-BY-ADDRESS diagnostic service instance and hence DcmDsdSubService containers are not created.

### 3.4.10.8. Configuration of subservices for Diagnostic Routine Control

Configuration parameters	Mapping description
DcmCon- figSet/DcmDsd/ DcmDsdService- eTable/DcmDsdSer- vice/DcmDsdSubSer- vice	Subservices are not applicable for the DIAGNOSTIC-ROUTINE-CONTROL diagnostic service instance and hence DcmDsdSubService containers are not created.

### 3.4.10.9. Configuration of subservices for Diagnostic Read Data By Periodic Identifier

Configuration parameters	Mapping description
DcmCon- figSet/DcmDsd/ DcmDsdService- eTable/DcmDsdSer- vice/DcmDsdSubSer- vice	Subservices are not applicable for the DIAGNOSTIC-READ-DATA-BY-PERIODIC-IDENTIFIER diagnostic service instance and hence DcmDsdSubService containers are not created.

### 3.4.10.10. Configuration of subservices for Diagnostic Dynamically Define Data Identifier

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>For every DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER that has its Subfunction set, a DcmDsdSubService container is created. The container name is set to DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER/SUBFUNCTIONS.</p> <p>DcmDsdSubServiceId is set according to ISO-14229 to the corresponding value of DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER/SUBFUNCTIONS.</p> <p>DcmDsdSubServiceSessionLevelRef references all the associated DcmDspSession containers that correspond to the DIAGNOSTIC-DYNAMICALLY-DEFINE-DATA-IDENTIFIER entities with which the DIAGNOSTIC-ACCESS-PERMISSION is associated. For more information, see <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p> <p>DcmDsdSubServiceSecurityLevelRef references all the associated DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities with which the DIAGNOSTIC-ACCESS-PERMISSION is associated. For more information, see <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p>

### 3.4.10.11. Configuration of subservices for Diagnostic Clear Diagnostic Information

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>Subservices are not applicable for the DIAGNOSTIC-CLEAR-DIAGNOSTIC-INFORMATION diagnostic service instance and hence DcmDsdSubService containers are not created.</p>

### 3.4.10.12. Configuration of subservices for Diagnostic Read DTC Information

Configuration parameters	Mapping description
DcmConfigSet/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>For every <b>DIAGNOSTIC-READ-DTC-INFORMATION</b> that has its <b>CATEGORY</b> set, a <b>DcmDsdSubService</b> container is created. The container name is set to <b>DIAGNOSTIC-READ-DTC-INFORMATION/CATEGORY</b>.</p> <p><b>DcmDsdSubServiceId</b> is set according to ISO-14229 to the corresponding value of <b>DIAGNOSTIC-READ-DTC-INFORMATION/CATEGORY</b>.</p> <p><b>DcmDsdSubServiceSessionLevelRef</b> references all the associated <b>DcmDspSession</b> containers that correspond to the <b>DIAGNOSTIC-READ-DTC-INFORMATION</b> entities which the <b>DIAGNOSTIC-ACCESS-PERMISSION</b> associated. For more information, see <a href="#">Section 3.4.10.22, "Determining the access permissions for diagnostic service instances"</a>.</p> <p><b>DcmDsdSubServiceSecurityLevelRef</b> references all the associated <b>DcmDspSecurity</b> containers that correspond to the <b>DIAGNOSTIC-SECURITY-LEVEL</b> entities which the <b>DIAGNOSTIC-ACCESS-PERMISSION</b> associated with the <b>DIAGNOSTIC-READ-DTC-INFORMATION</b> references. For more information, see <a href="#">Section 3.4.10.22, "Determining the access permissions for diagnostic service instances"</a>.</p>

### 3.4.10.13. Configuration of diagnostic subservices EcuReset

Configuration parameters	Mapping description
DcmConfigSet/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>For every <b>DIAGNOSTIC-ECU-RESET</b> that has its <b>CATEGORY</b> set, a <b>DcmDsdSubService</b> container is created. The container name is set to <b>DIAGNOSTIC-ECU-RESET/CATEGORY</b>.</p> <p><b>DcmDsdSubServiceId</b> is set according to ISO-14229 to the corresponding value of <b>DIAGNOSTIC-ECU-RESET/CATEGORY</b>. In case you want to configure a custom sub service, then set the value of the sub service id based on <b>ECU-RESET/CUSTOM-SUB-FUNCTION-NUMBER</b>.</p> <p><b>DcmDsdSubServiceSessionLevelRef</b> references all the associated <b>DcmDspSession</b> containers that correspond to the <b>DIAGNOSTIC-ECU-RESET</b> entities with which the <b>DIAGNOSTIC-ACCESS-PERMISSION</b> is associated. For more information, see <a href="#">Section 3.4.10.22, "Determining the access permissions for diagnostic service instances"</a>.</p>



Configuration parameters	Mapping description
	DcmDsdSubServiceSecurityLevelRef references all the associated DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-ECU-RESET references. For more information, see <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a> .

### 3.4.10.14. Configuration of diagnostic subservices ComControl

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>For every DIAGNOSTIC-COM-CONTROL that has its CATEGORY set, a DcmDsdSubService container is created. The container name is set to DIAGNOSTIC-COM-CONTROL/CATEGORY.</p> <p>DcmDsdSubServiceId is set according to ISO-14229 to the corresponding value of DIAGNOSTIC-COM-CONTROL/CATEGORY. In case you want to configure a custom sub service, then set the value of the sub service id based on COM-CONTROL/CUSTOM-SUB-FUNCTION-NUMBER.</p> <p>DcmDsdSubServiceSessionLevelRef references all the associated DcmDspSession containers that correspond to the DIAGNOSTIC-COM-CONTROL entities with which the DIAGNOSTIC-ACCESS-PERMISSION is associated. For more information, see <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p> <p>DcmDsdSubServiceSecurityLevelRef references all the associated DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities which the DIAGNOSTIC-ACCESS-PERMISSION associated with the DIAGNOSTIC-COM-CONTROL references. For more information, see <a href="#">Section 3.4.10.22, “Determining the access permissions for diagnostic service instances”</a>.</p>

### 3.4.10.15. Configuration of subservices for Diagnostic RequestOnBoardMonitoringTestResults

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	Subservices are not applicable for the DIAGNOSTIC-REQUEST-ON-BOARD-MONITORING-TEST-RESULTS diagnostic service instance and hence DcmDsdSubService containers are not created.

### 3.4.10.16. Configuration of subservices for Diagnostic RequestVehicleInfo

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	Subservices are not applicable for the DIAGNOSTIC-REQUEST-VEHICLE-INFO diagnostic service instance and hence DcmDsdSubService containers are not created.

### 3.4.10.17. Configuration of subservices for Diagnostic RequestDownload

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	Subservices are not applicable for the DIAGNOSTIC-REQUEST-DOWNLOAD diagnostic service instance and hence DcmDsdSubService containers are not created.

### 3.4.10.18. Configuration of subservices for Diagnostic RequestUpload

Configuration parameters	Mapping description
DcmCon- figSet/DcmDsd/ DcmDsdService- eTable/DcmDsdSer- vice/DcmDsdSubSer- vice	Subservices are not applicable for the <code>DIAGNOSTIC-REQUEST-UPLOAD</code> diagnostic service instance and hence <code>DcmDsdSubService</code> containers are not created.

### 3.4.10.19. Configuration of subservices for Diagnostic DataTransfer

Configuration parameters	Mapping description
DcmCon- figSet/DcmDsd/ DcmDsdService- eTable/DcmDsdSer- vice/DcmDsdSubSer- vice	Subservices are not applicable for the <code>DIAGNOSTIC-DATA-TRANSFER</code> diagnostic service instance and hence <code>DcmDsdSubService</code> containers are not created.

### 3.4.10.20. Configuration of subservices for Diagnostic RequestTransferExit

Configuration parameters	Mapping description
DcmCon- figSet/DcmDsd/ DcmDsdService- eTable/DcmDsdSer- vice/DcmDsdSubSer- vice	Subservices are not applicable for the <code>DIAGNOSTIC-REQUEST-TRANSFER-EXIT</code> diagnostic service instance and hence <code>DcmDsdSubService</code> containers are not created.

### 3.4.10.21. Configuration of diagnostic subservices ControlDTCSetting

Configuration parameters	Mapping description
DcmConfigSet/DcmDsd/DcmDsdServiceTable/DcmDsdService/DcmDsdSubService	<p>For every DIAGNOSTIC-CONTROL-DTC-SETTING, a DcmDsdSubService container is created. The container name is set to DIAGNOSTIC-CONTROL-DTC-SETTING/SHORTNAME.</p> <p>DcmDsdSubServiceId is set to DIAGNOSTIC-CONTROL-DTC-SETTING/DTC-SETTING-PARAMETER.</p> <p>DcmDsdSubServiceSessionLevelRef references all the associated DcmDspSession containers that correspond to the DIAGNOSTIC-CONTROL-DTC-SETTING entities with which the DIAGNOSTIC-ACCESS-PERMISSION is associated. For more information, see <a href="#">Section 3.4.10.22, "Determining the access permissions for diagnostic service instances"</a>.</p> <p>DcmDsdSubServiceSecurityLevelRef references all the associated DcmDspSecurity containers that correspond to the DIAGNOSTIC-SECURITY-LEVEL entities with which the DIAGNOSTIC-ACCESS-PERMISSION is associated . For more information, see <a href="#">Section 3.4.10.22, "Determining the access permissions for diagnostic service instances"</a>.</p>

### 3.4.10.22. Determining the access permissions for diagnostic service instances

The access permission of a diagnostic service instance is determined as follows:

- ▶ If the DIAGNOSTIC-SESSION-CONTROL-CLASS/ACCESS-PERMISSION-VALIDITY of the diagnostic service instance is ACCESS-PERMISSION-SERVICE-INSTANCE, the access permission of the diagnostic service instance is used.
- ▶ If the DIAGNOSTIC-SESSION-CONTROL-CLASS/ACCESS-PERMISSION-VALIDITY of the diagnostic service instance is ACCESS-PERMISSION-SERVICE-CLASS, the access permission of the diagnostic service instance class is used.
- ▶ If the DIAGNOSTIC-SESSION-CONTROL-CLASS/ACCESS-PERMISSION-VALIDITY of the diagnostic service instance is ACCESS-PERMISSION-INSTANCE-OVERRIDES-CLASS, the access permission of the diagnostic service instance is used. If the access permission of the diagnostic service instance is not available, then the access permission of the diagnostic service instance class is used.

### 3.4.10.23. Determining the type for a routine signal

- ▶ UINT8 for BASE-TYPE-ENCODING NONE and BASE-TYPE-SIZE 8

- ▶ `UINT16` for `BASE-TYPE-ENCODING NONE` and `BASE-TYPE-SIZE 16`
- ▶ `UINT32` for `BASE-TYPE-ENCODING NONE` and `BASE-TYPE-SIZE 32`
- ▶ `SINT8` for `BASE-TYPE-ENCODING 2C` and `BASE-TYPE-SIZE 8`
- ▶ `SINT16` for `BASE-TYPE-ENCODING 2C` and `BASE-TYPE-SIZE 16`
- ▶ `SINT32` for `BASE-TYPE-ENCODING 2C` and `BASE-TYPE-SIZE 32`
- ▶ `BOOLEAN` for `BASE-TYPE-ENCODING BOOLEAN` and `BASE-TYPE-SIZE 1` or `BASE-TYPE-SIZE 8`
- ▶ `VARIABLE-LENGTH` for `ARRAY-SIZE-SEMANTICS VARIABLE-SIZE`, `BASE-TYPE-ENCODING NONE`, and `BASE-TYPE-SIZE 8`

#### 3.4.10.24. Configuration of `DcmProcessingConditions`

- ▶ A `DcmModeCondition` is created based on `DiagnosticEnvModeCondition` that is valid. The `DcmModeCondition` has the following parameter set: A `DcmConditionType` that has set the value of the `CompareType` attribute of `DiagnosticEnvModeCondition`, and two references `DcmBswModeRef` and `DcmSwcModeRef`. Only one reference is set at a time depending on the `ModeElement` attribute from the `DiagnosticEnvModeCondition`. The `DcmBswModeRef` has a reference to `DiagnosticEnvBswModeElement` and the `DcmSwcModeRef` has a reference to `DiagnosticEnvSwcModeElement`.
- ▶ A `DcmModeRule` is created based on the `DiagnosticEnvConditionFormula`. The `DcmModeRule` has the following parameters set: A `DcmLogicalOperator` that has set the value of the `Op` attribute of `DiagnosticEnvConditionFormula`. A `DcmModeRuleNrcValue` that has set the value of the `NrcValues` attribute of `DiagnosticEnvConditionFormula` and a `DcmArgumentRef`. The `DcmArgumentRef` has references to the parts of the `DiagnosticEnvConditionFormula`.

#### 3.4.10.25. Configuration of `DcmDspPid`

- ▶ The `DcmDspPidIdentifier` is created if the id of the `DiagnosticParameterIdentifier` is valid.
- ▶ The `DcmDspPidService` has the following parameter set: A `DCM_SERVICE_01`, `DCM_SERVICE_02` if `DiagnosticParameterIdentifier` is referenced by `DiagnosticRequestCurrentPowertrainData` or `DiagnosticRequestPowertrainFreezeFrameData` services, and the value `DCM_SERVICE_01_02` if it's referenced by both services.
- ▶ The `DcmDspPidSize` has the `pidSize` parameter of the `DiagnosticParameterIdentifier` if it's valid.

##### 3.4.10.25.1. Configuration of `DcmDspPidData`

- ▶ The `DcmDspPidDataPos` value is set to `maxNumberOfElements` from the `DiagnosticDataElement` of the `DiagnosticParameterIdentifier`.

- ▶ The `DcmDspPidDataSize` value is set depending on the `maxNumberOfElements` from the `DiagnosticDataElement` of the `DiagnosticParameterIdentifier`. If it's referenced by a `DiagnosticServiceSwMapping` and has a valid `MappedFlatSwcServiceDependency` mapping that has `RoleBasedPortAssignment` that have a valid `PortPrototype` mapping then, if the `PortPrototype` has `ProvidedInterface` it's considered of type `SenderReceiverInterface` and the value will be calculated like this:  $\text{maxNumberOfElements} * (\text{baseType.getBaseTypeSize()} / 8)$  If `ProvidedInterface` is of type `ClientServerInterface` then the value will be the `maxNumberOfElements` of the `DiagnosticDataElement`.

#### 3.4.10.25.2. Configuration of `DcmDspPidDataSupportInfo`

- ▶ The `DcmDspPidDataSupportInfoBit` value is set from `supportInfoBit` value of the `DiagnosticParameterIdentifier`.
- ▶ The `DcmDspPidDataSupportInfoRef` value is a reference set to `DcmDspPidSupportInfo` based on the `supportInfoByte` value of the `DiagnosticParameterIdentifier`.

#### 3.4.10.25.3. Configuration of `DcmDspPidService01`

- ▶ The `DcmDspPidDataReadFnc` value is set based on the `DiagnosticDataElement` if it's referenced in a `DiagnosticServiceSwMapping` and has a valid `MappedBswServiceDependency` mapping with a `BswServiceDependency` that has a `RoleBasedBswModuleEntryAssignment` then the value will be the `Role` value.
- ▶ The `DcmDspPidDataUsePort` value is set depending on the `DiagnosticServiceSwMapping`. The values will be the following: `USE_DATA_SYNCH_FNC` if the `DiagnosticServiceSwMapping` has a valid `MappedBswServiceDependency` mapping or `USE_DATA_SYNCH_CLIENT_SERVER` if the `DiagnosticServiceSwMapping` has a valid `MappedFlatSwcServiceDependency` or `SwcServiceDependency` mapping.

#### 3.4.10.25.4. Configuration of `DcmDspPidSupportInfo`

- ▶ The `DcmDspPidSupportInfoLen` value is set to `Size` from the parameter `DiagnosticSupportInfoByte` of the `DiagnosticParameterIdentifier`.
- ▶ The `DcmDspPidSupportInfoPos` value is set to `Position` from the parameter `DiagnosticSupportInfoByte` of the `DiagnosticParameterIdentifier`.

### 3.4.11. Dem

Configuration parameters	Mapping description
DemConfigSet	Check if a DemConfigSet container is created inside the module. If one already exists then an additional one is not created, otherwise a new DemConfigSet container is created.
DemConfigSet/DemDTCClass	<p>For every DIAGNOSTIC-TROUBLE-CODE-UDS that is assigned to the configured ECU-INSTANCE one DemDTCClass container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-TROUBLE-CODE-UDS.</p> <p>DemUdsDTC is set to DIAGNOSTIC-TROUBLE-CODE-UDS/UDS-DTC-VALUE.</p> <p>DemDTCFunctionalUnit is set to DIAGNOSTIC-TROUBLE-CODE-UDS/FUNCTIONAL-UNIT.</p> <p>DemDTCSeverity is set to DIAGNOSTIC-TROUBLE-CODE-UDS/SEVERITY.</p> <p>DemImmediateNvStorage is set to DIAGNOSTIC-TROUBLE-CODE-UDS/DIAGNOSTIC-TROUBLE-CODE-PROPS/IMMEDIATE-NV-DATA-STORAGE.</p> <p>DemObdDTC is set to DIAGNOSTIC-TROUBLE-CODE-OBD/OBD-DTC-VALUE.</p>
DemGeneral/DemGroupOfDTC	<p>For every DIAGNOSTIC-TROUBLE-CODE-GROUP that is assigned to the configured ECU-INSTANCE one DemGroupOfDTC container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-TROUBLE-CODE-GROUP.</p> <p>DemGroupDTCs is set to DIAGNOSTIC-TROUBLE-CODE-GROUP/GROUP-NUMBER.</p>
DemGeneral/DemEnableCondition	<p>For every DIAGNOSTIC-ENABLE-CONDITION that is assigned to the configured ECU-INSTANCE one DemEnableCondition container is created. The container name is &lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-ENABLE-CONDITION.</p> <p>DemEnableConditionStatus is set to DIAGNOSTIC-ENABLE-CONDITION/INIT-VALUE.</p>
DemGeneral/DemEnableCondition-Group	For every different DIAGNOSTIC-ENABLE-CONDITION-GROUP that contains different sets of DIAGNOSTIC-ENABLE-CONDITION references, that is assigned to the configured ECU-INSTANCE, a single DemEnableCondition-Group container is created. The container name is <name>, where <name> is the mangled name of the DIAGNOSTIC-ENABLE-CONDITION-GROUP.

Configuration parameters	Mapping description
	<p>DemEnableConditionRef references all the associated DemEnableCondition containers that correspond to the DIAGNOSTIC-ENABLE-CONDITION elements aggregated within this DIAGNOSTIC-ENABLE-CONDITION-GROUP.</p>
DemGeneral/DemOperationCycle	<p>A DemOperationCycle container is created for every DIAGNOSTIC-OPERATION-CYCLE that is assigned to the configured ECU-INSTANCE and which is used as either a DIAGNOSTIC-OPERATION-CYCLE-REF or as a HEALING-CYCLE attribute for a DIAGNOSTIC-CONNECTED-INDICATOR. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-OPERATION-CYCLE.</p> <p>DemOperationCycleAutomaticEnd is set to DIAGNOSTIC-OPERATION-CYCLE/AUTOMATIC-END.</p> <p>DemOperationCycleType is set to DIAGNOSTIC-OPERATION-CYCLE/TYPE.</p>
DemGeneral/DemAgingCycle	<p>A DemAgingCycle container is created for every DIAGNOSTIC-OPERATION-CYCLE that is assigned to the configured ECU-INSTANCE and which is used as either a DIAGNOSTIC-OPERATION-CYCLE-REF or as AGING-CYCLE for a DIAGNOSTIC-AGING. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;PREFIX&gt; is DEM_AG_CYCLE_ and &lt;name&gt; is the mangled name of the DIAGNOSTIC-OPERATION-CYCLE.</p>
DemGeneral	<p>Check if a DemGeneral container is created inside the module. If a container already exists, no additional container is created. Otherwise, a new DemGeneral container is created.</p> <p>DemEnableConditionSupport is set to true if at least one DIAGNOSTIC-ENABLE-CONDITION exists that is assigned to the configured ECU-INSTANCE.</p> <p>DemTypeOfFreezeFrameRecordNumeration is set to DEM_FF_REC_NUM_CONFIGURED if at least one DIAGNOSTIC-TROUBLE-CODE-PROPS exists that is assigned to the configured ECU-INSTANCE and contains at least one DiagnosticFreezeFrame with a valid RecordNumber parameter.</p> <p>DemDebounceCounterBasedSupport is set to true if the DIAGNOSTIC-EVENT that is assigned to the configured ECU-INSTANCE has support for DIAG-EVENT-DEBOUNCE-COUNTER-BASED.</p> <p>DemDebounceTimeBasedSupport is set to true if the DIAGNOSTIC-EVENT that is assigned to the configured ECU-INSTANCE has support for DIAG-EVENT-DEBOUNCE-TIME-BASED.</p>



Configuration parameters	Mapping description
	<p>If at least one <code>DIAGNOSTIC-COMMON-ELEMENT</code> exists that is an instance of <code>DIAGNOSTIC-ECU-INSTANCE-PROPS</code> with <code>DTC-STATUS-AVAILABILITY-MASK</code> set and is assigned to the configured <code>ECU-INSTANCE</code>, then the value of the <code>DemDtcStatusAvailabilityMask</code> attribute is configured based on the <code>DTC-STATUS-AVAILABILITY-MASK</code> from the first <code>DIAGNOSTIC-ECU-INSTANCE-PROPS</code> configured.</p> <p>If at least one <code>DIAGNOSTIC-COMMON-ELEMENT</code> exists that is an instance of <code>DIAGNOSTIC-ECU-INSTANCE-PROPS</code> with <code>OBD-SUPPORT</code> set with a different value than <code>NO-OBD-SUPPORT</code> and is assigned to the configured <code>ECU-INSTANCE</code>, then the value of the <code>DemOBDSupport</code> attribute is set to true and the <code>DemOBDSupportKind</code> attribute is configured based on the <code>OBD-SUPPORT</code> from the first <code>DIAGNOSTIC-ECU-INSTANCE-PROPS</code> configured. Otherwise the <code>DemOBDSupport</code> attribute is set to false and the <code>DemOBDSupportKind</code> is disabled.</p>
<code>DemGeneral/DemIndicator</code>	<p>For every <code>DIAGNOSTIC-INDICATOR</code> that is assigned to the configured <code>ECU-INSTANCE</code> one <code>DemIndicator</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the mangled name of the <code>DIAGNOSTIC-INDICATOR</code>.</p> <p><code>DemIndicatorID</code> is set to an auto-calculated value which specifies the index of this container.</p>
<code>DemGeneral/DemDataElementClass</code>	<p>A <code>DemDataElementClass</code> choice container is created for all the DiagnosticDataElements aggregated by a <code>DiagnosticTroubleCodeProps</code>, either through the <code>DiagnosticExtendedDataRecords</code> or through the <code>FreezeFrameContent</code>. For each of the <code>DiagnosticDataElements</code> linked inside a <code>DiagnosticDemProvidedDataMapping</code> element assigned to the configured <code>EcuInstance</code> a <code>DemInternalDataElementClass</code> choice container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;PREFIX&gt;</code> is <code>DemInternalDataElementClass_</code> and <code>&lt;name&gt;</code> is the mangled <code>shortName</code> of the <code>DiagnosticDataElement</code>.</p> <p><code>DemInternalDataElement</code> is set to the <code>DIAGNOSTIC-DATA-PROVIDER</code> category only if the values of <code>DataProvider</code> are reserved by the AUTOSAR standard and are one of the following:</p> <ul style="list-style-type: none"> <li>▶ <code>DEM_AGINGCTR_DOWNCNT</code></li> <li>▶ <code>DEM_AGINGCTR_UPCNT</code></li> <li>▶ <code>DEM_CURRENT_FDC</code></li> <li>▶ <code>DEM_CYCLES_SINCE_FIRST_FAILED</code></li> <li>▶ <code>DEM_CYCLES_SINCE_LAST_FAILED</code></li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ DEM_OCCCTR</li> <li>▶ DEM_OVFLIND</li> <li>▶ DEM_SIGNIFICANCE</li> </ul> <p>If DIAGNOSTIC-DATA-PROVIDER has a different value than the ones reserved by the AUTOSAR standard, then DemInternalDataElement is set to the default value DEM_AGINGCTR and a warning is issued.</p> <p>DemDataElementDataSize is set to (DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * DIAGNOSTIC-DATA-ELEMENT/SW-DATA-DEF-PROPS/SW-DATA-DEF-PROPS-CONDITIONAL/SW-BASE-TYPE/BASE-TYPE-SIZE)/8.</p> <p>By default if the DiagnosticDataElement is not linked inside a DiagnosticDem-ProvidedDataMapping then a DemExternalCSDDataElementClass choice container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;PREFIX&gt; is DemExternalCSDDataElementClass_ and &lt;name&gt; is the mangled shortName of the DiagnosticDataElement.</p> <p>DemDataElementDataSize is set to (DIAGNOSTIC-DATA-ELEMENT/MAX-NUMBER-OF-ELEMENTS * DIAGNOSTIC-DATA-ELEMENT/SW-DATA-DEF-PROPS/SW-DATA-DEF-PROPS-CONDITIONAL/SW-BASE-TYPE/BASE-TYPE-SIZE)/8.</p>
DemGeneral/DemDemDidClass	<p>For every DIAGNOSTIC-DATA-IDENTIFIER that is assigned to the configured ECU-INSTANCE one DemDemDidClass container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-DATA-IDENTIFIER and the &lt;PREFIX&gt; is DemDidClass_.</p> <p>DemDidIdentifier is set to DIAGNOSTIC-DATA-IDENTIFIER/ID.</p> <p>DemDidDataElementClassRef references all the associated DemDataElementClass containers that correspond to the DIAGNOSTIC-DATA-ELEMENT elements aggregated within this DIAGNOSTIC-DATA-IDENTIFIER.</p>
DemGeneral/DemFreezeFrameClass	<p>For every different set of DIAGNOSTIC-DATA-IDENTIFIER elements from DIAGNOSTIC-DATA-IDENTIFIER-SET aggregated by each DIAGNOSTIC-TROUBLE-CODE-PROPS that is assigned to the configured ECU-INSTANCE, only one DemFreezeFrameClass container is created. The container name is &lt;name&gt;&lt;SUFFIX&gt;, where &lt;name&gt; is DiagnosticFreezeFrameClass_ and the &lt;SUFFIX&gt; is the number of the DemFreezeFrameClass containers created.</p>

Configuration parameters	Mapping description
	DemDidClassRef references all the associated DiagnosticDataIdentifiers elements aggregated within a DIAGNOSTIC-DATA-IDENTIFIER-SET.
DemGeneral/DemFreezeFrameRecNumClass	<p>For every different set of DIAGNOSTIC-FREEZE-FRAME-RECORD-NUMBER elements aggregated by each DIAGNOSTIC-TROUBLE-CODE-PROPS that is assigned to the configured ECU-INSTANCE only one DemFreezeFrameRecNumClass container is created. The container name is &lt;name&gt;&lt;SUFFIX&gt;, where &lt;name&gt; is DiagnosticFreezeFrameRecNumClass_ and the &lt;SUFFIX&gt; is the number of the DemFreezeFrameRecNumClass containers created.</p> <p>DemFreezeFrameRecordNumber is set to the DIAGNOSTIC-FREEZE-FRAME-RECORD-NUMBER aggregated by a DIAGNOSTIC-TROUBLE-CODE-PROPS.</p>
DemConfigSet/DemEventParameter	<p>For each DIAGNOSTIC-EVENT that is assigned to the configured ECU-INSTANCE, one DemEventParameter container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-EVENT.</p> <p>DemEventId is set to an auto-calculated value which specified the index of this container.</p> <p>DemEventKind is set to DIAGNOSTIC-EVENT/EVENT-KIND.</p> <p>DemDTCClassRef references the associated DemDTCClass container that corresponds to the DIAGNOSTIC-TROUBLE-CODE-UDS which is mapped to the DIAGNOSTIC-EVENT via DIAGNOSTIC-EVENT-TO-TROUBLE-CODE-UDS-MAPPING.</p> <p>DemFreezeFrameClassRef references the associated DemFreezeFrameClass container that corresponds to the DIAGNOSTIC-TROUBLE-CODE-PROPS/FREEZE-FRAME-CONTENT-REF, where DIAGNOSTIC-TROUBLE-CODE-PROPS can be obtained via DIAGNOSTIC-EVENT-TO-TROUBLE-CODE-UDS-MAPPING.</p> <p>DemFreezeFrameRecNumClassRef references the associated DemDTCClass container that corresponds to the DIAGNOSTIC-TROUBLE-CODE-PROPS/DIAGNOSTIC-EXTENDED-DATA-RECORD-REF-CONDITIONAL, where DIAGNOSTIC-TROUBLE-CODE-PROPS can be obtained via DIAGNOSTIC-EVENT-TO-TROUBLE-CODE-UDS-MAPPING.</p> <p>DemMaxNumberFreezeFrameRecords is set to the DIAGNOSTIC-TROUBLE-CODE-PROPS/MAX-NUMBER-FREEZE-FRAME-RECORDS, where DIAG-</p>

Configuration parameters	Mapping description
	DIAGNOSTIC-TROUBLE-CODE-PROPS can be obtained via DIAGNOSTIC-EVENT-TO-TROUBLE-CODE-UDS-MAPPING.
DemConfigSet/DemEventParameter/DemCallbackClearEventAllowed	A DemCallbackClearEventAllowed container is created under DemEventParameter if DIAGNOSTIC-EVENT/EVENT-CLEAR-ALLOWED is set. The <name> is set to DemCallbackClearEventAllowed.
DemConfigSet/DemEventParameter/DemEventClass	<p>A DemEventClass container is created under DemEventParameter. The &lt;name&gt; is set to DemEventClass.</p> <p>DemEventSignificance is set to the DIAGNOSTIC-TROUBLE-CODE-UDS/DIAGNOSTIC-TROUBLE-CODE-PROPS/SIGNIFICANCE linked to the DiagnosticEvent if the DIAGNOSTIC-TROUBLE-CODE-PROPS/SIGNIFICANCE is valid. Otherwise, DemEventSignificance is set to the DIAGNOSTIC-TROUBLE-CODE-OBD/DIAGNOSTIC-TROUBLE-CODE-PROPS/SIGNIFICANCE linked to the DiagnosticEvent via the DIAGNOSTIC-TROUBLE-CODE-UDS if the DIAGNOSTIC-TROUBLE-CODE-PROPS/SIGNIFICANCE is valid.</p> <p>DemEventDestination is set to the first MEMORY-DESTINATION-REF from the DIAGNOSTIC-TROUBLE-CODE-UDS/DIAGNOSTIC-TROUBLE-CODE-PROPS/MEMORY-DESTINATION-REFS linked to the DiagnosticEvent if the DIAGNOSTIC-TROUBLE-CODE-PROPS/MEMORY-DESTINATION-REF is valid. Otherwise, DemEventDestination is set to the first MEMORY-DESTINATION-REF from the DIAGNOSTIC-TROUBLE-CODE-OBD/DIAGNOSTIC-TROUBLE-CODE-PROPS/MEMORY-DESTINATION-REFS linked to the DiagnosticEvent via the DIAGNOSTIC-TROUBLE-CODE-UDS if the DIAGNOSTIC-TROUBLE-CODE-PROPS/MEMORY-DESTINATION-REF is valid.</p> <p>DemFFPrestorageSupported is set to DIAGNOSTIC-EVENT/PRESTORAGE-FREEZE-FRAME.</p> <p>DemEventPriority is set to DIAGNOSTIC-TROUBLE-CODE-PROPS/PRIORITY.</p> <p>DemAgingAllowed is set to DIAGNOSTIC-EVENT/AGING-ALLOWED.</p> <p>DemEventFailureCycleCounterThreshold is set to DIAGNOSTIC-EVENT/EVENT-FAILURE-CYCLE-COUNTER-THRESHOLD.</p> <p>DemEnableConditionGroupRef references the associated DemEnableConditionGroup container that corresponds to the DIAGNOSTIC-ENABLE-CONDITION-GROUP which is mapped to the DIAGNOSTIC-EVENT via DIAGNOSTIC-EVENT-TO-ENABLE-CONDITION-GROUP-MAPPING.</p>

Configuration parameters	Mapping description
	<p>DemOperationCycleRef <b>references the associated</b> DemOperationCycle container that corresponds to the DIAGNOSTIC-OPERATION-CYCLE which is mapped to the DIAGNOSTIC-EVENT via DIAGNOSTIC-EVENT-TO-OPERATION-CYCLE-MAPPING.</p> <p>DemAgingCycleRef <b>references the associated</b> DemAgingCycle container that corresponds to the DIAGNOSTIC-AGING which is mapped to the DIAGNOSTIC-EVENT via DIAGNOSTIC-EVENT-TO-TROUBLE-CODE-UDS-MAPPING.</p> <p>DemAgingCycleCounterThreshold <b>is set to</b> DIAGNOSTIC-AGING/THRESHOLD which is mapped to DemAgingCycle referred above.</p> <p>DemConsiderPtoStatus <b>is set to</b> DIAGNOSTIC-TROUBLE-CODE-OBD/CONSIDER-PTO-STATUS.</p> <p>DemEventOBDRreadinessGroup <b>is set to</b> DIAGNOSTIC-TROUBLE-CODE-OBD/EVENT-OBDR-READINESS-GROUP.</p>
DemConfigSet/DemEventParameter/DemEventClass/DemIndicatorAttribute	<p>The DemIndicatorAttribute container is created for every DIAGNOSTIC-CONNECTED-INDICATOR aggregated by the DIAGNOSTIC-EVENT. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-CONNECTED-INDICATOR.</p> <p>DemIndicatorBehaviour <b>is set to</b> DIAGNOSTIC-CONNECTED-INDICATOR/BEHAVIOR.</p> <p>DemIndicatorHealingCycleRef <b>references the associated</b> DemOperationCycle container that corresponds to DIAGNOSTIC-CONNECTED-INDICATOR/HEALING-CYCLE-REF.</p> <p>DemIndicatorRef <b>references the associated</b> DemIndicator container that corresponds to DIAGNOSTIC-CONNECTED-INDICATOR/INDICATOR-REF.</p> <p>DemIndicatorHealingCycleCounterThreshold <b>is set to</b> DIAGNOSTIC-CONNECTED-INDICATOR/INDICATOR-REF/HEALING-CYCLE-COUNTER-THRESHOLD.</p>
DemConfigSet/DemEventParameter/DemEventClass/DemDebounceAlgorithmClass	<p>A DemDebounceAlgorithmClass container is created for every DemEventClass based on the DiagnosticDebounceAlgorithmProps mapped to the DiagnosticEvent via DiagnosticEventToDebounceAlgorithmMapping. The DemDebounceAlgorithmClass can be one of the following types:</p> <ul style="list-style-type: none"> <li>► DemDebounceMonitorInternal</li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ DemDebounceCounterBased</li> <li>▶ DemDebounceTimeBase</li> </ul>
DemConfigSet/DemEventParameter/DemEventClass/DemDebounceAlgorithm-Class/DemDebounceTimeBase	<p>DemDebounceTimeFailedThreshold <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-TIME-BASED/TIME-FAILED-THRESHOLD.</p> <p>DemDebounceTimePassedThreshold <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-TIME-BASED/TIME-PASSED-THRESHOLD.</p>
DemConfigSet/DemEventParameter/DemEventClass/DemDebounceAlgorithm-Class/DiagEventDebounceCounterBased	<p>DemDebounceCounterDecrementStepSize <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-DECREMENT-STEP-SIZE.</p> <p>DemDebounceCounterFailedThreshold <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-FAILED-THRESHOLD.</p> <p>DemDebounceCounterIncrementStepSize <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-INCREMENT-STEP-SIZE.</p> <p>DemDebounceCounterJumpDown <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-JUMP-DOWN.</p> <p>DemDebounceCounterJumpDownValue <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-JUMP-DOWN-VALUE.</p> <p>DemDebounceCounterJumpUp <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-JUMP-UP.</p> <p>DemDebounceCounterJumpUpValue <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-JUMP-UP-VALUE.</p> <p>DemDebounceCounterPassedThreshold <b>is set to</b> DIAGNOSTIC-DEBOUNCE-ALGORITHM-PROPS/DIAG-EVENT-DEBOUNCE-COUNTER-BASED/COUNTER-PASSED-THRESHOLD.</p>

Configuration parameters	Mapping description
DemGeneral/DemExtendedDataClass	<p>For every different DIAGNOSTIC-TROUBLE-CODE-PROPS that contains different sets of DIAGNOSTIC-EXTENDED-DATA-RECORD references, that is assigned to the configured ECU-INSTANCE, a single DemExtendedDataClass container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the mangled name of the DIAGNOSTIC-TROUBLE-CODE-PROPS.</p> <p>DemExtendedDataRecordClassRef references all the associated DemExtendedDataRecordClass containers that correspond to the DIAGNOSTIC-EXTENDED-DATA-RECORD aggregated within the DIAGNOSTIC-TROUBLE-CODE-PROPS.</p>
DemGeneral/DemExtendedDataRecordClass	<p>For every DIAGNOSTIC-EXTENDED-DATA-RECORD that is assigned to the configured ECU-INSTANCE one DemExtendedDataRecordClass container is created. The container &lt;name&gt; is the mangled name of the DIAGNOSTIC-EXTENDED-DATA-RECORD.</p> <p>DemExtendedDataRecordNumber is set to DIAGNOSTIC-EXTENDED-DATA-RECORD/RECORD-NUMBER.</p> <p>DemExtendedDataRecordUpdate is set to DIAGNOSTIC-EXTENDED-DATA-RECORD/UPDATE.</p> <p>DemDataElementClassRef references all the associated DemDataElementClass containers that correspond to the DIAGNOSTIC-DATA-ELEMENT elements aggregated within this DIAGNOSTIC-EXTENDED-DATA-RECORD.</p>

### 3.4.12. DoIP

Configuration parameters	Mapping description
DoIPConfigSet	<p>One DoIPConfigSet container and one DoIPConnections subcontainer are created if the imported ECU-INSTANCE sends and/or receives one or more PDUs that belong to a DO-IP-TP-CONNECTION. A PDU belongs to a DO-IP-TP-CONNECTION if the DO-IP-TP-CONNECTION references the PDU via TP-SDU-REF.</p> <p>The VLAN of a DO-IP-TP-CONNECTION is the PHYSICAL-CHANNEL of the PDU-TRIGGERING that the DO-IP-TP-CONNECTION references via TP-SDU-REF.</p>

Configuration parameters	Mapping description
	<p>If the ECU-INSTANCE sends a PDU via a DO-IP-TP-CONNECTION, the <i>local diagnosis address</i> and the <i>tester address</i> of the DO-IP-TP-CONNECTION are the ADDRESS values of the DO-IP-LOGIC-ADDRESS elements that the DO-IP-TP-CONNECTION references via DO-IP-SOURCE-ADDRESS, respectively via DO-IP-TARGET-ADDRESS.</p> <p>If the ECU-INSTANCE receives a PDU via a DO-IP-TP-CONNECTION, the <i>local diagnosis address</i> and the <i>tester address</i> of the DO-IP-TP-CONNECTION are the ADDRESS values of the DO-IP-LOGIC-ADDRESS elements that the DO-IP-TP-CONNECTION references via DO-IP-TARGET-ADDRESS, respectively via DO-IP-SOURCE-ADDRESS.</p> <p>A <i>DoIP channel</i> consists of the set of all DO-IP-TP-CONNECTION elements via which the ECU-INSTANCE:</p> <ul style="list-style-type: none"> <li>► sends DCM-I-PDU elements that have their DIAG-PDU-TYPE either set to DIAG-RESPONSE or not set at all;</li> <li>► receives DCM-I-PDU elements that have their DIAG-PDU-TYPE either set to DIAG-REQUEST or not set at all.</li> </ul> <p>Moreover, the DO-IP-TP-CONNECTION elements have to share the same VLAN, <i>local diagnosis address</i>, and <i>tester address</i> in order to belong to the same <i>DoIP channel</i>.</p>
DoIPConfigSet/DoIPConnections/DoIPTcpConnection, DoIPConfigSet/DoIPConnections/DoIPUdpVehicleAnnouncement, DoIPConfigSet/DoIPConnections/DoIPUdpConnection	<p>If the imported ECU-INSTANCE sends and/or receives one or more PDUs of type GENERAL-PURPOSE-PDU with CATEGORY set to DoIP via one or several SOCKET-CONNECTION elements, one or more subcontainers are added to DoIPConfigSet/DoIPConnections. If the PDUs are sent and/or received via Tcp SOCKET-CONNECTION elements, one DoIPTcpConnection container is created. For more information about SOCKET-CONNECTION, see <a href="#">Section 3.4.37, “SoAd”</a>. The container name is &lt;chn&gt;_&lt;remote_addr&gt;Tcp, where &lt;chn&gt; is the mangled name of the ETHERNET-PHYSICAL-CHANNEL the PDUs are transmitted on and &lt;remote_addr&gt; is the mangled name of the <i>remote</i> SOCKET-ADDRESS. If there are two or more Tcp SOCKET-CONNECTION elements that exchange DoIP PDUs with the same remote SOCKET-ADDRESS, multiple DoIPTcpConnection containers are created. A suffix is appended to the container names of the second, third, etc. of these containers to ensure unique container names.</p> <p>If there is only one PDU sent to the IPv4-limited broadcast address (255.255.255.255) or to the IPv6-limited broadcast address (FF02::0:0:0:0:1) via one Udp SOCKET-CONNECTION, a DoIPUdpVehicleAnnounce-</p>



Configuration parameters	Mapping description
	ment container is created. If there are one or more PDUs sent and/or received via a <code>Udp SOCKET-CONNECTION</code> , a <code>DoIPUdpConnection</code> container is created. In the two latter cases, the container names are <code>&lt;chn&gt;_&lt;remote_addr&gt;UdpVehicleAnnouncement</code> , respectively <code>&lt;chn&gt;_&lt;remote_addr&gt;Udp</code> .
<code>DoIPConfigSet/DoIPConnections/DoIPTcpConnection/DoIPSoAdRxPdu</code> , <code>DoIPConfigSet/DoIPConnections/DoIPUdpConnection/DoIPSoAdRxPdu</code>	If received PDUs exist for which the container <code>DoIPTcpConnection</code> or <code>DoIPUdpConnection</code> has been created, one <code>DoIPSoAdRxPdu</code> subcontainer is added. <code>DoIPSoAdRxPduRef</code> references the representation of the first received PDU in the <code>EcuC</code> module. A warning is issued if multiple received PDUs were found for the <code>DoIPTcpConnection/DoIPUdpConnection</code> container.
<code>DoIPConfigSet/DoIPConnections/DoIPTcpConnection/DoIPSoAdTxPdu</code> , <code>DoIPConfigSet/DoIPConnections/DoIPUdpConnection/DoIPSoAdTxPdu</code>	If sent PDUs exist for which the container <code>DoIPTcpConnection</code> or <code>DoIPUdpConnection</code> has been created, one <code>DoIPSoAdTxPdu</code> subcontainer is added. <code>DoIPSoAdTxPduRef</code> references the representation of the first sent PDU in the <code>EcuC</code> module. A warning is issued if multiple sent PDUs were found for the <code>DoIPTcpConnection/DoIPUdpConnection</code> container.
<code>DoIPConfigSet/DoIPConnections/DoIPUdpVehicleAnnouncement/DoIPSoAdTxPdu</code>	If sent PDUs exist for which the container <code>DoIPUdpVehicleAnnouncement</code> has been created, one <code>DoIPSoAdTxPdu</code> sub container is added. <code>DoIPSoAdTxPduRef</code> references the representation of the first sent PDU in the <code>EcuC</code> module. A warning is issued if multiple sent PDUs were found for the <code>DoIPUdpVehicleAnnouncement</code> container.
<code>DoIPConfigSet/DoIPConnections/DoIPTargetAddress</code>	One <code>DoIPTargetAddress</code> container is created for each valid and unique <i>local diagnosis address</i> value of any <code>DO-IP-TP-CONNECTION</code> of the <code>ECU-INSTANCE</code> . The container name is <code>DoIPTargetAddress_&lt;address&gt;</code> , where <code>&lt;address&gt;</code> is the value of the <i>local diagnosis address</i> . This value is also configured in <code>DoIPTargetAddressValue</code> .
<code>DoIPConfigSet/DoIPTester</code>	One <code>DoIPTester</code> container is created for each valid and unique <i>tester address</i> value. The container name is <code>DoIPTester_&lt;address&gt;</code> , where <code>&lt;address&gt;</code> is the value of the <i>tester address</i> . This value is also configured in <code>DoIPTesterSA</code> .
<code>DoIPConfigSet/DoIPChannel</code>	For each <i>DoIP channel</i> , one <code>DoIPChannel</code> container is created. If the <i>DoIP channel</i> contains one or more <code>DO-IP-TP-CONNECTION</code> elements that receive

Configuration parameters	Mapping description
	<p>a PDU, the container name is the mangled name of the first of these elements, otherwise the name is the mangled name of the first contained DO-IP-TP-CONNECTION that sends a PDU.</p> <p>DoIPChannelSARef is set up to reference the DoIPConfigSet/DoIPTester container that has been created for the common <i>tester address</i> of the DO-IP-TP-CONNECTION elements of the <i>DoIP channel</i>.</p> <p>DoIPChannelTARef is set up to reference the DoIPConfigSet/DoIPConnections/DoIPTargetAddress container that has been created for the common <i>local diagnosis address</i> of the DO-IP-TP-CONNECTION elements of the <i>DoIP channel</i>.</p>
DoIPConfigSet/DoIPChannel/DoIPPduRRxPdu	If one or more of the DO-IP-TP-CONNECTION elements of the <i>DoIP channel</i> receive a PDU, one DoIPPduRRxPdu subcontainer is created. Its DoIPPduRRxPduRef references the representation of the first of these received PDUs in the EcuC module. A warning is issued if none of the DO-IP-TP-CONNECTION elements of the <i>DoIP channel</i> receives a PDU.
DoIPConfigSet/DoIPChannel/DoIPPduRTxPdu	If one or more of the DO-IP-TP-CONNECTION elements of the <i>DoIP channel</i> send a PDU, one DoIPPduRTxPdu subcontainer is created. Its DoIPPduRTxPduRef references the representation of the first of these sent PDUs in the EcuC module.

### 3.4.13. EcuC

Configuration parameters	Mapping description
EcuCpduCollection/Pdu	<p>For every PDU instance (see <a href="#">Section 3.3.1.3, “Instance handling”</a>) sent, received or routed (see <a href="#">Section 3.3.5, “PDU routing”</a>) by the imported ECU-INSTANCE, a Pdu container is created. This also includes:</p> <ul style="list-style-type: none"> <li>▶ PDU instances that represent PDUs referenced in DYNAMIC-PARTS or STATIC-PARTS of MULTIPLEXED-I-PDU elements.</li> <li>▶ PDU instances that represent PDUs that are transmitted within CONTAINER-I-PDU elements. For information about CONTAINER-I-PDU, see <a href="#">Section 3.4.27, “lpduM”</a>).</li> </ul> <p>The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU belonging to the PDU instance.</p>

Configuration parameters	Mapping description
	<p>For every PDU referenced by a TP-CONNECTION belonging to the imported ECU-INSTANCE, a Pdu container is created as well. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>If the ECU-INSTANCE receives multiple NM-PDU elements in one CAN-CLUSTER, only one Pdu container is created representing the PDU with the lowest CAN-ID.</p> <p>For an NM-PDU an NmUserDataPdu container is created if at least one of the following conditions is met:</p> <ul style="list-style-type: none"> <li>▶ The NM-PDU contains an I-SIGNAL-TO-I-PDU-MAPPING that references an I-SIGNAL or an I-SIGNAL-GROUP.</li> <li>▶ The NM-PDU is sent and belongs to a <i>PNC-enabled</i> NM-CLUSTER.</li> </ul> <p>An NM-CLUSTER is considered PNC-enabled in one of the following cases:</p> <ul style="list-style-type: none"> <li>▶ The NM-CLUSTER has its NM-PNC-PARTICIPATION not set to false</li> <li>▶ A PNC-MAPPING references an I-SIGNAL-I-PDU-GROUP which contains PDUs - either directly or via one of its subordinate I-SIGNAL-I-PDU-GROUP elements - that belong to the COMMUNICATION-CLUSTER referenced by the NM-CLUSTER. The referenced I-SIGNAL-I-PDU-GROUP or any of its subordinate I-SIGNAL-I-PDU-GROUP elements must also be referenced by ASSOCIATED-COM-I-PDU-GROUP-REFS of the imported ECU-INSTANCE</li> <li>▶ A PNC-MAPPING references the ETHERNET-PHYSICAL-CHANNEL which is referenced from the NM-CLUSTER as well</li> <li>▶ A PNC-MAPPING references a CAN-PHYSICAL-CHANNEL or a FLEXRAY-PHYSICAL-CHANNEL which is contained in a CAN-CLUSTER or a FLEXRAY-CLUSTER which is in turn referenced by the NM-CLUSTER</li> </ul> <p>The container name of the NmUserDataPdu container is &lt;PREFIX&gt;&lt;name&gt;_ NmComUserData&lt;INSTSUFFIX&gt;.</p> <p>If any PNC-enabled NM-CLUSTER is a FLEXRAY-NM-CLUSTER, an additional <i>EIRA</i> (external and internal request array) Pdu container named FrNmPnEiraRxNSdu is created. If any of the PNC-enabled NM-CLUSTER elements is a CAN-NM-CLUSTER, an additional Pdu container named CanNmPnEiraRxNSdu is created. If any of the PNC-enabled NM-CLUSTER elements is a UDP-NM-CLUSTER, an additional Pdu container named UdpNmPnEiraRxNSdu is created.</p>

Configuration parameters	Mapping description
	<p>If the following conditions are met, one additional <i>ERA</i> (external request array) <i>Pdu</i> container is created for each <code>COMMUNICATION-CONNECTOR</code> of the <code>ECU-INSTANCE</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>PNC-GATEWAY-TYPE</code> of the <code>COMMUNICATION-CONNECTOR</code> is set to <code>ACTIVE</code>.</li> <li>▶ <code>COMMUNICATION-CONNECTOR</code> is connected to an <code>ETHERNET-PHYSICAL-CHANNEL</code>, a <code>CAN-CLUSTER</code>, or a <code>FLEXRAY-CLUSTER</code>, which in turn is related to a <code>PNC-enabled NM-CLUSTER</code>.</li> </ul> <p>The name of the <i>Pdu</i> container is <code>&lt;PREFIX&gt;&lt;channel&gt;NmPnEraRxNSdu</code>, where <code>&lt;channel&gt;</code> is the <code>SHORT-NAME</code> of the <code>FLEXRAY-CLUSTER</code>, <code>CAN-CLUSTER</code>, or <code>ETHERNET-PHYSICAL-CHANNEL</code>.</p> <p><code>N-PDU</code> elements of <code>LIN-FRAME-TRIGGERING</code> elements which have their <code>IDENTIFIER</code> set to 60 or 61 are not imported.</p> <p>If a sent <code>N-PDU</code> is referenced by two <code>CAN-TP-CONNECTION</code> elements a second <i>Pdu</i> container is created. The <code>Tx CAN-TP-CONNECTION</code> must reference this <code>N-PDU</code> via <code>DATA-PDU-REF</code>, the <code>Rx CAN-TP-CONNECTION</code> via <code>FLOW-CONTROL-PDU-REF</code>. The direction of the <code>CAN-TP-CONNECTION</code> is determined by the <code>PDU</code> referenced by <code>TP-SDU-REF</code>. The container name of the second <i>Pdu</i> container is <code>&lt;PREFIX&gt;&lt;name&gt;_D&lt;INSTSUFFIX&gt;</code>.</p> <p><code>PduLength</code> is set to <code>LENGTH</code> of the <code>PDU</code>, except for the following cases:</p> <p>For an <code>NmUserDataPdu</code> container that is created for an <code>NM-PDU</code>, <code>PduLength</code> is calculated depending on the type of <code>NM-CLUSTER</code> to which the <code>NM-PDU</code> belongs. First the length of the non-user data is calculated:</p> <ul style="list-style-type: none"> <li>▶ <code>CAN-NM-CLUSTER</code>, <code>UDP-NM-CLUSTER</code>: <math>\max(\text{NM-CBV-POSITION}, \text{NM-NID-POSITION}) + 1</math>. If one of the parameters is not defined or greater than 1, it is assumed to be -1 in the formula above.</li> <li>▶ <code>FLEXRAY-NM-CLUSTER</code>: 2, if <code>NM-NODE-ID-ENABLED</code> of the <code>NM-ECU</code> to which the <code>NM-PDU</code> belongs is set to <code>true</code>, 1 otherwise.</li> </ul> <p><math>\text{PduLength} = \text{LENGTH} - \langle \text{length of the non-user data} \rangle</math>. If the calculated <code>PduLength</code> is zero or less, a warning is issued and <code>PduLength</code> is not set.</p> <p>For <i>Pdu</i> containers created for <code>PNC-enabled NM-CLUSTER</code> elements <code>PduLength</code> is set to <code>PNC-VECTOR-LENGTH</code> of the <code>SYSTEM</code>. If <code>PNC-VECTOR-LENGTH</code> is not defined a warning is issued and <code>PduLength</code> is not set.</p>

Configuration parameters	Mapping description
	<code>SysTPduToFrameMappingRef</code> is set to the AUTOSAR path of the <code>PDU-TO-FRAME-MAPPING</code> that references the PDU. If no <code>PDU-TO-FRAME-MAPPING</code> references the PDU, <code>SysTPduToFrameMappingRef</code> is not configured.

If the configured `ECU-INSTANCE` contains a server component which receives its requests and sends its responses via Ethernet, the request/response PDUs are extended with Meta-Data that allows the server to keep track of the `SocketConnection` via which a request was received in order to use the same `SocketConnection` for the transmission of the response.

Additional Meta-Data is configured if at least one PDU container is created for a PDU instance that fulfills the following conditions:

- ▶ The PDU is of type `I-SIGNAL-I-PDU`
- ▶ The `PDU-TRIGGERING` that references the PDU is contained in an `ETHERNET-PHYSICAL-CHANNEL`
- ▶ The `PDU-TRIGGERING` is referenced by a `SOCKET-CONNECTION-IPDU-IDENTIFIER` of a `SOCKET-CONNECTION-BUNDLE`.
- ▶ The `I-SIGNAL-I-PDU` contains exactly one `I-SIGNAL`
- ▶ The `SYSTEM-SIGNAL` of the `I-SIGNAL` is referenced by a `CLIENT-SERVER-TO-SIGNAL-MAPPING` via `CALL-SIGNAL-REF` if the configured `ECU-INSTANCE` receives the `I-SIGNAL`, or via `RETURN-SIGNAL-REF` if the configured `ECU-INSTANCE` sends the `I-SIGNAL`

In `EcucPduCollection/MetaDataType`, one container is created using `MetaDataTypeSocketConnectionId` as name. Into that container a `MetaDataTypeItem` sub container named `MetaDataTypeItemSocketConnectionId` is inserted. The `MetaDataTypeItemLength` parameter of the sub container is set to 2, the `MetaDataTypeItemType` parameter of the sub container is set to `SOCKET_CONNECTION_ID_16`.

The `MetaDataTypeRef` parameter of every `EcucPduCollection/Pdu` container that requires Meta-Data is configured to refer to the `MetaDataTypeSocketConnectionId` container.

### 3.4.14. Eth

Configuration parameters	Mapping description
<code>EthConfigSet/EthCtrlConfig</code>	Every <code>ETHERNET-COMMUNICATION-CONTROLLER</code> which belongs to the imported <code>ECU-INSTANCE</code> and which is connected to at least one <code>ETHERNET-CLUSTER</code> is considered a <i>physical</i> <code>ETHERNET-COMMUNICATION-CONTROLLER</code> of the <code>ECU-INSTANCE</code> . For every <i>physical</i> <code>ETHERNET-COMMUNICATION-CONTROLLER</code> of the <code>ECU-INSTANCE</code> , one <code>EthCtrlConfig</code> container is created.

Configuration parameters	Mapping description
	<p>The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the ETHERNET-COMMUNICATION-CONTROLLER.</p> <p>EthCtrlRxBufLenByte is set to MAXIMUM-RECEIVE-BUFFER-LENGTH.</p> <p>EthCtrlTxBufLenByte is set to MAXIMUM-TRANSMIT-BUFFER-LENGTH.</p> <p>EthCtrlPhyAddress is set to MAC-UNICAST-ADDRESS. If MAC-UNICAST-ADDRESS does not represent a valid MAC address, a warning is reported and EthCtrlPhyAddress is not set.</p>

### 3.4.15. EthIf

Configuration parameters	Mapping description
EthIfGeneral	If any of the ETHERNET-CLUSTER elements to which the imported ECU-INSTANCE is connected has its COUPLING-PORT-SWITCHOFF-DELAY defined, that value is configured in EthIfSwitchOffPortTimeDelay.
EthIfConfigSet/EthIfPhysController	<p>For each <i>physical</i> ETHERNET-COMMUNICATION-CONTROLLER of the imported ECU-INSTANCE (see <a href="#">Section 3.4.14, “Eth”</a>), an EthIfPhysController container is created. The container name is the SHORT-NAME of the ETHERNET-COMMUNICATION-CONTROLLER.</p> <p>EthIfEthCtrlRef references the container created for the <i>physical</i> ETHERNET-COMMUNICATION-CONTROLLER in the Eth module.</p>
EthIfConfigSet/EthIfController	<p>A <i>physical</i> ETHERNET-COMMUNICATION-CONTROLLER of the imported ECU-INSTANCE (see <a href="#">Section 3.4.14, “Eth”</a>) is connected to one or more ETHERNET-PHYSICAL-CHANNEL elements. Such a connection exists if an ETHERNET-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE references the ETHERNET-COMMUNICATION-CONTROLLER and is referenced by the ETHERNET-PHYSICAL-CHANNEL. Each of the connections represents a <i>virtual</i> ETHERNET-COMMUNICATION-CONTROLLER of the ECU-INSTANCE. For each <i>virtual</i> ETHERNET-COMMUNICATION-CONTROLLER of the imported ECU-INSTANCE, an EthIfController container is created. The container name is &lt;PREFIX&gt;&lt;name_cc&gt;_&lt;name_chn&gt;, where &lt;name_cc&gt; is the SHORT-NAME of the ETHERNET-COMMUNICATION-CONTROLLER and &lt;name_chn&gt; is the SHORT-NAME of the ETHERNET-PHYSICAL-CHANNEL.</p>

Configuration parameters	Mapping description
	<p><code>EthIfPhysControllerRef</code> references the <code>EthIfPhysController</code> container that has been created for the <i>physical</i> ETHERNET-COMMUNICATION-CONTROLLER.</p> <p>If the ETHERNET-PHYSICAL-CHANNEL that belongs to the virtual ETHERNET-COMMUNICATION-CONTROLLER contains a VLAN that provides a VLAN-IDENTIFIER, <code>EthIfVlanId</code> is set to the value of VLAN-IDENTIFIER.</p> <p>If the ETHERNET-COMMUNICATION-CONNECTOR or the ETHERNET-COMMUNICATION-CONTROLLER provide a valid MAXIMUM-TRANSMISSION-UNIT, <code>EthIfCtrlMtu</code> is set to the value of MAXIMUM-TRANSMISSION-UNIT.</p> <p>If an <code>EthIfSwitchPortGroup</code> container is created for the ETHERNET-PHYSICAL-CHANNEL of this <code>EthIfController</code> container, <code>EthIfSwitchRefORPortGroupRef</code> is set up to reference that <code>EthIfSwitchPortGroup</code> container.</p>
<code>EthIfConfigSet/EthIfSwitch</code>	<p>For each COUPLING-ELEMENT that has its COUPLING-TYPE set to SWITCH and which references the imported ECU-INSTANCE in ECU-INSTANCE-REF, one <code>EthIfSwitch</code> container is created. The container name is the SHORT-NAME of the COUPLING-ELEMENT.</p> <p><code>EthIfSwitchRef</code> references the container created for the COUPLING-ELEMENT in the <code>EthSwt</code> module.</p>
<code>EthIfConfigSet/EthIfSwitchPortGroup</code>	<p>If the imported ECU-INSTANCE has its ETH-SWITCH-PORT-GROUP-DERIVATION parameter set to true, the configuration algorithm retrieves the list of all COUPLING-PORT elements of any COUPLING-ELEMENT for which an <code>EthIfSwitch</code> container is created.</p> <p>For each ETHERNET-PHYSICAL-CHANNEL and for each PNC-MAPPING that is referenced by any COUPLING-PORT, one <code>EthIfSwitchPortGroup</code> container is created. The container name is either <code>VLANSwtPortGrp_&lt;VLAN&gt;</code>, where <code>&lt;VLAN&gt;</code> is the name of the ETHERNET-PHYSICAL-CHANNEL, or <code>PNCswtPortGrp_&lt;PncID&gt;</code>, where <code>&lt;PncID&gt;</code> is the PNC-IDENTIFIER of the PNC-MAPPING.</p> <p><code>EthIfPortRef</code> references are configured to refer to each <code>EthSwtPort</code> container in <code>EthSwt</code> that corresponds to a COUPLING-PORT which references the ETHERNET-PHYSICAL-CHANNEL or the PNC-MAPPING for which this <code>EthIfSwitchPortGroup</code> container is created.</p> <p><code>EthIfSwitchPortGroupRefSemantics</code> is only configured in <code>EthIfSwitchPortGroup</code> containers that are created for an ETHERNET-PHYSICAL-CHANNEL. If there is any PNC-MAPPING of the configured ECU-INSTANCE which is related to any PDU which is sent over the ETHER-</p>

Configuration parameters	Mapping description
	NET-PHYSICAL-CHANNEL, the parameter value is set to ETHIF_SWITCH_PORT_GROUP_LINK_INFO, otherwise it is set to ETHIF_SWITCH_PORT_GROUP_CONTROL.

### 3.4.16. EthSM

Configuration parameters	Mapping description
EthSMNetwork	<p>For every ETHERNET-PHYSICAL-CHANNEL that is connected to at least one <i>virtual</i> ETHERNET-COMMUNICATION-CONTROLLER of the imported ECU-INSTANCE (see <a href="#">Section 3.4.15, "EthIf"</a>), an EthSMNetwork container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the ETHERNET-PHYSICAL-CHANNEL.</p> <p>EthSMComMNetworkHandleRef references the ComMChannel container in the ComM module configuration, which has been created for the ETHERNET-PHYSICAL-CHANNEL.</p> <p>EthSMethIfControllerRef references the EthIfController container in the EthIf module configuration, which has been created for the first virtual ETHERNET-COMMUNICATION-CONTROLLER that is connected to the ETHERNET-PHYSICAL-CHANNEL.</p>

### 3.4.17. EthSwt

Configuration parameters	Mapping description
EthSwtConfig	One EthSwtConfig container is created for each COUPLING-ELEMENT that references the imported ECU-INSTANCE via ECU-INSTANCE-REF and has its COUPLING-TYPE set to SWITCH. The container name is <PREFIX><name>, where <name> is the SHORT-NAME of the COUPLING-ELEMENT.
EthSwtConfig/EthSwtPort	<p>For each COUPLING-PORT contained in a configured COUPLING-ELEMENT one EthSwtPort subcontainer is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the COUPLING-PORT.</p> <p>EthSwtPortRole is set depending on the value of COUPLING-PORT/COUPLING-PORT-ROLE:</p>



Configuration parameters	Mapping description
	<p>▶ ETHSWT_HOST_PORT for HOST-PORT</p> <p>▶ ETHSWT_UP_LINK_PORT for UP-LINK-PORT</p> <p>For STANDARD-PORT, the parameter is not configured.</p> <p>EthSwtPortMacLayerType is set depending on the value of COUPLING-PORT/MAC-LAYER-TYPE:</p> <p>▶ ETHSWT_PORT_MAC_LAYER_TYPE_XGMII for XG-MII</p> <p>▶ ETHSWT_PORT_MAC_LAYER_TYPE_XMII for X-MII</p> <p>▶ ETHSWT_PORT_MAC_LAYER_TYPE_XXGMII for XXG-MII</p> <p>EthSwtPortPhysicalLayerType is set depending on the value of COUPLING-PORT/PHYSICAL-LAYER-TYPE:</p> <p>▶ ETHSWT_PORT_100BASE_TX for 100BASE-TX</p> <p>▶ ETHSWT_PORT_1000BASE_T for 1000BASE-T</p> <p>▶ ETHSWT_PORT_100BASE_T1 for 100BASE-T1</p> <p>▶ ETHSWT_PORT_1000BASE_T1 for 1000BASE-T1</p>
EthSwtConfig/EthSwtPort/EthSwtPortPredefinedMacAddresses	<p>The MAC addresses to configure are taken from the MAC-MULTICAST-ADDRESS value of the MAC-MULTICAST-GROUP elements which the COUPLING-PORT references via MAC-MULTICAST-ADDRESS-REFS/MAC-MULTICAST-ADDRESS-REF. For each distinct MAC address value one entry is added to EthSwtPortPredefinedMacAddresses.</p>
EthSwtConfig/EthSwtPort/EthSwtPortIngress	<p>For each COUPLING-PORT, one EthSwtPort/EthSwtPortIngress subcontainer is created.</p> <p>EthSwtPortIngressDefaultVlan is set to VLAN/VLAN-IDENTIFIER if COUPLING-PORT/DEFAULT-VLAN-REF references an ETHERNET-PHYSICAL-CHANNEL that contains a VLAN which in turn defines a valid VLAN-IDENTIFIER.</p> <p>EthSwtPortIngressDefaultPriority is set to VLAN-MEMBERSHIP/DEFAULT-PRIORITY if the VLAN-MEMBERSHIP is contained in COUPLING-PORT/VLAN-MEMBERSHIPS and VLAN-MEMBERSHIP/VLAN-REF references the ETHERNET-PHYSICAL-CHANNEL which is also referenced by COUPLING-PORT/DEFAULT-VLAN-REF. Otherwise, if the DEFAULT-PRIORITY values of all VLAN-MEMBERSHIPS of a COUPLING-PORT are identical, the EthSwtPortIngressDefaultPriority is set to this value.</p>

Configuration parameters	Mapping description
	<p>EthSwtPortTrafficClassAssignment is set to COUPLING-PORT-TRAFFIC-CLASS-ASSIGNMENT/TRAFFIC-CLASS if the COUPLING-PORT contains exactly one valid COUPLING-PORT-DETAILS/ETHERNET-TRAFFIC-CLASS-ASSIGNMENTS/ETHERNET-TRAFFIC-CLASS-ASSIGNMENT subelement which in turn contains a valid TRAFFIC-CLASS element but no PRIORITYS/PRIORITY subelements.</p> <p>EthSwtPortTrafficClassAssignment is set to COUPLING-PORT-TRAFFIC-CLASS-ASSIGNMENT/TRAFFIC-CLASS if the COUPLING-PORT contains exactly one valid COUPLING-PORT-DETAILS/ETHERNET-TRAFFIC-CLASS-ASSIGNMENTS/ETHERNET-TRAFFIC-CLASS-ASSIGNMENT subelement which in turn contains a valid TRAFFIC-CLASS element but no PRIORITYS/PRIORITY subelements.</p>
EthSwtConfig/EthSwtPort/EthSwtPortIngress/EthSwtPriorityRegeneration	<p>If the COUPLING-PORT contains a valid COUPLING-PORT-DETAILS subelement, then one EthSwtPriorityRegeneration container is created for each ETHERNET-PRIORITY-REGENERATIONS/ETHERNET-PRIORITY-REGENERATION element contained in COUPLING-PORT/COUPLING-PORT-DETAILS that contains a valid and distinct INGRESS-PRIORITY value. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the ETHERNET-PRIORITY-REGENERATION.</p> <p>EthSwtPriorityRegenerationIngressPriority is set to ETHERNET-PRIORITY-REGENERATION/INGRESS-PRIORITY, EthSwtPriorityRegenerationRegeneratedPriority is set to ETHERNET-PRIORITY-REGENERATION/REGENERATED-PRIORITY.</p>
EthSwtConfig/EthSwtPort/EthSwtPortIngress/EthSwtPriorityTrafficClassAssignment	<p>If the COUPLING-PORT contains a valid COUPLING-PORT-DETAILS subelement and COUPLING-PORT-DETAILS/ETHERNET-TRAFFIC-CLASS-ASSIGNMENTS contains at least one ETHERNET-TRAFFIC-CLASS-ASSIGNMENT element which in turn contains at least one PRIORITY element in ETHERNET-TRAFFIC-CLASS-ASSIGNMENT/PRIORITYS, then one EthSwtPriorityTrafficClassAssignment container is created for each distinct value in PRIORITY. The container name is &lt;PREFIX&gt;&lt;name&gt;_&lt;prio&gt;, where &lt;name&gt; is the SHORT-NAME of the ETHERNET-TRAFFIC-CLASS-ASSIGNMENT and &lt;prio&gt; is the value of ETHERNET-TRAFFIC-CLASS-ASSIGNMENT/PRIORITYS/PRIORITY.</p> <p>EthSwtPriorityTrafficClassAssignmentPriority is set to ETHERNET-TRAFFIC-CLASS-ASSIGNMENT/PRIORITYS/PRIORITY, EthSwtPriorityTrafficClassAssignmentTrafficClass is set to ETHERNET-TRAFFIC-CLASS-ASSIGNMENT/TRAFFIC-CLASS.</p>

Configuration parameters	Mapping description
EthSwtConfig/EthSwtPort/EthSwtPortEgress	<p>For each COUPLING-PORT that contains at least one entry in COUPLING-PORT-DETAILS/COUPLING-PORT-STRUCTURAL-ELEMENTS, one EthSwtPortEgress container is created.</p> <p>If COUPLING-PORT-DETAILS/COUPLING-PORT-STRUCTURAL-ELEMENTS/LAST-EGRESS-SCHEDULER-REF references a valid COUPLING-PORT-SCHEDULER of the COUPLING-PORT, then EthSwtPortEgressLastSchedulerRef is configured to reference the container that has been created for that COUPLING-PORT-SCHEDULER.</p>
EthSwtConfig/EthSwtPort/EthSwtPortEgress/EthSwtPortFifo	<p>For each COUPLING-PORT-FIFO subelement of COUPLING-PORT-STRUCTURAL-ELEMENTS, one EthSwtPortFifo container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the COUPLING-PORT-FIFO. For each distinct and valid value in COUPLING-PORT-FIFO/ASSIGNED-TRAFFIC-CLASS/ASSIGNED-TRAFFIC-CLASS, one EthSwtPortFifoTrafficClassAssignment subcontainer is created that contains that value.</p>
EthSwtConfig/EthSwtPort/EthSwtPortEgress/EthSwtPortShaper	<p>For each COUPLING-PORT-SHAPER subelement of COUPLING-PORT-STRUCTURAL-ELEMENTS, one EthSwtPortShaper container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the COUPLING-PORT-SHAPER.</p> <p>EthSwtPortShaperIdleSlope is set to COUPLING-PORT-SHAPER/IDLE-SLOPE, EthSwtPortEgressPredecessorFifoRef is configured to reference the EthSwtPortFifo container that has been created for the COUPLING-PORT-FIFO which COUPLING-PORT-SHAPER/REDECESSOR-FIFO-REF references.</p>
EthSwtConfig/EthSwtPort/EthSwtPortEgress/EthSwtPortScheduler	<p>For each COUPLING-PORT-SCHEDULER subelement of COUPLING-PORT-STRUCTURAL-ELEMENTS, one EthSwtPortScheduler container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the COUPLING-PORT-SCHEDULER.</p> <p>EthSwtPortSchedulerAlgorithm is set depending on the value of COUPLING-PORT-SCHEDULER/PORT-SCHEDULER:</p> <ul style="list-style-type: none"> <li>▶ ETHSWT_SCHEDULER_DEFICIT_ROUND_ROBIN for DEFICIT-ROUND-ROBIN</li> <li>▶ ETHSWT_SCHEDULER_STRICT_PRIORITY for STRICT-PRIORITY</li> <li>▶ ETHSWT_SCHEDULER_WEIGHTED_ROUND_ROBIN for WEIGHTED-ROUND-ROBIN</li> </ul>

Configuration parameters	Mapping description
	<p>For each COUPLING-PORT-STRUCTURAL-ELEMENT referenced by COUPLING-PORT-SCHEDULER/PREDECESSOR-REFS/PREDECESSOR-REF one EthSwtPortSchedulerPredecessor subcontainer is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the referenced COUPLING-PORT-STRUCTURAL-ELEMENT.</p> <p>EthSwtPortSchedulerPredecessorOrder is set to <math>10 * (&lt;numberOfElementsInPredecessorList&gt; - &lt;positionInPredecessorList&gt;)</math>, i.e. 0 for the last referenced element in COUPLING-PORT-SCHEDULER/PREDECESSOR-REFS, 10 for the second to last referenced, 20 for the third to last referenced element, etc. EthSwtPortEgressPredecessorRef is configured to reference the container that has been created for the COUPLING-PORT-STRUCTURAL-ELEMENT which COUPLING-PORT-SCHEDULER/PREDECESSOR-REFS/PREDECESSOR-REF references.</p>
EthSwtConfig/EthSwtPort/EthSwtPortVlanMembership	<p>The VLAN ID of a VLAN-MEMBERSHIP is the VLAN-IDENTIFIER of the VLAN contained in the ETHERNET-PHYSICAL-CHANNEL that VLAN-MEMBERSHIP/VLAN-REF refers to. For each VLAN-MEMBERSHIP that is associated with a distinct valid VLAN ID, one EthSwtPortVlanMembership container is created. The container name is EthSwtPortVlanMembership_&lt;VLAN_ID&gt;, where &lt;VLAN_ID&gt; is the associated VLAN ID.</p> <p>EthSwtPortVlanMembershipId is set to the VLAN ID.</p> <p>EthSwtPortVlanForwardingType is set depending on the value of VLAN-MEMBERSHIP/SEND-ACTIVITY:</p> <ul style="list-style-type: none"> <li>▶ ETHSWT_NOT_SENT for NOT-SENT</li> <li>▶ ETHSWT_SENT_TAGGED for SENT-TAGGED</li> <li>▶ ETHSWT_SENT_UNTAGGED for SENT-UNTAGGED</li> </ul>

### 3.4.18. EthTSyn

Configuration parameters	Mapping description
EthTSynGeneral	<p>One EthTSynGeneral container is created if there is at least one GLOBAL-TIME-DOMAIN that contains a GLOBAL-TIME-ETH-MASTER or a GLOBAL-TIME-ETH-SLAVE element that references an ETHERNET-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE.</p>

Configuration parameters	Mapping description
	<p>EthTSynMessageCompliance is configured if all of the GLOBAL-TIME-DOMAIN elements that contain a ETH-GLOBAL-TIME-DOMAIN-PROPS element providing a valid value in MESSAGE-COMPLIANCE have that value set consistently. If that value is IEEE802-1AS, EthTSynMessageCompliance is set to true. If that value is IEEE802-1AS-AUTOSAR, EthTSynMessageCompliance is set to false.</p>
EthTSynGlobalTimeDomain	<p>One EthTSynGlobalTimeDomain container is created for each GLOBAL-TIME-DOMAIN that contains a GLOBAL-TIME-ETH-MASTER or a GLOBAL-TIME-ETH-SLAVE element that references an ETHERNET-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the GLOBAL-TIME-DOMAIN.</p> <p>EthTSynGlobalTimeDomainId is set to DOMAIN-ID.</p> <p>EthTSynSynchronizedTimeBaseRef references the corresponding StbMSynchronizedTimeBase container in the StbM module. If the GLOBAL-TIME-DOMAIN is a subdomain of a parent GLOBAL-TIME-DOMAIN, EthTSynSynchronizedTimeBaseRef references the StbMSynchronizedTimeBase container that has been created for the parent GLOBAL-TIME-DOMAIN. For further information about the configuration of the StbM module, see <a href="#">Section 3.4.39, "StbM"</a></p>
EthTSynGlobalTimeDomain/EthTSynGlobalTimeFollowUpDataIDList	<p>If the Ethernet GLOBAL-TIME-DOMAIN contains a valid ETH-GLOBAL-TIME-DOMAIN-PROPS subelement that contains a non-empty ID list in FUP-DATA-ID-LISTS, that list is used to configure the container list EthTSynGlobalTimeDomain/EthTSynGlobalTimeFollowUpDataIDList/EthTSynGlobalTimeFollowUpDataIDListElement.</p> <p>One subcontainer is created per element named Element_&lt;idx&gt;, where &lt;idx&gt; is the zero-based index of the element within the list. EthTSynGlobalTimeFollowUpDataIDListIndex contains the zero-based index of the element within the list, EthTSynGlobalTimeFollowUpDataIDListValue is configured to contain the value of the element.</p>
EthTSynGlobalTimeDomain/EthTSynPortConfig	<p>If the GLOBAL-TIME-DOMAIN for which the EthTSynGlobalTimeDomain container has been created does not contain an ETH-GLOBAL-TIME-DOMAIN-PROPS that contains a valid MANAGED-COUPPLING-PORTS element, one EthTSynPortConfig subcontainer is created. It has the same name as its parent EthTSynGlobalTimeDomain container</p>

Configuration parameters	Mapping description
	<p><code>EthTSynGlobalTimeEthIfRef</code> references the <code>EthIfController</code> container that has been created for the <code>ETHERNET-COMMUNICATION-CONNECTOR</code> to which the <code>GLOBAL-TIME-ETH-MASTER</code> or <code>GLOBAL-TIME-ETH-SLAVE</code> refers. For further information about the configuration of the <code>EthIf</code> module, see <a href="#">Section 3.4.15, “EthIf”</a>.</p> <p>If the Ethernet <code>GLOBAL-TIME-DOMAIN</code> contains a valid <code>ETH-GLOBAL-TIME-DOMAIN-PROPS</code> subelement that in turn contains a valid <code>VLAN-PRIORITY</code> subelement, <code>EthTSynFramePrio</code> is configured to hold the value of <code>VLAN-PRIORITY</code>.</p> <p><code>EthTSynGlobalTimeDebounceTime</code> is set to <code>GLOBAL-TIME-DOMAIN/DEBOUNCE-TIME</code>.</p> <p>If the <code>GLOBAL-TIME-DOMAIN</code> for which the <code>EthTSynGlobalTimeDomain</code> container has been created contains an <code>ETH-GLOBAL-TIME-DOMAIN-PROPS</code> element that in turn contains one or more <code>ETH-GLOBAL-TIME-MANAGED-COUPLING-PORT</code> elements that refer to a <code>COUPLING-PORT</code> for which a <code>EthSwtPort</code> container has been created, see <a href="#">Section 3.4.17, “EthSwt”</a>, then one <code>EthTSynPortConfig</code> is created for each of these <code>ETH-GLOBAL-TIME-MANAGED-COUPLING-PORT</code> elements. In that case, the container name is the <code>SHORT-NAME</code> of the <code>COUPLING-PORT</code> and <code>EthTSynSwitchManagementEthSwitchPortRef</code> is configured to refer to the <code>EthSwtPort</code> container in the <code>EthSwt</code> module. In addition to that, a subcontainer <code>EthTSynPdelayConfig</code> is created.</p>
<code>EthTSynGlobalTimeDomain/EthTSynPortConfig/EthTSynPdelayConfig</code>	<p><code>EthTSynGlobalTimePdelayRespEnable</code> is set to <code>ETH-GLOBAL-TIME-MANAGED-COUPLING-PORT/PDELAY-RESPONSE-ENABLED</code>.</p> <p><code>EthTSynGlobalTimePropagationDelay</code> is set to <code>COUPLING-PORT/COUPLING-PORT-DETAILS/GLOBAL-TIME-PROPS/PROPAGATION-DELAY</code> of the <code>COUPLING-PORT</code> that is referenced by <code>ETH-GLOBAL-TIME-MANAGED-COUPLING-PORT/COUPLING-PORT-REF</code>.</p> <p><code>EthTSynGlobalTimeTxPdelayReqPeriod</code> is set to <code>ETH-GLOBAL-TIME-MANAGED-COUPLING-PORT/PDELAY-REQUEST-PERIOD</code>.</p>
<code>EthTSynGlobalTimeDomain/EthTSynPortConfig/EthTSynGlobalTimeMaster</code>	<p>This container is only configured if the parent <code>EthTSynPortConfig</code> container has not been created for a <code>ETH-GLOBAL-TIME-MANAGED-COUPLING-PORT</code>.</p> <p>If the <code>GLOBAL-TIME-ETH-MASTER</code> of the <code>GLOBAL-TIME-DOMAIN</code> references an <code>ETHERNET-COMMUNICATION-CONNECTOR</code> of the imported <code>ECU-INSTANCE</code>, an <code>EthTSynGlobalTimeMaster</code> container is created.</p>

Configuration parameters	Mapping description
	<p>EthTSynGlobalTimeTxPeriod is set to SYNC-PERIOD of the GLOBAL-TIME-ETH-MASTER.</p> <p>EthTSynCyclicMsgResumeTime is set to IMMEDIATE-RESUME-TIME of the GLOBAL-TIME-ETH-MASTER.</p> <p>EthTSynGlobalTimeTxCrcSecured is set to CRC-SECURED of the GLOBAL-TIME-ETH-MASTER.</p> <p>EthTSynIsSystemWideGlobalTimeMaster is set to IS-SYSTEM-WIDE-GLOBAL-TIME-MASTER of the GLOBAL-TIME-ETH-MASTER.</p>
EthTSynGlobalTime-Domain/EthTSynPortConfig/EthTSynGlobalTimeSlave	<p>This container is only configured if the parent EthTSynPortConfig container has not been created for a ETH-GLOBAL-TIME-MANAGED-COUPLING-PORT.</p> <p>If one of the GLOBAL-TIME-ETH-SLAVE elements of the GLOBAL-TIME-DOMAIN references an ETHERNET-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE, an EthTSynGlobalTimeSlave container is created.</p> <p>EthTSynRxCrcValidated is set to CRC-VALIDATED of the GLOBAL-TIME-ETH-SLAVE.</p>

### 3.4.19. FiM

Configuration parameters	Mapping description
FiM/FiMConfigSet/FiMFID	A FiMFID is created for each DiagnosticFunctionIdentifier.
FiMConfigSet/FiMSummaryEvent	<p>Based on the attributes ActualEvent or AliasEvent of the DiagnosticFimAliasEventMapping a FiMSummaryEvent container is created for every mapping, as follows:</p> <ol style="list-style-type: none"> <li>1. If the ActualEvent attribute exists then the FiMSummaryEvent is created based on it.</li> <li>2. If the AliasEvent attribute exists then the FiMSummaryEvent is created based on it.</li> </ol> <p>After going through all the DiagnosticFimAliasEventMapping, each FimAliasEventGroupMapping is taken into account, and based on the DiagnosticFimEventGroup and the DiagnosticFimAliasEventGroup attributes a FiMSummaryEvent is created for every mapping as follows:</p>

Configuration parameters	Mapping description
	<ol style="list-style-type: none"> <li>1. If the <code>DiagnosticFimEventGroup</code> attribute exists then the <code>FiMSummaryEvent</code> is created based on the actual events that it contains, and which were not covered by the <code>DiagnosticFimAliasEventMapping</code>.</li> <li>2. If the <code>DiagnosticFimAliasEventGroup</code> attribute exists then the <code>FiMSummaryEvent</code> is created based on the alias events that it contains, and which were not covered by the <code>DiagnosticFimAliasEventMapping</code>.</li> </ol>
<code>FiMConfigSet/FiMinhibitionConfiguration</code>	For every <code>DiagnosticFunctionIdentifierInhibit</code> a container of type <code>FiMinhibitionConfiguration</code> is created. The name of the container is the short name of <code>DiagnosticFunctionIdentifierInhibit</code> .
<code>FiMConfigSet/FiMinhibitionConfiguration/DiagnosticFunctionIdentifierInhibit/FiMinhEventId</code>	For every <code>FiMinhibitionConfiguration</code> container a <code>FiMinhEventId</code> sub-container is created with the short name <code>FiMinhEventId</code> . The <code>FiMinhEventId</code> has a <code>FiMinhRefChoice</code> container of type choice.
<code>FiMConfigSet/FiMEventSummary/FiMinputSumEventRef</code>	For every <code>FiMEventSummary</code> container a mandatory <code>FiMinputSumEventRef</code> reference is set.
<code>FiMConfigSet/FiMEventSummary/FiMOutputSumEventRef</code>	For every <code>FiMEventSummary</code> container a mandatory <code>FiMOutputSumEventRef</code> reference is set.
<code>FiMConfigSet/FiMSummaryEventId</code>	<p>For each <code>FiAliasEventGroupMapping</code> a <code>FiMSummaryEventId</code> container is created based on the attributes <code>DiagnosticFimEventGroup</code> and <code>DiagnosticFimAliasEventGroup</code> as follows:</p> <ol style="list-style-type: none"> <li>1. If the <code>DiagnosticFimEventGroup</code> attribute exists then the <code>FiMSummaryEventId</code> is created based on the actual eventGroup.</li> <li>2. If the <code>DiagnosticFimAliasEventGroup</code> attribute exists then the <code>FiMSummaryEventId</code> is created based on the alias eventGroup.</li> </ol>



### 3.4.20. Fr

Configuration parameters	Mapping description
FrMultipleConfiguration/FrController	<p>For every FLEXRAY-COMMUNICATION-CONTROLLER which is connected to a FLEXRAY-CLUSTER and which belongs to the imported ECU-INSTANCE, a Fr-Controller container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-COMMUNICATION-CONTROLLER.</p> <p>FrPAllowHaltDueToClock is set to ALLOW-HALT-DUE-TO-CLOCK.</p> <p>FrPAllowPassiveToActive is set to ALLOW-PASSIVE-TO-ACTIVE.</p> <p>FrPChannels is set depending on which FLEXRAY-PHYSICAL-CHANNEL elements the FLEXRAY-COMMUNICATION-CONTROLLER is connected to:</p> <ul style="list-style-type: none"> <li>▶ FR_CHANNEL_A if connected to CHANNEL-A.</li> <li>▶ FR_CHANNEL_B if connected to CHANNEL-B.</li> <li>▶ FR_CHANNEL_AB if connected to CHANNEL-A and CHANNEL-B.</li> </ul> <p>FrPClusterDriftDamping is set to CLUSTER-DRIFT-DAMPING.</p> <p>FrPdAcceptedStartupRange is set to ACCEPTED-STARTUP-RANGE.</p> <p>FrPDecodingCorrection is set to DECODING-CORRECTION.</p> <p>FrPDelayCompensationA is set to DELAY-COMPENSATION-A.</p> <p>FrPDelayCompensationB is set to DELAY-COMPENSATION-B.</p> <p>FrPdListenTimeout is set to LISTEN-TIMEOUT.</p> <p>FrPdMicrotick is set depending on the value of MICROTICK-DURATION [ns]:</p> <ul style="list-style-type: none"> <li>▶ T200NS for 200.</li> <li>▶ T100NS for 100.</li> <li>▶ T50NS for 50.</li> <li>▶ T25NS for 25.</li> <li>▶ T12_5NS for 12.5.</li> <li>▶ For any other values FrPdMicrotick is not configured and a warning is reported.</li> </ul> <p>FrPEternalSync is set to EXTERNAL-SYNC.</p>

Configuration parameters	Mapping description
	<p>FrPFallBackInternal is set to FALL-BACK-INTERNAL.</p> <p>FrPKeySlotId is set to KEY-SLOT-ID. If KEY-SLOT-ONLY-ENABLED, KEY-SLOT-USED-FOR-START-UP, or KEY-SLOT-USED-FOR-SYNC are set to true, but KEY-SLOT-ID is undefined, a warning is reported.</p> <p>FrPKeySlotOnlyEnabled is set to KEY-SLOT-ONLY-ENABLED.</p> <p>FrPKeySlotUsedForStartup is set to KEY-SLOT-USED-FOR-START-UP.</p> <p>FrPKeySlotUsedForSync is set to KEY-SLOT-USED-FOR-SYNC.</p> <p>FrPLatestTx is set to LATEST-TX.</p> <p>FrPMacroInitialOffsetA is set to MACRO-INITIAL-OFFSET-A.</p> <p>FrPMacroInitialOffsetB is set to MACRO-INITIAL-OFFSET-B.</p> <p>FrPMicroInitialOffsetA is set to MICRO-INITIAL-OFFSET-A.</p> <p>FrPMicroInitialOffsetB is set to MICRO-INITIAL-OFFSET-B.</p> <p>FrPMicroPerCycle is set to MICRO-PER-CYCLE.</p> <p>FrPNmVectorEarlyUpdate is set to NM-VECTOR-EARLY-UPDATE.</p> <p>FrPOffsetCorrectionOut is set to OFFSET-CORRECTION-OUT.</p> <p>FrPOffsetCorrectionStart is set to OFFSET-CORRECTION-START of the FLEXRAY-CLUSTER to which the FLEXRAY-COMMUNICATION-CONTROLLER is connected.</p> <p>FrPPayloadLengthDynMax is set to MAXIMUM-DYNAMIC-PAYLOAD-LENGTH.</p> <p>FrPRateCorrectionOut is set to RATE-CORRECTION-OUT.</p> <p>FrPSamplesPerMicrotick is set depending on the value of SAMPLES-PER-MICROTICK:</p> <ul style="list-style-type: none"> <li>▶ N1SAMPLES for 1.</li> <li>▶ N2SAMPLES for 2.</li> <li>▶ N4SAMPLES for 4.</li> <li>▶ For all other values of SAMPLES-PER-MICROTICK FrPSamplesPerMicrotick is set to N1SAMPLES and a warning is reported.</li> </ul>

Configuration parameters	Mapping description
	<p>FrPSecondKeySlotId is set to SECOND-KEY-SLOT-ID. If TWO-KEY-SLOT-MODE is set to true, but SECOND-KEY-SLOT-ID is undefined, a warning is reported.</p> <p>FrPTwoKeySlotMode is set to TWO-KEY-SLOT-MODE</p> <p>FrPWakeupChannel is set depending on the COMMUNICATION-CONNECTOR elements of the FLEXRAY-COMMUNICATION-CONTROLLER. The PHYSICAL-CHANNEL which is connected to the COMMUNICATION-CONNECTOR which has WAKE-UP-CHANNEL set to true determines the value of FrPWakeupChannel:</p> <ul style="list-style-type: none"> <li>▶ FR_CHANNEL_A if the CHANNEL-NAME is CHANNEL-A.</li> <li>▶ FR_CHANNEL_B if the CHANNEL-NAME is CHANNEL-B.</li> </ul> <p>If no COMMUNICATION-CONNECTOR has its WAKE-UP-CHANNEL set to true a warning is issued and FrPWakeupChannel is set to FR_CHANNEL_A.</p> <p>FrPWakeupPattern is set to WAKE-UP-PATTERN.</p>
FrMultipleConfiguration/FrController/FrAbsoluteTimer	If no FrAbsoluteTimer container exists yet, a new one named FrAbsoluteTimer is created.

### 3.4.21. FrArTp

Configuration parameters	Mapping description
FrArTpMultipleConfig/FrArTpChannel	<p>For each FLEXRAY-AR-TP-CHANNEL that contains at least one FLEXRAY-AR-TP-CONNECTION which is processed by the imported ECU-INSTANCE, one FrArTpChannel container is created. The name of the container is FrArTpChannel_&lt;idx&gt;, where &lt;idx&gt; is a zero-based index.</p> <p>FrArTpAckType is configured depending on the value of ACK-TYPE:</p> <ul style="list-style-type: none"> <li>▶ FRARTP_ACK_WITH_RT for ACK-WITH-RT.</li> <li>▶ FRARTP_ACK_WITHOUT_RT for ACK-WITHOUT-RT.</li> <li>▶ FRARTP_NO for NO-ACK.</li> </ul>

Configuration parameters	Mapping description
	<p>FrArTpAdrType is configured depending on the value of EXTENDED-ADDRESSING:</p> <ul style="list-style-type: none"> <li>▶ FRARTP_TB for true.</li> <li>▶ FRARTP_OB for false.</li> </ul> <p>FrArTpGrpSeg is set to MULTICAST-SEGMENTATION.</p> <p>FrArTpLm is configured depending on the value of MAXIMUM-MESSAGE-LENGTH:</p> <ul style="list-style-type: none"> <li>▶ FRARTP_ISO6 for ISO-6.</li> <li>▶ FRARTP_ISO for ISO.</li> <li>▶ FRARTP_L4G for I4G.</li> </ul> <p>FrArTpMaxAr is set to MAX-AR.</p> <p>FrArTpMaxAs is set to MAX-AS.</p> <p>FrArTpMaxBs is set to MAX-BS.</p> <p>FrArTpMaxRn is set to MAX-RETRIES.</p> <p>FrArTpMaxWft is set to MAX-FC-WAIT.</p> <p>FrArTpStMin is set to MINIMUM-SEPARATION-TIME.</p> <p>FrArTpStMinGrpSeg is set to MINIMUM-MULTICAST-SEPERATION-TIME.</p> <p>FrArTpTc is set to CANCELLATION.</p> <p>FrArTpTimeBr is set to TIME-BR.</p> <p>FrArTpTimeCs is set to TIME-CS.</p> <p>FrArTpTimeoutAr is set to TIMEOUT-AR.</p> <p>FrArTpTimeoutAs is set to TIMEOUT-AS.</p> <p>FrArTpTimeoutBs is set to TIMEOUT-BS.</p> <p>FrArTpTimeoutCr is set to TIMEOUT-CR.</p>
FrTpMultipleConfig/FrArTpChan-	<p>The imported ECU-INSTANCE processes a FLEXRAY-AR-TP-CONNECTION if the FLEXRAY-AR-TP-CONNECTION references via SOURCE-REF or TAR-</p>

Configuration parameters	Mapping description
nel/FrArTpConnection	<p>GET-REFS/TARGET-REF any FLEXRAY-AR-TP-NODE that belongs to the imported ECU-INSTANCE.</p> <p>A FLEXRAY-AR-TP-NODE belongs to the imported ECU-INSTANCE if it references any COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE via CONNECTOR-REF.</p> <p>The sender FLEXRAY-AR-TP-NODE of a FLEXRAY-AR-TP-CONNECTION is the FLEXRAY-AR-TP-NODE which the FLEXRAY-AR-TP-CONNECTION references via SOURCE-REF</p> <p>The receiver FLEXRAY-AR-TP-NODE elements of a FLEXRAY-AR-TP-CONNECTION are the FLEXRAY-AR-TP-NODE elements which the FLEXRAY-AR-TP-CONNECTION references via TARGET-REFS/TARGET-REF.</p> <p>The TP-ADDRESS of a FLEXRAY-AR-TP-NODE is the TP-ADDRESS which it references via TP-ADDRESS-REF.</p> <p>The sender TP-ADDRESS of a FLEXRAY-AR-TP-CONNECTION is the TP-ADDRESS of the sender node of the FLEXRAY-AR-TP-CONNECTION. The receiver TP-ADDRESS of a FLEXRAY-AR-TP-CONNECTION is either the TP-ADDRESS which the FLEXRAY-AR-TP-CONNECTION references via MULTICAST-REF or the TP-ADDRESS of the first receiver FLEXRAY-AR-TP-NODE if MULTICAST-REF is not defined.</p> <p>If the sender FLEXRAY-AR-TP-NODE belongs to the imported ECU-INSTANCE, its TP-ADDRESS is considered the <i>local</i> address of the FLEXRAY-AR-TP-CONNECTION, and the receiver TP-ADDRESS is considered as its <i>remote</i> TP-ADDRESS. If the sender FLEXRAY-AR-TP-NODE does not belong to the imported ECU-INSTANCE, its TP-ADDRESS is considered as <i>remote</i> and the receiver TP-ADDRESS is considered as <i>local</i>.</p> <p>FrArTpLa is set to TP-ADDRESS/TP-ADDRESS of the <i>local</i> TP-ADDRESS.</p> <p>FrArTpMultRec is set to true if the FLEXRAY-AR-TP-CONNECTION references a TP-ADDRESS via MULTICAST-REF, otherwise to false.</p> <p>FrArTpRa is set to TP-ADDRESS/TP-ADDRESS of the <i>remote</i> TP-ADDRESS.</p>
FrTpMultipleConfig/FrArTpChannel/FrArTpConnection/FrArTpRxSdu	<p>If the imported ECU-INSTANCE receives any PDU which the FLEXRAY-AR-TP-CONNECTION references either via DIRECT-TP-SDU-REF or via REVERSED-TP-SDU-REF, an FrArTpRxSdu sub container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p>

Configuration parameters	Mapping description
	FrArTpRxSduRef is configured to reference the corresponding container of the PDU in the EcuC module.
FrTpMultipleConfig/FrArTpChannel/FrArTpConnection/FrArTpTxSdu	<p>If the imported ECU-INSTANCE sends any PDU which the FLEXRAY-AR-TP-CONNECTION references either via DIRECT-TP-SDU-REF or via REVERSED-TP-SDU-REF, an FrArTpTxSdu sub container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>FrArTpTxSduRef is configured to reference the corresponding container of the PDU in the EcuC module.</p>
FrTpMultipleConfig/FrArTpChannel/FrArTpPdu	<p>For each N-PDU which the FLEXRAY-AR-TP-CHANNEL references via N-PDU-REFS/N-PDU-REF and which the imported ECU-INSTANCE either receives or sends, one FrArTpPdu container is created. The name of the container is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the N-PDU.</p> <p>FrArTpPduRef is configured to reference the corresponding container of the N-PDU in the EcuC module.</p> <p>FrArTpPduDirection is set to FRARTP_RX if the imported ECU-INSTANCE receives the N-PDU. If the imported ECU-INSTANCE sends the N-PDU, FrArTpPduDirection is set to FRARTP_TX.</p>

### 3.4.22. FrIf

Configuration parameters	Mapping description
FrIfConfig/FrIfCluster	<p>For every FLEXRAY-CLUSTER to which the imported ECU-INSTANCE is connected a FrIfCluster container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-CLUSTER.</p> <p>FrIfGdWakeupRxIdle is set to WAKEUP-RX-IDLE.</p> <p>FrIfGdWakeupRxLow is set to WAKEUP-RX-LOW.</p> <p>FrIfGdWakeupRxWindow is set to WAKEUP-RX-WINDOW.</p> <p>FrIfGdWakeupTxIdle is set to WAKEUP-TX-IDLE.</p>

Configuration parameters	Mapping description
	<p>FrIfGPayloadLengthStatic is set to PAYLOAD-LENGTH-STATIC.</p> <p>FrIfGNetworkManagementVectorLength is set to NETWORK-MANAGEMENT-VECTOR-LENGTH.</p> <p>FrIfGdCycle is set to CYCLE.</p> <p>FrIfGdCasRxLowMax is set to CAS-RX-LOW-MAX.</p> <p>FrIfGNumberOfStaticSlots is set to NUMBER-OF-STATIC-SLOTS.</p> <p>FrIfGColdStartAttempts is set to COLD-START-ATTEMPTS.</p> <p>FrIfGdActionPointOffset is set to ACTION-POINT-OFFSET.</p> <p>FrIfGdDynamicSlotIdlePhase is set to DYNAMIC-SLOT-IDLE-PHASE.</p> <p>FrIfGdMinislot is set to MINISLOT-DURATION.</p> <p>FrIfGdMinislotActionPointOffset is set to MINISLOT-ACTION-POINT-OFFSET.</p> <p>FrIfGdNit is set to NETWORK-IDLE-TIME.</p> <p>FrIfGdStaticSlot is set to STATIC-SLOT-DURATION.</p> <p>FrIfGdSymbolWindow is set to SYMBOL-WINDOW.</p> <p>FrIfGdTSSTransmitter is set to TRANSMISSION-START-SEQUENCE-DURATION.</p> <p>FrIfGListenNoise is set to LISTEN-NOISE.</p> <p>FrIfGMacroPerCycle is set to MACRO-PER-CYCLE.</p> <p>FrIfGdMacrotick is set to MACROTICK-DURATION.</p> <p>FrIfGMaxWithoutClockCorrectPassive is set to MAX-WITHOUT-CLOCK-CORRECTION-PASSIVE.</p> <p>FrIfGMaxWithoutClockCorrectFatal is set to MAX-WITHOUT-CLOCK-CORRECTION-FATAL.</p> <p>FrIfGNumberOfMinislots is set to NUMBER-OF-MINISLOTS.</p> <p>FrIfGChannels is set depending on the FLEXRAY-CLUSTER's PHYSICAL-CHANNEL elements to which the imported ECU-INSTANCE is connected:</p>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ FR_CHANNEL_A if connected to CHANNEL-A.</li> <li>▶ FR_CHANNEL_B if connected to CHANNEL-B.</li> <li>▶ FR_CHANNEL_AB if connected to both CHANNEL-A and CHANNEL-B.</li> </ul> <p>FrIfGdSampleClockPeriod is set depending on the value of SAMPLE-CLOCK-PERIOD[s]:</p> <ul style="list-style-type: none"> <li>▶ T50NS for values <math>\geq 0.000000050</math>.</li> <li>▶ T25S for values <math>\geq 0.000000025</math> and <math>&lt; 0.000000050</math>.</li> <li>▶ T12_5NS for values <math>\geq 0.0000000125</math> and <math>&lt; 0.000000025</math>.</li> <li>▶ For values <math>&lt; 0.0000000125</math> FrIfGdSampleClockPeriod is set to T12_5NS and a warning is reported.</li> </ul> <p>FrIfGdBit is set depending on the value of BIT [s], BAUDRATE [bit/s] or SPEED [kbit/s] according to the following formulas:</p> <ul style="list-style-type: none"> <li>▶ <math>\text{BIT} * 10^9</math>.</li> <li>▶ <math>10^9 / \text{BAUDRATE}[\text{bit/s}]</math> if BIT is not available.</li> <li>▶ <math>10^6 / \text{SPEED}[\text{kbit/s}]</math> if neither BIT nor BAUDRATE are available.</li> </ul> <p>FrIfGdBit is then configured depending on the calculation result:</p> <ul style="list-style-type: none"> <li>▶ T100NS for 100.</li> <li>▶ T200NS for 200.</li> <li>▶ T400NS for 400.</li> <li>▶ For all other values FrIfGdBit is set to T100NS and a warning is reported.</li> </ul> <p>FrIfDetectNITError is set to DETECT-NIT-ERROR.</p> <p>FrIfGCycleCountMax is set to CYCLE-COUNT-MAX.</p> <p>FrIfGdIgnoreAfterTx is set to IGNORE-AFTER-TX.</p> <p>FrIfGdSymbolWindowActionPointOffset is set to SYMBOL-WINDOW-ACTION-POINT-OFFSET.</p> <p>FrIfGdWakeupTxActive is set to WAKEUP-TX-ACTIVE.</p> <p>FrIfGSyncFrameIDCountMax is set to SYNC-FRAME-ID-COUNT-MAX.</p> <p>FrIfSafetyMargin is set to SAFETY-MARGIN.</p>



Configuration parameters	Mapping description
FrIfConfig/FrIf-Cluster/FrIfController	<p>For every FLEXRAY-COMMUNICATION-CONTROLLER connected to the FLEXRAY-CLUSTER and the imported ECU-INSTANCE a FrIfController container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-COMMUNICATION-CONTROLLER.</p> <p>FrIfFrCtrlRef references the corresponding container in the Fr module configuration.</p>
FrIfConfig/FrIf-Cluster/FrIf-Controller/FrIf-FrameTriggering	<p>For every FLEXRAY-FRAME-TRIGGERING which contains via the referenced FLEXRAY-FRAME and I-PDU-TO-FRAME-MAPPING elements PDUs sent or received by the imported ECU-INSTANCE a FrIfFrameTriggering container is created. The container name is t&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-FRAME.</p> <p>FrIfChannel is set depending on which PHYSICAL-CHANNEL the FLEXRAY-FRAME-TRIGGERING is sent/received:</p> <ul style="list-style-type: none"> <li>▶ FRIF_CHANNEL_A if sent/received on CHANNEL-A.</li> <li>▶ FRIF_CHANNEL_B if sent/received on CHANNEL-B.</li> <li>▶ FRIF_CHANNEL_AB if two FLEXRAY-FRAME-TRIGGERING elements exist, one on CHANNEL-A, the other on CHANNEL-B, which reference the same FLEXRAY-FRAME. In this case the following conditions must hold as well: <ul style="list-style-type: none"> <li>▶ BASE-CYCLE, CYCLE-REPETITION, and SLOT-ID must be identical.</li> <li>▶ Both FLEXRAY-FRAME-TRIGGERING must have the same transmission direction (sent/received).</li> <li>▶ The SLOT-ID must be &lt;= NUMBER-OF-STATIC-SLOTS as defined in the FLEXRAY-CLUSTER.</li> <li>▶ ALLOW-DYNAMIC-L-SDU-LENGTH, PAYLOAD-PREAMBLE-INDICATOR, and MESSAGE-ID must be identical or undefined for both FLEXRAY-FRAME-TRIGGERING elements.</li> </ul> </li> </ul> <p>If the conditions hold, only a single FrIfFrameTriggering container is created.</p> <p>FrIfFrameStructureRef references the container created for the FLEXRAY-FRAME referenced by the FLEXRAY-FRAME-TRIGGERING (see FrIfConfig/FrIfFrameStructure).</p> <p>FrIfBaseCyle, FrIfCycleRepetition are set to BASE-CYCLE and CYCLE-REPETITION of the FLEXRAY-FRAME-TRIGGERING elements FLEXRAY-ABSOLUTELY-SCHEDULED-TIMING respectively, where values</p>

Configuration parameters	Mapping description
	<p>of multiple FLEXRAY-ABSOLUTELY-SCHEDULED-TIMING elements are normalized (i.e. BASE-CYCLE-0/CYCLE-REPETITION-2 and BASE-CYCLE-1/CYCLE-REPETITION-2 are normalized to BASE-CYCLE-0/CYCLE-REPETITION-1).</p> <p>FrIfLSduLength is set to FRAME-LENGTH of the FLEXRAY-FRAME</p> <p>FrIfSlotId is set to SLOT-ID.</p> <p>FrIfPayloadPreamble is set to PAYLOAD-PREAMBLE-INDICATOR.</p> <p>FrIfAllowDynamicLSduLength is set to ALLOW-DYNAMIC-L-SDU-LENGTH.</p> <p>FrIfMessageId is set to MESSAGE-ID.</p>
FrIfConfig/FrIf-FrameStructure	<p>For every FRAME instance sent/received by the imported ECU-INSTANCE a FrIfFrameStructure container is created. The container name is f&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-FRAME.</p>
FrIfConfig/FrIf-FrameStructure/FrIfPduIn-Frame	<p>For every PDU sent/received by the imported ECU-INSTANCE and contained by the FLEXRAY-FRAME for which the FrIfFrameStructure container has been created, a FrIfPduInFrame container is created. The container name is p&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>FrIfPduOffset is set to START-POSITION of the PDU-TO-FRAME-MAPPING, divided by 8.</p> <p>FrIfPduUpdateBitOffset is set to UPDATE-INDICATION-BIT-POSITION of the PDU-TO-FRAME-MAPPING, converted to monotone representation.</p> <p>FrIfPduRef references the container created for this PDU under FrIfConfig/FrIfPdu.</p>
FrIfConfig/FrIfPdu	<p>For every PDU instance (see <a href="#">Section 3.3.1.3, "Instance handling"</a>) sent, received or routed (see <a href="#">Section 3.3.5, "PDU routing"</a>) by the imported ECU-INSTANCE, a FrIfPdu container is created. The container name is p&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU belonging to the PDU instance.</p> <p>FrIfPduDirection is set to FrIfRxPdu if received by the imported ECU-INSTANCE, or to FrIfTxPdu if sent by the imported ECU-INSTANCE. The name of FrIfRxPdu/FrIfTxPdu is set to &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU belonging to the PDU instance.</p>

Configuration parameters	Mapping description
	<p><code>FrIfRxPduRef</code>/<code>FrIfTxPduRef</code> references the corresponding container in the <code>EcuC</code> module configuration.</p> <p><code>FrIfUserTxUL</code>/<code>FrIfUserRxIndicationUL</code> is set depending on the type of PDU:</p> <ul style="list-style-type: none"> <li>▶ <code>FR_NM</code> for NM-PDU elements.</li> <li>▶ <code>FR_TP</code> for N-PDU elements that are not routed via gateway.</li> <li>▶ <code>PDUR</code> for I-SIGNAL-PDU elements, MULTIPLEXED-I-PDU elements, CONTAINER-I-PDU elements, GENERAL-PURPOSE-I-PDU elements, DCM-I-PDU elements, for USER-DEFINED-I-PDU elements, which either have a <code>CATEGORY</code> other than <code>XCP</code> or are routed, and for N-PDU elements that are routed (see <a href="#">Section 3.3.5, “PDU routing”</a>).</li> <li>▶ <code>XCP</code> for XCP-PDU elements.</li> <li>▶ <code>CDD</code> for USER-DEFINED-I-PDU elements that have their <code>CATEGORY</code> set to <code>XCP</code> and for all other PDU types.</li> </ul>

### 3.4.23. FrNm

Configuration parameters	Mapping description
<code>FrNmGlobalConfig</code> / <code>FrNmGlobalProperties</code>	<p>The following parameters are set using the first <code>FLEXRAY-NM-ECU</code> of all <code>FLEXRAY-NM-CLUSTER</code> elements belonging to the imported <code>ECU-INSTANCE</code>:</p> <p><code>FrNmMainAcrossFrCycle</code> is set to <code>NM-MAIN-FUNCTION-ACROSS-FR-CYCLE</code>.</p>
<code>FrNmGlobalConfig</code> / <code>FrNmGlobalFeatures</code>	<p><code>FrNmComUserDataSupport</code> is set to <code>true</code> if <code>FrNmRxUserDataPduRef</code> or <code>FrNmTxUserDataPduRef</code> is set for any <code>FrNmChannelConfig</code>/<code>FrNmChannelIdentifiers</code>, or if any <code>FLEXRAY-NM-CLUSTER</code> linked to the imported <code>ECU-INSTANCE</code> has its <code>NM-PNC-PARTICIPATION</code> either not defined or set to <code>true</code>. Otherwise <code>FrNmComUserDataSupport</code> is set to <code>false</code>.</p> <p><code>FrNmPnResetTime</code> is set to <code>PN-RESET-TIME</code> of the configured <code>ECU-INSTANCE</code>.</p> <p>The following parameters are set using the first <code>NM-ECU</code> of all <code>FLEXRAY-NM-CLUSTER</code> elements belonging to the imported <code>ECU-INSTANCE</code>:</p>

Configuration parameters	Mapping description
	<p>FrNmBusSynchronizationEnabled is set to NM-BUS-SYNCHRONIZATION-ENABLED.</p> <p>FrNmDualChannelPduEnable is set to NM-MULTIPLE-CHANNELS-ENABLED.</p> <p>FrNmPassiveModeEnabled: see <a href="#">Section 3.4.4, “CanNm”</a>, CanNmPassiveModeEnabled.</p> <p>FrNmPduRxIndicationEnabled is set to NM-PDU-RX-INDICATION-ENABLED.</p> <p>FrNmRemoteSleepIndicationEnabled is set to NM-REMOTE-SLEEP-IND-ENABLED.</p> <p>FrNmStateChangeIndicationEnabled is set to NM-STATE-CHANGE-IND-ENABLED.</p> <p>FrNmUserDataEnabled is set to NM-USER-DATA-ENABLED.</p> <p>FrNmRepeatMessageBitEnabled is set to NM-REPEAT-MESSAGE-BIT-ENABLE.</p> <p>If inconsistencies are detected among parameters of multiple NM-ECU elements, a warning is reported.</p> <p>FrNmHwVoteEnable is set to NM-HW-VOTE-ENABLED of the FLEXRAY-NM-ECU belonging to the NM-ECU.</p> <p>FrNmControlBitVectorEnabled is set to NM-CONTROL-BIT-VECTOR-ENABLED of the first FLEXRAY-NM-CLUSTER-COUPLING belonging to the imported ECU-INSTANCE.</p>
FrNmChannelConfig/FrNmChannel	<p>For every FLEXRAY-NM-CLUSTER which belongs to the imported ECU-INSTANCE, a FrNmChannel container is created.</p> <p>The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-NM-CLUSTER.</p> <p>A FLEXRAY-NM-CLUSTER belongs to the imported ECU-INSTANCE if at least one of the FLEXRAY-NM-CLUSTER's FLEXRAY-NM-NODE elements references a FLEXRAY-COMMUNICATION-CONTROLLER of this ECU-INSTANCE.</p> <p>The NM-ECU used for configuring some of the FrNmChannel parameters is the NM-ECU which the first FLEXRAY-NM-NODE references via NM-IF-ECU-REF.</p>

Configuration parameters	Mapping description
FrNmChannelConfig/FrNmChannel/FrNmChannelIdentifiers	<p>FrNmNodeDetectionEnabled is set to NM-CLUSTER/NM-NODE-DETECTION-ENABLED, or to NM-ECU/NM-NODE-DETECTION-ENABLED if NM-CLUSTER/NM-NODE-DETECTION-ENABLED is not available.</p> <p>FrNmSourceNodeIdentifierEnabled is set to NM-CLUSTER/NM-NODE-ID-ENABLED, or to NM-ECU/NM-NODE-ID-ENABLED if NM-CLUSTER/NM-NODE-ID-ENABLED is not available.</p> <p>FrNmControlBitVectorActive is set to NM-CONTROL-BIT-VECTOR-ACTIVE.</p> <p>FrNmRepeatMessageBitActive is set to NM-REPEAT-MESSAGE-BIT-ACTIVE.</p> <p>FrNmSynchronizationPointEnabled is set to NM-SYNCHRONIZING-NETWORK.</p> <p>FrNmChannelHandle references the FrIfCluster container in the FrIf module configuration, which has been created for the FLEXRAY-CLUSTER referenced via COMMUNICATION-CLUSTER-REF.</p> <p>FrNmNodeId is set to NM-NODE-ID of the first FLEXRAY-NM-NODE which belongs to the FLEXRAY-NM-CLUSTER and at the same time belongs to the ECU-INSTANCE. A FLEXRAY-NM-NODE belongs to an ECU-INSTANCE if it references a FLEXRAY-COMMUNICATION-CONTROLLER of this ECU-INSTANCE.</p> <p>FrNmComMNetworkHandleRef references the ComMChannel container that is created for the COMMUNICATION-CLUSTER referenced in COMMUNICATION-CLUSTER-REF.</p> <p>FrNmPduScheduleVariant is set depending on the value of NM-SCHEDULE-VARIANT of the first FLEXRAY-NM-CLUSTER-COUPLING belonging to the FLEXRAY-NM-CLUSTER:</p> <p>► FRNM_PDU_SCHEDULE_VARIANT_&lt;x&gt; is set to SCHEDULE-VARIANT-&lt;x&gt; where x lies within [1..7].</p>
FrNmChannelConfig/FrNmChannel/FrNmChannelTiming	<p>FrNmDataCycle is set to FRNM_CYCLE_VALUE_&lt;value of NM-DATA-CYCLE&gt;. If NM-DATA-CYCLE is not one of [1,2,4,8,18,32,64], a warning is reported and FrNmDataCycle is not configured.</p> <p>FrNmRepetitionCycle is set depending on the value of NM-REPETITION-CYCLE, see FrNmDataCycle for how values are mapped.</p>

Configuration parameters	Mapping description
	<p><b>FrNmVotingCycle</b> is set depending on the value of NM-VOTING-CYCLE, see <b>FrNmDataCycle</b> for how values are mapped.</p> <p><b>FrNmMainFunctionPeriod</b> is set to NM-MAIN-FUNCTION-PERIOD.</p> <p><b>FrNmMsgTimeoutTime</b> is set to NM-MESSAGE-TIMEOUT-TIME.</p> <p><b>FrNmNodeDetectionLock</b> is set to NM-DETECTION-LOCK.</p> <p><b>FrNmReadySleepCnt</b> is calculated by the formula <math>(\text{NM-READY-SLEEP-TIME} / \text{CYCLE}) / \text{NM-REPETITION-CYCLE} - 1</math>. NM-READY-SLEEP-TIME is taken from the first FLEXRAY-COMMUNICATION-CONNECTOR connecting the COMMUNICATION-CONTROLLER of the first FLEXRAY-NM-NODE to a PHYSICAL-CHANNEL of the FLEXRAY-NM-CLUSTER's FLEXRAY-COMMUNICATION-CLUSTER. A warning is reported if multiple different NM-READY-SLEEP-TIME values are found. If the calculation yields a non-integral value, a warning is reported and <b>FrNmReadySleepCnt</b> is not set.</p> <p>If NM-READY-SLEEP-TIME is not available, <b>FrNmReadySleepCnt</b> is set to NM-READY-SLEEP-COUNT.</p> <p><b>FrNmRemoteSleepIndTime</b> is set to NM-REMOTE-SLEEP-INDICATION-TIME.</p> <p><b>FrNmRepeatMessageTime</b> is set to NM-REPEAT-MESSAGE-TIME.</p>
FrNmChannelConfig/FrNmChannelIdentifiers/FrNmRxPdu	<p><b>For every NM-PDU referenced via RX-NM-PDU-REF by the first FLEXRAY-NM-NODE belonging to the FLEXRAY-NM-CLUSTER and the imported ECU-INSTANCE, a FrNmRxPdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the NM-PDU.</b></p> <p><b>If either none or more than two NM-PDU elements are referenced via RX-NM-PDU-REF a warning is reported.</b></p> <p><b>FrNmRxPduContainsData</b> is set to true if the NM-PDU contains I-SIGNAL-TO-I-PDU-MAPPING elements referencing an I-SIGNAL or an I-SIGNAL-GROUP, or if NM-DATA-INFORMATION is set to true. In all other cases <b>FrNmRxPduContainsData</b> is set to false.</p> <p><b>FrNmRxPduPduContainsVote</b> is set to NM-VOTE-INFORMATION.</p> <p><b>FrNmRxPduRef</b> references the corresponding container in the EcuC module configuration.</p>

Configuration parameters	Mapping description
FrNmChannelConfig/FrNmChannelIdentifiers/FrNmUserDataRxPdu	<p>The list of all NM-PDU elements that are referenced via RX-NM-PDU-REF by the first FLEXRAY-NM-NODE that belongs to the FLEXRAY-NM-CLUSTER and the imported ECU-INSTANCE constitutes the received NM-PDU elements of the FLEXRAY-NM-CLUSTER.</p> <p>The FrNmUserDataRxPdu container is created if an NmUserDataPdu container has been created in the EcuC module configuration for at least one of these NM-PDU elements, see <a href="#">Section 3.4.13, "EcuC"</a>.</p> <p>The name of FrNmUserDataRxPdu is set to &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;_NmComUserData, where &lt;name&gt; is the SHORT-NAME of the NM-PDU.</p> <p>FrNmRxUserDataPduRef references the NmUserDataPdu container in the EcuC module which has been created for the NM-PDU. If more than one NM-PDU contains I-SIGNAL-TO-I-PDU-MAPPING elements referencing an I-SIGNAL or an I-SIGNAL-GROUP, the first NM-PDU is used and a warning is reported.</p>
FrNmChannelConfig/FrNmChannelIdentifiers/FrNmTxPdu	<p>For every NM-PDU referenced via TX-NM-PDU-REF by the first FLEXRAY-NM-NODE belonging to the FLEXRAY-NM-CLUSTER and the imported ECU-INSTANCE, a FrNmTxPdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the NM-PDU.</p> <p>If more than two NM-PDU elements are referenced via TX-NM-PDU-REF a warning is reported.</p> <p>FrNmTxPduContainsData is set to true if the NM-PDU contains an I-SIGNAL-TO-I-PDU-MAPPING referencing an I-SIGNAL or an I-SIGNAL-GROUP, or if NM-DATA-INFORMATION is set to true. In all other cases FrNmTxPduContainsData is set to false.</p> <p>FrNmTxPduPduContainsVote is set to NM-VOTE-INFORMATION.</p> <p>FrNmTxPduRef references the corresponding container in the EcuC module configuration.</p>
FrNmChannelConfig/FrNmChannelIdentifiers/FrNmUserDataTxPdu	<p>See FrNmUserDataRxPdu (NM-PDU elements referenced via TX-NM-PDU-REF are used for FrNmUserDataTxPdu).</p>

For the configuration of PNC-related parameters see [Section 3.4.4, “CanNm”](#). The parameters and configuration containers obtain the prefix `FrNmPn`. The `PNC-FILTER-DATA-MASK` values of all `FLEXRAY-COMMUNICATION-CONNECTOR` elements that belong to the imported `ECU-INSTANCE` are taken as input for the calculation of `FrNmPnFilterMaskByte`.

### 3.4.24. FrSM

Configuration parameters	Mapping description
<code>FrSMConfig</code> / <code>FrSM-Cluster</code>	<p>For every <code>FLEXRAY-CLUSTER</code> which belongs to the imported <code>ECU-INSTANCE</code>, a <code>FrSMCluster</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>FLEXRAY-CLUSTER</code>.</p> <p><code>FrSMComMNetworkHandleRef</code> references the <code>ComMChannel</code> container in the <code>ComM</code> module configuration, which has been created for the <code>FLEXRAY-CLUSTER</code>.</p> <p><code>FrSMFrIfClusterRef</code> references the <code>FrIfCluster</code> container in the <code>FrIf</code> module configuration, which has been created for the <code>FLEXRAY-CLUSTER</code>.</p>

### 3.4.25. FrTp

Configuration parameters	Mapping description
<code>FrTpGeneral</code>	<p>The following parameters are set using the first <code>FLEXRAY-TP-ECU</code> belonging to the imported <code>ECU-INSTANCE</code>:</p> <p><code>FrTpMainFuncCycle</code> is set to <code>CYCLE-TIME-MAIN-FUNCTION</code>.</p> <p><code>FrTpFullDuplexEnable</code> is set to <code>FULL-DUPLEX-ENABLED</code>.</p> <p><code>FrTpTransmitCancellation</code> is set to <code>CANCELLATION</code>.</p> <p>If inconsistencies are detected among parameters of multiple <code>FLEXRAY-TP-ECU</code> elements of the imported <code>ECU-INSTANCE</code>, a warning is reported.</p>
<code>FrTpMultipleConfig</code> / <code>FrTpConnection</code>	<p>For each <code>FLEXRAY-TP-CONNECTION</code> which belongs to the imported <code>ECU-INSTANCE</code>, a <code>FrTpConnection</code> container is created, named <code>FrTpConnection_&lt;suffix&gt;</code>, where <code>&lt;suffix&gt;</code> is a zero-based index. A <code>FLEXRAY-TP-CONNECTION</code> belongs to the imported <code>ECU-INSTANCE</code> if at least one transmitting or receiving <code>FLEXRAY-TP-NODE</code> of this <code>FLEXRAY-TP-CONNECTION</code> refer-</p>



Configuration parameters	Mapping description
	<p>ences a <code>COMMUNICATION-CONNECTOR</code> which is also referenced by the imported <code>ECU-INSTANCE</code>.</p> <p><code>FrTpConCtrlRef</code> references the container created for the <code>FLEXRAY-TP-CONNECTION-CONTROL</code> referenced (see <code>FrTpMultipleConfig/FrTpConnectionControl</code>).</p> <p><code>FrTpRxPduPoolRef</code> references the container created for the <code>Rx N-PDU elements</code> referenced via <code>FLEXRAY-TP-PDU-POOL</code> elements (see <code>FrTpMultipleConfig/FrTpRxPduPool</code>).</p> <p><code>FrTpTxPduPoolRef</code> references the container created for the <code>Tx N-PDU elements</code> referenced via <code>FLEXRAY-TP-PDU-POOL</code> elements (see <code>FrTpMultipleConfig/FrTpTxPduPool</code>).</p> <p><code>FrTpRxSdu</code>: this container is created if the PDU referenced by the <code>FLEXRAY-TP-CONNECTION</code> via <code>DIRECT-TP-SDU-REF</code> is received or routed (see <a href="#">Section 3.3.5, "PDU routing"</a>) by the imported <code>ECU-INSTANCE</code>, or if this PDU is referenced via <code>REVERSED-TP-SDU-REF</code> and is sent or routed by the imported <code>ECU-INSTANCE</code>. The name of <code>FrTpRxSdu</code> is set to <code>&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the PDU.</p> <p><code>FrTpRxSdu/FrTpRxSduRef</code> references the corresponding container in the <code>EcuC</code> module configuration.</p> <p><code>FrTpTxSdu</code>: this container is created if the PDU referenced by the <code>FLEXRAY-TP-CONNECTION</code> via <code>DIRECT-TP-SDU-REF</code> is sent or routed (see <a href="#">Section 3.3.5, "PDU routing"</a>) by the imported <code>ECU-INSTANCE</code>, or if this PDU is referenced via <code>REVERSED-TP-SDU-REF</code> and is received or routed by the imported <code>ECU-INSTANCE</code>. The name of <code>FrTpTxSdu</code> is set to <code>&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the PDU.</p> <p><code>FrTpTxSdu/FrTpTxSduRef</code> references the corresponding container in the <code>EcuC</code> module configuration.</p> <p><code>FrTpBandwidthLimitation</code> is set to <code>BANDWIDTH-LIMITATION</code>.</p> <p><code>FrTpMultipleReceiverCon</code> is set to <code>true</code> if a valid <code>TP-ADDRESS</code> is referenced by the <code>FLEXRAY-TP-CONNECTION</code> via <code>MULTICAST-REF</code>. Otherwise <code>FrTpMultipleReceiverCon</code> is set to <code>false</code>.</p>

Configuration parameters	Mapping description
	<p><b>FrTpLa:</b> if the FLEXRAY-TP-NODE referenced via TRANSMITTER-REF belongs to the imported ECU-INSTANCE, FrTpLa is set to the TP-ADDRESS referenced by this FLEXRAY-TP-NODE. Otherwise FrTpLa is set to the TP-ADDRESS referenced by the FLEXRAY-TP-CONNECTION via MULTICAST-REF, or, if this is not available, to the TP-ADDRESS of the first FLEXRAY-TP-NODE referenced via RECEIVER-REF.</p> <p><b>FrTpRa:</b> if the FLEXRAY-TP-NODE referenced via TRANSMITTER-REF does not belong to the imported ECU-INSTANCE, FrTpRa is set to the TP-ADDRESS referenced by this FLEXRAY-TP-NODE. Otherwise FrTpRa is set to the TP-ADDRESS referenced by the FLEXRAY-TP-CONNECTION via MULTICAST-REF, or, if this is not available, to the TP-ADDRESS of the first FLEXRAY-TP-NODE referenced via RECEIVER-REF.</p>
FrTpMultipleConfig/FrTpConnectionControl	<p>For each FLEXRAY-TP-CONNECTION-CONTROL referenced by an imported FLEXRAY-TP-CONNECTION a FrTpConnectionControl container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-TP-CONNECTION-CONTROL.</p> <p>FrTpAckType is set depending on the value of ACK-TYPE:</p> <ul style="list-style-type: none"> <li>▶ FRTP_ACK_WITH_RT for ACK-WITH-RT.</li> <li>▶ FRTP_NO for NO-ACK.</li> </ul> <p>FrTpMaxAr is set to MAX-AR.</p> <p>FrTpMaxAs is set to MAX-AS.</p> <p>FrTpMaxBufferSize is set to MAX-BUFFER-SIZE.</p> <p>FrTpMaxFCWait is set to MAX-FC-WAIT.</p> <p>FrTpMaxFrIf is set to MAX-FR-IF.</p> <p>FrTpMaxRn is set to MAX-RETRIES.</p> <p>FrTpTimeBr is set to TIME-BR.</p> <p>FrTpTimeBuffer is set to TIME-BUFFER.</p> <p>FrTpTimeFrIf is set to TIME-FR-IF.</p> <p>FrTpTimeoutAr is set to TIMEOUT-AR.</p> <p>FrTpTimeoutAs is set to TIMEOUT-AS.</p>

Configuration parameters	Mapping description
	<p><b>FrTpTimeoutBs</b> is set to TIMEOUT-BS.</p> <p><b>FrTpTimeoutCr</b> is set to TIMEOUT-CR.</p> <p><b>FrTpSCexp</b> is set to SEPARATION-CYCLE-EXPONENT.</p> <p><b>FrTpMaxNbrOfNPduPerCycle</b> is set to MAX-NUMBER-OF-NPDU-PER-CYCLE.</p>
FrTpMultipleConfig/FrTpRxPduPool	<p><b>For each FLEXRAY-TP-PDU-POOL that is referenced by a sent FLEXRAY-TP-CONNECTION via RX-PDU-POOL-REF or that is referenced by a received FLEXRAY-TP-CONNECTION via TX-PDU-POOL-REF, and which contains only references to N-PDU elements received by the imported ECU-INSTANCE, an FrTpRxPduPool container is created. A FLEXRAY-TP-CONNECTION is considered sent/received if it belongs to the imported ECU-INSTANCE and if it references a PDU via DIRECT-TP-SDU-REF which is sent/received by this ECU-INSTANCE. The container name is &lt;name&gt;_Rx, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-TP-PDU-POOL.</b></p> <p><b>If a FLEXRAY-TP-PDU-POOL that is referenced by a sent FLEXRAY-TP-CONNECTION via RX-PDU-POOL-REF or that is referenced by a received FLEXRAY-TP-CONNECTION via TX-PDU-POOL-REF, contains any references to PDUs sent by the imported ECU-INSTANCE, the following algorithm is used to create FrTpRxPduPool containers:</b></p> <p><b>For each unique set of N-PDU elements received by the imported ECU-INSTANCE and referenced by FLEXRAY-TP-PDU-POOL elements of a FLEXRAY-TP-CONNECTION (referenced via both RX-PDU-POOL-REF and TX-PDU-POOL-REF), a FrTpRxPduPool container named PduPool_&lt;suffix&gt; is created, where &lt;suffix&gt; is a zero-based index.</b></p> <p><b>For all referenced N-PDU elements the parameter FrTpRxPduRef is set (using a reference to corresponding container in the EcuC module).</b></p>
FrTpMultipleConfig/FrTpTxPduPool	<p><b>For each FLEXRAY-TP-PDU-POOL that is referenced by a sent FLEXRAY-TP-CONNECTION via TX-PDU-POOL-REF or that is referenced by a received FLEXRAY-TP-CONNECTION via RX-PDU-POOL-REF, and which contains only references to N-PDU elements sent by the imported ECU-INSTANCE, an FrTpTxPduPool container is created. The container name is &lt;name&gt;_Tx, where &lt;name&gt; is the SHORT-NAME of the FLEXRAY-TP-PDU-POOL.</b></p> <p><b>If a FLEXRAY-TP-PDU-POOL that is referenced by a sent FLEXRAY-TP-CONNECTION via TX-PDU-POOL-REF or that is referenced by a received FLEXRAY-TP-CONNECTION via RX-PDU-POOL-REF, contains any references to PDUs re-</b></p>

Configuration parameters	Mapping description
	<p>ceived by the imported ECU-INSTANCE, the following algorithm is used to create FrTpRxPduPool containers:</p> <p>For each unique set of N-PDU elements sent by the imported ECU-INSTANCE and referenced by FLEXRAY-TP-PDU-POOL elements of a FLEXRAY-TP-CONNECTION (referenced via both RX-PDU-POOL-REF and TX-PDU-POOL-REF), a FrTpTxPduPool container named PduPool_&lt;suffix&gt; is created, where &lt;suffix&gt; is a zero-based index.</p> <p>For all referenced N-PDU elements the parameter FrTpTxPduRef is set (using a reference to corresponding container in the EcuC module).</p>

### 3.4.26. FrTSyn

Configuration parameters	Mapping description
FrTSynGlobalTimeDomain	<p>One FrTSynGlobalTimeDomain container is created for each GLOBAL-TIME-DOMAIN that contains a GLOBAL-TIME-FR-MASTER or a GLOBAL-TIME-FR-SLAVE element that references a FLEXRAY-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the GLOBAL-TIME-DOMAIN.</p> <p>FrTSynGlobalTimeDomainId is set to DOMAIN-ID.</p> <p>FrTSynSynchronizedTimeBaseRef references the corresponding StbMSynchronizedTimeBase container in the StbM module. If the GLOBAL-TIME-DOMAIN is a subdomain of a parent GLOBAL-TIME-DOMAIN, FrTSynSynchronizedTimeBaseRef references the StbMSynchronizedTimeBase container that has been created for the parent GLOBAL-TIME-DOMAIN. For further information about the configuration of the StbM module, see <a href="#">Section 3.4.39, "StbM"</a>.</p>
FrTSynGlobalTimeDomain/FrTSynGlobalTimeOfsDataIDList, FrTSynGlobalTimeDomain/FrTSynGlobalTimeSyncDataIDList	<p>The FR-GLOBAL-TIME-DOMAIN-PROPS element of the FlexRay GLOBAL-TIME-DOMAIN entity is used to retrieve the following subelements to configure container lists:</p> <ul style="list-style-type: none"> <li>▶ OFS-DATA-ID-LIST</li> <li>▶ SYNC-DATA-ID-LIST</li> </ul> <p>The configured container lists are the following:</p>

Configuration parameters	Mapping description									
	<div><div><div>▶ FrTSynGlobalTimeDomain/FrTSynGlobalTimeOfsDataIDList/FrTSynGlobalTimeOfsDataIDListElement</div><div>▶ FrTSynGlobalTimeDomain/FrTSynGlobalTimeSyncDataIDList/FrTSynGlobalTimeSyncDataIDListElement</div></div><div><p>In each container list, one subcontainer is created per element named Element_&lt;idx&gt;, where &lt;idx&gt; is the zero-based index of the element within the list. In each of these lists, one index parameter and one value parameter are configured. The index parameter represents the zero-based index of the element in the list. The value parameter represents the actual value.</p><table><tr><th>ID list</th><th>Index parameter</th><th>Value parameter</th></tr><tr><td>FrTSynGlobalTimeOfsDataIDList</td><td>FrTSynGlobalTimeOfsDataIDListIndex</td><td>FrTSynGlobalTimeOfsDataIDListValue</td></tr><tr><td>FrTSynGlobalTimeSyncDataIDList</td><td>FrTSynGlobalTimeSyncDataIDListIndex</td><td>FrTSynGlobalTimeSyncDataIDListValue</td></tr></table></div></div>	ID list	Index parameter	Value parameter	FrTSynGlobalTimeOfsDataIDList	FrTSynGlobalTimeOfsDataIDListIndex	FrTSynGlobalTimeOfsDataIDListValue	FrTSynGlobalTimeSyncDataIDList	FrTSynGlobalTimeSyncDataIDListIndex	FrTSynGlobalTimeSyncDataIDListValue
ID list	Index parameter	Value parameter								
FrTSynGlobalTimeOfsDataIDList	FrTSynGlobalTimeOfsDataIDListIndex	FrTSynGlobalTimeOfsDataIDListValue								
FrTSynGlobalTimeSyncDataIDList	FrTSynGlobalTimeSyncDataIDListIndex	FrTSynGlobalTimeSyncDataIDListValue								
FrTSynGlobalTimeDomain/FrTSynGlobalTimeMaster	<div><div><p>If the GLOBAL-TIME-FR-MASTER of the GLOBAL-TIME-DOMAIN references a FLEXRAY-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE, an FrTSynGlobalTimeMaster container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the GLOBAL-TIME-FR-MASTER.</p><p>FrTSynGlobalTimeTxCrcSecured is set depending on the value of GLOBAL-TIME-FR-MASTER/CRC-SECURED: CRC_SUPPORTED for CRC-SUPPORTED and CRC_NOT_SUPPORTED for CRC-NOT-SUPPORTED.</p><p>FrTSynGlobalTimeTxPeriod is set to GLOBAL-TIME-FR-MASTER/SYNC-PERIOD.</p><p>FrTSynCyclicMsgResumeTime is set to GLOBAL-TIME-FR-MASTER/IMMEDIATE-RESUME-TIME.</p><p>FrTSynGlobalTimeDebounceTime is set to GLOBAL-TIME-DOMAIN/DEBOUNCE-TIME.</p></div></div>									
FrTSynGlobalTimeDomain/FrTSynGlobalTimeMaster/FrTSynGlobalTimeMasterPdu	<div><p>A GLOBAL-TIME-DOMAIN is associated with a PDU if that PDU is a GENERAL-PURPOSE-PDU that has its CATEGORY set to GLOBAL_TIME and one of the conditions holds:</p></div>									

Configuration parameters	Mapping description
	<p>► The GLOBAL-TIME-DOMAIN references the PDU in GLOBAL-TIME-PDU-REF</p> <p>► The GLOBAL-TIME-DOMAIN references a PDU-TRIGGERING either via GLOBAL-TIME-PDU-TRIGGERING-REF or via PDU-TRIGGERING-REF, and that PDU-TRIGGERING refers to the PDU</p> <p>If the GLOBAL-TIME-DOMAIN is associated with a PDU, and if this is the PDU that the configured ECU-INSTANCE sends on the FLEXRAY-CLUSTER which the GLOBAL-TIME-DOMAIN references via COMMUNICATION-CLUSTER-REF, one FrTSynGlobalTimeMasterPdu container is created. Its name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>FrTSynGlobalTimePduRef references the EcuC container created for the PDU that is associated with the GLOBAL-TIME-DOMAIN.</p>
FrTSynGlobalTimeDomain/FrTSynGlobalTimeSlave	<p>If one of the GLOBAL-TIME-FR-SLAVE elements of the GLOBAL-TIME-DOMAIN references a FLEXRAY-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE, an FrTSynGlobalTimeSlave container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the GLOBAL-TIME-FR-SLAVE.</p> <p>FrTSynRxCrcValidated is set depending on the value of GLOBAL-TIME-FR-SLAVE/CRC-VALIDATED: CRC_VALIDATED for CRC-VALIDATED, CRC_NOT_VALIDATED for CRC-NOT-VALIDATED, and CRC_IGNORED for CRC-IGNORED.</p> <p>FrTSynGlobalTimeSequenceCounterJumpWidth is set to GLOBAL-TIME-FR-SLAVE/SEQUENCE-COUNTER-JUMP-WIDTH.</p>
FrTSynGlobalTimeDomain/FrTSynGlobalTimeSlave/FrTSynGlobalTimeSlavePdu	<p>If the GLOBAL-TIME-DOMAIN is associated with a PDU, and if this is the PDU that the configured ECU-INSTANCE receives on the FLEXRAY-CLUSTER which the GLOBAL-TIME-DOMAIN references via COMMUNICATION-CLUSTER-REF, one FrTSynGlobalTimeSlavePdu container is created. Its name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>FrTSynGlobalTimePduRef references the EcuC container created for the PDU that is associated with the GLOBAL-TIME-DOMAIN.</p>
FrTSynGeneral/FrTSynGlobalTimeSyncDataIDList	<p>For all FlexRay GLOBAL-TIME-DOMAIN entities the configured ECU-INSTANCE is connected to, all FR-GLOBAL-TIME-DOMAIN-PROPS are retrieved. From that FR-GLOBAL-TIME-DOMAIN-PROPS list, the first non-empty SYNC-DATA-ID-LIST is retrieved to configure the container list FrTSynGeneral/FrTSyn-</p>

Configuration parameters	Mapping description
	<p>GlobalTimeSyncDataIDList/FrTSynGlobalTimeSyncDataIDListElement.</p> <p>One subcontainer is created per element named <code>Element_&lt;idx&gt;</code>, where <code>&lt;idx&gt;</code> is the zero-based index of the element within the list. <code>FrTSynGlobalTimeSyncDataIDListIndex</code> contains the zero-based index of the element within the list, <code>FrTSynGlobalTimeSyncDataIDListValue</code> is configured to contain the value of the element.</p>

### 3.4.27. IpduM

Configuration parameters	Mapping description
IpduMGeneral/IpduMHeaderByteOrder	<p>If the imported ECU-INSTANCE sends or receives at least one CONTAINER-I-PDU, <code>IpduMHeaderByteOrder</code> is configured depending on the CONTAINER-I-PDU-HEADER-BYTE-ORDER parameter of the SYSTEM:</p> <ul style="list-style-type: none"> <li>▶ <code>IPDUM_LITTLE_ENDIAN</code> for MOST-SIGNIFICANT-BYTE-LAST</li> <li>▶ <code>IPDUM_BIG_ENDIAN</code> for MOST-SIGNIFICANT-BYTE-FIRST</li> </ul>
IpduMConfig/IpduMRxPathway	<p>For every MULTIPLEXED-I-PDU which references at least one PDU in its DYNAMIC-PART-ALTERNATIVE elements or in its STATIC-PART, and which is also received by the imported ECU-INSTANCE, an <code>IpduMRxPathway</code> container is created. The container name is <code>RXP_&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, where <code>&lt;name&gt;</code> is the SHORT-NAME of the MULTIPLEXED-I-PDU.</p>
IpduMConfig/IpduMRxPathway/IpduMRxIndication	<p>The name of <code>IpduMRxIndication</code> is set to <code>&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, where <code>&lt;name&gt;</code> is the SHORT-NAME of the MULTIPLEXED-I-PDU.</p> <p><code>IpduMRxIndicationPduRef</code> references the container created for the MULTIPLEXED-I-PDU in the <code>EcuC</code> module configuration.</p> <p><code>IpduMByteOrder</code> it set to <code>LITTLE_ENDIAN</code>.</p> <p>If <code>SELECTOR-FIELD-BYTE-ORDER</code> is set to MOST-SIGNIFICANT-BYTE-FIRST, the bit range defined by <code>SELECTOR-FIELD-START-POSITION</code> and <code>SELECTOR-FIELD-LENGTH</code> is converted to MOST-SIGNIFICANT-BYTE-LAST, which may result in multiple bit ranges. Multiple bit ranges in turn result in an error and the termination of the import. In case the bit range crosses byte boundaries, a warning is reported.</p>

Configuration parameters	Mapping description
	<p>IpduMSelectorFieldPosition/IpduMSelectorFieldPosition is set to the start position of the bit range.</p> <p>IpduMSelectorFieldPosition/IpduMSelectorFieldLength is set to the length of the bit range.</p>
IpduMConfig/IpduMRxPathway/IpduMRxIndication/IpduMRxDynamicPart	<p>For every DYNAMIC-PART-ALTERNATIVE of the MULTIPLEXED-I-PDU which references an I-SIGNAL-I-PDU that is routed (see <a href="#">Section 3.3.5, “PDU routing”</a>) or contains at least one I-SIGNAL received by the imported ECU-INSTANCE, an IpduMRxDynamicPart container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL-I-PDU.</p> <p>IpduMOutgoingDynamicPduRef references the container created for the I-SIGNAL-I-PDU in the EcuC module configuration.</p> <p>IpduMRxSelectorValue is set to SELECTOR-FIELD-CODE.</p>
IpduMConfig/IpduMRxPathway/IpduMRxIndication/IpduMRxDynamicPart/IpduMSegment	<p>For every bit range defined by SEGMENT-POSITION elements of the DYNAMIC-PART an IpduMSegment container is created. The container name is IpduMSegment_&lt;auto incremented number&gt;.</p> <p>If SEGMENT-BYTE-ORDER is set to MOST-SIGNIFICANT-BYTE-FIRST, the bit range defined by SEGMENT-POSITION and SEGMENT-LENGTH is converted to MOST-SIGNIFICANT-BYTE-LAST, which may result in multiple bit ranges.</p> <p>IpduMSegmentPosition and IpduMDestinationBit are set to the start position of the bit range.</p> <p>IpduMSegmentLength is set to the length of the bit range.</p>
IpduMConfig/IpduMRxPathway/IpduMRxIndication/IpduMRxStaticPart	<p>If a STATIC-PART of the MULTIPLEXED-I-PDU exists, which references an I-SIGNAL-I-PDU that is routed (see <a href="#">Section 3.3.5, “PDU routing”</a>) or contains at least one I-SIGNAL received by the imported ECU-INSTANCE, an IpduMRxStaticPart container is created. The name of IpduMRxStaticPart is set to &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL-I-PDU.</p> <p>IpduMOutgoingStaticPduRef references the container created for the I-SIGNAL-I-PDU in the EcuC module configuration.</p> <p>For the configuration of IpduMSegment refer to IpduMRxDynamicPart/IpduMSegment.</p>



Configuration parameters	Mapping description
IpduMConfig/IpduMTxPathway	For every MULTIPLEXED-I-PDU sent by the imported ECU-INSTANCE, an IpduMTxPathway container is created. The container name is TXP_<PREFIX><name><INSTSUFFIX>, where <name> is the SHORT-NAME of the MULTIPLEXED-I-PDU.
IpduMConfig/IpduMTxPathway/IpduMTxRequest	<p>The name of IpduMTxRequest is set to &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the MULTIPLEXED-I-PDU.</p> <p>IpduMOutgoingPduRef references the container created for the MULTIPLEXED-I-PDU in the EcuC module configuration.</p> <p>IpduMByteOrder is set to LITTLE_ENDIAN.</p> <p>For the configuration of IpduMSelectorFieldPosition see IpduMRxIndication/IpduMSelectorFieldPosition.</p> <p>IpduMIPduUnusedAreasDefault is set to UNUSED-BIT-PATTERN. If UNUSED-BIT-PATTERN is less than zero or greater than 255, a warning is reported and IpduMIPduUnusedAreasDefault remains undefined.</p> <p>IpduMTxTriggerMode is set depending on the value of TRIGGER-MODE:</p> <ul style="list-style-type: none"> <li>▶ STATIC_PART_TRIGGER for STATIC-PART-TRIGGER.</li> <li>▶ DYNAMIC_PART_TRIGGER for DYNAMIC-PART-TRIGGER.</li> <li>▶ STATIC_OR_DYNAMIC_PART_TRIGGER for STATIC-OR-DYNAMIC-PART-TRIGGER.</li> <li>▶ NONE for NONE.</li> </ul> <p>IpduMInitialDynamicPart references the IpduMTxDynamicPart container which has been created for the first DYNAMIC-PART-ALTERNATIVE which has its INITIAL-DYNAMIC-PART set to true.</p> <p>If multiple DYNAMIC-PART-ALTERNATIVE elements have its INITIAL-DYNAMIC-PART set to true, a warning is issued.</p>
IpduMConfig/IpduMTxPathway/IpduMTxRequest/IpduMTxDynamicPart	For every DYNAMIC-PART-ALTERNATIVE of the MULTIPLEXED-I-PDU which references an I-SIGNAL-I-PDU that is routed (see <a href="#">Section 3.3.5, "PDU routing"</a> ) or contains at least one I-SIGNAL sent by the imported ECU-INSTANCE, an IpduMTxDynamicPart container is created. The container name is <PREFIX><name><INSTSUFFIX>, where <name> is the SHORT-NAME of the I-SIGNAL-I-PDU.

Configuration parameters	Mapping description
	<p>IpduMTxDynamicPduRef references the container created for the I-SIGNAL-I-PDU in the EcuC module configuration.</p> <p>IpduMTxSelectorValue is set to SELECTOR-FIELD-CODE.</p> <p>IpduMSegment: see IpduMRxDynamicPart/IpduMSegment.</p>
IpduMConfig/IpduMTxPathway/IpduMTxRequest/IpduMTxStaticPart	<p>If a STATIC-PART of the MULTIPLEXED-I-PDU exists, which references an I-SIGNAL-I-PDU that is routed (see <a href="#">Section 3.3.5, “PDU routing”</a>) or contains at least one I-SIGNAL sent by the imported ECU-INSTANCE, an IpduMTxStaticPart container is created. The name of IpduMTxStaticPart is set to &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL-I-PDU.</p> <p>IpduMTxStaticPduRef references the container created for the I-SIGNAL-I-PDU in the EcuC module configuration.</p> <p>For the configuration of IpduMSegment see IpduMRxDynamicPart/IpduMSegment.</p>
IpduMConfig/IpduMContainerRxPdu	<p>For every CONTAINER-I-PDU which is received by the imported ECU-INSTANCE, an IpduMContainerRxPdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the CONTAINER-I-PDU.</p> <p>IpduMContainerHeaderSize is configured depending on HEADER-TYPE:</p> <ul style="list-style-type: none"> <li>▶ IPDUM_HEADERTYPE_SHORT for SHORT-HEADER</li> <li>▶ IPDUM_HEADERTYPE_LONG for LONG-HEADER</li> <li>▶ IPDUM_HEADERTYPE_NONE for NO-HEADER</li> </ul> <p>IpduMContainerRxAcceptContainedPdu is configured depending on RX-ACCEPT-CONTAINED-I-PDU:</p> <ul style="list-style-type: none"> <li>▶ IPDUM_ACCEPT_ALL for ACCEPT-ALL</li> <li>▶ IPDUM_ACCEPT_CONFIGURED for ACCEPT-CONFIGURED</li> </ul> <p>IpduMContainerRxPduRef references the container created for the CONTAINER-I-PDU in the EcuC module configuration.</p> <p>IpduMContainerQueueSize is set to CONTAINER-I-PDU/MINIMUM-RX-CONTAINER-QUEUE-SIZE if it exists and if it is greater than the pre-existing IpduMContainerQueueSize value.</p>

Configuration parameters	Mapping description
IpduMConfig/IpduMContainerTxPdu	<p>For every CONTAINER-I-PDU which is sent by the imported ECU-INSTANCE, an IpduMContainerTxPdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the CONTAINER-I-PDU.</p> <p>IpduMContainerHeaderSize is configured in the same way as in IpduMConfig/IpduMContainerRxPdu.</p> <p>IpduMContainerTxFirstContainedPduTrigger is configured depending on CONTAINER-TRIGGER:</p> <ul style="list-style-type: none"> <li>▶ true for FIRST-CONTAINED-TRIGGER</li> <li>▶ false for DEFAULT-TRIGGER</li> </ul> <p>IpduMContainerTxSendTimeout is set to CONTAINER-TIMEOUT.</p> <p>IpduMContainerTxSizeThreshold is set to THRESHOLD-SIZE.</p> <p>IpduMUnusedAreasDefault is set to UNUSED-BIT-PATTERN.</p> <p>IpduMContainerTxPduRef references the container created for the CONTAINER-I-PDU in the EcuC module configuration.</p> <p>IpduMContainerTxTriggerMode is set to IPDUM_DIRECT if the CONTAINER-I-PDU is contained in a SECURED-I-PDU. Otherwise, IpduMContainerTxTriggerMode is configured depending on the type of network that sends the CONTAINER-I-PDU:</p> <ul style="list-style-type: none"> <li>▶ IPDUM_DIRECT for Ethernet and CAN</li> <li>▶ IPDUM_TRIGGERTRANSMIT for FlexRay and LIN</li> </ul> <p>IpduMContainerQueueSize is set to CONTAINER-I-PDU/MINIMUM-TX-CONTAINER-QUEUE-SIZE or, as a fall-back, to CONTAINER-I-PDU/SDGS/SDG [@GID='IpduMContainerTxPduAttributes']/SD[@GID='IpduMContainerQueueSize'] if the value is greater than the pre-existing IpduMContainerQueueSize value.</p>
IpduMConfig/IpduMContainedRxPdu	<p>For every PDU that is configured to be received within a CONTAINER-I-PDU, an IpduMContainedRxPdu container is created. A PDU is configured to be received within a CONTAINER-I-PDU if it meets the following conditions:</p> <ul style="list-style-type: none"> <li>▶ The type of the PDU is a subclass of I-PDU.</li> <li>▶ The PDU contains a CONTAINED-I-PDU-PROPS subelement.</li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ The PDU is referenced by a PDU-TRIGGERING.</li> <li>▶ The imported ECU-INSTANCE owns an I-PDU-PORT that is referenced by the PDU-TRIGGERING and which has its COMMUNICATION-DIRECTION set to IN.</li> <li>▶ The PDU-TRIGGERING is referenced by at least one received CONTAINER-I-PDU.</li> </ul> <p>The name of the IpduMContainedRxDpu is set to &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the contained PDU.</p> <p>IpduMContainedPduHeaderId is configured with either CONTAINED-I-PDU-PROPS/HEADER-ID-LONG-HEADER or CONTAINED-I-PDU-PROPS/HEADER-ID-SHORT-HEADER or not configured at all, depending on the HEADER-TYPE value of the CONTAINER-I-PDU:</p> <ul style="list-style-type: none"> <li>▶ CONTAINED-I-PDU-PROPS/HEADER-ID-LONG-HEADER is taken if HEADER-TYPE is set to LONG-HEADER.</li> <li>▶ CONTAINED-I-PDU-PROPS/HEADER-ID-SHORT-HEADER is taken if HEADER-TYPE is set to SHORT-HEADER.</li> </ul> <p>IpduMContainedPduHeaderId is not configured, if HEADER-TYPE is set to NO-HEADER.</p> <p>If the PDU is not associated with a CONTAINER-I-PDU or the associated CONTAINER-I-PDU does not provide a HEADER-TYPE, CONTAINED-I-PDU-PROPS/HEADER-ID-LONG-HEADER is taken. If the contained PDU does not provide CONTAINED-I-PDU-PROPS/HEADER-ID-LONG-HEADER, CONTAINED-I-PDU-PROPS/HEADER-ID-SHORT-HEADER is taken instead.</p> <p>IpduMContainedRxInContainerPduRef references the container created for the associated CONTAINER-I-PDU. The reference is configured if RX-ACCEPT-CONTAINED-I-PDU of the CONTAINER-I-PDU is set to a value other than ACCEPT-ALL or not set at all.</p> <p>IpduMContainedRxDpuRef references the container created for the PDU in the EcuC module configuration.</p> <p>IpduMContainedPduOffset is set to CONTAINED-I-PDU-PROPS/OFFSET if the HEADER-TYPE is set to NO-HEADER.</p>

Configuration parameters	Mapping description
	<p><code>IpduMPduUpdateBitPosition</code> is set to <code>CONTAINED-I-PDU-PROPS/UPDATE-INDICATION-BIT-POSITION</code> if the <code>HEADER-TYPE</code> is set to <code>NO-HEADER</code>.</p>
<p><code>IpduMConfig/IpduMContainedTxPdu</code></p>	<p>For every PDU that is sent within a <code>CONTAINER-I-PDU</code>, an <code>IpduMContainedTxPdu</code> container is created. A PDU is sent within a <code>CONTAINER-I-PDU</code> if it meets the conditions as follows:</p> <ul style="list-style-type: none"> <li>▶ The type of the PDU is a subclass of <code>I-PDU</code>.</li> <li>▶ The PDU contains a <code>CONTAINED-I-PDU-PROPS</code> subelement.</li> <li>▶ The PDU is referenced by a <code>PDU-TRIGGERING</code>.</li> <li>▶ The imported <code>ECU-INSTANCE</code> owns an <code>I-PDU-PORT</code> that is referenced by the <code>PDU-TRIGGERING</code> and which has its <code>COMMUNICATION-DIRECTION</code> set to <code>OUT</code>.</li> <li>▶ The <code>PDU-TRIGGERING</code> is referenced from the <code>CONTAINER-I-PDU</code>.</li> </ul> <p>The name of the <code>IpduMContainedTxPdu</code> is set to <code>&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the contained PDU.</p> <p><code>IpduMContainedPduHeaderId</code> is configured in the same way as the corresponding parameter in <code>IpduMConfig/IpduMContainedRxPdu</code>.</p> <p><code>IpduMContainedTxPduCollectionSemantics</code> is configured depending on <code>CONTAINED-I-PDU-PROPS/COLLECTION-SEMANTICS</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>IPDUM_COLLECT_LAST_IS_BEST</code> for <code>LAST-IS-BEST</code></li> <li>▶ <code>IPDUM_COLLECT_QUEUED</code> for <code>QUEUED</code></li> </ul> <p><code>IpduMContainedTxPduSendTimeout</code> is set to <code>CONTAINED-I-PDU-PROPS/TIMEOUT</code>.</p> <p><code>IpduMContainedTxPduTrigger</code> is configured depending on <code>CONTAINED-I-PDU-PROPS/TRIGGER</code>:</p> <ul style="list-style-type: none"> <li>▶ <code>IPDUM_TRIGGER_ALWAYS</code> for <code>ALWAYS</code></li> <li>▶ <code>IPDUM_TRIGGER_NEVER</code> for <code>NEVER</code></li> </ul> <p><code>IpduMContainedTxInContainerPduRef</code> references the container created for the associated <code>CONTAINER-I-PDU</code>.</p>

Configuration parameters	Mapping description
	<p><b>IpduMContainedTxPduRef</b> is configured in the same way as <b>IpduMContainedRxPduRef</b> in <b>IpduMConfig/IpduMContainedRxPdu</b>.</p> <p><b>IpduMContainedPduOffset</b> is configured in the same way as the corresponding parameter in <b>IpduMConfig/IpduMContainedRxPdu</b>.</p> <p><b>IpduMPduUpdateBitPosition</b> is configured in the same way as the corresponding parameter in <b>IpduMConfig/IpduMContainedRxPdu</b>.</p> <p><b>IpduMContainedTxPduPriority</b> is set to <b>CONTAINED-I-PDU-PROPS/PRIORITY</b>.</p>

### 3.4.28. LdCom

Configuration parameters	Mapping description
LdComIPdu	<p>For every PDU instance (see <a href="#">Section 3.3.1.3, “Instance handling”</a>) that represents an <b>I-SIGNAL-I-PDU</b>, which is sent or received by the imported <b>ECU-INSTANCE</b> and for which the following conditions apply, an <b>LdComIPdu</b> container is created.</p> <ul style="list-style-type: none"> <li>▶ The PDU instance contains exactly one <b>I-SIGNAL-TO-I-PDU-MAPPING</b> referencing an <b>I-SIGNAL</b>.</li> <li>▶ <b>ComSignalType</b> of the <b>I-SIGNAL</b> is <b>UINT8_N</b> or <b>UINT8_DYN</b>.</li> <li>▶ <b>PACKING-BYTE-ORDER</b> of the <b>I-SIGNAL-TO-I-PDU-MAPPING</b> is set to <b>OPAQUE</b>.</li> <li>▶ <b>START-POSITION</b> of the <b>I-SIGNAL-TO-I-PDU-MAPPING</b> is set to 0.</li> <li>▶ <b>UPDATE-INDICATION-BIT-POSITION</b> of the <b>I-SIGNAL-TO-I-PDU-MAPPING</b> is not set.</li> <li>▶ The <b>I-SIGNAL-PORT</b> referenced by the <b>I-SIGNAL's I-SIGNAL-TRIGGERING</b> has no <b>TIMEOUT</b> defined.</li> <li>▶ The <b>I-SIGNAL-PORT</b> referenced by the <b>I-SIGNAL's I-SIGNAL-TRIGGERING</b> has no <b>FIRST-TIMEOUT</b> defined.</li> <li>▶ The <b>I-SIGNAL-PORT</b> referenced by the <b>I-SIGNAL's I-SIGNAL-TRIGGERING</b> either has no <b>DATA-FILTER</b> defined or has <b>DATA-FILTER/DA-TA-FILTER-TYPE</b> set to <b>ALWAYS</b>.</li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ There is no I-SIGNAL-I-PDU-GROUP which references the I-SIGNAL-I-PDU.</li> <li>▶ There is no I-SIGNAL-MAPPING which references the I-SIGNAL's I-SIGNAL-TRIGGERING.</li> </ul> <p>The following conditions only apply for I-SIGNAL-I-PDUS, whose LdComIPduDirection is set to LDCOM_SEND.</p> <ul style="list-style-type: none"> <li>▶ I-PDU-TIMING-SPECIFICATIONS/I-PDU-TIMING/TRANSMISSION-MODE-DECLARATION is defined.</li> <li>▶ TRANSFER-PROPERTY of the I-SIGNAL-TO-I-PDU-MAPPING is set to TRIGGERED or TRIGGERED-WITHOUT-REPETITION.</li> <li>▶ MINIMUM-DELAY of the I-PDU-TIMING is not set if the LdComIPduDirection is set to LDCOM_SEND.</li> <li>▶ The I-PDU-TIMING has a TRANSMISSION-MODE-TRUE-TIMING but no TRANSMISSION-MODE-FALSE-TIMING defined.</li> <li>▶ The TRANSMISSION-MODE-DECLARATION either has no TRANSMISSION-MODE-CONDITIONS defined or one single TRANSMISSION-MODE-CONDITION which references the I-SIGNAL-TO-I-PDU-MAPPING and which has its DATA-FILTER/DATA-FILTER-TYPE set to ALWAYS.</li> <li>▶ The TRANSMISSION-MODE-DECLARATION has no MODE-DRIVEN-FALSE-CONDITIONS and no MODE-DRIVEN-TRUE-CONDITIONS defined.</li> <li>▶ The TRANSMISSION-MODE-TRUE-TIMING has only an EVENT-CONTROLLED-TIMING defined and its NUMBER-OF-REPETITIONS must be set to 0.</li> </ul> <p>The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the I-SIGNAL-I-PDU.</p> <p>LdComPduRef references the corresponding container in the EcuC module configuration.</p> <p>LdComSystemTemplateSignalRef is set to the AUTOSAR path of the I-SIGNAL-TO-I-PDU-MAPPING.</p> <p>LdComApiType is configured in the same way as ComIPduType in <a href="#">Section 3.4.8, "Com"</a>, with the exception that LDCOM_TP and LDCOM_IF are used as configured parameter values instead of TP and NORMAL.</p>

Configuration parameters	Mapping description
	<code>LdComIPduDirection</code> is set to <code>LDCOM_SEND</code> if the PDU instance is sent by the imported ECU-INSTANCE. Otherwise it is set to <code>LDCOM_RECEIVE</code> .

### 3.4.29. Lin

Configuration parameters	Mapping description
<code>LinChannel</code>	<p>For every LIN-CLUSTER which belongs to the imported ECU-INSTANCE, a <code>LinChannel</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the SHORT-NAME of the LIN-CLUSTER's PHYSICAL-CHANNEL. A LIN-CLUSTER belongs to the imported ECU-INSTANCE if a LIN-MASTER connects the LIN-CLUSTER to the imported ECU-INSTANCE via its COMMUNICATION-CONNECTOR.</p> <p>If a LIN-CLUSTER is not connected to the imported ECU-INSTANCE by a LIN-MASTER, a warning is reported and no <code>LinChannel</code> container is created for this LIN-CLUSTER.</p> <p>If the LIN-CLUSTER comprises more than one PHYSICAL-CHANNEL, an error is reported.</p> <p><code>LinChannelBaudRate</code> is set to <code>BAUDRATE</code>. If <code>BAUDRATE</code> is not available, <code>LinChannelBaudRate</code> is set to <code>SPEED * 1000</code>.</p>

### 3.4.30. LinIf

Configuration parameters	Mapping description
<code>LinIfChannel</code>	<p>For every LIN-CLUSTER which belongs to the imported ECU-INSTANCE, a <code>LinIfChannel</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the SHORT-NAME of the LIN-CLUSTER's PHYSICAL-CHANNEL. A LIN-CLUSTER belongs to the imported ECU-INSTANCE if a LIN-MASTER connects the LIN-CLUSTER to the imported ECU-INSTANCE via its COMMUNICATION-CONNECTOR.</p> <p>If a LIN-CLUSTER is not connected to the imported ECU-INSTANCE by a LIN-MASTER, a warning is reported and no <code>LinIfChannel</code> container is created for this LIN-CLUSTER.</p>



Configuration parameters	Mapping description
	<p>If the LIN-CLUSTER comprises more than one PHYSICAL-CHANNEL, an error is reported.</p> <p>If the single PHYSICAL-CHANNEL is not a LIN-PHYSICAL-CHANNEL, an error is reported.</p> <p>LinIfChannelRef references the corresponding container in the Lin module configuration.</p> <p>LinIfComMNetworkHandleRef references the corresponding container in the ComM module configuration.</p>
LinIfChannel/LinIf-Master	<p>The following parameters are set using the LIN-MASTER connecting the imported ECU-INSTANCE to the LIN-CLUSTER:</p> <p>LinIfClusterTimeBase is set to TIME-BASE.</p> <p>LinIfJitter is set to TIME-BASE-JITTER.</p>
LinIfChannel/LinIfSlave	<p>If the LIN-MASTER of a given LIN-CLUSTER contains one or more LIN-SLAVE-CONFIG elements, these are used to configure the LinIfSlave configuration containers. If the LIN-MASTER does not contain any LIN-SLAVE-CONFIG, all LIN-SLAVE elements that are connected to the LIN-CLUSTER are used to configure the LinIfSlave configuration containers.</p> <p>For every LIN-SLAVE-CONFIG or LIN-SLAVE element one LinIfSlave container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of either LIN-SLAVE-CONFIG/IDENT or LIN-SLAVE.</p> <p>LinIfProtocolVersion is set to PROTOCOL-VERSION.</p> <p>LinIfConfiguredNad is set to CONFIGURED-NAD.</p> <p>LinIfFunctionId is set to FUNCTION-ID.</p> <p>LinIfSupplierId is set to SUPPLIER-ID.</p> <p>LinIfVariant is set to VARIANT-ID.</p>
LinIfChannel/LinIf-Frame	<p>In the following, APPLICATION-ENTRY elements referencing FRAME-TRIGGERING elements are referred to as ApplicationFrame elements; all other types of ENTRY elements do not reference FRAME-TRIGGERING elements and are referred to as ConfigurationFrame elements. SlaveToSlaveFrame elements are a special kind of ApplicationFrame elements which are neither sent nor received by the LIN-MASTER.</p>

Configuration parameters	Mapping description
	<p>For every kind of frame, a <code>LinIfFrame</code> container is created. The container name for <code>ApplicationFrame</code> elements is <code>&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, for <code>SlaveToSlaveFrame</code> elements it is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>FRAME</code> referenced by the <code>LIN-FRAME-TRIGGERING</code>. The container name for <code>ConfigurationFrame</code> elements is <code>&lt;PREFIX&gt;&lt;name&gt;&lt;auto incremented number&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the parent <code>LIN-SCHEDULE-TABLE</code>.</p> <p><code>LinIfPid</code> is set to the protected identifier of the <code>LIN-FRAME-TRIGGERING</code>. For details on how to calculate the protected identifier refer to [2]. If the <code>LinIfFrame</code> has been created for a <code>ConfigurationFrame</code>, <code>LinIfPid</code> is set to 60, which is the ID of the <code>MasterRequestFrame</code> (MRF). If the <code>LIN-FRAME-TRIGGERING</code> references a <code>LIN-SPORADIC-FRAME</code>, <code>LinIfPid</code> is not configured.</p> <p><code>LinIfLength</code> is set to <code>FRAME-LENGTH</code> of the <code>LIN-UNCONDITIONAL-FRAME</code> referenced by the <code>LIN-FRAME-TRIGGERING</code>. If the <code>LIN-FRAME-TRIGGERING</code> references a <code>LIN-SPORADIC-FRAME</code> or <code>LIN-EVENT-TRIGGERED-FRAME</code>, the <code>FRAME-LENGTH</code> of the first <code>LIN-UNCONDITIONAL-FRAME</code> referenced by the <code>LIN-SPORADIC-FRAME</code> or <code>LIN-EVENT-TRIGGERED-FRAME</code> is used. For <code>ConfigurationFrame</code> elements <code>LinIfLength</code> is always set to 8.</p> <p><code>LinIfFrameType</code> is set depending on the <code>IDENTIFIER</code> of the <code>LIN-FRAME-TRIGGERING</code>:</p> <ul style="list-style-type: none"> <li>▶ MRF for 60</li> <li>▶ SRF for 61</li> </ul> <p>For other values of <code>IDENTIFIER</code> <code>LinIfFrameType</code> is set depending on the type of the referenced <code>FRAME</code>:</p> <ul style="list-style-type: none"> <li>▶ UNCONDITIONAL for <code>LIN-UNCONDITIONAL-FRAME</code> elements</li> <li>▶ SPORADIC for <code>LIN-SPORADIC-FRAME</code> elements</li> <li>▶ EVENT_TRIGGERED for <code>LIN-EVENT-TRIGGERED-FRAME</code> elements</li> </ul> <p>For <code>ConfigurationFrame</code> elements <code>LinIfFrameType</code> is set depending on the type of the <code>TABLE-ENTRY</code>:</p> <ul style="list-style-type: none"> <li>▶ FREE for <code>FREE-FORMAT-ENTRY</code> and <code>DATA-DUMP-ENTRY</code></li> <li>▶ SAVE_CONFIGURATION for <code>SAVE-CONFIGURATION-ENTRY</code></li> <li>▶ ASSIGN_NAD for <code>ASSIGN-NAD</code></li> <li>▶ ASSIGN for <code>ASSIGN-FRAME-ID</code></li> </ul>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ UNASSIGN for UNASSIGN-FRAME-ID</li> <li>▶ ASSIGN_FRAME_ID_RANGE for ASSIGN-FRAME-ID-RANGE</li> <li>▶ CONDITIONAL for CONDITIONAL-CHANGE-NAD</li> </ul> <p>For ConfigurationFrame elements LinIfChecksumType is set to CLASSIC. For LIN-FRAME-TRIGGERING elements referencing a LIN-UNCONDITIONAL-FRAME, LinIfChecksumType is set to LIN-CHECKSUM.</p> <p>For LIN-SPORADIC-FRAME elements and LIN-EVENT-TRIGGERED-FRAME elements LIN-CHECKSUM is taken from the LIN-FRAME-TRIGGERING elements referencing the substituted LIN-UNCONDITIONAL-FRAME elements. If inconsistencies are detected among the LIN-CHECKSUM values of these LIN-FRAME-TRIGGERING elements, a warning is reported.</p>
LinIfChannel/LinIf-FixedFrame/LinIfFixed-FramesduByte	<p>For ConfigurationFrame elements the byte array used to configure LinIf-FixedFramesduByte is calculated depending on the type of the TABLE-ENTRY. In the following, array elements are listed starting from byte zero, and the parameters CONFIGURED-NAD, SUPPLIER-ID, and FUNCTION-ID are either taken from the LIN-SLAVE-CONFIG referenced via ASSIGNED-LIN-SLAVE-CONFIG-REF or, if this reference does not exist, from the LIN-SLAVE referenced via ASSIGNED-CONTROLLER-REF.</p> <ul style="list-style-type: none"> <li>▶ FREE-FORMAT: the byte array is taken directly from BYTE-VALUES.</li> <li>▶ ASSIGN-NAD: INITIAL-NAD of LIN-COMMUNICATION-CONNECTOR or INITIAL-NAD of LIN-SLAVE-CONFIG, 0x06, 0xb0, LSB of SUPPLIER-ID, MSB of SUPPLIER-ID, LSB of MESSAGE-ID, MSB of MESSAGE-ID, NEW-NAD .</li> <li>▶ SAVE-CONFIGURATION-ENTRY: CONFIGURED-NAD, 0x01, 0xb6, 0xff, 0xff, 0xff, 0xff .</li> <li>▶ ASSIGN-FRAME-ID/UNASSIGN-FRAME-ID : CONFIGURED-NAD, 0x06, 0xb1, LSB of SUPPLIER-ID, MSB of SUPPLIER-ID, LSB of MESSAGE-ID, MSB of MESSAGE-ID, protected identifier of LIN-FRAME-TRIGGERING.</li> </ul> <p>The LIN-FRAME-TRIGGERING is referenced by ASSIGN-FRAME-ID/UNASSIGN-FRAME-ID via ASSIGNED-FRAME-TRIGGERING-REF/UNASSIGNED-FRAME-TRIGGERING-REF.</p> <p>If the ASSIGN-FRAME-ID/UNASSIGN-FRAME-ID entity references a LIN-SLAVE-CONFIG entity, the MESSAGE-ID is directly taken from ASSIGN-FRAME-ID/MESSAGE-ID, respectively from UNASSIGN-FRAME-ID/MESSAGE-ID.</p>

Configuration parameters	Mapping description
	<p>If the <code>ASSIGN-FRAME-ID/UNASSIGN-FRAME-ID</code> entity references a <code>LIN-SLAVE</code> entity, the <code>MESSAGE-ID</code> is taken from the <code>LIN-CONFIGURABLE-FRAME</code> referencing the same <code>LIN-FRAME</code> as the <code>LIN-FRAME-TRIGGERING</code>.</p> <p>► <code>ASSIGN-FRAME-ID-RANGE: CONFIGURED-NAD, 0x06, 0xb7, START-INDEX, FRAME-PID[INDEX = 0]/PID, FRAME-PID[INDEX = 1]/PID, FRAME-PID[INDEX = 2]/PID, FRAME-PID[INDEX = 3]/PID.</code></p> <p>If <code>ASSIGN-FRAME-ID-RANGE</code> does not contain any <code>FRAME-PID</code> elements and the <code>ASSIGN-FRAME-ID-RANGE</code> refers to a <code>LIN-SLAVE</code> entity, the <code>PID</code> values are either retrieved from the <code>LIN-ORDERED-CONFIGURABLE-FRAMES</code> or, if these are not available, from the <code>LIN-CONFIGURABLE-FRAMES</code> of the <code>LIN-SLAVE</code> that is referenced via <code>ASSIGNED-CONTROLLER-REF</code>. The <code>LIN-ORDERED-CONFIGURABLE-FRAMES</code> and <code>LIN-CONFIGURABLE-FRAMES</code> of a slave are contained in the <code>LIN-COMMUNICATION-CONNECTOR</code> belonging to the <code>LIN-SLAVE</code>.</p> <p>The index of a <code>CONFIGURABLE-FRAME</code> element in <code>LIN-ORDERED-CONFIGURABLE-FRAMES</code> is determined by the <code>INDEX</code> parameter of the element. The index of a <code>CONFIGURABLE-FRAME</code> element in <code>LIN-CONFIGURABLE-FRAMES</code> is determined by its position, starting with zero as the index of the first element.</p> <p>Each of the <code>CONFIGURABLE-FRAME</code> elements in the list owns an <code>IDENTIFIER</code>, which is stored in the <code>FRAME-TRIGGERING</code> referencing the same <code>FRAME</code> that is referenced by the <code>CONFIGURABLE-FRAME</code>. The <code>PID</code> of a <code>CONFIGURABLE-FRAME</code> is its <code>IDENTIFIER</code> plus two parity bits. For details on the parity bits refer to <a href="#">[2]</a>.</p> <p>The bytes <code>[4 .. 7]</code> are filled with the <code>PID</code> of the <code>CONFIGURABLE-FRAME</code> at index <code>[START-INDEX .. START-INDEX + 3]</code>.</p> <p>If no valid <code>FRAME-PID</code> or <code>CONFIGURABLE-FRAME</code> is found at a given <code>INDEX</code>, <code>0xff</code> is configured.</p> <p>► <code>CONDITIONAL-CHANGE-NAD: CONFIGURED-NAD, 0x06, 0xb3, ID, BYTE, MASK, INVERT, NEW-NAD.</code></p> <p>► <code>DATA-DUMP-ENTRY: CONFIGURED-NAD, 0x06, 0xb4, BYTE-VALUES/BYTE-VALUE[0], BYTE-VALUES/BYTE-VALUE[1], BYTE-VALUES/BYTE-VALUE[2], BYTE-VALUES/BYTE-VALUE[3], BYTE-VALUES/BYTE-VALUE[4].</code></p>

Configuration parameters	Mapping description
	<p>If the number of <code>BYTE-VALUE</code> elements is not exactly five, an error is reported.</p> <p>If any of the values required to fill the byte array cannot be retrieved, an error is reported.</p> <p>For each byte of the array, a <code>LinIfFixedFrameSduByte</code> is created. The container name is <code>LinIfFixedFrameSduByte_&lt;byte position within array&gt;</code>.</p> <p><code>LinIfFixedFrameSduBytePos</code> is set to the byte position within the array.</p> <p><code>LinIfFixedFrameSduByteVal</code> is set to <code>&lt;byte value&gt;</code>, where only the eight least significant bits are considered.</p>
<code>LinIfChannel/LinIfFrame/LinIfPduDirection</code>	<p>For <code>LIN-FRAME-TRIGGERING</code> elements referencing a <code>LIN-SPORADIC-FRAME</code> and which have their <code>IDENTIFIER</code> set to values other than 60 or 61, the choice container is set to <code>LinIfRxPdu</code> (received by <code>LIN-MASTER</code>) or <code>LinIfTxPdu</code> (sent by <code>LIN-MASTER</code>). The name of <code>LinIfRxPdu/LinIfTxPdu</code> is set to <code>&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the PDU belonging to the PDU instance (see <a href="#">Section 3.3.1.3, “Instance handling”</a>) of the <code>LIN-FRAME-TRIGGERING</code>.</p> <p><code>LinIfRxPduRef/LinIfTxPduRef</code> references the container in the <code>EcuC</code> module configuration, which has been created for the PDU instance of the <code>LIN-FRAME-TRIGGERING</code>. If the number of PDU instances for the <code>LIN-FRAME-TRIGGERING</code> is not exactly one, no properties are exported for <code>LinIfRxPdu/LinIfTxPdu</code> and a warning is reported.</p> <p><code>LinIfUserRxIndicationUL/LinIfUserTxUL</code> is set to <code>PDUR</code> for <code>I-SIGNAL-PDU</code> elements, <code>MULTIPLEXED-I-PDU</code> elements, <code>CONTAINER-I-PDU</code> elements, <code>GENERAL-PURPOSE-I-PDU</code> elements, <code>DCM-I-PDU</code> elements, and for <code>USER-DEFINED-I-PDU</code> elements, which either have a <code>CATEGORY</code> other than <code>XCP</code> or are routed (see <a href="#">Section 3.3.5, “PDU routing”</a>), or to <code>CDD</code> for received or sent <code>USER-DEFINED-I-PDU</code> elements that have their <code>CATEGORY</code> set to <code>XCP</code> and for all other PDU types.</p> <p>For <code>LIN-FRAME-TRIGGERING</code> elements not sent/received by the <code>LIN-MASTER</code>, but referenced by a <code>TABLE-ENTRY</code>, the <code>LinIfPduDirection</code> choice container is set to <code>LinIfSlaveToSlavePdu</code>. For all other <code>TABLE-ENTRY</code> types, the choice container is set to <code>LinIfInternalPdu</code>.</p>

Configuration parameters	Mapping description
LinIfChannel/LinIfFrame/LinIfSubstitutionFrame	<p>For every LIN-UNCONDITIONAL-FRAME referenced by a LIN-SPO-RADIC-FRAME via SUBSTITUTED-FRAME-REF, or by a LIN-EVENT-TRIGGERED-FRAME via LIN-UNCONDITIONAL-FRAME-REF, a LinIfSubstitutionFrame container is created. The container name is the same as the LinIfFrame created for the referenced LIN-UNCONDITIONAL-FRAME.</p> <p>LinIfSubstitutionFrameRef references the container created for the referenced LIN-UNCONDITIONAL-FRAME.</p> <p>LinIfFramePriority is set to the position of the referring element (SUBSTITUTED-FRAME-REF/LIN-UNCONDITIONAL-FRAME-REF) within its parent element.</p>
LinIfChannel/LinIfScheduleTable	<p>For each LIN-SCHEDULE-TABLE a LinIfScheduleTable container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the LIN-SCHEDULE-TABLE.</p> <p>LinIfScheduleTableName is set to SHORT-NAME.</p> <p>LinIfRunMode is set depending on RUN-MODE:</p> <ul style="list-style-type: none"> <li>▶ RUN_CONTINUOUS for RUN-CONTINUOUS</li> <li>▶ RUN_ONCE for RUN-ONCE</li> </ul> <p>LinIfResumePosition is set depending on RESUME-POSITION:</p> <ul style="list-style-type: none"> <li>▶ CONTINUE_AT_IT_POINT for CONTINUE-AT-IT-POSITION</li> <li>▶ START_FROM_BEGINNING for START-FROM-BEGINNING</li> </ul>
LinIfChannel/LinIfScheduleTable/LinIfEntry	<p>For each TABLE-ENTRY a LinIfEntry container is created. The container name is Entry&lt;auto incremented number&gt;.</p> <p>LinIfDelay is set to DELAY.</p> <p>LinIfEntryIndex is set to POSITION-IN-TABLE.</p> <p>LinIfFrameRef references the corresponding LinIfFrame container.</p> <p>LinIfCollisionResolvingRef is only set for TABLE-ENTRY elements which reference a LIN-FRAME-TRIGGERING referencing a LIN-EVENT-TRIGGERED-FRAME. It references the LinIfScheduleTable created for the LIN-SCHEDULE-TABLE referenced via COLLISION-RESOLVING-SCHEDULE-REF.</p>

### 3.4.31. LinSM

Configuration parameters	Mapping description
LinSMCon- figSet/LinSMChannel	<p>For every LIN-CLUSTER which belongs to the imported ECU-INSTANCE, a LinSMChannel container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the LIN-CLUSTER.</p> <p>LinSMComMNetworkHandleRef references the ComMChannel container in the ComM module configuration, which has been created for the LIN-CLUSTER.</p>
LinSMCon- figSet/LinSMChan- nel/LinSMSchedule	<p>For every LIN-SCHEDULE-TABLE of the LIN-CLUSTER's first LIN-PHYSICAL-CHANNEL, a LinSMSchedule container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the LIN-SCHEDULE-TABLE.</p> <p>LinSMScheduleIndexRef references the LinIfScheduleTable container in the LinIf module configuration, which has been created for the LIN-SCHEDULE-TABLE.</p>

### 3.4.32. LinTp

Configuration parameters	Mapping description
LinTpGlobalConfig	<p>The following parameters are set using the first LIN-TP-NODE which belongs to the imported ECU-INSTANCE. A LIN-TP-NODE belongs to the ECU-INSTANCE if at least one of the COMMUNICATION-CONNECTOR elements it references also belongs to this ECU-INSTANCE.</p> <p>LinTpP2Timing is set to P-2-TIMING.</p> <p>LinTpP2Max is set to P-2-MAX.</p> <p>LinTpMaxNumberOfRespPendingFrames is set to MAX-NUMBER-OF-RESPENDING-FRAMES.</p> <p>If inconsistencies among multiple LIN-TP-NODE elements are detected, a warning is reported.</p>
LinTpGlobalCon- fig/LinTpRxNSdu	<p>For every PDU which is referenced by a LIN-TP-CONNECTION which belongs to the imported ECU-INSTANCE, and which is also received or routed by the ECU-INSTANCE, a LinTpRxNSdu container is created. For more information, see</p>

Configuration parameters	Mapping description
	<p><a href="#">Section 3.3.5, “PDU routing”</a>. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>A LIN-TP-CONNECTION belongs to the imported ECU-INSTANCE if at least one transmitting or receiving LIN-TP-NODE of this LIN-TP-CONNECTION references a COMMUNICATION-CONNECTOR which is also referenced by the imported ECU-INSTANCE.</p> <p>If multiple LIN-TP-CONNECTION elements reference the same PDU, only one LinTpRxNSdu container is created. The parameters TimeoutAs, TimeoutCr, and TimeoutCs of these LIN-TP-CONNECTION elements are checked for consistency. If inconsistencies are detected, a warning is reported.</p> <p>LinTpRxNSduPduRef references the corresponding container in the EcuC module configuration.</p> <p>LinTpRxNSduChannelRef references the container created for the LIN-PHYSICAL-CHANNEL of the LIN-TP-CONNECTION in the LinIf module configuration.</p> <p>LinTpRxNSduTpChannelRef references the LinTpChannelConfig container created for the LIN-PHYSICAL-CHANNEL of the LIN-TP-CONNECTION.</p> <p>LinTpRxNSduNad is set to TP-ADDRESS referenced by the LIN-TP-NODE referenced via TRANSMITTER-REF.</p> <p>LinTpDl is set to LENGTH.</p> <p>LinTpNcr is set to TIMEOUT-CR.</p>
LinTpGlobalConfig/LinTpTxNSdu	<p>For every PDU which is referenced by a LIN-TP-CONNECTION which belongs to the imported ECU-INSTANCE, and which is also sent or routed by the ECU-INSTANCE, a LinTpTxNSdu container is created. For more information, see <a href="#">Section 3.3.5, “PDU routing”</a>. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>If multiple LIN-TP-CONNECTION elements reference the same PDU, only one LinTpTxNSdu container is created. The parameters TimeoutAs, TimeoutCr, and TimeoutCs of these LIN-TP-CONNECTION elements are checked for consistency. If inconsistencies are detected, a warning is reported.</p> <p>LinTpTxNSduPduRef references the corresponding container in the EcuC module configuration.</p>



Configuration parameters	Mapping description
	<p><code>LinTpTxNSduChannelRef</code> references the container created for the LIN-PHYSICAL-CHANNEL of the LIN-TP-CONNECTION in the <code>LinIf</code> module configuration.</p> <p><code>LinTpTxNSduTpChannelRef</code> references the <code>LinTpChannelConfig</code> container created for the LIN-PHYSICAL-CHANNEL of the LIN-TP-CONNECTION.</p> <p><code>LinTpTxNSduNad</code> is set to TP-ADDRESS referenced via MULTICAST-REF. If no MULTICAST-REF exists, the TP-ADDRESS of the first LIN-TP-NODE referenced via RECEIVER-REFS is used. If more than one MULTICAST-REF exists, a warning is issued.</p> <p><code>LinTpNas</code> is set to TIMEOUT-AS.</p> <p><code>LinTpNcs</code> is set to TIMEOUT-CS.</p>
<code>LinTpGlobalConfig/LinTpChannelConfig</code>	<p>For the LIN-PHYSICAL-CHANNEL which belongs to the LIN-TP-CONNECTION a <code>LinTpChannelConfig</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the SHORT-NAME of the LIN-PHYSICAL-CHANNEL.</p> <p>A LIN-PHYSICAL-CHANNEL belongs to a LIN-TP-CONNECTION if it is part of the COMMUNICATION-CLUSTER referenced by the parent LIN-TP-CONFIG.</p> <p><code>LinTpDropNotRequestedNad</code> is set to DROP-NOT-REQUESTED-NAD. If inconsistencies are detected among DROP-NOT-REQUESTED-NAD values of multiple LIN-TP-CONNECTION elements which belong to the same LIN-PHYSICAL-CHANNEL, a warning is reported.</p>

### 3.4.33. Nm

Configuration parameters	Mapping description
<code>NmChannelConfig</code>	<p>For every CAN-CLUSTER, FLEXRAY-CLUSTER, and ETHERNET-PHYSICAL-CHANNEL for which an Nm channel container has been created in <code>UdpNm</code>, <code>CanNm</code>, or <code>FrNm</code>, an <code>NmChannelConfig</code> container is created. For details on Nm channel container creation in the bus-specific NM modules, see <a href="#">Section 3.4.4, “CanNm”</a>, <a href="#">Section 3.4.41, “UdpNm”</a>, and <a href="#">Section 3.4.23, “FrNm”</a>.</p> <p>The container name is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the SHORT-NAME of the NM-CLUSTER or, if the <code>NmChannelConfig</code> has been created for an ETH-</p>

Configuration parameters	Mapping description
	<p>ETHERNET-PHYSICAL-CHANNEL, the ETHERNET-PHYSICAL-CHANNEL's SHORT-NAME.</p> <p>The NM-ECU used for configuring some of the <code>NmChannelConfig</code> parameters is the NM-ECU which the first NM-NODE that is associated to the configured ECU-INSTANCE and to the NM-CLUSTER references via NM-IF-ECU-REF.</p> <p><code>NmNodeDetectionEnabled</code> is set to NM-CLUSTER/NM-NODE-DETECTION-ENABLED, or to NM-ECU/NM-NODE-DETECTION-ENABLED if NM-CLUSTER/NM-NODE-DETECTION-ENABLED is not available.</p> <p><code>NmNodeIdEnabled</code> is set to NM-CLUSTER/NM-NODE-ID-ENABLED, or to NM-ECU/NM-NODE-ID-ENABLED if NM-CLUSTER/NM-NODE-ID-ENABLED is not available.</p> <p><code>NmRepeatMsgIndEnabled</code> is set to NM-CLUSTER/NM-REPEAT-MSG-IND-ENABLED, or to NM-ECU/NM-REPEAT-MSG-IND-ENABLED if NM-CLUSTER/NM-REPEAT-MSG-IND-ENABLED is not available.</p> <p><code>NmSynchronizingNetwork</code> is set to NM-SYNCHRONIZING-NETWORK.</p> <p><code>NmChannelSleepMaster</code> is set to NM-CHANNEL-SLEEP-MASTER.</p> <p><code>NmComMChannelRef</code> references the <code>ComMChannel</code> container in the <code>ComM</code> module that corresponds to this <code>NmChannelConfig</code> container.</p> <p><code>NmBusType/NmStandardBusNmConfig/NmStandardBusType</code> is set depending on the type of the NM-CLUSTER:</p> <ul style="list-style-type: none"> <li>▶ <code>NM_BUSNM_CANNM</code> for CAN-NM-CLUSTER elements.</li> <li>▶ <code>NM_BUSNM_FRNM</code> for FLEXRAY-NM-CLUSTER elements.</li> <li>▶ <code>NM_BUSNM_UDPNM</code> for UDP-NM-CLUSTER elements.</li> <li>▶ For any other cluster type <code>NmStandardBusType</code> is not set and a warning is issued.</li> </ul> <p>The following parameters are set using the NM-COORDINATOR which belongs to the first NM-NODE belonging to the NM-CLUSTER and the imported ECU-INSTANCE. An NM-COORDINATOR belongs to an NM-NODE if it is aggregated by the NM-ECU of the NM-NODE and if the NM-COORDINATOR references this NM-NODE.</p> <p><code>NmShutdownDelayTimer</code> is set to NM-SHUTDOWN-DELAY-TIMER.</p>

Configuration parameters	Mapping description
	<p>The following parameters are set using the first NM-NODE which belongs to the NM-CLUSTER and the imported ECU-INSTANCE.</p> <p>NmPassiveModeEnabled is set to NM-PASSIVE-MODE-ENABLED.</p> <p>NmActiveCoordinator is set depending on the value of NM-COORDINATOR-ROLE:</p> <ul style="list-style-type: none"> <li>▶ true for ACTIVE.</li> <li>▶ false for PASSIVE.</li> </ul> <p>NmCoordClusterIndex is set to NM-COORD-CLUSTER. If NM-COORD-CLUSTER is not available, NmCoordClusterIndex is set to INDEX of the NM-COORDINATOR.</p>
NmGlobalConfig	The following parameters are set using the first NM-ECU of all NM-CLUSTER elements belonging to the imported ECU-INSTANCE.
NmGlobalConfig/Nm-GlobalProperties	NmCycletimeMainFunction is set to NM-CYCLETIME-MAIN-FUNCTION.
NmGlobalConfig/Nm-GlobalFeatures	<p>NmUserDataEnabled is set to NM-USER-DATA-ENABLED.</p> <p>NmComUserDataSupport is set to true if any NmUserDataPdu container has been created in the EcuC module configuration as described in <a href="#">Section 3.4.13, "EcuC"</a>, or if any NM-CLUSTER linked to the imported ECU-INSTANCE has its NM-PNC-PARTICIPATION either not defined or set to true.</p> <p>NmPduRxIndicationEnabled is set to NM-PDU-RX-INDICATION-ENABLED.</p> <p>NmStateChangeIndEnabled is set to NM-STATE-CHANGE-IND-ENABLED.</p> <p>NmRemoteSleepIndEnabled is set to NM-REMOTE-SLEEP-IND-ENABLED.</p> <p>NmBusSynchronizationEnabled is set to NM-BUS-SYNCHRONIZATION-ENABLED.</p> <p>NmCoordinatorSupportEnabled is set to true if NM-COORDINATOR elements exist for the NM-ECU elements.</p> <p>NmCarWakeUpRxEnabled is set to true, if at least one NM-CLUSTER belonging to the imported ECU-INSTANCE has NM-CAR-WAKE-UP-RX-ENABLED set to true. If all NM-CLUSTER elements have NM-CAR-WAKE-UP-RX-ENABLED set to false, NmCarWakeUpRxEnabled is also set to false. Otherwise NmCarWakeUpRxEnabled is not set.</p>

Configuration parameters	Mapping description
	<p>The following parameters are set using the first NM-COORDINATOR of all NM-ECU elements of all NM-CLUSTER elements which belong to the imported ECU-INSTANCE.</p> <p>NmGlobalCoordinatorTime is set to NM-GLOBAL-COORDINATOR-TIME.</p> <p>NmCoordinatorSyncSupport is set to NM-COORD-SYNC-SUPPORT.</p>

### 3.4.34. PduR

Configuration parameters	Mapping description
PduRRoutingTables/PduRRoutingTable/PduRRoutingPath	<p>For every PDU instance (see <a href="#">Section 3.3.1.3, "Instance handling"</a>) sent, received or routed (see <a href="#">Section 3.3.5, "PDU routing"</a>) by the imported ECU-INSTANCE, a PduRRoutingPath container is created.</p> <p>For every PDU referenced by a TP-CONNECTION belonging to the imported ECU-INSTANCE, a PduRRoutingPath container is created as well. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU. For NM-PDUs the container name is &lt;PREFIX&gt;&lt;name&gt;_NmComUserData&lt;INSTSUFFIX&gt;.</p> <p>Also, for all Pdu containers created for PNC-enabled NM-CLUSTER elements in the EcuC module (see <a href="#">Section 3.4.13, "EcuC"</a>), a PduRRoutingPath is created. The container name is the name of the Pdu container in the EcuC module, and both PduRSrcPduRef and PduRDestPduRef reference this container.</p> <p>For the following PDU instances no PduRRoutingPath is created:</p> <ul style="list-style-type: none"> <li>▶ PDU instances representing N-PDU elements unless an I-PDU-MAPPING exists for them.</li> <li>▶ PDU instances representing NM-PDU elements for which no NmUserDataPdu container has been created, see <a href="#">Section 3.4.13, "EcuC"</a>.</li> <li>▶ PDU instances sent by the imported ECU-INSTANCE for which also an I-PDU-MAPPING exists which references the PDU's PDU-TRIGGERING via TARGET-I-PDU-REF.</li> <li>▶ PDU instances representing I-SIGNAL-I-PDU elements which do not contain any signal which the ECU-INSTANCE sends or receives and for which no I-PDU-MAPPING exists. If such a PDU is detected, a warning is reported.</li> </ul>

Configuration parameters	Mapping description
	<p>► PDU instances representing DCM-I-PDU elements that are referenced via DO-IP-TP-CONNECTION elements and which are sent and have their DIAG-PDU-TYPE value set to DIAG-REQUEST, or which are received and have their DIAG-PDU-TYPE value set to DIAG-RESPONSE.</p> <p>PduRSrcPdu/PduRSrcPduRef references the PDU container in the EcuC module configuration. For NM-PDU elements it references the NmUserDataPdu container in the EcuC module which has been created for this NM-PDU. The name of PduRSrcPdu is set to &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;_S, where &lt;name&gt; is the SHORT-NAME of the PDU.</p>
PduRRoutingTables/PduRRoutingTable/PduRRoutingPath/PduRDestPdu	<p>If the PDU instance is routed locally (i.e. the ECU-INSTANCE processes the data contained in the PDU), a PduRDestPdu container is created. Received PDUs which are referenced by TP-CONNECTION elements and by the SOURCE-I-PDU-REF of at least one I-PDU-MAPPING additionally require that the TP-CONNECTION elements reference a multicast TP-ADDRESS. The container name is the name of its PduRRoutingPath parent container plus the suffix _D. PduRDestPdu/PduRDestPduRef references the same EcuC PDU container as PduRSrcPdu/PduRSrcPduRef of the parent container.</p> <p>The PDU instance is routed via gateway if two conditions hold:</p> <ul style="list-style-type: none"> <li>► The ECU-INSTANCE receives the PDU instance</li> <li>► I-PDU-MAPPING elements exist which reference the PDU instance's PDU-TRIGGERING via SOURCE-I-PDU-REF</li> </ul> <p>If the PDU instance is routed via gateway, one PduRDestPdu container is created for each I-PDU-MAPPING. The sent PDU instance that corresponds to the PDU-TRIGGERING that is referenced via I-PDU-MAPPING/TARGET-I-PDU/TARGET-I-PDU-REF is used to configure the PduRDestPdu container. If the I-PDU-MAPPING contains a valid PDUR-TP-CHUNK-SIZE subelement and the PduRRoutingPath does not contain additional sibling PduRDestPdu containers, the content of PDUR-TP-CHUNK-SIZE is used to configure PduRDestPdu/PduRTpThreshold.</p> <p>PduRDestPduRef references the EcuC container created for the sent PDU instance.</p>
PduRRoutingTables/PduRRoutingTable/PduRRoutingPath/PduRDestPdu/PduRDefaultValue/PduRDe-	<p>For every DEFAULT-VALUE-ELEMENT of the TARGET-I-PDU, a PduRDefaultValueElement container is created. The name of the container is PduRDefaultValueElement_&lt;ELEMENT-POSITION&gt;.</p> <p>If ELEMENT-POSITION &gt;= PDU's LENGTH a warning is reported and no PduRDefaultValueElement is created.</p>

Configuration parameters	Mapping description
faultValueElement	<p>If multiple DEFAULT-VALUE-ELEMENT have the same ELEMENT-POSITION, only one PduRDefaultValueElement container is created and a warning is reported.</p> <p>If ELEMENT-BYTE-VALUE does not lie within the interval [0 .. 255], a warning is reported and no PduRDefaultValueElement is created.</p> <p>PduRDefaultValueElement is set to ELEMENT-BYTE-VALUE.</p> <p>PduRDefaultValueElementBytePosition is set to ELEMENT-POSITION.</p>
PduRRoutingTables/PduRRoutingPathGroup	<p>For every PDUR-I-PDU-GROUP referenced by the imported ECU-INSTANCE via ASSOCIATED-PDUR-I-PDU-GROUP-REF, a PduRRoutingPathGroup container is created. The name of the container is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the PDUR-I-PDU-GROUP.</p> <p>For each PDU-TRIGGERING-REF of the PDUR-I-PDU-GROUP a PduRDestPduRef reference is created. It refers to the PduRDestPdu container that has been created for the PDU-TRIGGERING referenced by PDU-TRIGGERING-REF.</p>

### 3.4.35. Sd

Configuration parameters	Mapping description
SdConfig/SdInstance	<p>For each ETHERNET-PHYSICAL-CHANNEL for which the following conditions hold, one SdInstance container is created.</p> <ul style="list-style-type: none"> <li>▶ The imported ECU-INSTANCE sends and/or receives PDUs on the ETHERNET-PHYSICAL-CHANNEL via one or several SOCKET-CONNECTION elements.</li> <li>▶ The <i>local</i> SOCKET-ADDRESS of at least one of these SOCKET-CONNECTION elements contains an APPLICATION-ENDPOINT that in turn contains at least one PROVIDED-SERVICE-INSTANCE or at least one CONSUMED-SERVICE-INSTANCE. For more information about SOCKET-ADDRESS, see <a href="#">Section 3.4.37, "SoAd"</a>.</li> </ul> <p>The container name is &lt;PREFIX&gt;&lt;name&gt; where &lt;name&gt; is the SHORT-NAME of the ETHERNET-PHYSICAL-CHANNEL.</p> <p>SdInstanceHostname is configured by retrieving the FULLY-QUALIFIED-DOMAIN-NAME elements of all NETWORK-ENDPOINT elements that belong to the ETHERNET-PHYSICAL-CHANNEL and that are referenced by the ETH-</p>

Configuration parameters	Mapping description
	<p>ETHERNET-COMMUNICATION-CONNECTOR elements of the imported ECU-INSTANCE. If none of these NETWORK-ENDPOINT elements contains a FULLY-QUALIFIED-DOMAIN-NAME, the FULLY-QUALIFIED-DOMAIN-NAME elements of the NETWORK-ENDPOINT elements that belong to the ETHERNET-PHYSICAL-CHANNEL and that are referenced by any APPLICATION-ENDPOINT of a <i>local</i> SOCKET-ADDRESS (see <a href="#">Section 3.4.37, "SoAd"</a>) of the imported ECU-INSTANCE are collected. If the collection yields exactly one distinct FULLY-QUALIFIED-DOMAIN-NAME, it is used to configure SdInstanceHostname. If none or more than one distinct FULLY-QUALIFIED-DOMAIN-NAME elements are found, SdInstanceHostname is not set.</p>
SdConfig/SdInstance/SdInstanceTxPdu	<p>If an Sd PDU exists which is sent by the imported ECU-INSTANCE and referenced by a SOCKET-CONNECTION of the ETHERNET-PHYSICAL-CHANNEL, an SdInstanceTxPdu container is created. SdTxPduRef references the corresponding container in the EcuC module configuration. A PDU is considered an Sd PDU if it is a GENERAL-PURPOSE-PDU and its CATEGORY is set to SD.</p>
SdConfig/SdInstance/SdInstanceUnicastRxPdu	<p>If an Sd PDU exists which is received by the imported ECU-INSTANCE and referenced by a unicast SOCKET-CONNECTION of the ETHERNET-PHYSICAL-CHANNEL, an SdInstanceUnicastRxPdu container is created. SdRxPduRef references the corresponding container in the EcuC module configuration. A SOCKET-CONNECTION is considered unicast if its <i>local</i> SOCKET-ADDRESS represents an IPv4 unicast address.</p>
SdConfig/SdInstance/SdInstanceMulticastRxPdu	<p>If an Sd PDU exists which is received by the imported ECU-INSTANCE and referenced by a multicast SOCKET-CONNECTION of the ETHERNET-PHYSICAL-CHANNEL, an SdInstanceMulticastRxPdu container is created. SdRxPduRef references the corresponding container in the EcuC module configuration. A SOCKET-CONNECTION is considered multicast if its <i>local</i> SOCKET-ADDRESS represents an IPv4 multicast address.</p>
SdConfig/SdInstance/SdServerService	<p>Every SOCKET-CONNECTION of the ETHERNET-PHYSICAL-CHANNEL for which the imported ECU-INSTANCE acts as a server contains zero to many PROVIDED-SERVICE-INSTANCE elements in its <i>local</i> SOCKET-ADDRESS. For each of these PROVIDED-SERVICE-INSTANCE elements, an SdServerService container is created. The container name is &lt;PREFIX&gt;&lt;name&gt; where &lt;name&gt; is the SHORT-NAME of the PROVIDED-SERVICE-INSTANCE.</p> <p>SdServerServiceInstanceId is set to INSTANCE-IDENTIFIER.</p> <p>SdServerServiceId is set to SERVICE-IDENTIFIER.</p> <p>SdServerServiceMajorVersion is set to SD-SERVER-CONFIG/SERVER-SERVICE-MAJOR-VERSION.</p>

Configuration parameters	Mapping description
	<p>SdServerServiceMinorVersion is set to SD-SERVER-CONFIG/SERVER-SERVICE-MINOR-VERSION.</p> <p>SdServerServiceTimerRef references the SdServerTimer container created for the SD-SERVER-CONFIG.</p> <p>If the <i>local</i> SOCKET-ADDRESS is connected to a SoAdSocketConnectionGroup of type SoAdSocketUdp, SdServerServiceUdpRef references the SoAdSocketConnectionGroup. For more information about SOCKET-ADDRESS, see <a href="#">Section 3.4.37, “SoAd”</a>.</p> <p>If the <i>local</i> SOCKET-ADDRESS is connected to a SoAdSocketConnectionGroup of type SoAdSocketTcp, SdServerServiceTcpRef references the SoAdSocketConnectionGroup.</p>
SdConfig/SdInstance/SdServerService/SdServerCapabilityRecord	<p>For each CAPABILITY-RECORDS/TAG-WITH-OPTIONAL-VALUE, an SdServerCapabilityRecord container is created. The container name is SdServerCapabilityRecord_&lt;auto incremented number&gt;.</p> <p>SdServerCapabilityRecordKey is set to KEY.</p> <p>SdServerCapabilityRecordValue is set to VALUE.</p>
SdConfig/SdInstance/SdServerService/SdEventHandler	<p>For each EVENT-HANDLER of the PROVIDED-SERVICE-INSTANCE, an SdEventHandler container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the EVENT-HANDLER.</p> <p>SdEventHandlerEventGroupId is set to EVENT-GROUP-IDENTIFIER of the first CONSUMED-EVENT-GROUP that is referenced by the EVENT-HANDLER.</p> <p>SdEventHandlerMulticastThreshold is set to EVENT-HANDLER/MULTICAST-THRESHOLD.</p> <p>If any of the SO-AD-ROUTING-GROUP elements referenced by the EVENT-HANDLER has its EVENT-GROUP-CONTROL-TYPE set to ACTIVATION-MULTICAST, SdEventHandlerMulticast/SdEventActivationRef references the SoAdRoutingGroup container that has been created for this SO-AD-ROUTING-GROUP.</p> <p>The APPLICATION-ENDPOINT that transmits the multicast PDUs of an EVENT-HANDLER is either the APPLICATION-ENDPOINT that EVENT-HANDLER/APPLICATION-ENDPOINT-REF refers to, or, if EVENT-HANDLER/APPLICATION-ENDPOINT-REF does not exist, the APPLICATION-ENDPOINT that contains the EVENT-HANDLER. SdMulticastEventSoConRef references a</p>



Configuration parameters	Mapping description
	<p><b><i>multicast</i></b> SoAdSocketConnection container in the SoAd module if this APPLICATION-ENDPOINT meets the following conditions:</p> <ul style="list-style-type: none"> <li>▶ The APPLICATION-ENDPOINT is aggregated by a <i>local</i> SOCKET-ADDRESS of the imported ECU-INSTANCE.</li> <li>▶ The SoAd configuration contains a SoAdSocketConnectionGroup container that uses the SOCKET-ADDRESS as <i>local</i> address.</li> <li>▶ The SoAdSocketConnectionGroup configuration contains a SoAdSocketConnection that is associated with a <i>remote multicast</i> SOCKET-ADDRESS.</li> </ul> <p>SdEventHandlerTimerRef: <b>see</b> SdServerServiceTimerRef.</p> <p>SdServerCapabilityRecord: <b>see</b> SdServerService/SdServerCapabilityRecord.</p>
SdConfig/SdInstance/SdServerService/SdEventHandler/SdEventHandlerUdp	<p>If the <i>local</i> SOCKET-ADDRESS is connected to a SoAdSocketConnectionGroup of type SoAdSocketUdp (see <a href="#">Section 3.4.37, "SoAd"</a>), an SdEventHandlerUdp container is created.</p> <p>If any of the SO-AD-ROUTING-GROUP elements referenced by the EVENT-HANDLER has its EVENT-GROUP-CONTROL-TYPE set to ACTIVATION-UNICAST or to ACTIVATION-AND-TRIGGER-UNICAST, SdEventActivationRef references the SoAdRoutingGroup container that has been created for this SO-AD-ROUTING-GROUP.</p> <p>If any of the SO-AD-ROUTING-GROUP elements referenced by the EVENT-HANDLER has its EVENT-GROUP-CONTROL-TYPE set to TRIGGER-UNICAST or to ACTIVATION-AND-TRIGGER-UNICAST, SdEventTriggeringRef references the SoAdRoutingGroup container that has been created for this SO-AD-ROUTING-GROUP.</p>
SdConfig/SdInstance/SdServerService/SdEventHandler/SdEventHandlerTcp	<p>If the <i>local</i> SOCKET-ADDRESS is connected to a SoAdSocketConnectionGroup of type SoAdSocketTcp (see <a href="#">Section 3.4.37, "SoAd"</a>), an SdEventHandlerTcp container is created.</p> <p>The parameters SdEventActivationRef and SdEventTriggeringRef are configured in the same way as the corresponding parameters of SdEventHandlerUdp.</p>
SdConfig/SdInstance/SdServerService	<p>SdServerServiceActivationRef references the SoAdRoutingGroup container that has been created for the first SO-AD-ROUTING-GROUP referenced by the PROVIDED-SERVICE-INSTANCE.</p>

Configuration parameters	Mapping description
vice/SdProvided-Methods	
SdConfig/SdInstance/SdServerTimer	<p>For all SD-SERVER-CONFIG elements that contain identical values in all parameters listed below, one SdServerTimer container is created. The container name is SdServerTimer&lt;auto incremented number&gt;.</p> <p>SdServerTimerInitialOfferDelayMax is set to INITIAL-OFFER-BEHAVIOR/INITIAL-DELAY-MAX-VALUE.</p> <p>SdServerTimerInitialOfferDelayMin is set to INITIAL-OFFER-BEHAVIOR/INITIAL-DELAY-MIN-VALUE.</p> <p>SdServerTimerInitialOfferRepetitionBaseDelay is set to INITIAL-OFFER-BEHAVIOR/INITIAL-REPETITIONS-BASE-DELAY.</p> <p>SdServerTimerInitialOfferRepetitionsMax is set to INITIAL-OFFER-BEHAVIOR/INITIAL-REPETITIONS-MAX.</p> <p>SdServerTimerOfferCyclicDelay is set to OFFER-CYCLIC-DELAY.</p> <p>SdServerTimerRequestResponseMaxDelay is set to REQUEST-RESPONSE-DELAY/MAX-VALUE.</p> <p>SdServerTimerRequestResponseMinDelay is set to REQUEST-RESPONSE-DELAY/MIN-VALUE.</p> <p>SdServerTimerTTL is set to TTL.</p>
SdConfig/SdInstance/SdClientService	<p>Every SOCKET-CONNECTION of the ETHERNET-PHYSICAL-CHANNEL for which the imported ECU-INSTANCE acts as a client contains zero to many CONSUMED-SERVICE-INSTANCE elements in its <i>local</i> SOCKET-ADDRESS. For each of these CONSUMED-SERVICE-INSTANCE elements, an SdClientService container is created. The container name is &lt;PREFIX&gt;&lt;name&gt; where &lt;name&gt; is the SHORT-NAME of the CONSUMED-SERVICE-INSTANCE.</p> <p>The parameters SdClientServiceInstanceId, SdClientServiceId, SdClientServiceMajorVersion, SdClientServiceMinorVersion, SdClientServiceTimerRef and SdClientCapabilityRecord are configured in the same way as the corresponding parameters of the SdServerService container.</p> <p>If the <i>local</i> SOCKET-ADDRESS is connected to a SoAdSocketConnectionGroup of type SoAdSocketUdp, SdClientServiceUdpRef references this</p>

Configuration parameters	Mapping description
	<p>SoAdSocketConnectionGroup. For more information about SOCKET-ADDRESS, see <a href="#">Section 3.4.37, “SoAd”</a>.</p> <p>If the <i>local</i> SOCKET-ADDRESS is connected to a SoAdSocketConnectionGroup of type SoAdSocketTcp, SdClientServiceTcpRef references this SoAdSocketConnectionGroup.</p>
SdConfig/SdInstance/SdClientService/SdConsumedEventGroup	<p>For each CONSUMED-EVENT-GROUP of the CONSUMED-SERVICE-INSTANCE, an SdConsumedEventGroup container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the CONSUMED-EVENT-GROUP.</p> <p>SdConsumedEventGroupId is set to EVENT-GROUP-IDENTIFIER.</p> <p>SdConsumedEventGroupTimerRef references the SdClientTimer container created for the SD-CLIENT-CONFIG.</p> <p>SdClientCapabilityRecord: see SdServerService/SdServerCapabilityRecord.</p> <p>If any of the SO-AD-ROUTING-GROUP elements referenced by the CONSUMED-EVENT-GROUP has its EVENT-GROUP-CONTROL-TYPE set to ACTIVATION-UNICAST or to ACTIVATION-AND-TRIGGER-UNICAST, a reference is set up to the SoAdRoutingGroup container that has been created for this SO-AD-ROUTING-GROUP. If the <i>local</i> SOCKET-ADDRESS is connected to a SoAdSocketConnectionGroup of type SoAdSocketUdp, the reference is SdConsumedEventGroupUdpActivationRef if the SoAdSocketConnectionGroup is of type SoAdSocketTcp and the reference is SdConsumedEventGroupTcpActivationRef. For more information about SOCKET-ADDRESS, see <a href="#">Section 3.4.37, “SoAd”</a>.</p> <p>If any of the SO-AD-ROUTING-GROUP elements referenced by the CONSUMED-EVENT-GROUP has its EVENT-GROUP-CONTROL-TYPE set to ACTIVATION-MULTICAST, SdConsumedEventGroupMulticastActivationRef references the SoAdRoutingGroup container that has been created for this SO-AD-ROUTING-GROUP.</p> <p>SdConsumedEventGroupMulticastGroupRef is set up to reference a SoAdSocketConnectionGroup container in the SoAd module if the following conditions are met:</p>

Configuration parameters	Mapping description
	<ul style="list-style-type: none"> <li>▶ The CONSUMED-EVENT-GROUP references an APPLICATION-ENDPOINT that is aggregated by a <i>local multicast</i> SOCKET-ADDRESS of the imported ECU-INSTANCE.</li> <li>▶ The SoAd configuration contains a SoAdSocketConnectionGroup container that uses the SOCKET-ADDRESS as <i>local</i> address.</li> </ul>
SdConfig/SdInstance/SdClientService/SdConsumed-Methods	SdClientServiceActivationRef references the SoAdRoutingGroup container that has been created for the first SO-AD-ROUTING-GROUP referenced by the CONSUMED-SERVICE-INSTANCE.
SdConfig/SdInstance/SdClientTimer	<p>For all SD-CLIENT-CONFIG elements that contain identical values in all parameters listed below, one SdClientTimer container is created. The container name is SdClientTimer&lt;auto incremented number&gt;.</p> <p>SdClientTimerInitialFindDelayMax is set to INITIAL-FIND-BEHAVIOR/INITIAL-DELAY-MAX-VALUE.</p> <p>SdClientTimerInitialFindDelayMin is set to INITIAL-FIND-BEHAVIOR/INITIAL-DELAY-MIN-VALUE.</p> <p>SdClientTimerInitialFindRepetitionsBaseDelay is set to INITIAL-FIND-BEHAVIOR/INITIAL-REPETITIONS-BASE-DELAY.</p> <p>SdClientTimerInitialFindRepetitionsMax is set to INITIAL-FIND-BEHAVIOR/INITIAL-REPETITIONS-MAX.</p> <p>SdClientTimerRequestResponseMaxDelay is set to REQUEST-RESPONSE-DELAY/MAX-VALUE.</p> <p>SdClientTimerRequestResponseMinDelay is set to REQUEST-RESPONSE-DELAY/MIN-VALUE.</p> <p>SdClientTimerTTL is set to TTL.</p>

### 3.4.36. SecOC

The SecOC secures or authenticates the payload of a PDU by using a SECURED-I-PDU and an associated *payload PDU*. A SECURED-I-PDU is associated with a payload PDU if SECURED-I-PDU/PAYLOAD-REF refers to a PDU-TRIGGERING which in turn refers to the payload PDU.

If the SECURED-I-PDU has its USE-AS-CRYPTOGRAPHIC-I-PDU parameter either set to `false` or not set at all, the SECURED-I-PDU contains the associated payload PDU and the meta-data, i.e. *Message Authentication Code* and *Freshness Value*.

If the SECURED-I-PDU has its USE-AS-CRYPTOGRAPHIC-I-PDU parameter set to `true`, the SECURED-I-PDU mostly contains the security data, while the payload is independently transmitted in a second payload PDU. A SECURED-I-PDU that has its USE-AS-CRYPTOGRAPHIC-I-PDU set to `true` is referred to as *cryptographic* PDU. The PDU that contains the encrypted or authenticated payload is referred to as *payload* PDU.

Configuration parameters	Mapping description
SecOC/SecOCTx-PduProcessing, SecOC/SecOCRxPduProcessing	<p>For every SECURED-I-PDU that the imported ECU-INSTANCE sends, a SecOCTxPduProcessing container is created, for every SECURED-I-PDU that is received by the imported ECU-INSTANCE, a SecOCRxPduProcessing container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the SECURED-I-PDU.</p> <p>SecOCPduType is configured depending on the lower layer AUTOSAR module of the PduR that processes the SECURED-I-PDU. For CanTp, FrTp, FrArTp, LinTp, and DoIp, the value of SecOCPduType is set to SECOC_TPPDU. In all other cases, the value of SecOCPduType is set to SECOC_IFPDU.</p> <p>If AUTHENTICATION-PROPS-REF refers to a valid SECURE-COMMUNICATION-AUTHENTICATION-PROPS element, SecOCAuthInfoTxLength is set to SECURE-COMMUNICATION-AUTHENTICATION-PROPS/AUTH-INFO-TX-LENGTH. Otherwise SecOCAuthInfoTxLength is set to SECURE-COMMUNICATION-PROPS/AUTH-INFO-TX-LENGTH.</p> <p>SecOCAuthenticationBuildAttempts is set to SECURE-COMMUNICATION-PROPS/AUTHENTICATION-BUILD-ATTEMPTS.</p> <p>SecOCDataId is set to SECURE-COMMUNICATION-PROPS/DATA-ID.</p> <p>SecOCFreshnessValueId is set to SECURE-COMMUNICATION-PROPS/FRESHNESS-VALUE-ID.</p> <p>If FRESHNESS-PROPS-REF refers to a valid SECURE-COMMUNICATION-FRESHNESS-PROPS element, SecOCFreshnessValueLength is set to SECURE-COMMUNICATION-FRESHNESS-PROPS/FRESHNESS-VALUE-LENGTH. Otherwise SecOCFreshnessValueLength is set to SECURE-COMMUNICATION-PROPS/FRESHNESS-VALUE-LENGTH.</p> <p>If FRESHNESS-PROPS-REF refers to a valid SECURE-COMMUNICATION-FRESHNESS-PROPS element, SecOCFreshnessValueTxLength is set to SECURE-COMMUNICATION-FRESHNESS-PROPS/FRESHNESS-VAL-</p>

Configuration parameters	Mapping description
	<p>UE-TX-LENGTH. Otherwise SecOCFreshnessValueTxLength is set to SECURE-COMMUNICATION-PROPS/FRESHNESS-VALUE-TX-LENGTH.</p> <p>SecOCUseAuthDataFreshness is set to USE-AUTH-DATA-FRESHNESS of the I-PDU-PORT via which the SECURED-I-PDU is sent or received.</p>
SecOC/SecOCTx-PduProcessing	<p>For every SECURED-I-PDU that the imported ECU-INSTANCE sends, the following parameters are configured in SecOCTxPduProcessing:</p> <ul style="list-style-type: none"> <li>▶ SecOCTxAuthenticPduLayer/SecOCTxAuthenticLayerPduRef is set to reference the EcuC configuration container of the PDU that the SECURED-I-PDU references via PAYLOAD-REF. That container represents the PDU that is provided by the upper layer module. The following PDU types are supported: <ul style="list-style-type: none"> <li>▶ I-SIGNAL-I-PDU</li> <li>▶ CONTAINER-I-PDU</li> <li>▶ MULTIPLEXED-I-PDU</li> <li>▶ USER-DEFINED-I-PDU</li> <li>▶ DCM-I-PDU</li> <li>▶ GENERAL-PURPOSE-I-PDU</li> </ul> </li> <li>▶ SecOCTxPduSecuredArea/SecOCSecuredTxPduLength is set to SECURE-COMMUNICATION-PROPS/SECURED-AREA-LENGTH.</li> <li>▶ SecOCTxPduSecuredArea/SecOCSecuredTxPduOffset is set to SECURE-COMMUNICATION-PROPS/SECURED-AREA-OFFSET.</li> </ul> <p>The content of the choice container SecOCTxSecuredPduLayer depends on whether the SECURED-I-PDU is a <i>cryptographic</i> PDU or not. If it is a <i>cryptographic</i> PDU, the content of the choice container is set to SecOCTxSecuredPduCollection, otherwise to SecOCTxSecuredPdu.</p> <p>SecOCTxSecuredPduCollection/SecOCTxAuthenticPdu/SecOCTxAuthenticPduRef is set to reference the configuration container of the <i>payload</i> PDU in the EcuC module configuration.</p> <p>SecOCTxSecuredPduCollection/SecOCTxCryptographicPdu/SecOCTxCryptographicPduRef is set to reference the configuration container of the <i>cryptographic</i> PDU in the EcuC module configuration.</p>

Configuration parameters	Mapping description
	<p>SecOCTxSecuredPdu/SecOCTxSecuredLayerPduRef is set to reference the configuration container of the SECURED-I-PDU in the EcuC module configuration.</p>
<p>SecOC/SecOCRx-PduProcessing</p>	<p>For every SECURED-I-PDU that the imported ECU-INSTANCE receives, the following parameters are configured in SecOCRxPduProcessing:</p> <ul style="list-style-type: none"> <li>▶ SecOCAuthenticationVerifyAttempts is set to SECURE-COMMUNICATION-PROPS/AUTHENTICATION-RETRIES.</li> <li>▶ SecOCAuthDataFreshnessLen is set to SECURE-COMMUNICATION-PROPS/AUTH-DATA-FRESHNESS-LENGTH.</li> <li>▶ SecOCAuthDataFreshnessStartPosition is set to SECURE-COMMUNICATION-PROPS/AUTH-DATA-FRESHNESS-START-POSITION.</li> <li>▶ SecOCRxAuthenticPduLayer/SecOCRxAuthenticLayerPduRef is set to reference the EcuC configuration container of the PDU that the SECURED-I-PDU references via PAYLOAD-REF. That container represents the PDU that is provided to the upper layer module. The following PDU types are supported: <ul style="list-style-type: none"> <li>▶ I-SIGNAL-I-PDU</li> <li>▶ CONTAINER-I-PDU</li> <li>▶ MULTIPLEXED-I-PDU</li> <li>▶ USER-DEFINED-I-PDU</li> <li>▶ DCM-I-PDU</li> <li>▶ GENERAL-PURPOSE-I-PDU</li> </ul> </li> <li>▶ SecOCRxPduSecuredArea/SecOCSecuredRxPduLength is set to SECURE-COMMUNICATION-PROPS/SECURED-AREA-LENGTH.</li> <li>▶ SecOCRxPduSecuredArea/SecOCSecuredRxPduOffset is set to SECURE-COMMUNICATION-PROPS/SECURED-AREA-OFFSET.</li> </ul> <p>The content of the choice container SecOCRxSecuredPduLayer depends on whether the SECURED-I-PDU is a <i>cryptographic</i> PDU or not. If it is a <i>cryptographic</i> PDU, the content of the choice container is set to SecOCRxSecuredPduCollection, otherwise to SecOCRxSecuredPdu.</p> <p>SecOCRxSecuredPduCollection/SecOCRxAuthenticPdu/SecOCRxAuthenticPduRef is set to reference the configuration container of the <i>payload</i> PDU in the EcuC module configuration.</p>

Configuration parameters	Mapping description
	<p>SecOCRxSecuredPduCollection/SecOCRxCryptographicPdu/SecOCRxCryptographicPduRef is set to reference the configuration container of the <i>cryptographic</i> PDU in the EcuC module configuration.</p> <p>SecOCRxSecuredPduCollection/SecOCSecuredRxPduVerification is set to RX-SECURITY-VERIFICATION of the I-PDU-PORT via which the SECURED-I-PDU is received.</p> <p>SecOCRxSecuredPdu/SecOCRxSecuredLayerPduRef is set to reference the configuration container of the SECURED-I-PDU in the EcuC module configuration.</p> <p>SecOCRxSecuredPdu/SecOCSecuredRxPduVerification is set to RX-SECURITY-VERIFICATION of the I-PDU-PORT via which the SECURED-I-PDU is received.</p>

### 3.4.37. SoAd

Configuration parameters	Mapping description
SoAdConfig/SoAd- SocketConnection- Group	<p>For each sent and/or received SOCKET-CONNECTION-BUNDLE, for which the imported ECU-INSTANCE acts as a server, a SoAdSocketConnectionGroup container is created. The imported ECU-INSTANCE acts as a server for a SOCKET-CONNECTION-BUNDLE if the SOCKET-CONNECTION-BUNDLE references a ETHERNET-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE via SERVER-PORT-REF -&gt; SOCKET-ADDRESS -&gt; CONNECTOR-REF. A SOCKET-CONNECTION-BUNDLE is sent and/or received by the imported ECU-INSTANCE if it references PDUs that the imported ECU-INSTANCE also sends, receives or routes via SOCKET-CONNECTION-IPDU-IDENTIFIER elements. For further information about routing see <a href="#">Section 3.3.5, "PDU routing"</a>.</p> <p>SOCKET-CONNECTION-IPDU-IDENTIFIER elements can be contained in SOCKET-CONNECTION-BUNDLE and in SOCKET-CONNECTION elements. A SOCKET-CONNECTION processes all SOCKET-CONNECTION-IPDU-IDENTIFIER elements that it aggregates itself and all SOCKET-CONNECTION-IPDU-IDENTIFIER elements that are aggregated by its parent SOCKET-CONNECTION-BUNDLE. How a SOCKET-CONNECTION-IPDU-IDENTIFIER can reference PDUs is described in <a href="#">Section 3.4.40, "TcpIp"</a>. The container name is CG&lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the SOCKET-CONNECTION-BUNDLE.</p>



Configuration parameters	Mapping description
	<p>All sent and/or received <code>SOCKET-CONNECTION</code> elements for which the imported <code>ECU-INSTANCE</code> acts as a client (see <a href="#">Section 3.4.40, "TcpIp"</a>) are grouped according to the <i>local</i> <code>SOCKET-ADDRESS</code>. For each of these groups, one <code>SoAdSocketConnectionGroup</code> container is created. The container name is <code>CG&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-LABEL</code> of one of the <code>SOCKET-CONNECTION</code> elements.</p> <p>If any <code>SOCKET-CONNECTION-BUNDLE</code> or any <code>SOCKET-CONNECTION</code> related to the created <code>SoAdSocketConnectionGroup</code> container aggregates at least one <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> element that provides a value in <code>HEADER-ID</code>, <code>SoAdPduHeaderEnable</code> is set to <code>true</code>, else to <code>false</code>.</p> <p><code>SoAdSocketLocalAddressRef</code> references the <code>TcpIpLocalAddr</code> container created for the <code>NETWORK-ENDPOINT</code> of the <i>local</i> <code>SOCKET-ADDRESS</code>. If the <code>SoAdSocketConnectionGroup</code> is created for a <code>SOCKET-CONNECTION-BUNDLE</code>, the <i>local</i> <code>SOCKET-ADDRESS</code> is referenced by <code>SERVER-PORT-REF</code>. If the <code>SoAdSocketConnectionGroup</code> is created for a <code>SOCKET-CONNECTION</code>, the <i>local</i> <code>SOCKET-ADDRESS</code> is referenced by <code>CLIENT-PORT-REF</code>.</p> <p><code>SoAdSocketProtocol</code> is set depending on whether <code>SOCKET-ADDRESS/APPLICATION-ENDPOINT/TP-CONFIGURATION</code> contains a <code>TCP-TP</code> or a <code>UDP-TP</code> sub element:</p> <ul style="list-style-type: none"> <li>▶ <code>SoAdSocketTcp</code> if a <code>TCP-TP</code> element exists</li> <li>▶ <code>SoAdSocketUdp</code> if a <code>UDP-TP</code> element exists</li> </ul> <p>If <code>SoAdSocketProtocol</code> is set to <code>SoAdSocketTcp</code>, the following parameters are set:</p> <p><code>SoAdSocketTcp/SoAdSocketTcpInitiate</code> is set to <code>true</code> if the following conditions are met:</p> <ul style="list-style-type: none"> <li>▶ The <code>SoAdSocketConnectionGroup</code> is created for a <code>SOCKET-CONNECTION</code></li> <li>▶ The <code>SoAdSocketConnectionGroup</code> contains exactly one <code>SoAdSocketConnection</code> sub container</li> </ul> <p>In all other cases <code>SoAdSocketTcp/SoAdSocketTcpInitiate</code> is set to <code>false</code>.</p> <p><code>SoAdSocketTcp/SoAdSocketTcpNoDelay</code> is set depending on <code>TCP-TP/NA-GLES-ALGORITHM</code>:</p>

Configuration parameters	Mapping description
	<p> <ul style="list-style-type: none"> <li>▶ true, if NAGLES-ALGORITHM is set to false.</li> <li>▶ false, if NAGLES-ALGORITHM is set to true.</li> </ul> </p> <p>SoAdSocketTcp/SoAdSocketTcpKeepAliveProbesMax is set to KEEP-ALIVE-PROBES-MAX. SoAdSocketTcp/SoAdSocketTcpKeepAliveInterval is set to KEEP-ALIVE-INTERVAL. SoAdSocketTcp/SoAdSocketTcpKeepAliveTime is set to KEEP-ALIVE-TIME.</p> <p>SoAdSocketTcp/SoAdSocketTcpKeepAlive is set to true if either KEEP-ALIVE is true or at least one of the following parameters is defined:</p> <p> <ul style="list-style-type: none"> <li>▶ KEEP-ALIVE-PROBES-MAX</li> <li>▶ KEEP-ALIVE-INTERVAL</li> <li>▶ KEEP-ALIVE-TIME</li> </ul> </p> <p>If SoAdSocketProtocol is set to SoAdSocketUdp, the following parameters are set:</p> <p>SoAdSocketUdp/SoAdSocketUdpTriggerTimeout is set to PDU-COLLECTION-TIMEOUT of the SOCKET-CONNECTION. If the SoAdSocketConnectionGroup is created for a SOCKET-CONNECTION-BUNDLE, the first SOCKET-CONNECTION of the SOCKET-CONNECTION-BUNDLE which has a valid PDU-COLLECTION-TIMEOUT is used.</p> <p>SoAdSocketUdp/SoAdSocketn_pduUdpTxBufferMin is set to PDU-COLLECTION-MAX-BUFFER-SIZE of the SOCKET-CONNECTION. If the SoAdSocketConnectionGroup is created for a SOCKET-CONNECTION-BUNDLE, the first SOCKET-CONNECTION of the SOCKET-CONNECTION-BUNDLE which has a valid PDU-COLLECTION-MAX-BUFFER-SIZE is used.</p> <p>If all PROVIDED-SERVICE-INSTANCE and CONSUMED-EVENT-GROUP elements that are contained in the APPLICATION-ENDPOINT of the <i>local</i> SOCKET-ADDRESS provide a common PRIORITY value, this value is used to configure SoAdSocketFramePriority. If there is no such common PRIORITY value, SoAdSocketFramePriority is set to PRIORITY of the APPLICATION-ENDPOINT. If PRIORITY of the APPLICATION-ENDPOINT is not available, PRIORITY of the NETWORK-ENDPOINT that is referenced by the APPLICATION-ENDPOINT is used.</p> <p>SoAdSocketLocalPort is set to TCP-TP/TCP-TP-PORT/PORT-NUMBER of the <i>local</i> SOCKET-ADDRESS, if TCP-TP-PORT/DYNAMICALLY-ASSIGNED is either not available or set to false and SoAdSocketProtocol is set to</p>

Configuration parameters	Mapping description
	<p>SoAdSocketTcp. SoAdSocketLocalPort is set to UDP-TP/UDP-TP-PORT/PORT-NUMBER of the <i>local</i> SOCKET-ADDRESS, if UDP-TP-PORT/DYNAMICALLY-ASSIGNED is either not available or set to false and SoAdSocketProtocol is set to SoAdSocketUdp.</p> <p>If the SoAdSocketConnectionGroup is created for a SOCKET-CONNECTION, RUNTIME-PORT-CONFIGURATION of this SOCKET-CONNECTION is set to SD, and the <i>local</i> SOCKET-ADDRESS represents an IPv4 multicast address, SoAdSocketLocalPort is set to 0.</p>
SoAdConfig/SoAdSocketConnectionGroup/SoAdSocketConnection	<p>If the SoAdSocketConnectionGroup is created for a SOCKET-CONNECTION-BUNDLE, a SoAdSocketConnection container is created for each SOCKET-CONNECTION of the SOCKET-CONNECTION-BUNDLE. If the SoAdSocketConnectionGroup is created for a SOCKET-CONNECTION, a SoAdSocketConnection container is created for this SOCKET-CONNECTION. The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-LABEL of the SOCKET-CONNECTION.</p> <p>SoAdSocketRemoteAddress/SoAdSocketRemoteIpAddress is set depending on the <i>remote</i> SOCKET-ADDRESS. If the SoAdSocketConnectionGroup is created for a SOCKET-CONNECTION-BUNDLE, the <i>remote</i> SOCKET-ADDRESS is referenced by CLIENT-PORT-REF of the SOCKET-CONNECTION. If the SoAdSocketConnectionGroup is created for a SOCKET-CONNECTION, the <i>remote</i> SOCKET-ADDRESS is referenced by SERVER-PORT-REF of the parent SOCKET-CONNECTION-BUNDLE.</p> <p>SoAdSocketRemoteAddress/SoAdSocketRemoteIpAddress is set to ANY in the following cases:</p> <ul style="list-style-type: none"> <li>▶ The imported ECU-INSTANCE acts as a server for the SOCKET-CONNECTION, CLIENT-IP-ADDR-FROM-CONNECTION-REQUEST is set to true and the <i>remote</i> SOCKET-ADDRESS represents an IPv4 unicast address.</li> <li>▶ The imported ECU-INSTANCE acts as a client for the SOCKET-CONNECTION and RUNTIME-IP-ADDRESS-CONFIGURATION is set to SD.</li> </ul> <p>In all other cases the value of IPV-4-CONFIGURATION/IPV-4-ADDRESS or IPV-6-CONFIGURATION/IPV-6-ADDRESS of the NETWORK-ENDPOINT that is referenced by the APPLICATION-ENDPOINT of the <i>remote</i> SOCKET-ADDRESS is retrieved and SoAdSocketRemoteAddress/SoAdSocketRemoteIpAddress is set to that value. SoAdSocketRemoteAddress/SoAdSocketRemoteIpAddress is set to ANY if IPV-4-CONFIGURATION/IPV-4-ADDRESS contains the value 0.0.0.0.</p>

Configuration parameters	Mapping description
	<p>SoAdSocketRemoteAddress/SoAdSocketRemotePort is set depending on the <i>remote</i> SOCKET-ADDRESS.</p> <p>SoAdSocketRemoteAddress/SoAdSocketRemotePort is set to 0 in the following cases:</p> <ul style="list-style-type: none"> <li>▶ The imported ECU-INSTANCE acts as a server for the SOCKET-CONNECTION, CLIENT-PORT-FROM-CONNECTION-REQUEST is set to true and the <i>remote</i> SOCKET-ADDRESS represents an IPv4 unicast address.</li> <li>▶ The imported ECU-INSTANCE acts as a client for the SOCKET-CONNECTION and RUNTIME-PORT-CONFIGURATION is set to SD.</li> </ul> <p>In all other cases SoAdSocketRemoteAddress/SoAdSocketRemotePort is set to PORT-NUMBER of the APPLICATION-ENDPOINT of the <i>remote</i> SOCKET-ADDRESS.</p>
SoAdConfig/SoAdSocketConnectionGroup/SoAdSocketUdpRetryEnabled	<p>If the SoAdSocketConnectionGroup sends or receives at least one PDU, whose length plus Udp header size plus IP header size exceeds the MaximumTransferUnit of the transmitting or receiving EthernetCommunicationController and thus needs to be fragmented, the value of SoAdSocketUdpRetryEnabled is set to true.</p>
SoAdConfig/SoAdPduRoute	<p>For every PDU sent or routed (see <a href="#">Section 3.3.5, “PDU routing”</a>) by the imported ECU-INSTANCE which is referenced by a SOCKET-CONNECTION-IPDU-IDENTIFIER of a SOCKET-CONNECTION or of a SOCKET-CONNECTION-BUNDLE, a SoAdPduRoute container is created unless the local SOCKET-ADDRESS of the SOCKET-CONNECTION or SOCKET-CONNECTION-BUNDLE is a multicast address. How a SOCKET-CONNECTION-IPDU-IDENTIFIER can reference PDUs is described in <a href="#">Section 3.4.40, “TcpIp”</a>. The container name is PR&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>SoAdTxPduRef references the corresponding PDU container in the EcuC module.</p> <p>SoAdTxUpperLayerType is set to TP in the following cases:</p> <ul style="list-style-type: none"> <li>▶ For GENERAL-PURPOSE-PDU elements with CATEGORY set to DoIP.</li> <li>▶ For GENERAL-PURPOSE-PDU elements with CATEGORY set to Dlt_TP.</li> <li>▶ For DCM-I-PDU elements unless they are referenced by a PDU-TRIGGERING which in turn is referenced via DIAGNOSTIC-CONNECTION/PERIODIC-RESPONSE-UUDT-REF.</li> </ul>

Configuration parameters	Mapping description
	<p>SoAdTxUpperLayerType is set to IF in the following cases:</p> <ul style="list-style-type: none"> <li>▶ For GENERAL-PURPOSE-PDU elements with CATEGORY set to Dlt_IF.</li> </ul> <p>In all other cases, SoAdTxUpperLayerType is set to IF as a default.</p> <p>SoAdTxPduCollectionSemantics is configured by collecting the PDU-COLLECTION-SEMANTICS values of all SOCKET-CONNECTION-IPDU-IDENTIFIER elements that belong to this SoAdPduRoute. If that collection yields exactly one distinct value, that value is used to configure SoAdTxUpperLayerType:</p> <ul style="list-style-type: none"> <li>▶ SOAD_COLLECT_LAST_IS_BEST is configured for LAST-IS-BEST</li> <li>▶ SOAD_COLLECT_QUEUED is configured for QUEUED</li> </ul>
SoAdConfig/SoAd-PduRoute/SoAdPduRouteDest	<p>The imported ECU-INSTANCE transmits the sent PDU in all SoAdSocketConnection containers of one SoAdSocketConnectionGroup container that use the same HEADER-ID if one of the following conditions holds:</p> <ul style="list-style-type: none"> <li>▶ The SoAdSocketConnectionGroup container has been created for a SOCKET-CONNECTION-BUNDLE and the SOCKET-CONNECTION-IPDU-IDENTIFIER that refers to the PDU-TRIGGERING of the PDU is contained in this SOCKET-CONNECTION-BUNDLE.</li> <li>▶ The SoAdSocketConnectionGroup container has been created for a SOCKET-CONNECTION-BUNDLE. Each SOCKET-CONNECTION of this SOCKET-CONNECTION-BUNDLE contains one SOCKET-CONNECTION-IPDU-IDENTIFIER that refers to the PDU-TRIGGERING of the PDU and provides the same HEADER-ID value.</li> <li>▶ The SoAdSocketConnectionGroup container has been created for a group of SOCKET-CONNECTION elements that refer to the same local SOCKET-ADDRESS. Each of these SOCKET-CONNECTION elements contains one SOCKET-CONNECTION-IPDU-IDENTIFIER that refers to the PDU-TRIGGERING of the PDU and provides the same HEADER-ID value.</li> </ul> <p>If the imported ECU-INSTANCE transmits the sent PDU in all SOCKET-CONNECTION elements of the SOCKET-CONNECTION-BUNDLE that use the same HEADER-ID, one SoAdPduRouteDest container is created unless the type of the sent PDU is listed in <a href="#">Section 3.4.37.1, “PDU types without transmission support on SoAdSocketConnectionGroup level”</a>. The container name is &lt;name&gt;_&lt;headerId&gt;, where &lt;name&gt; is the name of the container that represents the related SOCKET-CONNECTION-BUNDLE. This definition is outlined in the description of SoAdConfig/SoAdSocketConnectionGroup. &lt;headerId&gt; is</p>

Configuration parameters	Mapping description
	<p>the <code>HEADER-ID</code> of the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> referencing the PDU. How a <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> can reference PDUs is described in <a href="#">Section 3.4.40, “TcpIp”</a>. If no valid <code>HEADER-ID</code> is available, the container name is <code>&lt;name&gt;</code>.</p> <p><code>SoAdTxPduHeaderId</code> is set to <code>HEADER-ID</code> of the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> referencing the sent PDU.</p> <p><code>SoAdTxUdpTriggerMode</code> is set depending on <code>PDU-COLLECTION-TRIGGER</code> of the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> referencing the sent PDU: <code>TRIGGER_ALWAYS</code> for ALWAYS and <code>TRIGGER_NEVER</code> for NEVER.</p> <p><code>SoAdTxUdpTriggerTimeout</code> is set to <code>PDU-COLLECTION-PDU-TIMEOUT</code> of the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> which references the sent PDU.</p> <p><code>SoAdTxSocketConnOrSocketConnBundleRef</code> either references the <code>SoAdSocketConnectionGroup</code> container created for the <code>SOCKET-CONNECTION-BUNDLE</code> or the <code>SoAdSocketConnection</code> container created for the <code>SOCKET-CONNECTION</code>. <a href="#">Section 3.4.37.2, “SocketConnOrSocketConnBundleRef”</a> describes in detail which container is referenced in a given scenario.</p> <p><code>SoAdTxRoutingGroupRef</code> references all <code>SoAdRoutingGroup</code> containers created for the <code>SO-AD-ROUTING-GROUP</code> elements referenced by the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code>. If the <code>SoAdPduRoute</code> container has been created for a group of <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> elements, <code>SoAdTxRoutingGroupRef</code> references the set of <code>SoAdRoutingGroup</code> containers that were created for the <code>SO-AD-ROUTING-GROUP</code> elements that are referenced by at least one of the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> elements.</p> <p>If the imported <code>ECU-INSTANCE</code> transmits the sent PDU only in a subset of the <code>SOCKET-CONNECTION</code> elements of the <code>SOCKET-CONNECTION-BUNDLE</code>, one <code>SoAdPduRouteDest</code> container is created for each <code>SOCKET-CONNECTION</code> that transmits the PDU. The container name is <code>&lt;name&gt;_&lt;headerId&gt;</code>, where <code>&lt;name&gt;</code> is the name of the container representing the related <code>SOCKET-CONNECTION</code>. This definition is outlined in the description of <code>SoAdConfig/SoAdSocketConnectionGroup/SoAdSocketConnection</code>.</p> <p>All other parameters are configured in the same way as if the PDU was sent in all <code>SOCKET-CONNECTION</code> elements of the <code>SOCKET-CONNECTION-BUNDLE</code>.</p>

Configuration parameters	Mapping description
SoAdConfig/SoAdSocketRoute	<p>The imported ECU-INSTANCE receives one or more PDUs all SoAdSocketConnection containers of one SoAdSocketConnectionGroup container that use the same HEADER-ID if one of the following conditions holds:</p> <ul style="list-style-type: none"> <li>▶ The SoAdSocketConnectionGroup container has been created for a SOCKET-CONNECTION-BUNDLE and the SOCKET-CONNECTION-IPDU-IDENTIFIER elements that refer to the PDU-TRIGGERING elements of the PDUs are contained in this SOCKET-CONNECTION-BUNDLE.</li> <li>▶ The SoAdSocketConnectionGroup container has been created for a SOCKET-CONNECTION-BUNDLE. Each SOCKET-CONNECTION of this SOCKET-CONNECTION-BUNDLE contains SOCKET-CONNECTION-IPDU-IDENTIFIER elements that refer to the PDU-TRIGGERING elements of all PDUs and each SOCKET-CONNECTION-IPDU-IDENTIFIER provides the same HEADER-ID value.</li> <li>▶ The SoAdSocketConnectionGroup container has been created for a group of SOCKET-CONNECTION elements that refers to the same local SOCKET-ADDRESS. Each of these SOCKET-CONNECTION elements contains SOCKET-CONNECTION-IPDU-IDENTIFIER elements that refer to PDU-TRIGGERING elements of all PDUs and each SOCKET-CONNECTION-IPDU-IDENTIFIER provides the same HEADER-ID value.</li> </ul> <p>If the PDUs that are received or routed via a given HEADER-ID are received in all SoAdSocketConnection containers of one SoAdSocketConnectionGroup, one SoAdSocketRoute container is created unless the type of the sent PDU is listed in <a href="#">Section 3.4.37.1, "PDU types without transmission support on SoAdSocketConnectionGroup level"</a>. For more information about received or routed PDUs, see <a href="#">Section 3.3.5, "PDU routing"</a> and <a href="#">Section 3.4.40, "TcpIp"</a></p> <p>The container name is SR&lt;PREFIX&gt;&lt;name&gt;_&lt;headerId&gt; where &lt;name&gt; is the name of the SoAdSocketConnectionGroup container. This definition is outlined in the description of SoAdConfig/SoAdSocketConnectionGroup, and &lt;headerId&gt; is the value of HEADER-ID. If no HEADER-ID is available the container name is SR&lt;PREFIX&gt;&lt;name&gt;.</p> <p>SoAdRxPduHeaderId is set to HEADER-ID of the SOCKET-CONNECTION-IPDU-IDENTIFIER elements that reference the received PDUs.</p> <p>SoAdRxSocketConnOrSocketConnBundleRef either references the SoAdSocketConnectionGroup container or the SoAdSocketConnection container. <a href="#">Section 3.4.37.2, "SocketConnOrSocketConnBundleRef"</a> describes in detail which container is referenced in a given scenario.</p>

Configuration parameters	Mapping description
	<p>If the PDUs that are received or routed via a given <code>HEADER-ID</code> are received in a subset of the <code>SoAdSocketConnection</code> containers of one <code>SoAdSocketConnectionGroup</code>, one <code>SoAdSocketRoute</code> container is created for each of the <code>SoAdSocketConnection</code> containers that receive the PDUs. For more information about received or routed PDUs, see <a href="#">Section 3.3.5, “PDU routing”</a> and <a href="#">Section 3.4.40, “TcpIp”</a>.</p> <p>The container name is <code>SR&lt;PREFIX&gt;&lt;name&gt;_&lt;headerId&gt;</code> where <code>&lt;name&gt;</code> is the name of the <code>SoAdSocketConnection</code> container. This definition is outlined in the description of <code>SoAdConfig/SoAdSocketConnectionGroup/SoAdSocketConnection</code>, and <code>&lt;headerId&gt;</code> is the value of <code>HEADER-ID</code>. If no <code>HEADER-ID</code> is available, the container name is <code>SR&lt;PREFIX&gt;&lt;name&gt;</code>.</p> <p><code>SoAdRxPduHeaderId</code> is set to <code>HEADER-ID</code> of the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> elements that reference the received PDUs.</p>
<p><code>SoAdConfig/SoAdSocketRoute/SoAdSocketRouteDest</code></p>	<p>For every received PDU that has the same <code>HEADER-ID</code> defined by the referencing <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code>, a <code>SoAdSocketRouteDest</code> container is created. The container name is <code>&lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the PDU. How a <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code> can reference PDUs is described in <a href="#">Section 3.4.40, “TcpIp”</a>.</p> <p><code>SoAdRxPduRef</code> references the corresponding container in the <code>EcuC</code> module.</p> <p><code>SoAdRxUpperLayerType</code> is configured in the same way as <code>SoAdTxUpperLayerType</code>.</p> <p>If the <code>SoAdSocketLocalAddressRef</code> parameter of the associated <code>SoAdSocketConnectionGroup</code> refers to a multicast address, <code>SoAdRxRoutingGroupRef</code> references all <code>SoAdRoutingGroup</code> containers that have been created for <code>SO-AD-ROUTING-GROUP</code> that have <code>EVENT-GROUP-CONTROL-TYPE</code> set to <code>ACTIVATION-MULTICAST</code> and that are referenced by the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code>.</p> <p>If the <code>SoAdSocketLocalAddressRef</code> parameter of the associated <code>SoAdSocketConnectionGroup</code> refers to a unicast address, <code>SoAdRxRoutingGroupRef</code> references all <code>SoAdRoutingGroup</code> containers that have been created for <code>SO-AD-ROUTING-GROUP</code> that have <code>EVENT-GROUP-CONTROL-TYPE</code> set to a value other than <code>ACTIVATION-MULTICAST</code> and that are referenced by the <code>SOCKET-CONNECTION-IPDU-IDENTIFIER</code>.</p>



Configuration parameters	Mapping description
SoAdConfig/SoAd- RoutingGroup	<p>For each unique SO-AD-ROUTING-GROUP referenced by a SOCKET-CONNECTION-IPDU-IDENTIFIER of a SOCKET-CONNECTION used to create SoAdPduRoute and/or SoAdSocketRoute containers, a SoAdRoutingGroup container is created. The container name is RG&lt;PREFIX&gt;&lt;name&gt; where &lt;name&gt; is the SHORT-NAME of the SO-AD-ROUTING-GROUP.</p> <p>SoAdRoutingGroupTxTriggerable is set to true, if EVENT-GROUP-CONTROL-TYPE is set to ACTIVATION-AND-TRIGGER-UNICAST or TRIGGER-UNICAST.</p>

### 3.4.37.1. PDU types without transmission support on SoAdSocketConnectionGroup level

For the following PDU types dedicated SoAdPduRoute and SoAdSocketRoute containers are created for every SOCKET-CONNECTION of a SOCKET-CONNECTION-BUNDLE, even if one and the same PDU is sent or received in every SOCKET-CONNECTION of a SOCKET-CONNECTION-BUNDLE:

PDU type	Category	Protocol
GENERAL-PURPOSE-PDU	DoIP	Tcp
GENERAL-PURPOSE-PDU	DoIP	Udp

### 3.4.37.2. SocketConnOrSocketConnBundleRef

SoAdPduRoute and SoAdSocketRoute containers reference SoAdSocketConnectionGroup or SoAdSocketConnection containers via the parameters SoAdTxSocketConnOrSocketConnBundleRef and SoAdRxSocketConnOrSocketConnBundleRef.

If a SoAdPduRoute/SoAdSocketRoute references a SoAdSocketConnectionGroup, the PDUs related to the SoAdPduRoute/SoAdSocketRoute can be sent/received via any of the SoAdSocketConnection elements of the SoAdSocketConnectionGroup at runtime.

Whether or not a SoAdPduRoute/SoAdSocketRoute references a SoAdSocketConnectionGroup or a SoAdSocketConnection depends on the requirements of the SO-AD-ROUTING-GROUP elements associated with the PDUs and on the properties of the SOCKET-CONNECTION-IPDU-IDENTIFIER which specifies HEADER-ID and PDU.

A SOCKET-CONNECTION-IPDU-IDENTIFIER may refer to one or more SO-AD-ROUTING-GROUP elements. They are also referenced by the following entities that are related to service oriented communication:

- ▶ PROVIDED-SERVICE-INSTANCE
- ▶ CONSUMED-SERVICE-INSTANCE
- ▶ CONSUMED-EVENT-GROUP
- ▶ EVENT-HANDLER

If all SO-AD-ROUTING-GROUP elements of a SOCKET-CONNECTION-IPDU-IDENTIFIER are referenced from entities of one single type, then that type determines whether the SoAdPduRoute/SoAdSocketRoute references a SoAdSocketConnectionGroup or a SoAdSocketConnection. If that type is ProvidedServiceInstance, the SoAdPduRoute/SoAdSocketRoute references a SoAdSocketConnection. For all other types, the SoAdPduRoute/SoAdSocketRoute references a SoAdSocketConnectionGroup.

If none or more than one type was found, the SoAdPduRoute/SoAdSocketRoute references a SoAdSocketConnectionGroup in two scenarios:

- ▶ A SOCKET-ADDRESS of the configured ECU-INSTANCE is referenced by a SOCKET-CONNECTION-BUNDLE and the SOCKET-CONNECTION-BUNDLE contains a SOCKET-CONNECTION-IPDU-IDENTIFIER element which references a PDU-TRIGGERING that in turn refers to the PDU.
- ▶ Each SOCKET-CONNECTION referring to one and the same SOCKET-ADDRESS of the configured ECU-INSTANCE aggregates a SOCKET-CONNECTION-IPDU-IDENTIFIER that contains a common HEADER-ID and refers to the same PDU-TRIGGERING which in turn refers to the PDU. The number of SOCKET-CONNECTION elements must be greater than one.

In all other cases, the SoAdPduRoute/SoAdSocketRoute references a SocketConnection.

### 3.4.38. SomeIpTp

Configuration parameters	Mapping description
SomeIpTp/SomeIpTpChannel	<p>For every SOMEIP-TP-CONNECTION element that refers via TP-SDU-REF to a PDU which the imported ECU-INSTANCE sends or receives, a SomeIpTpChannel container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>If SOMEIP-TP-CONNECTION refers to a SOMEIP-TP-CHANNEL which contains a valid SEPARATION-TIME, that value is used to configure SomeIpTpNPduSeparationTime. Otherwise, the SEPARATION-TIME value of the SOMEIP-TP-CONNECTION is used for that purpose.</p> <p>If SOMEIP-TP-CONNECTION refers to a SOMEIP-TP-CHANNEL which contains a valid RX-TIMEOUT-TIME, that value is used to configure SomeIpTpRxTimeoutTime.</p>

Configuration parameters	Mapping description
SomeIpTp/SomeIpTpChannel/SomeIpTpRxNSdu	<p>If the SOMEIP-TP-CONNECTION refers to a PDU that the imported ECU-INSTANCE receives, one SomeIpTpRxNSdu sub container is created. Its name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>SomeIpTpRxSduRef is set to reference the configuration container of the PDU in the EcuC module configuration.</p>
SomeIpTp/SomeIpTpChannel/SomeIpTpRxNSdu/SomeIpTpRxNPdu	<p>One SomeIpTpRxNPdu is created if the SOMEIP-TP-CONNECTION refers via TRANSPORT-PDU-REF to a PDU for which the following conditions hold:</p> <ul style="list-style-type: none"> <li>▶ The referenced PDU is of type GENERAL-PURPOSE-I-PDU</li> <li>▶ The CATEGORY field of the PDU is set to SOMEIP_SEGMENTED_IPDU</li> <li>▶ The imported ECU-INSTANCE receives the PDU</li> </ul> <p>SomeIpTpRxNPduRef is set to reference the configuration container of the PDU in the EcuC module configuration.</p>
SomeIpTp/SomeIpTpChannel/SomeIpTpTxNSdu	<p>If the SOMEIP-TP-CONNECTION refers to a PDU that the imported ECU-INSTANCE sends, one SomeIpTpTxNSdu sub container is created. Its name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the PDU.</p> <p>SomeIpTpTxNSduRef is set to reference the configuration container of the PDU in the EcuC module configuration.</p>
SomeIpTp/SomeIpTpChannel/SomeIpTpRxNSdu/SomeIpTpRxNPdu	<p>One SomeIpTpRxNPdu is created if the SOMEIP-TP-CONNECTION refers via TRANSPORT-PDU-REF to a PDU for which the following conditions hold:</p> <ul style="list-style-type: none"> <li>▶ The referenced PDU is of type GENERAL-PURPOSE-I-PDU</li> <li>▶ The CATEGORY field of the PDU is set to SOMEIP_SEGMENTED_IPDU</li> <li>▶ The imported ECU-INSTANCE sends the PDU</li> </ul> <p>SomeIpTpTxNPduRef is set to reference the configuration container of the PDU in the EcuC module configuration.</p>

### 3.4.39. StbM

Configuration parameters	Mapping description
StbMSynchronizedTimeBase	<p>One <code>StbMSynchronizedTimeBase</code> container is created for each <code>GLOBAL-TIME-DOMAIN</code> that fulfills the following conditions:</p> <ul style="list-style-type: none"> <li>▶ The imported <code>ECU-INSTANCE</code> belongs to the <code>GLOBAL-TIME-DOMAIN</code>.</li> <li>▶ The <code>GLOBAL-TIME-DOMAIN</code> does not belong to a parent <code>GLOBAL-TIME-DOMAIN</code> to which the imported <code>ECU-INSTANCE</code> belongs as well.</li> </ul> <p>The imported <code>ECU-INSTANCE</code> belongs to a <code>GLOBAL-TIME-DOMAIN</code> in the following cases:</p> <ul style="list-style-type: none"> <li>▶ The <code>GLOBAL-TIME-MASTER</code> of the <code>GLOBAL-TIME-DOMAIN</code> references a <code>COMMUNICATION-CONNECTOR</code> of the imported <code>ECU-INSTANCE</code></li> <li>▶ One of the <code>GLOBAL-TIME-SLAVE</code> elements of the <code>GLOBAL-TIME-DOMAIN</code> references a <code>COMMUNICATION-CONNECTOR</code> of the imported <code>ECU-INSTANCE</code></li> <li>▶ The <code>GLOBAL-TIME-DOMAIN</code> is considered a parent <code>GLOBAL-TIME-DOMAIN</code> of a <code>GLOBAL-TIME-DOMAIN</code> of the imported <code>ECU-INSTANCE</code></li> </ul> <p>A <code>GLOBAL-TIME-DOMAIN gtp</code> is considered to be the parent <code>GLOBAL-TIME-DOMAIN</code> of a <code>GLOBAL-TIME-DOMAIN gts</code> in the following cases:</p> <ul style="list-style-type: none"> <li>▶ <code>gts</code> contains a <code>GLOBAL-TIME-GATEWAY</code> which references a <code>GLOBAL-TIME-MASTER</code> contained in <code>gts</code> and a <code>GLOBAL-TIME-SLAVE</code> contained in <code>gtp</code>.</li> <li>▶ <code>gts</code> either contains a <code>GLOBAL-TIME-MASTER</code> or <code>GLOBAL-TIME-SLAVE</code>, and <code>gtp</code> neither contains a <code>GLOBAL-TIME-MASTER</code> nor any <code>GLOBAL-TIME-SLAVE</code>, but references <code>gts</code> in <code>SUB-DOMAIN-REFS</code>.</li> </ul> <p>The name of an imported <code>StbMSynchronizedTimeBase</code> container is <code>&lt;PREFIX&gt;&lt;name&gt;</code>, where <code>&lt;name&gt;</code> is the <code>SHORT-NAME</code> of the <code>GLOBAL-TIME-DOMAIN</code>.</p> <p><code>StbMSynchronizedTimeBaseIdentifier</code> is set to <code>DOMAIN-ID</code>.</p> <p><code>StbMSyncLossTimeout</code> is set to <code>SYNC-LOSS-TIMEOUT</code>.</p> <p><code>StbMTimeLeapFutureThreshold</code> is set to <code>TIME-LEAP-FUTURE-THRESHOLD</code>.</p> <p><code>StbMTimeLeapPastThreshold</code> is set to <code>TIME-LEAP-PAST-THRESHOLD</code>.</p>

Configuration parameters	Mapping description
	<p>StbMClearTimeleapCount is set to TIME-LEAP-HEALING-COUNTER.</p> <p>For the configuration of StbMIsSystemWideGlobalTimeMaster, all GLOBAL-TIME-MASTER elements of the GLOBAL-TIME-DOMAIN are retrieved. If the GLOBAL-TIME-DOMAIN is <i>abstract</i>, i.e. it does not reference a GLOBAL-TIME-MASTER and no GLOBAL-TIME-SLAVE, the GLOBAL-TIME-MASTER elements that reference a COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE of all GLOBAL-TIME-DOMAIN elements that are referenced via SUB-DO-MAIN-REF are collected.</p> <p>If the GLOBAL-TIME-DOMAIN is not <i>abstract</i>, the GLOBAL-TIME-MASTER in GLOBAL-TIME-DOMAIN/MASTER is collected if it references a COMMUNI-CATION-CONNECTOR of the imported ECU-INSTANCE.</p> <p>If no GLOBAL-TIME-MASTER was retrieved in the previous step, false is con-figured. If all retrieved GLOBAL-TIME-MASTER elements yield the same IS-SYSTEM-WIDE-GLOBAL-TIME-MASTER value, that value is configured. Other-wise, nothing is configured.</p> <p>If OFFSET-TIME-DOMAIN-REF refers to a valid GLOBAL-TIME-DOMAIN, Stb-MOffsetTimeBase is configured to reference the StbMSynchronizedTime-Base container that has been created for that GLOBAL-TIME-DOMAIN.</p>
StbMSynchronized-TimeBase/StbM-TimeCorrection	<p>If the GLOBAL-TIME-DOMAIN contains a GLOBAL-TIME-CORRECTION-PROPS, then a StbMTimeCorrection container is created, and following parameters are set:</p> <p>StbMOffsetCorrectionAdaptionInterval is set to OFFSET-CORREC-TION-ADAPTION-INTERVAL.</p> <p>StbMOffsetCorrectionJumpThreshold is set to OFFSET-CORREC-TION-JUMP-THRESHOLD.</p> <p>StbMRateCorrectionMeasurementDuration is set to RATE-CORREC-TION-MEASUREMENT-DURATION.</p> <p>StbMRateCorrectionsPerMeasurementDuration is set to RATE-COR-RECTIONS-PER-MEASUREMENT-DURATION.</p>

### 3.4.40. TcpIp

Configuration parameters	Mapping description
TcpIpConfig/TcpIpCtrl	<p>For every <i>virtual</i> ETHERNET-COMMUNICATION-CONTROLLER of the imported ECU-INSTANCE (see <a href="#">Section 3.4.15, “EthIf”</a>), a TcpIpCtrl container is created. The container name is &lt;PREFIX&gt;&lt;name_cc&gt;_&lt;name_chn&gt;, where &lt;name_cc&gt; is the SHORT-NAME of the ETHERNET-COMMUNICATION-CONTROLLER and &lt;name_chn&gt; is the SHORT-NAME of the ETHERNET-PHYSICAL-CHANNEL.</p> <p>TcpIpEthIfCtrlRef references the container created for this <i>virtual</i> ETHERNET-COMMUNICATION-CONTROLLER in the EthIf module.</p> <p>TcpIpIpFramePrioDefault is set to the value of DEFAULT-PRIORITY of the VLAN-MEMBERSHIP belonging to the ETHERNET-PHYSICAL-CHANNEL of the ETHERNET-COMMUNICATION-CONTROLLER. A VLAN-MEMBERSHIP belongs to an ETHERNET-PHYSICAL-CHANNEL if it references this ETHERNET-PHYSICAL-CHANNEL and is aggregated by a COUPLING-PORT of the ETHERNET-COMMUNICATION-CONTROLLER. If DEFAULT-PRIORITY is not available, TcpIpIpFramePrioDefault is set to 0</p>
TcpIpConfig/TcpIpIpConfig/TcpIpIpFragmentationConfig	<p>If at least one PDU that is sent or received via Udp needs fragmentation, i.e. its payload length plus the length of the Udp header plus the length of the IP header exceeds the MTU size of the sending or receiving EthernetCommunicationController, a container TcpIpIpConfig and a subcontainer TcpIpIpFragmentationConfig is created in TcpIpConfig. If any of the PDUs exceeding the MTU size is received, TcpIpIpFragmentationRxEnabled is set to true. If any of the PDUs exceeding the MTU size is sent, TcpIpIpFragmentationTxEnabled is set to OUTFORDER.</p>
TcpIpConfig/TcpIpTcpConfig	<p>If there is at least one SOCKET-ADDRESS element which represents a local IP port of the imported ECU-INSTANCE and which contains a TP-CONFIGURATION/TCP-TP element in its APPLICATION-ENDPOINT which in turn contains at least one of the parameters</p> <ul style="list-style-type: none"> <li>▶ KEEP-ALIVE-INTERVAL</li> <li>▶ KEEP-ALIVE-PROBES-MAX</li> <li>▶ KEEP-ALIVE-TIME</li> </ul> <p>or has its KEEP-ALIVE parameter set to true then the parameter TcpIpTcpKeepAliveEnabled is set to true.</p>

Configuration parameters	Mapping description
TcpIpConfig/TcpIpLocalAddr	<p>A NETWORK-ENDPOINT is considered to be configured at runtime in one of the following situations:</p> <ul style="list-style-type: none"> <li>▶ The IPV-4-CONFIGURATION of the NETWORK-ENDPOINT has its IPV-4-ADDRESS-SOURCE set to a value other than FIXED.</li> <li>▶ The IPV-6-CONFIGURATION of the NETWORK-ENDPOINT has its IPV-6-ADDRESS-SOURCE set to a value other than FIXED.</li> <li>▶ The NETWORK-ENDPOINT represents a multicast address that is configured at runtime.</li> </ul> <p>In all other cases, a NETWORK-ENDPOINT is considered to be configured at configuration time.</p> <p>A NETWORK-ENDPOINT represents a multicast address that is configured at runtime if either its IPV-4-ADDRESS or its IPV-6-ADDRESS is a multicast address and there exists a SOCKET-CONNECTION which has RUNTIME-IP-ADDRESS-CONFIGURATION set to SD and if the imported ECU-INSTANCE acts as a client for the SOCKET-CONNECTION. The imported ECU-INSTANCE acts as a client for the SOCKET-CONNECTION if the following conditions are met:</p> <ul style="list-style-type: none"> <li>▶ The SOCKET-CONNECTION references an ETHERNET-COMMUNICATION-CONNECTOR of the imported ECU-INSTANCE via CLIENT-PORT-REF -&gt; SOCKET-ADDRESS -&gt; CONNECTOR-REF.</li> <li>▶ The SOCKET-CONNECTION-IPDU-IDENTIFIER elements that are either aggregated by the SOCKET-CONNECTION or by the SOCKET-CONNECTION-BUNDLE of the SOCKET-CONNECTION reference PDUs that are also sent, received, or routed by the imported ECU-INSTANCE. For further information about routing see <a href="#">Section 3.3.5, "PDU routing"</a>.</li> </ul> <p>A SOCKET-CONNECTION-IPDU-IDENTIFIER references PDUs either directly via PDU-REF or indirectly via PDU-TRIGGERING-REF.</p> <p>Every NETWORK-ENDPOINT which is referenced by a ETHERNET-COMMUNICATION-CONNECTOR of a <i>virtual</i> ETHERNET-COMMUNICATION-CONTROLLER is taken as input for the creation of TcpIpLocalAddr containers. For further information about ETHERNET-COMMUNICATION-CONTROLLER, see <a href="#">Section 3.4.15, "EthIf"</a>.</p> <p>If a NETWORK-ENDPOINT is considered to be configured at configuration time, one TcpIpLocalAddr is created for it. The container name is</p>

Configuration parameters	Mapping description
	<p>&lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the NETWORK-ENDPOINT.</p> <p>If a NETWORK-ENDPOINT is considered to be configured at run-time, one TcpIpLocalAddr container is created for each SOCKET-CONNECTION or SOCKET-CONNECTION-BUNDLE that references the NETWORK-ENDPOINT via CLIENT-PORT-REF or SERVER-PORT-REF. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;socket_name&gt;, where &lt;name&gt; is the SHORT-NAME of the NETWORK-ENDPOINT and &lt;socket_name&gt; is the SHORT-NAME of the SOCKET-CONNECTION or SOCKET-CONNECTION-BUNDLE.</p> <p>TcpIpCtrlRef references the TcpIpCtrl container created for the <i>virtual</i> ETHERNET-COMMUNICATION-CONTROLLER.</p> <p>The following parameters are configured using either the first IPV-4-CONFIGURATION which has IPV-4-ADDRESS-SOURCE set to FIXED or the first IPV-6-CONFIGURATION which has IPV-6-ADDRESS-SOURCE set to FIXED:</p> <p>TcpIpDomainType is set to TCPIP_AF_INET if NETWORK-ENDPOINT/NETWORK-ENDPOINT-ADDRESSES contains at least one IPV-4-CONFIGURATION entry and no IPV-6-CONFIGURATION entries. It is set to TCPIP_AF_INET6 if NETWORK-ENDPOINT/NETWORK-ENDPOINT-ADDRESSES contains at least one IPV-6-CONFIGURATION entry and no IPV-4-CONFIGURATION entries.</p> <p>TcpIpAddressType is set to TCPIP_MULTICAST if IPV-4-ADDRESS or IPV-6-ADDRESS represents a multicast address, otherwise TcpIpAddressType is set to TCPIP_UNICAST.</p>
TcpIpConfig/TcpIpLocalAddr/TcpIpStaticIpAddressConfig	<p>This container is only configured for NETWORK-ENDPOINT elements that do not represent multicast addresses that are configured at runtime.</p> <p>TcpIpStaticIpAddress is set to ANY if the NETWORK-ENDPOINT is a multicast address which is configured at run-time, or to IPV-4-ADDRESS, respectively IPV-6-ADDRESS in all other cases.</p> <p>If TcpIpAddressType is set to TCPIP_MULTICAST, TcpIpNetmask is not configured. Otherwise it is either set to the content of IPV-4-CONFIGURATION/NETWORK-MASK converted to the <i>Classless Inter-Domain Routing (CIDR)</i> notation, or to IPV-6-CONFIGURATION/IP-ADDRESS-PREFIX-LENGTH which is already provided in CIDR notation.</p> <p>If TcpIpAddressType is set to TCPIP_MULTICAST, TcpIpDefaultRouter is not configured. Otherwise the value of IPV-4-CONFIGURATION/DE-</p>



Configuration parameters	Mapping description
	<p>FAULT-GATEWAY or IPV-6-CONFIGURATION/DEFAULT-ROUTER is retrieved. If that value does not equal ANY, it is used to configure TcpIpDefaultRouter.</p>
<p>TcpIpConfig/TcpIpLocalAddr/TcpIpAddrAssignment</p>	<p>For every element in the list of IPV-4-CONFIGURATION/IPV-4-ADDRESS-SOURCE entries respectively for every element in the list of IPV-6-CONFIGURATION/IPV-6-ADDRESS-SOURCE entries of the NETWORK-END-POINT a TcpIpAddrAssignment container is created. The container name is TcpIpAddrAssignment_&lt;assignmentMethod&gt;, where &lt;assignmentMethod&gt; depends on the value of IPV-4-ADDRESS-SOURCE or IPV-6-ADDRESS-SOURCE:</p> <ul style="list-style-type: none"> <li>▶ TCPIP_LINKLOCAL for AUTO-IP or LINK-LOCAL</li> <li>▶ TCPIP_LINKLOCAL_DOIP for AUTO-IP--DOIP or LINK-LOCAL--DOIP</li> <li>▶ TCPIP_DHCP for DHCPV-4 or DHCPV-6</li> <li>▶ TCPIP_STATIC for FIXED</li> <li>▶ TCPIP_IPV6_ROUTER for ROUTER-ADVERTISEMENT</li> </ul> <p>If IPV-4-ADDRESS-SOURCE is set to AUTO-IPDHCPV-4, two TcpIpAddrAssignment containers are created, one for AUTO-IP and one for DHCPV-4.</p> <p>TcpIpAssignmentMethod is set to &lt;assignmentMethod&gt;.</p> <p>If IPV-4-ADDRESS-SOURCE or IPV-6-ADDRESS-SOURCE contains a valid value other than AUTO-IPDHCPV-4, TcpIpAssignmentPriority is set to ASSIGNMENT-PRIORITY.</p> <p>TcpIpAssignmentTrigger is set to TCPIP_MANUAL if TcpIpStaticIpAddress is set to ANY.</p> <p>For NETWORK-ENDPOINT elements that do not contain any IPV-4-ADDRESS-SOURCE or any IPV-6-ADDRESS-SOURCE but represent a multicast address which is configured at runtime, one default TcpIpAddrAssignment container is created. Its name is TcpIpAddrAssignment_MANUAL. TcpIpAssignmentMethod is set to TCPIP_STATIC and TcpIpAssignmentTrigger is set to TCPIP_MANUAL.</p>

### 3.4.41. UdpNm

Configuration parameters	Mapping description
UdpNmGlobalConfig	<p>UdpNmComUserDataSupport is set to true if UdpNmRxUserDataPduRef or UdpNmTxUserDataPduRef is set for any UdpNmChannelConfig or if any UDP-NM-CLUSTER linked to the imported ECU-INSTANCE has its NM-PNC-PARTICIPATION either not defined or set to true. Otherwise UdpNmComUserDataSupport is set to false.</p> <p>UdpNmPnResetTime is set to PN-RESET-TIME of the configured ECU-INSTANCE.</p> <p>The following parameters are set using the first NM-ECU of the imported ECU-INSTANCE:</p> <p>UdpNmUserDataEnabled is set to NM-USER-DATA-ENABLED.</p> <p>UdpNmRemoteSleepIndEnabled is set to NM-REMOTE-SLEEP-IND-ENABLED.</p> <p>UdpNmBusSynchronizationEnabled is set to NM-BUS-SYNCHRONIZATION-ENABLED.</p> <p>UdpNmStateChangeIndEnabled is set to NM-STATE-CHANGE-IND-ENABLED.</p> <p>UdpNmPassiveModeEnabled: see <a href="#">Section 3.4.4, "CanNm"</a>, CanNmPassiveModeEnabled.</p> <p>UdpNmPduRxIndicationEnabled is set to NM-PDU-RX-INDICATION-ENABLED.</p> <p>UdpNmComControlEnabled is set to NM-COM-CONTROL-ENABLED.</p> <p>UdpNmMainFunctionPeriod is set to NM-CYCLETIME-MAIN-FUNCTION.</p> <p>UdpNmComMNetworkHandleRef references the ComMChannel container that is created for the COMMUNICATION-CLUSTER referenced in COMMUNICATION-CLUSTER-REF.</p> <p>If inconsistencies are detected among parameters of multiple NM-ECU elements, a warning is reported.</p> <p>The following parameters are set using the first UDP-NM-CLUSTER-COUPLING of all UDP-NM-CLUSTER elements connected to the imported ECU-INSTANCE:</p>

Configuration parameters	Mapping description
	<p>If inconsistencies are detected among parameters of multiple UDP-NM-CLUSTER-COUPLING elements, a warning is reported.</p> <p>If a UDP-NM-CLUSTER configured as partial networking cluster (PNC) (see <a href="#">Section 3.4.13, “EcuC”</a>) belongs to the imported ECU-INSTANCE, the following parameters are set:</p> <p>UdpNmPnEiraRxNSduRef references the corresponding container in the EcuC module configuration.</p> <p>UdpNmPnEiraCalcEnabled is set to true.</p> <p>UdpNmPnInfo/UdpNmPnInfoOffset is set to PNC-VECTOR-OFFSET. If PNC-VECTOR-OFFSET is not defined, a warning is issued and UdpNmPnInfoOffset is not set.</p> <p>UdpNmPnInfo/UdpNmPnInfoLength is set to PNC-VECTOR-LENGTH. If PNC-VECTOR-LENGTH is not defined, a warning is issued and UdpNmPnInfoLength is not set.</p> <p>For the configuration of UdpNmPnFilterMaskByte all PNC-FILTER-DATA-MASK values of the ETHERNET-COMMUNICATION-CONNECTOR elements of the configured ECU-INSTANCE are taken as input. The configuration algorithm is the same as described for CanNmPnFilterMaskByte in <a href="#">Section 3.4.4, “Can-Nm”</a>.</p>
UdpNmChannelConfig	<p>For every ETHERNET-PHYSICAL-CHANNEL for which the following conditions hold, one UdpNmChannelConfig container is created.</p> <ul style="list-style-type: none"> <li>▶ The imported ECU-INSTANCE sends or receives at least one NM-PDU on the ETHERNET-PHYSICAL-CHANNEL.</li> <li>▶ A UDP-NM-CLUSTER which belongs to the imported ECU-INSTANCE references the ETHERNET-PHYSICAL-CHANNEL either directly via VLAN-REF or it references the ETHERNET-CLUSTER that contains the ETHERNET-PHYSICAL-CHANNEL.</li> </ul> <p>The container name is &lt;PREFIX&gt;&lt;name&gt;, where &lt;name&gt; is the SHORT-NAME of the ETHERNET-PHYSICAL-CHANNEL.</p> <p>A UDP-NM-CLUSTER belongs to the imported ECU-INSTANCE if at least one of its UDP-NM-NODE elements references an ETHERNET-COMMUNICATION-CONTROLLER of this ECU-INSTANCE.</p>

Configuration parameters	Mapping description
	<p>The NM-ECU used for configuring some of the <code>UdpNmChannelConfig</code> parameters is the NM-ECU which the first UDP-NM-NODE references via NM-IF-ECU-REF.</p> <p><code>UdpNmNodeDetectionEnabled</code> is set to NM-CLUSTER/NM-NODE-DETECTION-ENABLED, or to NM-ECU/NM-NODE-DETECTION-ENABLED if NM-CLUSTER/NM-NODE-DETECTION-ENABLED is not available.</p> <p><code>UdpNmRepeatMsgIndEnabled</code> is set to NM-CLUSTER/NM-REPEAT-MSG-IND-ENABLED, or to NM-ECU/NM-REPEAT-MSG-IND-ENABLED if NM-CLUSTER/NM-REPEAT-MSG-IND-ENABLED is not available.</p> <p><code>UdpNmNodeIdEnabled</code> is set to NM-CLUSTER/NM-NODE-ID-ENABLED, or to NM-ECU/NM-NODE-ID-ENABLED if NM-CLUSTER/NM-NODE-ID-ENABLED is not available.</p> <p><code>UdpNmTimeoutTime</code> is set to NM-NETWORK-TIMEOUT.</p> <p><code>UdpNmWaitBusSleepTime</code> is set to NM-WAIT-BUS-SLEEP-TIME.</p> <p><code>UdpNmRepeatMessageTime</code> is set to NM-REPEAT-MESSAGE-TIME.</p> <p><code>UdpNmRemoteSleepIndTime</code> is set to NM-REMOTE-SLEEP-INDICATION-TIME.</p> <p><code>UdpNmMsgCycleTime</code> is set to NM-MSG-CYCLE-TIME.</p> <p><code>UdpNmMsgTimeoutTime</code> is set to NM-MESSAGE-TIMEOUT-TIME.</p> <p><code>UdpNmImmediateNmCycleTime</code> is set to NM-IMMEDIATE-NM-CYCLE-TIME.</p> <p><code>UdpNmImmediateNmTransmissions</code> is set to NM-IMMEDIATE-NM-TRANSMISSIONS.</p> <p><code>UdpNmPduNidPosition</code> is set depending on the value of NM-NID-POSITION:</p> <ul style="list-style-type: none"> <li>▶ UDPNM_PDU_BYTE_0 for 0.</li> <li>▶ UDPNM_PDU_BYTE_1 for 1.</li> <li>▶ UDPNM_PDU_OFF for any other value.</li> </ul> <p><code>UdpNmPduCbvPosition</code> is set depending on the value of NM-CBV-POSITION:</p> <ul style="list-style-type: none"> <li>▶ UDPNM_PDU_BYTE_0 for 0.</li> <li>▶ UDPNM_PDU_BYTE_1 for 1.</li> </ul>

Configuration parameters	Mapping description
	<p>► UDPNM_PDU_OFF for any other value.</p> <p>UdpNmRxPdu/&lt;EcuC container name&gt;/UdpNmRxPduRef references the container in the EcuC module which has been created for the Rx NM-PDU. The Rx NM-PDU is the first NM-PDU that is transmitted on the ETHERNET-PHYSICAL-CHANNEL and that is referenced via RX-NM-PDU-REFS/RX-NM-PDU-REF of the NM-NODE associated with the ETHERNET-PHYSICAL-CHANNEL. The NM-NODE associated with an ETHERNET-PHYSICAL-CHANNEL is the first NM-NODE that receives an NM-PDU on the ETHERNET-PHYSICAL-CHANNEL. &lt;EcuC container name&gt; is the name of the referenced EcuC container. If no Rx NM-PDU is available, a warning is reported.</p> <p>If an NmUserDataPdu container has been created for the NM-PDU in the EcuC module configuration, UdpNmUserDataRxPdu/UdpNmRxUserDataPduRef references this container. The name of UdpNmUserDataRxPdu is set to the name of the referenced EcuC container.</p> <p>UdpNmTxPdu/UdpNmTxPduRef references the container in the EcuC module which has been created for the Tx NM-PDU. The Tx NM-PDU is the first NM-PDU that is transmitted on the ETHERNET-PHYSICAL-CHANNEL and that is referenced via TX-NM-PDU-REFS/TX-NM-PDU-REF of the NM-NODE associated with the ETHERNET-PHYSICAL-CHANNEL. The name of UdpNmTxPdu is set to the name of the referenced EcuC container.</p> <p>If an NmUserDataPdu container has been created for the NM-PDU in the EcuC module configuration, UdpNmUserDataTxPdu/UdpNmTxUserDataPduRef references this container. The name of UdpNmUserDataTxPdu is set to the name of the referenced EcuC container.</p> <p>The following parameters are set using the first NM-NODE of the UDP-NM-CLUSTER connected to the imported ECU-INSTANCE. If inconsistencies are detected among parameters of multiple NM-NODE elements, a warning is reported.</p> <p>UdpNmMsgCycleOffset is set to NM-MSG-CYCLE-OFFSET.</p> <p>UdpNmNodeId is set to NM-NODE-ID.</p> <p>The configuration of PNC-related parameters is done in analogy to the configuration of the PNC-related CanNm parameters, see <a href="#">Section 3.4.4, “CanNm”</a>. The parameters and configuration containers obtain the prefix UdpNmPn. UdpNmPn-FilterMaskByte is not configured.</p>

### 3.4.42. Xcp

Configuration parameters	Mapping description
Xcp/XcpConfig/XcpPdu/XcpTxPdu	<p>For every GENERAL-PURPOSE-I-PDU that the imported ECU-INSTANCE sends without routing it (see <a href="#">Section 3.3.5, “PDU routing”</a>) and which has its CATEGORY field set to XCP, a XcpTxPdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the GENERAL-PURPOSE-I-PDU.</p> <p>XcpTxPdu/XcpTxPduRef is set to reference the configuration container of the GENERAL-PURPOSE-I-PDU in the EcuC module configuration.</p>
Xcp/XcpConfig/XcpPdu/XcpRxPdu	<p>For every GENERAL-PURPOSE-I-PDU that the imported ECU-INSTANCE receives without routing it (see <a href="#">Section 3.3.5, “PDU routing”</a>) and which has its CATEGORY field set to XCP, a XcpRxPdu container is created. The container name is &lt;PREFIX&gt;&lt;name&gt;&lt;INSTSUFFIX&gt;, where &lt;name&gt; is the SHORT-NAME of the GENERAL-PURPOSE-I-PDU.</p> <p>XcpRxPdu/XcpRxPduRef is set to reference the configuration container of the GENERAL-PURPOSE-I-PDU in the EcuC module configuration.</p>

## 4. Bibliography

### Bibliography

- [1] *AUTOSAR System Template*, Issue Version 4.2.0, Release 4.0, Revision 3, Publisher: AUTOSAR
- [2] *LIN Specification Package Revision 2.0*, Publish date: September 23, 2003, Publisher: LIN Consortium
- [3] *AUTOSAR System Template*, Issue Version 4.6.0, Release 4.2, Revision 2, Publisher: AUTOSAR
- [4] *AUTOSAR System Template*, Issue AUTOSAR CP Release 4.3.0, Publisher: AUTOSAR