




4. Quick Start

- 1) In waiting state, Press " +30" " to start cooking with 100% power, each added press will increase 30 seconds cooking time up to 95 minutes.
- 2) In microwave, grill, combi. cooking or time defrost state, each press of

second " +30" "

- 3) In waiting state, turn " " anti-clockwise to set cooking time with 100% microwave power, then press " +30" " to start cooking.



5. Defrost By Weight


- 1) Press " |  " once, and the oven will display "dEF1".

- 2) Turn " " to select the weight of food from 100 to 2000 g.

- 3) Press " +30" " to start defrosting.


6. Defrost By Time

- 1) Press " |  " twice, and the oven will display "dEF2".


- 2) Turn " " to select the defrost time.

- 3) Press " +30" " to start defrosting.

7. Auto Menu


- 1) Turn " " right to choose the menu, and "A-1" to "A-10" will display, which means pizza, potato, meat, fish, vegetable, beverage, pasta, popcorn, chicken and reheat.


- 2) Press " +30" " to confirm.


- 3) Turn " " to choose the default weight as the menu chart.

- 4) Press " +30" " to start cooking.

Example: If you want to use "Auto Menu" to cook fish for 350g.

- 1) Turn " " clockwise till "A-4" display.

- 2) Press " +30" " to confirm.

- 3) Turn " " to select the weight of fish till "350" display.

- 4) Press " +30" " to start cooking.

