

# **Quick Start Guide for ETSI Adaptivity and Carrier Sensing Test ver. 1.0.1**

## **Contents**

<b>Release History.....</b>	<b>2</b>
<b>1. Introduction.....</b>	<b>3</b>
<b>2. Driver configuration .....</b>	<b>3</b>
<b>3. Driver configuration – disable (default setting) .....</b>	<b>3</b>
<b>4. Driver configuration – enable for ETSI Adaptivity test.....</b>	<b>4</b>
<b>5. Driver configuration – enable for Carrier Sense test .....</b>	<b>4</b>

### Release History

1.0.0	2014/09/26	1. Add documentation for ADAPTIVITY_VERSION 7.0, 7.1, 7.2
1.0.1	2018/09/28	2. Add periodic idle time declaration.

Realtek

## 1. Introduction

Realtek Wi-Fi solutions support both ETSI Adaptivity test and Carrier Sense test. This document describes ways to configure Wi-Fi driver for the corresponding test and simple debug methods.

The test item "periodic idle time" can be skipped by a declaration document from chip vendor. Please get the document from chip vendor for Certification Lab reference **Before** starting test.

According to the test requirement, the Wi-Fi performance will drop at interfering environment. Please enable this function only when you really need it.

## 2. Driver configuration

There are 2 configuration arguments in Makefile to control:

- **CONFIG\_RTW\_ADAPTIVITY\_EN**
  - **disable**  
Disable adaptivity function
  - **enable**  
Enable adaptivity function
- **CONFIG\_RTW\_ADAPTIVITY\_MODE**
  - **normal**  
For ETSI adaptivity test
  - **carrier\_sense**  
For carrier sense test

## 3. Driver configuration – disable (default setting)

To disable Realtek adaptivity function (also the default setting of these 2 configuration arguments):

```
CONFIG_RTW_ADAPTIVITY_EN = disable
CONFIG_RTW_ADAPTIVITY_MODE = normal
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
ADAPTIVITY_VERSION 7.2
RTW_ADAPTIVITY_EN_DISABLE
RTW_ADAPTIVITY_MODE_NORMAL
RTW_ADAPTIVITY_DML_DISABLE
TH_L2H_ini TH_EDCCA_HL_diff IGI_Base ForceEDCCA AdapEn_RSSI IGI_LowerBound
0xf5      7      0x32      0      20      0
```

#### 4. Driver configuration – enable for ETSI Adaptivity test

If your product needs to fit the requirement of ETSI Adaptivity test:

```
CONFIG_RTW_ADAPTIVITY_EN = enable
CONFIG_RTW_ADAPTIVITY_MODE = normal
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
ADAPTIVITY_VERSION 7.1
RTW_ADAPTIVITY_EN_ENABLE
RTW_ADAPTIVITY_MODE_NORMAL
RTW_ADAPTIVITY_DML_DISABLE
TH_L2H_ini TH_EDCCA_HL_diff IGI_Base ForceEDCCA AdapEn_RSSI IGI_LowerBound
0xf5      7      0x32      0      20      0
```

#### 5. Driver configuration – enable for Carrier Sense test

If your product needs to fit the requirement of Carrier Sense test:

```
CONFIG_RTW_ADAPTIVITY_EN = enable
CONFIG_RTW_ADAPTIVITY_MODE = carrier_sense
```

Check the configuration arguments through driver's proc interface at runtime:

```
# cat /proc/net/rtl8723bs/wlan0/odm/adaptivity
```

```
ADAPTIVITY_VERSION 7.1
```

```
RTW_ADAPTIVITY_EN_ENABLE
```

```
RTW_ADAPTIVITY_MODE_CARRIER_SENSE
```

```
RTW_ADAPTIVITY_DML_DISABLE
```

```
TH_L2H_ini TH_EDCCA_HL_diff IGI_Base ForceEDCCA AdapEn_RSSI IGI_LowerBound
```

```
0xf5
```

```
7
```

```
0x32
```

```
0
```

```
20
```

```
0
```

Realtek