

**Partner: Biamp**  
**Model: Tesira**  
**Device Type: Digital Signal Processor**



## GENERAL INFORMATION

<b>SIMPLWINDOWS NAME:</b>	Biamp Tesira Dialer Control v1.5
<b>CATEGORY:</b>	Mixer
<b>VERSION:</b>	1.5
<b>SUMMARY:</b>	This module controls the Biamp Tesira TI Dialer and TI Control Status objects on the Biamp Tesira Server and Forte.
<b>GENERAL NOTES:</b>	<p>This module controls the Biamp Tesira TI Dialer and TI Control Status objects.</p> <p>In order to use this module you must assign two Instance Tags, Dialer_Instance_Tag and Control_Status_Instance_Tag. The Biamp Dialer control object provides functionality for Call and Directory Control, while Control Status provide for call status and incoming call features. Together they provide complete control. TI Receive and TI Transmit Level/Mute adjustment are supported by the Biamp Tesira Level Control v1.5 module and Biamp Tesira State Control v1.5 module.</p>
<b>CRESTRON HARDWARE REQUIRED:</b>	N/A
<b>SETUP OF CRESTRON HARDWARE:</b>	This module requires the Biamp Tesira Command Processor IP v1.5 or the Biamp Tesira Command Processor v1.5 modules in order to operate. Please read the help files associated with these modules for Crestron Hardware Setup.
<b>VENDOR FIRMWARE:</b>	Tesira Server - 2.3.0.24 Tesira Forte – 2.3.0.24

**Partner: Biamp**  
**Model: Tesira**  
**Device Type: Digital Signal Processor**

**PARAMETER:**

<b>Dialer_Instance_Tag</b>	Dialer_Instance_Tag is the unique name of the Biamp Tesira TI Dialer object you wish to control. <i>Note: If your Instance_Tag has spaces in its name, surround the name with quotes using the \x22 hex escape sequence. Example: \x22My Name\x22</i>
<b>Control_Status_Instance_Tag</b>	Control_Status_Instance_Tag is the unique name of the Biamp Tesira TI Control Status object you wish to control. <i>Note: If your Instance_Tag has spaces in its name, surround the name with quotes using the \x22 hex escape sequence. Example: \x22My Name\x22</i>
<b>Directory_Page_Size</b>	Directory_Page_Size can be a value from 1d to 16d. The values is used to determine the page size for the directory list.

**Partner: Biamp**  
**Model: Tesira**  
**Device Type: Digital Signal Processor**


**CONTROL:**

Poll_Dialer	D	Pulse to poll for items that are not handled by subscriptions. A subscription is a process of registering for unsolicited messages. Some Biamp Tesira Control objects have this capability.
On_Hook, Off_Hook, Toggle_Hook	D	Pulse to control Hook.
Answer	D	Pulse to answer call.
Flash	D	Pulse to perform Hook-Flash.
Redial	D	Pulse to redial last call.
Auto_Answer_On, Off, Toggle	D	Pulse to control Auto-Answer.
Get_Caller_ID_Basic	D	Pulse to request basic call ID information. Must have an active incoming call.
Get_Caller_ID_Full	D	Pulse to request full call ID information. Must have an active incoming call.
Keypad_0-9, Star, Pound	D	Pulse to enter digits 0-9, * and # to Keypad_Text for dialing. If there is an active call, DTMF tones will be transmitted automatically..
Keypad_Clear, BackSpace	D	Pulse to edit Keypad_Text.
Keypad_Dial	D	Pulse to Dial Keypad_Text.
Directory_Top_Page	D	Pulse to display the first entries in the directory. Quantity to display is set by the parameter Directory_Page_Size.
Directory_Previous_Page	D	Pulse to display the previous entries in the directory (Toward Top). Quantity to display is set by the parameter Directory_Page_Size.
Directory_Next_Page	D	Pulse to display the next entries in the directory (Toward Bottom). Quantity to display is set by the parameter Directory_Page_Size.
Directory_Bottom_Page	D	Pulse to display the bottom entries in the directory. Quantity to display is set by the parameter Directory_Page_Size and remaining items..
Select_Directory_Page_Item_*	D	Pulse to select a displayed directory item. Will assign directory item for display to Selected_Directory_Item_Name_Text and Select_Directory_Item_Num_Text.
Dial_Selected_Directory_Item	D	Pulse to dial directory entry displayed in Selected_Directory_Item_Name_Text and Select_Directory_Item_Num_Text.
Select_Directory_Save_Location	A	Setting this value will pick the location in the directory to edit an entry. Valid values are 1d through 16d.

**Partner: Biamp****Model: Tesira****Device Type: Digital Signal Processor**

Directory_Save_Name_Text	S	Setting this value will assign the display text of the directory item location assigned by Select_Directory_Save_Location. Save_Directory_Item must be pulsed in order to finalize the save.
Directory_Save_Num_Text	S	Setting this value will assign the phone number of the directory item location assigned by Select_Directory_Save_Location. Save_Directory_Item must be pulsed in order to finalize the save.
Save_Directory_Item	D	Pulse to save Directory_Save_Name_Text and Directory_Save_Num_Text to the directory item assigned by Select_Directory_Save_Location.
From_Processor	S	Serial data signal to be routed from one of the To_Module_* outputs on the Biamp Tesira Command Processor IP v1.5 module or the Biamp Tesira Command Processor v1.5 module.

**Partner: Biamp**  
**Model: Tesira**  
**Device Type: Digital Signal Processor**

**FEEDBACK:**

<b>Is_Initialized</b>	D	Signal is high to indicate the module has successfully received a response from its initializing queries.
<b>Is_On_Hook, Is_Off_Hook</b>	D	Indicates hook status.
<b>Is_Dialing</b>	D	Indicates dialing is in progress.
<b>Has_Incoming_Call</b>	D	Indicates incoming call.
<b>Last_Number_Dialed_Text</b>	S	Displays last number called.
<b>Auto_Answer_Is_On</b>	D	Indicates Auto-Answer is enabled.
<b>Auto_Answer_Is_Off</b>	D	Indicates Auto-Answer is disabled.
<b>Call_ID_Num_Text, Call_ID_Name_Text</b>	S	Displays caller ID information. Must pulse either Get_Caller_ID_Basic or Get_Caller_ID_Full during an incoming call in order to see the current values.
<b>Keypad_Text</b>	S	Displays the current entered telephone number.
<b>Directory_Page_Item_*_Text</b>	S	Displays the currently paged directory items. Directory_Page_Size sets how many items are displayed at a time.
<b>Selected_Directory_Item_Name_Text</b>	S	Displays the name of the currently selected directory item.
<b>Selected_Directory_Item_Num_Text</b>	S	Displays the phone number of the currently selected directory item.
<b>To_Processor</b>	S	Serial data signal to be sent to the From_Modules input on the Biamp Tesira Command Processor IP v1.5 or the Biamp Tesira Command Processor v1.5 modules.

**Partner: Biamp**  
**Model: Tesira**  
**Device Type: Digital Signal Processor**

**TESTING:**

<b>OPS USED FOR TESTING:</b>	PRO2: 4.008.0008 CP3: 1.010.0060
<b>SIMPL WINDOWS USED FOR TESTING:</b>	4.02.56
<b>CRES DB USED FOR TESTING:</b>	50.00.004.00
<b>DEVICE DATABASE:</b>	63.05.006.00
<b>SYMBOL LIBRARY USED FOR TESTING:</b>	933
<b>SAMPLE PROGRAM:</b>	Biamp Tesira IP v1.5 Demo CP3 Biamp Tesira IP v1.5 Demo PRO2 Biamp Tesira v1.5 Demo CP3 Biamp Tesira v1.5 Demo PRO2
<b>REVISION HISTORY:</b>	v1.0 – Initial Release v1.1 – Updated all of the control modules to unsubscribe prior to subscribing to fix RS232 initialization issues. Control modules have also been updated to disallow input control prior to control module being initialized. v1.2 – No revision performed. v1.3 – Added Crestron recommended updates to change the methods used for handling messages from the command processor to account for variations between 2 and 3 series processors. v1.4 – For RS232 control, replaced individual “unsubscribe” commands with a single “exit” command which unsubscribes from all messages. v1.5 – No revision performed.