

## **LENOVO YOGA WON'T TURN ON? BEST FIXES**

Lenovo Yoga is a line of laptop computers designed and marketed by Lenovo and known for its ability to fold backwards into tablet mode due to a special hinged screen. Your Lenovo Yoga won't turn on? Below are the probable causes and best fixes.

### **LENOVO YOGA WON'T TURN ON? POSSIBLE CAUSES**

- **Overheating**

Most laptop processors have an internal thermal function that shuts the laptop system down when it starts to overheat. The laptop won't start again until it cools down. A laptop that is not venting properly could have a faulty fan.

- **Faulty power cord**

It is possible that your laptops power cord has developed some breaks at a point, which could be disrupting the flow of electricity from the power outlet to the laptop.

- **Internal problems**

If your Lenovo Yoga won't turn on, it is possible that it could be due to some internal problems. A faulty or bad motherboard, faulty charging circuits, bad video card or a faulty RAM could be the reason your Lenovo Yoga won't turn on.

- **Faulty power connector and battery**

Laptop power connectors can become loose overtime and stop working, and it is possible that the battery has become bad and too old to function due to age.

- **Software problems**

Software applications like Microsoft and others can crash (malfunction) and cause your device to go off.

### **LENOVO YOGA WON'T TURN ON? BEST FIXES**

- **Check the power cord**

If your Lenovo Yoga power cord has any breaks, you would need to replace it. You can find a replacement online, at electronic retailers or by calling the manufacturing company.

- **Try power**

Plug the device to the power cord first. If that does not work, wait for about 10 minutes in case the battery needs to charge to a certain level.

- **Try a different power outlet**

If your Lenovo Yoga won't turn on, it could be due to a bad power outlet that the power cord is connected to. You should try connecting to a different power outlet to be sure that your power cord or laptop is not bad.

- **Connect to an external monitor**

If your Lenovo Yoga won't turn on, try connecting to an external monitor to test your display cables. Connect your device to an external monitor such as a TV using a HDMI cable, then restart your device. When your device reboots completely it should display on the TV. If not, try clicking the F4 key on your device keyboard to initiate a display on the TV.

- **Restart your device**

Restarting your device can really help in solving this problem. Try restarting your device without any external hardware like a mouse, keyboard or hard drive connected. If your device powers on, it is possible that the external hardware device connected was causing the device to not come on.

- **Hard reboot**

If your Lenovo Yoga won't come on, unplug the power adapter then press and hold the power button for about 20 seconds and try rebooting it up again.

- **Update the device software**

Old or outdated device software can cause your device to crash/malfunction. Update the versions of software installed on your device to help improve your device functionality, which will in turn help improve your device display problem.

- **Check for overheating**

If your Lenovo Yoga won't come on, check your device for overheating. If your device is overheating, you should let your device cool down before trying to turn your device on again. If you think your device isn't venting properly, you should take your device to the computer engineer to have a look at the vent fan.

- **Take your device to a professional**

If all the above options don't help in solving your problem, you can take your device to an experienced professional to have a look at your device, so you can know exactly what is wrong with your device.

## **WHY WON'T MY LENOVO YOGA TURN ON EVEN WHEN PLUGGED IN?**

Your Lenovo Yoga battery must have run down, and when you tried charging it, it did not come on. This could be due to the following reasons;

- **A bad or broken power cord**

Your Lenovo Yoga laptops power cord could be broken or there could be no current running through the wires. If this is the case, you would need to have it replaced.

- **Bad or loose power connectors**

If your Lenovo Yoga won't turn on, it is probably due to a bad or loose power connector. Power connectors can become loose sometimes and you would need to take your laptop to a computer engineer.

- **Bad battery**

When the battery of a laptop goes bad, it is probably because the device is old or the battery has gone faulty and it can cause the device to go off.

- **Internal problems**

If your Lenovo Yoga won't turn on, it could be due to internal problems that you cannot see or notice. Internal hardware parts like the mother board or video card could have gone faulty and cause the device to go off.

## **DOES THE LENOVO YOGA HAVE A RESET BUTTON?**

The Lenovo Yoga does have a reset button. It is usually on the left or right side of the power button and is called the Novo button. In order to reset your Lenovo Yoga laptop, follow the steps below:

- Power off your laptop first and then power it back on.
- Click the Novo button for a few seconds, you'll be directed to the Novo button menu.
- Select "System recovery" and click "Enter".
- In Step 1, select "Restore from initial backup" and click "Enter".
- Then click "Start" to begin factory reset.

## **HOW DO I RESTART MY LENOVO LAPTOP BLACK SCREEN?**

In order to restart your Lenovo laptop black screen, you should click the keys – Windows key + Ctrl key + Shift key + B key all at the same time. Release immediately. This should bring your display back and solve your black screen problem.

If none of the above tips help you in fixing your Lenovo Yoga device, you should contact Lenovo support.