
















HINT:

Use the table below to help determine the cause of problem symptoms. If multiple suspected areas are listed, the potential causes of the symptoms are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.

Symptom	Suspected Area	Link
Wander or pulls	Tires (worn or improperly inflated)	
	Wheel alignment (incorrect)	
	Steering linkage (loose or worn)	
	Hub bearings (loose or worn)	
	Steering gear (adjustment required or broken)	
	Suspension parts (worn out)	-
Front wheel shimmy	Tires (worn or improperly inflated)	
	Wheels (out of balance)	
	Shock absorber (worn out)	
	Wheel alignment (incorrect)	
	Hub bearings (loose or worn)	
	Steering linkage (loose or worn)	
	Steering gear (adjustment required or broken)	
Rear wheel shimmy	Tires (worn or improperly inflated)	
	Wheels (out of balance)	
	Shock absorber (worn out)	
	Axle shaft (loose or worn)	