

RoboSail Sensors data and Calculated Values

Values to Read In

Wind Vane (direction wind is coming from)

- US Digital MA3 Magnetic Encoder
- Data comes in 0-360°, set 0° = in irons, starboard wind is -180° and port wind is +180°
- Relative reading

Compass (direction boat is pointing)

- Data comes in 0 to 360°, expect North is 0° but we will orient sensor so East = 0°
- Adafruit LSM303 Accelerometer and Compass Breakout
- Absolute reading

GPS (location in latitude and longitude)

- starts as angle in degrees, we convert to radians, then to x, y (meters)
- Adafruit Ultimate GPS Breakout
- Absolute reading

Values to Calculate

Absolute Wind Direction (real direction wind is coming from)

- Set East = 0° range = -180° to +180°
- Data needed: Relative Wind Direction
- **Absolute** Wind Direction = **Absolute** Compass + **Relative** Wind Vane (see sketch)

Absolute Angle-to-Waypoint (direction from boat to destination)

- range is -180° to +180° or 0 to 360°
- Starting point is (x1, y1), destination waypoint is (x2, y2)
- Data needed: GPS location of boat and destination, or just difference
- **Absolute** Angle-to-Waypoint = $\arctan(y2 - y1 / x2 - x1)$

Relative Angle-to-Waypoint (angle boat must turn through to be heading at destination)

- range is -180° to +180° or 0 to 360°
- Data needed:
 - GPS location of boat and destination (or just difference)
 - Compass heading
- **Relative** Angle-to-Waypoint = **Absolute** Angle-to-Waypoint – **Absolute** Compass (see sketch)



