

[Pasos para habilitar dispositivos BT:](#)

[BlueALSA \(formerly know as BluezALSA\)](#)

[Comandos Bluetooth:](#)

[\\$ echo help | bluetoothctl](#)

[\\$ hcitool](#)

[\\$ hcitool con](#)

[--- PAIRING a BT Device:](#)

[--- PLAYING Text to speech:](#)

[--- PLAYING Internetradio:](#)

[--- ASOUNDRC for PLAYING](#)

[--- VOLUME](#)

[--- Ver los devices BT](#)

[--- AUTOCONNECT](#)

[--- CAPTURING](#)

[--- PARA VER SI UN DEVICE ESTÁ CONECTADO](#)

Pasos para habilitar dispositivos BT:

https://www.sigmdel.ca/michel/ha/rpi/bluetooth_01_en.html

1) Para que la RPI no pueda acceder a la SIM de un telefono paired, editar la siguiente línea de

```
/lib/systemd/system/bluetooth.service  
ExecStart=/usr/lib/bluetooth/bluetoothd --noplugin=sap
```

2) Añadir el usuario al grupo bluetooth

```
sudo adduser usuario bluetooth
```

3) Emparejar (pair), conectar (connect) y confiar (trust) en nuestro dispositivo.

```
$ bluetoothctl  
[NEW] Controller 00:1A:7D:DA:71:13 rpi2fir [default]  
[NEW] Device 54:E4:3A:1E:FC:92 iPhone  
[bluetooth]# agent on  
Agent registered  
[bluetooth]# scan on  
Discovery started  
[CHG] Controller 00:1A:7D:DA:71:13 Discovering: yes  
[CHG] Device 54:E4:3A:1E:FC:92 RSSI: -43
```

```
[bluetooth]# pair 54:E4:3A:1E:FC:92      ← Emparejar
Attempting to pair with 54:E4:3A:1E:FC:92
Failed to pair: org.bluez.Error.AlreadyExists ← Ya lo habíamos
emparejado ;-)
[bluetooth]# connect 54:E4:3A:1E:FC:92
Attempting to connect to 54:E4:3A:1E:FC:92 ← Conectar tb en el
teléfono
[CHG] Device 54:E4:3A:1E:FC:92 Connected: yes
[iPhone]# trust 54:E4:3A:1E:FC:92      ← Confiar
Changing 54:E4:3A:1E:FC:92 trust succeeded
[iPhone]# quit
Agent unregistered
[DEL] Controller 00:1A:7D:DA:71:13 rpi2fir [default]
$
```

BlueALSA (formerly know as BluezALSA)

<https://github.com/Arkq/bluez-alsa>

<https://forum.armbian.com/topic/6480-bluealsa-bluetooth-audio-using-alsa-not-pulseaudio/>

Se supone que tenemos BlueALSA as background task:
 bluealsa --disable-hfp &

Se entiende que el 'usuario' pertenece al grupo 'audio'

Final Note: Bluealsa and PulseAudio do not play well together. You will have to completely uninstall PulseAudio and all its baggage in order to use bluealsa. O por lo menos Bluetooth support has to be disabled in the PulseAudio, any Bluetooth related module has to be unloaded.

Note: Given your bluetooth device is a virtual device, it will not be listed when you run `aplay -l` or similar listing commands.

Comandos Bluetooth:

\$ echo help | bluetoothctl

```
[bluetooth]# help
Available commands:
  list                List available controllers
  show [ctrl]         Controller information
  select <ctrl>       Select default controller
  devices             List available devices
  paired-devices      List paired devices
  power <on/off>      Set controller power
  pairable <on/off>   Set controller pairable mode
  discoverable <on/off> Set controller discoverable mode
  agent <on/off/capability> Enable/disable agent with given capability
  default-agent       Set agent as the default one
  advertise <on/off/type> Enable/disable advertising with given type
  set-advertise-uuids [uuid1 uuid2 ...] Set advertise uuids
```

```

    set-advertise-service [uuid][data=[xx xx ...] Set advertise service
data
    set-advertise-manufacturer [id][data=[xx xx ...] Set advertise
manufacturer data
    set-advertise-tx-power <on/off> Enable/disable TX power to be
advertised
    set-scan-filter-uuids [uuid1 uuid2 ...] Set scan filter uuids
    set-scan-filter-rssi [rssi] Set scan filter rssi, and clears pathloss
    set-scan-filter-pathloss [pathloss] Set scan filter pathloss, and
clears rssi
    set-scan-filter-transport [transport] Set scan filter transport
    set-scan-filter-clear          Clears discovery filter.
    scan <on/off>                  Scan for devices
    info [dev]                     Device information
    pair [dev]                     Pair with device
    trust [dev]                    Trust device
    untrust [dev]                  Untrust device
    block [dev]                    Block device
    unblock [dev]                  Unblock device
    remove <dev>                   Remove device
    connect <dev>                  Connect device
    disconnect [dev]               Disconnect device
    list-attributes [dev]          List attributes
    set-alias <alias>              Set device alias
    select-attribute <attribute>   Select attribute
    attribute-info [attribute]     Select attribute
    read                           Read attribute value
    write <data=[xx xx ...]>       Write attribute value
    notify <on/off>                Notify attribute value
    register-profile <UUID ...>   Register profile to connect
    unregister-profile             Unregister profile
    version                        Display version
    quit                           Quit program

```

\$ hcitool

hcitool - HCI Tool ver 5.43

Usage:

```
hcitool [options] <command> [command parameters]
```

Options:

```
--help      Display help
-i dev      HCI device
```

Commands:

```
dev  Display local devices
inq  Inquire remote devices
scan Scan for remote devices
name Get name from remote device
info Get information from remote device
spinq Start periodic inquiry
epinq Exit periodic inquiry
cmd  Submit arbitrary HCI commands
con  Display active connections
cc   Create connection to remote device
dc   Disconnect from remote device
sr   Switch master/slave role
cpt  Change connection packet type

```

```

rssi  Display connection RSSI
lq    Display link quality
tpl   Display transmit power level
afh   Display AFH channel map
lp    Set/display link policy settings
lst   Set/display link supervision timeout
auth  Request authentication
enc   Set connection encryption
key   Change connection link key
clkoff    Read clock offset
clockRead local or remote clock
lescan    Start LE scan
leinfo    Get LE remote information
lewladd   Add device to LE White List
lewlrm    Remove device from LE White List
lewlsz    Read size of LE White List
lewlclr   Clear LE White List
lerladd   Add device to LE Resolving List
lerlrm    Remove device from LE Resolving List
lerlclr   Clear LE Resolving List
lerlsz    Read size of LE Resolving List
lerlon    Enable LE Address Resolution
lerloff   Disable LE Address Resolution
lecc      Create a LE Connection
ledc      Disconnect a LE Connection
lecup     LE Connection Update

```

For more information on the usage of each command use:
 hcitool <command> --help

\$ hcitool con

Connections:

```
> ACL 54:E4:3A:1E:FC:92 handle 70 state 1 lm SLAVE AUTH ENCRYPT
```

--- PAIRING a BT Device:

```

bluetoothctl >
scan on
[NEW] Device 30:23:23:F4:48:2C TH-S10U
scan off
pair 30:23:23:F4:48:2C
trust 30:23:23:F4:48:2C
exit

```

After that power off&on the bt-device and the device will connect automatically as a trusted device.

Before we try our first audio-command we had to export one thing to make BlueALSA mor system-friendly:
 export LIBASOUND_THREAD_SAFE=0

--- PLAYING Text to speech:

```
speak "Hello, how are you?" -w /home/guido/espeak.wav -s145
aplay -D bluealsa:HCI=hci0,DEV=30:23:23:F4:48:2C,PROFILE=a2dp
/home/guido/espeak.wav
```

--- PLAYING Internetradio:

```
mpg123 -a bluealsa:HCI=hci0,DEV=30:23:23:F4:48:2C,PROFILE=a2dp -@
/home/guido/ffh80s.pls
```

--- ASOUNDRC for PLAYING

~/.asoundrc with the following content:

```
defaults.bluealsa.interface "hci0"
defaults.bluealsa.device "30:23:23:F4:48:2C"
defaults.bluealsa.profile "a2dp"
defaults.bluealsa.delay 10000
```

Then:

```
mpg123 -a bluealsa -@ /home/guido/ffh80s.pls
```

--- VOLUME

For set the volume of such a device you have to know the "real" name of the device out of the bluetoothctl and the name of the used protocol:

```
Device: 30:23:23:F4:48:2C TH-S10U
```

```
Protocol: A2DP
```

```
amixer -D bluealsa sset 'TH-S10U - A2DP ' 70%
```

--- Ver los devices BT

```
$ echo -e "devices\nquit" | bluetoothctl
[NEW] Controller 00:1A:7D:DA:71:13 wpi [default]
[NEW] Device 54:E4:3A:1E:FC:92 iPhone
[bluetooth]# devices
Device 54:E4:3A:1E:FC:92 iPhone
[bluetooth]# quit
[DEL] Controller 00:1A:7D:DA:71:13 wpi [default]
```

--- AUTOCONNECT

After starting bluealsa and then a moment later the BT-device will auto-connect if trusted:

```
Device 30:21:8E:AA:4C:45 ML-28U
```

```
Device 30:23:23:F4:48:2C TH-S10U
```

Device 00:11:67:3F:9B:18 BTL9001

If you didn't want to auto-connect or it wouldn't autoconnect you can connect to a paired & trusted BT-Speaker with the command:

```
echo -e "connect 00:11:67:3F:9B:18\nquit" | bluetoothctl
```

Disconnect is the same:

```
echo -e "disconnect 00:11:67:3F:9B:18\nquit" | bluetoothctl
```

You could also change the commandline here for pairing or trusting a device like

```
echo -e "pair 00:11:67:3F:9B:18\ntrust 00:11:67:3F:9B:18\nquit" | bluetoothctl
```

--- CAPTURING

To capture audio from the connected Bluetooth device:

```
$ arecord -D bluealsa capture.wav
```

```
$ arecord -D bluealsa:HCI=hci0,DEV=XX:XX:XX:XX:XX:XX,PROFILE=sco test.wav
```

```
$ arecord -D bluealsa:HCI=hci0,DEV=54:E4:3A:1E:FC:92 -r44100 -c2 | aplay -D jack &
```

Nótese que arecord y aplay harán resampling automático salvo que se inhiba.

--- PARA VER SI UN DEVICE ESTÁ CONECTADO

```
$ echo -e "paired-devices\nquit" | bluetoothctl
[NEW] Controller 00:1A:7D:DA:71:13 wpi [default]
[NEW] Device 54:E4:3A:1E:FC:92 iPhone
[bluetooth]# paired-devices
Device 54:E4:3A:1E:FC:92 iPhone
[bluetooth]# quit
[DEL] Controller 00:1A:7D:DA:71:13 wpi [default]
$
```

```
$ echo -e "info 54:E4:3A:1E:FC:92\nquit" | bluetoothctl
[NEW] Controller 00:1A:7D:DA:71:13 wpi [default]
[NEW] Device 54:E4:3A:1E:FC:92 iPhone
[bluetooth]# info 54:E4:3A:1E:FC:92
Device 54:E4:3A:1E:FC:92
    Name: iPhone
    Alias: iPhone
```

```
Class: 0x7a020c
Icon: phone
Paired: yes
Trusted: yes
Blocked: no
Connected: no
LegacyPairing: no
UUID: Vendor specific (00000000-deca-fade-deca-
deafdecacafe)
UUID: Service Discovery Serve.. (00001000-0000-1000-8000-
00805f9b34fb)
UUID: Audio Source (0000110a-0000-1000-8000-
00805f9b34fb)
UUID: A/V Remote Control Target (0000110c-0000-1000-8000-
00805f9b34fb)
UUID: Advanced Audio Distribu.. (0000110d-0000-1000-8000-
00805f9b34fb)
UUID: A/V Remote Control (0000110e-0000-1000-8000-
00805f9b34fb)
UUID: NAP (00001116-0000-1000-8000-
00805f9b34fb)
UUID: Handsfree (0000111e-0000-1000-8000-
00805f9b34fb)
UUID: Handsfree Audio Gateway (0000111f-0000-1000-8000-
00805f9b34fb)
UUID: Phonebook Access Server (0000112f-0000-1000-8000-
00805f9b34fb)
UUID: Message Access Server (00001132-0000-1000-8000-
00805f9b34fb)
UUID: PnP Information (00001200-0000-1000-8000-
00805f9b34fb)
UUID: Vendor specific (02030302-1d19-415f-86f2-
22a2106a0a77)
Modalias: bluetooth:v004Cp6D03d0B20
[bluetooth]# quit
[DEL] Controller 00:1A:7D:DA:71:13 wpi [default]
$
```