



```
#Design of Slab
#Given Data
#Effective span is already given in question
span= float(input("Enter the value of effective span in meters:"))
b= float(input("Enter the value of width of slab in mm:"))
bs= float(input("Entert the value of Support Width in meters:"))
fck = float(input(" Enter the value of Characteristics Compressive Strength:"))
fy = float(input("Enter the value of grade of steel:"))
Es = float(input("Enter the value of Modulus of Elasticity is:"))
LL = float(input("Enter the value of Live Load:"))
FF = float(input("Enter the value of Floor Finish:"))
Density = float(input("Enter the value of Density of RCC:"))
# Design Constants
# Neutral Axis Factor
ku=0.0035/((0.0055)+(fy/(1.15*Es)))
print("The value of Neutral Axis Factor (ku) is:", ku)
# Moment of Resistan ce Facor
Ru= 0.36*fck*ku*(1-(0.42*ku))
print("The value of Moment Resisteance factor (Ru) is:", Ru)
#Assurming pt 0.5 from fig.4 from IS 456:2007 page no.38
fs=float(input("Ent er the value of Steel Stress of Service:"))
#From Graph find out the Modification Factor
MF=float(input("Enter the value of Modification Factor:"))
#From Clause 23.2.1 Select span/d Ratio
S=float(input("Enter the value of span/d ratio:"))
#Correction Factors
k1=float(input("Enter the value of Correction factor if sapn> 10m (k1):"))
k2= float(input(" Enter the value of Tension r/f correction factor (k2):"))
k3= float(input ("enter the value of Compression r/f correction factor (k3):"))
k4= float (input(" Enter the value of correction factor in case of flanged section (k4):"))
# Effective depth
d1=(span*1000)/(S*MF*k1*k2*k3*k4)
print("The value of effective depth as per deflection criteria is:", d1)
# Define Effective depth and overall depth Assuming value of cover
d = float(input("Enter the value of Effective depth in mm (d):"))
D= float(input("Enter the value of Overall depth in mm (D):"))
# Load Calculations
# Self Weight of slab
DL=D*Density/1000
print("The Dead load is:", DL)
# Total Load is
Factor=float(input("Enter the value of partial Safety Factor is: "))
TL=DL+LL+FF
print("The value of total load is:", TL)
Wu=Factor*TL
print("Wu=", Wu)
# Bendingf Moment Calculations (Mu)
Mu= Wu*span*span/8
print("The Value of Bending Moment (Mu) is:", Mu)
# Check for effective depth
d2=(Mu*1000000/(Ru*b))**0.5
print("The value of Effective depth as per Mornent criteria:", d2)
if d2>d:
    print ("Revise the Depth:")
else:
    print ("SAFE")
d = float(input("Enter the value of Effective depth in mm (d):"))
print("Minimum Steel Calculations")
Astmin = 0.12*b*D/100
print("The value of Minimum steel is:", Astmin)
print("Main Steel calculations")
Ast=((0.5*fck*b*d)/(fy))*(1-((1-((4.6*Mu*1000000)/(fck*b*d))))**0.5))
print("Ast:", Ast)
print("Check for Ast")
if Ast<Astmin:
    print("Take Ast=Astmin")
else:
    print("Ast>Astmin, Hence SAFE")
dia1 = float(input("Enter the value of bar diameter for main steel:"))
dia2 = float(input(" Enter the value of bar diameter for Distribution steel:"))
#Area of bar
ao1 = 0.7854*dia1*dia1
print("The Value of Area of main steel bar (ao1):", ao1)
ao2= 0.7854* dia2*dia2
print("The Value of Area of main steel bar (ao2):", ao2)
# Sapcing Calculations
Spacing1 = ao1*b/Ast
print("The sapcing for main steel bars is;", Spacing1)
Spacing2=ao2*b/Astmin
print("The sapcing for distribution steel bars is;", Spacing2)
nprint("Check 1 for main steel")
```

```

print("Check 1 for main steel")
if Spacing1>300:
    print("UNSAFE")
else:
    print("SAFE")
print("'Check 2 for main steel")
if Spacing1 > 3*d:
    print("UNSAFE")
else:
    print("SAFE")
print("Check 1 for Distribution steel")
if Spacing1>300:
    print("UNSAFE")
else:
    print("SAFE")
print("Check 2 for Distribution steel")
if Spacing1>5*d:
    print("UNSAFE")
else:
    print("SAFE")
print("Approximated values of Spacing:")
S1= float(input("Enter the value of spacing of main bars:"))
S2=float(input("Enter the value of spacing of distribution bars:"))
Astprovided=ao1*b/S1
print("The provided steel area for main bars at section in mm^2 is:", Astprovided)
Astprodist=ao2*b/S2
print("The provided steel area for distribution bars at section in mm^2 is: ", Astprodist)
# Check for Shear
Vu=(Wu*span/2)-(Wu*((bs/2)-(d/1000)))
print("The value of SF at a Section is:", Vu)
Stress=(Vu*1000)/(b*d)
print("The value of shear stress is:", Stress)
# From table 20 IS 456:2007 page 73
Stressmax = float(input("Enter the value of maximum Shear stress:"))
if Stress>Stressmax:
    print("Crushing will happen")
else:
    print("SAFE")
pt=(100*Ast)/(b*d)*120
print("Enter the value of percentage steel is:", pt)
#From table 19 IS 456:2007 page 73
SS=float(input("Enter the value of Shear Stress is:"))
k=float(input("Enter the value of depth factor:"))
Shear=k*SS
print("The value of shear at section is, Shear")
if Stress>Shear:
    print("Shear Reinforcement Required")
else:
    print("Shear Reinforcement not Required, SAFE")
# Check for Deflection
ActDEF=span*1000/d
print("The value of span/d is:", ActDEF)
# Actual Deflection
MaxDEF=S*MF*k1*k2*k3*k4
print("The permissible deflection is:", MaxDEF)
if MaxDEF>S/d:
    print("SAFE")
else:
    print("UNSAFE")
# Check for Anchorage Length
M1=0.87*fy*Ast*(d*(fy*Ast)/(fck*b))
print("The value of Moment (M1)", M1)
lo = 8*dia1
La = 1.3*(M1/Vu)+10
print ("The value of Anchorage length is:", La)
# Development Length
bonds = float(input("Enter the value of Bond Stress:"))
Ld = 0.87*fy*dia1/4*bonds*1.6
print("The value of Development length is:", Ld)
if La>Ld:
    print("'SAFE")
else:
    print("increase anchorage")

```

Enter the value of effective span in meters:3
 Enter the value of width of slab in mm:1000
 Enter the value of Support Width in meters:0.23
 Enter the value of Characteristics Compressive Strength:20
 Enter the value of grade of steel:415
 Enter the value of Modulus of Elasticity is:200000
 Enter the value of Live Load:4
 Enter the value of Floor Finish:1.8
 Enter the value of Density of RCC:25
 The value of Neutral Axis Factor (ku) is: 0.4791666666666667
 The value of Moment Resistance factor (Ru) is: 2.7556874999999996
 Enter the value of Steel Stress of Service:240

Enter the value of Modification Factor:1.2
Enter the value of span/d ratio:20
Enter the value of Correction factor if sapn> 10m (k1):1
Enter the value of Tension r/f correction factor (k2):1
Enter the value of Compression r/f correction factor (k3):1
Enter the value of correction factor in case of flanged section (k4):1
The value of effective depth as per deflection criteria is: 125.0
Enter the value of Effective depth in mm (d):130
Enter the value of Overall depth in mm (D):150
The Dead load is: 3.75
Enter the value of partial Safety Factor is: 1.5
The value of total load is: 9.55
Wu= 14.32500000000001
The Value of Bending Moment (Mu) is: 16.115625
The value of Effective depth as per Mornent criteria: 76.473082008588
'SAFE
Enter the value of Effective depth in mm (d):130
Minimum Steel Calculations
The value of Minimum steel is: 180.0
Main Steel calculations'
Ast: 364.7577413804497
Check for Ast
Ast>Astmin, Hence SAFE
Enter the value of bar diameter for main steel:10
Enter the value of bar diameter for Distribution steel:8
The Value of Area of main steel bar (ao1): 78.54
The Value of Area of main steel bar (ao2): 50.2656
The sapcing for main steel bars is; 215.32099552640113
The sapcing for distribution steel bars is; 279.2533333333333
Check 1 for main steel
SAFE
'Check 2 for main steel
SAFE
Check 1 fon Distribution steel
SAFE
Check 2 for Distribution steel
SAFE
Approximated values of Sapcing:
Enter the value of spacing of main bars:210
Enter the value of spacing of distribution bars:270
The provided steel area for main bars at section in mm^2 is: 374.0
The provided steel area for distribution bars at section in mm^2 is: 186.1688888888889
The value of SF at a Section is: 21.702375
The value of shear stress is: 0.16694134615384615
Enter the value of maximum Shear stress:2.8
SAFE
Enter the value of percentage steel is: 33.66994535819536
Enter the value of Shear Stress is:0.378
Enter the value of depth factor:1.3
The value of shear at section is, Shear
Shear Reinforcement not Required, SAFE
The value od span/d is: 23.076923076923077
The permissible deflection is: 24.0
SAFE
The value of Moment (M1)' 129579959.05445163
The value of Anchorage length is: 7762015.161683324
Enter the value of Bond Stress:1.2
The value of Development length is: 1733.04
'SAFE