

## Connections

Problem	Solution
The monitor is blank.	<b>The camera is connected to a TV:</b> Pictures will be displayed on the TV instead of in the camera monitor (📖 272).
Both the TV and camera monitor are blank.	<b>EYE SENSOR is selected for VIEW MODE SETTING &gt; PLAYBACK:</b> Put your eye to the viewfinder or choose a different <b>VIEW MODE SETTING</b> option (📖 207).
No picture or sound on TV.	<ul style="list-style-type: none"> <li>• <b>The camera is not properly connected:</b> Connect the camera properly (📖 272).</li> <li>• <b>Input on the television is set to “TV”:</b> Set input to “HDMI” (📖 272).</li> <li>• <b>The volume on the TV is too low:</b> Use the controls on the television to adjust the volume (📖 272).</li> </ul>
The computer does not recognize the camera.	Be sure the camera and computer are correctly connected (📖 277).
FUJIFILM X RAW STUDIO or FUJIFILM X Acquire fails to correctly detect the camera.	Check the option selected for <b>PC CONNECTION MODE</b> on the camera. Select <b>USB RAW CONV./BACKUP RESTORE</b> before connecting the USB cable (📖 284).
Cannot connect to iPhones or iPads.	<b>ON</b> is selected for <b>USB POWER SUPPLY SETTING</b> . Select <b>OFF</b> when the camera is connected via a Lightning connection to a device that do not supply power (📖 240).
Cannot connect to smartphone.	<b>Confirm that the camera is correctly connected:</b> The procedure for connecting the camera varies with the type of connector with which the smartphone is equipped (📖 281).