

Pivoting telescopic table

Maintenance**7 Maintenance**

Target groups O, E, M, C



Definition of the target groups:

- Operating Instructions *General*,
Chapter *Introduction/target groups*.



Observe the following information:

- Operating Instructions *General*,
Chapter *Safety*,
Chapter *Maintenance*,
- *Subsuppliers'* Operating Instructions,
- *Electrical Equipment* Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	OC	TI
General	▪ Fastening	▪ Fasten	P	Y
	▪ Damage (condition)	▪ Replace ▪ Repair	P	M
	▪ Function	▪ Repair	N	S
	▪ Unusual noises	▪ Eliminate the cause	N	M
	▪ Wear	▪ Replace ▪ Repair	P	M
	▪ Contamination	▪ Clean	P	M
Front table and pivoting table surface	▪ Damage ▪ Wear	▪ Repair	P	D
Guide ledges	▪ Damage ▪ Wear	▪ Repair	P	M
Bearing assembly	▪ Function	▪ Adjust clearance ▪ Replace	P	Y
Cylinder	▪ Function	▪ Replace ▪ Repair	N	S

Pivoting telescopic table

Maintenance

Area	Inspection	Action	OC	TI
		▪ Set speed		
	▪ Bearing assembly	▪ Fasten ▪ Replace ▪ Repair	P	Y
	▪ Seal	▪ Replace ▪ Repair	P	D
Fluid line, fluid connection	▪ Leaks	▪ Replace ▪ Repair	P	M
	▪ Volumetric flow rate	▪ Set volumetric flow rate	N	M
Limit switch	▪ Function	▪ Adjust ▪ Replace ▪ Repair	Z	M

Operating condition (OC)

N	Normal operation (production)
Z	Enabling mode
P	Stop (maintenance, troubleshooting)

Time interval (TI)

S	every shift (8 hours)
D	every day (24 hours)
M	every month
Y	every year

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.