

Hydraulic adjustment system

Maintenance

7.1 Maintenance schedule

Area	Inspection	Action	OC	TI
General	▪ Fastening	▪ Fasten	P	Y
	▪ Damage (condition)	▪ Replace ▪ Repair	P	M
	▪ Function	▪ Repair	N	S
	▪ Unusual noises	▪ Eliminate the cause	N	M
	▪ Wear	▪ Replace ▪ Repair	P	M
	▪ Contamination	▪ Clean	P	M
Fluid line, fluid connection	▪ Leaks	▪ Replace ▪ Repair	P	M
	▪ Volumetric flow rate	▪ Set volumetric flow rate	N	M
Cylinder	▪ Function	▪ Replace ▪ Repair ▪ Set speed	N	S
	▪ Bearing assembly	▪ Fasten ▪ Replace ▪ Repair	P	Y
	▪ Seal	▪ Replace ▪ Repair	P	M

Operating condition (OC)

N	Normal operation (production)
P	Stop (maintenance, troubleshooting)

Time interval (TI)

S	every shift (8 hours)
M	every month
Y	every year

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.