

William Taylor
CTC Office Installation Manual
The Conductors

CTC Installation Manual

12/12/2018

The Conductors
William Taylor
(For assistance, call or text (570) 971-4680.)

Change Log

Date	Author(s)	Description
12/12/18	William Taylor	First Issue

Table of Contents

- 1: Launch the program
- 2: Manually sending a train
- 3: Loading a schedule and automatically sending trains
- 4: View and approve a dispatched train
- 5: Change the mode to automatic/manual
- 6: Request to close a block for maintenance
- 7: Request a manual switch change
- 8: Request a manual crossing change
- 9: Change the whole project's time multiplier
- 10: View train occupancy on the track
- 11: View and test throughput
- 12: Test Routing

1) Launch the Program

- Run the file CTC.jar in the CTC directory
- To view any XML, open the "CTC/xml" folder if running just the CTC, open the main xml folder if running the whole system
 - This document counts expects only the CTC.jar file to be running.

2) Manually sending a train

- On the left-hand side, choose which destination to go to, choose the speed, and hit dispatch. Note that speed must be between 0-70 mph
- To see the output, see step #4

3) Loading a schedule and automatically sending trains

- Click on the Load Schedule button on the top right
- Choose GreenLine.csv, or RedLine.csv (both can be stored at once if needed)
- Mode is set to automatic, and a train is instantly deployed with that schedule
- Change the mode to manual to stop trains being sent out over time
- To see the train output, see step #4

4) View and approve a dispatched train (Train Model normally does this)

- In the CTC's XML folder (CTC/xml), open "TrainOutputs.xml"
- Find your dispatched train, read the values needed
- To show that the train was sent out, change the 0 before </Dispatch> to a 1
 - View in the CTC module, the status of the train
- To remove the train, change that 1 to a 2. It is removed from display and XML
 - If you close and reopen the XML file, the train will no longer be there

5) Change the mode to automatic/manual

- A schedule must be loaded and selected to be in automatic mode
- Click the dropdown menu, and choose on for automatic, off for manual

6) Request to close a block for maintenance

- Under Close/Open Track, select which line, and type the block number to close
- Choose to open or close the section, then click the request change button
- In "CTC/xml/CTCOutput.xml", check the new request of the following format
 - R1TCR : stands for Red, block 1, Track Close Request
 - G10TOR : stands for Green, block 10, Track Open Request
- The Track Controller then handles this, and should output states
- Reading in closed sections was removed, as TC output ended up not working

7) Request a manual switch change

- Under Flip Switch, choose the location of the switch you would like to flip
- View the request for the switch change in "CTC/xml/CTCOutput.xml"
- Keep in mind, requests are removed after 15 seconds
- The following format is followed: Line+Switch Number+Request type
 - ex. R1SNR : Red, switch #1, Switch Normal Request
 - ex. G2SRR : Green, switch, #2, Switch Reverse Request
- Note that all requests have a 1 value
- To act as the Track Controller changing the switch:
 - Open "CTC/xml/TrackControllerOutputs.xml"
 - Navigate to your switch number, with SNP on the end (i.e G2SNP)
 - 0 means the switch is reversed, 1 means the switch is normal
 - Switch the value, and view the output on the CTC module

8) Request a manual crossing change

- Follow the same format as requesting a switch change, with:
 - The following "CTC/xml/CTCOutput.xml" format to output requests
 - ex. G19UR : Green, crossing in block 19, up request
 - ex. R47DR : Red, crossing in block 47, down request
 - This is the "xml/TrackControllerOutputs.xml" format to edit the display
 - R47C and G19C are the crossings, with values the CTC receives
 - For the values, 0 is for a down crossing, 1 for an up crossing
- Keep in mind, requests are removed after 15 seconds

9) Change the whole project's time multiplier

- Click on the Time Multiplier drop down menu, select the desired value
- Open "CTC/xml/multiplier.txt", and view the multiplier value here

10) View Train Occupancy on the Track

- Open the file "CTC/xml/TrackModelOutputs.xml"
- A 1 associated with each block number means that the block is empty
- Change one of those 1's to a 0 to treat it as a train on that block, then check the G Line or R Line on the display to see that the section of track is occupied

11) View and test throughput

- Look at the top left for throughput, it starts at 0 unless changed
- To change throughput value sent by the Track Model
 - Open "CTC/xml/TrackModelOutputs.xml"
 - The last variable named throughput, is the value the CTC is getting, change the 0 if needed
 - The value received is the total number of passengers that have boarded the trains over time from the Track Model

12) Test Routing

- Change the occupancy of one of the following sections of track, to automatically send out switch requests for routing (change occupancy in step #10)
- Sections that flip switches with some block numbers associated with them
 - Red: B(4), I(46), G(21), K(55), M(61)
 - Green: L(69), M(74), P(89), Q(98), S(102), Y(147), E(17), B(4), H(33), I(36)
- Dispatching new trains automatically requests some switches as well
- (change occupancy in step #10)
- (view switch requests in step #7)