

# **Samsung Poseidon**

**MTool - Storage Management GUI**

User Manual

# Contents

<a href="#">1</a>	<a href="#">Introduction</a>	4
<a href="#">2</a>	<a href="#">MTool GUI: Getting started</a>	5
<a href="#">2.1</a>	<a href="#">Accessing the MTool GUI</a>	6
<a href="#">2.2</a>	<a href="#">MTool Dashboard</a>	7
<a href="#">2.3</a>	<a href="#">MTool Storage Management</a>	8
<a href="#">2.3.1</a>	<a href="#">Array Management</a>	9
<a href="#">2.3.2</a>	<a href="#">Volume Management</a>	13
<a href="#">2.4</a>	<a href="#">MTool Performance View</a>	22
<a href="#">2.5</a>	<a href="#">MTool User Management</a>	26
<a href="#">2.6</a>	<a href="#">MTool Storage Management Start or Stop Operations</a>	28

# Overview

This document describes the POS Storage Management GUI (MTool). The MTool enables a user to perform the following functions:

- View Dashboard
- Array management
- Volume management
- Graphical view of system resource availability
- User management
- View system status

This document covers the following topics:

- Introduction
- MTool: Getting started
- Array and volume configuration
- Performance monitoring
- User management
- POS start and stop operations

# 1 Introduction

POS Storage Management GUI (MTool) enables an easy way to administer POS storage system.

The major objectives of MTool are:

- **Availability:** MTool is available from various devices, platforms and systems.
- **Speed:** MTool provides data with highest performance so that users have access to important data at right times.
- **Simplicity:** A simple and intuitive design to help productivity and overall cost.
- **Commonality:** Commonly used graphics, widgets and terminology enable easy integration with existing systems and onboarding the users quickly.

With these deliverables in mind, a System Administrator can use the MTool to configure and prepare the storage system for the user workloads quickly after completing the setup. Then the System Administrator can manage the system with minimal knowledge. The GUI provides a performance monitoring tool for the main storage parameters.

Array and volume storage configuration and management is streamlined in MTool. User management is simplified and performance views provide detailed information of the system state.

## 2 MTool GUI: Getting started

This section describes how to accomplish the following tasks:

- Accessing the MTool GUI
- Managing and monitoring the POS system (e.g. array or volume management)
- Performance monitoring of the POS system
- User management

## 2.1 Accessing the MTool GUI

The MTool GUI can be accessed using Firefox Mozilla and Google Chrome browser.

The MTool supports the use of a single point of authentication function for the GUI through a centralized data in a lightweight database.

MTool is accessible from the browser as shown in Figure1




Figure 1. MTool GUI URL

On the first page for MTool GUI, user needs to log on as an administrator.

1. MTool GUI URL: [http://<mtool\\_ip>](http://<mtool_ip>)

---

*Note: MTool GUI URL may come pre-installed*

---

2. On a new system, users can use the following default credentials:

- User = admin
- Password = admin

3. After initial login, user can add additional users using admin privileges

---

*Note: MTool supports only "admin" role at this time.*

---




Figure 2. MTool login page

## 2.2 MTool Dashboard

Dashboard provides user an overview of the Poseidon box. It has three sections,

- Performance overview
- Storage Details
- Storage Summary

In addition, it also has links to few admin tasks such as user management, etc. It also shows the current working status of the storage management system and the last time the status is updated.

1. **Performance Overview** – shows the basic performance details such as Latency, Bandwidth, Throughput, CPU utilization and Memory utilization of the storage management box.
2. **Last-Updated** - shows when the status label was updated.
3. **Status Label** shows whether the storage management is available or not.
4. Host IP, MAC address and name.
5. **Storage Details** - shows the space utilization.
6. **Volume Summary** - provides the volume level information in the storage management box.




Figure 3. MTool dashboard page

## 2.3 MTool Storage Management

The Storage Management page allows user to create an array and volumes, view existing array and volumes and manage existing arrays and volumes.

1. User can create an array based on the types of disks selected in the slots .i.e. Storage, Spare and Write Buffer Disks.
2. User can create a single or multiple volumes at a time by specifying the volume name, volume size, volume count and description.
3. User can view the volume information including volume name, volume size, used size, IP, description and status in a tabular format.
4. User can view the existing space for volume creation process.






Figure 4. MTool storage management page

### 2.3.1 Array Management

Array management option allows user to create and manage a single array.

---

*Note: Currently only one array is supported.*

---

#### 2.3.1.1 Create Array

Follow the steps below to create sample array creation process:

1. **Fault Tolerance Level** – Select from the dropdown

---

*Note: Currently “RAID-5” is the only one supported.*

---

2. **Disk Type** - Select storage disks from the dropdown list. The 2 options for disk type are
  - Storage Disk
  - Spare Disk
2. **Write Buffer Path** – Select from the dropdown list.
3. User can view the available disks.

---

*The max number of allowable disks is 32.*

---

4. User can view the color codes for various types of disk supported by MTool.
5. User can view additional details, e.g. name, size, by hovering over the disk number
6. Click **Create Array** button

**Array Management**

Fault tolerance Level  
RAID-5 1

Write Buffer Path 3

Disk Type  
Storage Disk 2

4

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32

5

☒ Selected Storage disk ☐ Selected Spare disk ☐ Not Selected ☐ Empty Slot

6 **Create Array**

Figure 5. MTool Array Management




Figure 6. MTool Array creation steps

7. A confirmation message, “**Array Created Successfully**” displayed.




Figure 7. MTool successful array creation confirmation



Figure 8. MTool successful array creation and ability to delete and unmount

### 2.3.1.2 Delete Array

Follow the steps below to delete array:

1. Click **Delete Array** button

2. A confirmation message is displayed, click **Yes** button to confirm the delete operation




Figure 9. MTool array deletion confirmation

3. A confirmation message, “**Array Deleted Successfully**” displayed.




Figure 10. Tool successful array deletion confirmation

### 2.3.1.3 Unmount Array

Follow the steps below to unmount array:

1. Click “**Unmount Array**” button
2. By hovering over the “**Unmount Array**” button, the additional info is displayed




Figure 11. MTool unmount array operation

3. A confirmation message, “**Array Unmounted Successfully**” displayed.




Figure 12. MTool successful array unmount confirmation

### 2.3.2 Volume Management

Volume management option allows user to create and manage one volume or multiple volumes.

Follow the steps below to Manage Volume:

1. User can choose to create one volume or multiple volume. User can enter the number of volume he or she wishes to create.

2. User can enter the volume name. When user tries to create multiple volumes, then user can enter the suffix value to append to the multiple volumes that need to be created.
3. User can choose a number suffix value. For example, if user chooses to create 5 volumes with a volume name as “*volume\_company*” and numeric suffix value of 0, then volumes with the following names would be created.
  - Volume\_company0
  - Volume\_company1 and so on to ...
  - volume\_company4
4. User can choose the max volume size (i.e. enter 0) or a predefined value.
5. User can choose the max IOPS value (i.e. enter 0) or a predefined value.
6. User can choose the max bandwidth size (i.e. enter 0) or a predefined value.
7. User can choose to mount the volume or leave it unmounted.
8. User can stop the volume creation process when an error occurs.

**Create Volume**

Volume Count \* 1

1

☒ Mount Volume 7

For Volume Count > 1, please provide a seed in the Suffix Start Value field (e.g. 0,1)

Volume Name \* 2

vol

Suffix Start Value 3

0

Volume Size \* 4

0 GB

Maximum IOPS (KIOPS) \* 5

0

Maximum Bandwidth (MB/s) \* 6

0

☐ Stop Multi-Volume Creation on Error 8

**CREATE VOLUME**

Figure 13. MTool create volume steps

Below is a screen showing the volume creation step for 5 volumes.

**Create Volume**

Volume Count \*

5

☒ Mount Volume

For Volume Count > 1, please provide a seed in the Suffix Start Value field (e.g. 0,1)

Volume Name \*

volume\_company

Suffix Start Value

0

Volume Size \*

10 GB

Maximum IOPS (KIOPS) \*

0

Maximum Bandwidth (MB/s) \*


0

☐ Stop Multi-Volume Creation on Error

**CREATE VOLUME**

Figure 14. MTool sample volume create steps

A user can hit the “CREATE VOLUME” button for MTool to create the required volumes. MTool may take a few seconds depending on how many volumes are selected for creation.



The screenshot shows the 'Create Volume' form with the following fields and values:

- Volume Count \***: 5
- Mount Volume**: ☒
- For Volume Count > 1, please provide a seed in the Suffix Start Value field (e.g. 0,1)**: (Instructional text)
- Volume Name \***: volume\_company
- Suffix Start Value**: 0
- Volume Size \***: 10 GB
- Maximum IOPS (KIOPS) \***: 0
- Maximum Bandwidth (MB/s) \***: 0
- Stop Multi-Volume Creation on Error**: ☐
- CREATE VOLUME**: (Button)
- Volume Creation is in progress. Please wait for sometime.**: (Status message)

Figure 15. MTool volume creation intermediate step waiting for processing



Below is a screen showing the volume information for the newly created volumes.

1. User can search for specific volumes by using search terms for size, name, etc.
2. User can select all volumes to delete them.


*Note: Multi volume edit is not supported at this time.*

3. User can select a specific volume to either delete it or edit it.
4. User can mount or unmount a volume
5. User can toggle the button to either mount or unmount the volume.
6. User can select edit option for a specific volume
7. User can view the total number of volumes in the system

Volume List <span>1</span> <input type="text" value="Search"/>						
<input type="checkbox"/>	Name	Total Size	Used Size	Max IOPS (KIOPS)	Max Bandwidth (MB/s)	Mount Status Update
<input type="checkbox"/>	volume_company4	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/> 4
<input type="checkbox"/>	volume_company3	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/> 6
<input type="checkbox"/>	volume_company2	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/>
<input type="checkbox"/>	volume_company1	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/>
<input type="checkbox"/>	volume_company0	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/>
<span>7</span> 5 rows <span> &lt;</span> <span>&lt;</span> 1-5 of 5 <span>&gt;</span> <span>&gt; </span>						

Figure 16. MTool volume information

Below is a screen showing search function for volume data.




<input type="checkbox"/>	Name	Total Size	Used Size	Max IOPS (KIOPS)	Max Bandwidth (MB/s)	Mount Status	Update
<input type="checkbox"/>	volume_company2	10 GB	0 Bytes	MAX	MAX		

5 rows |< < 1-1 of 1 > >|

Figure 17. MTool search volume information by keywords

Below is a screen showing delete function for all volumes.

1. User can select the checkbox to select all volumes
2. User can click on the delete icon to perform delete operation on all volumes



<input checked="" type="checkbox"/>	Name	Total Size	Used Size	Max IOPS (KIOPS)	Max Bandwidth (MB/s)	Mount Status	Update
<input checked="" type="checkbox"/>	volume_company4	10 GB	0 Bytes	MAX	MAX		
<input checked="" type="checkbox"/>	volume_company3	10 GB	0 Bytes	MAX	MAX		
<input checked="" type="checkbox"/>	volume_company2	10 GB	0 Bytes	MAX	MAX		
<input checked="" type="checkbox"/>	volume_company1	10 GB	0 Bytes	MAX	MAX		
<input checked="" type="checkbox"/>	volume_company0	10 GB	0 Bytes	MAX	MAX		

5 rows |< < 1-5 of 5 > >|

Figure 18. MTool delete all volumes

Below is a screen that shows delete function for one or many volumes.

1. User is notified whether one, many or all volumes are selected
2. User can select the checkbox to select one or many volumes
3. User can click on the delete icon to perform delete operation on the selected volumes

Volume List							Search	3
	Name	Total Size	Used Size	Max IOPS (KIOPS)	Max Bandwidth (MB/s)	Mount Status	Update	
<input checked="" type="checkbox"/>	volume_company4	10 GB	0 Bytes	MAX	MAX			
<input type="checkbox"/>	volume_company3	10 GB	0 Bytes	MAX	MAX			
<input type="checkbox"/>	volume_company2	10 GB	0 Bytes	MAX	MAX			
<input type="checkbox"/>	volume_company1	10 GB	0 Bytes	MAX	MAX			
<input type="checkbox"/>	volume_company0	10 GB	0 Bytes	MAX	MAX			
<div>5 rows</div> <div>              &lt;             &lt;             1-5 of 5             &gt;             &gt;            </div>								

Figure 19. MTool delete one or more volumes

Screen below shows confirmation of the unmount operation.




Figure 20. MTool unmount volume confirmation

Screen below shows unmount or mount operation on a given volume.

1. User is notified whether volume is mounted or unmounted
2. User can view the mount status of the volume




Figure 21. MTool successful unmount operation confirmation

Screen below shows update function for a given volume.

1. User can update the name of the volume
2. User can update the IOPS value
3. User can update the bandwidth value
4. User can click on the “Ok” or “Cancel” button to update or cancel the changes

Volume List							Search	×
<input type="checkbox"/>	Name	Total Size	Used Size	Max IOPS (KIOPS)	Max Bandwidth (MB/s)	Mount Status	Update	
<input type="checkbox"/>	volume_company4 <b>1</b>	10 GB	0 Bytes	0 <b>2</b>	200 <b>3</b>	<input type="checkbox"/>	✓ <b>4</b> ✗	
<input type="checkbox"/>	volume_company3	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	volume_company2	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	volume_company1	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	volume_company0	10 GB	0 Bytes	MAX	MAX	<input checked="" type="checkbox"/>		
5 rows  < < 1-5 of 5 > >								

Figure 22. MTool update volume information

Screen below shows update operation on a given volume.

1. User is notified whether volume is updated successfully
2. User can view the updated data of the volume




Figure 23. MTool update volume information confirmation

## 2.4 MTool Performance View

Performance page shows the detailed charts regarding performance of the Poseidon box. It has charts for:

1. Throughput
2. IOPS
3. Latency
4. CPU utilization




Figure 24. MTool Performance page showing throughput and IOPS data




Figure 25. MTool Performance page showing latency data




Figure 26. MTool Performance page showing CPU data



User can choose from following options for performance data

1. Level
  - Array
  - Volume
  - System
2. Time (various time intervals)



Figure 27. MTool options for various performance data points

Below is a screen that shows the CPU data for last 1 minute.




Figure 28. MTool various time intervals available for CPU data

## 2.5 MTool User Management

The user management page allows admins to add a new user and modify Username, Email Id, Mobile Number fields of an existing user.

### 2.5.1.1 New User

User Addition requires six fields i.e. Username, Role, Password, Confirm password, Mobile Number and Email ID.

Follow the steps below to add a new user:

1. User can add a new user by providing
  - User name
  - Password
  - Phone
2. User can choose the default role “Admin”
3. User can save changes by clicking on “**Submit**” button

Figure 29. MTool add new user information

### 2.5.1.2 Delete User

User Deletion allows the admins to delete the entire user(s) details.

*Note: If a user record is deleted by the admin, the user would not be able to login to the management portal.*

1. Admins can use **Add New User** functionality to re-add the user.

Figure 30. MTool user management page


### 2.5.1.3 Modify User

User Modification allows the admins to modify Username, Active Status, Email Id, Mobile Number fields of an existing user.

*Note: If a user's active status is disabled by the admin, then the user would not be able to login till the status is reverted to active state by the admin*

Follow the steps below to update a given user information:

1. User can update the phone
2. User can update an email
3. User can either save changes or discard them



User List				
Role	User Name	Phone	Email	Actions
ADMIN	admin	<span>1</span> +82 123 4567 890	<span>2</span> admin@corp.com	<span>3</span> ✓ ✕

Figure 31. MTool update user information

## 2.6 MTool Storage Management Start or Stop Operations

This page allows users to start or stop the Storage Management system. This will provide the real time status of the system. This feature is available for admin users only.

This page enables users to:

1. View the current status of the storage management system
2. Either start or stop the storage management system
3. View the response of the operation on the storage management system




Figure 32. MTool start and stop operation page