



# **Application Note**

## **AN\_391**

# **EVE Platform Guide**

**Version 1.0**

**Issue Date: 2015-09-29**

This application note is intended as a companion to the examples for the FT8xx series of devices. Each example for the EVE family has a source code zip file supporting a variety of platforms and an accompanying application note which describes the operation of the sample code. This application note provides additional information on the platforms used to run the sample code and compatibility of the samples across the EVE family.

Use of FTDI devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold FTDI harmless from any and all damages, claims, suits or expense resulting from such use.

**Future Technology Devices International Limited (FTDI)**

Unit 1, 2 Seaward Place, Glasgow G41 1HH, United Kingdom

Tel.: +44 (0) 141 429 2777 Fax: + 44 (0) 141 429 2758

Web Site: <http://ftdichip.com>

Copyright © 2015 Future Technology Devices International Limited

---

## Table of Contents

<b>1 Introduction .....</b>	<b>3</b>
1.1 Overview .....	3
1.2 Scope .....	3
<b>2 Sample Application Matrix .....</b>	<b>4</b>
<b>3 Loading the Demonstration Code.....</b>	<b>5</b>
3.1 Visual Studio .....	6
3.2 FT90x Platform.....	9
3.3 MSVC Emulator .....	12
3.4 Arduino .....	14
<b>4 Platform Configuration .....</b>	<b>16</b>
<b>5 Contact Information .....</b>	<b>25</b>
<b>Appendix A– References .....</b>	<b>26</b>
Document References .....	26
Acronyms and Abbreviations.....	26
<b>Appendix B – List of Tables &amp; Figures .....</b>	<b>27</b>
List of Figures .....	27
List of Tables.....	27
<b>Appendix C– Revision History .....</b>	<b>28</b>

## 1 Introduction

This application note is intended as a companion to the examples for the FT8xx series of devices. Each example for the EVE family has a source code zip file supporting a variety of platforms:

- Microsoft Visual Studio
- FT900
- MSVC Emulator
- Arduino

Each example also has an accompanying application note which describes the operation of the sample code.

This application note provides additional information on the platforms used to run the sample code and compatibility of the samples across the EVE family.

### 1.1 Overview

This guide covers the following topics:

- Matrix showing compatibility of each sample with the different EVE devices and platforms
- Example of how to load and run the demo on each platform
- Highlighting the sections of platform.h which can be used to select the correct code options for the target platform

### 1.2 Scope

This document is intended to be used in conjunction with the source code project and the application note specific to the sample program. It uses the Gradient example for illustration but does not cover the specific graphics aspects demonstrated in each example.

## 2 Sample Application Matrix

This section shows the compatibility of the demo projects across the different EVE devices and demonstration boards.

The EVE2 column indicates the demos which currently support the EVE2 (FT81x) platform in addition to the FT80x. The FT81x uses a different register map from the FT80x in order to support the additional registers required for its extended functionality and therefore require updated header files to allow either register map to be defined. The demos updated for EVE2 also have some areas with code specific to the FT80x or FT81x which is enabled depending on the #defines selected in the platform header file.

Application	EVE2	Platforms																	
		MSVC					Arduino						MSVC Emulator					FT90X	
		MPSSE																	
		VM800B43 VM800B50	VM800B35	VM801B43 VM801B50	VM810C50		VM800P43 VM800P50	VM800P35	VM801P43 VM801P50	VM800B43 VM800B50	VM800B35	VM801B43 VM801B50	VM800B43 VM800B50	VM800B35	VM801B43 VM801B50	VM810C50	ME800A-HV35R	ME810A-HV35R	
SampleApp	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Lift	✓	✓	✓	✗	✓	✓	✗	✓	✗	✗	✗	✓	✗	✓	✓	✓	✓	✓	
FT_App_Gauge	✓	✓	✓	✓	✗	✓	✓	✓	✓	✓	✓	✓	✓	✓	✗	✓	✓	✓	
FT_App_Gradient	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Sketch	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Signature	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Signals	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_MeterDemo	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Metaballs	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Mainmenu	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗	✗	✓	✓	✓	✓	✓	✓	✓	
FT_App_Keyboard	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Jackpot	✓	✓	✗	✓	✓	✓	✗	✓	✗	✗	✗	✓	✗	✓	✓	✓	✗	✗	
FT_App_Imageviewer	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗	✗	✓	✓	✓	✓	✓	✓	✓	
FT_App_Graph	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_RotaryDial	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
FT_App_Logo	✓	✓	✗	✓	✓	✓	✗	✓	✗	✗	✗	✓	✗	✓	✓	✓	✗	✗	
FT_App_PlayVideo	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	
FT_App_WashingMachine	✓	✓	✗	✓	✓	✓	✗	✓	✗	✗	✗	✓	✗	✓	✓	✓	✗	✗	
FT_App_Refrigerator	✗	✓	✗	✓	✗	✓	✗	✓	✗	✗	✗	✓	✗	✓	✗	✗	✗	✗	
FT_App_Clocks	✗	✓	✓	✓	✗	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗	✗	
FT_App_FtClocks	✗	✓	✓	✓	✗	✓	✓	✓	✗	✗	✗	✓	✓	✓	✓	✗	✗	✗	
FT_App_Polygon	✗	✓	✓	✓	✗	✓	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗	✗	✗	
FT_App_CustomWidgets	✗	✓	✓	✓	✗	✓	✓	✓	✗	✗	✗	✓	✓	✓	✗	✗	✗	✗	
FT_App_Player	✗	✓	✓	✓	✗	✓	✓	✓	✗	✗	✗	✓	✓	✓	✗	✗	✗	✗	
FT_App_Restaurant	✗	✓	✗	✓	✗	✓	✗	✓	✗	✗	✗	✓	✗	✓	✗	✗	✗	✗	
FT_App_Music	✗	✓	✓	✓	✗	✓	✓	✓	✗	✗	✗	✓	✓	✓	✗	✗	✗	✗	
FT_App_Reader	✗	✓	✗	✓	✗	✓	✗	✓	✗	✗	✗	✓	✗	✓	✗	✗	✗	✗	
FT_App_ChineseFont	✗	✓	✗	✓	✗	✓	✗	✓	✗	✗	✗	✓	✗	✓	✗	✗	✗	✗	

**Figure 2.1 Platform table for EVE demos**

Notes:

1. PlayVideo demo requires QSPI and will be supported on future FT900-based demo boards

### 3 Loading the Demonstration Code

This section provides details of loading and running the code on the FT90x, Visual Studio, Arduino and MSVC Emulator platforms.

The source code zip file for each project can be downloaded from the page below:

[http://www.ftdichip.com/Support/SoftwareExamples/FT800\\_Projects.htm](http://www.ftdichip.com/Support/SoftwareExamples/FT800_Projects.htm)

The Gradient example is used in the screenshots for illustration purposes only. However, similar steps apply for the other demonstrations.

Note: For some demos, when running on the Arduino and FT900 platforms, a FAT formatted SD card is required and all files in the “Test” folder must be copied to the root directory of the SD card. The Test folder will be empty if the SD card is not required by the demo.

## 3.1 Visual Studio

This section covers the loading of the demonstration code on a PC with Visual Studio installed. In this case, the code running on the Visual Studio application represents the SPI Master which controls the FT8xx device.

### Hardware Requirement

This section applies to hardware configurations using the CM232H cable, VA800A-SPI or the VM8xxBU which have an on-board USB-SPI interface. The code requires an interface based on the FT232H chipset and does not support 3<sup>rd</sup> party USB->SPI adapters.

If using the C232HM, the pin-out below should be used when connecting the wires to the header of the FT8xx development module (e.g. VM800B/VM800C).

SCK	ORANGE
MOSI	YELLOW
MISO	GREEN
CS#	BROWN
PD#	BLUE
GND	BLACK

**Table 1 C232HM Connections to the VM8xx pins**

### Software Requirement

The demo applications were developed on MSVC 2010 Express edition. The project can also be opened on later versions of MSVC which will migrate from the older version. Note that in some cases MSVC will not modify the platform tool set during the migration of the project.

Before running the code, ensure that the USB-SPI cable/interface (e.g. C232HM) is connected to the USB port of the computer and the FTDI Windows drivers are loaded. The adapter should appear under the Universal Serial Bus Controllers section of the Device Manager.

If the driver installation has not been carried out, please consult the user guide for the USB->SPI interface for instructions on installing the interface.

### Folder Structure

The provided zip file supports various platforms. The main files related to the MSVC platform are:

- Folder [Project -> Msvc\\_win32](#) contains the project and solution files (e.g. [Project -> Msvc\\_win32 -> FT\\_App\\_Gradient -> Ft\\_App\\_Gradient.sln](#))
- Folder [Src](#) contains the c source files for the main application and supporting functions
- Folder [Hdr](#) contains header files and sub-folder [Msvc\\_win32](#) contains further headers for the MSVC platform
- The [Test](#) folder contains supporting files for the project where required (for example, bitmap images)

Full details are given in the readme file included in the project zip package.

## Loading the Project

The code project can then be opened within the Visual Studio software. The solution can be opened by double-clicking the .sln file (e.g. [Project -> Msvc\\_win32 -> FT\\_App\\_Gradient -> Ft\\_App\\_Gradient.sln](#)) or by File -> Open Project/Solution within the Visual Studio software itself.


## Configuring the Project

Before running the demo, ensure that the project is configured for the correct FT8xx board and screen size within the FT\_Platform.h file which can be opened from the Solution Explorer window in Visual Studio.

Please refer to section 4


## Running the Project

To run the project, perform a clean or re-build all via the BUILD menu. Then, select the Debug mode from the drop-down and start debugging.



**Figure 3.1 Visual Studio screenshot**

The command window will appear a few seconds after clicking the Local Windows Debugger button and the initial calibration screen will be displayed on the module's LCD screen.



```
Information on channel number 0:  
Flags=0x2  
Type=0x8  
ID=0x4036014  
LocId=0x214  
SerialNumber=FTXDNDXX  
Description=C232HM-DDHSL-0  
FtHandle=0x0  
  
handle=0x525458 status=0x0  
UCI register ID after wake up 7c  
  
reg_touch_rz =0x7fff  
reg_touch_rzthresh =0x4b0  
reg_touch_tag_xy=0x00000000  
reg_touch_tag=0x0_
```

**Figure 3.2 Command window with demo running**

### Stopping the Demonstration

To stop debugging, the Visual Studio menu item **DEBUG -> Stop Debugging** can be used or the command window can be closed via the cross button at the top-right of the command window.

Breakpoints and stepping can be used when running the code to allow the operation to be more easily understood. Note that the code builds up buffers of commands for the FT8xx and so the result will not be visible until the **Swap** and **Flush\_Co\_Buffer** functions have been executed.



## 3.2 FT90x Platform


This section covers the loading of the example on an FT90x platform.

### Hardware Requirement

- EVE Module card (e.g. ME800A-HV35R, ME810A-HV35R)
- UMFTPD2A Module for program/debug
- FT900 board (e.g. MM900EVx)
- Micro USB cables

The MM900EVx module is mated onto the top of the ME8xx Board as shown in Figure 3.3. The display panel cable connects into the FPC socket on the top of the ME8xx module. A USB micro cable is used to power both boards.

The UMFTPD2A Module is used to download the program to the FT900 Board via the MicroMatch ribbon cable connector. It connects to the PC via a second micro USB cable which provides power and communications to the UMFTPD2A from the host PC.



**Figure 3.3 Hardware connections**

### Software Requirement

- FT900 Toolchain. See [AN\\_325 FT900 Toolchain Installation Guide](#).
- Software package for this Application Note (see section 3)

### Folder Structure

The provided zip file supports various platforms. The main files related to the FT900 platform are:

- Folder "Project\FT90x" contains the project file.
- The source files are included in Src folder.
- The header files are included in Hdr and Hdr\FT90x folder.
- The library files such as fatfs are included in bin\FT90x\ (see note below)
- The Test folder contains any supporting files which should be placed on the SD card (for example, bitmaps). (see note below)

Full details are given in the readme file included in the project zip package.

Note: For the Arduino and FT900 versions of some samples, a FAT formatted SD card is required. All files in the “Test” folder must be copied to the root directory of the SD card. The libfatfs.a library should also be included in the project when the program is running on FT900 platform. The Test and bin\FT90x folders may be empty in cases where the sample code does not require images etc. to be stored on an SD card.

## Dependencies

The Application uses the SPI, UART, etc. libraries provided by FTDI as part of the FT900 Toolchain. The following header files should also be included in the code: ff.h, ffconf.h, diskio.h and integer.h.

For further details of FT900 toolchain usage, see AN\_325 (FT900 Toolchain Installation Guide) and AN\_381 Sample Application for an example on how to import a project into the FT900 IDE.

## Loading the Project


To import the project into the Eclipse IDE, select File → Import.

Then choose General → Existing Projects into Workspace

Then select the root directory where the software package was saved on your PC.

**Note:** do not select ‘Copy projects into workspace’ as this does not copy all files required.

The project should now appear in the Project Explorer window.



**Figure 3.4 Project Import**

## Configuring the Project

Before running the demo, ensure that the project is configured for the correct FT8xx board and screen size within the FT\_Platform.h file which can be opened from the Solution Explorer window in Visual Studio.


Please refer to section 4

## Project Build

Right-click the project and select "Build project" to build the code. The progress can be monitored in the console window.

## Project Download

You can use "FT900Prog GUI Launcher" to download the binary generated into the FT900 memory. The "FT900Prog GUI Launcher" is installed together with Eclipse for FT900.



**Figure 3.5 FT900Prog GUI Launcher**

For other download and debug options, see [AN\\_325 FT900 Toolchain Installation Guide](#).

## 3.3 MSVC Emulator

The MSVC Emulator version of the project allows the sample to be run without any hardware. It uses the EVE Screen Editor utility provided by FTDI

### Hardware Requirement

Running on the MSVC Emulator does not require any hardware as the screen is simulated on the PC application.

However, by connecting an EVE module to the PC via the FTDI MPSSE interface, it may be used to preview the result on the actual display. For example

- VM800B/C, VM801B/C, VM810C can be used in conjunction with a USB-SPI adapter (CM232H or VA800A-SPI)
- VM80xBU has the USB-SPI adapter on-board and can be connected directly to the PC's USB port.

When using the C232HM, the connections are the same as in section 3.1.

### Software Requirement

The example project requires Visual Studio 2012 (or Express 2012) or later to be installed.

The latest FTDI EVE Screen Editor must also be installed. This can be obtained from <http://www.ftdichip.com/Support/Utilities.htm#EVEScreenEditor>

### Folder Structure

The provided zip file supports various platforms. The main files related to the Emulator platform are:

- Folder **Project** -> **MSVC\_Emulator** contains the project and solution files (e.g. **Project** -> **MSVC\_Emulator** -> **FT\_App\_Gradient** -> **Ft\_App\_Gradient.sln**)
- Folder **Src** contains the c source files for the main application and supporting functions
- Folder **Hdr** contains header files and sub-folder **MSVC\_Emulator** contains further headers for the MSVC platform
- The **Test** folder contains supporting files for the project where required (for example, bitmap images)

Full details are given in the readme file included in the project zip package.

## Loading the Project


The code project can then be opened within the Visual Studio software. The solution can be opened by double-clicking the .sln file (e.g. [Project -> MSVC\\_Emulator -> FT\\_App\\_Gradient -> Ft\\_App\\_Gradient.sln](#)) or by File -> Open Project/Solution within the Visual Studio software itself.

## Configuring the Project

Before running the demo, ensure that the project is configured for the correct FT8xx board and screen size within the FT\_Platform.h file which can be opened from the Solution Explorer window in Visual Studio. Please refer to section 4.


## Running the Project

To run the project, select the Release mode from the drop-down and click the Local Windows Debugger button.



**Figure 3.6 Code project open in Visual Studio**

A window will appear on the PC which represents the screen. Clicking with the mouse simulates touches on the screen. Note that the Screen Editor program itself will not open or be visible but must be installed in order for the emulation to work.



**Figure 3.7 Window simulating the FT8xx screen**

## 3.4 Arduino

The demo can be loaded into the Arduino IDE in order to be run on an Arduino platform.

### Hardware Requirement

The provided sample can be run on the VM800P and VM801P boards which have an Arduino-compatible ATMEGA328 MCU. These boards have a USB-UART interface to allow programming via the bootloader in the MCU.

They can also be run on the Arduino Pro platform along with a VM800B/C or VM801B. For details of the connections, refer to AN\_246 (Sample App Arduino introduction).

An SD card is required for some examples where a large amount of image data is required.

### Software Requirement

This requires the Arduino IDE to be installed. The samples require Arduino 1.0.1 or later. The IDE can be obtained from the Arduino homepage: <https://www.arduino.cc/>

**Note:** For the Arduino platform of some demos, a FAT formatted SD card is required and in this case all files in the “Test” folder must be copied to the root directory of the SD card. The Test folder may be empty in the sample code package and in this case no SD card is needed.

### Folder Structure

The provided zip file supports various platforms. The main files related to the Arduino platform are:


- Folder **Project -> Arduino** contains the .ino sketch file, along with Arduino versions of the library functions and headers. (e.g. **Project -> Arduino -> FT\_App\_Gradient -> Ft\_App\_Gradient.ino**)

- The **Test** folder contains supporting files for the project where required (for example, bitmap images)

Full details are given in the readme file included in the project zip package.

## Loading the Code

After opening the .ino file in the Arduino IDE, the tabs should show the code and header files as displayed below.



**Figure 3.8 Arduino IDE with code project open**

## Configuring the Project

Before running the demo, ensure that the project is configured for the correct FT8xx board and screen size within the FT\_Platform.h file which can be opened from the Solution Explorer window in Visual Studio.

Please refer to section 4

## Loading the Code

The VM800P/VM801P should be connected to the PC and the drivers installed. The Windows device manager (under the Ports section) can be used to verify which COM port has been assigned.

In the Arduino IDE, select the COM port under Tools \_ Serial Port. Ensure that the Tools -> Board setting is "Arduino Pro or Pro Mini (5V, 16MHz) w/ATMega328"

Click the Verify button (which has a tick shaped icon) to compile the code. The adjacent upload button (with an arrow-shaped icon) can be used to compile *and* upload the code to the MCU. The LEDs on the VM800P/801P indicate the data traffic during upload and shortly after these stop blinking, the board will re-start and the application will run.

## 4 Platform Configuration

The Visual Studio, FT900 and Emulator platforms use a common source file for the main application (e.g. Gradient.c) which in turn calls the library functions and commands from the library files in the project.

The code includes #defines in order to support these different host platforms and also to allow the same source code to support the different screen sizes and EVE family members. For example, to select the correct header files for FT80x/FT81x, when using FT81x specific features or to allow for capacitive or resistive screen types.

After loading the demonstration code and before running it, please ensure that the settings match the hardware platform.

The sections below highlight the main settings for each platform type.

### Visual Studio

A section of the platform.h file is shown below.

- The first area highlighted allows configuration of the FT8xx module being used. One define should be un-commented to correspond to the board in use. The file uses further #if defined areas to configure the other settings based on the module.
- The second area highlighted can be used in cases where it is required to control the #defines individually to obtain a custom combination. In this case, the defines from the first highlighted section would be commented.

Note that after changing any settings, it is necessary to re-build the project in Visual Studio so that the code is re-built with the new settings and options.

```
#ifndef _FT_PLATFORM_H_
#define _FT_PLATFORM_H_

/* platform specific macros */
#define MSVC_PLATFORM (1) // enable by default for MSVC platform

/* module specific macros */
#define VA800A_SPI (1)

#define VM800B43_50 (1) // Select one of these to match the EVE board being used
// #define VM800B35 (1)
// #define VM801B43_50 (1)
// #define VM810C50 (1)

#ifdef VM800B43_50

/* Define all the macros specific to VM800B43_50 module */
#define FT_800_ENABLE (1)
#define DISPLAY_RESOLUTION_WQVGA (1)
#define RESISTANCE_THRESHOLD (1200)
#endif /* VM800B43_50 */

#ifdef VM800B35

#define FT_800_ENABLE (1)
#define DISPLAY_RESOLUTION_QVGA (1)
#define RESISTANCE_THRESHOLD (1200)

#endif /* VM800B35 */

#ifdef VM801B43_50

#define FT_801_ENABLE (1)
#define DISPLAY_RESOLUTION_WQVGA (1)

#endif

#endif
```



```
#ifdef VM810C50

/* Define all the macros specific to VM800B43_50 module */
#define FT_810_ENABLE (1)
#define DISPLAY_RESOLUTION_WVGA (1)
#define RESISTANCE_THRESHOLD (1200)

#endif /* VM810C50 */

/* Module connected from PC to basic modules */
#ifdef VA800A_SPI
#define ENABLE_SPI_SINGLE (1)
#endif /* VA800A_SPI */

/* Custom configuration */
#if (!defined(VM800B43_50) && !defined(VM800B35) && !defined(VM801B43_50) && !defined(VM810C50))

/* Display configuration specific macros */
#define DISPLAY_RESOLUTION_QVGA (1)
#define DISPLAY_RESOLUTION_WQVGA (1)
#define DISPLAY_RESOLUTION_WVGA (1)
#define DISPLAY_RESOLUTION_HVGA_PORTRAIT (1)

/* Chip configuration specific macros */
#define FT_800_ENABLE (1)
#define FT_801_ENABLE (1)
#define FT_810_ENABLE (1)
#define FT_811_ENABLE (1)
#define FT_812_ENABLE (1)
#define FT_813_ENABLE (1)

/* SPI specific macros - compile time switches for SPI single, dial and quad use cases */
#define ENABLE_SPI_SINGLE (1)
#define ENABLE_SPI_DUAL (1)
#define ENABLE_SPI_QUAD (1)

/* Display driver configurations - mainly for ME900EV1 modules */
#define ENABLE_ILI9488_HVGA_PORTRAIT (1)

#endif

#if defined(FT_800_ENABLE) || defined(FT_801_ENABLE)
#define FT_80X_ENABLE (1)
#endif

#if (defined(FT_810_ENABLE) || defined(FT_811_ENABLE) || defined(FT_812_ENABLE) || defined(FT_813_ENABLE))
#define FT_81X_ENABLE (1)
#endif

/* C library inclusions */
#include <stdlib.h>
#include <stdio.h>
#include <string.h>
#include <math.h>
#include <Windows.h>
#include <direct.h>
#include <time.h>
#include <io.h>

/* D2xx and SPI from FTDI inclusions */
#include "ftd2xx.h"
#include "LibMPSSE_spi.h"

/* HAL inclusions */
#include "FT_DataTypes.h"
#include "FT_Gpu_Hal.h"
#include "FT_Gpu.h"
#include "FT_CoPro_Cmds.h"
#include "FT_Hal_Utils.h"

/* Macros specific to optimization */
#define BUFFER_OPTIMIZATION (1)
#define BUFFER_OPTIMIZATION_DDRAM (1)
#define BUFFER_OPTIMIZATION_CMDRAM (1)
#define MSVC_PLATFORM_SPI (1)

#define FT800_SEL_PIN 0
#define FT800_PD_N 7
```

This section allows the defines to be controlled individually if no selections were made for the EVE module type

```
#endif /*_FT_PLATFORM_H_*/
/* Nothing beyond this*/
```

## FT900

A section of the platform.h file is shown below.

- The first two areas highlighted allow configuration of the FT900 and FT8xx and the file uses further #if defined areas to configure the other settings based on these. One define from each section should be un-commented to correspond to the board in use.
- The third area highlighted can be used in cases where it is required to control the #defines individually (e.g. if not using one of the standard combinations). In this case, section the defines from the EVE board section would be commented.
- 

Note that after changing any settings, it is necessary to re-build the project by performing Right-Click -> Clean Project, then Right-Click -> Build Project.

```
#ifndef _FT_PLATFORM_H_
#define _FT_PLATFORM_H_

/* FT900 Platform */
#define FT900_PLATFORM (1)

/* Module specific configurations */
#define MM900EV1A (1) Select one of these to match the FT900 board being used
//#define MM900EV2A (1)
//#define MM900EV3A (1)
//#define MM900EV_LITE (1)

#if (defined(MM900EV1A) || defined(MM900EV2A) || defined(MM900EV3A) || defined(MM900EV_LITE))

/* RTC configurations */
#define FT900_PLATFORM_RTC_I2C (1)
#define RTC_PRESENT (1)

#endif

#define ME800A_HV35R (1) Select one of these to match the EVE board being used
//#define ME810A_HV35R (1)
//#define ME813A_WV7C (1)

#ifdef ME800A_HV35R

#define ENABLE_SPI_SINGLE (1)
#define FT_800_ENABLE (1)
#define DISPLAY_RESOLUTION_HVGA_PORTRAIT (1)
#define ENABLE_ILI9488_HVGA_PORTRAIT (1)
#define RESISTANCE_THRESHOLD (1800)

#endif /* #ifdef ME800A_HV35R */

#ifdef ME810A_HV35R

#define ENABLE_SPI_QUAD (1)
#define FT_810_ENABLE (1)
#define DISPLAY_RESOLUTION_HVGA_PORTRAIT (1)
#define ENABLE_ILI9488_HVGA_PORTRAIT (1)
#define RESISTANCE_THRESHOLD (1800)
#endif /* #ifdef ME800A_HV35R */

#ifdef ME813A_WV7C

#define ENABLE_SPI_QUAD (1)
#define FT_813_ENABLE (1)
#define DISPLAY_RESOLUTION_WVGA (1)

#endif /* #ifdef ME813A_WV7C */
```

```

/* Individual configurations if module specific configurations are not defined */
/* Enable the respective macros based on the custom platform */
#if (!defined(ME800A_HV35R) && !defined(ME810A_HV35R) && !defined(ME813A_WV7C))

/* platform specific macros */
#define FT900_PLATFORM (1)

/* Display configuration specific macros */
#define DISPLAY_RESOLUTION_QVGA (1)
#define DISPLAY_RESOLUTION_WQVGA (1)
#define DISPLAY_RESOLUTION_WVGA (1)
#define DISPLAY_RESOLUTION_HVGA_PORTRAIT (1)

/* Chip configuration specific macros */
#define FT_800_ENABLE (1)
#define FT_801_ENABLE (1)
#define FT_810_ENABLE (1)
#define FT_811_ENABLE (1)
#define FT_812_ENABLE (1)
#define FT_813_ENABLE (1)

/* SPI specific macros - compile time switches for SPI single, dial and quad use cases */
#define ENABLE_SPI_SINGLE (1)
#define ENABLE_SPI_DUAL (1)
#define ENABLE_SPI_QUAD (1)

/* Display driver configurations - mainly for ME900EV1 modules */
#define ENABLE_ILI9488_HVGA_PORTRAIT (1)

#endif /* #if (!defined(ME800A) && !defined(ME813A)) */

#if (defined(FT_800_ENABLE) || defined(FT_801_ENABLE))
#define FT_80X_ENABLE (1)
#endif

#if (defined(FT_810_ENABLE) || defined(FT_811_ENABLE) || defined(FT_812_ENABLE) || defined(FT_813_ENABLE))
#define FT_81X_ENABLE (1)
#endif

/* Standard C libraries */
#include <unistd.h>
#include <stdlib.h>
#include <stdio.h>
#include <string.h>
#include <assert.h>

/* FT900 libraries */
#include "ft900_uart_simple.h"
#include "ft900_sdhost.h"
#include "ft900_spi.h"
#include "ft900_gpio.h"
#include "ft900_rtc.h"
#include "ft900_interrupt.h"
#include "ft900_i2cm.h"
#include "ft900.h"
#include "ft900_delay.h"

/* HAL inclusions */
#include "FT_DataTypes.h"
#include "FT_Gpu_Hal.h"
#include "FT_Gpu.h"
#include "FT_CoPro_Cmds.h"
#include "FT_Hal_Utils.h"
#include "FT_ILI9488.h"

/* Hardware or Module specific macros for gpio line numbers */
#if (defined(MM900EV1A) || defined(MM900EV2A) || defined(MM900EV3A) || defined(MM900EV_LITE))
#define FT800_SEL_PIN 0
#define FT800_PD_N 43

/* Timer 1 is been utilized in case of FT900 platform */
#define FT900_FT_MILLIS_TIMER (timer_select_b)
#define FT900_TIMER_MAX_VALUE (65536L)
#define FT900_TIMER_PRESCALE_VALUE (100)
#define FT900_TIMER_OVERFLOW_VALUE (1000)

```

```
#endif
```

```
#endif /*_FT_PLATFORM_H_*/
```

## MSVC Emulator

A section of the platform.h file is shown below.

- The first area highlighted allows configuration of the FT8xx module being emulated. One define should be un-commented to correspond to the board in use. The file uses further #if defined areas to configure the other settings based on the module.
- The second area highlighted can be used in cases where it is required to control the #defines individually to obtain a custom combination. In this case, the #defines from the first highlighted section would be commented.

Note that after changing any settings, it is necessary to re-build the project in Visual Studio so that the code is re-built with the new settings and options.

Revision History:

```
#ifndef _FT_PLATFORM_H_
#define _FT_PLATFORM_H_

/* platform specific macros */
#define MSVC_FT800EMU (1) // enable by default for emulator platform

// #define VM800B43_50 (1) Select one of these to match the EVE board being emulated
// #define VM800B35 (1)
#define VM801B43_50 (1)
// #define VM810C50

#ifdef VM800B43_50

/* Define all the macros specific to VM800B43_50 module */
#define FT_800_ENABLE (1)
#define DISPLAY_RESOLUTION_WQVGA (1)
#define ENABLE_SPI_SINGLE (1)
#define RESISTANCE_THRESHOLD (1200)
#endif /* VM800B43_50 */

#ifdef VM800B35

#define FT_800_ENABLE (1)
#define DISPLAY_RESOLUTION_QVGA (1)
#define ENABLE_SPI_SINGLE (1)
#define RESISTANCE_THRESHOLD (1200)
#endif /* VM800B35 */

#ifdef VM801B43_50

#define FT_801_ENABLE (1)
#define DISPLAY_RESOLUTION_WQVGA (1)
#define ENABLE_SPI_SINGLE (1)
#endif

#endif

/* Custom configuration */
#if (!defined(VM800B43_50) && !defined(VM800B35) && !defined(VM801B43_50))

/* Display configuration specific macros */
#define DISPLAY_RESOLUTION_QVGA (1)
#define DISPLAY_RESOLUTION_WQVGA (1)
#define DISPLAY_RESOLUTION_WVGA (1)
#define DISPLAY_RESOLUTION_HVGA_PORTRAIT (1)

/* Chip configuration specific macros */
#define FT_800_ENABLE (1)
#define FT_801_ENABLE (1)
#define FT_810_ENABLE (1)
#define FT_811_ENABLE (1)
#define FT_812_ENABLE (1)
#define FT_813_ENABLE (1)

/* SPI specific macros - compile time switches for SPI single, dial and quad use cases */
```

```
#define ENABLE_SPI_SINGLE (1)
#define ENABLE_SPI_DUAL (1)
#define ENABLE_SPI_QUAD (1)

#define RESISTANCE_THRESHOLD (1200)

#endif

#if defined(FT_800_ENABLE) || defined(FT_801_ENABLE)
#define FT_80X_ENABLE (1)
#endif

#if (defined(FT_810_ENABLE) || defined(FT_811_ENABLE) || defined(FT_812_ENABLE) || defined(FT_813_ENABLE))
#define FT_81X_ENABLE (1)
#endif

/* Standard C libraries */
#include <stdlib.h>
#include <stdio.h>
#include <string.h>
#include <math.h>
#include <Windows.h>
#include <direct.h>
#include <time.h>
#include <io.h>
/* HAL inclusions */
#include "FT_DataTypes.h"

#include "FT_EmulatorMain.h"
#include "FT_Gpu_Hal.h"
#include "FT_Gpu.h"
#include "FT_CoPro_Cmds.h"
#include "FT_Hal_Utils.h"
#define BUFFER_OPTIMIZATION

#define FT800_SEL_PIN 0
#define FT800_PD_N 7

#endif /*_FT_PLATFORM_H_*/
```

## Arduino

A section of the platform.h file is shown below.

- The first area highlighted allows configuration of the FT8xx module being used. One define should be un-commented to correspond to the board in use. The file uses further #if defined areas to configure the other settings based on the module.
- The second area highlighted can be used in cases where it is required to control the #defines individually to obtain a custom combination. In this case, the defines from the first highlighted section would be commented.

Note that after changing any settings, it is necessary to re-build the project via the Verify (tick) button.

```
#ifndef _FT_PLATFORM_H_
#define _FT_PLATFORM_H_

#define ARDUINO_PLATFORM

/* Module specific configurations */
#define VM800P43_50
// #define VM800P35
// #define VM801P43_50
// #define VM800B43_50
// #define VM800B35
// #define VM801B43_50

Select one of these to match the EVE board being used

#ifdef VM800P43_50

#define DISPLAY_RESOLUTION_WQVGA (1)
#define FT_800_ENABLE (1)
#define ENABLE_SPI_SINGLE (1)
#define FT_ARDUINO_ATMEGA328P_I2C (1)
#define RTC_PRESENT (1)
#define FT800_CS (9)
#define FT_SDCARD_CS (8)
#define FT800_INT (3)
#define FT800_PD_N (4)
#define FT_ARDUINO_PRO_SPI_CS FT800_CS
#define ARDUINO_PLATFORM_SPI
#define ARDUINO_PLATFORM_COCMD_BURST
#define RESISTANCE_THRESHOLD (1200)
#endif

#ifdef VM800P35

#define DISPLAY_RESOLUTION_QVGA (1)
#define FT_800_ENABLE (1)
#define ENABLE_SPI_SINGLE (1)
#define FT_ARDUINO_ATMEGA328P_I2C (1)
#define RTC_PRESENT (1)
#define FT800_CS (9)
#define FT_SDCARD_CS (8)
#define FT800_INT (3)
#define FT800_PD_N (4)
#define FT_ARDUINO_PRO_SPI_CS FT800_CS
#define ARDUINO_PLATFORM_SPI
#define ARDUINO_PLATFORM_COCMD_BURST
#define RESISTANCE_THRESHOLD (1200)
#endif

#ifdef VM801P43_50

#define DISPLAY_RESOLUTION_WQVGA (1)
#define FT_801_ENABLE (1)
#define ENABLE_SPI_SINGLE (1)
#define FT_ARDUINO_ATMEGA328P_I2C (1)
#define RTC_PRESENT (1)
#define FT800_CS (9)
#define FT_SDCARD_CS (8)
#define FT800_INT (3)
#define FT800_PD_N (4)
#define FT_ARDUINO_PRO_SPI_CS FT800_CS
```

```
#define ARDUINO_PLATFORM_SPI
#define ARDUINO_PLATFORM_COCMD_BURST

#endif

#ifdef VM800B43_50

#define DISPLAY_RESOLUTION_WQVGA (1)
#define FT_800_ENABLE (1)
#define ENABLE_SPI_SINGLE (1)
#define FT800_INT (3)
#define FT800_PD_N (4)
#define FT_SDCARD_CS (5)
#define FT800_CS (10)
#define FT_ARDUINO_PRO_SPI_CS (10)
#define ARDUINO_PLATFORM_SPI
#define ARDUINO_PLATFORM_COCMD_BURST
#define RESISTANCE_THRESHOLD (1200)
#endif

#ifdef VM800B35

#define DISPLAY_RESOLUTION_QVGA (1)
#define FT_800_ENABLE (1)
#define ENABLE_SPI_SINGLE (1)
#define FT800_INT (3)
#define FT800_PD_N (4)
#define FT_SDCARD_CS (5)
#define FT800_CS (10)
#define FT_ARDUINO_PRO_SPI_CS (10)
#define ARDUINO_PLATFORM_SPI
#define ARDUINO_PLATFORM_COCMD_BURST
#define RESISTANCE_THRESHOLD (1200)
#endif

#ifdef VM801B43_50

#define DISPLAY_RESOLUTION_WQVGA (1)
#define FT_801_ENABLE (1)
#define ENABLE_SPI_SINGLE (1)
#define FT800_INT (3)
#define FT800_PD_N (4)
#define FT_SDCARD_CS (5)
#define FT800_CS (10)
#define FT_ARDUINO_PRO_SPI_CS (10)
#define ARDUINO_PLATFORM_SPI
#define ARDUINO_PLATFORM_COCMD_BURST

#endif

/* Custom configuration set by the user */
#if (!defined(VM800P43_50) && !defined(VM800P35) && !defined(VM801P43_50) && !defined(VM800B43_50) && !defined(VM800B35) && !defined(VM801B43_50))
#define DISPLAY_RESOLUTION_QVGA (1)
#define DISPLAY_RESOLUTION_WQVGA (1)
#define DISPLAY_RESOLUTION_WVGA (1)
#define DISPLAY_RESOLUTION_HVGA_PORTRAIT (1)
/* This section allows the defines to be controlled individually
if no selections were made for the EVE type */

/* Chip configuration specific macros */
#define FT_800_ENABLE (1)
#define FT_801_ENABLE (1)
#define FT_810_ENABLE (1)
#define FT_811_ENABLE (1)
#define FT_812_ENABLE (1)
#define FT_813_ENABLE (1)

/* SPI specific macros - compile time switches for SPI single, dial and quad use cases */
#define ENABLE_SPI_SINGLE (1)
#define ENABLE_SPI_DUAL (1)
#define ENABLE_SPI_QUAD (1)

#define FT800_PD_N (4)
#define FT800_CS (10)

/* Display driver configurations - mainly for ME900EV1 modules */
#define ENABLE_ILI9488_HVGA_PORTRAIT (1)
#define ARDUINO_PLATFORM_SPI

/* Threshold for resistance */
```

---

```
#define RESISTANCE_THRESHOLD (1200)

#endif

#if (defined(FT_800_ENABLE) || defined(FT_801_ENABLE))
#define FT_80X_ENABLE (1)
#endif

#if (defined(FT_810_ENABLE) || defined(FT_811_ENABLE) || defined(FT_812_ENABLE) || defined(FT_813_ENABLE))
#define FT_81X_ENABLE (1)
#endif

/* Standard C libraries */
#include <stdio.h>
/* Standard Arduino libraries */
#include <Arduino.h>
#include <EEPROM.h>
#include <SPI.h>
#include <avr/pgmspace.h>

/* HAL inclusions */
#include "FT_DataTypes.h"
#include "FT_Gpu_Hal.h"
#include "FT_Gpu.h"
#include "FT_CoPro_Cmds.h"
#include "FT_Hal_Utils.h"

#define FT800_SEL_PIN FT800_CS

#endif /* _FT_PLATFORM_H_ */
```



## 5 Contact Information

### Head Office – Glasgow, UK

Future Technology Devices International Limited  
Unit 1, 2 Seaward Place, Centurion Business Park  
Glasgow G41 1HH  
United Kingdom  
Tel: +44 (0) 141 429 2777  
Fax: +44 (0) 141 429 2758

E-mail (Sales) [sales1@ftdichip.com](mailto:sales1@ftdichip.com)  
E-mail (Support) [support1@ftdichip.com](mailto:support1@ftdichip.com)  
E-mail (General Enquiries) [admin1@ftdichip.com](mailto:admin1@ftdichip.com)

### Branch Office – Taipei, Taiwan

Future Technology Devices International Limited  
(Taiwan)  
2F, No. 516, Sec. 1, NeiHu Road  
Taipei 114  
Taiwan, R.O.C.  
Tel: +886 (0) 2 8791 3570  
Fax: +886 (0) 2 8791 3576

E-mail (Sales) [tw.sales1@ftdichip.com](mailto:tw.sales1@ftdichip.com)  
E-mail (Support) [tw.support1@ftdichip.com](mailto:tw.support1@ftdichip.com)  
E-mail (General Enquiries) [tw.admin1@ftdichip.com](mailto:tw.admin1@ftdichip.com)

### Branch Office – Tigard, Oregon, USA

Future Technology Devices International Limited  
(USA)  
7130 SW Fir Loop  
Tigard, OR 97223-8160  
USA  
Tel: +1 (503) 547 0988  
Fax: +1 (503) 547 0987

E-Mail (Sales) [us.sales@ftdichip.com](mailto:us.sales@ftdichip.com)  
E-Mail (Support) [us.support@ftdichip.com](mailto:us.support@ftdichip.com)  
E-Mail (General Enquiries) [us.admin@ftdichip.com](mailto:us.admin@ftdichip.com)

### Branch Office – Shanghai, China

Future Technology Devices International Limited  
(China)  
Room 1103, No. 666 West Huaihai Road,  
Shanghai, 200052  
China  
Tel: +86 21 62351596  
Fax: +86 21 62351595

E-mail (Sales) [cn.sales@ftdichip.com](mailto:cn.sales@ftdichip.com)  
E-mail (Support) [cn.support@ftdichip.com](mailto:cn.support@ftdichip.com)  
E-mail (General Enquiries) [cn.admin@ftdichip.com](mailto:cn.admin@ftdichip.com)

### Web Site

<http://ftdichip.com>

### Distributor and Sales Representatives

Please visit the Sales Network page of the [FTDI Web site](http://ftdichip.com) for the contact details of our distributor(s) and sales representative(s) in your country.

System and equipment manufacturers and designers are responsible to ensure that their systems, and any Future Technology Devices International Ltd (FTDI) devices incorporated in their systems, meet all applicable safety, regulatory and system-level performance requirements. All application-related information in this document (including application descriptions, suggested FTDI devices and other materials) is provided for reference only. While FTDI has taken care to assure it is accurate, this information is subject to customer confirmation, and FTDI disclaims all liability for system designs and for any applications assistance provided by FTDI. Use of FTDI devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold harmless FTDI from any and all damages, claims, suits or expense resulting from such use. This document is subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Neither the whole nor any part of the information contained in, or the product described in this document, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. Future Technology Devices International Ltd, Unit 1, 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH, United Kingdom. Scotland Registered Company Number: SC136640

## Appendix A– References

### Document References

[Datasheet for VM800C](#)

[Datasheet for VM800B](#)

[FT800 programmer guide](#)

[FT800 Embedded Video Engine Datasheet](#)

[FT81x Programmer Guide](#)

[FT81x Datasheet](#)

### Acronyms and Abbreviations

Terms	Description
Arduino Pro	The open source platform variety based on ATMEL's ATMEGA chipset
EVE	Embedded Video Engine
FT900	FT900 Microcontroller from FTDI
SPI	Serial Peripheral Interface
UI	User Interface
USB	Universal Serial Bus

## **Appendix B – List of Tables & Figures**

### **List of Figures**

Figure 2.1 Platform table for EVE demos .....	4
Figure 3.1 Visual Studio screenshot.....	7
Figure 3.2 Command window with demo running .....	8
Figure 3.3 Hardware connections .....	9
Figure 3.4 Project Import.....	10
Figure 3.5 FT900Prog GUI Launcher .....	11
Figure 3.6 Code project open in Visual Studio .....	13
Figure 3.7 Window simulating the FT8xx screen.....	14
Figure 3.8 Arduino IDE with code project open .....	15

### **List of Tables**

Table 1 C232HM Connections to the VM8xx pins .....	6
--	---

---

## Appendix C– Revision History

Document Title: AN\_391 EVE Platform Guide  
Document Reference No.: FT\_001247  
Clearance No.: FTDI#467  
Product Page: <http://www.ftdichip.com/FTProducts.htm>  
Document Feedback: [Send Feedback](#)

Revision	Changes	Date
1.0	Initial release	2015-09-29