



---

# Battery CANBUS Protocol

**Administrator**

**2023-09-05**

## Version History

Date	Version	Note	Author
2020-2-11	01	Add cell voltage, temperature, cycle cnt etc.	
2023-02-28	02	Add battery brand	
2023-08-19	03	Add remote command from inverter	Chloe
2023-09-05	04	Modify the voltage accuracy of high voltage batteries to 0.1V	Chloe

CAN 总线配置CAN Bus configuration:

标准帧/Standard frame

通讯速率：500kbps /Communication rate: 500kbps; 字节序：小端

/Endian: little endian

系统数据/System information

BMS 数据自动发送，发送周期 1s/ send out data automatically every 1 second;

储能逆变器响应/ Inverter response: Inverter CAN ID: 0x305: Data: 00 00 00 00 00 00 00 00储能逆变器远程控制

指令/ Remote command from storage inverter CANID: 0x300 Inverter 数据定义/Data definition:

CAN ID: 0x300

Byte	Definition	Note
Byte 0	Bit0 RSD battery	0x01 Shutdown battery
Byte 1	RSVD	0x00
Byte 2	RSVD	0x00
Byte 3	RSVD	0x00
Byte 4	RSVD	0x00
Byte 5	RSVD	0x00
Byte 6	RSVD	0x00
Byte 7	RSVD	0x00

BMS 数据定义/Data definition: CAN ID:  
0x359

Byte	definition	Note
Byte 0	Protection 1	See Table 1
Byte 1	Protection 2	
Byte 2	Alarm 1	
Byte 3	Alarm 2	
Byte 4	Module number	Parallel module number
Byte 5	Capacity	Ah
Byte 6		
Byte 7		

Table 1 Protection and Alarm

	Protection1	Protection2	Alarm1	Alarm2
Bit0	rsvd	Charge over current	rsvd	Charge high current
Bit1	Over voltage	rsvd	High voltage	rsvd
Bit2	Under voltage	rsvd	Low voltage	rsvd
Bit3	Over temperature	System error	High temperature	Internal communication fail
Bit4	Under temperature	rsvd	Low temperature	rsvd
Bit5	rsvd	rsvd	rsvd	rsvd
Bit6	rsvd	rsvd	rsvd	rsvd
Bit7	Discharge over current	rsvd	Discharge high current	rsvd

**CAN ID: 0x351**

Byte	definition	Unit	Note
Byte0	Charge voltage recommand	0.1V	Charge voltage recommand
Byte1			
Byte2	Charge current limitation	0.1A	Max charge current
Byte3			
Byte4	Discharge current limitation	0.1A	Max discharge current
Byte5			
Byte6	Discharge cut voltage	0.1V	
Byte7			

**CAN ID: 0x355**

Byte	definition	Unit	Note
Byte0	SOC	%	Single or average value for parallel modules
Byte1			
Byte2	SOH	%	Single or average value for parallel modules
Byte3			
Byte4	Max Cell voltage	1mV	
Byte5			
Byte6	Min cell voltage	1mV	
Byte7			

**CAN ID: 0x356**

Byte	definition	Unit	Note
Byte0	Pack volage	0.01V for low voltage batteries <b>0.1V for high voltage batteries</b>	Single or average value for parallel modules
Byte1			
Byte2	Pack current	0.1A	Single or total value for parallel modules
Byte3			
Byte4	Max Cell temperature	0.1°C	
Byte5			
Byte6	Min Cell temperature	0.1°C	
Byte7			

**CAN ID: 0x35C**

Byte	definition	Unit	Note
Byte0	Request flag		See Table 2
Byte1			
Byte2	Cycle cnt		
Byte3			
Byte4			
Byte5			
Byte6			
Byte7			

**Table 2 Request flag**

	Definition	Note
<b>Bit0</b>	rsvd	
<b>Bit1</b>	rsvd	
<b>Bit2</b>	rsvd	
<b>Bit3</b>	Full charge request	Set when BMS need calibrate SOC
<b>Bit4</b>	Forced charge request1	Set when SOC get in the certain range defined by BMS
<b>Bit5</b>	Forced charge request2	Set when SOC get in the certain range defined by BMS
<b>Bit6</b>	Discharge enable	Set when discharge is allowed
<b>Bit7</b>	Charge enable	Set when charge is allowed

**CAN ID: 0x35E**

Byte	definition	Unit	Note
<b>Byte0</b>	Battery brand 0	ASCII	
<b>Byte1</b>	Battery brand 1	ASCII	
<b>Byte2</b>	Battery brand 2	ASCII	
<b>Byte3</b>	Battery brand 3	ASCII	
<b>Byte4</b>	Battery brand 4	ASCII	
<b>Byte5</b>	Battery brand 5	ASCII	
<b>Byte6</b>	Battery brand 6	ASCII	
<b>Byte7</b>	Battery brand 7	ASCII	