





# OMRON FLEXIBOWL PLUGIN



**This Plugin was developed with the idea of communicating quickly and safely with the flexibowl through Omron robots, using version 4 or version 3 of the Omron Ace software. The Plugin does not require additional Omron licenses.**


## FlexiBowl®



## ACE versione 4




### STEP 1:



By selecting the desired *Application Manager* in the *Multiview Explorer*, by right clicking under the *Variables* tree you can add three *string* variables named as follows:

- **Command**
- **Ip**
- **ReturnFlexibowl**

### STEP 2:




By again selecting the desired *Application Manager*, a new c# task can be added under the *Programs* tree by right clicking.

This task can be launched from V+ to move the flexibowl.

Rename the task as “Flexibowl Plugin”.

### STEP 3:



Double click the program just created to edit it.

The declarations to be used are in zone 1, while the body of the script is in part 2.

We will now edit said script.

## ACE versione 4



### STEP 4:

```
Line Number: [ ] Go to Line [ ]
1 using Ace.Services.NameLookup;
2 using Ace.Server;
3 using System;
4 using System.Collections.Generic;
5 using System.Diagnostics;
6
7 using System.Net;
8 using System.Net.Sockets;
9 using System.Text;
10 using Ace.Server.Core.Scripting;
11 using Ace.Server.Core.Variable;
12
13 namespace Ace.Custom {
14
15     public class Program {
16
17         public INameLookupService ace;
18
19         public void Main() {
20
21         }
```

Add the following dependencies in section 1 of the code:

```
using System.Net;
using System.Net.Sockets;
using System.Text;
using Ace.Server.Core.Scripting;
using Ace.Server.Core.Variable;
```

### STEP 5:

In the section of code 2 instead delete and replace with all the code on the following page. The image below shows a preview of the final result.

```
--
13 namespace Ace.Custom {
14
15     public class Program {
16
17         public INameLookupService ace;
18
19         public void Main() {
20
21             Trace.WriteLine("Flexibowl PlugIn " + DateTime.Now.ToString() + " Run");
22
23             string receiveString = "";
24             int byteSent = 0;
25
26             UdpClient m_udpClient= new UdpClient(7777);
27             ///////////////////////////////////////////////////
28             /// To change/////////////////////////////////
29             IVariableString Command = (IVariableString) ace["Application Manager0/Variables/Command"];
30             IVariableString Ip = (IVariableString) ace["Application Manager0/Variables/Ip"];
31             IVariableString ReturnFlexibowl = (IVariableString) ace["Application Manager0/Variables/ReturnFlexibowl"];
32             ///////////////////////////////////////////////////
33             ReturnFlexibowl.CurrentValue="False";
34             IPEndPoint ep = new IPEndPoint(IPAddress.Parse(Ip.CurrentValue), 7775);
35             try {
36                 m_udpClient.Connect(ep);
37                 m_udpClient.Client.SendTimeout = 500;
38                 m_udpClient.Client.ReceiveTimeout = 500;
39             }
40             catch (ArgumentNullException ex) // dgram is null.
41             {
42                 Trace.WriteLine(ex.ToString());
43             }
44             string dataToSend = Command.CurrentValue.ToUpper();
45
46             try {
47                 Byte[] SCLstring = Encoding.ASCII.GetBytes(dataToSend);
48
49             }
```

```
Trace.WriteLine("Flexibowl PlugIn " + DateTime.Now.ToString() + " Run");

string receiveString = "";
int byteSent = 0;

UdpClient m_udpClient= new UdpClient(7777);
//////////
/// To change//////////
IVariableString Command = (IVariableString) ace["/Application Manager/Variables/Command"];
IVariableString Ip = (IVariableString) ace["/Application Manager/Variables/Ip"];
IVariableString ReturnFlexibowl = (IVariableString) ace["/Application Manager/Variables/ReturnFlexibowl"];
//////////
ReturnFlexibowl.CurrentValue="False";
IPEndPoint ep = new IPEndPoint(IPAddress.Parse(Ip.CurrentValue), 7775);

try {
    m_udpClient.Connect(ep);
    m_udpClient.Client.SendTimeout = 500;
    m_udpClient.Client.ReceiveTimeout = 500;
}
catch (ArgumentNullException ex)
{
    Trace.WriteLine(ex.ToString());
}

string dataToSend = Command.CurrentValue.ToUpper();

try {
    Byte[] SCLstring = Encoding.ASCII.GetBytes(dataToSend);
    Byte[] sendBytes = new Byte[SCLstring.Length + 3];
    sendBytes[0] = 0;
    sendBytes[1] = 7;
    System.Array.Copy(SCLstring, 0, sendBytes, 2, SCLstring.Length);
    sendBytes[sendBytes.Length - 1] = 13; // CR
    byteSent = m_udpClient.Send(sendBytes, sendBytes.Length);
    var receivedData = m_udpClient.Receive(ref ep);
    receiveString = Encoding.ASCII.GetString(receivedData);
    if ((receiveString.Contains("%") && (dataToSend.Contains("Q")))) {
        bool moving = true;
        while (moving == true) {
            SCLstring = Encoding.ASCII.GetBytes("RS");
            sendBytes = new Byte[SCLstring.Length + 3];
            sendBytes[0] = 0;
            sendBytes[1] = 7;
            System.Array.Copy(SCLstring, 0, sendBytes, 2, SCLstring.Length);
            sendBytes[sendBytes.Length - 1] = 13; // CR
            byteSent = m_udpClient.Send(sendBytes, sendBytes.Length);
            receivedData = m_udpClient.Receive(ref ep);
            receiveString = Encoding.ASCII.GetString(receivedData);
            if (receiveString.Contains("F"))
                moving = true;
            else
                moving = false;
            System.Threading.Thread.Sleep(20);
        }
        ReturnFlexibowl.CurrentValue = "Done";
    }
    else {
        SCLstring = new Byte[receivedData.Length - 3];
        System.Array.Copy(receivedData, 2, SCLstring, 0, SCLstring.Length);
        receiveString = Encoding.ASCII.GetString(SCLstring);
        ReturnFlexibowl.CurrentValue = receiveString;
    }
    m_udpClient.Dispose();
}
catch (ArgumentNullException ex)
{
    Trace.WriteLine(ex.ToString());
}
```

## ACE versione 4



### STEP 6:

After copying and pasting the code, check that the paths of the variables previously created are correct.

To verify this, check the box highlighted in the image to make sure the paths of the three variables are correct.

Select one of the three variables previously created, drag&drop on the page with the code.

In this case you have created a reference to your variable; check the correct path and delete the line created.

Ensure the paths of the three variables in the code are correct.


#### Example:

Original

`IVariableString Command = (IVariableString) ace["/Application Manager0/Variables/Command"];`

Edited

`IVariableString Command = (IVariableString) ace["/Application Manager4/Variables/Command"];`




## ACE versione 4



### STEP 7:

Once here, the movement of the Flexibowl can be tested.

By setting the Ip in the IP variable (ref. 1) and the command to be run in the Command variable (ref. 2), click the Run button (ref. 3) to send the command to the Flexibowl with the set Ip.



### STEP 8:

We will now see how to set the variables and run the script from V+

Let's create a V+ program with the code on the next page.

Copy the code and check that the paths of the variables are correct, e.g.:

*`$object = "/Application Manager0/Variables/Ip"`*

After setting the Ip and the command, by running the V+ script the flexibowl will carry out the command

```
;insert the data  
;/;;;;;;;;;  
$ip="169.254.1.10"  
$command="QX3"  
;/;;;;;;;;;
```

*At the moment the Ip, Command and return.flexibowl variables in V+ are local (AUTO). To set them from external programs, make these variables Global, therefore not Auto. Running the V+ script will execute the C# script, which will operate the flexibowl*

```
.PROGRAM flbplugin()
  AUTO $object, $variable, $ip, $command, $return.flexibow, $method, $args[0]
  AUTO REAL status, is.alive
  ;insert the data
  ;////////////////////
  $ip="169.254.1.10"
  $command="QX3"
  ;////////////////////
  ;Set the data on c#
  ;IP
  $object = "/Application Manager0/Variables/Ip"
  $variable = "CurrentValue"
  CALL rm.write.str($object, $variable, 1, $ip, status)
  IF (status < 0) THEN
    TYPE "Unable To Write Value: ", status
    PAUSE
  END
  ;COMMAND
  $object = "/Application Manager0/Variables/Command"
  $variable = "CurrentValue"
  CALL rm.write.str($object, $variable, 1, $command, status)
  IF (status < 0) THEN
    TYPE "Unable To Write Value: ", status
    PAUSE
  END
  ;Execute the c#
  CALL rm.chk.server(is.alive)
  IF (is.alive == FALSE) THEN
    TYPE "Not Communicating"
    PAUSE
  END ; Execute a script on the server and wait for 3 seconds for it to complete
  $object = "/Application Manager0/Programs/FlexibowIPlugin"
  $method = "Execute"
  CALL rm.execute($object, $method, 0, $args[], 5, status)
  IF (status < 0) THEN
    TYPE "Problem executing script: ", status
    PAUSE
  END
  ;Read the Answer
  $object = "/Application Manager0/Variables/ReturnFlexibowI"
  $variable = "CurrentValue"
  ;Read the answer from flexibowI
  CALL rm.read.str($object, $variable, 1, $return.flexibow, status)
  IF (status < 0) THEN
    TYPE "Unable To Read the Value: ", status
    PAUSE
  END
.END
```

## STEP 9:

List of commands and descriptions to be sent to the Flexibowl:

| Action                | Description   |
|-----------------------|---|
| <b>MOVE</b>           | Moves the feeder the current parameters.                    |
| <b>MOVE-FLIP</b>      | Moves the feeder and activates Flip simultaneously          |
| <b>MOVE-BLOW-FLIP</b> | Moves the feeder and activates Flip and blow simultaneously |
| <b>MOVE-BLOW</b>      | Moves the feeder and activates Flip simultaneously          |
| <b>SHAKE</b>          | Shakes the feeder with the current parameters               |
| <b>LIGHT ON</b>       | Light on  |
| <b>LIGHT OFF</b>      | Light off   |
| <b>FLIP</b>           | Flip  |
| <b>BLOW</b>           | Blow  |
| <b>QUICK_EMPTYING</b> | Quick Emptying Option                                       |
| <b>RESET_ALARM</b>    | Reset Alarm and enable the motor                            |

| Command     | Description           |
|-------------|-----------------------|
| <b>QX2</b>  | Move                  |
| <b>QX3</b>  | Move - Flip           |
| <b>QX4</b>  | Move - Blow - Flip    |
| <b>QX5</b>  | Move - Blow           |
| <b>QX5</b>  | Shake                 |
| <b>QX7</b>  | Light on              |
| <b>QX8</b>  | Light off             |
| <b>QX9</b>  | Flip                  |
| <b>QX10</b> | Blow                  |
| <b>QX11</b> | Quick Emptying Option |
| <b>QX12</b> | Reset Alarm           |



## ACE versione 3




From here on we will see how to integrate the Flexibowl Plugin into Ace 3.X or earlier versions.

### STEP 1:

Create THREE String V+ variables.

- Ip
- Command
- RerturnFlexibowl




## ACE versione 3




### STEP 2:

Create a folder in the WorkspaceExplorer and call it Flexibowl.  
Now right click the folder just created, ImportWorkspaceFile, and upload the FlexibowlPlugin.awp file provided by us.



### STEP 3:

Now the V+ variables need to be indexed with the C# variables.  
For example, double click the C# Ip variable. By setting this variable as a *ControllerStringVariable* (black box), it can be associated with our V+ Ip variable (green box). Do this for all three variables.



## ACE versione 3

### STEP 4:

You need to check that the paths of the C# variables are correct.

To verify this, check the box highlighted in the image to make sure the paths of the three variables are correct.

To do this, select one of the three C# variables, drag&drop on the code page and check that the path is correct.

In this case you have created a reference to your variable; check the correct path and delete the line created.

Ensure the paths of the three variables in the code are correct.


#### Example:

Original

```
IVariableString Command = (IVariableString) ace["/Application Manager0/Variables/Command"];
```

Edited

```
IVariableString Command = (IVariableString) ace["/Application Manager4/Variables/Command"];
```



## STEP 5:

We will now see how to set the variables and run the script from V+  
Let's create a V+ program with the code on the next page.  
Copy the code and check that the paths of the variables are correct, e.g.:

*\$object = "/Application Manager0/Variables/Ip"*

After setting the Ip and the command, by running the V+ script the flexibowl will carry out the command

```
;insert the data
;/////////////////////////////////
$ip="169.254.1.10"
$command="QX3"

.PROGRAM flexibowlplg()

    AUTO $object, $variable, $ip, $command , $return.flexibow
, $method, $args[0]
    AUTO REAL status, is.alive

    ;insert the data
    ;/////////////////////////////////
    $ip="169.254.1.10"
    $command="QX3"
    ;/////////////////////////////////

    ;Execute the c#
    CALL rm.chk.server(is.alive)
    IF (is.alive == FALSE) THEN
        TYPE "Not Communicating"
        PAUSE
    END    ; Execute a script on the server and wait for 3
seconds for it to complete
    $object = "/Flexibowl/Flexibowl"
    $method = "Execute"
    CALL rm.execute($object, $method, 0, $args[], 5, status)
    IF (status < 0) THEN
        TYPE "Problem executing script: ", status
        PAUSE
    END

    ;the Answer
    ;$returnflexibowl

.END
```

*At the moment the Ip, Command and return.flexibow variables in V+ are local (AUTO). To set them from external programs, make these variables Global, therefore not Auto.  
Running the V+ script will execute the C# script, which will operate the flexibowl*

