



JV Management System

Doc Number : GMJV-KeNHA-BRW-WO-M039FM008
Revision : 01
Doc Type : Form
Author/Owner : Wellington Odali
Reviewed by : Maurice Ademba
Effective Date : January 2022
Review Date : January 2023
Number Pages : Page 1 of 3
Approved by : Godfrey Walala

Title: Daily Maintenance Report

Site Name		BUSIA			
Dates/Duration		30/08/2022			
Technician Name		BULLY MOGAKA			
Systems			System Check		Comments/issues/observations
			X	✓	
	VOLTAGE				
Electrical Systems	<u>LINE VOLTAGE</u>				} Within range
	L1-L2	428	✓		
	L1-L3	419	✓		
	L2-L3	425	✓		
	<u>PHASE VOLTAGE</u>				
	L1-N	249	✓		
	L2-N	246	✓		
	L3-N	248	✓		
	<u>PHASE & EARTH</u>				
	L1-E	249	✓		
	L2-E	246	✓		
	L3-E	248	✓		
	<u>OTHER APPLIANCES</u>				
	Isolators		✓		} okay
	MCCBs		✓		
Contactors		✓			
MCBs		✓			
Photocells		✓			
Scales systems Check the following:-	Scale Accuracy		✓		} okay
	Indicator Functionality		✓		
	System Grounding		✓		
	Remote Display Unit	X		4 RDUs are faulty	



JV Management System

Doc Number : GMJV-KeNHA-BRW-WO M039FM008

Revision : 01

Doc Type : Form

Author/Owner : Wellington Odali

Reviewed by: Maurice Ademba

Effective Date : January 2022

Review Date : January 2023

Number Pages : Page 2 of 3

Approved by : Godfrey Walala

Title: Daily Maintenance Report

Traffic control system Check the following:-	Booms functionality Traffic lights Clean cameras Network equipment	x ✓ ✓ ✓	Functional but arms are not connected } Okay
Generator Check the following:-	Battery Voltage Test run genset Fuel level Voltages on test run(vac) Run hours to service Emergency button	✓ ✓ ✓ ✓ ✓	13.7 VDC OK 3/4 full L-L 415V, L-N 240V 46.2 hrs Okay
Buildings & General Maintenance Check the following:-	Power to Buildings Power to Switches Power to socket outlets Power to Bulbs Power to Floodlights Air Conditioners Leaking Roof Drainage	✓ ✓ ✓ ✓ x x ✓	} Okay COP's AC is faulty None Okay



JV Management System

Doc Number : GMJV-KeNHA-BRW-WO-M039FM008

Revision : 01

Doc Type : Form

Author/Owner : Wellington Odali

Reviewed by : Maurice Ademba

Effective Date : January 2022

Review Date : January 2023

Number Pages : Page 3 of 3

Approved by : Godfrey Walala

Title: Daily Maintenance Report

Others		✓		None
Health, Safety & Environment				
Check the following:	Adherence to safety procedures by staff		✓	} Adhered to
	Adheres to min PPE		✓	
	Potential hazards	x		

Prepared By: (Technician) BILLY MOGAKA Sign BILLY

Checked By: (Duty Manager) Duncan Odhiambo Sign Duncan





JV Management System

Doc Number : GMJV-KenHA-BRW-WOM039FM002

Revision : 01

Doc Type : Form

Author/Owner : Wellington Odali

Reviewed by : Maurice Ademba

Effective Date : January 2022

Review Date : January 2023

Number Pages : Page 1 of 2

Approved by : Godfrey Walala

Title: Generator Start-Up Form

Name of Technician

BILLI MOGAKA

Date or Duration valid

30/08/2022

Site Name

BUSIA

GENERATOR START UP PROCEDURE-14KVA 3PHASE TEKSAN GENERATOR

	✓	X	COMMENTS
1. Ensure the emergency (RED) buttons are NOT pressed in. If pressed-in twist clockwise and the button will pop out.	✓		Done & working correctly
2. Press the STOP soft key for 2 seconds to clear any old emergency status	✓		
3. Press the AUTO soft key till the GREEN LED appears to show the generator is on automatic standby.	✓		
4. Incase the generator is switched off using the emergency button, follow the steps 1 to 3 again	✓		
5. Whenever the generator does not start automatically and its on AUTO standby, press the OFF soft key button then press either AUTO or MANUAL soft key button	✓		
6. When generators comes ON afrer procedure 5. above press the AUTO soft key button	✓		
7. To stop the generator whenever the automatic change over does not switch it OFF use the STOP soft key not the EMERGENCY button	✓		
8. Always ensure before locking the generator shelter that you inspect it for leakages. Follow steps 1 and finally inspect the cables	✓		



JV Management System

Doc Number : GMJV-KeNHA-BRW-WOM039FM002

Revision : 01

Doc Type : Form

Author/Owner : Wellington Odali

Reviewed by: Maurice Ademba

Effective Date : January 2022

Review Date : January 2023

Number Pages : Page 2 of 2

Approved by : Godfrey Walala

Title: Generator Start-Up Form

RESETTING THE GENERATOR AFTER SERVICE ALARMS COME ON

1. Use the programme (PGM) arrow < > soft keys to select the function on the controller screen.	✓		
2. Select COUNTERS screen, the first screen will show engine total hours of running, after pressing the arrow key again, the second COUNTERS screen will show Engine hours to service request	✓		
3. If the hours (100hrs) to service request have already been achieved and the alarm lamp for service request and the hazard lamp are ON, call the service provider immediately	✓		
4. To enable the generator to run before the service provider is on site, clear the alarms by pressing the test lamp ☼ and the alarm ☰ soft key buttons together for 2secs till alarm ! Clears then press the STOP soft key button to clear the alarm for service request.	✓		
5. Press the AUTO button soft key button.	✓		

Done
Working
Correctly

Prepared By: (Technician) BILLY MOGAKA

Sign

Checked By: (Duty Manager) Duncan Odhiambo

Sign





JV Management System

Title: HSWIM Check List

Doc Number : GMJV-KeNHA-BRW-VOM039FM004

Revision : 01

Doc Type : Form

Author/Owner : Wellington Odali

Reviewed by: Maurice Ademba

Effective Date : January 2022

Review Date : January 2023

Number Pages : Page 1 of 1

Approved by : Godfrey Walala

HSWIM CHECK LIST

Name of Technician

BILLY MOGAKA

Date or Duration valid

30/08/2022

Site Name

BUSIA

PHYSICAL & SYSTEM CHECKS	FREQ	✓	X	COMMENTS
1. Check on the functionality of Weighing Sensors	D	✓		Working correctly
2. Check on the functionality of Loops	D	✓		
3. Check on the functionality of MSI Position Sensors	D	✓		
4. Check on the functionality of ANPR cameras	D	✓		
5. Check on the functionality of Overview Cameras	D	✓		
6. Check on the alignment of ANPR and Overview Cameras	D	✓		
7. Check on the functionality of gantry floodlights	D	✓		Additional lights needed
8. Check whether HSWIM parameters are transmitted and viewed at the Directing Office.	D	✓		Working correctly
9. Check on the state of Grounding and Lightening Arrestors	D	✓		
10. Check on the Physical State of HSWIM Equipment	D	✓		
i) Check cables are intact and well terminated and not exposed	D	✓		
ii) Check on the grouting status of the sensors	M	✓		3 bollards are broken
iii) Check on the physical state of the gantry (ensure it is not knocked/damaged)	D	✓		
iv) Check on the state of gantry protection (bollards)	D	✓		
v) Check cable routing (pipes, sleeves and ducts) are secure and not flooded with water	D	✓		
vi) Check whether silt/soil has accumulated at the sensor area	D	✓		Not silting or flooding
vii) Check drainage around the sensor area to ensure it is not flooded.	D	✓		Main road has flooding near the loop area.
11. Check on the white box components	D			okay
i) Check on the functionality and physical state of Breakers, Connectors, PLCs, Network Switches, Power Supply and cable termination.	D	✓		
*Gantry Cameras to be cleaned and aligned monthly	M	✓		

Prepared By: (Technician)

BILLY MOGAKA

Sign

Checked By: (Duty Manager)

Duncan Odhiambo

Sign





JV Management System

Doc Number : GMJV-KeNHA-BRW-WOM039FM007

Revision : 01

Doc Type : Form

Author/Owner : Wellington Odali

Reviewed by : Maurice Adamba

Effective Date : January 2022

Review Date : January 2023

Number Pages : Page 1 of 1

Approved by : Godfrey Walala

Title: SCALE ANPR, SCALE SIDE VIEW & CCTV CAMERAS CHECK LIST

SCALE ANPR, SCALE SIDE VIEW & CCTV CAMERAS CHECKLIST

Name of Technician

BILLY MOGAKA

Date or Duration valid

30/08/2022

Site Name

BUSIA

CAMERAS CHECKLIST	FREQ	✓	X	Comments
ANPR & Side View photos				
1. Check with the system administrators at the image server all cameras to ensure they are all ON	D	✓		Checked, all is working correctly
2. If all cameras are OFF check the single phase consumer unit at the weighing room for any tripped MCB	D	✓		
3. If the cameras are OFF randomly, check the yellow boxes at the camera pole for a tripped MCB or a faulty blue ginger PSU (check LED)	D	✓		
4. If blue ginger and/or circuit breaker are faulty after testing the input and output ensure they are replaced (AC circuit breaker input & output=240V while Blue ginger input AC 240V & output DC 12V)	D	✓		
5. If 4 above is true test the camera functionality from the server with the system admin	D	✓		
6. Inspect cameras' 4 port IP switches in the outdoor housing-Check that its powered, ports LED blinking, cables connected securely	W	✓		
7. Inspect all cameras for physical damage or misalignment	D	✓		
8. Inspect cameras view relative to master alignment photo.	D	✓		
9. If camera is misaligned after 7 above, realign the camera as required and test the view from the image server again	D	✓		
10. Wipe all camera view window with a clean damp cloth followed by a dry lint free cloth till the window is clean	W	✓		
11. Inspect the lanes next to the cameras for probable danger of knocking the poles and advise accordingly	D	✓		
12. Check floodlights for proper functionality-ON/OFF status as required- (Night inspection)	W	✓		
13. Check floodlights for proper alignment	W	✓		
CCTV				
1. Check at the LED monitor for ON or OFF status for all CCTV cameras	D	✓		okay
2. If any camera is OFF check the single phase consumer unit at the weigh room for any tripped MCB	D	✓		
3. Check BNC connectors for proper connections at the back of the DVR in case 2 above is ON and cameras are still OFF	D	✓		
4. Check for proper focus of each CCTV camera	W	✓		
5. If any camera is off focus, have a person (system admin) at the screen and yourself at the camera to adjust the focus knobs under the Redi view cameras till focus is restored.	W	✓		
6. Check the playback of the CCTV cameras at the DVR at different dates and time	W	✓		
7. Inspect the CCTV cameras for physical damage and misalignment	W	✓		
8. If misaligned after 6 above ensure they are correctly aligned as per the master alignment photo	W	✓		
9. Wipe all camera view window with a clean damp cloth followed by a dry lint free cloth till the window is clean	W	✓		

Additional light required (KMP) BND NPR



NOTES

1. Use a lint free cloth to clean Camera lenses and windows
2. Use a properly functioning multimeter to measure voltage
3. Ensure you have all minimum personal protective safety gear while working at heights