

Network-related Synchronization

- `sync/control`

- `control[31]` is the “ARM SOWF” bit (0x80000000). This bit needs to be set on all ROACH2’s pretty close to each other (within one SOWF cycle). The internal SOWF generator synchronizes to the first external SOWF pulse after a rising edge of this bit.
- `control[30]` is the “ARM 1PPS” bit (0x40000000). This bit needs to be set on all ROACH2’s pretty close to each other (within one 1PPS cycle). The internal SOWF generator synchronizes to the first external 1PPS pulse after a rising edge of this bit.
- `control[29]` is the “Arm MCNT” bit (0x20000000). This bit needs to be set on all ROACH2’s pretty close to each other (within one sync cycle). The MCNT counter resets on the first sync pulse after a rising edge of this bit.
- `control[0]` is the “SOWF/1PPS” select bit (0x000000001). This bit specifies which ADC provides SOWF and which ADC provides 1PPS. If it is a 0, then SOWF is expected via ADC0 and 1PPS is expected via ADC1. If it is a 1, then 1PPS is expected via ADC0 and SOWF is expected via ADC1.

Network-related Scope Configuration

- `scope/ctrl`

This register controls the behavior of the “scope” functionality.

- `ctrl[23:16]` - Sync out select. A value of 31 (16+15) selects the network’s [received?] sync out signal. [Really? Maybe it’s just 15?]
- `ctrl[15:08]` - Snap select 1. A value of 12 selects the network [received?] data signals for snapshotting in `scope/snap1`.
- `ctrl[07:00]` - Snap select 0. A value of 12 selects the network [received?] data signals for snapshotting in `scope/snap0`.

Network Configuration and Control

- `network/ctrl`

Control register for network related logic.

- `ctrl[31]` = 10 GbE Core Reset
- `ctrl[30]` = RX FIFO Reset
- `ctrl[5]` = Network TX Enable
- `ctrl[4]` = Network RX Enable
- `ctrl[0]` = Bypass control (0=normal; 1=bypass)

- `network/eth/0` to `network/eth/3`

These are the 10 GbE cores. They must have the low byte of their IP address set to this 8 bit binary value: 0RRR11EE, where RRR is the ROACH2 ID (0-7, i.e. basically the same thing as FID) and EE is the two bit core number (0-3). For example, eth2 (EE=10) on FID=3 (RRR=011) would need to have the low byte of its IP address set to: 00111110 = 0x3e = 62. The high three bytes of a core’s IP address must be set to the same value as the high three bytes of network/ipbase. MAC addresses and ARP tables must also be setup accordingly.

FID	eth0	eth1	eth2	eth3
0	12	13	14	15
1	28	29	30	31
2	44	45	46	47
3	60	61	62	63
4	76	77	78	79
5	92	93	94	95
6	108	109	110	111
7	124	125	126	127

Table 1: Last octet of 10 GbE IP addresses for each F engine.

- **network/fid**

The low 3 bits of this register sets the FID (F engine ID) of the ROACH2. This is basically input/antenna number. Each ROACH2 must have a unique value from 0 to 7.

- **network/ipbase**

The high 24 bits set the first three octets of the destination IP address that packets are sent to. This must match the high 24 bits of the 10 GbE cores' IP addresses.

Network Monitoring

- **network/eth/status**

Each byte contains 6 status bits from each ethernet core. The least significant byte is port 0. the most significant byte is port 3. Within each byte, the bits are:

- **status[5]: rx_overnrun**
- **status[4]: led_up** (maybe always up since it only reflects status to SFP+ phy?)
- **status[3]: led_rx**
- **status[2]: led_tx**
- **status[1]: tx_afull**
- **status[0]: tx_overflow**

- **network/mcnt/rx**

The 8 least significant bits of the received MCNTs on each interface all in one 32 bit register.

- **rx[07:00]** is 8 LSbs of mcnt received on eth0
- **rx[15:08]** is 8 LSbs of mcnt received on eth1
- **rx[23:16]** is 8 LSbs of mcnt received on eth2
- **rx[31:24]** is 8 LSbs of mcnt received on eth3

- **network/mcnt/rx0 to network/mcnt/rx3**

Contains the 32 least significant bits of the received MCNTs on each interface.

- **rx0** is 32 LSbs of mcnt received on eth0
- **rx1** is 32 LSbs of mcnt received on eth1
- **rx2** is 32 LSbs of mcnt received on eth2
- **rx3** is 32 LSbs of mcnt received on eth3
- **network/mcnt/tx**
Contains the 32 LSbs of mcnt that is being sent over net interfaces.
- **network/pcnt**
Each byte is a count (0-31) of packets buffered in each of the four packet buffers (one per 10 GbE core). The low byte is eth0.
- **network/sowf/cnt0 to network/sowf/cnt3**
Received Start of Walsh Frame counters for each interface. The “RX FIFO Reset” bit (network/ctrl[30]) resets the counters.
 - **cnt0** is count of SOWF rising edges received on eth0
 - **cnt1** is count of SOWF rising edges received on eth1
 - **cnt2** is count of SOWF rising edges received on eth2
 - **cnt3** is count of SOWF rising edges received on eth3
- **network/sync_count**
Count of sync pulses sent to the X engines. This register should increment exactly once per Walsh frame.
- **network/xid**
Each byte is bits 12 down to 5 of the most recently received XID on each 10 GbE core. The low byte is eth0. This is essentially the same thing as bits 13 down to 6 of the most recently received channel number. Bits 4 down to 0 of the received XID should be constant for each 10 GbE core.

Data Distribution

I think the channels going into the X engine on ROACH2 #0 (FID=0) will be:

```
First 8 channels in parallel:  0   1   2   3   4   5   6   7
Next 8 channels in parallel: 64 65 66 67 68 69 70 71
Next 8 channels in parallel: 128 129 130 131 132 133 134 135
And so on...
```

The channels for FID=1 will be the same pattern as for FID=0, but 8 channels higher. The channels for FID=2 will be the same pattern as for FID=0, but 16 channels higher. And so on...

Other Registers

This section describes other registers that are not specifically network related.

- **source/ctrl**
Control register for selecting/controlling F engine input sources.

- `ctrl[31]` = Arm noise source 1
- `ctrl[30]` = Arm noise source 0
- `ctrl[29:18]` = Tone frequency 1 (units?)
- `ctrl[17: 6]` = Tone frequency 0 (units?)
- `ctrl[5: 3]` = Input selector 1
- `ctrl[2: 0]` = Input selector 0

Input selector values are:

- 0 = All 0x00
- 1 = All 0x80 (maybe not working as intended?)
- 2 = ADC
- 3 = Noise
- 4 = Tone
- 5 = Dither (noise+tone?)
- 6 = All 0x00
- 7 = All 0x00

- `source/seed0`

Sets the seed of the noise generator 0.

- `source/seed1`

Sets the seed of the noise generator 1.

- `sync/ext_pps_cnt`

The count of external 1PPS pulses received (cannot be reset).

- `sync/ext_pps_period`

The period between the two most recent external 1PPS pulses.

- `sync/ext_sowf_cnt`

The count of external SOWF pulses received (cannot be reset).

- `sync/ext_sowf_period`

The period between the two most recent external SOWF pulses.