

ION Deployment Guide

Version 3.7.2

13 July 2020

Jane Marquart, NASA

Greg Menke, Columbus

Larry Shackelford, Microtel LLC

Scott Burleigh, Jet Propulsion Laboratory, California Institute of Technology

Contents

Overview	1
Configuration	2
Building the “ici” package	2
Building the “ltp” package	6
Building the “bp” package	7
Building the “ams” package	8
Building the “cfdp” package.....	8
Startup	9
Runtime Parameters	9
Multi-node Operation	10
Shutdown	11
Example Configuration Files.....	12
The ltpadmin Add Span command.....	17
Bundle-in-Bundle Encapsulation.....	24
Introduction to BIBE.....	24
Configuring BIBE in ION.....	25
Adaptation	28
Error Logging.....	28
Memory Allocation	28
Operation	30
“Wrong profile for this SDR”	30
Destroying a node	30
“No such directory; disabling heap residence in file...”	31
“Can’t find ION security database”	31
Clock sync.....	31
Node numbers	32
Duct names	32
Config file pitfalls to watch for.....	32
Porting.....	34
From Gary Grobe, 6 March 2012:	34

Acknowledgment

Some of the technology described in this Deployment Guide was developed at the Jet Propulsion Laboratory, California Institute of Technology, under a contract with the National Aeronautics and Space Administration.

Copyright © 2020 California Institute of Technology

Overview

The effort required to deploy the Interplanetary Overlay Network (ION) software in an operational setting may vary widely depending on the scope of the deployment and the degree to which the required ION functionality coincides with the capability provided by default in the software as distributed. This effort will be expended in two general phases: initial *infusion* and ongoing *operation*.

Infusion

Even in the best case, some minimal degree of configuration will be required. Many elements of ION behavior are managed at run time by decisions recorded in ION's protocol state databases, as populated by a variety of administration utility programs. Others are managed at compile time by means of compiler command-line switches selected when the software is built. These options are described in the [Configuration](#) section below.

In some cases, mission-specific behavior that goes beyond the options built into ION must be enabled during ION deployment. The intent of the ION design is to minimize – to eliminate, if possible – any need to modify ION source code in order to enable mission-specific behavior. Two general strategies are adopted for this purpose.

First, ION includes a number of conditionally defined functions that can be cleanly replaced with mission-specific alternative source code by setting a compiler command-line switch at build time. Setting such a switch causes the mission-specific source code, written in C, to be simply included within the standard ION source code at the time of compilation.

Second, more generally it is always possible to add new application executables, new startup/shutdown/monitor/control utilities or scripts, and even entirely new route computation systems, BP convergence-layer adapters, and/or LTP link service adapters without ever altering the distributed ION source code. Guidelines for making these kinds of modifications are described in the [Adaptation](#) section below.

Finally, in rare cases it may be necessary to execute ION in an operating-system environment to which it has not yet been ported. Guidance for porting ION to new platforms will be provided in a future edition of this Deployment Guide.

Operation

On an ongoing basis, an ION deployment may require reconfiguration from time to time and/or may require troubleshooting to resolve performance or stability problems. Some suggestions for reconfiguration and troubleshooting procedures are offered in the [Operation](#) section below.

Configuration

Building the “ici” package

Declaring values for the following variables, by setting parameters that are provided to the C compiler (for example, `-DFSWSOURCE` or `-DSM_SEMBASEKEY=0xff13`), will alter the functionality of ION as noted below.

PRIVATE_SYMTAB

This option causes ION to be built for VxWorks 5.4 or RTEMS with reliance on a small private local symbol table that is accessed by means of a function named `sm_FindFunction`. Both the table and the function definition are, by default, provided by the `symtab.c` source file, which is automatically included within the `platform_sm.c` source when this option is set. The table provides the address of the top-level function to be executed when a task for the indicated symbol (name) is to be spawned, together with the priority at which that task is to execute and the amount of stack space to be allocated to that task.

`PRIVATE_SYMTAB` is defined by default for RTEMS but not for VxWorks 5.4.

Absent this option, ION on VxWorks 5.4 must successfully execute the VxWorks `symFindByName` function in order to spawn a new task. For this purpose the entire VxWorks symbol table for the compiled image must be included in the image, and task priority and stack space allocation must be explicitly specified when tasks are spawned.

FSWLOGGER

This option causes the standard ION logging function, which simply writes all ION status messages to a file named `ion.log` in the current working directory, to be replaced (by `#include`) with code in the source file `fswlogger.c`. A file of this name must be in the inclusion path for the compiler, as defined by `-Ixxxx` compiler option parameters.

FSWCLOCK

This option causes the invocation of the standard `time` function within `getUTCTime` (in `ion.c`) to be replaced (by `#include`) with code in the source file `fswutc.c`, which might for example invoke a mission-specific function to read a value from the spacecraft clock. A file of this name must be in the inclusion path for the compiler.

FSWWDNAME

This option causes the invocation of the standard `getcwd` function within `cfdpInit` (in `libcfdpP.c`) to be replaced (by `#include`) with code in the source file `wdname.c`, which must in some way cause the mission-specific value of current working directory name to be copied into `cfdpdbBuf.workingDirectoryName`. A file of this name must be in the inclusion path for the compiler.

FSWSYMTAB

If the `PRIVATE_SYMTAB` option is also set, then the `FSWSYMTAB` option causes the code in source file `mysymtab.c` to be included in `platform_sm.c` in place of the default symbol table access implementation in `syntab.c`. A file named `mysymtab.c` must be in the inclusion path for the compiler.

FSWSOURCE

This option simply causes `FSWLOGGER`, `FSWCLOCK`, `FSWWDNAME`, and `FSWSYMTAB` all to be set.

GDSLOGGER

This option causes the standard ION logging function, which simply writes all ION status messages to a file named `ion.log` in the current working directory, to be replaced (by `#include`) with code in the source file `gdslogger.c`. A file of this name must be in the inclusion path for the compiler, as defined by `-Ixxxx` compiler option parameters.

GDSSOURCE

This option simply causes `GDSLOGGER` to be set.

ION OPS_ALLOC=xx

This option specifies the percentage of the total non-volatile storage space allocated to ION that is reserved for protocol operational state information, i.e., is not available for the storage of bundles or LTP segments. The default value is 40.

ION_SDR_MARGIN=xx

This option specifies the percentage of the total non-volatile storage space allocated to ION that is reserved simply as margin, for contingency use. The default value is 20.

The sum of `ION_OPS_ALLOC` and `ION_SDR_MARGIN` defines the amount of non-volatile storage space that is sequestered at the time ION operations are initiated: for purposes of congestion forecasting and prevention of resource oversubscription, this sum is subtracted from the total size of the SDR “heap” to determine the maximum volume of space available for bundles and LTP segments. Data reception and origination activities fail whenever they would cause the total amount of data store space occupied by bundles and segments to exceed this limit.

HEAP_PTRS

This is an optimization option for the SDR non-volatile data management system: when set, it enables the value of any variable in the SDR heap to be accessed directly by means of a pointer into the dynamic memory that is used as the data store storage medium, rather than by reading the variable into a location in local stack memory. Note that this option must **not** be enabled if the data store is configured

for file storage only, i.e., if the SDR_IN_DRAM flag was set to zero at the time the data store was created by calling `sdr_load_profile`. See the `ionconfig(5)` man page in Appendix A for more information.

NO_SDR_TRACE

This option causes non-volatile storage utilization tracing functions to be omitted from ION when the SDR system is built. It disables a useful debugging option but reduces the size of the executable software.

NO_PSM_TRACE

This option causes memory utilization tracing functions to be omitted from ION when the PSM system is built. It disables a useful debugging option but reduces the size of the executable software.

IN_FLIGHT

This option controls the behavior of ION when an unrecoverable error is encountered.

If it is set, then when an unrecoverable error is encountered the status message “Unrecoverable SDR error” is logged and the SDR non-volatile storage management system is globally disabled: the current data store access transaction is ended and (provided transaction reversibility is enabled) rolled back, and all ION tasks terminate.

Otherwise, the ION task that encountered the error is simply aborted, causing a core dump to be produced to support debugging.

SM_SEMKEY=0xXXXX

This option overrides the default value (0xee01) of the identifying “key” used in creating and locating the global ION shared-memory system mutex.

SVR4_SHM

This option causes ION to be built using `svr4` shared memory as the pervasive shared-memory management mechanism. `svr4` shared memory is selected by default when ION is built for any platform other than MinGW (for which File Mapping objects are used), VxWorks 5.4, or RTEMS. (For the latter two operating systems all memory is shared anyway, due to the absence of a protected-memory mode.)

POSIX1B_SEMAPHORES

This option causes ION to be built using POSIX semaphores as the pervasive semaphore mechanism. POSIX semaphores are selected by default when ION is built for RTEMS but are otherwise not used or supported; this option enables the default to be overridden.

SVR4_SEMAPHORES

This option causes ION to be built using svr4 semaphores as the pervasive semaphore mechanism. svr4 semaphores are selected by default when ION is built for any platform other than MinGW (for which Windows event objects are used), VxWorks 5.4 (for which VxWorks native semaphores are the default choice), or RTEMS (for which POSIX semaphores are the default choice).

SM_SEMASEKEY=0XXXXX

This option overrides the default value (0xee02) of the identifying “key” used in creating and locating the global ION shared-memory semaphore database, in the event that svr4 semaphores are used.

SEMMNI=xxx

This option declares to ION the total number of svr4 semaphore sets provided by the operating system, in the event that svr4 semaphores are used. It overrides the default value, which is 128. (Changing this value typically entails rebuilding the O/S kernel.)

SEMMSL=xxx

This option declares to ION the maximum number of semaphores in each svr4 semaphore set, in the event that svr4 semaphores are used. It overrides the default value, which is 250. (Changing this value typically entails rebuilding the O/S kernel.)

SEMMNS=xxx

This option declares to ION the total number of svr4 semaphores that the operating system can support; the maximum possible value is SEMMNI x SEMMSL. It overrides the default value, which is 32000. (Changing this value typically entails rebuilding the O/S kernel.)

Note that this option is also supported in the MinGW (Windows) port of ION, with the same default value; changing this value does **not** involve an operating system modification.

ION_NO_DNS

This option causes the implementation of a number of Internet socket I/O operations to be omitted for ION. This prevents ION software from being able to operate over Internet connections, but it prevents link errors when ION is loaded on a spacecraft where the operating system does not include support for these functions.

ERRMSGGS_BUFSIZE=xxxx

This option set the size of the buffer in which ION status messages are constructed prior to logging. The default value is 4 KB.

SPACE_ORDER=x

This option declares the word size of the computer on which the compiled ION software will be running: it is the base-2 log of the number of bytes in an address. The default value is 2, i.e., the size of an

address is $2^2 = 4$ bytes. For a 64-bit machine, `SPACE_ORDER` must be declared to be 3, i.e., the size of an address is $2^3 = 8$ bytes.

NO_SDRMGT

This option enables the SDR system to be used as a data access transaction system only, without doing any dynamic management of non-volatile data. With the `NO_SDRMGT` option set, the SDR system library can (and in fact must) be built from the `sdrxn.c` source file alone.

DOS_PATH_DELIMITER

This option causes `ION_PATH_DELIMITER` to be set to `'\'` (backslash), for use in the construction of path names. The default value of `ION_PATH_DELIMITER` is `'/'` (forward slash, as is used in Unix-like operating systems).

Building the “ltp” package

Declaring values for the following variables, by setting parameters that are provided to the C compiler (for example, `-DUDP_MULTISEND`, will alter the functionality of LTP as noted below.

UDP_MULTISEND

The `UDP_MULTISEND` option can improve LTP performance by sharply reducing system call overhead: multiple LTP segments encapsulated in UDP datagrams may be transmitted with a single `sendmmsg()` call rather than multiple `sendmsg()` calls. This reduces the cost of sending LTP blocks in small segments, which in turn can limit IP fragmentation for LTP traffic.

Note that `sendmmsg()` has no built-in rate control and offers no opportunity to exercise the rate control algorithm that minimizes UDP congestion loss in non-MULTISEND LTP. In order to achieve similar reduction in UDP congestion loss, a node that receives data sent by `sendmmsg()` may need to be configured for larger socket buffers. The `sysctl` operating system utility may be used for this purpose, setting new values for `net.core.rmem_max` and `_default` and `net.core.wmem_max` and `_default`.

Note also that not all operating systems support the `sendmmsg()` system call. ION currently enables `UDP_MULTISEND` only for flavors of Linux other than bionic.

MULTISEND_SEGMENT_SIZE

By default, ION LTP in `UDP_MULTISEND` mode will always limit LTP segment size to 1450 so that every segment may be encapsulated in an IP packet whose size does not exceed the standard Ethernet frame size. For networks in which the MTU is known to be larger, this parameter may be overridden at compile time.

MULTISEND_BATCH_LIMIT

By default, the maximum number of UDP datagrams that ION LTP in `UDP_MULTISEND` mode will send in a single `sendmmsg()` call is automatically computed as the block aggregation size threshold divided by

the maximum segment size; that is, normally the amount of data sent per `sendmmsg()` call is about one LTP block. This parameter may be overridden at compile time.

MULTIRECV_BUFFER_COUNT

In `UDP_MULTISEND` mode, ION LTP will also use `recvmsg()` to receive multiple LTP segments (encapsulated in UDP datagrams) in a single system call. By default, 127 segment reception buffers (each one large enough to receive a single LTP segment of maximum size) are reserved for this purpose. This parameter may be overridden at compile time.

Building the “bp” package

Declaring values for the following variables, by setting parameters that are provided to the C compiler (for example, `-DION_NOSTATS` or `-DBRSTERM=60`), will alter the functionality of BP as noted below.

TargetFFS

Setting this option adapts BP for use with the TargetFFS flash file system on the VxWorks operating system. TargetFFS apparently locks one or more system semaphores so long as a file is kept open. When a BP task keeps a file open for a sustained interval, subsequent file system access may cause a high-priority non-BP task to attempt to lock the affected semaphore and therefore block; in this event, the priority of the BP task may automatically be elevated by the inversion safety mechanisms of VxWorks. This “priority inheritance” can result in preferential scheduling for the BP task – which does not need it – at the expense of normally higher-priority tasks, and can thereby introduce runtime anomalies. BP tasks should therefore close files immediately after each access when running on a VxWorks platform that uses the TargetFFS flash file system. The TargetFFS compile-time option ensures that they do so.

BRSTERM=xx

This option sets the maximum number of seconds by which the current time at the BRS server may exceed the time tag in a BRS authentication message from a client; if this interval is exceeded, the authentication message is presumed to be a replay attack and is rejected. Small values of `BRSTERM` are safer than large ones, but they require that clocks be more closely synchronized. The default value is 5.

ION_NOSTATS

Setting this option prevents the logging of bundle processing statistics in status messages.

KEEPALIVE_PERIOD=xx

This option sets the number of seconds between transmission of keep-alive messages over any TCP or BRS convergence-layer protocol connection. The default value is 15.

ION_BANDWIDTH_RESERVED

Setting this option overrides strict priority order in bundle transmission, which is the default. Instead, bandwidth is shared between the priority-1 and priority-0 queues on a 2:1 ratio whenever there is no priority-2 traffic.

Building the “ams” package

Defining the following macros, by setting parameters that are provided to the C compiler (for example, -DNOEXPAT or -DAMS_INDUSTRIAL), will alter the functionality of AMS as noted below.

NOEXPAT

Setting this option adapts AMS to expect MIB information to be presented to it in “amsrc” syntax (see the amsrc(5) man page in Appendix A) rather than in XML syntax, normally because the expat XML interpretation system is not installed. The default syntax for AMS MIB information is XML, as described in the amsxml(5) man page in Appendix A.

AMS_INDUSTRIAL

Setting this option adapts AMS to an “industrial” rather than safety-critical model for memory management. By default, the memory acquired for message transmission and reception buffers in AMS is allocated from limited ION working memory, which is fixed at ION start-up time; this limits the rate at which AMS messages may be originated and acquired. When -DAMS_INDUSTRIAL is set at compile time, the memory acquired for message transmission and reception buffers in AMS is allocated from system memory, using the familiar malloc() and free() functions; this enables much higher message traffic rates on machines with abundant system memory where flight software constraints on dynamic system memory allocation are not applicable.

Building the “cfdp” package

Defining the following macro, by setting a parameter that is provided to the C compiler (i.e., -DTargetFFS), will alter the functionality of CFDP as noted below.

TargetFFS

Setting this option adapts CFDP for use with the TargetFFS flash file system on the VxWorks operating system. TargetFFS apparently locks one or more system semaphores so long as a file is kept open. When a CFDP task keeps a file open for a sustained interval, subsequent file system access may cause a high-priority non-CFDP task to attempt to lock the affected semaphore and therefore block; in this event, the priority of the CFDP task may automatically be elevated by the inversion safety mechanisms of VxWorks. This “priority inheritance” can result in preferential scheduling for the CFDP task – which does not need it – at the expense of normally higher-priority tasks, and can thereby introduce runtime anomalies. CFDP tasks should therefore close files immediately after each access when running on a VxWorks platform that uses the TargetFFS flash file system. The TargetFFS compile-time option assures that they do so.

Startup

ION requires several configuration settings to be defined at startup. Most notable are the settings for the Admin functions of ION. ION provides eight admin utilities, namely bpadmin, dtn2admin, ipnadmin, ionadmin, ionsecadmin, ltpadmin, bsspadmin, and cfdpadmin. Each of the corresponding modules that is to be used at runtime will need to be configured. An admin configuration file is where the configuration commands are stored.

In the Linux environment, two different styles of configuration files are possible. The first style dictates that all configuration commands for all in-use admins will be stored in one file. This single file is sectioned off internally to separate the commands of each admin. The program named “ionstart” that installs as part of the official release is an AWK program that accepts this single configuration file’s name as a parameter. It then parses through this file looking for sectioned-off areas for each possible admin function and then uses the commands within these sections to configure the corresponding modules.

The other style dictates that each admin will have its own unique configuration file. The ionstart program supports command line switches and parameters identifying each configuration file. The ION tutorial describes each in detail.

Runtime Parameters

Another way in which ION can be tweaked dynamically is through its runtime parameters. There are several values within ION that can be set as ION starts. See the figure below for the identifier names and types of values accepted.

```
wmKey (integer)
wmSize (integer)
wmAddress (integer)
sdrName (string)
sdrWmSize (integer)
configFlags (bit pattern in integer form, e.g., 3 for 00000011)
heapWords (integer)
heapKey (integer)
pathName (string)
```

The manner in which these values get read into ION is also file dependent. One of the more prominent admin commands is the ionadmin’s “1” (the numeral one) command. The first parameter to this command is required and is a numeric value that represents the node number of the DTN node being configured. The second parameter to this command is an optional one and, if present, holds the full pathname of a local file of runtime parameter values. On both Linux and VxWorks systems, this filename should NOT be enclosed in any type of quotation marks.

If specified and located, this file is a text file with 2 fields per line; lines are processed in sequence. The first field on each line holds one of the parameter identifier text strings as shown above. The second field holds the value that will be placed into the identified parameter. Make sure that the data type specified in the second field matches the type expected.

For documentation on these parameters, see the ionconfig(5) man page.

The "configFlags" entry controls several features of the "simple data recorder" (SDR). There are several flags of interest:

```
#define SDR_IN_DRAM      1      /*      Write to & read from memory.      */
#define SDR_IN_FILE      2      /*      Write file; read file if nec.      */
#define SDR_REVERSIBLE  4      /*      Transactions may be reversed.      */
```

SDR_IN_DRAM is required for normal ION operation and should virtually always be specified.

When SDR_REVERSIBLE is specified, SDR transactions that fail (e.g., due to memory allocation failure) are rolled back, allowing transactions to fail gracefully without corrupting the ION data bases. If the flag is not supplied, failed transactions will cause an immediate exit of the task receiving the failure. This feature is intended as an aid to debugging, so in operations ION should be normally operated with reversible transactions. When transaction reversibility is enabled, ION creates & manages a log file in the directory named by "pathName" which must be writable by ION and which tracks the SDR changes and supports rollback to the last consistent state. The filesystem for this directory should be high-performance but needn't be nonvolatile; a ramdisk is ideal. The maximum size of the logfile is dependent upon the largest transaction in the SDR, and is therefore of a size on the same order of magnitude as the largest bundle. NOTE that if the directory named by "pathname" does not exist then transaction reversibility will be disabled automatically; a message to this effect will be written to the ION log file.

When SDR_IN_FILE is specified, ION creates a file in the "pathName" directory, which is maintained as a copy of the SDR heap in DRAM; whenever the SDR heap in memory is modified, the changes are also written to the sdr heap file. Thus the heap file is always the same size as the in-memory heap. Again, if the directory named by "pathname" does not exist then retention of the ION SDR heap in a file will be disabled automatically; a message to this effect will be written to the ION log file.

For documentation on the admin commands, see the man pages. The man page names are in the form of xxxrc, where xxx gets replaced by the specific module name (bp, dtn2, ion, ionsec, ipn, ltp, bssp, cfdp). The directories in which to find these files are: ./ici/doc/pod5, ./ltp/doc/pod5, ./bssp/doc/pod5, ./bp/doc/pod5, and ./cfdp/doc/pod5.

Multi-node Operation

Normally the instantiation of ION on a given computer establishes a single ION node on that computer, for which hard-coded values of wmKey and sdrName (see ionconfig(5)) are used in common by all executables to assure that all elements of the system operate within the same state space. For some purposes, however, it may be desirable to establish multiple ION nodes on a single workstation. (For example, constructing an entire self-contained DTN network on a single machine may simplify some kinds of regression testing.) ION supports this configuration option as follows:

- Multi-node operation on a given computer is enabled if and only if the environment variable ION_NODE_LIST_DIR is defined in the environment of every participating ION process. Moreover, the value assigned to this variable must be the same text string in the environments

of all participating ION processes. That value must be the name (preferably, fully qualified) of the directory in which the ION multi-node database file “ion_nodes” will reside.

- The definition of ION_NODE_LIST_DIR makes it possible to establish up to one ION node per directory rather than just one ION node on the computer. When **ionadmin** is used to establish a node, the `ionInitialize()` function will get that node’s `wmKey` and `sdrName` from the `.ionconfig` file, use them to allocate working memory and create the SDR data store, and then write a line to the `ion_nodes` file noting the `nodeNbr`, `wmKey`, `sdrName`, and `wdName` for the node it just initialized. `wdName` is the current working directory in which **ionadmin** was running at the time it called `ionInitialize()`; it is the directory within which the node resides.
- This makes it easy to connect all the node's daemon processes – running within the same current working directory – to the correct working memory partition and SDR data store: the `ionAttach()` function simply searches the `ion_nodes` file for a line whose `wdName` matches the current working directory of the process that is trying to attach, then uses that line's `wmKey` and `sdrName` to link up.
- It is also possible to initiate a process from within a directory other than the one in which the node resides. To do so, define the additional environment variable `ION_NODE_WDNAME` in the shell from which the new process is to be initiated. When `ionAttach()` is called it will first try to get “current working directory” (for ION attachment purposes **only**) from that environment variable; only if `ION_NODE_WDNAME` is undefined will it use the actual `cwd` that it gets from calling `igetcwd()`.

Shutdown

Included in the root directory of the ION distribution is a bash script named **ionstop**. This script executes each of the “admin” utilities and instructs each subsystem to exit, by supplying the dummy command file name “.”. Once all of the utilities have exited, the script calls another script named **killm** (likewise located in the root directory of ion-open-source). The **killm** script first tries to kill all ION processes by name, then tries to destroy all of the shared-memory resources allocated to ION at the time the node was created.

If you are having trouble shutting an ION node down, see the notes on “Destroying a Node” later in this Guide.

It has been pointed out that if you are running ION in a Docker container inside a Kubernetes pod, the system is likely to assign process ID 1 to one of the ION processes at startup; since process 1 cannot be killed, the **ionstop** script can’t complete and your node will not be cleanly destroyed. One solution seems to be to use `dumb-init` for the docker container:

<https://engineeringblog.yelp.com/2016/01/dumb-init-an-init-for-docker.html>

To make this work, you may have to override your entry point in the manifest file used by the Kubectl “apply” command.

Example Configuration Files

ION Node Number Cross-reference

When you define a DTN node, you do so using ionadmin and its Initialize command (using the token '1'). This node is then referenced by its node number throughout the rest of the configuration file. Instances where this node number is defined (on line number 2) and referenced are highlighted below in magenta. The node numbers of other nodes referenced below (but defined elsewhere) are highlighted in green and cyan.

```
1 ## begin ionadmin
2 1 1 /home/spwdev/cstl/ion-configs/23/badajoz/3node-udp-ltp/badajoz.ionconfig
3
4 s
5
6 a contact +1 +86400 25 25 50000000
7 a contact +1 +84600 25 101 50000000
8 a contact +1 +84600 25 1 50000000
9
10 a contact +1 +86400 101 25 50000000
11 a contact +1 +86400 101 101 50000000
12 a contact +1 +86400 101 1 50000000
13
14 a contact +1 +86400 1 25 50000000
15 a contact +1 +86400 1 101 50000000
16 a contact +1 +86400 1 1 50000000
17
18
19 a range +1 +86400 25 25 1
20 a range +1 +86400 25 101 10
21 a range +1 +86400 25 1 10
22
23 a range +1 +86400 101 25 10
24 a range +1 +86400 101 101 1
25 a range +1 +86400 101 1 10
26
27 a range +1 +86400 1 25 10
28 a range +1 +86400 1 101 10
29 a range +1 +86400 1 1 1
30
31
32 m production 50000000
33 m consumption 50000000
```

```

34
35 ## end ionadmin
36 #####
37 ## begin ltpadmin
38 1 32
39
40 a span 25 1 1 1400 1400 1 'udplso 192.168.1.25:1113 1000000000'
41 a span 101 1 1 1400 1400 1 'udplso 192.168.1.101:1113 1000000000'
42 a span 1 1 1 1400 1400 1 'udplso 192.168.1.1:1113 1000000000'
43
44 s 'udplsi 192.168.1.1:1113'
45
46 ## end ltpadmin
47 #####
48 ## begin bpadmin
49 1
50
51 a scheme ipn 'ipnfw' 'ipnadminep'
52
53 a endpoint ipn:1.0 q
54 a endpoint ipn:1.1 q
55 a endpoint ipn:1.2 q
56
57 a protocol ltp 1400 100
58 a protocol tcp 1400 100
59
60 a outduct ltp 25 ltpclo
61 a outduct ltp 101 ltpclo
62 a outduct ltp 1 ltpclo
63
64 a induct ltp 1 ltpcli
65
66 s
67
68 ## end bpadmin
69 #####
70 ## begin ipnadmin
71 a plan 25 ltp/25
72 a plan 101 ltp/101
73 a plan 1 ltp/1
74
75 ## end ipnadmin

```


IPN Parameters Cross-reference

The “ipn” scheme for URI formation is generally used to form the endpoint IDs of endpoints in an ION deployment. Any transmission using endpoints formed in the “ipn” scheme will have endpoints IDs of this form:

ipn:nodenumber.servicenumber.

The Add Scheme command on line 51 below specifies that the “ipn” endpoint naming scheme is supported; the names of three endpoints formed in this scheme are shown in lines 53 thru 55.

The two remaining parameters on this command are used to define the software functions that will act as data forwarder and administrative data receiver.

The bpadmin Add Scheme command

a scheme *scheme_name* *forwarder_command* *admin_app_command*

The add scheme command. This command declares an endpoint naming "scheme" for use in endpoint IDs, which are structured as URIs: *scheme_name:scheme-specific_part*. *forwarder_command* will be executed when the scheme is started on this node, to initiate operation of a forwarding daemon for this scheme. *admin_app_command* will also be executed when the scheme is started on this node, to initiate operation of a daemon that opens an administrative endpoint identified within this scheme so that it can receive and process custody signals and bundle status reports.

Starting at line 71, the egress plans are defined. These determine the outducts by which data are sent to nodes that are topologically adjacent to the current node in the DTN-based network.

The ipnadmin Add Plan command

a plan *node_nbr* *default_duct_expression*

The add plan command. This command establishes an egress plan for the bundles that must be transmitted to the neighboring node identified by *node_nbr*. Each duct expression is a string of the form

protocol_name/outduct_name

signifying that the bundle is to be queued for transmission via the indicated convergence layer protocol outduct.

The configuration below defines three DTN nodes with the following connections.

```
1 ## begin ionadmin
2 1 1 /home/spwdev/cstl/ion-configs/23/badajoz/3node-udp-ltp/badajoz.ionconfig
3
```

```

4 s
5
6 a contact +1 +86400 25 25 50000000
7 a contact +1 +84600 25 101 50000000
8 #a contact +1 +84600 25 1 50000000
9
10 a contact +1 +86400 101 25 50000000
11 a contact +1 +86400 101 101 50000000
12 a contact +1 +86400 101 1 50000000
13
14 #a contact +1 +86400 1 25 50000000
15 a contact +1 +86400 1 101 50000000
16 a contact +1 +86400 1 1 50000000
17
18
19 a range +1 +86400 25 25 1
20 a range +1 +86400 25 101 10
21 #a range +1 +86400 25 1 10
22
23 a range +1 +86400 101 25 10
24 a range +1 +86400 101 101 1
25 a range +1 +86400 101 1 10
26
27 #a range +1 +86400 1 25 10
28 a range +1 +86400 1 101 10
29 a range +1 +86400 1 1 1
30
31
32 m production 50000000
33 m consumption 50000000
34
35 ## end ionadmin
36 #####
37 ## begin ltpadmin
38 1 32
39
40 a span 25 1 1 1400 1400 1 'udplso 192.168.1.25:1113 1000000000'
41 a span 101 1 1 1400 1400 1 'udplso 192.168.1.101:1113 1000000000'
42 a span 1 1 1 1400 1400 1 'udplso 192.168.1.1:1113 1000000000'
43
44 s 'udplsi 192.168.1.1:1113'
45

```

```

46 ## end ltpadmin
47 #####
48 ## begin bpadmin
49 1
50
51 a scheme ipn 'ipnfw' 'ipnadminep'
52
53 a endpoint ipn:1.0 q
54 a endpoint ipn:1.1 q
55 a endpoint ipn:1.2 q
56
57 a protocol ltp 1400 100
58 a protocol tcp 1400 100
59
60 a outduct ltp 25 ltpclo
61 a outduct ltp 101 ltpclo
62 a outduct ltp 1 ltpclo
63
64 a induct ltp 1 ltpcli
65
66 s
67
68 ## end bpadmin
69 #####
70 ## begin ipnadmin
71 a plan 25 ltp/25
72 a plan 101 ltp/101
73 a plan 1 ltp/1
74
75 ## end ipnadmin
76

```

LTP Parameters Cross-reference

The ltpadmin utility allows the features of the LTP protocol to become available. For details of the LTP protocol, see RFC 5325.

The first command that must be issued to ltpadmin is the Initialize command (see line number 38 below, the command token is the '1' (one)). The sole parameter passed to this command is *est_max_export_sessions*.

The ltpadmin Initialize command

This command uses *est_max_export_sessions* to configure the hash table it will use to manage access to export transmission sessions that are currently in progress. (For optimum performance,

est_max_export_sessions should normally equal or exceed the summation of *max_export_sessions* over all spans as discussed below.)

Appropriate values for this parameter and for the parameters configuring each "span" of potential LTP data exchange between the local LTP and neighboring engines are non-trivial to determine. See the ION LTP configuration spreadsheet and accompanying documentation for details.

- Essentially, the "max export sessions" must be \geq the total number of export sessions on all the spans. If it is expected that new spans will be added during an ION session, then max export sessions figure should be large enough to cover the maximum # of sessions possible.

- Next to be defined are the Spans. They define the interconnection between two LTP engines. There are many parameters associated with the Spans.

The **ltpadmin Add Span** command

a span *peer_engine_nbr* *max_export_sessions* *max_import_sessions* *max_segment_size* *aggregation_size_limit* *aggregation_time_limit* '*LSO_command*' [*queuing_latency*]

The "add span" command. This command declares that a span of potential LTP data interchange exists between the local LTP engine and the indicated (neighboring) LTP engine.

The *max_segment_size* and the *aggregation_size_limit* are expressed as numbers of bytes of data. *max_segment_size* limits the size of each of the segments into which each outbound data block will be divided; typically this limit will be the maximum number of bytes that can be encapsulated within a single transmission frame of the underlying link service. *max_segment_size* specifies the largest LTP segment that this span will produce.

aggregation_size_limit limits the number of LTP service data units (e.g., bundles) that can be aggregated into a single block: when the sum of the sizes of all service data units aggregated into a block exceeds this limit, aggregation into this block must cease and the block must be segmented and transmitted. When numerous small bundles are outbound, they are aggregated into a block of this size instead of being sent individually.

aggregation_time_limit alternatively limits the number of seconds that any single export session block for this span will await aggregation before it is segmented and transmitted, regardless of size. The aggregation time limit prevents undue delay before the transmission of data during periods of low activity. When a small number of small bundles are outbound, they are collected until this time limit is met, whereupon the aggregated quantity is sent as a single, larger block.

max_export_sessions constitutes the size of the local LTP engine's retransmission "window" for this span. The retransmission windows of the spans impose flow control on LTP transmission, preventing the allocation of all available space in the ION node's data store to LTP transmission sessions.

The *max_import_sessions* parameter is simply the neighboring engine's own value for the corresponding export session parameter.

LSO_command is script text that will be executed when LTP is started on this node, to initiate operation of a link service output task for this span. Note that *peer_engine_nbr* will automatically be appended to *LSO_command* by ltpadmin before the command is executed, so only the link-service-specific portion of the command should be provided in the *LSO_command* string itself.

queuing_latency is the estimated number of seconds that we expect to lapse between reception of a segment at this node and transmission of an acknowledging segment, due to processing delay in the node. (See the 'm ownqtime' command below.) The default value is 1.

If *queuing_latency* is a negative number, the absolute value of this number is used as the actual queuing latency and **session purging** is enabled; otherwise session purging is disabled. If session purging is enabled for a span then at the end of any period of transmission over this span all of the span's export sessions that are currently in progress are automatically canceled. Notionally this forces re-forwarding of the DTN bundles in each session's block, to avoid having to wait for the restart of transmission on this span before those bundles can be successfully transmitted.

Additional notes:

- A "session block" is filled by outbound bundles until its aggregation size limit is reached, or its aggregation time is reached, whereupon it is output as a series of segments (of size bounded by *max_segment_size*). This series of segments is reliably transferred via a LTP protocol session with the remote node, one session per block. By adjusting the size of the session block, the rate of arrival of response segments from the remote node can be controlled. Assuming a bundle rate sufficient to fill the session block, a large session block size means a lot of LTP segments per session (good for a high-rate return, low-rate forward link situation). A small session block size means the number of segments per session is smaller and the LTP protocol will complete the block transfer more quickly because the number of segment retries is generally smaller.
- A good starting point for a configuration is to set aggregation size limit to the number of bytes that will typically be transmitted in one second, so that blocks are typically clocked out about once per second. The maximum number of export sessions then should be at least the total number of seconds in the round-trip time for traffic on this LTP span, to prevent transmission from being blocked due to inability to start another session while waiting for the LTP acknowledgment that can end one of the current sessions.
- The multiplicity of session blocks permits bundles to stream; while one session block is being transmitted, a second can be filled (and itself transmitted) before the first is completed. By increasing the number of blocks, high latency links can be filled to capacity (provided there is adequate bandwidth available in the return direction for the LTP acknowledgments). It is desirable to reduce the *max_export_sessions* to a value where "most" of the sessions are employed because each session allocates an increment of buffer memory from the SDR whether it is used or not.
- When a session block is transmitted, it is emitted as a series of back-to-back LTP segments that are simply queued for transmission; LTP does not meter segment issuance in any way. The underlying

link layer is expected to pop segments from the queue and transmit them at the current rate as indicated in the contact plan. The `udplso` task has an optional rate-limit parameter which limits the task's rate of segment transmission over UDP/IP, reducing the incidence of UDP congestion loss.

- Note that an LTP session can only be concluded (enabling space occupied by the block to be recycled) when all segments have been successfully received – or retransmission limits have been reached and the session is canceled. High bit error rates on the link correlate to high rates of data loss when segments are large and/or blocks comprise large numbers of segments; this typically results in larger numbers of NACK/retransmit cycles, retarding session completion. When bit error rates are high, LTP performance can be improved by reducing segment size and/or aggregation size limit.

The `ltpadmin Start` command

s '*LSI command*'

This command starts link service output tasks for all LTP spans (to remote engines) from the local LTP engine, and it starts the link service input task for the local engine.

The sole command on line number 44 below starts two main operations within LTP. The first of these operations starts all of the link service output tasks, the ones defined for each LTP span (see the *LSO_command* parameter of the Add Span command). In this example, each task instantiates the same function (named '`udplso`'). Each '`udplso`' needs a destination for its transmissions and these are defined as hostname or IP Address (192.168.1.*) and port number (1113, the pre-defined default port number for all LTP traffic).

The second operation started by this command is to instantiate the link service input task. In this instance, the task is named "`udplsi`". It is through this task that all LTP input traffic will be received. Similar to the output tasks, the input task also needs definition of the interface on which LTP traffic will arrive, namely hostname or IP address (192.168.1.1) and port number (1113). If it is necessary for `udplsi` to listen on multiple network interfaces simultaneously, '`udplsi 0.0.0.0[:port]`' can be invoked. This instructs `udplsi` to listen to the UDP broadcast address, which aggregates traffic from all available network interfaces, including localhost.

Once the LTP engine has been defined, initialized and started, we need a definition as to how data gets routed to the Convergence Layer Adaptors. Defining a protocol via `bpadmin` is the first step in that process.

The `bpadmin Add Protocol` command

a protocol *protocol_name* *payload_bytes_per_frame* *overhead_bytes_per_frame*

The "add protocol" command. This command establishes access to the named convergence layer protocol at the local node. The *payload_bytes_per_frame* and *overhead_bytes_per_frame* arguments are used in calculating the estimated transmission capacity consumption of each bundle, to aid in route computation and congestion forecasting.

Once the protocol has been defined, it can be used to define ducts; both inducts and outducts as seen in lines 76 thru 80 below. The Add “duct” commands associate a protocol (in this case, LTP) with individual node numbers (in this case, 25, 101 and 1) and a task designed to handle the appropriate Convergence Layer output operations. A similar scenario applies for the induct where the LTP protocol and node number 13 get connected with “ltpcli” as the input Convergence Layer function.

The bpadmin Add Outduct and Add Induct commands

a outduct *protocol_name* duct_name '*CLO_command*' [*max_payload_length*]

The “add outduct” command. This command establishes a "duct" for transmission of bundles via the indicated CL protocol. The duct’s data transmission structure is serviced by the "outduct" task whose operation is initiated by *CLO_command* at the time the duct is started. *max_payload_length*, if specified, causes ION to fragment bundles issued via this outduct (as necessary) to ensure that all such bundles have payloads that are no larger than *max_payload_length*.

a induct *protocol_name* duct_name '*CLI_command*'

The “add induct” command. This command establishes a "duct" for reception of bundles via the indicated CL protocol. The duct’s data acquisition structure is used and populated by the "induct" task whose operation is initiated by *CLI_command* at the time the duct is started.

Note that *only a single induct is needed for all bundle reception via any single protocol at any single node*, and in fact ION may operate poorly if multiple inducts are established for any single protocol. For any induct whose duct name includes an IP address, use IP address 0.0.0.0 (INADDR_ANY) if the machine on which the node resides is multihomed and you want the node to be reachable via all of the machine’s network interfaces.

Once all of this has been defined, the last piece needed is the egress plan -- namely how do packets get transmitted to DTN nodes that are the local node’s “neighbors” in the topology of the network.

As you can see from line numbers 6 thru 29, the only network neighbor to node 1 is node 101. Node 25 has not been defined (because the commands in lines 8, 14, 21 and 27 have been commented). In line numbers 15 and 16, we see that the only destinations for data beginning at node 1 are nodes 101 and 1 (a loopback as such). Therefore, in order to get data from node 1 to node 25, our only choice is to send data to node 101. Our best hope of reaching node 25 is that the configurations for node 101 define a connection to node 25 (either a one-hop direct connection, or more multi-hop assumptions). This is where egress plans come into play.

On line numbers 87 thru 89, this configuration defines the only choices that can be made regarding destinations. For a destination of node 25, which is not a neighbor, all node 1 can do is pass the data to its only neighbor, namely node 101; the “exit” command enables this operation. For destinations of nodes 101 and 1, the scenario is pretty simple.

The ipnadmin Add Exit command

a exit *first_node_nbr* *last_node_nbr* *gateway_endpoint_ID*

The “add exit” command. This command establishes an “exit” for static routing. An exit is an association of some defined routing behavior with some range of node numbers identifying a set of nodes. Whenever a bundle is to be forwarded to a node whose number is in the exit’s node number range **and** it has not been possible to compute a dynamic route to that node from the contact schedules that have been provided to the local node **and** that node is not a neighbor to which the bundle can be directly transmitted, BP will forward the bundle to the gateway node associated with this exit.

The ipnadmin Add Plan command

a plan *node_nbr duct_expression [nominal_data_rate]*

The “add plan” command. This command establishes an egress plan for the bundles that must be transmitted to the neighboring node identified by *node_nbr*.

Each duct expression is a string of the form

"protocol_name/outduct_name"

signifying that the bundle is to be queued for transmission via the indicated convergence layer protocol outduct.

The duct expression used in these examples has “ltp” being the protocol name and 101 and 1 being the outduct names.

The configuration below defines three DTN nodes with the following connections.

```

1 ## begin ionadmin
2 1 1 /home/spwdev/cstl/ion-configs/23/badajoz/3node-udp-ltp/badajoz.ionconfig
3
4 s
5
6 a contact +1 +86400 25 25 50000000
7 a contact +1 +84600 25 101 50000000
8 #a contact +1 +84600 25 1 50000000
9
10 a contact +1 +86400 101 25 50000000
11 a contact +1 +86400 101 101 50000000
12 a contact +1 +86400 101 1 50000000
13
14 #a contact +1 +86400 1 25 50000000
15 a contact +1 +86400 1 101 50000000
16 a contact +1 +86400 1 1 50000000
17
18
```



```

19 a range +1 +86400 25 25 1
20 a range +1 +86400 25 101 10
21 #a range +1 +86400 25 1 10
22
23 a range +1 +86400 101 25 10
24 a range +1 +86400 101 101 1
25 a range +1 +86400 101 1 10
26
27 #a range +1 +86400 1 25 10
28 a range +1 +86400 1 101 10
29 a range +1 +86400 1 1 1
30
31
32 m production 50000000
33 m consumption 50000000
34
35 ## end ionadmin
36 #####
37 ## begin ltpadmin
38 1 32
39
40 a span 25 1 25000 1 25000 1400 1400 1 'udplso 192.168.1.25:1113 1000000000'
41 a span 101 1 25000 1 25000 1400 1400 1 'udplso 192.168.1.101:1113 1000000000'
42 a span 1 1 25000 1 25000 1400 1400 1 'udplso 192.168.1.1:1113 1000000000'
43
44 s 'udplsi 192.168.1.1:1113'
45
46 ## end ltpadmin
47 #####
48 ## begin bpadmin
49 1
50
51 a scheme ipn 'ipnfw' 'ipnadminep'
52
53 a endpoint ipn:1.0 q
54 a endpoint ipn:1.1 q
55 a endpoint ipn:1.2 q
56
57 a protocol ltp 1400 100
58 a protocol tcp 1400 100
59
60 #a outduct ltp 25 ltpclo

```

```
61 a outduct ltp 101 ltpclo
62 a outduct ltp 1 ltpclo
63
64 a induct ltp 1 ltpcli
65
66 s
67
68 ## end bpadmin
69 #####
70 ## begin ipnadmin
71 #a plan 25 ltp/25
72 a plan 101 ltp/101
73 a plan 1 ltp/1
74 a group 25 25 101
75 ## end ipnadmin
76
```

Bundle-in-Bundle Encapsulation

For some purposes it may be helpful to encapsulate a bundle inside another bundle – that is, to let the serialized representation of a bundle be part of the payload of another bundle. This mechanism is called “Bundle-in-Bundle Encapsulation” (BIBE) and is defined in Internet Draft *draft-burleigh-dtn-bibect-00.txt* (which will likely be renamed at some point and ideally will become an IETF standards-track Request For Comments in due course).

Introduction to BIBE

By way of overview, here is an excerpt from that document:

Each BP node that conforms to the BIBE specification provides a BIBE convergence-layer adapter (CLA) that is implemented within the administrative element of the BP node's application agent. Like any convergence-layer adapter, the BIBE CLA provides:

- A transmission service that sends an outbound bundle (from the bundle protocol agent) to a peer CLA. In the case of BIBE, the sending CLA and receiving peer CLA are both BP nodes.
- A reception service that delivers to the bundle protocol agent an inbound bundle that was sent by a peer CLA (itself a BP node) via the BIBE convergence layer protocol.

The BIBE CLA performs these services by:

- Encapsulating outbound bundles in BIBE protocol data units, which take the form of Bundle Protocol administrative records as described later.
- Requesting that the bundle protocol agent transmit bundles whose payloads are BIBE protocol data units.
- Taking delivery of BIBE protocol data units that are the payloads of bundles received by the bundle protocol agent.
- Delivering to the bundle protocol agent the bundles that are encapsulated in delivered BIBE protocol data units.

Bundle-in-bundle encapsulation may have broad utility, but the principal motivating use case is the deployment of "cross domain solutions" in secure communications. Under some circumstances a bundle may arrive at a node that is on the frontier of a region of network topology in which augmented security is required, from which the bundle must egress at some other designated node. In that case, the bundle may be encapsulated within a bundle to which the requisite additional BP Security (BPSEC) extension block(s) can be attached, whose source is the point of entry into the insecure region (the "security source") and whose destination is the point of egress from the insecure region (the "security destination").

Note that:

- If the payload of the encapsulating bundle is protected by a Bundle Confidentiality Block (BCB), then the source and destination of the encapsulated bundle are encrypted, providing defense against traffic analysis that BPSEC alone cannot offer.
- Bundles whose payloads are BIBE protocol data units may themselves be forwarded via a BIBE convergence-layer adapter, enabling nested bundle encapsulation to arbitrary depth as required by security policy.
- Moreover, in the event that no single point of egress from an insecure region of network topology can be determined at the moment a bundle is to be encapsulated, multiple copies of the bundle may be encapsulated individually and forwarded to all candidate points of egress.

The protocol includes a mechanism for recovery from loss of an encapsulating bundle, called "custody transfer". This mechanism is adapted from the custody transfer procedures described in the experimental Bundle Protocol specification developed by the Delay-Tolerant Networking Research group of the Internet Research Task Force and documented in RFC 5050. Custody transfer is a convention by which the loss or corruption of BIBE encapsulating bundles can be mitigated by the exchange of other bundles, which are termed "custody signals".

BIBE is implemented in ION, but configuring ION nodes to employ BIBE is not as simple as one might think. That is because BIBE functions as both a BP application and a convergence-layer adapter; coercing the Bundle Protocol to function in both capacities, offering services to itself at two different layers of the protocol stack, requires careful configuration.

Configuring BIBE in ION

Like any convergence-layer protocol, BIBE is used to copy a bundle from one BP node (the sending node) to another node (the receiving node), over one segment of the end-to-end path from the bundle's source node to its destination node. Somewhat confusingly, in BIBE the copying of the bundle is accomplished by issuing a second encapsulating bundle, which has its own source node and destination node:

- The source node of the encapsulating bundle accepts a bundle from the sending node (which, in ION, is always the same node), encapsulates that original bundle in the encapsulating bundle, and forwards the encapsulating bundle.
- The destination endpoint of the encapsulating bundle receives the encapsulating bundle, extracts the original bundle from the encapsulating bundle, and conveys the original bundle to the receiving node (which may be the same node or some other node).

Each pair of sending and receiving nodes can be thought of as a "tunnel" which requires specific configuration. These tunnels constitute the communication relationships that must be implemented as "outducts" in ION.

BCLAs

While the node IDs of the source and destination nodes of encapsulating bundles are necessary parameters for BIBE transmission, they are not sufficient: encapsulating bundles are characterized by

quality of service, lifetime, etc., just like other bundles. For this purpose we use an additional BIBE administration utility program – **bibeadmin** – that consumes a file of **.bprc** commands; these commands add, revise, and delete BIBE convergence layer adapter objects (*bclas*) that are managed in a BIBE database. For example:

```
a bcla ipn:3.0 20 20 300 2 128
```

This command adds a bcla identified by “ipn:3.0” – the ID of the destination node of all encapsulating bundles formed according to this bcla – which asserts that the expected latency for each encapsulating bundle to reach this destination node is 20 seconds, the expected latency for a responding custody signal bundle is likewise 20 seconds, the encapsulating bundle’s time-to-live is 300 seconds, its class of service is 2 (expedited), and its ordinal sub-priority is 128.

Note that other configuration elements may also be implicitly associated with this bcla. For example, BPSEC security rules may map this BIBE source/destination node pair to security block configurations that will pertain to all encapsulating bundles formed according to this bcla.

Ducts

Since BIBE is a convergence-layer protocol, each BIBE tunnel must be configured by means of BP administration (**bpadmin**) using **.bprc** commands; BIBE must be added as a protocol, the local node must be added as the BIBE induct, and each supported BIBE tunnel must be added as a BIBE outduct. For example:

```
a protocol bibe
```

```
a induct bibe * “
```

```
a outduct bibe ipn:4.0 ‘bibeclon ipn:3.0’
```

The “a outduct” command states that the BIBE outduct (tunnel) identified by node ID “ipn:4.0” (the receiving node) is serviced by a BIBE convergence-layer output daemon operating according to the bcla identified by “ipn:3.0” as described above. The destination node ipn:3.0 is responsible for forwarding each extracted (encapsulated) bundle to the receiving node ipn:4.0. The sending node and the source node of the encapsulating bundles are both, implicitly, the local node.

Note that for most convergence-layer adapters the node ID of the receiving node for a given outduct is implicit; for example, an stcp outduct explicitly identifies only the socket address of the receiving node’s socket – that is, the convergence-layer protocol endpoint ID – not the node ID of the receiving node. BIBE differs only in that the convergence-layer protocol endpoint ID is, explicitly, the node ID of the receiving node, simply because BP is being used as the convergence-layer protocol.

Plans

In order to cause bundles to be conveyed to a specified receiving node via a BIBE outduct, that outduct must be associated with that node in an egress plan. For example, in the **.ipnrc** file:

```
a plan ipn:4.0 bibe/ipn:4.0
```

```
a plan ipn:3.0 stcp/91.7.31.134:4546
```

The first command asserts that all bundles destined for node “ipn:4.0” are to be forwarded using BIBE outduct “ipn:4.0”. The second asserts that all bundles destined for node “ipn:3.0” (here, all BIBE encapsulating bundles formed according to the bcla identified by “ipn:3.0”) are to be forwarded using the stcp outduct connected to TCP socket “91.7.31.134:4546”.

Contacts

Finally, in order for data to flow to receiving node ipn:4.0 via the bibe/ipn:4.0 outduct, a contact object must be added to the contact plan enabling the transmissions:

```
a contact +0 +10000000000 2 4 100000
```

This command states that data flow from node 2 (here, the local node) to node 4 (the receiving node) is continuously enabled, but the rate of transmission is limited to 100,000 bytes per second.

Adaptation

Error Logging

ION contains a flexible system that allows its code to display errors in several different ways. At the core of this system is a typedef that defines a data type named “Logger” (with upper case “L”) that is a function variable that accepts a character pointer (string) parameter and returns a value of type void.

```
typedef void (* Logger) (char *);
```

In ION, there is one variable defined to be of this type. Its identifier is “logger” (with lower case “l”) and it is initialized to a value of “logToStdout”. The function “logToStdout” is defined and its contents cause the string parameter to be printed to the stdout device. Therefore, any call to the function variable “logger” will have same effects as a call to the function “logToStdout”.

However, remember that “logger” is a variable and is allowed to change its value to that of other functions that accept string parameters and return void. This is how ION allows for flexibility in logging errors.

At startup, ION makes a call to “ionRedirectMemos”. This function makes a call to “setLogger” which eventually changes the value of the “logger” variable. The new value of the variable named “logger” is “writeMemoToIonLog”. This function writes strings to a file named “ion.log”.

It is through this mechanism that any calls to the functions “writeMemo”, “writeMemoNote” or “writeErrMemo” eventually pass their parameters to the function “writeMemoToIonLog”. This is how the Linux-based ION’s operate.

Checkout the FSWLOGGER macro option as documented in section 2.1.1 of the Design Guide.

Memory Allocation

What types of memory does ION use and how is memory allocated/controlled?

For an introductory description of the memory resources used by ION, see Section 1.5 of the ION Design and Operation guide entitled “Resource Management in ION”.

Section 1.5 of the Design and Operation guide makes reference to parameters called “wmSize” and “heapWords”. Discussion on these and all of the parameters can be found in this document under the section entitled “Runtime Parameters”.

ION allocates its large blocks of memory via calls to malloc. Should the need ever arise to place these large blocks of memory at known, fixed addresses, it would be possible to modify the function memalign, in the file platform.c. A better approach would be to create a shared-memory segment for each pre-allocated memory block (possibly using ION’s sm_ShmemAttach() function to do this) and pass the applicable shared-memory key values to ION at startup, in the “heapKey” and/or “wmKey” runtime parameters.

Any code that references the function “sm_ShmAttach” will be looking to acquire some block of memory. These would include the Space Management Trace features and standalone programs such as “file2sm”, “sm2file” and “sm1istsh”.

Operation

ION is generally optimized for continuous operational use rather than research. In practice, this means that a lot more attention, both in the code and in the documentation, has been paid to the care and feeding of an existing ION-based network than to the problem of setting up a new network in the first place. (The unspoken expectation is that you're only going to do it once anyway.)

Unfortunately this can make ION somewhat painful for new users to work with. The notes in this section are aimed at reducing this pain, at least a little.

“Wrong profile for this SDR”

ION is based on shared access to a common data store in memory (and/or in a file), and the objects in that data store are intended to persist across multiple restarts of network activity in a continuously operational network. That's okay for Space Station operations, but it's not helpful while you're still struggling to get the network running in the first place. For this purpose you are probably creating and destroying one or more nodes repetitively.

A key concept:

Each time you run the standard **ionstart** script provided with ION, you are creating a new network from scratch. To minimize confusion, be sure to clear out the old data store first.

If you don't wipe out the old system before trying to start the new one, then either you will pick up where you left off in testing the old system (and any endpoints, ducts, etc. you try to add will be rejected as duplicates) or – in the event that you have changed something fundamental in the configuration, or are using an entirely different configuration file – you'll see the “Wrong profile for this SDR” message and won't be able to continue at all.

Destroying a node

In most cases the **ionstop** script should do the node for you. Invoke it once for every node of your network. To verify that you're starting from a clean slate, run the **ipcs** command after **ionstop**: the list of Semaphore Arrays should be empty. If it's not, you've got one or more leftover processes from the previous network still running; use **ps ax** to find them and **kill -9** to get rid of them. The process names to look for are:

- Most names that start with “ion”, “bp”, “brs”, “stcp”, “dgr”, “ltp”, “cfdp”, or “ams”.
- **udplsi**, **udpccli**, **tcpcli**, **rxclock**.

Then run the **killm** script again to make sure the node's shared-memory resources have been released; run **ipcs** again to verify, and review your leftover processes again if those resources still haven't been released.

An additional wrinkle: if you configure ION to manage your ION data store in a file as well as (or instead of) managing it in shared memory, then in addition to calling **killm** to destroy the semaphores and the copy of the data store that resides in shared memory, you also need to delete the data store file; this destroys the copy of the data store that resides in the file system. If the data store isn't deleted, then

when you restart ION using your standard configuration file the file-system copy of the data store will automatically be reloaded into shared memory and all the config file commands that create new schemes, endpoints, etc. will fail, because they're still in the data store that you were using before.

Another habit that can be helpful: whenever you restart ION from scratch, delete all the `ion.log` files in all of the directories in which you're configuring your ION nodes. This isn't mandatory – ION will happily append new log messages to existing log files, and the messages are time-tagged anyway, so it's always possible to work out what happened when. But starting fresh with new log files removes a lot of clutter so that it's easy to see exactly what's happening in this particular iteration of your network research. ION will create new log files automatically if they don't exist; if there's something particularly interesting in the log from a prior system, copy that log file with a different name so you can come back to it if you need to.

“No such directory; disabling heap residence in file...”

This message just means that the directory whose name you've provided as the value of *pathName* in the ION configuration file does not exist, and therefore the ION operations that rely on being able to write files in that directory are disabled. It's strictly informative; nearly everything in ION will work just fine even if this message is printed every time you run.

But if you do care about transaction reversibility, for example, or if you just want to get rid of the annoying message, simply create the directory that is named in *pathName* (it can be any path name you like) and make sure it's world-writable. The `ionconfig(5)` man page discusses this parameter and others that affect the fundamental character of the system you're configuring.

“Can't find ION security database”

These messages are just warnings, but they are annoying. We're still struggling to work out a way to support bundle security protocol as fully and readily as possible but still let people run ION without it, if they want, without too much hassle.

For now, the best answer might be to insert the following lines into each `host.rc` file immediately after the `###end ionadmin` line. They should create an empty ION security database on each host, which should shut down all those warnings:

```
## begin ionsecadmin
1
## end ionsecadmin
```

Clock sync

Several key elements of ION (notably LTP transmission and bundle expiration) rely on the clocks of all nodes in the network being synchronized to within a few seconds. NTP is a good way to accomplish this, if you've got access to an NTP server. If you can't get your clocks synchronized, stick to the TCP or UDP convergence-layer adapters, don't count on using contact graph routing, and use long lifetimes on all bundles to prevent premature bundle expiration.

Node numbers

In ION we always use the same numeric value for LTP (and BSSP) engine number and BP node number – and for CFDP entity number and AMS continuum number as well. The idea is that a given ION node has a single identifying number, which by convention we use wherever a protocol endpoint identifier is needed for any local protocol agent. This is not a DTN or CCSDS requirement, but it doesn't violate any of the protocol specifications and it does marginally simplify both implementation and configuration.

Duct names

The `bprc(5)` man page explains the general format of the commands for adding convergence-layer inducts and outducts, but it doesn't provide the syntax for duct names, since duct name syntax is different for different CL protocols. Here's a summary of duct name syntax for the CL protocols supported as of ION 3.6.1:

- LTP and BSSP: the duct name is simply the engine number, which in ION is always the same as the BP node number. E.g., "9". The induct name is the number of the local node. One outduct is needed for each node to which bundles will be sent by the indicated protocol (including the local node, if you want to do BP loopback transmission), naming the corresponding induct of the receiving node.
- BRSS (bundle relay service – server): the induct name format is *hostname[:portnbr]*, where *portnbr* defaults to 80 if omitted. Whenever possible, it's best to use the host's IP address in dotted-string form ("109.32.19.6") as its "hostname". (Where host names are resolved by reference to `/etc/hosts` rather than DNS, the name of a given host may be known by a variety of different names on different peer hosts. This can introduce baffling connectivity problems.) The induct name identifies the local node's machine. All BRSS outducts are created automatically upon acceptance of connections from clients, never added by `bpadmin`.
- BRSC (bundle relay service – client): the induct and sole outduct have the same name, of the form *hostname[:portnbr]_nodenbr*, where *hostname[:portnbr]* is the BRS server's induct name and *nodenbr* is the local node's BP node number. Port number defaults to 80 if omitted.
- All other Internet-based CL protocols (udp, tcp, stcp): induct and outduct names are of the form *hostname[:portnbr]*. Port number defaults to 4556 if omitted. One outduct is needed for each node to which bundles will be sent, naming the induct of the receiving node.

Config file pitfalls to watch for

Here are some other points to bear in mind as you debug your ION node configuration:

- The ranges between all pairs of neighboring nodes are required for the correct operation of contact graph routing. The canonical form of a range expression is "from" the smaller node number "to" the larger node number, and this form implies that the range in the opposite direction is the same (as one would normally expect). A range expression with those values reversed is interpreted as an overriding range, indicating that the distance between the two nodes is not symmetrical – weird, but for some environments we have to be able to say this because the forward and reverse data paths are very different (e.g., configured to go through different antenna complexes).

- Be very careful when you code Internet-style (TCP, UDP, etc.) duct names. These names have to be correct and consistent, or else you will see no flow of data. Don't ever use "127.0.0.1" as a hostname unless you are certain you will never want to communicate with nodes on any other machines. If your hostname is mapped to an IP address in `/etc/hosts` rather than by DNS, make sure that the address that the hostname maps to is not 127.0.0.1, for the same reason.

Porting

From Gary Grobe, 6 March 2012:

Just an FYI ... we've been building on an ARM Cortex-A8 using the default profile of x86-redhat with no issues and successful transfers. And we did nothing different w/ the autotools process from what is listed in the ION documentation. This was done w/ the latest 2.5.3 OSS release on top of Debian squeeze.