



SDI-12 Quick Start Guide

Professional FW Version 6.0

SDI-12 communication protocol allows compatible devices to communicate with each other. More information about SDI-12 can be found at <http://www.sdi-12.org>. 4.1, 4.0, 3.0, 2.8 and 2.7 firmware versions have a different array of commands. Contact Stevens Water for more information.

Model Numbers

Version Part # Suffix	
02	Professional, w/25 ft. cable
02-30	Professional (Extended Temp), w/25 ft. cable
04	Professional, w/50 ft. cable
04-30	Professional (Extended Temp), w/50 ft. cable
06	Professional, w/100 ft. cable
06-30	Professional (Extended Temp), w/100 ft. cable

Power

Power Requirements	9 to 20 VDC (12VDC Ideal)
Power Consumption	<1 mA Idle, 10 mA for 2s Active

Wiring

Red Wire	+ Power Input
Black Wire	Ground
Blue Wire	SDI-12 Data Signal

Addressing

The first character of any command or response on SDI-12 is the sensor address. A lowercase ‘a’ is used to represent the address. Each SDI-12 sensor must have its own unique address. The default address is “0”. Use SDI-12 “Transparent Mode” to issue commands.

SDI-12 Command	Response	Description
aAb!	b	Change Sensor Address a – Sensor Address b – New Sensor Address

Identification

A request for identification will return the sensor address, part number, firmware version, sensor version, calibration, and serial number.

SDI-12 Command	Response	Description
aI!	a12STEVENSWnnnnnv.vvvvSNxxxxxxxx	Send Identification a – Sensor address 12 – SDI-12 protocol version STEVENSW – Manufacturer nnnnn – Part number v.vvv – Firmware version c – Calibration xxxxxxxx – Serial number

Measurements

SDI-12 Command	Response	Description
aM!	atttn	Request Measurement a – Sensor address ttt – seconds (000 – 999) until the measurement is ready n – number of data fields (1-9) in the measurement
aD0!	a<F><I><G>	Send Measurement Readings F – Soil Moisture I – Bulk EC (Temp Corrected) G – Temperature (C)
aD1!	a<H><J><L>	Send Measurement Readings H – Temperature (F) J – Bulk EC L – Real Dielectric Permittivity
aD2!	a<M><K><O>	Send Measurement Readings M – Imaginary Dielectric Permittivity K – Pore Water EC O – Dielectric Loss Tangent

aM1!	atttn	Request Measurement ttt – seconds (000 – 999) until the measurement is ready n – number of data fields (1-9) in the measurement
aD0!	a<L><M><N>	Send Measurement Readings L – Real Dielectric Permittivity M – Imaginary Dielectric Permittivity N – Imaginary Dielectric Permittivity (Temperature Corrected)
aD1!	a<O><P>	Send Measurement Readings O – Dielectric Loss Tangent P – Diode Temperature

The following tables list the values and units:

Selector Order	Parameter	Unit
F	Soil Moisture	Water fraction by Volume (wfv)
G	Soil Temperature	Celsius (C)
H	Soil Temperature	Fahrenheit (F)
I	Bulk EC (Temperature Corrected)	Siemens/Meter (S/m)
J	Bulk EC	Siemens/Meter (S/m)
K	Pore Water EC	Siemens/Meter (S/m)
L	Real Dielectric Permittivity	-
M	Imaginary Dielectric Permittivity	-
N	Imaginary Dielectric Permittivity (Temperature corrected)	-
O	Dielectric Loss Tangent	-
P	Diode Temperature	Celsius (C)

SDI-12 Measurement Sets (Professional and Extended Temperature Version)									
Command	P1	P2	P3	P4	P5	P6	P7	P8	P9
aM! and aC!	F	I	G	H	J	L	M	K	O
aM1! and aC1!	L	M	N	O	P				

Pore Water Offset

SDI-12 Command	Response	Description
aXR_PWOS!	a<Current Offset>	Read Pore Water Offset
aXW_PWOS_<New Offset>!	a<New Offset>	Write Pore Water Offset
aXD_PWOS!	a+3.4	Reset Pore Water Offset to default 3.4

Calibration

The following extended command will change the coefficients in one of two general formulas that translate the real dielectric permittivity to soil moisture. In many cases, the HydraProbe will not need to be recalibrated. The default General calibration has been heavily reviewed and will provide reasonable accuracy for most applications. If you need to change the calibration or if a custom calibration is required, we recommend referring to the HydraProbe user manual for more information.

SDI-12 Command	Response	Description
aXR_SOIL!	a<G/O/R/C/K>	Get Current soil type G – General O – Organic R – Rockwool C – Custom 1 K – Custom 2
aXW_SOIL_<New Soil Type>!	a<G/O/R/C/K>	Write New Soil Type G – General O – Organic R – Rock Wool C – Custom 1 K – Custom 2
aXR_COEFA!	a<A>	Read coefficient A
aXR_COEFB!	a	Read coefficient B
aXR_COEFC!	a<C>	Read coefficient C
aXR_COEFD!	a<D>	Read coefficient D
aXR_COEFE!	a<E>	Read coefficient E
aXR_COEFF!	a<F>	Read coefficient F
aXR_COEF!	a<A><C><D><E><F>	Read all coefficients
aXW_COEFA_<A>!	a<A>	Write coefficient A
aXW_COEFB_!	a	Write coefficient B
aXW_COEFC_<C>!	a<C>	Write coefficient C
aXW_COEFD_<D>!	a<D>	Write coefficient D
aXW_COEFE_<E>!	a<E>	Write coefficient E
aXW_COEFF_<F>!	a<F>	Write coefficient F
aXD_COEF!	a<A><C><D><E><F>	Reset all coefficient to default

Accuracy and Ranges

Parameter	Standard Version
Soil moisture for inorganic mineral soils	Accuracy*: +/- 0.01 WFV for most soils (m ³ ,m ⁻³) +/- <0.03 for fine textured soil (typical) Range: From Complete Dry to Full Saturation (0% to 100% of saturation)
Bulk EC	Accuracy: +/- 2.0% or 0.02 S/m Whichever is greater Range: 0 to 1.0 S/m
Temperature	Accuracy: +/- 0.3 °C Range: -10 to 60 °C
Inter-Sensor Variability	+/- 0.012 WFV (Typical)
Pore Water EC	Hilhorst Equation, depends on soil conditions

*Accuracy of soil moisture depends on the soil and is highly variable.