



# RS-485 Quick Start Guide

## Standard FW Version 6.0

RS-485 is a serial communication standard. RS-485 is a good option compared to SDI-12 if you need longer cabling. RS-485 can operate with up to 3000 ft of cable. The disadvantage compared to SDI-12 is that RS-485 does draw more power. Broadcast address: “///” if there is a single probe on the bus. 4.1, 4.0, 3.0, 2.8 and 2.7 firmware versions have a different array of commands. Contact Stevens Water for more information.

### Model Numbers

Version Part # Suffix	
<b>01</b>	Standard, w/25 ft. cable
<b>02</b>	Professional, w/25 ft. cable
<b>02-30</b>	Professional (Extended Temp), w/25 ft. cable
<b>03</b>	Standard, w/50 ft. cable
<b>04</b>	Professional, w/50 ft. cable
<b>04-30</b>	Professional (Extended Temp), w/50 ft. cable
<b>05</b>	Standard, w/100 ft. cable
<b>06</b>	Professional, w/100 ft. cable
<b>06-30</b>	Professional (Extended Temp), w/100 ft. cable

### Power

<b>Power Requirements</b>	9 to 20 VDC (12VDC Ideal)
<b>Power Consumption</b>	<10 mA Idle, 30 mA for 2s Active

### Wiring

<b>Red Wire</b>	+ Power Input
<b>Black Wire</b>	Ground
<b>Green Wire</b>	Data inverting Signal Negative (-) A
<b>White Wire</b>	Data non-inverting Signal Positive (+) B

## Communication Settings

<b>Baud Rate</b>	9600
<b>Data Bits</b>	8
<b>Parity</b>	None
<b>Stop Bits</b>	1
<b>Flow Control</b>	None

All commands sent must end with a “Carriage Return” “Line Feed” pair.

## Addressing

Lowercase ‘aaa’ is used to represent the address. The default address is “000”.

RS-485 Command	Response	Description	Access Level
aaaXR_AD	<Current Address>	Read Address	Read Only
aaaXW_AD_<New Address>	<New Address>	Write Address	Write Only

## Identification

RS-485 Command	Response	Description	Access Level
aaaXR_SN	aaa<Serial Number>	Read Serial Number	Read Only
aaaXR_FV	aaa<Firmware Version>	Read Firmware Version	Read Only
aaaXR_MN	aaa<Model Number>	Read Model Number	Read Only

## Measurement

RS-485 Command	Response	Description	Access Level
aaaTR	-	Request Measurement	Read Only
aaaT0	aaa<F><I><G><H><K><O>	Read Measurement Readings F – Soil Moisture I – Bulk EC (Temp Corrected) G – Soil Temp (C) H – Soil Temp (F) K – Pore Water EC O – Loss Tangent	Read Only
aaaXR_QM	aaa<X/0>	Read Quick Mode Selection X – Quick Mode Disabled 0 – Quick Mode Enabled	Read Only
aaaXW_QM_X	aaaX	Disable Quick Mode	Read Only
aaaXW_QM_0	aaa0	Enable Quick Mode	Write Only

The following tables list the values and units:

Selector Order	Parameter	Unit
F	Soil Moisture	Water fraction by Volume (wfv)
I	Bulk EC (Temperature Corrected)	Siemens/Meter (S/m)
G	Soil Temperature	Celsius (C)
H	Soil Temperature	Fahrenheit (F)
K	Pore Water EC	Siemens/Meter (S/m)
O	Dielectric Loss Tangent	-

### Pore Water Offset

RS-485 Command	Response	Description	Access Level
aaaXR_PWOS	aaa<Current Offset>	Read Pore Water Offset	Read Only
aaaXR_PWOS_<New Offset>	aaa<New Offset>	Write Pore Water Offset	Write Only
aaaXD_PWOS	aaa+3.4	Reset Pore Water Offset to default 3.4	Write Only

### Calibration

The default General calibration has been heavily reviewed and will provide reasonable accuracy for most applications. If you need to change the calibration, we recommend referring to the HydraProbe user manual for more information.

RS-485 Command	Response	Description	Access Level
aaaXR_SOIL	aaa<G/O/R>	Get Current Soil Type G – General O – Organic R – Rockwool	Read Only
aaaXW_SOIL_<New Soil Type>	aaa<G/O/R>	Write New Soil Type G – General O – Organic R – Rockwool	Write Only

## Accuracy and Ranges

Parameter	Standard Version
Soil moisture for inorganic mineral soils	Accuracy*: +/- 0.01 WFV for most soils ( $m^3, m^{-3}$ ) +/- <0.03 for fine textured soil (typical) Range: From Complete Dry to Full Saturation (0% to 100% of saturation)
Bulk EC	Accuracy: +/- 2.0% or 0.02 S/m Whichever is greater Range: 0 to 1.0 S/m
Temperature	Accuracy: +/- 0.3 °C Range: -10 to 60 °C
Inter-Sensor Variability	+/- 0.012 WFV (typical)
Pore Water EC	Hilhorst Equation, depends on soil conditions

\*Accuracy of soil moisture depends on the soil and is highly variable.