

# OS1 Hardware User Manual

*For Gen 1 OS1 sensors*

**Ouster**

**Dec 01, 2020**

# Contents

---

<b>1</b>	<b>Safety and Safe Use</b>	<b>3</b>
1.1	Safety & Legal Notices . . . . .	3
1.2	Proper Assembly, Maintenance and Safe Use . . . . .	5
<b>2</b>	<b>OS1 Gen 1 Overview</b>	<b>7</b>
<b>3</b>	<b>OS1 Product Models</b>	<b>8</b>
<b>4</b>	<b>Mechanical Interface</b>	<b>9</b>
4.1	Included Components . . . . .	9
4.2	Mounting and Heatsinking Guidelines . . . . .	10
4.3	Thermal Requirements . . . . .	11
<b>5</b>	<b>Electrical Interface</b>	<b>12</b>
5.1	Interface Box . . . . .	12
5.2	Direct Cable Connection and Pinout . . . . .	13
<b>6</b>	<b>Digital IO</b>	<b>14</b>
6.1	SYNC_PULSE_IN . . . . .	14
6.2	MULTIPURPOSE_IO (M_IO) . . . . .	15
<b>7</b>	<b>OS1 CAD files</b>	<b>17</b>
<b>8</b>	<b>Hardware Errata</b>	<b>18</b>
8.1	MULTIPURPOSE_IO Errata . . . . .	18

---

# 1 Safety and Safe Use

---

## 1.1 Safety & Legal Notices

---

The OS1-64, OS1-32, and OS1-16 have been evaluated to be **Class 1 laser products** per **60825-1: 2014 (Ed. 3)** and operate in the 850nm band.



L'OS1-64, l'OS1-32, et l'OS1-16 répondent aux critères des **produits laser de classe 1**, selon la norme **IEC 60825-1: 2014 (3ème édition)** et émettent dans le domaine de l'infrarouge, à une longueur d'onde de 850nm environ.

**FDA 21CFR1040 Notice:** OS1-64, OS1-32, and OS1-16 comply with FDA performance standards for laser products except for deviations pursuant to Laser Notice No. 56, dated January 19, 2018.

**Notice FDA 21CFR1040:** L'OS1-64, l'OS1-32, et l'OS1-16 sont conformes aux exigences de performances établies par la FDA pour les produits laser, à l'exception des écarts en application de l'avis n°56, daté du 19 janvier 2018.



The following symbols appear on the product label and in the manual and have the following meaning.

-  This symbol indicates that the sensor emits laser radiation.
-  This symbol indicates the presence of a hot surface that may cause skin burn.

### CAUTIONS:

- The OS1 is a hermetically sealed unit, and is non user-serviceable.
- Use of controls, or adjustments, or performance of procedures other than those specified herein, may result in hazardous radiation exposure.

- Your use of the OS1 is subject to the Terms of Sale that you signed with Ouster or your distributor/integrator. Included in these terms is the prohibition on:
  - Removing or otherwise opening the sensor housing
  - Inspecting the internals of the sensor
  - Reverse-engineering any part of the sensor
  - Permitting any third party to do any of the foregoing
- Operating the sensor without either the attached mount with which the sensor is shipped, or attaching the sensor to a surface of appropriate thermal capacity runs the risk of having the sensor overheat under certain circumstances.
- This product emits Class 1 invisible laser radiation. The entire window is considered to be the laser aperture. While Class 1 lasers are considered to be "eye safe", avoid prolonged direct viewing of the laser and do not use optical instruments to view the laser.
- When operated in an ambient temperature  $>40^{\circ}\text{C}$ , the metallic surfaces of the sensor may be hot enough to potentially cause skin burn. Avoid skin contact with the sensor's base, lid and heatsink when the sensor is operated under these conditions.

#### **PRECAUTIONS:**

- L'OS1 est une unité hermétiquement scellée, qui ne peut être entretenue ou modifiée par l'utilisateur.
- L'utilisation de commandes, de réglages, ou l'exécution de procédures autres que celles spécifiées dans le présent document peuvent entraîner des rayonnements laser dangereux.
- L'utilisation de l'OS1 est soumise aux conditions de vente signées avec Ouster ou le distributeur/intégrateur, incluant l'interdiction de:
  - Retirer ou ouvrir de quelque façon le boîtier du capteur
  - Analyser les composants internes du capteur
  - Pratiquer la rétro-ingénierie de toute ou partie du capteur
  - Autoriser une tierce personne à mener les actions listées ci-dessus
- Ce produit émet un rayonnement laser invisible de classe 1. L'ouverture de sortie du laser est constituée par la fenêtre du capteur dans sa totalité. Même si les lasers de classe 1 ne sont pas considérés comme dangereux pour les yeux, ne regardez pas directement le rayonnement laser de façon prolongée et n'utilisez pas d'instruments optiques pour observer le rayonnement laser.
- Lors d'une utilisation à température ambiante supérieure à  $40^{\circ}\text{C}$ , la surface métallique du capteur peut présenter des risques de brûlures pour la peau. Dans ces conditions, il est important d'éviter tout contact avec la partie supérieure, la base ou le dissipateur thermique du capteur.

**Equipment Label:** Note that the equipment label, which includes model and serial number and notice that the unit is a Class 1 Laser Product, is affixed to the underside of the Sensor Enclosure Base itself. It is only visible after the attached mount with which the Sensor is shipped, is removed. Please refer

to location details in the [Mechanical Interface](#) section.

**L'étiquette de l'équipement**, comprenant le modèle, le numéro de série, et la classification du produit laser (ici, classe 1), est apposée au dessous de la base du boîtier du capteur. Il n'est visible qu'après avoir retiré le diffuseur de chaleur avec lequel le capteur est expédié. L'emplacement est décrit avec précision dans la section «[Mechanical Interface](#)».

Electromagnetic Compatibility: The OS1 is an FCC 47 CFR 15 Subpart B device. This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

"Ouster" and "OS1" are both registered trademarks of Ouster, Inc. They may not be used without express permission from Ouster, Inc.

If you have any questions about the above points, contact us at [legal@ouster.io](mailto:legal@ouster.io).

## 1.2 Proper Assembly, Maintenance and Safe Use

---

The OS1 may be easily setup by mounting to the base to a mounting with the correct mounting hole pattern, and following the interconnection instructions delineated in [Mounting and Heatsinking Guidelines](#). Any mounting orientation is acceptable. Each sensor is shipped attached to a mount for test or normal use specified operating temperature range, but the sensor may be mounted directly to any appropriate mount with Thermal Capacity appropriate for the application of the user. Please contact Ouster for assistance with approving the use of user specific mounting arrangements.

Any attempt to utilize the sensor outside the Environmental parameters delineated in the OS1 data sheet may result in voiding of the warranty.

When power is applied, the sensor powers up and commences boot-up with the laser disabled. The bootup sequence is approximately 60s in duration, after which the internal sensor optics subassembly commences spinning, and the laser is activated, and the unit operates in the default 1024 x 10 Hz mode. When the sensor is running, and the laser is operating, a faint red flickering light may be seen behind the optical window. Note that the OS1 utilizes an 850nm infrared laser that is only dimly discernable to the naked eye, while transmitting a laser eye- safe fundamental signal in the 850nm IR band. While the sensor is fully Class 1 eye safe, Ouster strongly recommends against peering into the optical window at close range while the sensor is operating. The OS1 is a hermetically sealed unit, and is not user-serviceable. Any attempt to unseal the enclosure has the potential to expose the operator to hazardous laser radiation.

Ouster sensors are equipped with a multi-layer series of internal safety interlocks to ensure compliance to Class 1 Laser Eye Safe limits.

The Sensor user interface may be used configure the sensor to a number of combinations of scan rates and resolutions other than the default values of 1024 x 10 Hz resolution. In all available combinations, the unit has been evaluated by an NRTL to remain within the classification of a Class 1 Laser Device as per IEC 60825-1:2014 (Ed. 3).

## Assemblage correct et utilisation sûre

L'OS1 s'installe facilement en fixant la base sur un support percé de trous concordants, et en suivant les instructions d'interconnexion décrites dans la section «[Mounting and Heatsinking Guidelines](#)». Toute orientation de montage est acceptable. Chaque capteur est expédié équipé d'un dissipateur de chaleur, utilisable en phase de test et en conditions normales. Néanmoins tout autre support présentant une capacité thermique appropriée pour l'application de l'utilisateur peut être utilisé. Veuillez contacter Ouster dans le cas où un montage spécifique à votre application serait nécessaire.

Toute tentative d'utilisation du capteur en dehors des paramètres environnementaux définis dans la fiche technique de l'OS1 peut entraîner l'annulation de la garantie.

Lorsque le capteur est sous tension, celui-ci démarre et commence son initialisation avec le laser dés-activé. Le temps de démarrage est d'environ 60s, après quoi le sous-système optique entre en rotation et le laser est activé, le capteur opère alors dans son mode par défaut de 1024 x 10 Hz. Lorsque le capteur est en marche et que le laser est active, on peut apercevoir une faible lumière rouge vacillante derrière la vitre teintée. L'OS1 utilise une longueur d'ondes infra-rouge de 850nm nm à peine perceptible pour l'œil humain, et le rayonnement laser IR émis est sans danger pour les yeux. Cependant, bien que les rayonnements laser de classe 1 soient sans danger dans des conditions raisonnablement prévisibles, Ouster recommande fortement de ne pas regarder fixement la vitre teintée pendant que le capteur est en marche. L'OS1 est une unité hermétiquement scellée, qui ne peut pas être entretenue, modifiée ou réparée par l'utilisateur. Toute tentative d'ouverture du boîtier a pour risque d'exposer l'opérateur à un rayonnement laser dangereux.

L'OS1 est une unité hermétiquement scellée, qui ne peut pas être entretenue, modifiée ou réparée. Toute tentative d'ouverture du boîtier a pour risque d'exposer l'opérateur à un rayonnement laser dangereux.

Les capteurs Ouster sont équipés d'une série de dispositifs de sécurité à plusieurs niveaux, de façon à assurer en toutes circonstances le respect des limites d'irradiance correspondant aux rayonnements lasers de classe 1, sans danger pour les yeux.

L'interface utilisateur du logiciel du capteur peut être utilisée pour configurer le capteur selon un certain nombre de combinaisons de vitesses de balayage et de résolutions autres que les valeurs utilisées par défaut, respectivement de 1024 x 10 Hz.

## 2 OS1 Gen 1 Overview

---

The OS1 Gen 1 offers an industry-leading combination of price, performance, reliability, size, weight, and power. It is designed for indoor/outdoor all-weather environments and long lifetime. As the smallest high performance lidar on the market, the OS1 can be directly integrated into vehicle facias, robots, and drones.

The OS1 family of sensors consist of three models, the OS1-64, OS1-32, and OS1-16, with differing resolution, but of identical mechanical dimensions.

### **HIGHLIGHTS**

- Fixed resolution per frame operating mode
- Camera-grade intensity, near-infrared, and range data
- Multi-sensor crosstalk immunity
- Simultaneous and co-calibrated 2D and 3D output
- Industry leading intrinsic calibration
- Example client code available

For the purposes of this document, the term "OS1" refers to the family of sensors, and only where there is a difference in performance will each modwel be referred to by its specific model designation.

## 3 OS1 Product Models

---

The Gen 1 OS1 is available with 64, 32, or 16 beams of vertical resolution and with uniform, gradient, or below horizon beam spacing options. Product specs and more information on these configurations can be found on the [OS1 product page](#).




# 4 Mechanical Interface

## 4.1 Included Components

### The OS1 is shipped with the following items

- OS1-64, OS1-32, or OS1-16
- Sensor to interface box cable/connector
- Interface box and AC/DC power supply (2 meters)
- RJ45 cable (1 meter)
- Optional: Heat sink



Downloadable CAD files for the OS1 can be found online at [www.ouster.com/lidar-product-details](http://www.ouster.com/lidar-product-details)

**Warning:** Water ingress protection: The sensor ingress protection rating is only valid if the I/O cable is plugged into the panel mount connector on the base of the sensor, and the locking collet rotated past the detent click to the properly locked condition i.e past the *détente* position. The

cable and plug are an element of the sensor ingress protection system. Without this the ingress protection rating may be compromised. Bending the cable at a sharp angle directly after egress from the plug over mold should also be avoided. Sharp bends and high axial stresses on the cable immediately adjacent to the plug over mold may create a moisture ingress path into the the connector. Please note the cable minimum bend radius requirements below:

I/O Cable type	O.D.	Cable Minimum Bend Radius	
		Fixed Bend	Flexing Bend
Ouster Thick Cable	10.5mm	79mm (7.5*OD)	158mm (15*OD)
Ouster Thin Cable (Standard)	8mm	50mm (5*OD)	80mm (10*OD)

## 4.2 Mounting and Heatsinking Guidelines

Our sensors ship with modular mounting options. Proper mounting will ensure optimal sensor performance, reducing noise from vibration and providing efficient heat dissipation.

- Mount to a material with high thermal conductivity. The following are recommended aluminum alloys and their thermal conductivity:
  - 1) 6061: 167 W/m-K
  - 2) 7075: 130 W/m-K
  - 3) 2024: 121 W/m-K
- Ensure interfaces are clean and free from debris
- Torque bolts appropriately for the mount material and bolts
- Use TIM (Thermal Interface Material) for any irregular or unmachined surfaces
- Do not overconstrain the sensor if mounting to both the top and the bottom
- Use a thermally conductive pad to ensure good conductivity while not overconstraining.
- Ensure your implementation maintains the base and top of the sensor at no greater than 25°C above ambient with an ambient less than 50°C
- The shape of any heatsink should maximize the surface area for free and forced convection while being thick enough to allow the heat to conduct through the material

If you have questions about your specific mounting situation please contact the Ouster at [support@ouster.io](mailto:support@ouster.io).

## 4.3 Thermal Requirements

Thermal requirements specific to Gen 1 OS1 are listed below. Note that the modular cap are sensors with removable and modular caps with radial fins whereas legacy caps cannot be removed.


Table 4.1: Thermal requirements for Gen 1 OS1 with modular caps

	Requirements		Example Test Case
	Base Temp (°C)	Enclosure Top Cap Temp (°C)	Modular Convective Air Temp with Radial Heatsink and Standard Base (°C)
<b>Legacy Cap - Max Temp before Shot Limiting</b>	55	55	50
<b>Legacy Cap - Max Temp before Sensor Shuts Off</b>	65	65	60
<b>Modular Cap - Max Temp before Shot Limiting</b>	52	52	47
<b>Modular Cap - Max Temp before Sensor Shuts Off</b>	65	65	60

# 5 Electrical Interface

## 5.1 Interface Box

The Interface Box that accompanies the OS1 is designed to allow the sensor to be operated for test and evaluation purposes. It terminates the interface cable from the sensor, allows it to be powered up and provides access to the sensor gigabit Ethernet Interface via a standard RJ45 connector. DC Power to the sensor is provided to the Interface Box by the accompanying 24V DC supply.



## 5.2 Direct Cable Connection and Pinout

The OS1 can be operated without the use of an Interface Box.

**Warning:** Ouster is not responsible for any errors in wiring as a result of bypassing the Interface Box and this activity may result in a voiding of your warranty if it results in damage to the sensor. The following guidelines for direct cable connection assume use of the Ouster-provided 24V 1.5A power supply. Ouster cannot be held responsible for damage to the device if alternate is used




Figure5.1: cable pinout of on-sensor receptacle

Table5.1: Ouster Cable Pinout: Connector, Sensor P/Ns: 840\_101855, 840\_102144, 840\_102145, 840\_102146

Net Name	Pin Number	Wire	Twisted With
MULTIPURPOSE_IO	3	Purple, 26 AWG	N/A
SYNC_PULSE_IN	2	Yellow, 26 AWG	N/A
VCC_24	1	Red, 22 AWG	N/A
GROUND	7	Black, 22 AWG	N/A
TRP_1_P (Ethernet)	5	White/Orange, 26 AWG	Orange
TRP_1_N (Ethernet)	4	Orange, 26 AWG	White/Orange
TRP_2_P (Ethernet)	8	White/Green, 26 AWG	Green
TRP_2_N (Ethernet)	6	Green, 26 AWG	White/Green
TRP_3_P (Ethernet)	9	Blue, 26 AWG	White/Blue
TRP_3_N (Ethernet)	10	White/Blue, 26 AWG	Blue
TRP_4_P (Ethernet)	12	White/Brown, 26 AWG	Brown
TRP_4_N (Ethernet)	11	Brown, 26 AWG	White/Brown

# 6 Digital IO

## 6.1 SYNC\_PULSE\_IN

**SYNC\_PULSE\_IN** is a dedicated input channel that is accessible within the Interface Box Jumper J4. This channel expects an input pulse sequence which can be used for time synchronization. See the Software User Manual for more information on configuring this input. Any references to pulse polarity in this document references the signal polarity on the **SYNC\_PULSE\_IN** pin of the sensor. This input channel is protected by an optoisolator which will draw 10 mA at full turn on.

Table 6.1: SYNC\_PULSE\_IN Interface Requirements

Parameter	Min Voltage	Max Voltage	Min Driver Current
LOGIC LOW	0 V	1 V	N/A
LOGIC HIGH	3.3 V	15 V	5 mA

*SYNC\_PULSE\_IN Interface Requirements were tested with 2 m cable interface box connection at 2 MHz.*

- When GPIO has 5 mA drive strength minimum, GPIO can be directly connected to the **SYNC\_PULSE\_IN** pin of the interface box header. This is the most common case and has been tested to work on common Arduino microcontroller series. Typical common logic levels of 3.3 V, 5 V GPIO of microcontrollers can produce drive strength of 5 mA min (Arduino, MSP430, etc.).


Requires 5 mA min drive strength to turn on optoisolator LED

3.3 V ~ 24 V GPIO PIN above 5 mA drive strength

OS1 SYNC\_IN (header pin of the interface box)

Most GPIO microcontroller falls into this case (ARDUINO UNO, MSP430, etc.)

- If the 5 mA drive strength minimum cannot be met, a buffer circuit is required to drive **SYNC\_PULSE\_IN**. Example circuits are provided for common 3.3 V and 5 V logic.



## 6.2 MULTIPURPOSE\_IO (M\_IO)

**MULTIPURPOSE\_IO (M\_IO)** is a configurable input or output channel accessible within the Interface Box Jumper J4 connected to the MULTIPURPOSE\_IO pin of the Interface Box. Detailed information on how to configure this channel using the sensor TCP interface can be found in the API Guide. By default this channel is disabled.

When this channel is configured as an **OUTPUT**, the **M\_IO** sends a pulse sequence that can be used for timesynchronization or event triggering outside the sensor. For a full description of output pulse triggering options, see the Software User Manual. This output is an optoisolated open collector circuit, relying on an externally provided pull-up resistor. This resistor is not provided as part of the interface box.

Table 6.2: MULTIPURPOSE\_IO - OUTPUT Interface Requirements

Parameter	Min	Max
Pull Up Voltage	N/A	15 V
Sinking Current	N/A	25 mA

Output is an optoisolated open collector. However current OS1 units have an earlier version of this port which requires an external circuit to utilize this port in output mode. See the below MULTIPURPOSE\_IO ERRATA section for more details.

When this channel is configured as an **INPUT**, the **M\_IO** can accept a standard NMEA \$GPRMC UART message. These messages are a common way for GPS systems to share timestamp information in UTC time format. More information on this packet structure and supported baud rates can be found in the time synchronization section of the Software User Manual.

Table 6.3: MULTIPURPOSE\_IO - INPUT Interface Requirements

Parameter	Min Voltage	Max Voltage	Min Driver Current
LOGIC LOW	0 V	1 V	N/A
LOGIC HIGH	1.7 V	15 V	10 mA

Above are tested with 2m cable interface box connection at 2 MHz.

**Note:** Please note that these input channels are being renamed. Interface Boxes may be labeled with the deprecated name. "PPS\_MASTER" has been renamed to **MULTIPURPOSE\_IO**, and **PPS\_SLAVE** has been renamed to **SYNC\_PULSE\_IN**



## 7 OS1 CAD files

---

All the most up-to-date CAD files of our products can be found on our [Lidar Product Details](#) page.

## 8 Hardware Errata

### 8.1 MULTIPURPOSE\_IO Errata

Current OS1 sensors require an external compensation circuit when the MULTIPURPOSE\_IO port is configured as an OUTPUT. Without this circuit, the resulting waveform is a low amplitude pulse train regardless of the pull up voltage. The following example circuit can correct the output waveform. Current Gen 2 sensors including the OS1 Gen 2 have this fix implemented and thus do not require a buffer circuit.

Buffer circuit fix for MULTIPURPOSE\_IO in OUTPUT mode:




Table8.1: MULTIPURPOSE\_IO - OUTPUT Buffer Circuit Example

Parameter	M_IO SYNC_PULSE_OUT_MODE	IN	SYNC_PULSE_OUT_MODE with corrected ampli- tude
Example LOW	Waveform LOGIC 0 V		0 V
Example HIGH	Waveform LOGIC 1.2 V		3.3 V