

To Install NSCL DAQ

Richard Longland and John Kelley

2014-10-03 Fri

Prerequisites

General

- build-essential
- openssh-server
- magit
- libgsl0-dev
- subversion

nscldaq

- swig2.0 (swig in debian)
- gengetopt
- tcl8.5-dev # defaults to tcl8.6 in ubuntu
- tk8.5-dev # defaults to tk8.6 in ubuntu
- libtk (tklib in debian) # these give runtime errors if not present
- libtcl (tcllib in debian)
- libcppunit-dev # no errors in configure about this but it's needed!
- ftpd
- rsh-server
- rsh-client
- libusb-dev
- tcllib
- tklib

spectcl

- libmotif-dev (liblestif2-dev in debian)
- imagemagick
- libgd-dev (libgd2-xpm-dev in debian)
- byacc # build error about yacc
- flex
- bison
- gri
- libtk-img-dev

- itcl3-dev
- itk3-dev
- iwidgets4
- bwidget
- blt-dev
- libxt-dev

General

- Install in /usr/opt/
- **DO NOT TRY ANYTHING ELSE!** There are some hard coded references in the code to this directory so it's just not worth your trouble...
- Build everything as root
 - sudo su -
 - cd /usr/src/
 - mkdir NSCLDAQ
 - mkdir SpecTcl

For NSCLDAQ

- <http://sourceforge.net/projects/nscldaq/>
- I'm using Version 10.2.108
- By the way, if you screw up in here, make sure you make `clean` and remove any installed files before trying again!
- Download to NSCLDAQ directory and untar (`tar -xzvf nscldaq-10.2-108.tar.gz`)
- `cd nscldaq-10.2-108`
- Compile
 - `./configure --prefix=/usr/opt/nscldaq/nscldaq-10.2-108 --enable-usb`
 - `make`
 - `make install`
 - `ln -s /usr/opt/nscldaq /usr/opt/daq`

For SpecTcl

- <http://sourceforge.net/projects/nsclspectcl/>
- I'm using Version SpecTcl-3.3-016
- Download to NSCLDAQ directory and untar (`tar -xzvf SpecTcl-3.3-016.tar.gz`)
- `cd SpecTcl-3.3-016`
- `./configure --prefix=/usr/opt/spectcl/SpecTcl-3.3-016 --with-tcl-libdir=/usr/lib/x86_64-linux-gnu/`
- `make`
- Touch some files to avoid errors in documentation
 - `touch ccusb/dummy.html`
 - `touch vmusb/dummy.html`

- `make install`

Set up some "current" links

- `ln -s /usr/opt/nscldaq/nscldaq-10.2-108 /usr/opt/nscldaq/current`
- `ln -s /usr/opt/spectcl/SpectCl-3.3-016/ /usr/opt/spectcl/current`

Post-install

- Log out of root
 - `exit`
 - `cd`
- Do "the ssh trick"
 - `ssh localhost`
 - Answer "yes"
 - Enter password to log in, then `exit` to log out
 - `ssh-keygen` and don't use a password (choose all defaults)
 - `cat ~/.ssh/id_rsa.pub >> ~/.ssh/authorized_keys`
- Find the nscldaq file in the source directory
 - `mkdir -p /home/daq/Live`
 - `cp /usr/src/NSCLDAQ/nscldaq-10.2-108/nscldaq ~/NSCLDAQ`
 - Edit the nscldaq file (This has all been done and the file is in /home/daq/NSCLDAQ/PostInstallFiles)
 - * Make DAQHOME=/usr/opt/nscldaq/current
 - * Fix the bash script to make == into =
 - * Make PIDFILEDIR=/home/daq/Live
 - * Make sure ~PORTMGRSWITCHES=""~
 - Make it executable: `chmod u+x nscldaq`
 - `sudo ./nscldaq start`
 - `sudo ./nscldaq status`
 - `sudo ./nscldaq stop`
 - `sudo ./nscldaq status`
- Copy this file into /etc/init.d/
- Link in runlevels so that it starts on boot
 - `sudo update-rc.d nscldaq defaults`
- `ls /etc/rc2.d/` (You should see it in there somewhere)
- Reboot and check if it's running
 - `sudo /etc/init.d/nscldaq status`
 - or
 - `ps aux | grep DaqPortManager`
 - `ps aux | grep RingMaster`

Environment

- In .bashrc put the following (my version is in PostInstallFiles)

- export HOMEDIR=\$HOME
- export NSCLBASE=\$HOME
- export DISTDIR=/usr/opt/applications
- export BinDir=\$HOMEDIR/bin
- export DAQHOST=localhost
- export SSHOTARGET=localhost
- export INSTROOT=/usr/opt/nscldaq/current
- ~export TCLLIBPATH="\$TCLLIBPATH \$INSTROOT/lib \$INSTROOT/Scripts \$INSTROOT/TclLibs"~
- export PATH=\$PATH:/usr/opt/nscldaq/current/bin:/usr/opt/spectcl/current/bin:~/bin
- There are some files needed in ~/bin. I'll put these in /home/daq/NSCLDAQ/PostInstallFiles/bin
 - Menu
 - startCfd
 - startReadout
 - startScaler
 - startSpecTcl
- Put the Menu application in /usr/opt/applications.
I've put it in /home/daq/NSCLDAQ/PostInstallFiles/menu
 - sudo mkdir /usr/opt/applications
 - sudo cp -r /home/daq/NSCLDAQ/PostInstallFiles/menu /usr/opt/applications/
- Make an event directory and link it
 - mkdir ~/events
 - ln -s ~/events ~/stagearea

Bin files

These files are all found in /home/daq/NSCLDAQ/PostInstallFiles/bin/

- Menu
 - A simple bash script to run the menu application
 - wish \$DISTDIR/menu/Menu.ui.tcl &
- startReadout
 - Make sure this points at
 - /usr/opt/nscldaq/current/bin/ReadoutShell
 - with -host=localhost
 - and -path=/usr/opt/nscldaq/current/bin/VMUSBReadout
- startScalers
 - Make sure this points at
 - /usr/opt/nscldaq/current/bin/ScalerDisplay
 - Read the settings from /config/scalerConfig.tcl
- startSpecTcl
 - This one points at SpecTcl run file
 - cd into the script directory
 - cd ~/config
 - exec /usr/opt/spectcl/current/bin/VMUSBSpecTcl </dev/null &

Setup Experiment

- The setup is in `~/config`
- Copy this from `/home/daq/NSCLDAQ/PostInstallFiles/config/`
- Do the same for the `spectcl` directory
 - `cp /home/daq/NSCLDAQ/PostInstallFiles/spectcl /home/daq/`

Running with USB

- Users need access to the USB device. If you get an error that looks like
`CTheApplication caught a string exception: usb_get_string_simple failed in CVMUSB`

It's probably because the user does not have USB access.

- First check that the VM-USB card is found by:
 - Run `tail -f /var/log/syslog`
 - Unplug and replug the USB cable
- Some udev rules need to be set
 - Edit `/etc/udev/rules.d/90-usb.rules`

```
SUBSYSTEM=="usb", ENV{DEVTYPE}=="usb_device", MODE="0666"
```
 - **NOTE:** This is slightly different from the `usb_device` subsystem used in previous versions
 - This will allow users to read and write to the usb device
- **If this doesn't work**
 - First try changing 90 to 95 in the filename above. No need to reboot, just unplug and replug the USB cable
 - here are some useful testing utilities
 - Find the device (not simply `/dev/usb0` as in old linux kernels)
 - * In Ubuntu, do the following. In debian, you need to figure out which device to use some other way!
 - * `less /var/log/udev`
 - * Look for VM-USB
 - * eg. `DEVNAME=/dev/bus/usb/002/004`
 - * Use this `DEVNAME` in the commands below
 - Read all of the attributes of this device with
`udevadm info -a -n /dev/bus/usb/002/004`
 - Test the udev rules as you edit them with
`udevadm test $(udevadm info -q path -n /dev/bus/usb/002/004) 2>&1`
 - You should see the `/etc/udev/rules.d/90-usb.rules` get sourced and the permissions of the device get set to "0666"