

PROJECT #2 GUIDE

UCB ECEN 5803 FALL 2021 PROJECT #2: ST ARM CORTEX M4 MBED

TABLE OF CONTENTS

Introduction	2
NUCLEO-F401RE.....	2
Microcontroller features.....	2
Nucleo features.....	2
Nucleo pinout	3
Arduino-compatible headers	3
Morpho headers	3
Getting started	4
Technical references	7
I. Setup mBED	7
Getting Started with mbed	7
1. Connect your mbed-enabled NUCLEO 401RE to a PC.....	7
2. Click the MBED.HTM link to get logged in	7
3. Have Fun!	7
II. Setup MDK	8
Requirements	8
Hardware Setup	8
III. Setup Mbed Studio [Optional]	8
Mbed Studio	8
IV. Module 1. Hello world, what time is it?.....	9
V. Module 2. Button Read, ADC Read, LED PWM, and UART	9
VI. Module 3. RTOS threads	9
VII. Module 4. Signal analyzer	9
VIII. Module 5. Auto-Configure with STMCUBE (optional)	10

INTRODUCTION

NUCLEO-F401RE

Affordable and flexible platform to ease prototyping using a STM32F401RET6 microcontroller.



The STM32 Nucleo board provides an affordable and flexible way for users to try out new ideas and build prototypes with any STM32 microcontroller line, choosing from the various combinations of performance, power consumption and features.

The Arduino™ connectivity support and ST Morpho headers make it easy to expand the functionality of the STM32 Nucleo open development platform with a wide choice of specialized shields.

The STM32 Nucleo board does not require any separate probe as it integrates the ST-LINK/V2-1 debugger/programmer.

MICROCONTROLLER FEATURES

- STM32F401RET6 in LQFP64 package
- ARM®32-bit Cortex®-M4 CPU
- 84 MHz max CPU frequency
- VDD from 1.7 V to 3.6 V
- 512 KB Flash
- 96 KB SRAM
- GPIO (50) with external interrupt capability
- 12-bit ADC with 16 channels
- RTC
- Timers (8)
- I2C (3)
- USART (3)
- SPI (3)
- USB OTG FS
- SDIO


NUCLEO FEATURES

- Two types of extension resources

- Arduino Uno Revision 3 connectivity
 - STMicroelectronics Morpho extension pin headers for full access to all STM32 I/Os
- On-board ST-LINK/V2-1 debugger/programmer with SWD connector
 - Selection-mode switch to use the kit as a standalone ST-LINK/V2-1
- Flexible board power supply
 - USB VBUS or external source (3.3 V, 5 V, 7 - 12 V)
 - Power management access point
- User LED (LD2)
- Two push buttons: USER and RESET
- USB re-enumeration capability: three different interfaces supported on USB
 - Virtual Com port
 - Mass storage (USB Disk drive) for drag'n'drop programming
 - Debug port


NUCLEO PINOUT

ARDUINO-COMPATIBLE HEADERS



MORPHO HEADERS

These headers give access to all STM32 pins.



GETTING STARTED

First, **verify that your version of the board has X2 or X3 populated**. If not, ask the TA's for another board.


This video shows how to get started with ARM mbed Integrated Development Environment using STM32 Nucleo platform:

<https://youtu.be/BrMw5TNQROo>

NUCLEO ST-LINK/V2 DRIVER INSTALLATION AND FIRMWARE UPGRADE – VERY IMPORTANT!

- Install the ST-LINK/V2 driver before connecting the Nucleo board to your PC the first time. Follow this [LINK](#) for all details.

- For optimum performances, ensure that the Nucleo ST-LINK/V2 firmware is upgraded to the latest version. Follow this [LINK](#) for all details. You can also unzip the files with the upgrade on Canvas en.stsw-link... .zip
- For Windows, run the STLinkUpgrade.exe, you should see this window:





- CAUTION: the upgrade software STLinkUpgrade.exe in the link may not work on your system. The program to run then is listed as STLinkUpgrade.jar. After plugging in your board, running it will give you this window:





You must click on “Open in update mode” to perform the update. Note that the latest version is V2J38M27. Many boards will have V2J24M4 or similar initially, so need to be updated.

When you are successful, you will see this window when connecting to the Nucleo board:



Or you may see this:





TECHNICAL REFERENCES

For more information, please refer to:

- [STM32F401RE Microcontroller](#)
- [Nucleo board](#)
- [SDK changes log](#)

I. SETUP MBED

GETTING STARTED WITH MBED

1. CONNECT YOUR MBED-ENABLED NUCLEO 401RE TO A PC

Use the USB lead to connect your Nucleo 401RE to a PC, using the miniUSB connector. The power LED light will come on, indicating it has power. After a few seconds of activity, the PC will recognize the mbed Microcontroller as a standard USB drive.

2. CLICK THE MBED.HTM LINK TO GET LOGGED IN

Go to the new USB Drive, and click MBED.HTM to open it in a web browser.

If you do not have an mbed account, choose "Signup", and create your mbed Account. Otherwise, log in with your normal username and password.

This will give you access to the website, tools, libraries and documentation.

3. HAVE FUN!

II. SETUP MDK

REQUIREMENTS

- Software:
 - Keil MDK
 - If have not already done this in Project 1, you can download a free version of Keil MDK-ARM tool (MDK-Lite) here: <https://www.keil.com/arm/demo/eval/arm.htm>. You do not need a serial number or license key for this version.
 - If you are seeing error messages that indicate you need the Keil MDK legacy support, you may download the Keil MDK5 legacy support at: <http://www.keil.com/download/files/mdkcm510.exe>
- Hardware:
 - Nucleo F401RE: <http://mbed.org/platforms/ST-Nucleo-F401RE/>

HARDWARE SETUP

To enable the download and debugging features on your Nucleo F401RE board, use the following steps to upgrade the firmware:

1. Download the firmware from: <http://mbed.org/teams/ST/wiki/Nucleo-Firmware>
2. Follow the steps on the web page.

More details on debugging can be found at:

<https://mbed.org/blog/entry/Debugging-on-mbed-enabled-platforms/>

III. SETUP MBED STUDIO [OPTIONAL]

MBED STUDIO

The desktop IDE for Mbed

Mbed Studio is a free IDE for Mbed OS application and library development, including all the dependencies and tools you need in a single package so that you can create, compile and debug your Mbed programs on the desktop.

Installing Mbed Studio

Download Mbed Studio from here: <https://os.mbed.com/studio/> or <https://os.mbed.com/docs/mbed-studio/current/installing/installing-mbed-studio.html>. For normal installation, run the installer and follow the installation steps. For further documentation, see <https://os.mbed.com/docs/mbed-studio/current/introduction/index.html>

For portions of this assignment that do not require an RTOS, use the bare metal profile found here:

<https://os.mbed.com/docs/mbed-os/v6.15/bare-metal/index.html>

For a starting mBed studio project with an RTOS, you can use the Mbed OS Blinky Tutorial found here:

<https://os.mbed.com/docs/mbed-studio/current/getting-started/index.html>

IV. MODULE 1. HELLO WORLD, WHAT TIME IS IT?

1. Use the results from Homework 3P to complete this module.
2. Where (at what address) does the Reset handler begin in the memory map?
3. How much memory is used by the code (Led blinking code for the homework)?
4. Run the mBed Nucleo Example (display_time). Set the time to the current time, and combine this with you're the mBed Nucleo Example (printf) to print the current time to a terminal window on your PC. Capture a screen shot of the terminal window. How much memory is used by this code?
5. Explain the memory model of ARM Cortex-M4 with respect to the code memory, data memory, IRQ handlers and peripherals. Explain with the help of a diagram where required.
6. As a separate project, run either the Dhrystone or the Whetstone benchmark program on your target processor using the code provided, which may need to be modified. If running the Dhrystone, calculate the number of VAX DMIPS.

V. MODULE 2. BUTTON READ, ADC READ, LED PWM, AND UART

1. From Canvas, download the word document Lab_Exercise2_2.zip and Code22.zip and unzip.
2. This module will require you to interface some hardware which is provided in a kit.
3. Follow the Lab_Exercise2_2 directions, which include exercises 8.1 (button), 8.2(interrupt), 9 (analog), and 11.4 (integration). However please note that any screenshot present in the documents are for your reference, but they may not be in sync with the current version of tools.
4. Answer the questions in the Lab documents.

VI. MODULE 3. RTOS THREADS

1. From Canvas, download the word document Lab_Exercise3_3.docx.
2. Follow the Lab_Exercise3_3 directions. However, notice you can use the mbed RTOS (choose version number) or the CMSIS RTOS (Keil RTX) for this module.
3. Answer the questions in the Lab document.

VII. MODULE 4. SIGNAL ANALYZER

1. Create a program to more fully evaluate the ST STM32F401RE MCU for use in a Signal Analyzer:
 - a. Write a program either using the mbed compiler, or in the Keil MDK, to generate a 1004 Hz tone through the DAC. Simulate this program in Simulink. Please note if there is no DAC module present, a software DAC function would also be accepted; store the samples generated into a .csv or .txt file.
 - b. Write a program either using the mbed compiler, Mbed studio, or in the Keil MDK, to read a 1004 Hz tone from a file or the ADC and perform a harmonic analysis. Simulate this program in Simulink. Use the samples from your .csv or .txt file from the previous question for the input to the analyzer, or generate them by using a function generator to create a 1004Hz input to the ADC.
 - c. Blink the User LED at a rate proportional to the ADC input fundamental frequency.
2. Run Splint or an equivalent code checker (like CppCheck or CppLint) on your code in 1 of this module. Resolve any errors, explain the warnings.



3. Auto-generate documentation using Doxygen on your code in 1 of this module. Provide either an HTML directory or PDF file documenting your codebase.
4. Estimate the processor load in % of CPU cycles.

VIII. MODULE 5. AUTO-CONFIGURE WITH STMCUBE (OPTIONAL)

1. Create start-up code using the STMCUBE configuration software. Compare this to the startup code you used in Module 1. How is it different? Provide a memory map for each.