

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.1.1.1.1.1.1.1170	unit temperature	read-only								x	x
1.1.1.1.1.1.1.1175	unit setpoint temperature corrected	read-only								x	x
1.1.1.1.1.1.1.1192	unit return air temperature	read-only	x	x		x	x	x		x	x
1.1.1.1.1.1.1.1193	unit supply air temperature	read-only				x	x	x		x	x
1.1.1.1.1.1.1.1196	unit outside air temperature	read-only		x		x	x	x	x	x	x
1.1.1.1.2.1.1.1171	unit humidity	read-only								x	x
1.1.1.1.2.1.1.1178	unit setpoint humidity corrected	read-only								x	x
1.1.1.1.2.1.1.1194	unit return air humidity	read-only	x	x		x	x	x		x	x
1.1.1.1.2.1.1.1195	unit supply air humidity	read-only				x	x	x		x	x
1.1.1.1.3.1.1.1208	current raised floor pressure	read-only								x	x
1.1.1.2.1.1.1.1191	unit water in temperature 1	read-only				x	x	x	x	x	x
1.1.1.2.1.1.1.1202	unit water in temperature 2	read-only								x	x
1.1.1.2.1.1.1.1206	unit water out temperature 1	read-only							x	x	x
1.1.1.2.1.1.1.1207	unit water out temperature 2	read-only								x	x
1.1.1.2.1.1.1.1211	unit setpoint water pressure	read-write								x	x
1.1.1.2.1.1.1.1212	unit current water pressure	read-only								x	x
1.1.1.3.1.1.2.232	unit evaporation temperature 1	read-only								x	x
1.1.1.3.1.1.2.233	unit evaporation pressure 1	read-only								x	x
1.1.1.3.1.1.2.234	unit condensation temperature 1	read-only								x	x
1.1.1.3.1.1.2.235	unit condensation pressure 1	read-only							x	x	x
1.1.1.3.1.1.2.250	unit condensation pressure 2	read-only							x	x	x
1.1.1.3.1.1.2.272	unit condensation temperature 2	read-only								x	x
1.1.1.3.1.1.2.273	unit evaporation pressure 2	read-only								x	x
1.1.1.3.1.1.2.274	unit evaporation temperature 2	read-only								x	x
1.1.1.3.1.1.2.278	unit suction pressure 1	read-only								x	
1.1.1.3.1.1.2.279	unit suction pressure 2	read-only									
1.1.1.4.1.1.1.10315	operation mode	read-only								x	
1.1.1.4.1.1.1.10316	reason for summer mode	read-only								x	
1.1.1.5.1.1.1.1210	universal temperature 1	read-only									x
1.1.1.5.1.1.1.1780	freeze circulation running	read-only									
1.1.2.1.1.1.1.1761	number of compressors	read-only							x	x	x
1.1.2.1.1.1.1.4403	compr. 1 running	read-only	x	x		x	x	x	x	x	x
1.1.2.1.1.1.1.4503	compr. 2 running	read-only					x	x	x	x	x
1.1.2.1.1.1.1.9503	compr. 3 running	read-only							x	x	
1.1.2.1.1.1.1.9603	compr. 4 running	read-only							x	x	
1.1.2.1.1.1.1.9703	compr. 5 running	read-only							x	x	
1.1.2.1.1.1.1.9803	compr. 6 running	read-only							x	x	
1.1.2.1.2.1.1.1.1762	number of suction valve	read-only								x	x
1.1.2.1.2.1.1.1.4611	suctionvalve1 current value	read-only								x	
1.1.2.1.2.1.1.1.4711	suctionvalve2 current value	read-only								x	
1.1.2.1.2.2.1.1.1771	number of ge/cw valves	read-only								x	x
1.1.2.1.2.2.1.1.5214	GE/CW-valve opening grade 1	read-only	x	x		x	x	x		x	x
1.1.2.1.2.2.1.1.5224	GE/CW-valve opening grade 2	read-only								x	
1.1.2.1.2.3.1.1.9318	hgbp1 opening grade	read-only								x	x
1.1.2.1.2.3.1.1.9418	hgbp2 opening grade	read-only								x	
1.1.2.1.2.4.1.1.1.8726	eev1 current superheat setpoint	read-only								x	x
1.1.2.1.2.4.1.1.1.8727	eev1 suction pressure	read-only								x	x
1.1.2.1.2.4.1.1.1.8728	eev1 saturation temperature	read-only								x	x
1.1.2.1.2.4.1.1.1.8729	eev1 coil out temperature	read-only								x	x
1.1.2.1.2.4.1.1.1.8730	eev1 superheat	read-only								x	x
1.1.2.1.2.4.1.1.1.8731	eev1 valve opening	read-only								x	x
1.1.2.1.2.4.2.1.1.8826	eev2 current superheat setpoint	read-only								x	x
1.1.2.1.2.4.2.1.1.8827	eev2 suction pressure	read-only								x	x
1.1.2.1.2.4.2.1.1.8828	eev2 saturation temperature	read-only								x	x
1.1.2.1.2.4.2.1.1.8829	eev2 coil out temperature	read-only								x	x
1.1.2.1.2.4.2.1.1.8830	eev2 superheat	read-only								x	x
1.1.2.1.2.4.2.1.1.8831	eev2 valve opening	read-only								x	x
1.1.2.1.2.5.1.1776	number of EEVs	read-only								x	x
1.1.2.1.2.5.1.1786	number of hotgas bypass	read-only									
1.1.2.1.2.5.1.2238	unit freecooling-valve	read-only							x	x	x
1.1.2.1.2.5.1.5312	G-valve opening grade	read-only								x	x
1.1.2.1.2.5.1.10101	freecooling possible	read-only							x	x	x
1.1.2.1.3.1.1.1763	number of drycoolers	read-only								x	x
1.1.2.1.3.1.1.5402	drycooler1 running	read-only				x		x		x	x
1.1.2.1.3.1.1.5416	drycooler1 speed	read-only								x	x
1.1.2.1.3.1.1.5502	drycooler2 running	read-only								x	
1.1.2.1.3.1.1.5602	drycooler3 running	read-only								x	
1.1.2.1.3.1.1.5702	drycooler4 running	read-only								x	
1.1.2.1.4.1.1.1764	number of pumps	read-only							x	x	x
1.1.2.1.4.1.1.5802	pump1 running	read-only				x	x	x	x	x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.1.2.1.4.1.1.5821	pump1 speed	read-only								x	x
1.1.2.1.4.1.1.5902	pump2 running	read-only							x		x
1.1.2.1.4.1.1.5921	pump2 speed	read-only								x	x
1.1.2.1.4.1.1.6002	pump3 running	read-only								x	
1.1.2.1.4.1.1.6021	pump3 speed	read-only								x	
1.1.2.1.4.1.1.6102	pump4 running	read-only								x	
1.1.2.1.4.1.1.6121	pump4 speed	read-only								x	
1.1.2.1.5.1.1.9913	ECO-COOL louver opening grade	read-only								x	
1.1.2.1.5.1.1.10408	Fresh air louver opening grade	read-only								x	
1.1.2.1.5.1.1.10508	Anti-freeze louver opening grade	read-only								x	
1.1.2.1.5.1.1.10608	Circulation louver opening grade	read-only								x	
1.1.2.1.5.1.1.10702	Exit louver opening grade	read-only								x	
1.1.2.1.6.1.1.10802	Cond. fan 1 running	read-only								x	
1.1.2.1.6.1.1.10808	Cond. fan 1 actual speed	read-only								x	
1.1.2.1.6.1.1.10902	Cond. fan 2 running	read-only								x	
1.1.2.1.6.1.1.10908	Cond. fan 2 actual speed	read-only								x	
1.1.2.2.1.1.1.1765	number of e-heatings	read-only								x	x
1.1.2.2.1.1.1.4803	elec.-heating1 running	read-only	x	x		x	x	x		x	
1.1.2.2.1.1.1.4817	elec.-heating1 PWM-grade	read-only								x	
1.1.2.2.1.1.1.4903	elec.-heating2 running	read-only	x			x	x	x		x	
1.1.2.2.1.1.1.5003	elec.-heating3 running	read-only								x	
1.1.2.2.2.1.6202	hotgas-heating running	read-only								x	
1.1.2.2.2.1.6302	PWW-heating running	read-only				x	x	x		x	
1.1.2.2.2.1.6315	PWW-heating current value	read-only				x	x	x		x	
1.1.2.3.1.1.6402	humidifier1 running	read-only	x	x		x	x	x		x	
1.1.2.3.1.1.6427	humidifier1 current value	read-only		x		x	x	x		x	
1.1.2.3.1.1.6802	dehumidification running	read-only	x	x		x	x	x		x	
1.1.2.3.1.1.6806	dehumidification valve value	read-only								x	
1.1.2.3.1.1.6807	dehumidification hotgasbypass value	read-only								x	
1.1.2.4.1.1.1767	number of fans	read-only								x	x
1.1.2.4.1.1.1768	number of louvers	read-only								x	x
1.1.2.4.1.1.6902	fan1 running	read-only	x	x		x	x	x		x	
1.1.2.4.1.1.6932	fan1 speed	read-only						x	x	x	
1.1.2.4.1.1.7032	fan2 speed	read-only							x	x	
1.1.2.4.1.1.7202	louver1 open	read-only	x	x		x	x	x		x	
1.1.2.4.6.1.1.11010	Filter 1 current pressure drop	read-only								x	
1.1.2.4.6.1.1.11110	Filter 2 current pressure drop	read-only								x	
1.1.2.4.6.1.1.11210	Filter 3 current pressure drop	read-only								x	
1.1.2.5.1.1.1769	number of sensors	read-only								x	x
1.1.2.5.1.1.1800	DIN1	read-only								x	x
1.1.2.5.1.1.1801	DIN2	read-only								x	x
1.1.2.5.1.1.1802	DIN3	read-only								x	x
1.1.2.5.1.1.1803	DIN4	read-only								x	x
1.1.2.5.1.1.1804	DIN5	read-only								x	x
1.1.2.5.1.1.1805	DIN6	read-only								x	x
1.1.2.5.1.1.1806	DIN7	read-only								x	x
1.1.2.5.1.1.1807	DIN8	read-only								x	x
1.1.2.5.1.1.1808	DIN9	read-only								x	x
1.1.2.5.1.1.1809	DIN10	read-only								x	x
1.1.2.5.1.1.1810	DIN11	read-only								x	x
1.1.2.5.1.1.1811	DIN12	read-only								x	x
1.1.2.5.1.1.1812	DIN13	read-only								x	x
1.1.2.5.1.1.1813	DIN14	read-only								x	x
1.1.2.5.1.1.1814	DIN15	read-only								x	x
1.1.2.5.1.1.1815	DIN16	read-only								x	x
1.1.2.5.1.1.1816	DIN17	read-only								x	x
1.1.2.5.1.1.1817	DIN18	read-only								x	x
1.1.2.5.1.1.1818	DIN19	read-only								x	x
1.1.2.5.1.1.1819	DIN20	read-only								x	x
1.1.2.5.1.1.1820	DIN21	read-only								x	x
1.1.2.5.1.1.1821	DIN22	read-only								x	x
1.1.2.5.1.1.1822	DIN23	read-only								x	x
1.1.2.5.1.1.1823	DIN24	read-only								x	x
1.1.2.5.1.1.1824	DIN25	read-only								x	x
1.1.2.5.1.1.1825	DIN26	read-only								x	x
1.1.2.5.1.1.1826	DIN27	read-only								x	x
1.1.2.5.1.1.1827	DIN28	read-only								x	x
1.1.2.5.1.1.1828	DIN29	read-only								x	x
1.1.2.5.1.1.1829	DIN30	read-only								x	x
1.1.2.5.1.1.1830	DIN31	read-only								x	x
1.1.2.5.1.1.1831	DIN32	read-only								x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.1.2.5.1.1.1832	DIN33	read-only								x	x
1.1.2.5.1.1.1833	DIN34	read-only								x	x
1.1.2.5.1.1.1834	DIN35	read-only								x	x
1.1.2.5.1.1.1835	DIN36	read-only								x	x
1.1.2.5.1.1.1836	DIN37	read-only								x	x
1.1.2.5.1.1.1837	DIN38	read-only								x	x
1.1.2.5.1.1.1838	DIN39	read-only								x	x
1.1.2.5.1.1.1839	DIN40	read-only								x	x
1.1.2.5.1.1.1840	DIN41	read-only								x	x
1.1.2.5.1.1.1841	DIN42	read-only								x	x
1.1.2.5.1.1.1842	DIN43	read-only								x	x
1.1.2.5.1.1.1843	DOUT1	read-only								x	x
1.1.2.5.1.1.1844	DOUT2	read-only								x	x
1.1.2.5.1.1.1845	DOUT3	read-only								x	x
1.1.2.5.1.1.1846	DOUT4	read-only								x	x
1.1.2.5.1.1.1847	DOUT5	read-only								x	x
1.1.2.5.1.1.1848	DOUT6	read-only								x	x
1.1.2.5.1.1.1849	DOUT7	read-only								x	x
1.1.2.5.1.1.1850	DOUT8	read-only								x	x
1.1.2.5.1.1.1851	DOUT9	read-only								x	x
1.1.2.5.1.1.1852	DOUT10	read-only								x	x
1.1.2.5.1.1.1853	DOUT11	read-only								x	x
1.1.2.5.1.1.1854	DOUT12	read-only								x	x
1.1.2.5.1.1.1855	DOUT13	read-only								x	x
1.1.2.5.1.1.1856	DOUT14	read-only								x	x
1.1.2.5.1.1.1857	DOUT15	read-only								x	x
1.1.2.5.1.1.1858	DOUT16	read-only								x	x
1.1.2.5.1.1.1859	DOUT17	read-only								x	x
1.1.2.5.1.1.1860	DOUT18	read-only								x	x
1.1.2.5.1.1.1861	DOUT19	read-only								x	x
1.1.2.5.1.1.1862	DOUT20	read-only								x	x
1.1.2.5.1.1.1863	DOUT21	read-only								x	x
1.1.2.5.1.1.1864	DOUT22	read-only								x	x
1.1.2.5.1.1.1865	DOUT23	read-only								x	x
1.1.2.5.1.1.1866	DOUT24	read-only								x	x
1.1.2.5.1.1.1867	DOUT25	read-only								x	x
1.1.2.5.1.1.1868	DOUT26	read-only								x	x
1.1.2.5.1.1.1869	DOUT27	read-only								x	x
1.1.2.5.1.1.1870	DOUT28	read-only								x	x
1.1.2.5.1.1.1871	DOUT29	read-only								x	x
1.1.2.5.1.1.1872	DOUT30	read-only								x	x
1.1.2.5.1.1.1873	DOUT31	read-only								x	x
1.1.2.5.1.1.1900	AIN1	read-only								x	x
1.1.2.5.1.1.1901	AIN2	read-only								x	x
1.1.2.5.1.1.1902	AIN3	read-only								x	x
1.1.2.5.1.1.1903	AIN4	read-only								x	x
1.1.2.5.1.1.1904	AIN5	read-only								x	x
1.1.2.5.1.1.1905	AIN6	read-only								x	x
1.1.2.5.1.1.1906	AIN7	read-only								x	x
1.1.2.5.1.1.1907	AIN8	read-only								x	x
1.1.2.5.1.1.1908	AIN9	read-only								x	x
1.1.2.5.1.1.1909	AIN10	read-only								x	x
1.1.2.5.1.1.1910	AIN11	read-only								x	x
1.1.2.5.1.1.1911	AIN12	read-only								x	x
1.1.2.5.1.1.1912	AIN13	read-only								x	x
1.1.2.5.1.1.1913	AIN14	read-only								x	x
1.1.2.5.1.1.1914	AIN15	read-only								x	x
1.1.2.5.1.1.1915	AIN16	read-only								x	x
1.1.2.5.1.1.1916	AIN17	read-only								x	x
1.1.2.5.1.1.1917	AIN18	read-only								x	x
1.1.2.5.1.1.1918	AIN19	read-only								x	x
1.1.2.5.1.1.1919	AIN20	read-only								x	x
1.1.2.5.1.1.1920	AIN21	read-only								x	x
1.1.2.5.1.1.1921	AOUT1	read-only								x	x
1.1.2.5.1.1.1922	AOUT2	read-only								x	x
1.1.2.5.1.1.1923	AOUT3	read-only								x	x
1.1.2.5.1.1.1924	AOUT4	read-only								x	x
1.1.2.5.1.1.1925	AOUT5	read-only								x	x
1.1.2.5.1.1.1926	AOUT6	read-only								x	x
1.1.2.5.1.1.1927	AOUT7	read-only								x	x
1.1.2.5.1.1.1928	AOUT8	read-only								x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number			Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
OID middle part													
1.1.2.5.1.1.1929			AOUT9	read-only								x	x
1.1.2.5.1.1.1930			AOUT10	read-only								x	x
1.1.2.5.1.1.1931			AOUT11	read-only								x	x
1.1.2.5.1.1.1932			AOUT12	read-only								x	x
1.1.2.5.1.1.1933			AOUT13	read-only								x	x
1.1.2.5.1.1.1934			AOUT14	read-only								x	x
1.1.2.5.1.1.1935			AOUT15	read-only								x	x
1.1.2.5.1.1.1936			AOUT16	read-only								x	x
1.1.2.5.1.1.1937			AOUT17	read-only								x	x
1.1.2.5.1.1.1938			AOUT18	read-only								x	x
1.1.2.5.1.1.1939			AOUT19	read-only								x	x
1.1.2.5.1.1.1940			AOUT20	read-only								x	x
1.1.2.6.1.1770			number of ext alarm in	read-only								x	x
1.1.3.1.1.11700			my zone	read-only								x	x
1.1.3.1.1.11701			my zone room temperature	read-only								x	x
1.1.3.1.1.11702			my zone room humidity	read-only								x	x
1.1.3.1.1.11703			my zone supply temperature	read-only								x	x
1.1.3.1.1.11704			my zone supply humidity	read-only								x	x
1.1.3.1.1.11705			my zone sequencing time	read-only								x	x
1.1.4.4.1.1.1.1166			unit runtime cooling	read-only								x	x
1.1.4.4.1.1.1.1167			unit runtime heating	read-only								x	x
1.1.4.4.1.1.1.1168			unit runtime humidification	read-only								x	x
1.1.4.4.1.1.1.1169			unit runtime dehumidification	read-only								x	x
1.1.4.4.1.1.1.1203			unit runtime freecooling	read-only								x	x
1.1.4.4.1.1.1.1204			unit runtime freecool-mixmode	read-only								x	x
1.1.4.4.2.1.1.1.4428			compr. 1 runtime	read-only	x			x	x	x	x	x	x
1.1.4.4.2.1.1.1.4528			compr. 2 runtime	read-only							x	x	x
1.1.4.4.2.1.1.1.9525			compr. 3 runtime	read-only							x	x	
1.1.4.4.2.1.1.1.9625			compr. 4 runtime	read-only							x	x	
1.1.4.4.2.1.1.1.9725			compr. 5 runtime	read-only							x	x	
1.1.4.4.2.1.1.1.9825			compr. 6 runtime	read-only							x	x	
1.1.4.4.2.2.1.1.5820			pump1 runtime	read-only				x	x	x	x	x	x
1.1.4.4.2.2.1.1.5920			pump2 runtime	read-only				x	x	x	x	x	x
1.1.4.4.2.2.1.1.6020			pump3 runtime	read-only								x	
1.1.4.4.2.2.1.1.6120			pump4 runtime	read-only								x	
1.1.4.4.2.3.1.1.4816			elec.-heating1 runtime	read-only								x	
1.1.4.4.2.3.1.1.4916			elec.-heating2 runtime	read-only								x	
1.1.4.4.2.3.1.1.5016			elec.-heating3 runtime	read-only								x	
1.1.4.4.2.4.1.1.5415			drycooler1 runtime	read-only								x	x
1.1.4.4.2.4.1.1.5515			drycooler2 runtime	read-only								x	
1.1.4.4.2.4.1.1.5615			drycooler3 runtime	read-only								x	
1.1.4.4.2.4.1.1.5715			drycooler4 runtime	read-only								x	
1.1.4.4.2.5.1.6426			humidifier1 runtime	read-only				x	x	x		x	
1.1.4.4.2.5.1.6931			fan1 runtime	read-only				x	x	x		x	
1.1.4.4.3.1.1164			unit runtime unit	read-only								x	x
1.1.4.4.3.1.1165			unit stoptime unit	read-only								x	x
1.1.4.5.1.1.1160			unit last maintenance year	read-only								x	x
1.1.4.5.1.1.1161			unit last maintenance month	read-only								x	x
1.1.4.5.1.1.1162			unit last maintenance day	read-only								x	x
1.1.4.5.1.1.1163			unit maintenance intervall	read-only								x	x
1.1.5.2.1.1			unit-type	read-only	x	x		x	x	x		x	x
1.1.5.2.1.3			SW-version	read-only	x	x	x	x	x	x	x	x	x
1.1.5.2.1.1758			number of EDIO	read-only								x	x
1.1.5.2.1.1759			number of EAIO	read-only								x	x
1.1.5.2.1.1760			type of EBUS	read-only								x	x
1.1.5.2.1.1775			number of EEIO	read-only								x	x
1.1.5.2.1.14100			unit name	read-only								x	x
1.2.1.1.1.1.1.1173			unit setpoint temperature day	read-write	x	x	x	x	x	x	x	x	
1.2.1.1.1.1.1.1174			unit setpoint temperature night	read-write							x	x	
1.2.1.1.1.1.1.2239			limit, return air temp. too high alarm	read-only	x	x	x	x	x	x		x	
1.2.1.1.1.1.1.2240			limit, return air temp. too low alarm	read-only	x	x	x	x	x	x		x	
1.2.1.1.1.1.1.2241			limit, supply air temp. too high alarm	read-only				x	x	x		x	
1.2.1.1.1.1.1.2242			limit, supply air temp. too low alarm	read-only				x	x	x		x	
1.2.1.1.1.1.1.2253			limit, return air temp. too high alarm delay	read-only								x	
1.2.1.1.1.1.1.2255			limit, return air temp. too low alarm delay	read-only								x	
1.2.1.1.1.1.1.2257			limit, supply air temp. too high alarm delay	read-only								x	
1.2.1.1.1.1.1.2259			limit, supply air temp. too low alarm delay	read-only								x	
1.2.1.1.2.1.1.1176			unit setpoint humidity	read-write	x	x	x	x	x	x		x	
1.2.1.1.2.1.1.2245			limit, return air humid. too high alarm	read-only	x	x	x	x	x	x		x	
1.2.1.1.2.1.1.2247			limit, supply air humid. too high alarm	read-only				x	x	x		x	
1.2.1.1.2.1.1.2265			limit, return air humid. too high alarm delay	read-only								x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.2.1.1.2.1.1.2267	limit, return air humid. too low alarm delay	read-only								x		
1.2.1.1.2.1.1.2269	limit, supply air humid. too high alarm delay	read-only								x		
1.2.1.1.2.1.1.2271	limit, supply air humid. too low alarm delay	read-only								x		
1.2.1.1.3.1.1.1209	setpoint raised floor pressure	read-write								x	x	
1.2.1.2.1.1.1237	water temperature setpoint 1	read-write									x	
1.2.1.2.1.1.1238	water temperature setpoint 2	read-write									x	
1.2.1.2.1.1.2243	limit, water temp. (in) too high alarm	read-only				x	x	x	x	x	x	
1.2.1.2.1.1.2244	limit, water temp. (in) too low alarm	read-only				x	x	x	x	x	x	
1.2.1.2.1.1.2261	limit, water temp. too high alarm delay	read-only								x	x	
1.2.1.2.1.1.2263	limit, water temp. too low alarm delay	read-only								x	x	
1.2.1.2.1.1.2276	limit, water temp. (out) too high alarm	read-only						x	x			
1.2.1.2.1.1.2277	limit, water temp. (out) too low alarm	read-only						x	x			
1.2.1.3.1.1.1218	unit setpoint condensation pressure Mix mode	read-write									x	
1.2.1.3.1.1.1219	unit setpoint condensation pressure DX mode	read-write						x		x	x	
1.2.1.3.1.1.1220	unit setpoint condensation pressure 2 Mix mode	read-write								x	x	
1.2.1.3.1.1.1221	unit setpoint condensation pressure 2 DX mode	read-write						x		x	x	
1.2.1.3.1.1.1509	LP management alarmdelay	read-only									x	
1.2.1.3.1.1.1539	HP management alarmdelay	read-only									x	
1.2.1.3.1.1.15812	pump1 pressure setpoint	read-only								x		
1.2.1.4.1.1.10308	summer mode temperature offset from setpoint	read-write								x		
1.2.1.4.1.1.10309	anti-freeze mode temperature offset from setpoint	read-write								x		
1.2.1.4.1.1.10314	fan start delay	read-write										
1.2.2.1.1.1.1.1.4416	compressor1 start temp. Summer	read-only	x	x		x	x	x	x	x	x	
1.2.2.1.1.1.1.1.4417	compressor1 hysteresis Summer	read-only	x	x		x	x	x	x	x	x	
1.2.2.1.1.1.1.1.4418	compressor1 start temp. Winter	read-only							x	x	x	
1.2.2.1.1.1.1.1.4419	compressor1 hysteresis winter	read-only							x	x	x	
1.2.2.1.1.1.1.1.4423	compr.1 alarm delay	read-only							x	x		
1.2.2.1.1.1.1.1.4426	compr.1 low press. Alarm delay	read-only							x	x		
1.2.2.1.1.1.1.1.4427	compr.1 break	read-only								x	x	
1.2.2.1.1.2.1.1.4516	compressor 2 start temp. Summer	read-only							x	x	x	
1.2.2.1.1.2.1.1.4517	compressor 2 hysteresis Summer	read-only							x	x	x	
1.2.2.1.1.2.1.1.4518	compressor 2 start temp. Winter	read-only							x	x	x	
1.2.2.1.1.2.1.1.4519	compressor 2 hysteresis winter	read-only							x	x	x	
1.2.2.1.1.2.1.1.4523	compr. 2 alarm delay	read-only							x	x		
1.2.2.1.1.2.1.1.4526	compr. 2 low press. Alarm delay	read-only							x	x		
1.2.2.1.1.2.1.1.4527	compr. 2 break	read-only								x	x	
1.2.2.1.1.3.1.1.9516	compressor 3 start temp. Summer	read-only							x	x		
1.2.2.1.1.3.1.1.9517	compressor 3 hysteresis Summer	read-only							x	x		
1.2.2.1.1.3.1.1.9518	compressor 3 start temp. Winter	read-only							x	x		
1.2.2.1.1.3.1.1.9519	compressor 3 hysteresis winter	read-only							x	x		
1.2.2.1.1.3.1.1.9523	compr. 3 alarm delay	read-only							x	x		
1.2.2.1.1.3.1.1.9528	compr.3 low press. Alarm delay	read-only							x	x		
1.2.2.1.1.3.1.1.9628	compr.4 low press. Alarm delay	read-only							x	x		
1.2.2.1.1.3.1.1.9728	compr.5 low press. Alarm delay	read-only							x	x		
1.2.2.1.1.3.1.1.9828	compr.6 low press. Alarm delay	read-only							x	x		
1.2.2.1.1.4.1.1.9524	compr. 3 break	read-only								x		
1.2.2.1.1.4.1.1.9616	compressor 4 start temp. Summer	read-only							x	x		
1.2.2.1.1.4.1.1.9617	compressor 4 hysteresis Summer	read-only							x	x		
1.2.2.1.1.4.1.1.9618	compressor 4 start temp. Winter	read-only							x	x		
1.2.2.1.1.4.1.1.9619	compressor 4 hysteresis winter	read-only							x	x		
1.2.2.1.1.4.1.1.9623	compr. 4 alarm delay	read-only							x	x		
1.2.2.1.1.4.1.1.9624	compr. 4 break	read-only								x		
1.2.2.1.1.5.1.1.9716	compressor 5 start temp. Summer	read-only							x	x		
1.2.2.1.1.5.1.1.9717	compressor 5 hysteresis Summer	read-only							x	x		
1.2.2.1.1.5.1.1.9718	compressor 5 start temp. Winter	read-only							x	x		
1.2.2.1.1.5.1.1.9719	compressor 5 hysteresis winter	read-only							x	x		
1.2.2.1.1.5.1.1.9723	compr. 5 alarm delay	read-only							x	x		
1.2.2.1.1.5.1.1.9724	compr. 5 break	read-only								x		
1.2.2.1.1.6.1.1.9816	compressor 6 start temp. Summer	read-only							x	x		
1.2.2.1.1.6.1.1.9817	compressor 6 hysteresis Summer	read-only							x	x		
1.2.2.1.1.6.1.1.9818	compressor 6 start temp. Winter	read-only							x	x		
1.2.2.1.1.6.1.1.9819	compressor 6 hysteresis winter	read-only							x	x		
1.2.2.1.1.6.1.1.9823	compr. 6 alarm delay	read-only							x	x		
1.2.2.1.1.6.1.1.9824	compr. 6 break	read-only								x		
1.2.2.1.1.7.1.2249	lowpressure winterdelay	read-only								x		
1.2.2.1.2.1.1.1.4608	suctionvalve1 start temperature	read-only				x	x	x		x		
1.2.2.1.2.1.1.1.4609	suctionvalve1 linear range	read-only				x	x	x		x		
1.2.2.1.2.1.1.1.4708	suctionvalve2 start temperature	read-only								x		
1.2.2.1.2.1.1.1.4709	suctionvalve2 linear range	read-only								x		
1.2.2.1.2.2.1.1.5208	GE/CW-valve start temperature 1	read-only	x			x	x	x		x	x	
1.2.2.1.2.2.1.1.5209	GE/CW-valve linear range 1	read-only	x			x	x	x		x	x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.2.2.1.2.2.1.1.5211	GE/CW-valve GE-off-temp	read-only								x		
1.2.2.1.2.2.1.1.5219	GE/CW-valve start temperature 2	read-only								x		
1.2.2.1.2.2.1.1.5220	GE/CW-valve linear range 2	read-only								x		
1.2.2.1.2.4.1.1.1.8719	eev1 superheat setpoint	read-write								x	x	
1.2.2.1.2.4.1.1.1.8720	eev1 dehumidification superheat setpoint	read-write								x	x	
1.2.2.1.2.4.2.1.1.8819	eev2 superheat setpoint	read-write								x	x	
1.2.2.1.2.4.2.1.1.8820	eev2 dehumidification superheat setpoint	read-write								x	x	
1.2.2.1.2.5.1.1.10108	freecooling start temperature	read-only							x	x	x	
1.2.2.1.2.5.1.1.10109	freecooling hysteresis	read-only							x	x	x	
1.2.2.1.3.1.1.1.5408	drycooler1 start-temperature winter	read-only								x		
1.2.2.1.3.1.1.1.5409	drycooler1 start-temperature summer	read-only				x	x	x		x		
1.2.2.1.3.1.1.1.5410	drycooler1 hysteresis	read-only								x		
1.2.2.1.3.1.1.1.5414	drycooler1 alarm delay	read-only								x	x	
1.2.2.1.3.2.1.1.5508	drycooler2 start-temperature winter	read-only								x		
1.2.2.1.3.2.1.1.5509	drycooler2 start-temperature summer	read-only								x		
1.2.2.1.3.2.1.1.5510	drycooler2 hysteresis	read-only								x		
1.2.2.1.3.2.1.1.5514	drycooler2 alarm delay	read-only								x		
1.2.2.1.3.3.1.1.5608	drycooler3 start-temperature winter	read-only								x		
1.2.2.1.3.3.1.1.5609	drycooler3 start-temperature summer	read-only								x		
1.2.2.1.3.3.1.1.5610	drycooler3 hysteresis	read-only								x		
1.2.2.1.3.3.1.1.5614	drycooler3 alarm delay	read-only								x		
1.2.2.1.3.4.1.1.5708	drycooler4 start-temperature winter	read-only								x		
1.2.2.1.3.4.1.1.5709	drycooler4 start-temperature summer	read-only								x		
1.2.2.1.3.4.1.1.5710	drycooler4 hysteresis	read-only								x		
1.2.2.1.3.4.1.1.5714	drycooler4 alarm delay	read-only								x		
1.2.2.1.4.1.1.1.5809	pump1 start-temperature	read-only				x	x	x		x		
1.2.2.1.4.1.1.1.5810	pump1 hysteresis	read-only				x	x	x		x		
1.2.2.1.4.1.1.1.5811	pump1 linear range	read-only								x		
1.2.2.1.4.1.1.1.5817	pump1 alarm delay	read-only							x	x	x	
1.2.2.1.4.1.1.1.5830	pump 1 setpoint speed	read-write								x		
1.2.2.1.4.2.1.1.5909	pump2 start-temperature	read-only								x		
1.2.2.1.4.2.1.1.5910	pump2 hysteresis	read-only								x		
1.2.2.1.4.2.1.1.5911	pump2 linear range	read-only								x		
1.2.2.1.4.2.1.1.5917	pump2 alarm delay	read-only							x	x	x	
1.2.2.1.4.2.1.1.5930	pump2 setpoint speed	read-write								x		
1.2.2.1.4.3.1.1.6009	pump3 start-temperature	read-only								x		
1.2.2.1.4.3.1.1.6010	pump3 hysteresis	read-only								x		
1.2.2.1.4.3.1.1.6011	pump3 linear range	read-only								x		
1.2.2.1.4.3.1.1.6017	pump3 alarm delay	read-only								x		
1.2.2.1.4.3.1.1.6030	pump3 setpoint speed	read-write								x		
1.2.2.1.4.4.1.1.6109	pump4 start-temperature	read-only								x		
1.2.2.1.4.4.1.1.6110	pump4 hysteresis	read-only								x		
1.2.2.1.4.4.1.1.6111	pump4 linear range	read-only								x		
1.2.2.1.4.4.1.1.6117	pump4 alarm delay	read-only								x		
1.2.2.1.4.4.1.1.6130	pump4 setpoint speed	read-write								x		
1.2.2.1.5.1.1.1.9908	ECO-COOL louver start outdoor temperature	read-only								x		
1.2.2.1.5.1.1.1.9909	ECO-COOL louver hysteresis	read-only								x		
1.2.2.1.5.1.1.1.9910	ECO-COOL louver start temperature	read-only								x		
1.2.2.1.5.1.1.1.9911	ECO-COOL louver linear range	read-only								x		
1.2.2.1.6.1.1.1.10823	Cond. fan 1 alarm delay	read-write								x		
1.2.2.1.6.1.1.1.10923	Cond. fan 2 alarm delay	read-write								x		
1.2.2.2.1.1.1.1.4809	elec.-heating1 start temperature	read-only	x	x		x	x	x		x		
1.2.2.2.1.1.1.1.4810	elec.-heating1 hysteresis	read-only	x	x		x	x	x		x		
1.2.2.2.1.1.1.1.4811	elec.-heating1 linear range	read-only								x		
1.2.2.2.1.1.1.1.4815	elec.-heating1 alarm delay	read-only								x		
1.2.2.2.1.2.1.1.4909	elec.-heating2 start temperature	read-only	x			x	x	x		x		
1.2.2.2.1.2.1.1.4910	elec.-heating2 hysteresis	read-only	x			x	x	x		x		
1.2.2.2.1.2.1.1.4911	elec.-heating2 linear range	read-only								x		
1.2.2.2.1.2.1.1.4915	elec.-heating2 alarm delay	read-only								x		
1.2.2.2.1.3.1.1.5009	elec.-heating3 start temperature	read-only				x	x	x		x		
1.2.2.2.1.3.1.1.5010	elec.-heating3 hysteresis	read-only				x	x	x		x		
1.2.2.2.1.3.1.1.5011	elec.-heating3 linear range	read-only								x		
1.2.2.2.1.3.1.1.5015	elec.-heating3 alarm delay	read-only								x		
1.2.2.2.2.1.1.6208	hotgas-heating start temperature	read-only								x		
1.2.2.2.2.1.1.6209	hotgas-heating hysteresis	read-only								x		
1.2.2.2.2.1.1.6213	hotgas-heating alarm delay	read-only								x		
1.2.2.2.3.1.1.6309	PWW-heating start-temperature	read-only				x	x	x		x		
1.2.2.2.3.1.1.6311	PWW-heating hysteresis	read-only				x	x	x		x		
1.2.2.2.3.1.1.6312	PWW-heating linear range	read-only				x	x	x		x		
1.2.2.3.1.1.1.6417	humidifier1 start-humidity	read-only	x	x		x	x	x		x		
1.2.2.3.1.1.1.6419	humidifier1 hysteresis	read-only	x	x		x	x	x		x		

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.2.2.3.1.1.1.6420	humidifier1 linear range	read-only		x		x	x	x		x		
1.2.2.3.1.1.1.6425	humidifier1 alarm delay	read-only								x		
1.2.2.3.1.1.1.6431	humidifier1 alarm delay 5uS	read-only								x		
1.2.2.3.1.1.1.6432	humidifier1 alarm delay 20uS	read-only								x		
1.2.2.3.2.1.1.6809	dehumidifier start-humidity	read-only	x	x		x	x	x		x		
1.2.2.3.2.1.1.6811	dehumidification hysteresis	read-only	x	x		x	x	x		x		
1.2.2.3.2.1.1.6817	dehumidifier min water temp	read-only								x		
1.2.2.3.2.1.1.6818	dehumidifier max water temp	read-only								x		
1.2.2.4.1.1.1.6909	fan1 speed nmax.	read-write								x		
1.2.2.4.1.1.1.6910	fan1 CW-mode nmax	read-write								x		
1.2.2.4.1.1.1.6913	fan1 start temp	read-only								x		
1.2.2.4.1.1.1.6914	fan1 start speed	read-only								x		
1.2.2.4.1.1.1.6927	fan1 alarm delay	read-only							x	x		
1.2.2.4.1.1.1.6930	fan1 filter alarm delay	read-only								x		
1.2.2.4.1.1.1.7027	fan2 alarm delay	read-only							x	x		
1.2.2.4.2.1.1.7208	louver1 delay	read-only								x		
1.2.2.4.6.1.1.11009	Filter 1 pressure drop	read-write								x		
1.2.2.4.6.1.1.11012	Filter 1 alarm delay	read-write								x		
1.2.2.4.6.1.1.11109	Filter 2 pressure drop	read-write								x		
1.2.2.4.6.1.1.11209	Filter 3 pressure drop	read-write								x		
1.2.2.5.1.1.1.2317	sensor1 alarm delay	read-only							x	x	x	
1.2.2.5.1.1.1.2319	sensor1 failure alarm delay	read-only								x	x	
1.2.2.5.1.1.1.2320	sensor1 adjust offset	read-only								x	x	
1.2.2.5.1.1.1.2321	sensor1 current phys. value	read-only								x	x	
1.2.2.5.2.1.1.2417	sensor2 alarm delay	read-only							x	x	x	
1.2.2.5.2.1.1.2419	sensor2 failure alarm delay	read-only								x	x	
1.2.2.5.2.1.1.2420	sensor2 adjust offset	read-only								x	x	
1.2.2.5.2.1.1.2421	sensor2 current phys. value	read-only								x	x	
1.2.2.5.3.1.1.2517	sensor3 alarm delay	read-only								x	x	
1.2.2.5.3.1.1.2519	sensor3 failure alarm delay	read-only							x	x	x	
1.2.2.5.3.1.1.2520	sensor3 adjust offset	read-only								x	x	
1.2.2.5.3.1.1.2521	sensor3 current phys. value	read-only								x	x	
1.2.2.5.4.1.1.2617	sensor4 alarm delay	read-only							x	x	x	
1.2.2.5.4.1.1.2619	sensor4 failure alarm delay	read-only								x	x	
1.2.2.5.4.1.1.2620	sensor4 adjust offset	read-only								x	x	
1.2.2.5.4.1.1.2621	sensor4 current phys. value	read-only								x	x	
1.2.2.5.5.1.1.2717	sensor5 alarm delay	read-only							x	x	x	
1.2.2.5.5.1.1.2719	sensor5 failure alarm delay	read-only								x	x	
1.2.2.5.5.1.1.2720	sensor5 adjust offset	read-only								x	x	
1.2.2.5.5.1.1.2721	sensor5 current phys. value	read-only								x	x	
1.2.2.5.6.1.1.2817	sensor6 alarm delay	read-only								x	x	
1.2.2.5.6.1.1.2819	sensor6 failure alarm delay	read-only								x	x	
1.2.2.5.6.1.1.2820	sensor6 adjust offset	read-only								x	x	
1.2.2.5.6.1.1.2821	sensor6 current phys. value	read-only								x	x	
1.2.2.5.7.1.1.2917	sensor7 alarm delay	read-only								x	x	
1.2.2.5.7.1.1.2919	sensor7 failure alarm delay	read-only								x	x	
1.2.2.5.7.1.1.2920	sensor7 adjust offset	read-only								x	x	
1.2.2.5.7.1.1.2921	sensor7 current phys. value	read-only								x	x	
1.2.2.5.8.1.1.3017	sensor8 alarm delay	read-only								x	x	
1.2.2.5.8.1.1.3019	sensor8 failure alarm delay	read-only								x	x	
1.2.2.5.8.1.1.3020	sensor8 adjust offset	read-only								x	x	
1.2.2.5.8.1.1.3021	sensor8 current phys. value	read-only								x	x	
1.2.2.5.9.1.1.3117	sensor9 alarm delay	read-only								x	x	
1.2.2.5.9.1.1.3119	sensor9 failure alarm delay	read-only								x	x	
1.2.2.5.9.1.1.3120	sensor9 adjust offset	read-only								x	x	
1.2.2.5.9.1.1.3121	sensor9 current phys. value	read-only								x	x	
1.2.2.5.10.1.1.3217	sensor10 alarm delay	read-only								x	x	
1.2.2.5.10.1.1.3219	sensor10 failure alarm delay	read-only								x	x	
1.2.2.5.10.1.1.3220	sensor10 adjust offset	read-only								x	x	
1.2.2.5.10.1.1.3221	sensor10 current phys. value	read-only								x	x	
1.2.2.5.11.1.1.3317	sensor11 alarm delay	read-only								x	x	
1.2.2.5.11.1.1.3319	sensor11 failure alarm delay	read-only								x	x	
1.2.2.5.11.1.1.3320	sensor11 adjust offset	read-only								x	x	
1.2.2.5.11.1.1.3321	sensor11 current phys. value	read-only								x	x	
1.2.2.5.12.1.1.3417	sensor12 alarm delay	read-only								x	x	
1.2.2.5.12.1.1.3419	sensor12 failure alarm delay	read-only								x	x	
1.2.2.5.12.1.1.3420	sensor12 adjust offset	read-only								x	x	
1.2.2.5.12.1.1.3421	sensor12 current phys. value	read-only								x	x	
1.2.2.5.13.1.1.3517	sensor13 alarm delay	read-only								x	x	
1.2.2.5.13.1.1.3519	sensor13 failure alarm delay	read-only								x	x	
1.2.2.5.13.1.1.3520	sensor13 adjust offset	read-only								x	x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.2.2.5.13.1.1.3521	sensor13 current phys. value	read-only							x	x	
1.2.2.5.14.1.1.3617	sensor14 alarm delay	read-only							x	x	
1.2.2.5.14.1.1.3619	sensor14 failure alarm delay	read-only							x	x	
1.2.2.5.14.1.1.3620	sensor14 adjust offset	read-only							x	x	
1.2.2.5.14.1.1.3621	sensor14 current phys. value	read-only							x	x	
1.2.2.5.15.1.1.3717	sensor15 alarm delay	read-only							x	x	
1.2.2.5.15.1.1.3719	sensor15 failure alarm delay	read-only							x	x	
1.2.2.5.15.1.1.3720	sensor15 adjust offset	read-only							x	x	
1.2.2.5.15.1.1.3721	sensor15 current phys. value	read-only							x	x	
1.2.2.5.16.1.1.3817	sensor16 alarm delay	read-only							x	x	
1.2.2.5.16.1.1.3819	sensor16 failure alarm delay	read-only							x	x	
1.2.2.5.16.1.1.3820	sensor16 adjust offset	read-only							x	x	
1.2.2.5.16.1.1.3821	sensor16 current phys. value	read-only							x	x	
1.2.2.5.17.1.1.3917	sensor17 alarm delay	read-only							x	x	
1.2.2.5.17.1.1.3919	sensor17 failure alarm delay	read-only							x	x	
1.2.2.5.17.1.1.3920	sensor17 adjust offset	read-only							x	x	
1.2.2.5.17.1.1.3921	sensor17 current phys. value	read-only							x	x	
1.2.2.5.18.1.1.4017	sensor18 alarm delay	read-only							x	x	
1.2.2.5.18.1.1.4019	sensor18 failure alarm delay	read-only							x	x	
1.2.2.5.18.1.1.4020	sensor18 adjust offset	read-only							x	x	
1.2.2.5.18.1.1.4021	sensor18 current phys. value	read-only							x	x	
1.2.2.5.19.1.1.4117	sensor19 alarm delay	read-only							x	x	
1.2.2.5.19.1.1.4119	sensor19 failure alarm delay	read-only							x	x	
1.2.2.5.19.1.1.4120	sensor19 adjust offset	read-only							x	x	
1.2.2.5.19.1.1.4121	sensor19 current phys. value	read-only							x	x	
1.2.2.5.20.1.1.4217	sensor20 alarm delay	read-only							x	x	
1.2.2.5.20.1.1.4219	sensor20 failure alarm delay	read-only							x	x	
1.2.2.5.20.1.1.4220	sensor20 adjust offset	read-only							x	x	
1.2.2.5.20.1.1.4221	sensor20 current phys. value	read-only							x	x	
1.2.2.5.21.1.1.4317	sensor21 alarm delay	read-only							x	x	
1.2.2.5.21.1.1.4319	sensor21 failure alarm delay	read-only							x	x	
1.2.2.5.21.1.1.4320	sensor21 adjust offset	read-only							x	x	
1.2.2.5.21.1.1.4321	sensor21 current phys. value	read-only							x	x	
1.2.2.6.1.1.1.1.7510	ext. alarm1 delay	read-only							x	x	
1.2.2.6.1.1.1.1.7511	ext. alarm1 text 0	read-only							x	x	
1.2.2.6.1.2.1.1.7610	ext. alarm2 delay	read-only							x	x	
1.2.2.6.1.2.1.1.7611	ext. alarm2 text 0	read-only							x	x	
1.2.2.6.1.3.1.1.7710	ext. alarm3 delay	read-only							x	x	
1.2.2.6.1.3.1.1.7711	ext. alarm3 text 0	read-only							x	x	
1.2.2.6.1.4.1.1.7810	ext. alarm4 delay	read-only							x	x	
1.2.2.6.1.4.1.1.7811	ext. alarm4 text 0	read-only							x	x	
1.2.2.6.1.5.1.1.7910	ext. alarm5 delay	read-only							x	x	
1.2.2.6.1.5.1.1.7911	ext. alarm5 text 0	read-only							x	x	
1.2.2.6.1.6.1.1.8010	ext. alarm6 delay	read-only							x	x	
1.2.2.6.1.6.1.1.8011	ext. alarm6 text 0	read-only							x	x	
1.2.2.6.1.7.1.1.8110	ext. alarm7 delay	read-only							x	x	
1.2.2.6.1.7.1.1.8111	ext. alarm7 text 0	read-only							x	x	
1.2.2.6.1.8.1.1.8210	ext. alarm8 delay	read-only							x	x	
1.2.2.6.1.8.1.1.8211	ext. alarm8 text 0	read-only							x	x	
1.2.2.6.1.9.1.1.8310	ext. alarm9 delay	read-only							x	x	
1.2.2.6.1.9.1.1.8311	ext. alarm9 text 0	read-only							x	x	
1.2.2.6.1.10.1.1.8410	ext. alarm10 delay	read-only							x	x	
1.2.2.6.1.10.1.1.8411	ext. alarm10 text 0	read-only							x	x	
1.2.2.6.2.1.1.17	busalarmdelay	read-only							x	x	
1.2.2.6.2.1.1.19	busadronconflict delay	read-only							x	x	
1.2.2.6.2.1.1.1712	fire alarm delay	read-only							x	x	
1.2.2.6.2.1.1.1714	water alarm delay	read-only							x	x	
1.2.2.6.2.1.1.1716	phase alarm delay	read-only							x	x	
1.2.2.6.2.1.1.1720	waterflow alarm delay	read-only							x	x	
1.2.2.6.2.1.1.1721	freeze alarm delay	read-only							x	x	
1.2.2.6.2.1.1.10313	room high pressure alarm delay	read-write							x		
1.3.1.1.1.1.1.1184	limited control: start temperature	read-only							x	x	
1.3.1.1.1.1.1.1185	limited control: lineary range temperature	read-only							x	x	
1.3.1.1.1.1.1.1190	unit integral factor	read-only							x	x	
1.3.1.1.1.1.1.1228	limited control: start temperature 2	read-only							x	x	
1.3.1.1.1.1.1.2251	unit overload switch on by temp	read-only							x	x	
1.3.1.1.1.1.1.2252	limit, return air temp. too high alarm priorities	read-only							x		
1.3.1.1.1.1.1.2254	limit, return air temp. too low alarm priorities	read-only							x		
1.3.1.1.1.1.1.2256	limit, supply air temp. too high alarm priorities	read-only							x		
1.3.1.1.1.1.1.2258	limit, supply air temp. too low alarm priorities	read-only							x		
1.3.1.1.1.1.1.2284	limit, return air temp. too high common alarm config	read-only							x		

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.1.1.1.1.2285	limit, return air temp. too low common alarm config	read-only								x		
1.3.1.1.1.1.2286	limit, supply air temp. too high common alarm config	read-only								x		
1.3.1.1.1.1.2287	limit, supply air temp. too low common alarm config	read-only								x		
1.3.1.1.2.1.1.1186	limited control: start humidity	read-only								x	x	
1.3.1.1.2.1.1.1187	limited control: lineary range humidity	read-only								x	x	
1.3.1.1.2.1.1.2264	limit, return air humid. too high alarm priorities	read-only								x		
1.3.1.1.2.1.1.2266	limit, return air humid. too low alarm priorities	read-only								x		
1.3.1.1.2.1.1.2268	limit, supply air humid. too high alarm priorities	read-only								x		
1.3.1.1.2.1.1.2270	limit, supply air humid. too low alarm priorities	read-only								x		
1.3.1.1.2.1.1.2275	unit overload switch on by humidity	read-only								x		
1.3.1.1.2.1.1.2290	limit, return air humid. too high common alarm config	read-only								x		
1.3.1.1.2.1.1.2291	limit, return air humid. too low common alarm config	read-only								x		
1.3.1.1.2.1.1.2292	limit, supply air humid. too high common alarm config	read-only								x		
1.3.1.1.2.1.1.2293	limit, supply air humid. too low common alarm config	read-only								x		
1.3.1.1.4.1.1183	unit control type, air (ac-units)	read-write								x		
1.3.1.2.1.1.1229	control type water (chiller)	read-write									x	
1.3.1.2.1.1.1239	unit overload switch on by watertemp	read-only									x	
1.3.1.2.1.1.2260	limit, water temp. too high alarm priorities	read-only								x	x	
1.3.1.2.1.1.2262	limit, water temp. too low alarm priorities	read-only								x	x	
1.3.1.2.1.1.2288	limit, water temp. too high common alarm config	read-only								x		
1.3.1.2.1.1.2289	limit, water temp. too low common alarm config	read-only								x		
1.3.1.3.1.1.1.1500	LP management common alarm config	read-only									x	
1.3.1.3.1.1.1.1508	LP management digital in	read-only									x	
1.3.1.3.1.1.1.1510	LP management alarmpriority	read-only									x	
1.3.1.3.1.1.1.1511	LP management time	read-only									x	
1.3.1.3.1.1.1.1512	LP management min pressure	read-only									x	
1.3.1.3.1.1.1.1513	LP management tries	read-only									x	
1.3.1.3.2.1.1.1530	HP management common alarm config	read-only									x	
1.3.1.3.2.1.1.1538	HP management digital in	read-only									x	
1.3.1.3.2.1.1.1540	HP management alarmpriority	read-only									x	
1.3.1.3.2.1.1.1541	HP management time	read-only									x	
1.3.1.3.2.1.1.1542	HP management max pressure	read-only									x	
1.3.1.3.2.1.1.1543	HP management tries	read-only									x	
1.3.1.3.2.1.1.1544	HP management mode	read-only									x	
1.3.1.4.1.1.1025	CW2 change-over	read-write								x	x	
1.3.1.4.1.1.1026	CW2 change-over state	read-only								x	x	
1.3.1.4.1.1.1027	OTE-mode off	read-write								x	x	
1.3.1.4.1.1.1028	unit start by remote-on/off	read-only								x	x	
1.3.1.4.1.1.1198	unit cooling priority	read-write								x	x	
1.3.1.4.1.1.1205	unit start delay	read-only								x	x	
1.3.1.4.1.1.1746	auto-restart after phase alarm	read-only								x	x	
1.3.1.5.1.1.1188	unit winter-mode starttemp	read-only								x	x	
1.3.1.5.1.1.1189	unit winter-mode hysteresis	read-only								x	x	
1.3.1.5.1.1.1199	outside temperature for pressure	read-only								x	x	
1.3.1.5.1.1.1200	gradient for pressure	read-only										
1.3.1.6.1.1.1231	freeze circulation starttemp	read-only									x	
1.3.1.6.1.1.1232	freeze circulation stop hysteresis	read-only									x	
1.3.1.6.1.1.1235	pump 1, 2 sequencing time	read-only									x	
1.3.1.6.1.1.1236	pump 1, 2 handover time	read-only									x	
1.3.1.6.1.1.1724	Free cooling (winter mode) analog aout	read-only									x	
1.3.1.6.1.1.10100	freecooling config	read-only							x	x		
1.3.1.6.1.1.10110	freecooling valve opening start	read-only							x	x		
1.3.1.6.1.1.10111	freecooling valve gradient	read-only							x	x		
1.3.1.6.1.1.10112	freecooling stop temperature	read-only							x	x		
1.3.1.7.1.1.10300	AE control active	read-only								x		
1.3.1.7.1.1.10303	force summer mode	read-write								x		
1.3.1.7.1.1.10304	action on humidity too high alarm	read-write								x		
1.3.1.7.1.1.10305	action on water alarm	read-write								x		
1.3.2.1.1.1.1.1.4400	compressor1 config. active	read-only								x	x	
1.3.2.1.1.1.1.1.4407	compr.1 common alarm config	read-only								x		
1.3.2.1.1.1.1.1.4408	compr.1 low press. common alarm config	read-only								x		
1.3.2.1.1.1.1.1.4420	compr.1 digital out	read-only								x	x	
1.3.2.1.1.1.1.1.4421	compr.1 alarm digital in	read-only								x		
1.3.2.1.1.1.1.1.4422	compr.1 alarm priorities	read-only								x		
1.3.2.1.1.1.1.1.4424	compr.1 low press. Digital in	read-only								x		
1.3.2.1.1.1.1.1.4425	compr.1 low press. Alarm priorities	read-only								x		
1.3.2.1.1.1.1.1.4429	compr.1 low press manag. time	read-only								x		
1.3.2.1.1.1.1.1.4430	compr.1 low press manag. press.	read-only								x		
1.3.2.1.1.1.1.1.4431	compr.1 low press manag. restarts	read-only								x		
1.3.2.1.1.1.1.1.4432	compr.1 high press manag. time	read-only								x		
1.3.2.1.1.1.1.1.4433	compr.1 high press manag. press.	read-only							x	x		

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part		Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.3.2.1.1.1.1.1.4434		compr.1 high press manag. restarts	read-only								x	
1.3.2.1.1.1.1.1.4435		compr.1 high press manag. mode	read-only								x	
1.3.2.1.1.2.1.1.4500		compressor 2 config. active	read-only								x	
1.3.2.1.1.2.1.1.4507		compr. 2 common alarm config	read-only								x	
1.3.2.1.1.2.1.1.4508		compr. 2 low press. common alarm config	read-only								x	
1.3.2.1.1.2.1.1.4520		compr. 2 digital out	read-only								x	
1.3.2.1.1.2.1.1.4521		compr. 2 alarm digital in	read-only								x	
1.3.2.1.1.2.1.1.4522		compr. 2 alarm priorities	read-only								x	
1.3.2.1.1.2.1.1.4524		compr. 2 low press. Digital in	read-only								x	
1.3.2.1.1.2.1.1.4525		compr. 2 low press. Alarm priorities	read-only								x	
1.3.2.1.1.2.1.1.4529		compr 2 low press manag. time	read-only								x	
1.3.2.1.1.2.1.1.4530		compr 2 low press manag. press.	read-only								x	
1.3.2.1.1.2.1.1.4531		compr.2 low press manag. restarts	read-only								x	
1.3.2.1.1.2.1.1.4532		compr.2 high press manag. time	read-only								x	
1.3.2.1.1.2.1.1.4533		compr.2 high press manag. press.	read-only							x		
1.3.2.1.1.2.1.1.4534		compr.2 high press manag. restarts	read-only							x		
1.3.2.1.1.2.1.1.4535		compr.2 high press manag. mode	read-only							x		
1.3.2.1.1.3.1.1.9500		compressor 3 config. active	read-only								x	
1.3.2.1.1.3.1.1.9507		compr. 3 common alarm config	read-only								x	
1.3.2.1.1.3.1.1.9520		compr. 3 digital out	read-only								x	
1.3.2.1.1.3.1.1.9521		compr. 3 alarm digital in	read-only								x	
1.3.2.1.1.3.1.1.9522		compr. 3 alarm priorities	read-only								x	
1.3.2.1.1.3.1.1.9526		compr 3 low press. Digital in	read-only								x	
1.3.2.1.1.3.1.1.9527		compr 3 low press. Alarm priorities	read-only								x	
1.3.2.1.1.3.1.1.9626		compr 4 low press. Digital in	read-only								x	
1.3.2.1.1.3.1.1.9627		compr.4 low press. Alarm priorities	read-only								x	
1.3.2.1.1.3.1.1.9726		compr.5 low press. Digital in	read-only								x	
1.3.2.1.1.3.1.1.9727		compr.5 low press. Alarm priorities	read-only								x	
1.3.2.1.1.3.1.1.9826		compr.6 low press. Digital in	read-only								x	
1.3.2.1.1.3.1.1.9827		compr.6 low press. Alarm priorities	read-only								x	
1.3.2.1.1.4.1.1.9600		compressor 4 config. active	read-only								x	
1.3.2.1.1.4.1.1.9607		compr. 4 common alarm config	read-only								x	
1.3.2.1.1.4.1.1.9620		compr. 4 digital out	read-only								x	
1.3.2.1.1.4.1.1.9621		compr. 4 alarm digital in	read-only								x	
1.3.2.1.1.4.1.1.9622		compr. 4 alarm priorities	read-only								x	
1.3.2.1.1.5.1.1.9700		compressor 5 config. active	read-only								x	
1.3.2.1.1.5.1.1.9707		compr. 5 common alarm config	read-only								x	
1.3.2.1.1.5.1.1.9720		compr. 5 digital out	read-only								x	
1.3.2.1.1.5.1.1.9721		compr. 5 alarm digital in	read-only								x	
1.3.2.1.1.5.1.1.9722		compr. 5 alarm priorities	read-only								x	
1.3.2.1.1.6.1.1.9800		compressor 6 config. active	read-only								x	
1.3.2.1.1.6.1.1.9807		compr. 6 common alarm config	read-only								x	
1.3.2.1.1.6.1.1.9820		compr. 6 digital out	read-only								x	
1.3.2.1.1.6.1.1.9821		compr. 6 alarm digital in	read-only								x	
1.3.2.1.1.6.1.1.9822		compr. 6 alarm priorities	read-only								x	
1.3.2.1.2.1.1.1.4600		suctionvalve1 config. Active	read-only								x	
1.3.2.1.2.1.1.1.4610		suctionvalve1 analog out	read-only								x	
1.3.2.1.2.1.1.1.4700		suctionvalve2 config. Active	read-only								x	
1.3.2.1.2.1.1.1.4710		suctionvalve2 analog out	read-only								x	
1.3.2.1.2.2.1.1.5200		GE/CW-valve config active	read-only								x	
1.3.2.1.2.2.1.1.5202		GE/CW-valve close with compr.-start	read-only								x	
1.3.2.1.2.2.1.1.5203		GE/CW-valve close if WT over SP	read-only								x	
1.3.2.1.2.2.1.1.5204		GE/CW-valve heating permitted	read-only								x	
1.3.2.1.2.2.1.1.5210		GE/CW-valve analog out 1	read-only								x	
1.3.2.1.2.2.1.1.5216		GE/CW-valve analog out 2	read-only								x	
1.3.2.1.2.2.1.1.5217		GE/CW-valve din for switch	read-only								x	
1.3.2.1.2.2.1.1.5218		GE/CW-valve opening grade setpoint	read-only								x	
1.3.2.1.2.2.1.1.5222		GE/CW-valve dout for switch	read-only								x	
1.3.2.1.2.2.1.1.5223		GE/CW-valve operation mode	read-only								x	
1.3.2.1.2.2.1.1.5228		GE/CW-valve opening grade of valve 1 during switch	read-only								x	
1.3.2.1.2.2.1.1.5231		GE/CW-valve control cycle	read-only									x
1.3.2.1.2.2.1.1.5232		GE/CW-valve P factor	read-only									x
1.3.2.1.2.2.1.1.5233		GE/CW-valve I factor	read-only									x
1.3.2.1.2.2.1.1.5234		GE/CW-valve D factor	read-only									x
1.3.2.1.2.2.1.1.5235		GE/CW-valve maximum opening time	read-only									x
1.3.2.1.2.2.1.1.5236		GE/CW-valve max adjust	read-only									x
1.3.2.1.2.2.1.1.5237		GE/CW-valve max adjust, calculated	read-only									x
1.3.2.1.2.3.1.1.5300		G-valve config active	read-only								x	
1.3.2.1.2.3.1.1.5308		G-valve pressure setpoint	read-only								x	
1.3.2.1.2.3.1.1.5309		G-valve analog out	read-only								x	
1.3.2.1.2.3.1.1.5310		G-valve pre opening time	read-write								x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.3.2.1.2.3.1.1.5311	G-valve pre opening grade	read-write								x	
1.3.2.1.2.3.1.1.5314	G-valve I factor	read-only								x	x
1.3.2.1.2.3.1.1.5315	G-valve D factor	read-only								x	x
1.3.2.1.2.3.1.1.5316	G-valve control cycle	read-write								x	x
1.3.2.1.2.3.1.1.5317	G-valve max adjust	read-write								x	x
1.3.2.1.2.3.1.1.5318	G-valve control factor / P factor	read-write								x	x
1.3.2.1.2.3.1.1.5319	G-valve opening grade setpoint	read-only								x	
1.3.2.1.2.3.1.1.5320	G-valve opening grade min	read-only								x	x
1.3.2.1.2.3.1.1.5321	G-valve maximum opening time	read-only									x
1.3.2.1.2.3.1.1.5322	G-valve max adjust, calculated	read-only									x
1.3.2.1.2.3.1.1.5323	G-valve opening grade, watertemp start	read-only									x
1.3.2.1.2.3.1.1.5324	G-valve opening grade start	read-only									x
1.3.2.1.2.3.1.1.5325	G-valve opening grade, watertemp stop	read-only									x
1.3.2.1.2.3.1.1.5326	G-valve opening grade stop	read-only									x
1.3.2.1.2.3.1.1.5327	G-valve pre opening grade, calculated	read-only									x
1.3.2.1.2.4.1.1.1.9300	hgbp1 config. active	read-only								x	x
1.3.2.1.2.4.1.1.1.9308	hgbp1 p-factor	read-only								x	x
1.3.2.1.2.4.1.1.1.9309	hgbp1 i-factor	read-only								x	x
1.3.2.1.2.4.1.1.1.9310	hgbp1 d-factor	read-only								x	x
1.3.2.1.2.4.1.1.1.9311	hgbp1 control cycle	read-only								x	x
1.3.2.1.2.4.1.1.1.9312	hgbp1 pre opening time	read-only								x	x
1.3.2.1.2.4.1.1.1.9313	hgbp1 pre opening grade	read-only								x	x
1.3.2.1.2.4.1.1.1.9314	hgbp1 min opening grade	read-only								x	x
1.3.2.1.2.4.1.1.1.9315	hgbp1 max opening grade	read-only								x	x
1.3.2.1.2.4.1.1.1.9316	hgbp1 analog out	read-only								x	x
1.3.2.1.2.4.2.1.1.9400	hgbp2 config. active	read-only								x	
1.3.2.1.2.4.2.1.1.9408	hgbp2 p-factor	read-only								x	
1.3.2.1.2.4.2.1.1.9409	hgbp2 i-factor	read-only								x	
1.3.2.1.2.4.2.1.1.9410	hgbp2 d-factor	read-only								x	
1.3.2.1.2.4.2.1.1.9411	hgbp2 control cycle	read-only								x	
1.3.2.1.2.4.2.1.1.9412	hgbp2 pre opening time	read-only								x	
1.3.2.1.2.4.2.1.1.9413	hgbp2 pre opening grade	read-only								x	
1.3.2.1.2.4.2.1.1.9414	hgbp2 min opening grade	read-only								x	
1.3.2.1.2.4.2.1.1.9415	hgbp2 max opening grade	read-only								x	
1.3.2.1.2.4.2.1.1.9416	hgbp2 analog out	read-only								x	
1.3.2.1.2.5.1.1.1.8700	eev1 config active	read-only								x	x
1.3.2.1.2.5.1.1.1.8701	eev1 battery supply	read-only								x	x
1.3.2.1.2.5.1.1.1.8702	eev1 MOP control	read-only								x	x
1.3.2.1.2.5.1.1.1.8703	eev1 superheat control mode	read-only								x	x
1.3.2.1.2.5.1.1.1.8708	eev1 pressure sensor error common alarm config	read-write								x	x
1.3.2.1.2.5.1.1.1.8709	eev1 temperature sensor error common alarm config	read-write								x	x
1.3.2.1.2.5.1.1.1.8710	eev1 stepper motor error common alarm config	read-write								x	x
1.3.2.1.2.5.1.1.1.8716	eev1 battery holding time	read-only								x	x
1.3.2.1.2.5.1.1.1.8717	eev1 refrigerant	read-only								x	x
1.3.2.1.2.5.1.1.1.8718	eev1 MOP temperature	read-only								x	x
1.3.2.1.2.5.1.1.1.8721	eev1 start-up opening duration	read-write								x	x
1.3.2.1.2.5.1.1.1.8722	eev1 start-up opening	read-write								x	x
1.3.2.1.2.5.1.1.1.8723	eev1 valve type	read-only								x	x
1.3.2.1.2.5.1.1.1.8724	eev1 sensor type evaporationg pressure	read-only								x	x
1.3.2.1.2.5.1.1.1.8732	eev1 pressure sensor error alarmprio	read-write								x	x
1.3.2.1.2.5.1.1.1.8733	eev1 temperature sensor error alarmprio	read-write								x	x
1.3.2.1.2.5.1.1.1.8734	eev1 stepper motor error alarmprio	read-write								x	x
1.3.2.1.2.5.2.1.1.8800	eev2 config active	read-only								x	x
1.3.2.1.2.5.2.1.1.8801	eev2 battery supply	read-only								x	x
1.3.2.1.2.5.2.1.1.8802	eev2 MOP control	read-only								x	x
1.3.2.1.2.5.2.1.1.8803	eev2 superheat control mode	read-only								x	x
1.3.2.1.2.5.2.1.1.8808	eev2 pressure sensor error common alarm config	read-write								x	x
1.3.2.1.2.5.2.1.1.8809	eev2 temperature sensor error common alarm config	read-write								x	x
1.3.2.1.2.5.2.1.1.8810	eev2 stepper motor error common alarm config	read-write								x	x
1.3.2.1.2.5.2.1.1.8816	eev2 battery holding time	read-only								x	x
1.3.2.1.2.5.2.1.1.8817	eev2 refrigerant	read-only								x	x
1.3.2.1.2.5.2.1.1.8818	eev2 MOP temperature	read-only								x	x
1.3.2.1.2.5.2.1.1.8821	eev2 start-up opening duration	read-write								x	x
1.3.2.1.2.5.2.1.1.8822	eev2 start-up opening	read-write								x	x
1.3.2.1.2.5.2.1.1.8823	eev2 valve type	read-only								x	x
1.3.2.1.2.5.2.1.1.8824	eev2 sensor type evaporationg pressure	read-only								x	x
1.3.2.1.2.5.2.1.1.8832	eev2 pressure sensor error alarmprio	read-write								x	x
1.3.2.1.2.5.2.1.1.8833	eev2 temperature sensor error alarmprio	read-write								x	x
1.3.2.1.2.5.2.1.1.8834	eev2 stepper motor error alarmprio	read-write								x	x
1.3.2.1.3.1.1.1.5400	drycooler1 config active	read-only								x	x
1.3.2.1.3.1.1.1.5405	drycooler1 common alarm config	read-only								x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.2.1.3.1.1.1.5411	drycooler1 digital out	read-only								x	x	
1.3.2.1.3.1.1.1.5412	drycooler1 alarm digital in	read-only								x	x	
1.3.2.1.3.1.1.1.5413	drycooler1 alarm priorities	read-only								x	x	
1.3.2.1.3.1.1.1.5417	drycooler1 analog out	read-only								x	x	
1.3.2.1.3.1.1.1.5418	drycooler1 pre running speed	read-only								x		
1.3.2.1.3.1.1.1.5419	drycooler1 control cycle	read-write								x	x	
1.3.2.1.3.1.1.1.5420	drycooler1 max adjust	read-write								x	x	
1.3.2.1.3.1.1.1.5421	drycooler1 control factor / P factor	read-write								x	x	
1.3.2.1.3.1.1.1.5423	drycooler1 water setpoint primary in FC-mode	read-only								x	x	
1.3.2.1.3.1.1.1.5424	drycooler1 I factor	read-only								x	x	
1.3.2.1.3.1.1.1.5425	drycooler1 D factor	read-only								x	x	
1.3.2.1.3.1.1.1.5426	drycooler1 max speed in DX-mode	read-only								x	x	
1.3.2.1.3.1.1.1.5427	drycooler1 minimum speed	read-only								x	x	
1.3.2.1.3.2.1.1.5500	drycooler2 config active	read-only								x		
1.3.2.1.3.2.1.1.5505	drycooler2 common alarm config	read-only								x		
1.3.2.1.3.2.1.1.5511	drycooler2 digital out	read-only								x		
1.3.2.1.3.2.1.1.5512	drycooler2 alarm digital in	read-only								x		
1.3.2.1.3.2.1.1.5513	drycooler2 alarm priorities	read-only								x		
1.3.2.1.3.3.1.1.5600	drycooler3 config active	read-only								x		
1.3.2.1.3.3.1.1.5605	drycooler3 common alarm config	read-only								x		
1.3.2.1.3.3.1.1.5611	drycooler3 digital out	read-only								x		
1.3.2.1.3.3.1.1.5612	drycooler3 alarm digital in	read-only								x		
1.3.2.1.3.3.1.1.5613	drycooler3 alarm priorities	read-only								x		
1.3.2.1.3.4.1.1.5700	drycooler4 config active	read-only								x		
1.3.2.1.3.4.1.1.5705	drycooler4 common alarm config	read-only								x		
1.3.2.1.3.4.1.1.5711	drycooler4 digital out	read-only								x		
1.3.2.1.3.4.1.1.5712	drycooler4 alarm digital in	read-only								x		
1.3.2.1.3.4.1.1.5713	drycooler4 alarm priorities	read-only								x		
1.3.2.1.4.1.1.1.5800	pump1 config active	read-only								x	x	
1.3.2.1.4.1.1.1.5804	pump1 common alarm config	read-only								x	x	
1.3.2.1.4.1.1.1.5808	pump1 type	read-only								x		
1.3.2.1.4.1.1.1.5813	pump1 digital out	read-only								x	x	
1.3.2.1.4.1.1.1.5814	pump1 analog out	read-only								x		
1.3.2.1.4.1.1.1.5815	pump1 alarm digital in	read-only								x	x	
1.3.2.1.4.1.1.1.5816	pump1 alarm priorities	read-only								x	x	
1.3.2.1.4.1.1.1.5818	pump1 pre runtime	read-only								x	x	
1.3.2.1.4.1.1.1.5819	pump1 pre speed	read-only								x		
1.3.2.1.4.1.1.1.5824	pump1 partner-pump	read-only								x	x	
1.3.2.1.4.1.1.1.5825	pump1 I factor	read-only								x		
1.3.2.1.4.1.1.1.5826	pump1 D factor	read-only								x		
1.3.2.1.4.1.1.1.5827	pump 1 control cycle	read-write								x		
1.3.2.1.4.1.1.1.5828	pump 1 max adjust	read-write								x		
1.3.2.1.4.1.1.1.5829	pump 1 control factor	read-write								x		
1.3.2.1.4.1.1.1.5831	pump 1 min speed	read-write								x		
1.3.2.1.4.1.1.1.5832	pump 1 after runtime	read-only									x	
1.3.2.1.4.2.1.1.5900	pump2 config active	read-only								x	x	
1.3.2.1.4.2.1.1.5904	pump2 common alarm config	read-only								x	x	
1.3.2.1.4.2.1.1.5908	pump2 type	read-only								x		
1.3.2.1.4.2.1.1.5913	pump2 digital out	read-only								x	x	
1.3.2.1.4.2.1.1.5914	pump2 analog out	read-only								x		
1.3.2.1.4.2.1.1.5915	pump2 alarm digital in	read-only								x	x	
1.3.2.1.4.2.1.1.5916	pump2 alarm priorities	read-only								x	x	
1.3.2.1.4.2.1.1.5918	pump2 pre runtime	read-only								x	x	
1.3.2.1.4.2.1.1.5919	pump2 pre speed	read-only								x		
1.3.2.1.4.2.1.1.5924	pump2 partner-pump	read-only								x	x	
1.3.2.1.4.2.1.1.5925	pump2 I factor	read-only								x		
1.3.2.1.4.2.1.1.5926	pump2 D factor	read-only								x		
1.3.2.1.4.2.1.1.5927	pump2 control cycle	read-write								x		
1.3.2.1.4.2.1.1.5928	pump2 max adjust	read-write								x		
1.3.2.1.4.2.1.1.5929	pump2 control factor	read-write								x		
1.3.2.1.4.2.1.1.5931	pump2 min speed	read-write								x		
1.3.2.1.4.3.1.1.6000	pump3 config active	read-only								x		
1.3.2.1.4.3.1.1.6004	pump3 common alarm config	read-only								x		
1.3.2.1.4.3.1.1.6008	pump3 type	read-only								x		
1.3.2.1.4.3.1.1.6013	pump3 digital out	read-only								x		
1.3.2.1.4.3.1.1.6014	pump3 analog out	read-only								x		
1.3.2.1.4.3.1.1.6015	pump3 alarm digital in	read-only								x		
1.3.2.1.4.3.1.1.6016	pump3 alarm priorities	read-only								x		
1.3.2.1.4.3.1.1.6018	pump3 pre runtime	read-only								x		
1.3.2.1.4.3.1.1.6019	pump3 pre speed	read-only								x		
1.3.2.1.4.3.1.1.6024	pump3 partner-pump	read-only								x		

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.2.1.4.3.1.1.6025	pump3 I factor	read-only								x		
1.3.2.1.4.3.1.1.6026	pump3 D factor	read-only								x		
1.3.2.1.4.3.1.1.6027	pump3 control cycle	read-write								x		
1.3.2.1.4.3.1.1.6028	pump3 max adjust	read-write								x		
1.3.2.1.4.3.1.1.6029	pump3 control factor	read-write								x		
1.3.2.1.4.3.1.1.6031	pump3 min speed	read-write								x		
1.3.2.1.4.4.1.1.6100	pump4 config active	read-only								x		
1.3.2.1.4.4.1.1.6104	pump4 common alarm config	read-only								x		
1.3.2.1.4.4.1.1.6108	pump4 type	read-only								x		
1.3.2.1.4.4.1.1.6113	pump4 digital out	read-only								x		
1.3.2.1.4.4.1.1.6114	pump4 analog out	read-only								x		
1.3.2.1.4.4.1.1.6115	pump4 alarm digital in	read-only								x		
1.3.2.1.4.4.1.1.6116	pump4 alarm priorities	read-only								x		
1.3.2.1.4.4.1.1.6118	pump4 pre runtime	read-only								x		
1.3.2.1.4.4.1.1.6119	pump4 pre speed	read-only								x		
1.3.2.1.4.4.1.1.6124	pump4 partner-pump	read-only								x		
1.3.2.1.4.4.1.1.6125	pump4 I factor	read-only								x		
1.3.2.1.4.4.1.1.6126	pump4 D factor	read-only								x		
1.3.2.1.4.4.1.1.6127	pump4 control cycle	read-write								x		
1.3.2.1.4.4.1.1.6128	pump4 max adjust	read-write								x		
1.3.2.1.4.4.1.1.6129	pump4 control factor	read-write								x		
1.3.2.1.4.4.1.1.6131	pump4 min speed	read-write								x		
1.3.2.1.5.1.1.1.9900	ECO-COOL louver config active	read-only								x		
1.3.2.1.5.1.1.1.9912	ECO-COOL louver analog out	read-only								x		
1.3.2.1.5.2.1.1.10400	Fresh air louver config active	read-only								x		
1.3.2.1.5.2.1.1.10410	Fresh air louver analog output	read-only								x		
1.3.2.1.5.2.1.1.10411	Fresh air louver proportional coefficient	read-write								x		
1.3.2.1.5.2.1.1.10412	Fresh air louver integral coefficient	read-write								x		
1.3.2.1.5.2.1.1.10413	Fresh air louver derivative coefficient	read-write								x		
1.3.2.1.5.2.1.1.10414	Fresh air louver maximum opening grade	read-write								x		
1.3.2.1.5.3.1.1.10500	Anti-freeze louver configuration active	read-only								x		
1.3.2.1.5.3.1.1.10510	Anti-freeze louver analog output	read-only								x		
1.3.2.1.5.3.1.1.10511	Anti-freeze louver proportional coefficient	read-write								x		
1.3.2.1.5.3.1.1.10512	Anti-freeze louver integral coefficient	read-write								x		
1.3.2.1.5.3.1.1.10513	Anti-freeze louver derivative coefficient	read-write								x		
1.3.2.1.5.3.1.1.10514	Anti-freeze louver maximum opening grade	read-write								x		
1.3.2.1.5.4.1.1.10600	Circulation louver configuration active	read-only								x		
1.3.2.1.5.4.1.1.10610	Circulation louver analog output	read-only								x		
1.3.2.1.5.4.1.1.10611	Circulation louver proportional coefficient	read-write								x		
1.3.2.1.5.4.1.1.10612	Circulation louver integral coefficient	read-write								x		
1.3.2.1.5.4.1.1.10613	Circulation louver derivative coefficient	read-write								x		
1.3.2.1.5.4.1.1.10614	Circulation louver maximum opening grade	read-write								x		
1.3.2.1.5.5.1.1.10700	Exit louver configuration active	read-only								x		
1.3.2.1.5.5.1.1.10708	Exit louver digital output	read-only								x		
1.3.2.1.6.1.1.1.10800	Cond. fan 1 configuration active	read-only								x		
1.3.2.1.6.1.1.1.10804	Cond. fan 1 common alarm configured	read-only								x		
1.3.2.1.6.1.1.1.10811	Cond. fan 1 control cycle	read-write								x		
1.3.2.1.6.1.1.1.10812	Cond. fan 1 maximum speed change	read-write								x		
1.3.2.1.6.1.1.1.10813	Cond. fan 1 minimum speed	read-write								x		
1.3.2.1.6.1.1.1.10814	Cond. fan 1 prerun time	read-write								x		
1.3.2.1.6.1.1.1.10815	Cond. fan 1 prerun speed	read-write								x		
1.3.2.1.6.1.1.1.10816	Cond. fan 1 proportional coefficient	read-write								x		
1.3.2.1.6.1.1.1.10817	Cond. fan 1 integral coefficient	read-write								x		
1.3.2.1.6.1.1.1.10818	Cond. fan 1 derivative coefficient	read-write								x		
1.3.2.1.6.1.1.1.10819	Cond. fan 1 analog output	read-only								x		
1.3.2.1.6.1.1.1.10820	Cond. fan 1 digital output	read-only								x		
1.3.2.1.6.1.1.1.10821	Cond. fan 1 digital alarm input	read-only								x		
1.3.2.1.6.1.1.1.10822	Cond. fan 1 digital alarm output	read-only								x		
1.3.2.1.6.1.1.1.10900	Cond. fan 2 configuration active	read-only								x		
1.3.2.1.6.1.1.1.10904	Cond. fan 2 common alarm configured	read-only								x		
1.3.2.1.6.1.1.1.10911	Cond. fan 2 control cycle	read-write								x		
1.3.2.1.6.1.1.1.10912	Cond. fan 2 maximum speed change	read-write								x		
1.3.2.1.6.1.1.1.10913	Cond. fan 2 minimum speed	read-write								x		
1.3.2.1.6.1.1.1.10914	Cond. fan 2 prerun time	read-write								x		
1.3.2.1.6.1.1.1.10915	Cond. fan 2 prerun speed	read-write								x		
1.3.2.1.6.1.1.1.10916	Cond. fan 2 proportional coefficient	read-write								x		
1.3.2.1.6.1.1.1.10917	Cond. fan 2 integral coefficient	read-write								x		
1.3.2.1.6.1.1.1.10918	Cond. fan 2 derivative coefficient	read-write								x		
1.3.2.1.6.1.1.1.10919	Cond. fan 2 analog output	read-only								x		
1.3.2.1.6.1.1.1.10920	Cond. fan 2 digital output	read-only								x		
1.3.2.1.6.1.1.1.10921	Cond. fan 2 digital alarm input	read-only								x		

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.2.1.6.1.1.10922	Cond. fan 2 digital alarm output	read-only								x		
1.3.2.2.1.1.1.1.4800	elec.-heating1 config active	read-only								x		
1.3.2.2.1.1.1.1.4805	elec.-heating1 common alarm config	read-only								x		
1.3.2.2.1.1.1.1.4808	elec.-heating1 type	read-only								x		
1.3.2.2.1.1.1.1.4812	elec.-heating1 digital out	read-only								x		
1.3.2.2.1.1.1.1.4813	elec.-heating1 alarm digital in	read-only								x		
1.3.2.2.1.1.1.1.4814	elec.-heating1 alarm priorities	read-only								x		
1.3.2.2.1.2.1.1.4900	elec.-heating2 config active	read-only								x		
1.3.2.2.1.2.1.1.4905	elec.-heating2 common alarm config	read-only								x		
1.3.2.2.1.2.1.1.4908	elec.-heating2 type	read-only								x		
1.3.2.2.1.2.1.1.4912	elec.-heating2 digital out	read-only								x		
1.3.2.2.1.2.1.1.4913	elec.-heating2 alarm digital in	read-only								x		
1.3.2.2.1.2.1.1.4914	elec.-heating2 alarm priorities	read-only								x		
1.3.2.2.1.3.1.1.5000	elec.-heating3 config active	read-only								x		
1.3.2.2.1.3.1.1.5005	elec.-heating3 common alarm config	read-only								x		
1.3.2.2.1.3.1.1.5008	elec.-heating3 type	read-only								x		
1.3.2.2.1.3.1.1.5012	elec.-heating3 digital out	read-only								x		
1.3.2.2.1.3.1.1.5013	elec.-heating3 alarm digital in	read-only								x		
1.3.2.2.1.3.1.1.5014	elec.-heating3 alarm priorities	read-only								x		
1.3.2.2.2.1.1.6200	hotgas-heating config active	read-only								x		
1.3.2.2.2.1.1.6205	hotgas-heating common alarm config	read-only								x		
1.3.2.2.2.1.1.6210	hotgas-heating digital out	read-only								x		
1.3.2.2.2.1.1.6211	hotgas-heating alarm digital in	read-only								x		
1.3.2.2.2.1.1.6212	hotgas-heating alarm priorities	read-only								x		
1.3.2.2.3.1.1.6300	PWW-heating config active	read-only								x		
1.3.2.2.3.1.1.6308	PWW-heating type	read-only								x		
1.3.2.2.3.1.1.6313	PWW-heating digital out	read-only								x		
1.3.2.2.3.1.1.6314	PWW-heating analog out	read-only								x		
1.3.2.3.1.1.1.6400	humidifier1 config active	read-only								x		
1.3.2.3.1.1.1.6405	humidifier1 common alarm config	read-only								x		
1.3.2.3.1.1.1.6406	humidifier1 conductivity config	read-only								x		
1.3.2.3.1.1.1.6407	humidifier1 5uS common alarm config	read-only								x		
1.3.2.3.1.1.1.6408	humidifier1 20uS common alarm config	read-only								x		
1.3.2.3.1.1.1.6416	humidifier1 type	read-only								x		
1.3.2.3.1.1.1.6421	humidifier1 digital out	read-only								x		
1.3.2.3.1.1.1.6422	humidifier1 analog out	read-only								x		
1.3.2.3.1.1.1.6423	humidifier1 alarm digital in	read-only								x		
1.3.2.3.1.1.1.6424	humidifier1 alarm priorities	read-only								x		
1.3.2.3.1.1.1.6429	humidifier1 alarm digital in 5uS	read-only								x		
1.3.2.3.1.1.1.6430	humidifier1 alarm digital in 20uS	read-only								x		
1.3.2.3.1.1.1.6433	humidifier1 alarm priorities 5uS	read-only								x		
1.3.2.3.1.1.1.6434	humidifier1 alarm priorities 20uS	read-only								x		
1.3.2.3.2.1.1.6800	dehumidification valve config active	read-only								x		
1.3.2.3.2.1.1.6805	dehumidification hotgas bypass config active	read-only								x		
1.3.2.3.2.1.1.6813	dehumidification digital out	read-only								x		
1.3.2.3.2.1.1.6821	dehumidification stop on room temp	read-only								x		
1.3.2.3.2.1.1.6822	min fan speed when precision dehumidification	read-only								x		
1.3.2.4.2.1.1.6900	fan1 config active	read-only							x	x		
1.3.2.4.2.1.1.6908	fan1 type	read-only								x		
1.3.2.4.2.1.1.6919	fan1 offset	read-only								x		
1.3.2.4.2.1.1.6923	fan1 digital out	read-only								x		
1.3.2.4.2.1.1.6924	fan1 analog out	read-only								x		
1.3.2.4.2.1.1.6934	fan1 min speed DX mode	read-write								x		
1.3.2.4.2.1.1.6935	fan1 control cycle	read-write								x		
1.3.2.4.2.1.1.6936	fan1 max adjust	read-write								x		
1.3.2.4.2.1.1.6937	fan1 control factor	read-write								x		
1.3.2.4.2.1.1.7000	fan2 config active	read-only							x	x		
1.3.2.4.3.1.1.6906	fan1 common alarm config	read-only								x		
1.3.2.4.3.1.1.6907	fan1 filter common alarm config	read-only								x		
1.3.2.4.3.1.1.6925	fan1 alarm digital in	read-only								x		
1.3.2.4.3.1.1.6926	fan1 alarm priorities	read-only								x		
1.3.2.4.3.1.1.6928	fan1 filter alarm digital in	read-only								x		
1.3.2.4.3.1.1.6929	fan1 filter alarm priorities	read-only								x		
1.3.2.4.4.1.1.6911	fan1 pre runtime	read-only								x		
1.3.2.4.4.1.1.6912	fan1 run after time	read-only								x		
1.3.2.4.4.1.1.6916	fan1 start 100% time	read-only								x		
1.3.2.4.4.1.1.6917	fan1 reduce time	read-only								x		
1.3.2.4.4.1.1.6918	fan1 reduce speed	read-only								x		
1.3.2.4.4.1.1.6920	fan1 dehumidification speed	read-only								x		
1.3.2.4.4.1.1.6921	fan1 ups speed	read-only								x		
1.3.2.4.4.1.1.6922	fan1 offset filter clogged	read-only								x		

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.2.4.4.1.1.6938	fan emergency starttemp.	read-write								x		
1.3.2.4.4.1.1.6939	fan emergency endtemp.	read-write								x		
1.3.2.4.4.1.1.6940	fan emergency speed	read-write								x		
1.3.2.4.4.1.1.6941	fan dehum time (delay)	read-only								x		
1.3.2.4.4.1.1.6942	fan1 min speed CW mode	read-write								x		
1.3.2.4.4.1.1.6943	fan 1 starttemp (freecooling, outdoor-temperature)	read-only							x	x		
1.3.2.4.4.1.1.7042	fan2 min speed CW mode	read-write								x		
1.3.2.4.4.1.1.7043	fan 2 starttemp (freecooling, outdoor-temperature)	read-only							x	x		
1.3.2.4.4.1.1.7142	fan3 min speed CW mode	read-write								x		
1.3.2.4.5.1.1.7200	louver1 config active	read-only								x		
1.3.2.4.5.1.1.7209	louver1 digital out	read-only								x		
1.3.2.4.6.1.1.11000	Filter 1 configuration active	read-only								x		
1.3.2.4.6.1.1.11002	Filter 1 common alarm configured	read-only								x		
1.3.2.4.6.1.1.11003	Filter 1 action on alarm	read-write								x		
1.3.2.4.6.1.1.11008	Filter 1 purpose	read-only								x		
1.3.2.4.6.1.1.11011	Filter 1 digital alarm output	read-only								x		
1.3.2.4.6.1.1.11100	Filter 2 configuration active	read-only								x		
1.3.2.4.6.1.1.11102	Filter 2 common alarm configured	read-only								x		
1.3.2.4.6.1.1.11103	Filter 2 action on alarm	read-write								x		
1.3.2.4.6.1.1.11108	Filter 2 purpose	read-only								x		
1.3.2.4.6.1.1.11111	Filter 2 digital alarm output	read-only								x		
1.3.2.4.6.1.1.11112	Filter 2 alarm delay	read-write								x		
1.3.2.4.6.1.1.11200	Filter 3 configuration active	read-only								x		
1.3.2.4.6.1.1.11202	Filter 3 common alarm configured	read-only								x		
1.3.2.4.6.1.1.11203	Filter 3 action on alarm	read-write								x		
1.3.2.4.6.1.1.11208	Filter 3 purpose	read-only								x		
1.3.2.4.6.1.1.11211	Filter 3 digital alarm output	read-only								x		
1.3.2.4.6.1.1.11212	Filter 3 alarm delay	read-write								x		
1.3.2.5.1.1.1.2300	sensor1 config. active	read-only							x	x		
1.3.2.5.1.1.1.2303	sensor1 defect common alarm config	read-only								x		
1.3.2.5.1.1.1.2304	sensor1 limit common alarm config	read-only								x		
1.3.2.5.1.1.1.2308	sensor1 purpose/use	read-only								x	x	
1.3.2.5.1.1.1.2309	sensor1 type	read-only								x	x	
1.3.2.5.1.1.1.2310	sensor1 analog input	read-only								x	x	
1.3.2.5.1.1.1.2311	sensor1 min value	read-only								x	x	
1.3.2.5.1.1.1.2312	sensor1 max value	read-only								x	x	
1.3.2.5.1.1.1.2313	sensor1 min phys. value	read-only								x	x	
1.3.2.5.1.1.1.2314	sensor1 max phys. value	read-only								x	x	
1.3.2.5.1.1.1.2315	sensor1 tolerance	read-only								x	x	
1.3.2.5.1.1.1.2316	sensor1 alarm priorities	read-only								x	x	
1.3.2.5.1.1.1.2318	sensor1 failure alarm priorities	read-only								x	x	
1.3.2.5.2.1.1.2400	sensor2 config. active	read-only							x	x	x	
1.3.2.5.2.1.1.2403	sensor2 defect common alarm config	read-only								x	x	
1.3.2.5.2.1.1.2404	sensor2 limit common alarm config	read-only								x	x	
1.3.2.5.2.1.1.2408	sensor2 purpose	read-only								x	x	
1.3.2.5.2.1.1.2409	sensor2 type	read-only								x	x	
1.3.2.5.2.1.1.2410	sensor2 analog input	read-only								x	x	
1.3.2.5.2.1.1.2411	sensor2 min value	read-only								x	x	
1.3.2.5.2.1.1.2412	sensor2 max value	read-only								x	x	
1.3.2.5.2.1.1.2413	sensor2 min phys. value	read-only								x	x	
1.3.2.5.2.1.1.2414	sensor2 max phys. value	read-only								x	x	
1.3.2.5.2.1.1.2415	sensor2 tolerance	read-only								x	x	
1.3.2.5.2.1.1.2416	sensor2 alarm priorities	read-only								x	x	
1.3.2.5.2.1.1.2418	sensor2 failure alarm priorities	read-only								x	x	
1.3.2.5.3.1.1.2500	sensor3 config. active	read-only							x	x	x	
1.3.2.5.3.1.1.2503	sensor3 defect common alarm config	read-only								x	x	
1.3.2.5.3.1.1.2504	sensor3 limit common alarm config	read-only								x	x	
1.3.2.5.3.1.1.2508	sensor3 purpose	read-only								x	x	
1.3.2.5.3.1.1.2509	sensor3 type	read-only								x	x	
1.3.2.5.3.1.1.2510	sensor3 analog input	read-only								x	x	
1.3.2.5.3.1.1.2511	sensor3 min value	read-only								x	x	
1.3.2.5.3.1.1.2512	sensor3 max value	read-only								x	x	
1.3.2.5.3.1.1.2513	sensor3 min phys. value	read-only								x	x	
1.3.2.5.3.1.1.2514	sensor3 max phys. value	read-only								x	x	
1.3.2.5.3.1.1.2515	sensor3 tolerance	read-only								x	x	
1.3.2.5.3.1.1.2516	sensor3 alarm priorities	read-only								x	x	
1.3.2.5.3.1.1.2518	sensor3 failure alarm priorities	read-only								x	x	
1.3.2.5.4.1.1.2600	sensor4 config. active	read-only							x	x	x	
1.3.2.5.4.1.1.2603	sensor4 defect common alarm config	read-only								x	x	
1.3.2.5.4.1.1.2604	sensor4 limit common alarm config	read-only								x	x	
1.3.2.5.4.1.1.2608	sensor4 purpose	read-only								x	x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number			Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
OID middle part													
1.3.2.5.4.1.1.2609	sensor4 type	read-only										x	x
1.3.2.5.4.1.1.2610	sensor4 analog input	read-only										x	x
1.3.2.5.4.1.1.2611	sensor4 min value	read-only										x	x
1.3.2.5.4.1.1.2612	sensor4 max value	read-only										x	x
1.3.2.5.4.1.1.2613	sensor4 min phys. value	read-only										x	x
1.3.2.5.4.1.1.2614	sensor4 max phys. value	read-only										x	x
1.3.2.5.4.1.1.2615	sensor4 tolerance	read-only										x	x
1.3.2.5.4.1.1.2616	sensor4 alarm priorities	read-only										x	x
1.3.2.5.4.1.1.2618	sensor4 failure alarm priorities	read-only										x	x
1.3.2.5.5.1.1.2700	sensor5 config. active	read-only								x		x	x
1.3.2.5.5.1.1.2703	sensor5 defect common alarm config	read-only										x	x
1.3.2.5.5.1.1.2704	sensor5 limit common alarm config	read-only										x	x
1.3.2.5.5.1.1.2708	sensor5 purpose	read-only										x	x
1.3.2.5.5.1.1.2709	sensor5 type	read-only										x	x
1.3.2.5.5.1.1.2710	sensor5 analog input	read-only										x	x
1.3.2.5.5.1.1.2711	sensor5 min value	read-only										x	x
1.3.2.5.5.1.1.2712	sensor5 max value	read-only										x	x
1.3.2.5.5.1.1.2713	sensor5 min phys. value	read-only										x	x
1.3.2.5.5.1.1.2714	sensor5 max phys. value	read-only										x	x
1.3.2.5.5.1.1.2715	sensor5 tolerance	read-only										x	x
1.3.2.5.5.1.1.2716	sensor5 alarm priorities	read-only										x	x
1.3.2.5.5.1.1.2718	sensor5 failure alarm priorities	read-only										x	x
1.3.2.5.6.1.1.2800	sensor6 config. active	read-only										x	x
1.3.2.5.6.1.1.2803	sensor6 defect common alarm config	read-only										x	x
1.3.2.5.6.1.1.2804	sensor6 limit common alarm config	read-only										x	x
1.3.2.5.6.1.1.2808	sensor6 purpose	read-only										x	x
1.3.2.5.6.1.1.2809	sensor6 type	read-only										x	x
1.3.2.5.6.1.1.2810	sensor6 analog input	read-only										x	x
1.3.2.5.6.1.1.2811	sensor6 min value	read-only										x	x
1.3.2.5.6.1.1.2812	sensor6 max value	read-only										x	x
1.3.2.5.6.1.1.2813	sensor6 min phys. value	read-only										x	x
1.3.2.5.6.1.1.2814	sensor6 max phys. value	read-only										x	x
1.3.2.5.6.1.1.2815	sensor6 tolerance	read-only										x	x
1.3.2.5.6.1.1.2816	sensor6 alarm priorities	read-only										x	x
1.3.2.5.6.1.1.2818	sensor6 failure alarm priorities	read-only										x	x
1.3.2.5.7.1.1.2900	sensor7 config. active	read-only										x	x
1.3.2.5.7.1.1.2903	sensor7 defect common alarm config	read-only										x	x
1.3.2.5.7.1.1.2904	sensor7 limit common alarm config	read-only										x	x
1.3.2.5.7.1.1.2908	sensor7 purpose	read-only										x	x
1.3.2.5.7.1.1.2909	sensor7 type	read-only										x	x
1.3.2.5.7.1.1.2910	sensor7 analog input	read-only										x	x
1.3.2.5.7.1.1.2911	sensor7 min value	read-only										x	x
1.3.2.5.7.1.1.2912	sensor7 max value	read-only										x	x
1.3.2.5.7.1.1.2913	sensor7 min phys. value	read-only										x	x
1.3.2.5.7.1.1.2914	sensor7 max phys. value	read-only										x	x
1.3.2.5.7.1.1.2915	sensor7 tolerance	read-only										x	x
1.3.2.5.7.1.1.2916	sensor7 alarm priorities	read-only										x	x
1.3.2.5.7.1.1.2918	sensor7 failure alarm priorities	read-only										x	x
1.3.2.5.8.1.1.3000	sensor8 config. active	read-only										x	x
1.3.2.5.8.1.1.3003	sensor8 defect common alarm config	read-only										x	x
1.3.2.5.8.1.1.3004	sensor8 limit common alarm config	read-only										x	x
1.3.2.5.8.1.1.3008	sensor8 purpose	read-only										x	x
1.3.2.5.8.1.1.3009	sensor8 type	read-only										x	x
1.3.2.5.8.1.1.3010	sensor8 analog input	read-only										x	x
1.3.2.5.8.1.1.3011	sensor8 min value	read-only										x	x
1.3.2.5.8.1.1.3012	sensor8 max value	read-only										x	x
1.3.2.5.8.1.1.3013	sensor8 min phys. value	read-only										x	x
1.3.2.5.8.1.1.3014	sensor8 max phys. value	read-only										x	x
1.3.2.5.8.1.1.3015	sensor8 tolerance	read-only										x	x
1.3.2.5.8.1.1.3016	sensor8 alarm priorities	read-only										x	x
1.3.2.5.8.1.1.3018	sensor8 failure alarm priorities	read-only										x	x
1.3.2.5.9.1.1.3100	sensor9 config. active	read-only										x	x
1.3.2.5.9.1.1.3103	sensor9 defect common alarm config	read-only										x	x
1.3.2.5.9.1.1.3104	sensor9 limit common alarm config	read-only										x	x
1.3.2.5.9.1.1.3108	sensor9 purpose	read-only										x	x
1.3.2.5.9.1.1.3109	sensor9 type	read-only										x	x
1.3.2.5.9.1.1.3110	sensor9 analog input	read-only										x	x
1.3.2.5.9.1.1.3111	sensor9 min value	read-only										x	x
1.3.2.5.9.1.1.3112	sensor9 max value	read-only										x	x
1.3.2.5.9.1.1.3113	sensor9 min phys. value	read-only										x	x
1.3.2.5.9.1.1.3114	sensor9 max phys. value	read-only										x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.3.2.5.9.1.1.3115	sensor9 tolerance	read-only							x	x	
1.3.2.5.9.1.1.3116	sensor9 alarm priorities	read-only							x	x	
1.3.2.5.9.1.1.3118	sensor9 failure alarm priorities	read-only							x	x	
1.3.2.5.10.1.1.3200	sensor10 config. active	read-only							x	x	
1.3.2.5.10.1.1.3203	sensor10 defect common alarm config	read-only							x	x	
1.3.2.5.10.1.1.3204	sensor10 limit common alarm config	read-only							x	x	
1.3.2.5.10.1.1.3208	sensor10 purpose	read-only							x	x	
1.3.2.5.10.1.1.3209	sensor10 type	read-only							x	x	
1.3.2.5.10.1.1.3210	sensor10 analog input	read-only							x	x	
1.3.2.5.10.1.1.3211	sensor10 min value	read-only							x	x	
1.3.2.5.10.1.1.3212	sensor10 max value	read-only							x	x	
1.3.2.5.10.1.1.3213	sensor10 min phys. value	read-only							x	x	
1.3.2.5.10.1.1.3214	sensor10 max phys. value	read-only							x	x	
1.3.2.5.10.1.1.3215	sensor10 tolerance	read-only							x	x	
1.3.2.5.10.1.1.3216	sensor10 alarm priorities	read-only							x	x	
1.3.2.5.10.1.1.3218	sensor10 failure alarm priorities	read-only							x	x	
1.3.2.5.11.1.1.3300	sensor11 config. active	read-only							x	x	
1.3.2.5.11.1.1.3303	sensor11 defect common alarm config	read-only							x	x	
1.3.2.5.11.1.1.3304	sensor11 limit common alarm config	read-only							x	x	
1.3.2.5.11.1.1.3308	sensor11 purpose	read-only							x	x	
1.3.2.5.11.1.1.3309	sensor11 type	read-only							x	x	
1.3.2.5.11.1.1.3310	sensor11 analog input	read-only							x	x	
1.3.2.5.11.1.1.3311	sensor11 min value	read-only							x	x	
1.3.2.5.11.1.1.3312	sensor11 max value	read-only							x	x	
1.3.2.5.11.1.1.3313	sensor11 min phys. value	read-only							x	x	
1.3.2.5.11.1.1.3314	sensor11 max phys. value	read-only							x	x	
1.3.2.5.11.1.1.3315	sensor11 tolerance	read-only							x	x	
1.3.2.5.11.1.1.3316	sensor11 alarm priorities	read-only							x	x	
1.3.2.5.11.1.1.3318	sensor11 failure alarm priorities	read-only							x	x	
1.3.2.5.12.1.1.3400	sensor12 config. active	read-only							x	x	
1.3.2.5.12.1.1.3403	sensor12 defect common alarm config	read-only							x	x	
1.3.2.5.12.1.1.3404	sensor12 limit common alarm config	read-only							x	x	
1.3.2.5.12.1.1.3408	sensor12 purpose	read-only							x	x	
1.3.2.5.12.1.1.3409	sensor12 type	read-only							x	x	
1.3.2.5.12.1.1.3410	sensor12 analog input	read-only							x	x	
1.3.2.5.12.1.1.3411	sensor12 min value	read-only							x	x	
1.3.2.5.12.1.1.3412	sensor12 max value	read-only							x	x	
1.3.2.5.12.1.1.3413	sensor12 min phys. value	read-only							x	x	
1.3.2.5.12.1.1.3414	sensor12 max phys. value	read-only							x	x	
1.3.2.5.12.1.1.3415	sensor12 tolerance	read-only							x	x	
1.3.2.5.12.1.1.3416	sensor12 alarm priorities	read-only							x	x	
1.3.2.5.12.1.1.3418	sensor12 failure alarm priorities	read-only							x	x	
1.3.2.5.13.1.1.3500	sensor13 config. active	read-only							x	x	
1.3.2.5.13.1.1.3503	sensor13 defect common alarm config	read-only							x	x	
1.3.2.5.13.1.1.3504	sensor13 limit common alarm config	read-only							x	x	
1.3.2.5.13.1.1.3508	sensor13 purpose	read-only							x	x	
1.3.2.5.13.1.1.3509	sensor13 type	read-only							x	x	
1.3.2.5.13.1.1.3510	sensor13 analog input	read-only							x	x	
1.3.2.5.13.1.1.3511	sensor13 min value	read-only							x	x	
1.3.2.5.13.1.1.3512	sensor13 max value	read-only							x	x	
1.3.2.5.13.1.1.3513	sensor13 min phys. value	read-only							x	x	
1.3.2.5.13.1.1.3514	sensor13 max phys. value	read-only							x	x	
1.3.2.5.13.1.1.3515	sensor13 tolerance	read-only							x	x	
1.3.2.5.13.1.1.3516	sensor13 alarm priorities	read-only							x	x	
1.3.2.5.13.1.1.3518	sensor13 failure alarm priorities	read-only							x	x	
1.3.2.5.14.1.1.3600	sensor14 config. active	read-only							x	x	
1.3.2.5.14.1.1.3603	sensor14 defect common alarm config	read-only							x	x	
1.3.2.5.14.1.1.3604	sensor14 limit common alarm config	read-only							x	x	
1.3.2.5.14.1.1.3608	sensor14 purpose	read-only							x	x	
1.3.2.5.14.1.1.3609	sensor14 type	read-only							x	x	
1.3.2.5.14.1.1.3610	sensor14 analog input	read-only							x	x	
1.3.2.5.14.1.1.3611	sensor14 min value	read-only							x	x	
1.3.2.5.14.1.1.3612	sensor14 max value	read-only							x	x	
1.3.2.5.14.1.1.3613	sensor14 min phys. value	read-only							x	x	
1.3.2.5.14.1.1.3614	sensor14 max phys. value	read-only							x	x	
1.3.2.5.14.1.1.3615	sensor14 tolerance	read-only							x	x	
1.3.2.5.14.1.1.3616	sensor14 alarm priorities	read-only							x	x	
1.3.2.5.14.1.1.3618	sensor14 failure alarm priorities	read-only							x	x	
1.3.2.5.15.1.1.3700	sensor15 config. active	read-only							x	x	
1.3.2.5.15.1.1.3703	sensor15 defect common alarm config	read-only							x	x	
1.3.2.5.15.1.1.3704	sensor15 limit common alarm config	read-only							x	x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.2.5.15.1.1.3708	sensor15 purpose	read-only								x	x	
1.3.2.5.15.1.1.3709	sensor15 type	read-only								x	x	
1.3.2.5.15.1.1.3710	sensor15 analog input	read-only								x	x	
1.3.2.5.15.1.1.3711	sensor15 min value	read-only								x	x	
1.3.2.5.15.1.1.3712	sensor15 max value	read-only								x	x	
1.3.2.5.15.1.1.3713	sensor15 min phys. value	read-only								x	x	
1.3.2.5.15.1.1.3714	sensor15 max phys. value	read-only								x	x	
1.3.2.5.15.1.1.3715	sensor15 tolerance	read-only								x	x	
1.3.2.5.15.1.1.3716	sensor15 alarm priorities	read-only								x	x	
1.3.2.5.15.1.1.3718	sensor15 failure alarm priorities	read-only								x	x	
1.3.2.5.16.1.1.3800	sensor16 config. active	read-only								x	x	
1.3.2.5.16.1.1.3803	sensor16 defect common alarm config	read-only								x	x	
1.3.2.5.16.1.1.3804	sensor16 limit common alarm config	read-only								x	x	
1.3.2.5.16.1.1.3808	sensor16 purpose	read-only								x	x	
1.3.2.5.16.1.1.3809	sensor16 type	read-only								x	x	
1.3.2.5.16.1.1.3810	sensor16 analog input	read-only								x	x	
1.3.2.5.16.1.1.3811	sensor16 min value	read-only								x	x	
1.3.2.5.16.1.1.3812	sensor16 max value	read-only								x	x	
1.3.2.5.16.1.1.3813	sensor16 min phys. value	read-only								x	x	
1.3.2.5.16.1.1.3814	sensor16 max phys. value	read-only								x	x	
1.3.2.5.16.1.1.3815	sensor16 tolerance	read-only								x	x	
1.3.2.5.16.1.1.3816	sensor16 alarm priorities	read-only								x	x	
1.3.2.5.16.1.1.3818	sensor16 failure alarm priorities	read-only								x	x	
1.3.2.5.17.1.1.3900	sensor17 config. active	read-only								x	x	
1.3.2.5.17.1.1.3903	sensor17 defect common alarm config	read-only								x	x	
1.3.2.5.17.1.1.3904	sensor17 limit common alarm config	read-only								x	x	
1.3.2.5.17.1.1.3908	sensor17 purpose	read-only								x	x	
1.3.2.5.17.1.1.3909	sensor17 type	read-only								x	x	
1.3.2.5.17.1.1.3910	sensor17 analog input	read-only								x	x	
1.3.2.5.17.1.1.3911	sensor17 min value	read-only								x	x	
1.3.2.5.17.1.1.3912	sensor17 max value	read-only								x	x	
1.3.2.5.17.1.1.3913	sensor17 min phys. value	read-only								x	x	
1.3.2.5.17.1.1.3914	sensor17 max phys. value	read-only								x	x	
1.3.2.5.17.1.1.3915	sensor17 tolerance	read-only								x	x	
1.3.2.5.17.1.1.3916	sensor17 alarm priorities	read-only								x	x	
1.3.2.5.17.1.1.3918	sensor17 failure alarm priorities	read-only								x	x	
1.3.2.5.18.1.1.4000	sensor18 config. active	read-only								x	x	
1.3.2.5.18.1.1.4003	sensor18 defect common alarm config	read-only								x	x	
1.3.2.5.18.1.1.4004	sensor18 limit common alarm config	read-only								x	x	
1.3.2.5.18.1.1.4008	sensor18 purpose	read-only								x	x	
1.3.2.5.18.1.1.4009	sensor18 type	read-only								x	x	
1.3.2.5.18.1.1.4010	sensor18 analog input	read-only								x	x	
1.3.2.5.18.1.1.4011	sensor18 min value	read-only								x	x	
1.3.2.5.18.1.1.4012	sensor18 max value	read-only								x	x	
1.3.2.5.18.1.1.4013	sensor18 min phys. value	read-only								x	x	
1.3.2.5.18.1.1.4014	sensor18 max phys. value	read-only								x	x	
1.3.2.5.18.1.1.4015	sensor18 tolerance	read-only								x	x	
1.3.2.5.18.1.1.4016	sensor18 alarm priorities	read-only								x	x	
1.3.2.5.18.1.1.4018	sensor18 failure alarm priorities	read-only								x	x	
1.3.2.5.19.1.1.4100	sensor19 config. active	read-only								x	x	
1.3.2.5.19.1.1.4103	sensor19 defect common alarm config	read-only								x	x	
1.3.2.5.19.1.1.4104	sensor19 limit common alarm config	read-only								x	x	
1.3.2.5.19.1.1.4108	sensor19 purpose	read-only								x	x	
1.3.2.5.19.1.1.4109	sensor19 type	read-only								x	x	
1.3.2.5.19.1.1.4110	sensor19 analog input	read-only								x	x	
1.3.2.5.19.1.1.4111	sensor19 min value	read-only								x	x	
1.3.2.5.19.1.1.4112	sensor19 max value	read-only								x	x	
1.3.2.5.19.1.1.4113	sensor19 min phys. value	read-only								x	x	
1.3.2.5.19.1.1.4114	sensor19 max phys. value	read-only								x	x	
1.3.2.5.19.1.1.4115	sensor19 tolerance	read-only								x	x	
1.3.2.5.19.1.1.4116	sensor19 alarm priorities	read-only								x	x	
1.3.2.5.19.1.1.4118	sensor19 failure alarm priorities	read-only								x	x	
1.3.2.5.20.1.1.4200	sensor20 config. active	read-only								x	x	
1.3.2.5.20.1.1.4203	sensor20 defect common alarm config	read-only								x	x	
1.3.2.5.20.1.1.4204	sensor20 limit common alarm config	read-only								x	x	
1.3.2.5.20.1.1.4208	sensor20 purpose	read-only								x	x	
1.3.2.5.20.1.1.4209	sensor20 type	read-only								x	x	
1.3.2.5.20.1.1.4210	sensor20 analog input	read-only								x	x	
1.3.2.5.20.1.1.4211	sensor20 min value	read-only								x	x	
1.3.2.5.20.1.1.4212	sensor20 max value	read-only								x	x	
1.3.2.5.20.1.1.4213	sensor20 min phys. value	read-only								x	x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.2.5.20.1.1.4214	sensor20 max phys. value	read-only								x	x	
1.3.2.5.20.1.1.4215	sensor20 tolerance	read-only								x	x	
1.3.2.5.20.1.1.4216	sensor20 alarm priorities	read-only								x	x	
1.3.2.5.20.1.1.4218	sensor20 failure alarm priorities	read-only								x	x	
1.3.2.5.21.1.1.4300	sensor21 config. active	read-only								x	x	
1.3.2.5.21.1.1.4303	sensor21 defect common alarm config	read-only								x	x	
1.3.2.5.21.1.1.4304	sensor21 limit common alarm config	read-only								x	x	
1.3.2.5.21.1.1.4308	sensor21 purpose	read-only								x	x	
1.3.2.5.21.1.1.4309	sensor21 type	read-only								x	x	
1.3.2.5.21.1.1.4310	sensor21 analog input	read-only								x	x	
1.3.2.5.21.1.1.4311	sensor21 min value	read-only								x	x	
1.3.2.5.21.1.1.4312	sensor21 max value	read-only								x	x	
1.3.2.5.21.1.1.4313	sensor21 min phys. value	read-only								x	x	
1.3.2.5.21.1.1.4314	sensor21 max phys. value	read-only								x	x	
1.3.2.5.21.1.1.4315	sensor21 tolerance	read-only								x	x	
1.3.2.5.21.1.1.4316	sensor21 alarm priorities	read-only								x	x	
1.3.2.5.21.1.1.4318	sensor21 failure alarm priorities	read-only								x	x	
1.3.2.6.1.1.1.1.7500	ext. alarm config active 1	read-only								x	x	
1.3.2.6.1.1.1.1.7504	ext. Alarm 1 common alarm config	read-only								x	x	
1.3.2.6.1.1.1.1.7508	ext. alarm1 digital in	read-only								x	x	
1.3.2.6.1.1.1.1.7509	ext. alarm1 priorities	read-only								x	x	
1.3.2.6.1.2.1.1.7600	ext. alarm config active 2	read-only								x	x	
1.3.2.6.1.2.1.1.7604	ext. alarm 2 common alarm config	read-only								x	x	
1.3.2.6.1.2.1.1.7608	ext. alarm2 digital in	read-only								x	x	
1.3.2.6.1.2.1.1.7609	ext. alarm2 priorities	read-only								x	x	
1.3.2.6.1.3.1.1.7700	ext. alarm config active 3	read-only								x	x	
1.3.2.6.1.3.1.1.7704	ext. alarm 3 common alarm config	read-only								x	x	
1.3.2.6.1.3.1.1.7708	ext. alarm3 digital in	read-only								x	x	
1.3.2.6.1.3.1.1.7709	ext. alarm3 priorities	read-only								x	x	
1.3.2.6.1.4.1.1.7800	ext. alarm config active 4	read-only								x	x	
1.3.2.6.1.4.1.1.7804	ext. alarm 4 common alarm config	read-only								x	x	
1.3.2.6.1.4.1.1.7808	ext. alarm4 digital in	read-only								x	x	
1.3.2.6.1.4.1.1.7809	ext. alarm4 priorities	read-only								x	x	
1.3.2.6.1.5.1.1.7900	ext. alarm config active 5	read-only								x	x	
1.3.2.6.1.5.1.1.7904	ext. alarm 5 common alarm config	read-only								x	x	
1.3.2.6.1.5.1.1.7908	ext. alarm5 digital in	read-only								x	x	
1.3.2.6.1.5.1.1.7909	ext. alarm5 priorities	read-only								x	x	
1.3.2.6.1.6.1.1.8000	ext. alarm config active 6	read-only								x	x	
1.3.2.6.1.6.1.1.8004	ext. alarm 6 common alarm config	read-only								x	x	
1.3.2.6.1.6.1.1.8008	ext. alarm6 digital in	read-only								x	x	
1.3.2.6.1.6.1.1.8009	ext. alarm6 priorities	read-only								x	x	
1.3.2.6.1.7.1.1.8100	ext. alarm config active 7	read-only								x	x	
1.3.2.6.1.7.1.1.8104	ext. alarm 7 common alarm config	read-only								x	x	
1.3.2.6.1.7.1.1.8108	ext. alarm7 digital in	read-only								x	x	
1.3.2.6.1.7.1.1.8109	ext. alarm7 priorities	read-only								x	x	
1.3.2.6.1.8.1.1.8200	ext. alarm config active 8	read-only								x	x	
1.3.2.6.1.8.1.1.8204	ext. alarm 8 common alarm config	read-only								x	x	
1.3.2.6.1.8.1.1.8208	ext. alarm8 digital in	read-only								x	x	
1.3.2.6.1.8.1.1.8209	ext. alarm8 priorities	read-only								x	x	
1.3.2.6.1.9.1.1.8300	ext. alarm config active 9	read-only								x	x	
1.3.2.6.1.9.1.1.8304	ext. alarm 9 common alarm config	read-only								x	x	
1.3.2.6.1.9.1.1.8308	ext. alarm9 digital in	read-only								x	x	
1.3.2.6.1.9.1.1.8309	ext. alarm9 priorities	read-only								x	x	
1.3.2.6.1.10.1.1.8400	ext. alarm config active 10	read-only								x	x	
1.3.2.6.1.10.1.1.8404	ext. alarm 10 common alarm config	read-only								x	x	
1.3.2.6.1.10.1.1.8408	ext. alarm10 digital in	read-only								x	x	
1.3.2.6.1.10.1.1.8409	ext. alarm10 priorities	read-only								x	x	
1.3.2.6.2.1.1.11	busalarmcommon	read-only								x	x	
1.3.2.6.2.1.1.13	busadrfconflictcommon	read-only								x	x	
1.3.2.6.2.1.1.16	busalarmprio	read-only								x	x	
1.3.2.6.2.1.1.18	busadrfconflictprio	read-only								x	x	
1.3.2.6.2.1.1.1704	fire alarm DIN	read-only								x	x	
1.3.2.6.2.1.1.1705	water alarm DIN	read-only								x	x	
1.3.2.6.2.1.1.1706	waterflow alarm DIN	read-only								x	x	
1.3.2.6.2.1.1.1707	phase alarm DIN	read-only								x	x	
1.3.2.6.2.1.1.1711	fire alarm priorities	read-only								x	x	
1.3.2.6.2.1.1.1713	water alarm priorities	read-only								x	x	
1.3.2.6.2.1.1.1715	phase alarm priorities	read-only								x	x	
1.3.2.6.2.1.1.1719	waterflow alarm priority	read-only								x	x	
1.3.2.6.2.1.1.1742	fire alarm common alarm config	read-only								x	x	
1.3.2.6.2.1.1.1743	water alarm common alarm config	read-only								x	x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.3.2.6.2.1.1.1744	phase alarm common alarm config	read-only							x	x	
1.3.2.6.2.1.1.1747	waterflow alarm common alarm config	read-only							x	x	
1.3.2.6.2.1.1.10302	common alarm configured	read-only							x		
1.3.2.6.2.1.1.10310	force summer mode externally digital in	read-only							x		
1.3.2.6.2.1.1.10311	room high pressure alarm digital input	read-only							x		
1.3.2.6.2.1.1.10312	room high pressure alarm digital output	read-only							x		
1.3.2.6.3.1.1.1700	common alarm DOUT	read-only							x	x	
1.3.2.6.3.1.1.1701	winter mode DOUT	read-only							x	x	
1.3.2.6.3.1.1.1702	remote on/off DIN	read-only							x	x	
1.3.2.6.3.1.1.1703	ups DIN	read-only							x	x	
1.3.2.6.3.1.1.1708	CW-disable/DX-enable DIN	read-only							x	x	
1.3.2.6.3.1.1.1725	unit on/off DOUT	read-only							x	x	
1.3.2.6.4.1.1.1.8900	valout1 config. Active	read-only							x	x	
1.3.2.6.4.1.1.1.8908	valout1 purpose/use	read-only							x	x	
1.3.2.6.4.1.1.1.8910	valout1 analog output	read-only							x	x	
1.3.2.6.4.1.1.1.8911	valout1 min value	read-only							x	x	
1.3.2.6.4.1.1.1.8912	valout1 max value	read-only							x	x	
1.3.2.6.4.2.1.1.9000	valout2 config. Active	read-only							x	x	
1.3.2.6.4.2.1.1.9008	valout2 purpose/use	read-only							x	x	
1.3.2.6.4.2.1.1.9010	valout2 analog output	read-only							x	x	
1.3.2.6.4.2.1.1.9011	valout2 min value	read-only							x	x	
1.3.2.6.4.2.1.1.9012	valout2 max value	read-only							x	x	
1.3.2.6.4.3.1.1.9100	valout3 config. Active	read-only							x	x	
1.3.2.6.4.3.1.1.9108	valout3 purpose/use	read-only							x	x	
1.3.2.6.4.3.1.1.9110	valout3 analog output	read-only							x	x	
1.3.2.6.4.3.1.1.9111	valout3 min value	read-only							x	x	
1.3.2.6.4.3.1.1.9112	valout3 max value	read-only							x	x	
1.3.2.6.4.4.1.1.9200	valout4 config. Active	read-only							x	x	
1.3.2.6.4.4.1.1.9208	valout4 purpose/use	read-only							x	x	
1.3.2.6.4.4.1.1.9210	valout4 analog output	read-only							x	x	
1.3.2.6.4.4.1.1.9211	valout4 min value	read-only							x	x	
1.3.2.6.4.4.1.1.9212	valout4 max value	read-only							x	x	
1.3.2.7.1.1.1750	ups action cooling	read-only							x	x	
1.3.2.7.1.1.1751	ups action heating	read-only							x	x	
1.3.2.7.1.1.1752	ups action humidification	read-only							x	x	
1.3.2.7.1.1.1753	ups action dehumidification	read-only							x	x	
1.3.2.8.1.1.1.1.4401	compr. 1 manual operation active	read-write							x	x	
1.3.2.8.1.1.1.1.4402	compr. 1 manual operation state	read-write							x	x	
1.3.2.8.1.1.1.1.4501	compr. 2 manual operation active	read-write							x	x	
1.3.2.8.1.1.1.1.4502	compr. 2 manual operation state	read-write							x	x	
1.3.2.8.1.1.1.1.9501	compr. 3 manual operation active	read-write							x		
1.3.2.8.1.1.1.1.9502	compr. 3 manual operation state	read-write							x		
1.3.2.8.1.1.1.1.9601	compr. 4 manual operation active	read-write							x		
1.3.2.8.1.1.1.1.9602	compr. 4 manual operation state	read-write							x		
1.3.2.8.1.1.1.1.9701	compr. 5 manual operation active	read-write							x		
1.3.2.8.1.1.1.1.9702	compr. 5 manual operation state	read-write							x		
1.3.2.8.1.1.1.1.9801	compr. 6 manual operation active	read-write							x		
1.3.2.8.1.1.1.1.9802	compr. 6 manual operation state	read-write							x		
1.3.2.8.1.2.1.1.1.4601	suctionvalve1 manual operation active	read-write							x		
1.3.2.8.1.2.1.1.1.4612	suctionvalve1 manual operation value	read-write							x		
1.3.2.8.1.2.2.1.1.4701	suctionvalve2 manual operation active	read-write							x		
1.3.2.8.1.2.2.1.1.4712	suctionvalve2 manual operation value	read-write							x		
1.3.2.8.1.2.3.1.1.5201	GE/CW-valve manual operation active	read-write							x		
1.3.2.8.1.2.3.1.1.5215	GE/CW-valve man. operation opening grade	read-write							x	x	
1.3.2.8.1.2.4.1.1.5301	G-valve manual operation active	read-write							x	x	
1.3.2.8.1.2.4.1.1.5313	G-valve manual operation opening grade	read-write							x	x	
1.3.2.8.1.2.5.1.1.1.9301	hgbp1 manual operation active	read-only							x	x	
1.3.2.8.1.2.5.1.1.1.9317	hgbp1 man. operation opening grade	read-only							x	x	
1.3.2.8.1.2.5.2.1.1.9401	hgbp2 manual operation active	read-only							x		
1.3.2.8.1.2.5.2.1.1.9417	hgbp2 man. operation opening grade	read-only							x		
1.3.2.8.1.2.6.1.1.1.8704	eev1 manual operation	read-only							x	x	
1.3.2.8.1.2.6.1.1.1.8725	eev1 manual operation value	read-only							x	x	
1.3.2.8.1.2.6.2.1.1.8804	eev2 manual operation	read-only							x	x	
1.3.2.8.1.2.6.2.1.1.8825	eev2 manual operation value	read-only							x	x	
1.3.2.8.1.3.1.1.1.5401	drycooler1 manual operation active	read-write							x	x	
1.3.2.8.1.3.1.1.1.5404	drycooler1 manual operation running	read-write							x		
1.3.2.8.1.3.1.1.1.5422	drycooler1 manual operation opening grade	read-write							x	x	
1.3.2.8.1.3.2.1.1.5501	drycooler2 manual operation active	read-write							x		
1.3.2.8.1.3.2.1.1.5504	drycooler2 manual operation running	read-write							x		
1.3.2.8.1.3.3.1.1.5601	drycooler3 manual operation active	read-write							x		
1.3.2.8.1.3.3.1.1.5604	drycooler3 manual operation running	read-write							x		

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.3.2.8.1.3.4.1.1.5701	drycooler4 manual operation active	read-write								x	
1.3.2.8.1.3.4.1.1.5704	drycooler4 manual operation running	read-write								x	
1.3.2.8.1.4.1.1.1.5801	pump1 manual operation active	read-write								x	x
1.3.2.8.1.4.1.1.1.5805	pump1 manual operation running	read-only								x	x
1.3.2.8.1.4.1.1.1.5822	pump1 manual operation speed	read-write								x	x
1.3.2.8.1.4.2.1.1.5901	pump2 manual operation active	read-write								x	x
1.3.2.8.1.4.2.1.1.5905	pump2 manual operation running	read-only								x	x
1.3.2.8.1.4.2.1.1.5922	pump2 manual operation speed	read-write								x	x
1.3.2.8.1.4.3.1.1.6001	pump3 manual operation active	read-write								x	
1.3.2.8.1.4.3.1.1.6005	pump3 manual operation running	read-only								x	
1.3.2.8.1.4.3.1.1.6022	pump3 manual operation speed	read-write								x	
1.3.2.8.1.4.4.1.1.6101	pump4 manual operation active	read-write								x	
1.3.2.8.1.4.4.1.1.6105	pump4 manual operation running	read-only								x	
1.3.2.8.1.4.4.1.1.6122	pump4 manual operation speed	read-write								x	
1.3.2.8.1.5.1.1.1.9901	ECO-COOL louver manual operation active	read-write								x	
1.3.2.8.1.5.1.1.1.9914	ECO-COOL louver man. op. opening grade	read-write								x	
1.3.2.8.1.5.2.1.1.10401	Fresh air louver manual operation active	read-write								x	
1.3.2.8.1.5.2.1.1.10409	Fresh air louver manual operation opening grade	read-write								x	
1.3.2.8.1.5.3.1.1.10501	Anti-freeze louver manual operation active	read-write								x	
1.3.2.8.1.5.3.1.1.10509	Anti-freeze louver manual operation opening grade	read-write								x	
1.3.2.8.1.5.4.1.1.10601	Circulation louver manual operation active	read-write								x	
1.3.2.8.1.5.4.1.1.10609	Circulation louver manual operation opening grade	read-write								x	
1.3.2.8.1.5.5.1.1.10701	Exit louver manual operation active	read-write								x	
1.3.2.8.1.5.5.1.1.10703	Exit louver manual operation opening grade	read-write								x	
1.3.2.8.1.6.1.1.1.10801	Cond. fan 1 manual operation active	read-write								x	
1.3.2.8.1.6.1.1.1.10809	Cond. fan 1 manual operation speed	read-write								x	
1.3.2.8.1.6.1.1.1.10901	Cond. fan 2 manual operation active	read-write								x	
1.3.2.8.1.6.1.1.1.10909	Cond. fan 2 manual operation speed	read-write								x	
1.3.2.8.2.1.1.1.1.4801	elec.-heating1 manual operation active	read-write								x	
1.3.2.8.2.1.1.1.1.4804	elec.-heating1 manual operation running	read-write								x	
1.3.2.8.2.1.1.1.1.4818	elec.-heating1 manual operation PWM-grade	read-write								x	
1.3.2.8.2.1.2.1.1.4901	elec.-heating2 manual operation active	read-write								x	
1.3.2.8.2.1.2.1.1.4904	elec.-heating2 manual operation running	read-write								x	
1.3.2.8.2.1.3.1.1.5001	elec.-heating3 manual operation active	read-write								x	
1.3.2.8.2.1.3.1.1.5004	elec.-heating3 manual operation running	read-write								x	
1.3.2.8.2.2.1.1.6201	hotgas-heating manual operation active	read-write								x	
1.3.2.8.2.2.1.1.6203	hotgas-heating manual operation running	read-write								x	
1.3.2.8.2.3.1.1.6301	PWW-heating manual operation active	read-write								x	
1.3.2.8.2.3.1.1.6303	PWW-heating manual operation running	read-write								x	
1.3.2.8.2.3.1.1.6316	PWW-heating manual operation value	read-write								x	
1.3.2.8.3.1.1.1.6401	humidifier1 manual operation active	read-write								x	
1.3.2.8.3.1.1.1.6404	humidifier1 manual operation running	read-write								x	
1.3.2.8.3.1.1.1.6428	humidifier1 manual operation value	read-write								x	
1.3.2.8.3.2.1.1.6801	dehumidification manual operation active	read-write								x	
1.3.2.8.3.2.1.1.6804	dehumidification manual operation running	read-write								x	
1.3.2.8.4.1.1.1.6901	fan1 manual operation active	read-write								x	
1.3.2.8.4.1.1.1.6905	fan1 manual operation running	read-write								x	
1.3.2.8.4.1.1.1.6933	fan1 manual operation speed	read-write								x	
1.3.2.8.4.2.1.1.7201	louver1 manual operation active	read-write								x	
1.3.2.8.4.2.1.1.7203	louver1 manual operation open	read-write								x	
1.3.2.8.5.1.1.1.2305	sensor1 manual operation active	read-only								x	
1.3.2.8.5.1.1.1.2323	sensor1 manual operation value	read-only								x	x
1.3.2.8.5.2.1.1.2405	sensor2 manual operation active	read-only								x	x
1.3.2.8.5.2.1.1.2423	sensor2 manual operation value	read-only								x	x
1.3.2.8.5.3.1.1.2505	sensor3 manual operation active	read-only								x	x
1.3.2.8.5.3.1.1.2523	sensor3 manual operation value	read-only								x	x
1.3.2.8.5.4.1.1.2605	sensor4 manual operation active	read-only								x	x
1.3.2.8.5.4.1.1.2623	sensor4 manual operation value	read-only								x	x
1.3.2.8.5.5.1.1.2705	sensor5 manual operation active	read-only								x	x
1.3.2.8.5.5.1.1.2723	sensor5 manual operation value	read-only								x	x
1.3.2.8.5.6.1.1.2805	sensor6 manual operation active	read-only								x	x
1.3.2.8.5.6.1.1.2823	sensor6 manual operation value	read-only								x	x
1.3.2.8.5.7.1.1.2905	sensor7 manual operation active	read-only								x	x
1.3.2.8.5.7.1.1.2923	sensor7 manual operation value	read-only								x	x
1.3.2.8.5.8.1.1.3005	sensor8 manual operation active	read-only								x	x
1.3.2.8.5.8.1.1.3023	sensor8 manual operation value	read-only								x	x
1.3.2.8.5.9.1.1.3105	sensor9 manual operation active	read-only								x	x
1.3.2.8.5.9.1.1.3123	sensor9 manual operation value	read-only								x	x
1.3.2.8.5.10.1.1.3205	sensor10 manual operation active	read-only								x	x
1.3.2.8.5.10.1.1.3223	sensor10 manual operation value	read-only								x	x
1.3.2.8.5.11.1.1.3305	sensor11 manual operation active	read-only								x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number												
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH	
1.3.2.8.5.11.1.1.3323	sensor11 manual operation value	read-only								x	x	
1.3.2.8.5.12.1.1.3405	sensor12 manual operation active	read-only								x	x	
1.3.2.8.5.12.1.1.3423	sensor12 manual operation value	read-only								x	x	
1.3.2.8.5.13.1.1.3505	sensor13 manual operation active	read-only								x	x	
1.3.2.8.5.13.1.1.3523	sensor13 manual operation value	read-only								x	x	
1.3.2.8.5.14.1.1.3605	sensor14 manual operation active	read-only								x	x	
1.3.2.8.5.14.1.1.3623	sensor14 manual operation value	read-only								x	x	
1.3.2.8.5.15.1.1.3705	sensor15 manual operation active	read-only								x	x	
1.3.2.8.5.15.1.1.3723	sensor15 manual operation value	read-only								x	x	
1.3.2.8.5.16.1.1.3805	sensor16 manual operation active	read-only								x	x	
1.3.2.8.5.16.1.1.3823	sensor16 manual operation value	read-only								x	x	
1.3.2.8.5.17.1.1.3905	sensor17 manual operation active	read-only								x	x	
1.3.2.8.5.17.1.1.3923	sensor17 manual operation value	read-only								x	x	
1.3.2.8.5.18.1.1.4005	sensor18 manual operation active	read-only								x	x	
1.3.2.8.5.18.1.1.4023	sensor18 manual operation value	read-only								x	x	
1.3.2.8.5.19.1.1.4105	sensor19 manual operation active	read-only								x	x	
1.3.2.8.5.19.1.1.4123	sensor19 manual operation value	read-only								x	x	
1.3.2.8.5.20.1.1.4205	sensor20 manual operation active	read-only								x	x	
1.3.2.8.5.20.1.1.4223	sensor20 manual operation value	read-only								x	x	
1.3.2.8.5.21.1.1.4305	sensor21 manual operation active	read-only								x	x	
1.3.2.8.5.21.1.1.4323	sensor21 manual operation value	read-only								x	x	
1.3.2.8.6.1.1.1.1.7501	ext. alarm manual operation enable 1	read-only								x	x	
1.3.2.8.6.1.1.1.1.7503	ext. alarm manual operation active 1	read-only								x	x	
1.3.2.8.6.1.2.1.1.7601	ext. alarm manual operation enable 2	read-only								x	x	
1.3.2.8.6.1.2.1.1.7603	ext. alarm manual operation active 2	read-only								x	x	
1.3.2.8.6.1.3.1.1.7701	ext. alarm manual operation enable 3	read-only								x	x	
1.3.2.8.6.1.3.1.1.7703	ext. alarm manual operation active 3	read-only								x	x	
1.3.2.8.6.1.4.1.1.7801	ext. alarm manual operation enable 4	read-only								x	x	
1.3.2.8.6.1.4.1.1.7803	ext. alarm manual operation active 4	read-only								x	x	
1.3.2.8.6.1.5.1.1.7901	ext. alarm manual operation enable 5	read-only								x	x	
1.3.2.8.6.1.5.1.1.7903	ext. alarm manual operation active 5	read-only								x	x	
1.3.2.8.6.1.6.1.1.8001	ext. alarm manual operation enable 6	read-only								x	x	
1.3.2.8.6.1.6.1.1.8003	ext. alarm manual operation active 6	read-only								x	x	
1.3.2.8.6.1.7.1.1.8101	ext. alarm manual operation enable 7	read-only								x	x	
1.3.2.8.6.1.7.1.1.8103	ext. alarm manual operation active 7	read-only								x	x	
1.3.2.8.6.1.8.1.1.8201	ext. alarm manual operation enable 8	read-only								x	x	
1.3.2.8.6.1.8.1.1.8203	ext. alarm manual operation active 8	read-only								x	x	
1.3.2.8.6.1.9.1.1.8301	ext. alarm manual operation enable 9	read-only								x	x	
1.3.2.8.6.1.9.1.1.8303	ext. alarm manual operation active 9	read-only								x	x	
1.3.2.8.6.1.10.1.1.8401	ext. alarm manual operation enable 10	read-only								x	x	
1.3.2.8.6.1.10.1.1.8403	ext. alarm manual operation active 10	read-only								x	x	
1.3.3.1.1.11600	XYZ alarm valid (local stop)	read-only								x		
1.3.3.1.1.11601	XYZ alarm valid (comp LP alarm)	read-only								x		
1.3.3.1.1.11602	XYZ alarm valid (comp alarm)	read-only								x		
1.3.3.1.1.11603	XYZ alarm valid (e-heating alarm)	read-only								x		
1.3.3.1.1.11604	XYZ alarm valid (humidifier alarm)	read-only								x		
1.3.3.1.1.11605	XYZ alarm valid (humidifier 5uS alarm)	read-only								x		
1.3.3.1.1.11606	XYZ alarm valid (humidifier 20uS alarm)	read-only								x		
1.3.3.1.1.11607	XYZ alarm valid (air flow alarm)	read-only								x		
1.3.3.1.1.11608	XYZ alarm valid (filter clogged)	read-only								x		
1.3.3.1.1.11609	XYZ alarm valid (external alarm)	read-only								x		
1.3.3.1.1.11610	XYZ alarm valid (pump alarm)	read-only								x		
1.3.3.1.1.11611	XYZ alarm valid (drycooler alarm)	read-only								x		
1.3.3.1.1.11612	XYZ alarm valid (water alarm)	read-only								x		
1.3.3.1.1.11613	XYZ alarm valid (room temp too high)	read-only								x		
1.3.3.1.1.11614	XYZ alarm valid (room humidity too high)	read-only								x		
1.3.3.1.1.11615	XYZ alarm valid (supply temp too high)	read-only								x		
1.3.3.1.1.11616	XYZ alarm valid (supply humidity too high)	read-only								x		
1.3.3.1.1.11617	XYZ alarm valid (room temp too low)	read-only								x		
1.3.3.1.1.11618	XYZ alarm valid (room humidity too low)	read-only								x		
1.3.3.1.1.11619	XYZ alarm valid (supply temp too low)	read-only								x	x	
1.3.3.1.1.11620	XYZ alarm valid (supply humidity too low)	read-only								x	x	
1.3.3.1.1.11621	XYZ alarm valid (water temp too high)	read-only								x	x	
1.3.3.1.1.11622	XYZ alarm valid (water temp too low)	read-only								x	x	
1.3.3.1.1.11623	XYZ alarm valid (fire alarm)	read-only								x	x	
1.3.3.1.1.11624	XYZ alarm valid (sensor alarm)	read-only								x	x	
1.3.3.1.1.11625	XYZ alarm valid (sensor break)	read-only								x	x	
1.3.3.1.1.11626	XYZ alarm valid (hotgas reheat alarm)	read-only								x	x	
1.3.3.1.1.11706	my zone number of error units	read-only								x	x	
1.3.3.1.1.11707	my zone emergency temperature	read-only								x	x	
1.3.3.1.1.11708	my zone CW energy save mode activ	read-only								x	x	

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.3.3.1.1.11709	my zone testsequencing	read-only								x	x
1.3.3.1.1.11710	my zone average determination	read-only								x	x
1.3.3.1.1.11780	my zone nMax	read-only								x	x
1.3.3.1.1.11781	GE3 start temp of my zone	read-only								x	x
1.3.3.1.1.11782	GE3 hysteresis of my zone	read-only								x	x
1.3.3.1.1.11783	GE3 absolute start temp of my zone	read-only								x	x
1.3.3.1.1.11784	GEp absolute start watertemp of my zone	read-only									
1.3.3.1.1.11785	GEp water hysteresis of my zone	read-only									
1.3.3.1.1.11786	number of units of my zone (for PT)	read-only									
1.3.3.1.1.11787	my zone outdoor temperature	read-only									
1.3.3.1.1.11788	my zone current raised floor pressure	read-only									
1.3.4.3.2.5.1.1.10810	Cond. fan 1 runtime	read-only								x	
1.3.4.3.2.5.1.1.10910	Cond. fan 2 runtime	read-only									
1.3.4.4.1.1.1717	maintenance alarm prio	read-only								x	x
1.3.4.4.1.1.1745	maintenance common alarm config	read-only								x	x
1.3.5.2.1.1.6	global adress	read-only								x	x
1.4.1.1.1.10	busalarm	read-only							x		
1.4.1.1.1.12	busadrcnflct	read-only									
1.4.1.1.1.1013	Unit on / off	read-only	x	x	x	x	x	x		x	x
1.4.2.1.1.4	number of modules	read-only								x	x
1.4.2.1.1.7	hardware type (controller type)	read-only	x	x	x	x	x	x		x	x
1.4.2.1.1.8	general error	read-only						x		x	x
1.4.2.1.1.1000	PC-STOP (monitoring)	read-write	x	x		x	x	x	x	x	x
1.4.2.1.1.1001	REMOTE STOP (contact)	read-only	x	x		x	x	x	x	x	x
1.4.2.1.1.1002	LOCAL STOP	read-only	x	x		x	x	x	x	x	x
1.4.2.1.1.1003	TIMER-STOP (weekly oper.)	read-only	x	x		x	x	x	x	x	x
1.4.2.1.1.1004	SEQ. Stop (0=No, 1=Yes)	read-only	x			x	x	x	x	x	x
1.4.2.1.1.1005	WARM UP STOP	read-only	x			x	x	x	x	x	x
1.4.3.1.1011	reset all alarms	read-write	x			x	x	x		x	x
1.4.4.1.1.1.1010	common alarm	read-only								x	x
1.4.4.1.1.1.8500	airflow 1	read-only			x					x	
1.4.4.1.1.1.8501	airflow 2	read-only								x	
1.4.4.1.1.1.8502	airflow 3	read-only								x	
1.4.4.1.1.1.8503	highpressure 1	read-only							x	x	x
1.4.4.1.1.1.8504	highpressure 2	read-only							x	x	x
1.4.4.1.1.1.8505	water detector	read-only							x	x	x
1.4.4.1.1.1.8506	Phasecheck	read-only							x	x	x
1.4.4.1.1.1.8507	fire/smoke	read-only			x				x	x	x
1.4.4.1.1.1.8508	return air temp. too high alarm	read-only			x					x	
1.4.4.1.1.1.8509	return air humid. too high alarm	read-only			x					x	
1.4.4.1.1.1.8510	supply air temp. too high alarm	read-only								x	
1.4.4.1.1.1.8511	supply air humid. too high alarm	read-only								x	
1.4.4.1.1.1.8512	water temp. too high alarm	read-only							x	x	x
1.4.4.1.1.1.8513	return air temp. too low alarm	read-only			x					x	
1.4.4.1.1.1.8514	return air humid. too low alarm	read-only			x					x	
1.4.4.1.1.1.8515	supply air temp. too low alarm	read-only								x	
1.4.4.1.1.1.8516	supply air humid. too low alarm	read-only								x	
1.4.4.1.1.1.8517	water temp. too low alarm	read-only							x	x	x
1.4.4.1.1.1.8518	sensor 1 limit alarm	read-only								x	x
1.4.4.1.1.1.8519	sensor 2 limit alarm	read-only								x	x
1.4.4.1.1.1.8520	sensor 3 limit alarm	read-only								x	x
1.4.4.1.1.1.8521	sensor 4 limit alarm	read-only								x	x
1.4.4.1.1.1.8522	sensor 5 limit alarm	read-only								x	x
1.4.4.1.1.1.8523	sensor 6 limit alarm	read-only								x	x
1.4.4.1.1.1.8524	sensor 7 limit alarm	read-only								x	x
1.4.4.1.1.1.8525	sensor 8 limit alarm	read-only								x	x
1.4.4.1.1.1.8526	sensor 9 limit alarm	read-only								x	x
1.4.4.1.1.1.8527	sensor 10 limit alarm	read-only								x	x
1.4.4.1.1.1.8528	sensor 11 limit alarm	read-only								x	x
1.4.4.1.1.1.8529	sensor 12 limit alarm	read-only								x	x
1.4.4.1.1.1.8530	sensor 13 limit alarm	read-only								x	x
1.4.4.1.1.1.8531	sensor 14 limit alarm	read-only								x	x
1.4.4.1.1.1.8532	sensor 15 limit alarm	read-only								x	x
1.4.4.1.1.1.8533	sensor 16 limit alarm	read-only								x	x
1.4.4.1.1.1.8534	sensor 17 limit alarm	read-only								x	x
1.4.4.1.1.1.8535	sensor 18 limit alarm	read-only								x	x
1.4.4.1.1.1.8536	sensor 19 limit alarm	read-only								x	x
1.4.4.1.1.1.8537	sensor 20 limit alarm	read-only								x	x
1.4.4.1.1.1.8538	sensor 21 limit alarm	read-only								x	x
1.4.4.1.1.1.8539	sensor 1 defect alarm	read-only			x				x	x	x
1.4.4.1.1.1.8540	sensor 2 defect alarm	read-only							x	x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
1.4.4.1.1.1.8541	sensor 3 defect alarm	read-only							x	x	x
1.4.4.1.1.1.8542	sensor 4 defect alarm	read-only							x	x	x
1.4.4.1.1.1.8543	sensor 5 defect alarm	read-only							x	x	x
1.4.4.1.1.1.8544	sensor 6 defect alarm	read-only								x	x
1.4.4.1.1.1.8545	sensor 7 defect alarm	read-only								x	x
1.4.4.1.1.1.8546	sensor 8 defect alarm	read-only								x	x
1.4.4.1.1.1.8547	sensor 9 defect alarm	read-only								x	x
1.4.4.1.1.1.8548	sensor 10 defect alarm	read-only								x	x
1.4.4.1.1.1.8549	sensor 11 defect alarm	read-only								x	x
1.4.4.1.1.1.8550	sensor 12 defect alarm	read-only								x	x
1.4.4.1.1.1.8551	sensor 13 defect alarm	read-only								x	x
1.4.4.1.1.1.8552	sensor 14 defect alarm	read-only								x	x
1.4.4.1.1.1.8553	sensor 15 defect alarm	read-only								x	x
1.4.4.1.1.1.8554	sensor 16 defect alarm	read-only								x	x
1.4.4.1.1.1.8555	sensor 17 defect alarm	read-only								x	x
1.4.4.1.1.1.8556	sensor 18 defect alarm	read-only								x	x
1.4.4.1.1.1.8557	sensor 19 defect alarm	read-only								x	x
1.4.4.1.1.1.8558	sensor 20 defect alarm	read-only								x	x
1.4.4.1.1.1.8559	sensor 21 defect alarm	read-only								x	x
1.4.4.1.1.1.8560	highpressure / compr. 1 alarm	read-only							x	x	x
1.4.4.1.1.1.8561	highpressure / compr. 2 alarm	read-only					x	x	x	x	x
1.4.4.1.1.1.8562	low press. Alarm 1	read-only							x	x	x
1.4.4.1.1.1.8563	low press. Alarm 2	read-only					x	x	x	x	x
1.4.4.1.1.1.8564	elec.-heating1 alarm	read-only		x						x	x
1.4.4.1.1.1.8565	elec.-heating2 alarm	read-only								x	x
1.4.4.1.1.1.8566	elec.-heating3 alarm	read-only								x	x
1.4.4.1.1.1.8567	elec.-heating4 alarm	read-only								x	x
1.4.4.1.1.1.8568	drycooler1 alarm	read-only								x	x
1.4.4.1.1.1.8569	drycooler2 alarm	read-only								x	x
1.4.4.1.1.1.8570	drycooler3 alarm	read-only								x	x
1.4.4.1.1.1.8571	drycooler4 alarm	read-only								x	x
1.4.4.1.1.1.8572	pump1 alarm	read-only							x	x	x
1.4.4.1.1.1.8573	pump2 alarm	read-only							x	x	x
1.4.4.1.1.1.8574	pump3 alarm	read-only								x	x
1.4.4.1.1.1.8575	pump4 alarm	read-only								x	x
1.4.4.1.1.1.8576	humidifier1 alarm	read-only		x						x	
1.4.4.1.1.1.8577	humidifier2 alarm	read-only								x	
1.4.4.1.1.1.8578	humidifier3 alarm	read-only								x	
1.4.4.1.1.1.8579	humidifier1 alarm 5uS	read-only								x	
1.4.4.1.1.1.8580	humidifier2 alarm 5uS	read-only								x	
1.4.4.1.1.1.8581	humidifier3 alarm 5uS	read-only								x	
1.4.4.1.1.1.8582	humidifier1 alarm 20uS	read-only								x	
1.4.4.1.1.1.8583	humidifier2 alarm 20uS	read-only								x	
1.4.4.1.1.1.8584	humidifier3 alarm 20uS	read-only								x	
1.4.4.1.1.1.8585	fan1 alarm	read-only								x	
1.4.4.1.1.1.8586	fan2 alarm	read-only								x	
1.4.4.1.1.1.8587	fan3 alarm	read-only								x	
1.4.4.1.1.1.8588	fan1 filter alarm	read-only		x						x	
1.4.4.1.1.1.8589	fan2 filter alarm	read-only								x	
1.4.4.1.1.1.8590	fan3 filter alarm	read-only								x	
1.4.4.1.1.1.8591	ext. Alarm 1 active	read-only		x					x	x	x
1.4.4.1.1.1.8592	ext. Alarm 2 active	read-only		x					x	x	x
1.4.4.1.1.1.8593	ext. Alarm 3 active	read-only		x					x	x	x
1.4.4.1.1.1.8594	ext. Alarm 4 active	read-only							x	x	x
1.4.4.1.1.1.8595	ext. Alarm 5 active	read-only							x	x	x
1.4.4.1.1.1.8596	ext. Alarm 6 active	read-only							x	x	x
1.4.4.1.1.1.8597	ext. Alarm 7 active	read-only							x	x	x
1.4.4.1.1.1.8598	ext. Alarm 8 active	read-only							x	x	x
1.4.4.1.1.1.8599	ext. Alarm 9 active	read-only								x	x
1.4.4.1.1.1.8600	ext. Alarm 10 active	read-only								x	x
1.4.4.1.1.1.8601	hotgas-heating alarm	read-only								x	
1.4.4.1.1.1.8602	eev1 pressure sensor error	read-only								x	x
1.4.4.1.1.1.8603	eev1 temperature sensor error	read-only								x	x
1.4.4.1.1.1.8604	eev1 stepper motor error	read-only								x	x
1.4.4.1.1.1.8605	eev2 pressure sensor error	read-only								x	
1.4.4.1.1.1.8606	eev2 temperature sensor error	read-only								x	
1.4.4.1.1.1.8607	eev2 stepper motor error	read-only								x	
1.4.4.1.1.1.8608	waterflow failure	read-only							x	x	x
1.4.4.1.1.1.8609	Valve test alarm	read-only								x	x
1.4.4.1.1.1.8610	compr. 3 alarm	read-only							x	x	x
1.4.4.1.1.1.8611	compr. 4 alarm	read-only							x	x	x

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number			Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
OID middle part													
1.4.4.1.1.1.8612			compr. 5 alarm	read-only							x	x	x
1.4.4.1.1.1.8613			compr. 6 alarm	read-only							x	x	x
1.4.4.1.1.1.8614			condenser 1 alarm	read-only							x	x	x
1.4.4.1.1.1.8615			condenser 2 alarm	read-only							x	x	x
1.4.4.1.1.1.8616			outside air temp too high alarm	read-only							x	x	x
1.4.4.1.1.1.8617			outside air temp too low alarm	read-only							x	x	x
1.4.4.1.1.1.8618			io extension error	read-only							x	x	x
1.4.4.1.1.1.8619			water out temperature too high (flow water)	read-only							x	x	x
1.4.4.1.1.1.8620			water out temperature too low (flow water)	read-only							x	x	
1.4.4.1.1.1.8621			freeze alarm (equals DP2226)	read-only							x	x	x
1.4.4.1.1.1.8622			unit 1 failure	read-only								x	x
1.4.4.1.1.1.8623			unit 2 failure	read-only								x	x
1.4.4.1.1.1.8624			transmission failure	read-only								x	x
1.4.4.1.1.1.8625			controller failure	read-only								x	x
1.4.4.1.1.1.8626			reheat failure	read-only								x	x
1.4.4.1.1.1.8627			room high pressure alarm	read-only								x	x
1.4.4.1.1.1.8628			filter 1 alarm	read-only								x	
1.4.4.1.1.1.8629			filter 2 alarm	read-only								x	
1.4.4.1.1.1.8630			filter 3 alarm	read-only								x	
1.4.4.1.1.1.8631			compressor 1 circuit breaker tripped	read-only									
1.4.4.1.1.1.8632			compressor 2 circuit breaker tripped	read-only									
1.4.4.2.1.1006			Remote UPS	read-write	x			x	x	x		x	x
1.4.4.2.1.1007			Local UPS	read-only	x			x	x	x		x	x
1.4.4.2.1.1014			maintenance necessary	read-only								x	x
1.4.4.2.1.1023			unit winter mode	read-only								x	x
1.4.4.2.1.1024			day/night-mode	read-only								x	x
1.4.4.2.1.1754			unit cooling	read-only								x	x
1.4.4.2.1.1755			unit heating	read-only								x	x
1.4.4.2.1.1756			unit humidification	read-only								x	x
1.4.4.2.1.1757			unit dehumidification	read-only								x	x
2.1.1.1.1.1.1.10264			FCB room air temperature	read-only			x						
2.1.1.1.1.1.1.10266			supply air temperature comfort unit 1	read-only			x						
2.1.1.1.1.1.1.10267			supply air temperature comfort unit 2	read-only			x						
2.1.1.1.1.1.1.10268			FCB outside air temperature	read-only			x						
2.1.1.1.2.1.1.10265			FCB room air humidity	read-only			x						
2.1.1.1.2.1.1.10269			FCB outside air humidity	read-only			x						
2.1.2.4.1.1.10216			FAN FCB	read-only			x						
2.1.2.4.1.1.10219			LOUVER FCB	read-only			x						
2.1.2.4.1.1.10270			analogue out fan FCB	read-only			x						
2.1.2.4.1.1.10271			analogue out louver FCB	read-only			x						
2.1.2.4.1.1.10272			FCB analogue out humidifier	read-only			x						
2.1.2.6.1.1.10217			remote Comfort Unit 1	read-only			x						
2.1.2.6.1.1.10218			remote Comfort Unit 2	read-only			x						
2.3.1.1.1.1.1.10273			setpoint temperature cooling	read-write			x						
2.3.1.1.1.1.1.10274			setpoint temperature heating	read-write			x						
2.3.1.1.1.1.1.10275			second setpoint temperature heating	read-write			x						
2.3.1.1.1.1.1.10277			coling band	read-write			x						
2.3.1.1.1.1.1.10278			heating band	read-write			x						
2.3.1.1.1.1.1.10280			limit room temp max	read-write			x						
2.3.1.1.1.1.1.10281			limit room temp min	read-write			x						
2.3.1.1.2.1.1.10276			setpoint humidity	read-write			x						
2.3.1.1.2.1.1.10279			humidity band	read-write			x						
2.3.1.1.2.1.1.10282			limit room humidity too low	read-write			x						
2.3.1.1.2.1.1.10283			limit room humidity too high	read-write			x						
2.4.2.1.1.10201			FCB PC-STOP	read-write			x						
2.4.2.1.1.10202			FCB REMOTE STOP	read-only			x						
2.4.2.1.1.10203			FCB LOCAL STOP	read-only			x						
2.4.2.1.1.10204			FCB TIMER STOP	read-only			x						
2.4.4.1.1.1.10224			FCB common alarm	read-only			x						
2.4.4.1.1.1.10225			alarm comfort unit 1	read-only			x						
2.4.4.1.1.1.10226			alarm comfort unit 2	read-only			x						
2.4.4.1.1.1.10234			Reheat 1 failure	read-only			x						
2.4.4.1.1.1.10235			humidification failure	read-only			x						
2.4.4.1.1.1.10237			filter clogged	read-only			x						
2.4.4.1.1.1.10238			aux alarm 1	read-only			x						
2.4.4.1.1.1.10239			fire / smoke detector triggered	read-only			x						
2.4.4.1.1.1.10246			aux alarm 2	read-only			x						
2.4.4.1.1.1.10247			aux alarm 3	read-only			x						
2.4.4.1.1.1.10248			room air temperature too high alarm	read-only			x						
2.4.4.1.1.1.10249			room air humidity too high alarm	read-only			x						
2.4.4.1.1.1.10250			Bad working Comfort unit 1	read-only			x						

OID = 1.3.6.1.4.1.29462.10.2.<middle part>.b.a.m with b = bus number 1 or 2, a = global address of the unit, m = module number											
OID middle part	Description	Access	C1002	C1010/C2020	C2020FCB	C4000	C5000	C6000	C6000CH	C7000IOC	C7000CH
2.4.4.1.1.1.10251	Bad working Comfort unit 2	read-only			x						
2.4.4.1.1.1.10252	Room air temp too low	read-only			x						
2.4.4.1.1.1.10253	Room air humidity too low	read-only			x						
2.4.4.1.1.1.10260	fire / smoke detector alarm	read-only			x						
2.4.4.1.1.1.10261	FCB sensor failure	read-only			x						
2.4.4.1.1.1.10262	FCB controller failure	read-only			x						
2.4.4.1.1.1.10263	FCB IO-board transmission failure	read-only			x						
2.4.4.1.1.1.10336	airflow failure	read-only			x						