



**midistart**  
*music 25*



## ***Owner's manual***

### ***USB-MIDI-Masterkeyboard with 25 keys***

#### ***Features:***

- Class Compliant for Windows XP,  
Windows Vista 32/64 & Mac OS X (10.2.6 & higher)***
- 25 high-quality dynamic keys***
- Programable 2-way-joystick with integrated knob***
  - 4 different velocity curves***
- Programable slider***
- 10 user memory places to store own settings***
- Footswitch-input for a sustain-pedal***
- MIDI-Out***
- USB powered or optional with AC adaptor***

**eMail: [info@miditech.de](mailto:info@miditech.de) Internet: [www.miditech.de](http://www.miditech.de)**

## PREFACE

*Congratulations on purchasing the Midistart music 25 master MIDI controller keyboard. It is one of the finest products of its kind, made after extensive research into what customers require from a MIDI Controller.*

*When using your Midistart music 25 in conjunction with a computer and appropriate music software, you will be able to discover the wonderful world of Computer Music, with a set of complete musical instruments from your sound card or workstation.*


*This manual is written to help you become familiar with the features of the Midistart music 25. Please read the manual carefully to discover all the features of your Midistart music 25. After reading the manual, you will have a clear understanding of how to transmit different MIDI messages to other instruments and equipment. For ease of use of MIDI implementation, we strongly recommend you to have the manual at hand when you are using the keyboard, especially if you are new to the world of MIDI.*

## TABLE OF CONTENTS

1. Userpanel
2. Installation
3. Basic functions
4. System settings

### 1. The Userpanel:

#### Front panel:



#### Keyboard

The 25 keys are velocity sensitive, and can be used in combination with the SHIFT button to program multiple MIDI functions. On top of the keys you will find the MIDI controller function descriptor and the numeric keypad.

## ***2-way-joystick***

The joystick is part to control the pitch and/or modulation. Left/right sends Pitchbend, pressing the joystick up sends Modulation. Pressing it down sends Aftertouch, or you can define for this way a different controller.

## ***Power-LED***

This is the power indicator LED.

## ***SHIFT button***

The SHIFT button is used in combination with other keys to program the functions.


## ***DATA buttons +/-***

By default the DATA buttons are used for Octave function. If you hold the SHIFT button at the same time, they will be assigned with Transpose. The default keyrange of the Midistart music 25 is from C2-C4. With DATA +/- you can change it 3 octaves up or down.

## ***Assignable slider***

By default the slider is used for Volume control. This slider can be assigned with different CC-MIDI controllers.

### ***Rear panel:***



## ***PEDAL***

Can be used for a Sustain pedal. The polarity can be changed.

## ***MIDI OUT***

Standard 5-DIN MIDI Out port

## ***USB port***

To make the connection to the computer for the MIDI data transfer and to get USB power

## ***DC IN***

AC adaptor power in port, please use a AC/DC adaptor with 9 V DC/ 500 mA.

## ***POWER ON-OFF***

To turn the instrument on and off.

## ***2.Installation***

### ***Windows XP/ Vista/ Mac OSX***

Connect the Midistart music 25 keyboard to an available USB port on your computer with the USB cable provided. If the PC is running, switch the keyboard on with the power switch.

As the Midistart music 25 is a "Class Compliant" device, you do not need to install special software drivers. Windows XP; Vista and Mac OSX will automatically recognize the new device and establish it as "USB audio equipment" within the system. Once established it is ready to start use. Should you have previously used other USB audio equipment on this same USB port, it is advisable to choose another USB port that has never previously had audio equipment installed. This ensures that an Midistart "exclusive" is established at this port.

### ***Turning on with initialization***

If you press and hold both DATA buttons while switching on the Midistart music 25, the keyboard will initialize itself. This will clear all user settings and bring it back to the default settings.

## ***3. Basic functions of the Midistart music 25***

### ***DATA buttons***

By default the DATA buttons are used for Octave function. If you hold the SHIFT button at the same time, they will be assigned with Transpose. The default keyrange of the Midistart music 25 is from C2-C4. With DATA +/- you can change it 3 octaves up or down.

### ***Programming with the keys***

The controller functions will be programmed with the keyboard's keys. On top of a single keys you find the special function it has and the numeric keys. The right key is „Enter“, to confirm a change or program. In combination with the SHIFT button you can choose what function do you want to change.

For example, press the SHIFT button, and then „Assign slider“, the press the numeric key „1“, and „Enter“. Now the slider is assigned with the Modulation controller.

After this the power-LED will blink 3 times, and the light from the SHIFT button turns off. Some functions, eg. the Velocity curves, it is not necessary to confirm the new setting with „Enter“.

### ***Adjusting Volume – Assignable slider***

When the power on, the application of the slider is volume control.

You can use the slider to send the volume control message CC#7 to adjust volume.

Read how you can assign the slider to another CC-controller:

Press <SHIFT><Assignable slider><Set value> and confirm with <ENTER>

Value range : 0-146

The most left position of the slider will send data 0, and the most right position will send data 127.

### ***Transpose and octave – Oct/Trans key***

By default the DATA buttons are used for Octave function. If you hold the SHIFT button at the same time, they will be assigned with Transpose. The default keyrange of the Midistart music 25 is from C2-C4. With DATA +/- you can change it 3 octaves up or down.

You can use the <Oct/Trans> key to switch between the basic function for the DATA buttons, transpose or octave.

Press <SHIFT><Oct/Trans> and confirm with <ENTER>

Now the basic function of DATA +/- is transpose up/down.

### ***Working with the Joystick***

Move the joystick to the left/right to send the PITCHBEND message.

Move the joystick upward to send the MODULATION message.

Move the joystick downward to send the AFTER TOUCH message.

*How to assign the downward joystick message:*

Press <SHIFT><Assign Modu stick><Set value>and confirm with <ENTER>.

Value range : 0-145

The center position of the joystick will send data 0, and the lowest position will send data 127.

### ***How to choose a soundprogram in 3 steps:***

The next 3 steps will work together, if you want to choose a bank and a sound number in a sound module. You can use step 3 alone to change the sound number in the actual soundbank.

#### ***1.Bank MSB - Bank MSB key***

Press the SHIFT button, then the „Bank MSB“ key, after this the number you want to program, and confirm with „Enter“. Power LED blinks 3 times, and the SHIFT LED turns off.

Press <SHIFT><Bank MSB><Set value>

Do NOT confirm with <ENTER>.

#### ***2.Bank LSB - Bank LSB key***

Press the SHIFT button, then the „Bank LSB“ key, after this the number you want to program, do NOT confirm with „Enter“. Power LED blinks 3 times, and the SHIFT LED turns off.

Press <SHIFT><Bank LSB><Set value>

Do NOT confirm with <ENTER>.

#### ***3.Program change - Program change key***

Press the SHIFT button, then the „Program change“ key, after this the numeric sound number, eg. 61, and confirm with „Enter“. Power LED blinks 3 times, and the SHIFT LED turns off.

Press <SHIFT><Program change><Set value> NOW confirm with <ENTER>.

*The values of this three steps will send at one time, and switch the bank and the program number.*

#### ***MIDI channel - Channel key***

Press the SHIFT button, then the „Channel“ key, after this the numeric channel number from 1 to 16, and confirm with „Enter“. Power LED blinks 3 times, and the SHIFT LED turns off. Now the keyboard sends the MIDI data on the specified new MIDI channel.

Press <SHIFT><Channel><Set value> and confirm with <ENTER>.

Default value : 1

Value range : 1-16

#### ***Reset all controllers - Rest all controls key***

Press the SHIFT button, then the „Reset all controls“ key, and message of reset all controllers will be sent out immediately.

Press <SHIFT><Reset all controls> and immediatly CC121 is sent.

.

#### ***Reset all events - All notes off key***

Press the SHIFT button, then the „All notes off“ key, and message of reset all events will be sent out immediately.

Press <SHIFT><All notes off> and immediatly CC123 is sent.

*After complete setting operation with key on the keyboard, the SHIFT indicator will trun off and the keyboard will recover to normal play mode.*


## 4. System settings

### **Velocity Curve**


There are 4 different velocity curves can be selected ranged.

Press <SHIFT><Velocity curve> and immediatly the curve will be changed.


Velocity Curve 1 (Normal)




Velocity Curve 2 (Soft)



Velocity Curve 3 (Hard)



Velocity Curve 4 (Expand)



### **Pedal Polarity**

You can set the polarity of the switch type pedal. The default setting is normal off pedal. Press a key as a toggle switch.

Press <SHIFT><Pedal polarity> and immediatly the polarity will be changed.

### **GM/GS Switch**

With the default setting, when you first time to triggler this feature, the GS On message F0 41 10 42 12 40 00 7F 00 41 F7 will be sent. Triggler this feature again, the GM On message F0 7E 7F 09 01 F7 will be sent out. In another words, it'll send GS On and GM On message alternatively.

Press <SHIFT><GM/GS> and immediatly the GM On or GS On message will be send.

### **Registration - Storing your own settings**

All settings you made are non-volatile. After power off, settings will keep no change. When you turn on the keyboard again, it'll work with settings you made last time.

You may save your setting in 10 registration memories numbered 0 – 9 individually. You could recall one of them any time. The contents of the registration memory are: Oct/Trans setting, velocity curve, all assignments for slider, pedal etc.

***Store operation:***

Press <SHIFT>, <Regist> and <Set value> at the same time, it means, press a number key and regist key at the same time, it is not necessary to press <ENTER>.

***Recall Operation:***

Press <SHIFT><Regist><Set value> simply press a number key and do not need <Enter> a

## ***Standard Midi Controller (CC) numbers***

<b>Controller</b>	<b>Funktion</b>	<b>Controller</b>	<b>Funktion</b>
0	Bank Select	50	General Purpose #3
1	Modulation Wheel	51	General Purpose #4
2	Breath Control	52-63	Not defined
3	Not defined	64	Damper Pedal
4	Foot Controller	65	Portamento on/off
5	Portamento Time	66	Sostenuto on/off
6	Data Entry	67	Soft Pedal on/off
7	Channel Volume	68	Legato Footswitch
8	Balance	69	Hold 2
9	Not defined	70	Sound Variation
10	Pan	71	Timbre/Harmonic Intensity
11	Expression	72	Release Time
12	Effect Control 1	73	Attack Time
13	Effect Control 2	74	Brightness
14/15	Not defined	75	Decay Time
16	General Purpose #1	76	Vibrato Rate
17	General Purpose #2	77	Vibrato Depth
18	General Purpose #3	78	Vibrato Delay
19	General Purpose #4	79	Sound Contr.
20-31	Not defined	80	General Purpose #5
32	Bank Select	81	General Purpose #6
33	Modulation Wheel	82	General Purpose #7
34	Breath Control	83	General Purpose #8
35	Not defined	84	Portamento Control
36	Foot Controller	85-90	Not defined
37	Portamento Time	91	Reverb Send Level
38	Data Entry	92	Tremolo Depth
39	Channel Volume	93	Chorus Send Level
40	Balance	94	Celeste/Detune Depth
41	Not defined	95	Phaser Depth

42	Pan	96	Data Entry +1
43	Expression	97	Data Entry -1
44	Effect Control 1	98	NRPN LSB
45	Effect Control 2	99	NRPN MSB
46/47	Not defined	100	RPN LSB
48	General Purpose #1	101	RPN MSB
49	General Purpose #2	102-119	Not defined
120	All Sound Off	142	EG Attack Time
121	Reset All Controllers	143	EG Decay Time
122	Local Control on/off	144	EG Release Time
123	All Notes off	145	After Touch
124	Omni Mode off	146 *	Program Change
125	Omni Mode on	147 **	Start (MTC)
126	Poly Mode off	148 **	Continue (MTC)
127	Poly Mode on	149 **	Stop (MTC)
128	Pitch Bend	150 **	System Reset (MTC)
129	Pitch Bend Sensitivity	151 **	Stop (MMC)
130	Fine Tuning	152 **	Play (MMC)
131	Coarse Tuning	153 **	Deferred Play
132	Vibrato Rate	154 **	Forward (MMC)
133	Vibrato Depth	155 **	Rewind (MMC)
134	Vibrato Delay	156 **	Record Strobe (MMC)
135	Low Pass Filter Cutoff Frequency	157 **	Record Exit (MMC)
136	Low Pass Filter Resonance	158 **	Record Pause (MMC)
137	High Pass Filter Cutoff Frequency	159 **	Pause (MMC)
138	EQ Low Gain	160 **	Eject (MMC)
139	EQ High Gain	161 **	Chase (MMC)
140	EQ Low Frequency	162 **	Comman Error Reset (MMC)
141	EQ High Frequency	163 **	MMC Reset (MMC)

*\* This controller cannot be assigned to the joystick.*

*\*\* This controllers cannot be assigned to the joystick or the slider.*



## ***Specifications:***

Keyboard: 25 keys (C2 - C4), (velocity sensitive)

Functions: Basic functions: USB MIDI, Octave shift, Transpose, Joystick, Pedals, MIDI OUT, Slider,

Function buttons: MIDI Data: Bank select, Program change, GM System On, GS System on, All Notes Off, etc;

Parameters: Transpose, Octave, MIDI out channels, Velocity curve, Pitch bend, Modulation, Brightness, etc.

Panel Controls and Indicators: Function buttons with light × 2; Slider × 1, SHIFT button with light × 1, Joystick × 1.

Display: LED indicator for power/signal.

Input/Output Terminals: POWER ON/OFF switch × 1, POWER IN connector × 1, USB port × 1  
PEDAL jack × 1, MIDI OUT port × 1

Power Supply: USB bus power or AC Power Adapter (Optional), AC Power Adapter requirement: 9V 500mA



Dimensions (W x D x H) and Weight : 390 mm × 200mm × 500 mm, 2.3 kg

## **IMPORTANT SECURE INFORMATIONS**

Please read the following secure instructions first!

1. Never use the keyboard in the near of water like a swimming pool, bathtub or wet environment like a basement, in rain or similar.
2. Never use the keyboard in the near of heating elements like a radiator or similar, also high temperatures or direct sunbeam should be avoid.
3. Use only the power supply that is declared in our Specification
4. If you didn't use the keyboard for a longer time please plug power off.
5. Take care that no liquid flows inside the keyboard
6. Also take care that no metal objects like a coin or paperclip and other small objects can fall into the keyboard (e.g. by children...) because of electrical shortcut.
7. Do not open the keyboard, this is allowed by qualified technicians only.
8. Never leave the keyboard powered and switched on alone, because of fire for example by thunderstorm or other reasons.
9. Children should inform about the secure information and/or an adult should take care about, if children are to young for understanding this information.
10. In the near of a radio or television device, are electromagnetic fields possible they can disturb the reception. Enough distance is important!
11. In the near of Audio Amplifiers is noise possible. Enough distance is important too.
12. For cleaning never use petrol, alcohol or solvent because damaging of the housing. Use only a dry or little wet rag for cleaning and unplug the power supply or USB connector, because of electrical shock.
13. Never unplug the keyboard if the power supply is powered.
14. Don't throw the Keyboard, and also never let them crash down. Also don't push or trust the keyboard.
15. At a thunderstorm please unplug all connectors.

**Thank You.**

**Design and specifications subject to change without notice.  
No liability for printing mistakes**