

Thermoeye Inc.



TMC Series

Camera Control SDK Manual for TMC80 / TMC160 / TMC256

Contact help@thermoeye.co.kr
Technical Support <https://github.com/Thermoeye>

5F, 169, Sadang-ro, Dongjak-gu, Seoul, Republic of Korea (07003)

Revision

Version	Date	Contents
1.0	NOV.06.2023	Separated from ThermoCam160E/256E User Manual
1.1	NOV.14.2023	Added MatFrame, GetSystemStatus(), GetSystemError()
1.2	NOV.30.2023	Supported input index and coordinates at once for RoiSpot(), RoiLine(), RoiRect(), RoiEllipse()
1.3	JAN.17.2024	Modified product name Added NoiseFiltering
1.4	MAR.07.2024	Added CheckFirmware() Added TMC80 Product Added Turbo, DeepGreen in Color Map
1.5	JUN.03.2024	Added GetNetworkAdapterIPList() Modified GetCameraList() Modified RemoteCamInfo

Chapter

1.	ThermoCamSDK C# API.....	6
2.	ThermoEngine Namespace.....	6
2.1.	Classes	6
2.2.	Interfaces	6
2.3.	Structures	6
2.4.	Enumerations.....	6
3.	ThermoEngine.Camera Class.....	7
3.1.	Definition	7
3.2.	Open(LocalCamInfo) Method	8
3.3.	Open(RemoteCamInfo) Method.....	8
3.4.	Close Method.....	8
3.5.	QueryFrame Method.....	9
3.6.	GetTemperature Method	9
3.7.	Start Method.....	9
3.8.	Stop Method.....	10
3.9.	Dispose Method	10
3.10.	Control Field.....	10
4.	ThermoEngine.RemoteCamera Class.....	10
4.1.	Definition	10
4.2.	RemoteCamera Constructor	11
4.3.	GetCameraList Method.....	11
4.4.	GetNetworkAdapterIPList Method.....	11
5.	ThermoEngine.LocalCamera Class.....	11
5.1.	Definition	11
5.2.	LocalCamera Constructor.....	12

5.3.	GetCameraList Method.....	12
6.	ThermoEngine.Frame Class.....	12
6.1.	Definition	12
6.2.	GetPixel(int, int) Method.....	13
6.3.	GetPixel(int, int, int, int) Method	13
6.4.	SetPixel(int, int, ushort) Method.....	13
6.5.	SetPixel(int, int, int, int, ushort) Method.....	14
6.6.	MinMaxLoc Method	14
6.7.	DoMeasure(RoiObject) Method.....	15
6.8.	DoMeasure(List<RoiObject>) Method.....	15
6.9.	ToBitmap Method.....	15
6.10.	Dispose Method	15
7.	ThermoEngine.CamInfo Class.....	16
7.1.	Definition	16
8.	ThermoEngine.RemoteCamInfo Class.....	16
8.1.	Definition	16
9.	ThermoEngine.LocalCamInfo Class.....	16
9.1.	Definition	16
10.	ThermoEngine.RoiManager Class.....	17
10.1.	Definition	17
10.2.	Clear Method	17
10.3.	MouseDown Method	18
10.4.	MouseMove Method	18
10.5.	MouseUp Method.....	18
11.	ThermoEngine.RoiObject Class.....	19
11.1.	Definition	19

12.	ThermoEngine.RoiSpot Class	19
12.1.	Definition	19
13.	ThermoEngine.RoiLine Class	20
13.1.	Definition	20
14.	ThermoEngine.RoiRect Class	20
14.1.	Definition	20
15.	ThermoEngine.RoiEllipse Class	21
15.1.	Definition	21
16.	ThermoEngine.RoiPolygon Class	21
16.1.	Definition	21
17.	ThermoEngine.ICameraControl Interface	22
17.1.	Definition	22
17.2.	GetProductModelName Method	23
17.3.	GetProductSerialNumber Method	23
17.4.	GetHardwareVersion Method	23
17.5.	GetBootloaderVersion Method	24
17.6.	GetFirmwareVersion Method	24
17.7.	GetSystemStatus Method	24
17.8.	GetSystemError Method	24
17.9.	GetSensorModelName Method	25
17.10.	GetSensorSerialNumber Method	25
17.11.	GetSensorUptime Method	25
17.12.	ConvertRawToCelsius Method	25
17.13.	ConvertRawToFahrenheit Method	26
17.14.	ConvertRawToKelvin Method	26
17.15.	GetNetworkConfiguration Method	26

17.16.	SetNetworkConfiguration Method.....	27
17.17.	SetDefaultNetworkConfiguration Method	27
17.18.	RebootDevice Method.....	28
17.19.	CheckFirmware Method.....	28
17.20.	OpenFirmware Method.....	29
17.21.	UpdateFirmware Method	29
17.22.	CloseFirmware Method.....	29

1. ThermoCamSDK C# API

ThermoCamSDK provides the C# APIs to control the functionalities of camera device.

The sample project was created on Microsoft Visual Studio Community 2022 and was implemented on Windows .NET Framework 4.8.

2. ThermoEngine Namespace

2.1. Classes

Camera	Abstract class for camera control
RemoteCamera	Inheritance class for remote camera control
LocalCamera	Inheritance class for local camera control
Frame	Class for Frame control
CamInfo	Abstract class for camera information store
RemoteCamInfo	Inheritance class for remote camera information store
LocalCamInfo	Inheritance class for local camera information store
CameraStatus	Camera device system status class
RoiManager	Class for ROI management
RoiObject	Abstract class for ROI object
RoiSpot	Inheritance class for Spot type ROI
RoiLine	Inheritance class for Line type ROI
RoiRect	Inheritance class for Rectangle type ROI
RoiEllipse	Inheritance class for Ellipse type ROI
RoiPolygon	Inheritance class for Polygon type ROI

2.2. Interfaces

ICameraControl	Interface for camera sensor control
--------------------------------	-------------------------------------

2.3. Structures

LocItem	ROI location and temperature value
---------	------------------------------------

2.4. Enumerations

SysStatusCode	Camera device system status code
SysErrorCode	Camera device system error code
RoiType	ROI types
TempUnit	Temperature unit type

3. ThermoEngine.Camera Class

3.1. Definition

```
public class Camera : IDisposable
```

- The Camera Class is the main Class in ThermoEngine that provides functionalities to drive and control the Remote (Ethernet Network) and Local (USB) camera. The RemoteCamera and LocalCamera Classes are inherited from this Camera Class and provide functionalities for each connection specification.

- Derived Class

```
public class RemoteCamera : Camera
```

```
public class LocalCamera : Camera
```

- Properties

Name	Product Name
Width	Frame width
Height	Frame height
FPS	Frame rate, Frames per second
IsOpen	State of video streaming, true=play / false=stop
ColorMap	Color Map, 0=Grayscale / 1=Autumn / 2=Bone / 3=Jet / 4=Winter / 5=Rainbow / 6=Ocean / 7=Summer / 8=Spring / 9=Cool / 10=Hsv / 11=Pink / 12=Hot / 13=Parula / 14=Magma / 15=Inferno / 16=Plasma / 17=Viridis / 18=Cividis / 19=Twilight / 20=TwilightShifted / 21=Turbo / 22=DeepGreen
TempUnit	Temperature unit type, 0=Raw / 1=Celsius / 2=Fahrenheit / 3=Kelvin
TempUnitSymbol	Temperature unit symbol
NoiseFiltering	Video noise filtering on/off

- Methods

Open(LocalCamInfo)	Opens local camera device connection via USB UVC and CDC
Open(RemoteCamInfo)	Opens remote camera device connection via Ethernet RTSP and RTP
Close	Closes camera device connection
QueryFrame	Queries a resized frame
GetTemperature	Get converted temperature by temperature unit
Start	Starts camera video streaming
Stop	Stops camera video streaming

Dispose	Cleans up resources being used
-------------------------	--------------------------------

- Fields

Control	Prepares camera control interface.
-------------------------	------------------------------------

3.2. Open(LocalCamInfo) Method

```
public bool Open(LocalCamInfo camInfo)
```

- Opens local camera device connection via USB UVC and CDC
- Parameters

camInfo: device information to be connected via USB

- Return Value

True if this method opens camera connection successfully; otherwise, false if an exception is raised.

3.3. Open(RemoteCamInfo) Method

```
public bool Open(RemoteCamInfo camInfo)
```

- Opens remote camera device connection via Ethernet RTSP and RTP
- Parameters

camInfo: device information to be connected via Ethernet

- Return Value

True if this method opens camera connection successfully; otherwise, false if an exception is raised.

3.4. Close Method

```
public bool Close()
```

- Closes camera device connection
- Return Value

True if this method closes camera connection successfully; otherwise, false if an exception is raised.

3.5. QueryFrame Method

```
public Frame QueryFrame(int width, int height)
```

- Queries a resized frame
- Parameters

width: desired width

height: desired height

- Return Value

Frame object if this method gets a captured frame successfully; otherwise, null if an exception is raised.

- Remarks

If you want to get the original frame object, just call method without parameters as below:

```
var frame = mCamera.QueryFrame();
```

3.6. GetTemperature Method

```
public double GetTemperature(double raw)
```

- Get converted temperature by temperature unit
- Parameters

raw: raw value to be converted

- Return Value

Converted temperature value

3.7. Start Method

```
public bool Start()
```

- Starts camera video streaming
- Return Value

True if this method starts camera video streaming successfully; otherwise, false if an exception is raised.

3.8. Stop Method

```
public bool Stop()
```

- Stops camera video streaming
- Return Value

True if this method stops camera video streaming successfully; otherwise, false if an exception is raised.

3.9. Dispose Method

```
public void Dispose()
```

- Cleans up resources being used

3.10. Control Field

```
public ICameraControl Control
```

- Prepares camera control interface
- Must use this field to call camera control methods as below:

```
mCamera.Control.GetSensorModelName();
```

4. ThermoEngine.RemoteCamera Class

4.1. Definition

```
public class RemoteCamera : Camera
```

- The RemoteCamera Class is inherited from the Camera Class and provides functionalities to drive and control a Remote (Ethernet Network) camera.
- Constructors

RemoteCamera	Initializes a new instance of the RemoteCamera class
------------------------------	--

- Additional Methods

GetCameraList	Gets remote camera list
GetNetworkAdapterIPList	Gets local network adapter IP address list

4.2. RemoteCamera Constructor

```
public RemoteCamera()
```

- Initializes a new instance of the RemoteCamera class

4.3. GetCameraList Method

```
static public RemoteCamInfo[] GetCameraList(string adapterIP = null)
```

- Gets remote camera list
- Parameters

adapterIP: specified local network adapter IP address

- Return Value

Camera information list if this method gets connectable camera information successfully; otherwise, false if an exception is raised.

- Remark

If you want to get all cameras that can be connected via multiple local network adapters, just call method without parameters as below:

```
object list = RemoteCamera.GetCameraList();
```

4.4. GetNetworkAdapterIPList Method

```
static public string[] GetNetworkAdapterIPList()
```

- Gets local network adapter IP address list
- Return Value

IP address list if this method gets active local network adapters successfully; otherwise, false if an exception is raised.

5. ThermoEngine.LocalCamera Class

5.1. Definition

```
public class LocalCamera : Camera
```

- The LocalCamera Class is inherited from the Camera Class and provides functionalities to drive and control a Local (USB) camera.

- Constructors

LocalCamera	Initializes a new instance of the LocalCamera class
-----------------------------	---

- Additional Methods

GetCameraList	Gets local camera list
-------------------------------	------------------------

5.2. LocalCamera Constructor

```
public LocalCamera()
```

- Initializes a new instance of the LocalCamera class

5.3. GetCameraList Method

```
static public LocalCamInfo[] GetCameraList()
```

- Gets local camera list
- Return Value

Camera information list if this method gets connectable camera information successfully; otherwise, false if an exception is raised.

6. ThermoEngine.Frame Class

6.1. Definition

```
public class Frame : IDisposable
```

- The Frame Class provides functionalities to convert a captured single frame data object to a bitmap image object.
- Methods

GetPixel(int, int)	Gets pixel data in frame
GetPixel(int, int, int, int)	Gets area pixel data in frame
SetPixel(int, int, ushort)	Sets raw data into frame
SetPixel(int, int, int, int, ushort)	Sets raw data into area in frame
MinMaxLoc	Gets minimum, maximum and average values and locations
DoMeasure(RoiObject)	Measures location and temperature by ROI
DoMeasure(List<RoiObject>)	Measures location and temperature by ROI list
ToBitmap	Converts a captured frame to Bitmap image object

Dispose	Releases all resources used by the Frame
-------------------------	--

- Fields

MatFrame	Mat array for a captured frame
----------	--------------------------------

6.2. GetPixel(int, int) Method

```
public double GetPixel(int x, int y)
```

- Gets pixel data in frame
- Parameters
 - x: x position
 - y: y position
- Return Value
 - pixel data value

6.3. GetPixel(int, int, int, int) Method

```
public double[,] GetPixel(int x, int y, int width, int height)
```

- Gets area pixel data in frame
- Parameters
 - x: x position
 - y: y position
 - width: width
 - height: height
- Return Value
 - pixel data values

6.4. SetPixel(int, int, ushort) Method

```
public bool SetPixel(int x, int y, ushort value)
```

- Sets pixel data into frame
- Parameters

x: x position

y: y position

value: raw value

- Return Value

True if this method set value successfully; otherwise, false if an exception is raised.

6.5. SetPixel(int, int, int, int, ushort) Method

```
public bool SetPixel(int x, int y, int width, int height, ushort value)
```

- Sets pixel data into area in frame

- Parameters

x: x position

y: y position

width: width

height: height

value: raw value

- Return Value

True if this method set value successfully; otherwise, false if an exception is raised.

6.6. MinMaxLoc Method

```
public void MinMaxLoc(out double minVal,  
                     out double avgVal,  
                     out double maxVal,  
                     out System.Drawing.Point minLoc,  
                     out System.Drawing.Point maxLoc)
```

- Gets minimum, maximum and average values and locations

- Parameters

minVal: minimum value

avgVal: average value

maxVal: maximum value

minLoc: minimum location

maxLoc: maximum location

6.7. DoMeasure(RoiObject) Method

```
public void DoMeasure(ref RoiObject item)
```

- Measures location and temperature by ROI
- Parameters

item: measured ROI object

6.8. DoMeasure(List<RoiObject>) Method

```
public void DoMeasure(ref List<RoiObject> items)
```

- Measures location and temperature by ROI list
- Parameters

item: measured ROI objects list

6.9. ToBitmap Method

```
public Bitmap ToBitmap(int width, int height)
```

- Converts a captured frame to Bitmap image object
- Parameters

width: width size to be resized

height: height size to be resized

- Return Value

Bitmap image object if this method converts a frame successfully; otherwise, null if an exception is raised.

6.10. Dispose Method

```
public void Dispose()
```

- Releases all resources used by the Frame

7. ThermoEngine.CamInfo Class

7.1. Definition

```
public class CamInfo
```

- The `CamInfo` Class is an abstraction Class to store information about connected Remote (Ethernet Network) or Local (USB) camera. The `RemoteCamInfo` and `LocalCamInfo` Classes are inherited from this `CamInfo` Class to store their connection information.
- Derived Class :

```
public class RemoteCamInfo : CamInfo
```

```
public class LocalCamInfo : CamInfo
```

8. ThermoEngine.RemoteCamInfo Class

8.1. Definition

```
public class RemoteCamInfo : CamInfo
```

- The `RemoteCamInfo` Class is inherited from the `CamInfo` Class and provides functionalities to store information about a connected Remote (Ethernet Network) camera.
- Constructors

<code>RemoteCamInfo</code>	Initializes a new instance of the <code>RemoteCamInfo</code> class
----------------------------	--

- Fields

<code>Name</code>	Camera device name
<code>SerialNumber</code>	Product serial number
<code>AddrMAC</code>	MAC address
<code>AddrIP</code>	IP address
<code>AdapterIP</code>	Local Network Adapter IP address

9. ThermoEngine.LocalCamInfo Class

9.1. Definition

```
public class LocalCamInfo : CamInfo
```

- The `LocalCamInfo` Class is inherited from the `CamInfo` Class and provides functionalities to store information about a connected Local (USB) camera.
- Constructors

LocalCamInfo	Initializes a new instance of the LocalCamInfo class
---------------------	---

- Fields

Index	Camera index
Name	Camera device name
ComPort	Serial port name

10. ThermoEngine.RoiManager Class

10.1. Definition

public class RoiManager

- The **RoiManager** Class provides functionalities to manage objects by ROI type.
- Constructors

RoiManager	Initializes a new instance of the RoiManager class
-------------------	---

- Properties

SelectedItem	Selected ROI object
SelectedType	Selected ROI type

- Methods

Clear	Clear ROI object
MouseDown	Mouse down event handler
MouseMove	Mouse move event handler
MouseUp	Mouse up event handler

- Fields

Items	ROI object list
roiCount	ROI creation count up

10.2. Clear Method

public void Clear()

- Clear ROI object

10.3.MouseDown Method

```
public bool MouseDown(object sender, Point pt)
```

- Mouse down event handler
- Parameters

sender: event sender

pt: point coordinates

- Return Value

True if this method does successfully; otherwise, false if an exception is raised.

10.4.MouseMove Method

```
public bool MouseMove(object sender, Point pt)
```

- Mouse move event handler
- Parameters

sender: event sender

pt: point coordinates

- Return Value

True if this method does successfully; otherwise, false if an exception is raised.

10.5.MouseUp Method

```
public bool MouseUp(object sender, Point pt)
```

- Mouse up event handler
- Parameters

sender: event sender

pt: point coordinates

- Return Value

True if this method does successfully; otherwise, false if an exception is raised.

11.ThermoEngine.RoiObject Class

11.1.Definition

```
public class RoiObject
```

- The `RoiObject` Class provides functionalities to control objects by ROI type. The `RoiSpot`, `RoiLine`, `RoiRect`, `RoiEllipse`, `RoiPolygon` Classes are inherited from this `RoiObject` Class and provides functionalities for each type.
- Constructors

<code>RoiObject</code>	Initializes a new instance of the <code>RoiObject</code> class
------------------------	--

- Fields

<code>Index</code>	ROI object index
<code>RoiType</code>	ROI type, Hand=0 / Spot=1 / Line=2 / Rect=3 / Ellipse=4 / Polygon=5
<code>MinLoc</code>	Location for minimum temperature in ROI
<code>AvgLoc</code>	Location for average temperature in ROI
<code>MaxLoc</code>	Location for maximum temperature in ROI

12.ThermoEngine.RoiSpot Class

12.1.Definition

```
public class RoiSpot
```

- The `RoiSpot` Class is inherited from the `RoiObject` Class and provides functionalities to control Spot type ROI object.
- Constructors

<code>RoiSpot()</code>	Constructor of <code>RoiSpot</code>
<code>RoiSpot(int)</code>	Constructor of <code>RoiSpot</code> by object index
<code>RoiSpot(Point)</code>	Constructor of <code>RoiSpot</code> by point coordinates
<code>RoiSpot(int, int)</code>	Constructor of <code>RoiSpot</code> by x & y-coordinates
<code>RoiSpot(int, int, int)</code>	Constructor of <code>RoiSpot</code> by object index and x & y-coordinates

- Fields

<code>Spot</code>	Coordinates of Spot
-------------------	---------------------

13. ThermoEngine.RoiLine Class

13.1. Definition

```
public class RoiLine
```

- The RoiLine Class is inherited from the RoiObject Class and provides functionalities to control Line type ROI object.
- Constructors

RoiLine()	Constructor of RoiLine
RoiLine(int)	Constructor of RoiLine by object index
RoiLine(Point, Point)	Constructor of RoiLine by start & end point coordinates
RoiLine(int, int, int, int)	Constructor of RoiLine by start x & y-coordinates and end x & y-coordinates
RoiLine(int, int, int, int, int)	Constructor of RoiLine by object index and start x & y-coordinates and end x & y-coordinates

- Fields

Start	Start Coordinates of Line
Line	End Coordinates of Line

14. ThermoEngine.RoiRect Class

14.1. Definition

```
public class RoiRect
```

- The RoiRect Class is inherited from the RoiObject Class and provides functionalities to control Rectangular type ROI object.
- Constructors

RoiRect()	Constructor of RoiRect
RoiRect(int)	Constructor of RoiRect by object index
RoiRect(Rectangle)	Constructor of RoiRect by rectangle location and size
RoiRect(int, int, int, int)	Constructor of RoiRect by start x & y-coordinates and width & height
RoiRect(int, int, int, int, int)	Constructor of RoiRect by object index and start x & y-coordinates and width & height

- Fields

Rect	Location and size of Rectangle
------	--------------------------------

15.ThermoEngine.RoiEllipse Class

15.1.Definition

`public class RoiEllipse`

- The RoiEllipse Class is inherited from the RoiObject Class and provides functionalities to control Ellipse type ROI object.
- Constructors

RoiEllipse()	Constructor of RoiEllipse
RoiEllipse(int)	Constructor of RoiEllipse by object index
RoiEllipse(Rectangle)	Constructor of RoiEllipse by ellipse location and size
RoiEllipse(int, int, int, int)	Constructor of RoiEllipse by start x & y-coordinates and width & height
RoiEllipse(int, int, int, int, int)	Constructor of RoiEllipse by object index and start x & y-coordinates and width & height

- Fields

Ellipse	Location and size of Ellipse
---------	------------------------------

16.ThermoEngine.RoiPolygon Class

16.1.Definition

`public class RoiPolygon`

- The RoiPolygon Class is inherited from the RoiObject Class and provides functionalities to control Polygon type ROI object.
- Constructors

RoiPolygon()	Constructor of RoiPolygon
RoiPolygon(int)	Constructor of RoiPolygon by object index

- Properties

Item	Coordinates list
------	------------------

- Methods

Add	Add a point of polygon
Insert	Insert a point of polygon
Remove	Remove a point of polygon
RemoveAt	Remove a point by index of polygon

- Fields

Points	Coordinates list of Polygon
--------	-----------------------------

17.ThermoEngine.ICameraControl Interface

17.1.Definition

```
public interface ICameraControl
```

- The ICameraControl Interface provides functionalities to control the sensor of camera device.
- Each method requires the creation of an ICameraControl Interface instance and must call the Control Field as shown in the example below.

```
mCamera.Control.GetSensorModelName();
```

- Methods

GetProductModelName	Gets product model name of camera device
GetProductSerialNumber	Gets product serial number of camera device
GetHardwareVersion	Gets hardware version of camera device
GetBootloaderVersion	Gets bootloader version of camera device software
GetFirmwareVersion	Gets firmware version of camera device software
GetSystemStatus	Gets system status of camera device
GetSystemError	Gets system error of camera device
GetSensorModelName	Gets sensor model name of camera sensor
GetSensorSerialNumber	Gets sensor serial number of camera device
GetSensorUptime	Gets current uptime in milliseconds of camera sensor
ConvertRawToCelsius	Converts pixel raw value to Celsius value
ConvertRawToFahrenheit	Converts pixel raw value to Fahrenheit value
ConvertRawToKelvin	Converts pixel raw value to Kelvin value
GetNetworkConfiguration	Gets network configuration of camera device
SetNetworkConfiguration	Sets network configuration of camera device
SetDefaultNetworkConfiguration	Sets network configuration of camera device to

	factory default values
RebootDevice	Reboot camera device
CheckFirmware	Checks verification of firmware file and read firmware binary information
OpenFirmware	Opens firmware file to update new firmware of camera device
UpdateFirmware	Updates chunk data of firmware binary to camera device
CloseFirmware	Closes opened firmware file

17.2.GetProductModelName Method

```
public string GetProductModelName()
```

- Gets product model name of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.3.GetProductSerialNumber Method

```
public string GetProductSerialNumber()
```

- Gets product serial number of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.4.GetHardwareVersion Method

```
public string GetHardwareVersion()
```

- Gets hardware version of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.5.GetBootloaderVersion Method

`public string GetBootloaderVersion()`

- Gets bootloader version of camera device software
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.6.GetFirmwareVersion Method

`public string GetFirmwareVersion()`

- Gets firmware version of camera device software
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.7.GetSystemStatus Method

`public Tuple<ushort, string> GetSystemStatus()`

- Gets system status of camera device
- Return Value

Status code with message of SysStatus if this method gets status from device successfully; otherwise, 0xFFFF if an exception is raised.

17.8.GetSystemError Method

`public Tuple<ushort, string> GetSystemError()`

- Gets system error of camera device
- Return Value

Error code with message of SysError if this method gets status from device successfully; otherwise, 0xFFFF if an exception is raised.

17.9. GetSensorModelName Method

`public string GetSensorModelName()`

- Gets sensor model name of camera sensor
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.10. GetSensorSerialNumber Method

`public string GetSensorSerialNumber()`

- Gets sensor serial number of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.11. GetSensorUptime Method

`public string GetSensorUptime()`

- Gets current uptime in milliseconds of camera sensor
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.12. ConvertRawToCelsius Method

`public double ConvertRawToCelsius(double rawValue)`

- Converts raw value to Celsius value
- Parameters
 - `rawValue` raw value to be converted
- Return Value
 - Celsius value

17.13. ConvertRawToFahrenheit Method

```
public double ConvertRawToFahrenheit(double rawValue)
```

- Converts raw value to Fahrenheit value
- Parameters
rawValue raw value to be converted
- Return Value
Fahrenheit value

17.14. ConvertRawToKelvin Method

```
public double ConvertRawToKelvin(double rawValue)
```

- Converts raw value to Kelvin value
- Parameters
rawValue raw value to be converted
- Return Value
Kelvin value

17.15. GetNetworkConfiguration Method

```
public bool GetNetworkConfiguration(  
    out string mac, out string ipAssign, out string ip,  
    out string netmask, out string gateway, out string dns,  
    out string dns2  
)
```

- Gets network configuration of camera device
- Parameters
mac: obtained value for MAC address
ipAssign: obtained value for IP assignment, Static or DHCP
ip: obtained value for IP address, IPv4 only
netmask: obtained value for netmask address, IPv4 only
gateway: obtained value for gateway address, IPv4 only
dns: obtained value for main DNS address, IPv4 only

dns2: obtained value for sub DNS address, IPv4 only

- Return Value

True if this method gets values from device successfully; otherwise, false if an exception is raised.

17.16. SetNetworkConfiguration Method

```
public bool SetNetworkConfiguration(
    string ipAssign, string ip, string netmask,
    string gateway, string dns, string dns2
)
```

- Sets network configuration of camera device
- Parameters

ipAssign: value to be set for IP assignment, Static or DHCP

ip: value to be set for IP address, IPv4 only

netmask: value to be set for netmask address, IPv4 only

gateway: value to be set for gateway address, IPv4 only

dns: value to be set for main DNS address, IPv4 only

dns2: value to be set for sub DNS address, IPv4 only

- Return Value

True if this method sets values from device successfully; otherwise, false if an exception is raised.

17.17. SetDefaultNetworkConfiguration Method

```
public bool SetDefaultNetworkConfiguration(
    out string ipAssign, out string ip, out string netmask,
    out string gateway, out string dns, out string dns2
)
```

- Sets network configuration of camera device to factory default values
- Parameters

ipAssign: obtained default value for IP assignment, Static or DHCP

ip: obtained default value for IP address, IPv4 only

netmask: obtained default value for netmask address, IPv4 only

gateway: obtained default value for gateway address, IPv4 only

dns: obtained default value for main DNS address, IPv4 only

dns2: obtained default value for sub DNS address, IPv4 only

- Return Value

True if this method sets values from device successfully; otherwise, false if an exception is raised.

17.18. RebootDevice Method

```
public bool RebootDevice()
```

- Reboots camera device
- Return Value

True if camera device starts reboot successfully; otherwise, false if an exception is raised.

17.19. CheckFirmware Method

```
public bool CheckFirmware(
    string fwFilePath, out string vendorName, out string productName,
    out string versionName, out string buildTime, out int fileSize
)
```

- Checks verification of firmware file and read firmware binary information
- Parameters

fwFilePath: firmware file path to be loaded

vendorName: obtained vendor name

productName: obtained product name

versionName: obtained version name

buildTime: obtained build time

fileSize: obtained firmware binary size

- Return Value

True if the firmware file is suitable for update properly; otherwise, -1 if an exception is raised.

17.20. OpenFirmware Method

```
public int OpenFirmware(string fwFilePath)
```

- Opens firmware file to update new firmware of camera device
- Parameters

fwFilePath: firmware file path to be updated

- Return Value

Binary size if device opens a firmware file successfully; otherwise, -1 if an exception is raised.

17.21. UpdateFirmware Method

```
public int UpdateFirmware()
```

- Updates chunk data of firmware binary to camera device
- Return Value

Percentage value in progress if this method updates chunk data to device successfully; otherwise, -1 if an exception is raised.

17.22. CloseFirmware Method

```
public bool CloseFirmware()
```

- Closes opened firmware file
- Return Value

True if this method closes firmware file successfully; otherwise, false if an exception is raised.

- Remarks

Device will reboot automatically.