

Thermoeye Inc.



ThermoCam160E/256E

Camera Control SDK Manual

Contact help@thermoeye.co.kr
Technical Support <https://github.com/Thermoeye>

서울특별시 동작구 사당로 169, 5 층 (07003)

Revision

Version	Date	Contents
1.0	NOV.06.2023	ThermoCam160E/256E Manual에서 분리
1.1	NOV.14.2023	MatFrame, GetSystemStatus(), GetSystemError() 추가

목차

1.	ThermoCamSDK C# API.....	6
2.	ThermoEngine Namespace.....	6
2.1.	Classes	6
2.2.	Interfaces	6
2.3.	Structures	6
2.4.	Enumerations.....	6
3.	ThermoEngine.Camera Class.....	7
3.1.	Definition	7
3.2.	Open(LocalCamInfo) Method	8
3.3.	Open(RemoteCamInfo) Method.....	8
3.4.	Close Method.....	8
3.5.	QueryFrame Method.....	9
3.6.	GetTemperature Method	9
3.7.	Start Method.....	9
3.8.	Stop Method	10
3.9.	Dispose Method	10
3.10.	Control Field.....	10
4.	ThermoEngine.RemoteCamera Class.....	10
4.1.	Definition	10
4.2.	RemoteCamera Constructor	11
4.3.	GetCameraList Method.....	11
5.	ThermoEngine.LocalCamera Class.....	11
5.1.	Definition	11
5.2.	LocalCamera Constructor.....	11
5.3.	GetCameraList Method.....	11

6.	ThermoEngine.Frame Class.....	12
6.1.	Definition	12
6.2.	GetPixel(int, int) Method.....	12
6.3.	GetPixel(int, int, int, int) Method	13
6.4.	SetPixel(int, int, ushort) Method.....	13
6.5.	SetPixel(int, int, int, int, ushort) Method.....	13
6.6.	MinMaxLoc Method	14
6.7.	DoMeasure(RoiObject) Method.....	14
6.8.	DoMeasure(List<RoiObject>) Method.....	14
6.9.	ToBitmap Method.....	15
6.10.	Dispose Method	15
7.	ThermoEngine.CamInfo Class	15
7.1.	Definition	15
8.	ThermoEngine.RemoteCamInfo Class	15
8.1.	Definition	15
9.	ThermoEngine.LocalCamInfo Class.....	16
9.1.	Definition	16
10.	ThermoEngine.RoiManager Class	16
10.1.	Definition	16
10.2.	Clear Method	17
10.3.	MouseDown Method	17
10.4.	MouseMove Method	17
10.5.	MouseUp Method.....	18
11.	ThermoEngine.RoiObject Class.....	18
11.1.	Definition	18
12.	ThermoEngine.RoiSpot Class	18

12.1.	Definition	18
13.	ThermoEngine.RoiLine Class	19
13.1.	Definition	19
14.	ThermoEngine.RoiRect Class	19
14.1.	Definition	19
15.	ThermoEngine.RoiEllipse Class	20
15.1.	Definition	20
16.	ThermoEngine.RoiPolygon Class	20
16.1.	Definition	20
17.	ThermoEngine.ICameraControl Interface.....	21
17.1.	Definition	21
17.2.	GetProductModelName Method.....	22
17.3.	GetProductSerialNumber Method.....	22
17.4.	GetHardwareVersion Method	22
17.5.	GetBootloaderVersion Method.....	23
17.6.	GetFirmwareVersion Method	23
17.7.	GetSystemStatus Method	23
17.8.	GetSystemError Method	23
17.9.	GetSensorModelName Method	24
17.10.	GetSensorSerialNumber Method	24
17.11.	GetSensorUptime Method.....	24
17.12.	ConvertRawToCelsius Method.....	24
17.13.	ConvertRawToFahrenheit Method.....	25
17.14.	ConvertRawToKelvin Method.....	25
17.15.	GetNetworkConfiguration Method	25
17.16.	SetNetworkConfiguration Method	26

17.17.	SetDefaultNetworkConfiguration Method	26
17.18.	RebootDevice Method.....	27
17.19.	OpenFirmware Method.....	27
17.20.	UpdateFirmware Method	27
17.21.	CloseFirmware Method.....	28

1. ThermoCamSDK C# API

카메라 장치의 기능 제어를 위한 API를 제공합니다.

Sample project는 Microsoft Visual Studio Community 2022에서 생성되었으며, Windows .NET Framework 4.8 기준으로 구현되었습니다.

2. ThermoEngine Namespace

2.1. Classes

Camera	Abstract class for camera control
RemoteCamera	Inheritance class for remote camera control
LocalCamera	Inheritance class for local camera control
Frame	Class for Frame control
CamInfo	Abstract class for camera information store
RemoteCamInfo	Inheritance class for remote camera information store
LocalCamInfo	Inheritance class for local camera information store
CameraStatus	Camera device system status class
RoiManager	Class for ROI management
RoiObject	Abstract class for ROI object
RoiSpot	Inheritance class for Spot type ROI
RoiLine	Inheritance class for Line type ROI
RoiRect	Inheritance class for Rectangle type ROI
RoiEllipse	Inheritance class for Ellipse type ROI
RoiPolygon	Inheritance class for Polygon type ROI

2.2. Interfaces

ICameraControl	Interface for camera sensor control
--------------------------------	-------------------------------------

2.3. Structures

LocItem	ROI location and temperature value
---------	------------------------------------

2.4. Enumerations

SysStatusCode	Camera device system status code
SysErrorCode	Camera device system error code
RoiType	ROI types
TempUnit	Temperature unit type

3. ThermoEngine.Camera Class

3.1. Definition

```
public class Camera : IDisposable
```

- Remote (Ethernet Network) 및 Local (USB) 카메라를 구동하고 제어하기 위한 기능을 제공하는 ThermoEngine의 Main Class입니다. RemoteCamera 및 LocalCamera Class는 이 Camera Class를 상속받아 각 연결 규격에 따른 기능을 제공합니다.

- Derived Class

```
public class RemoteCamera : Camera
```

```
public class LocalCamera : Camera
```

- Properties

Name	Product Name
Width	Frame width
Height	Frame height
FPS	Frame rate, Frames per second
IsOpen	State of video streaming, true=play / false=stop
ColorMap	Color Map, 0=Grayscale / 1=Autumn / 2=Bone / 3=Jet / 4=Winter / 5=Rainbow / 6=Ocean / 7=Summer / 8=Spring / 9=Cool / 10=Hsv / 11=Pink / 12=Hot / 13=Parula / 14=Magma / 15=Inferno / 16=Plasma / 17=Viridis / 18=Cividis / 19=Twilight / 20=TwilightShifted
TempUnit	Temperature unit type, 0=Raw / 1=Celsius / 2=Fahrenheit / 3=Kelvin
TempUnitSymbol	Temperature unit symbol

- Methods

Open(LocalCamInfo)	Opens local camera device connection via USB UVC and CDC
Open(RemoteCamInfo)	Opens remote camera device connection via Ethernet RTSP and RTP
Close	Closes camera device connection
QueryFrame	Queries a resized frame
GetTemperature	Get converted temperature by temperature unit
Start	Starts camera video streaming
Stop	Stops camera video streaming
Dispose	Cleans up resources being used

- Fields

Control	Prepares camera control interface.
-------------------------	------------------------------------

3.2. Open(LocalCamInfo) Method

```
public bool Open(LocalCamInfo camInfo)
```

- Opens local camera device connection via USB UVC and CDC
- Parameters

camInfo: device information to be connected via USB

- Return Value

True if this method opens camera connection successfully; otherwise, false if an exception is raised.

3.3. Open(RemoteCamInfo) Method

```
public bool Open(RemoteCamInfo camInfo)
```

- Opens remote camera device connection via Ethernet RTSP and RTP
- Parameters

camInfo: device information to be connected via Ethernet

- Return Value

True if this method opens camera connection successfully; otherwise, false if an exception is raised.

3.4. Close Method

```
public bool Close()
```

- Closes camera device connection
- Return Value

True if this method closes camera connection successfully; otherwise, false if an exception is raised.

3.5. QueryFrame Method

```
public Frame QueryFrame(int width, int height)
```

- Queries a resized frame
- Parameters

width: desired width

height: desired height

- Return Value

Frame object if this method gets a captured frame successfully; otherwise, null if an exception is raised.

- Remarks

If you want to get the original frame object, just call method without parameters as below:

```
var frame = mCamera.QueryFrame();
```

3.6. GetTemperature Method

```
public double GetTemperature(double raw)
```

- Get converted temperature by temperature unit
- Parameters

raw: raw value to be converted

- Return Value

Converted temperature value

3.7. Start Method

```
public bool Start()
```

- Starts camera video streaming
- Return Value

True if this method starts camera video streaming successfully; otherwise, false if an exception is raised.

3.8. Stop Method

```
public bool Stop()
```

- Stops camera video streaming
- Return Value

True if this method stops camera video streaming successfully; otherwise, false if an exception is raised.

3.9. Dispose Method

```
public void Dispose()
```

- Cleans up resources being used

3.10. Control Field

```
public ICameraControl Control
```

- Prepares camera control interface
- Must use this field to call camera control methods as below:

```
mCamera.Control.GetSensorModelName();
```

4. ThermoEngine.RemoteCamera Class

4.1. Definition

```
public class RemoteCamera : Camera
```

- Camera Class를 상속받아 Remote (Ethernet Network) 카메라를 구동하고 제어하기 위한 기능을 제공하는 Class입니다.

- Constructors

RemoteCamera	Initializes a new instance of the RemoteCamera class
------------------------------	--

- Additional Methods

GetCameraList	Gets remote camera list
-------------------------------	-------------------------

4.2. RemoteCamera Constructor

```
public RemoteCamera()
```

- Initializes a new instance of the RemoteCamera class

4.3. GetCameraList Method

```
static public RemoteCamInfo[] GetCameraList()
```

- Gets remote camera list
- Return Value

Camera information list if this method gets connectable camera information successfully; otherwise, false if an exception is raised.

5. ThermoEngine.LocalCamera Class

5.1. Definition

```
public class LocalCamera : Camera
```

- Camera Class를 상속받아 Local (USB) 카메라를 구동하고 제어하기 위한 기능을 제공하는 Class입니다.
- Constructors

LocalCamera	Initializes a new instance of the LocalCamera class
-----------------------------	---

- Additional Methods

GetCameraList	Gets local camera list
-------------------------------	------------------------

5.2. LocalCamera Constructor

```
public LocalCamera()
```

- Initializes a new instance of the LocalCamera class

5.3. GetCameraList Method

```
static public LocalCamInfo[] GetCameraList()
```

- Gets local camera list

- Return Value

Camera information list if this method gets connectable camera information successfully; otherwise, false if an exception is raised.

6. ThermoEngine.Frame Class

6.1. Definition

```
public class Frame : IDisposable
```

- 캡처된 한 프레임 데이터 오브젝트를 비트맵 이미지 오브젝트로 변환하는 기능을 제공합니다.
- Methods

GetPixel(int, int)	Gets pixel data in frame
GetPixel(int, int, int, int)	Gets area pixel data in frame
SetPixel(int, int, ushort)	Sets raw data into frame
SetPixel(int, int, int, int, ushort)	Sets raw data into area in frame
MinMaxLoc	Gets minimum, maximum and average values and locations
DoMeasure(RoiObject)	Measures location and temperature by ROI
DoMeasure(List<RoiObject>)	Measures location and temperature by ROI list
ToBitmap	Converts a captured frame to Bitmap image object
Dispose	Releases all resources used by the Frame

- Fields

MatFrame	Mat array for a captured frame
--------------------------	--------------------------------

6.2. GetPixel(int, int) Method

```
public double GetPixel(int x, int y)
```

- Gets pixel data in frame
- Parameters
 - x: x position
 - y: y position
- Return Value
 - pixel data value

6.3. GetPixel(int, int, int, int) Method

```
public double[,] GetPixel(int x, int y, int width, int height)
```

- Gets area pixel data in frame
- Parameters
 - x: x position
 - y: y position
 - width: width
 - height: height
- Return Value
 - pixel data values

6.4. SetPixel(int, int, ushort) Method

```
public bool SetPixel(int x, int y, ushort value)
```

- Sets pixel data into frame
- Parameters
 - x: x position
 - y: y position
 - value: raw value
- Return Value
 - True if this method set value successfully; otherwise, false if an exception is raised.

6.5. SetPixel(int, int, int, int, ushort) Method

```
public bool SetPixel(int x, int y, int width, int height, ushort value)
```

- Sets pixel data into area in frame
- Parameters
 - x: x position
 - y: y position
 - width: width

height: height

value: raw value

- Return Value

True if this method set value successfully; otherwise, false if an exception is raised.

6.6. MinMaxLoc Method

```
public void MinMaxLoc(out double minVal,  
                     out double avgVal,  
                     out double maxVal,  
                     out System.Drawing.Point minLoc,  
                     out System.Drawing.Point maxLoc)
```

- Gets minimum, maximum and average values and locations
- Parameters

minVal: minimum value

avgVal: average value

maxVal: maximum value

minLoc: minimum location

maxLoc: maximum location

6.7. DoMeasure(RoiObject) Method

```
public void DoMeasure(ref RoiObject item)
```

- Measures location and temperature by ROI
- Parameters

item: measured ROI object

6.8. DoMeasure(List<RoiObject>) Method

```
public void DoMeasure(ref List<RoiObject> items)
```

- Measures location and temperature by ROI list
- Parameters

item: measured ROI objects list

6.9. ToBitmap Method

```
public Bitmap ToBitmap(int width, int height)
```

- Converts a captured frame to Bitmap image object
- Parameters

width: width size to be resized

height: height size to be resized

- Return Value

Bitmap image object if this method converts a frame successfully; otherwise, null if an exception is raised.

6.10. Dispose Method

```
public void Dispose()
```

- Releases all resources used by the Frame

7. ThermoEngine.CamInfo Class

7.1. Definition

```
public class CamInfo
```

- 연결된 Remote (Ethernet Network) 및 Local (USB) 카메라 정보의 저장을 위한 추상화 Class입니다. RemoteCamInfo 및 LocalCamInfo Class는 이 CamInfo Class를 상속받아 각 정보를 저장합니다.
- Derived Class :

```
public class RemoteCamInfo : CamInfo
```

```
public class LocalCamInfo : CamInfo
```

8. ThermoEngine.RemoteCamInfo Class

8.1. Definition

```
public class RemoteCamInfo : CamInfo
```

- CamInfo Class를 상속받아 연결된 Remote (Ethernet Network) 카메라 정보의 저장을 위한 Class입니다.

- Constructors

RemoteCamInfo	Initializes a new instance of the RemoteCamInfo class
----------------------	--

- Fields

Name	Camera device name
SerialNumber	Product serial number
AddrMAC	MAC address
AddrIP	IP address

9. ThermoEngine.LocalCamInfo Class

9.1. Definition

```
public class LocalCamInfo : CamInfo
```

- CamInfo Class를 상속받아 연결된 Local (USB) 카메라 정보의 저장을 위한 Class입니다.
- Constructors

LocalCamInfo	Initializes a new instance of the LocalCamInfo class
---------------------	---

- Fields

Index	Camera index
Name	Camera device name
ComPort	Serial port name

10. ThermoEngine.RoiManager Class

10.1. Definition

```
public class RoiManager
```

- ROI type별 object를 관리하는 기능을 제공합니다.
- Constructors

RoiManager	Initializes a new instance of the RoiManager class
-------------------	---

- Properties

SelectedItem	Selected ROI object
SelectedType	Selected ROI type

- Methods

Clear	Clear ROI object
MouseDown	Mouse down event handler
MouseMove	Mouse move event handler
MouseUp	Mouse up event handler

- Fields

Items	ROI object list
-------	-----------------

10.2.Clear Method

```
public void Clear()
```

- Clear ROI object

10.3.MouseDown Method

```
public bool MouseDown(object sender, Point pt)
```

- Mouse down event handler
- Parameters

sender: event sender

pt: point coordinates

- Return Value

True if this method does successfully; otherwise, false if an exception is raised.

10.4.MouseMove Method

```
public bool MouseMove(object sender, Point pt)
```

- Mouse move event handler
- Parameters

sender: event sender

pt: point coordinates

- Return Value

True if this method does successfully; otherwise, false if an exception is raised.

10.5.MouseUp Method

```
public bool MouseUp(object sender, Point pt)
```

- Mouse up event handler
- Parameters

sender: event sender

pt: point coordinates

- Return Value

True if this method does successfully; otherwise, false if an exception is raised.

11.ThermoEngine.RoiObject Class

11.1.Definition

```
public class RoiObject
```

- ROI type별 object를 제어하기 위한 기능을 제공하는 Class입니다. RoiSpot, RoiLine, RoiRect, RoiEllipse, RoiPolygon Class는 이 RoiObject Class를 상속받아 각 type에 따른 기능을 제공합니다.
- Constructors

RoiObject	Initializes a new instance of the RoiObject class
-----------	---

- Fields

Index	ROI object index
RoiType	ROI type, Hand=0 / Spot=1 / Line=2 / Rect=3 / Ellipse=4 / Polygon=5
MinLoc	Location for minimum temperature in ROI
AvgLoc	Location for average temperature in ROI
MaxLoc	Location for maximum temperature in ROI

12.ThermoEngine.RoiSpot Class

12.1.Definition

```
public class RoiSpot
```

- RoiObject Class를 상속받아 Spot type ROI object를 제어하기 위한 기능을 제공하는 Class입니다.
- Constructors

RoiSpot()	Constructor of RoiSpot
RoiSpot(int)	Constructor of RoiSpot by object index
RoiSpot(Point)	Constructor of RoiSpot by point coordinates
RoiSpot(int, int)	Constructor of RoiSpot by x & y-coordinates

- Fields

Spot	Coordinates of Spot
------	---------------------

13.ThermoEngine.RoiLine Class

13.1.Definition

```
public class RoiLine
```

- RoiObject Class를 상속받아 Line type ROI object를 제어하기 위한 기능을 제공하는 Class입니다.
- Constructors

RoiLine()	Constructor of RoiLine
RoiLine(int)	Constructor of RoiLine by object index
RoiLine(Point, Point)	Constructor of RoiLine by start & end point coordinates
RoiLine(int, int, int, int)	Constructor of RoiLine by start x & y-coordinates and end x & y-coordinates

- Fields

Start	Start Coordinates of Line
Line	End Coordinates of Line

14.ThermoEngine.RoiRect Class

14.1.Definition

```
public class RoiRect
```

- RoiObject Class를 상속받아 Rectangle type ROI object를 제어하기 위한 기능을 제공하는 Class입니다.
- Constructors

<code>RoiRect()</code>	Constructor of <code>RoiRect</code>
<code>RoiRect(int)</code>	Constructor of <code>RoiRect</code> by object index
<code>RoiRect(Rectangle)</code>	Constructor of <code>RoiRect</code> by rectangle location and size
<code>RoiRect(int, int, int, int)</code>	Constructor of <code>RoiRect</code> by start x & y-coordinates and width & height

- Fields

<code>Rect</code>	Location and size of Rectangle
-------------------	--------------------------------

15. ThermoEngine.RoiEllipse Class

15.1. Definition

`public class RoiEllipse`

- `RoiObject` Class를 상속받아 Ellipse type ROI object를 제어하기 위한 기능을 제공하는 Class입니다.
- Constructors

<code>RoiEllipse()</code>	Constructor of <code>RoiEllipse</code>
<code>RoiEllipse(int)</code>	Constructor of <code>RoiEllipse</code> by object index
<code>RoiEllipse(Rectangle)</code>	Constructor of <code>RoiEllipse</code> by ellipse location and size
<code>RoiEllipse(int, int, int, int)</code>	Constructor of <code>RoiEllipse</code> by start x & y-coordinates and width & height

- Fields

<code>Ellipse</code>	Location and size of Ellipse
----------------------	------------------------------

16. ThermoEngine.RoiPolygon Class

16.1. Definition

`public class RoiPolygon`

- `RoiObject` Class를 상속받아 Polygon type ROI object를 제어하기 위한 기능을 제공하는 Class입니다.
- Constructors

<code>RoiPolygon()</code>	Constructor of <code>RoiPolygon</code>
<code>RoiPolygon(int)</code>	Constructor of <code>RoiPolygon</code> by object index

- Properties

Item	Coordinates list
------	------------------

- Methods

Add	Add a point of polygon
Insert	Insert a point of polygon
Remove	Remove a point of polygon
RemoveAt	Remove a point by index of polygon

- Fields

Points	Coordinates list of Polygon
--------	-----------------------------

17.ThermoEngine.ICameraControl Interface

17.1.Definition

```
public interface ICameraControl
```

- 카메라 장치를 제어하기 위한 기능을 제공합니다.
- 각 Method를 사용하기 위해서는 ICameraControl Interface instance 생성이 필요하며, 아래 예시와 같이 Control Field를 호출해야 합니다.

```
mCamera.Control.GetSensorModelName();
```

- Methods

GetProductModelName	Gets product model name of camera device
GetProductSerialNumber	Gets product serial number of camera device
GetHardwareVersion	Gets hardware version of camera device
GetBootloaderVersion	Gets bootloader version of camera device software
GetFirmwareVersion	Gets firmware version of camera device software
GetSystemStatus	Gets system status of camera device
GetSystemError	Gets system error of camera device
GetSensorModelName	Gets sensor model name of camera sensor
GetSensorSerialNumber	Gets sensor serial number of camera device
GetSensorUptime	Gets current uptime in milliseconds of camera sensor
ConvertRawToCelsius	Converts pixel raw value to Celsius value

ConvertRawToFahrenheit	Converts pixel raw value to Fahrenheit value
ConvertRawToKelvin	Converts pixel raw value to Kelvin value
GetNetworkConfiguration	Gets network configuration of camera device
SetNetworkConfiguration	Sets network configuration of camera device
SetDefaultNetworkConfiguration	Sets network configuration of camera device to factory default values
RebootDevice	Reboot camera device
OpenFirmware	Opens firmware file to update new firmware of camera device
UpdateFirmware	Updates chunk data of firmware binary to camera device
CloseFirmware	Closes opened firmware file

17.2.GetProductModelName Method

```
public string GetProductModelName()
```

- Gets product model name of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.3.GetProductSerialNumber Method

```
public string GetProductSerialNumber()
```

- Gets product serial number of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.4.GetHardwareVersion Method

```
public string GetHardwareVersion()
```

- Gets hardware version of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.5.GetBootloaderVersion Method

`public string GetBootloaderVersion()`

- Gets bootloader version of camera device software
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.6.GetFirmwareVersion Method

`public string GetFirmwareVersion()`

- Gets firmware version of camera device software
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.7.GetSystemStatus Method

`public Tuple<ushort, string> GetSystemStatus()`

- Gets system status of camera device
- Return Value

Status code with message of SysStatus if this method gets status from device successfully; otherwise, 0xFFFF if an exception is raised.

17.8.GetSystemError Method

`public Tuple<ushort, string> GetSystemError()`

- Gets system error of camera device
- Return Value

Error code with message of SysError if this method gets status from device successfully; otherwise, 0xFFFF if an exception is raised.

17.9. GetSensorModelName Method

`public string GetSensorModelName()`

- Gets sensor model name of camera sensor
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.10. GetSensorSerialNumber Method

`public string GetSensorSerialNumber()`

- Gets sensor serial number of camera device
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.11. GetSensorUptime Method

`public string GetSensorUptime()`

- Gets current uptime in milliseconds of camera sensor
- Return Value

Text string if this method gets value from device successfully; otherwise, null if an exception is raised.

17.12. ConvertRawToCelsius Method

`public double ConvertRawToCelsius(double rawValue)`

- Converts raw value to Celsius value
- Parameters
 - `rawValue` raw value to be converted
- Return Value
 - Celsius value

17.13. ConvertRawToFahrenheit Method

```
public double ConvertRawToFahrenheit(double rawValue)
```

- Converts raw value to Fahrenheit value
- Parameters
 - rawValue raw value to be converted
- Return Value
 - Fahrenheit value

17.14. ConvertRawToKelvin Method

```
public double ConvertRawToKelvin(double rawValue)
```

- Converts raw value to Kelvin value
- Parameters
 - rawValue raw value to be converted
- Return Value
 - Kelvin value

17.15. GetNetworkConfiguration Method

```
public bool GetNetworkConfiguration(  
    out string mac, out string ipAssign, out string ip,  
    out string netmask, out string gateway, out string dns,  
    out string dns2  
)
```

- Gets network configuration of camera device
- Parameters
 - mac: obtained value for MAC address
 - ipAssign: obtained value for IP assignment, Static or DHCP
 - ip: obtained value for IP address, IPv4 only
 - netmask: obtained value for netmask address, IPv4 only
 - gateway: obtained value for gateway address, IPv4 only
 - dns: obtained value for main DNS address, IPv4 only

dns2: obtained value for sub DNS address, IPv4 only

- Return Value

True if this method gets values from device successfully; otherwise, false if an exception is raised.

17.16. SetNetworkConfiguration Method

```
public bool SetNetworkConfiguration(
    string ipAssign, string ip, string netmask,
    string gateway, string dns, string dns2
)
```

- Sets network configuration of camera device
- Parameters

ipAssign: value to be set for IP assignment, Static or DHCP

ip: value to be set for IP address, IPv4 only

netmask: value to be set for netmask address, IPv4 only

gateway: value to be set for gateway address, IPv4 only

dns: value to be set for main DNS address, IPv4 only

dns2: value to be set for sub DNS address, IPv4 only

- Return Value

True if this method sets values from device successfully; otherwise, false if an exception is raised.

17.17. SetDefaultNetworkConfiguration Method

```
public bool SetDefaultNetworkConfiguration(
    out string ipAssign, out string ip, out string netmask,
    out string gateway, out string dns, out string dns2
)
```

- Sets network configuration of camera device to factory default values
- Parameters

ipAssign: obtained default value for IP assignment, Static or DHCP

ip: obtained default value for IP address, IPv4 only

netmask: obtained default value for netmask address, IPv4 only

gateway: obtained default value for gateway address, IPv4 only

dns: obtained default value for main DNS address, IPv4 only

dns2: obtained default value for sub DNS address, IPv4 only

- Return Value

True if this method sets values from device successfully; otherwise, false if an exception is raised.

17.18. RebootDevice Method

```
public bool RebootDevice()
```

- Reboots camera device
- Return Value

True if camera device starts reboot successfully; otherwise, false if an exception is raised.

17.19. OpenFirmware Method

```
public int OpenFirmware(string fwFilePath)
```

- Opens firmware file to update new firmware of camera device
- Parameters

fwFilePath: firmware file path to be updated

- Return Value

Binary size if device opens a firmware file successfully; otherwise, -1 if an exception is raised.

17.20. UpdateFirmware Method

```
public int UpdateFirmware()
```

- Updates chunk data of firmware binary to camera device
- Return Value

Percentage value in progress if this method updates chunk data to device successfully; otherwise, -1 if an exception is raised.

17.21. CloseFirmware Method

```
public bool CloseFirmware()
```

- Closes opened firmware file
- Return Value

True if this method closes firmware file successfully; otherwise, false if an exception is raised.

- Remarks

Device will reboot automatically.