



Replace a Cisco Nexus 3232C storage switch

ONTAP Systems Switches

NetApp
March 11, 2022

This PDF was generated from <https://docs.netapp.com/us-en/ontap-systems-switches/switch-cisco-3232c/task-steps-to-replace-a-cisco-nexus-3232c-storage-switch.html> on March 11, 2022. Always check docs.netapp.com for the latest.

Table of Contents

Replace a Cisco Nexus 3232C storage switch	1
Steps to replace a Cisco Nexus 3232C storage switch	1

Replace a Cisco Nexus 3232C storage switch

You must be aware of certain configuration information, port connections and cabling requirements when you replace Cisco Nexus 3232C storage switches.

You must verify the following conditions exist before installing the NX-OS software and RCFs on a Cisco Nexus storage switch:

- Your system can support Cisco Nexus 3232C storage switches.
- You must have consulted the switch compatibility table on the Cisco Ethernet Switch page for the supported ONTAP, NX-OS, and RCF versions.



You should be aware there can be dependencies between command syntax in the RCF and NX-OS versions.

- You must have referred to the appropriate software and upgrade guides available on the Cisco web site for complete documentation on the Cisco switch upgrade and downgrade procedures at [Cisco Nexus 3000 Series Switches](#).
- You must have downloaded the applicable RCFs.

Steps to replace a Cisco Nexus 3232C storage switch

You can nondisruptively replace a defective Cisco Nexus 3232C storage switch by performing a specific sequence of tasks.

Before you begin

The existing network configuration must have the following characteristics:

- The Cisco Ethernet Switches page has the latest RCF and NX-OS versions on your switches.
- Management connectivity must exist on both switches.



Make sure that all troubleshooting steps have been completed to confirm that your switch needs replacing.

The replacement Cisco Nexus 3232C switch must have the following characteristics:

- Management network connectivity must be functional.
- Console access to the replacement switch must be in place.
- The appropriate RCF and NX-OS operating system image must be loaded onto the switch.
- Initial customization of the switch must be complete.

Procedure summary:

- **Confirm the switch to be replaced is S2 (Steps 1-5)**
- **Disconnect the cables from switch S2 (Step 6)**
- **Reconnect the cables to switch NS2 (Step 7)**

- **Verify all device configurations on switch NS2 (Steps 8-10)**
- This procedure replaces the second Nexus 3232C storage switch S2 with the new 3232C switch NS2.
- The two nodes are node1 and node2.

Steps

1. If AutoSupport is enabled on this cluster, suppress automatic case creation by invoking an AutoSupport message: `system node autosupport invoke -node * -type all - message MAINT=xh`

x is the duration of the maintenance window in hours.



The AutoSupport message notifies technical support of this maintenance task so that automatic case creation is suppressed during the maintenance window.

2. Check on the health status of the storage node ports to make sure that there is connection to storage switch S1: `storage port show -port-type ENET`

```
storage::*> storage port show -port-type ENET
```

Node	Port	Type	Mode	Speed (Gb/s)	State	Status	VLAN ID
node1	e3a	ENET	storage	100	enabled	online	30
	e3b	ENET	storage	0	enabled	offline	30
	e7a	ENET	storage	0	enabled	offline	30
	e7b	ENET	storage	0	enabled	offline	30
node2	e3a	ENET	storage	100	enabled	online	30
	e3b	ENET	storage	0	enabled	offline	30
	e7a	ENET	storage	0	enabled	offline	30
	e7b	ENET	storage	0	enabled	offline	30

3. Verify that storage switch S1 is available: `network device-discovery show`

```

storage::*> network device-discovery show
Node/      Local  Discovered
Protocol   Port   Device (LLDP: ChassisID)  Interface      Platform
-----
node1/cdp
           e3a    S1                      Ethernet1/1     NX3232C
           e4a    node2                   e4a             AFF-A700
           e4e    node2                   e4e             AFF-A700
node1/lldp
           e3a    S1                      Ethernet1/1     -
           e4a    node2                   e4a             -
           e4e    node2                   e4e             -
node2/cdp
           e3a    S1                      Ethernet1/2     NX3232C
           e4a    node1                   e4a             AFF-A700
           e4e    node1                   e4e             AFF-A700
node2/lldp
           e3a    S1                      Ethernet1/2     -
           e4a    node1                   e4a             -
           e4e    node1                   e4e             -

```

4. Run the `show lldp neighbors` command on the working switch to confirm that you can see both nodes and all shelves: `show lldp neighbors`

```

S1# show lldp neighbors
Capability codes:
  (R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
  (W) WLAN Access Point, (P) Repeater, (S) Station, (O) Other
Device ID           Local Intf      Hold-time  Capability  Port ID
node1                Eth1/1         121        S           e3a
node2                Eth1/2         121        S           e3a
SHFGD2008000011     Eth1/5         121        S           e0a
SHFGD2008000011     Eth1/6         120        S           e0a
SHFGD2008000022     Eth1/7         120        S           e0a
SHFGD2008000022     Eth1/8         120        S           e0a

```

5. Verify the shelf ports in the storage system: `storage shelf port show -fields remote-device,remote-port`

```
storage::*> storage shelf port show -fields remote-device,remote-port
```

shelf	id	remote-port	remote-device
-----	--	-----	-----
3.20	0	Ethernet1/5	S1
3.20	1	-	-
3.20	2	Ethernet1/6	S1
3.20	3	-	-
3.30	0	Ethernet1/7	S1
3.20	1	-	-
3.30	2	Ethernet1/8	S1
3.20	3	-	-

6. Remove all cables attached to storage switch S2.
7. Reconnect all cables to the replacement switch NS2.
8. Recheck the health status of the storage node ports: `storage port show -port-type ENET`

```
storage::*> storage port show -port-type ENET
```

Node	Port	Type	Mode	Speed (Gb/s)	State	Status	VLAN ID
-----	----	-----	-----	-----	-----	-----	----
node1							
	e3a	ENET	storage	100	enabled	online	30
	e3b	ENET	storage	0	enabled	offline	30
	e7a	ENET	storage	0	enabled	offline	30
	e7b	ENET	storage	100	enabled	online	30
node2							
	e3a	ENET	storage	100	enabled	online	30
	e3b	ENET	storage	0	enabled	offline	30
	e7a	ENET	storage	0	enabled	offline	30
	e7b	ENET	storage	100	enabled	online	30

9. Verify that both switches are available: `network device-discovery show`

```

storage::*> network device-discovery show
Node/      Local  Discovered
Protocol   Port   Device (LLDP: ChassisID)  Interface      Platform
-----
node1/cdp
           e3a    S1                      Ethernet1/1     NX3232C
           e4a    node2                   e4a             AFF-A700
           e4e    node2                   e4e             AFF-A700
           e7b    NS2                     Ethernet1/1     NX3232C
node1/lldp
           e3a    S1                      Ethernet1/1     -
           e4a    node2                   e4a             -
           e4e    node2                   e4e             -
           e7b    NS2                     Ethernet1/1     -
node2/cdp
           e3a    S1                      Ethernet1/2     NX3232C
           e4a    node1                   e4a             AFF-A700
           e4e    node1                   e4e             AFF-A700
           e7b    NS2                     Ethernet1/2     NX3232C
node2/lldp
           e3a    S1                      Ethernet1/2     -
           e4a    node1                   e4a             -
           e4e    node1                   e4e             -
           e7b    NS2                     Ethernet1/2     -

```

10. Verify the shelf ports in the storage system: `storage shelf port show -fields remote-device,remote-port`

```

storage::*> storage shelf port show -fields remote-device,remote-port
shelf id remote-port remote-device
-----
3.20  0  Ethernet1/5 S1
3.20  1  Ethernet1/5 NS2
3.20  2  Ethernet1/6 S1
3.20  3  Ethernet1/6 NS2
3.30  0  Ethernet1/7 S1
3.20  1  Ethernet1/7 NS2
3.30  2  Ethernet1/8 S1
3.20  3  Ethernet1/8 NS2

```

11. If you suppressed automatic case creation, re-enable it by invoking an AutoSupport message: `system node autosupport invoke -node * -type all -message MAINT=END`

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.