

密级状态： 绝密( ) 秘密( ) 内部资料( ) 公开( √ )  
Security Class: Top-Secret ( ) Secret ( ) Internal ( ) Public ( √ )

# Rockchip\_Android\_AB 系统使用说明文档

## Rockchip\_Android\_AB\_System\_Usage\_Introduction

(第二系统产品部)

(Technical Department, R & D Dept. II)

<b>文件状态:</b> <b>Status:</b> [ ] 草稿 [ ] Draft [ ] 正在修改 [ ] Modifying [√] 正式发布 [√] Released	<b>文件标识:</b> <b>File No.:</b>	RK-SM-YF-208
	<b>当前版本:</b> <b>Current Version:</b>	V1.6
	<b>作 者:</b> <b>Author:</b>	纪大晓 Ji Dayao
	<b>完成日期:</b> <b>Finish Date:</b>	2019-12-13
	<b>审 核:</b> <b>Auditor:</b>	
	<b>审核日期:</b> <b>Finish Date:</b>	

---

## 免责声明

本文档按“现状”提供，福州瑞芯微电子股份有限公司（“本公司”，下同）不对本文档的任何陈述、信息和内容的准确性、可靠性、完整性、适销性、特定目的性和非侵权性提供任何明示或暗示的声明或保证。本文档仅作为使用指导的参考。

由于产品版本升级或其他原因，本文档将可能在未经任何通知的情况下，不定期进行更新或修改。

## Disclaimer

This document is provided “as is” and Fuzhou Rockchip Electronics Co. Ltd (“the company”) makes no express or implied statement or warranty as to the accuracy, reliability, completeness, merchantability, specific purpose and non-infringement of any statement, information and contents of the document. This document is for reference only.

This document may be updated without any notification due to product version upgrades or other reasons.

## 商标声明

“Rockchip”、“瑞芯微”、“瑞芯”均为本公司的注册商标，归本公司所有。

本文档可能提及的其他所有注册商标或商标，由其各自所有者所有。

## Brand Statement

Rockchip, Rockchip<sup>TM</sup> icon, Rockchip and other Rockchip trademarks are trademarks of Fuzhou Rockchip Electronics Co., Ltd., and are owned by Fuzhou Rockchip Electronics Co., Ltd.

All other trademarks or registered trademarks mentioned in this document are owned by their respective owners.

## 版权所有 © 2019 福州瑞芯微电子股份有限公司

超越合理使用范畴，非经本公司书面许可，任何单位和个人不得擅自摘抄、复制本文档内容的部分或全部，并不得以任何形式传播。

## Copyright © 2019 Fuzhou Rockchip Electronics Co., Ltd.

Beyond reasonable use, without the written permission, any unit or individual shall not extract or copy part or all of the content of this document, and shall not spread in any form.

福州瑞芯微电子股份有限公司

Fuzhou Rockchip Electronics Co., Ltd.

地址：福建省福州市铜盘路软件园 A 区 18 号

网址：[www.rock-chips.com](http://www.rock-chips.com)

客户服务电话：+86-4007-700-590

客户服务传真：+86-591-83951833

客户服务邮箱：[fae@rock-chips.com](mailto:fae@rock-chips.com)

Fuzhou Rockchip Electronics Co., Ltd.

Address: No. 18 Building, A District, No.89,software Boulevard Fuzhou,Fujian,PRC

Website: [www.rock-chips.com](http://www.rock-chips.com)

Customer service tel.: +86-4007-700-590

Customer service fax: +86-591-83951833

Customer service e-mail: [fae@rock-chips.com](mailto:fae@rock-chips.com)

## 版本历史 Revision History

版本号 Version no.	作者 Author	修改日期 Revision Date	修改说明 Revision description	备注 Remark
V1.0	纪大峤 Ji Dayao	2018/8/1	初始版本 Initial version release	
V1.1	纪大峤 Ji Dayao	2018/8/2	增加 2.4 节烧写工具说明 Add flashing tool instruction in Chapter2.4	
V1.2	纪大峤 Ji Dayao	2018/9/10	Android 9.0 补充说明 Supplementary description for Android 9.0	
V1.3	纪大峤 Ji Dayao	2019/3/29	文档重构 Document restruction	
V1.4	纪大峤 Ji Dayao	2019/4/17	更新“4.验证方法” Update chapter 4	
V1.5	纪大峤 Ji Dayao	2019/11/19	添加 Android 10 配置说明 Add Android10.0 configuration instruction	
V1.6	纪大峤 Ji Dayao	2019/12/13	补充 DEVICE_MANIFEST_FILE 配置说明和 miniloader 版本号说明 Added DEVICE_MANIFEST_FILE configuration and miniloader version note.	

## 目 录 Contents

1	概述 OVERVIEW.....	1
2	系统配置说明 SYSTEM CONFIGURATION INSTRUCTION .....	1
2.1	ANDROID 系统配置说明 ANDROID SYSTEM CONFIGURATION .....	1
2.1.1	Android 9.0 系统配置说明 Android9.0 system configuration instruction.....	1
2.1.2	Android 10 系统配置 Android10.0 system configuration.....	4
2.2	KERNEL DTS 配置 KERNEL DTS CONFIGURATION .....	6
2.3	UBOOT 配置 UBOOT CONFIGURATION .....	7
2.4	烧写工具 ANDROIDTOOL 增加分区 ADD PARTITION FOR FLASH TOOL ANDROIDTOOL.....	7
3	AB 系统与 OTA 包编译 AB SYSTEM AND OTA PACKAGE COMPILING.....	8
4	验证方法（客户端与服务器）VALIDATION METHOD (CLIENT AND SERVER).....	8
4.1	无缝升级验证 SEAMLESS UPGRADING VALIDATION .....	9
5	注意事项 NOTICE.....	12

## 1 概述 Overview

本文档描述了 Rockchip A/B 系统的使用说明，可以在 Rockchip Android  $\geq 9.0$  平台上使用。

This document describes the usage of Rockchip A/B system which can be used on Rockchip Android platforms with Android 9.0 and higher versions.

使用该升级方法，所有待升级的分区都有 a 和 b 两份，相比传统的 Recovery 升级方式会大幅增加存储空间需求。其优点是 A/B 升级是无缝升级，可以在 Android 系统运行过程中，根据客户定制的客户端和服务端之间的交互策略与协议来完成升级。

Using this upgrading method, all the partitions to be upgraded have a and b, and it will dramatically increase the requirement of memory space comparing with traditional Recovery upgrading method. Its advantage is A/B upgrading is seamless upgrading, which can be completed according to the customized interactive strategy and protocol between the client and the server during Android system running process.

## 2 系统配置说明 System configuration instruction

在 Rockchip Android 平台上，AB 系统功能默认关闭，要使用 AB 系统，需要从 Android 系统、U-BOOT 和 kernel dts 三个方面进行配置。以下对此进行详细说明。

On Rockchip Android platforms, AB system function is disabled by default. If want to use AB system, need to do the configuration in Android system, U-BOOT and kernel dts. The details are described as below.

### 2.1 Android 系统配置说明 Android system configuration

Android 系统的配置分 Android 9.0 和 Android 10 分开说明，客户需要根据自己的实际情况，按照对应章节的指导进行操作。

Android system configuration includes Android9.0 and Android10.0. Customers need to operate according to the instruction in the corresponding chapter based on the actual situation.

#### 2.1.1 Android 9.0 系统配置说明 Android9.0 system configuration instruction

Android 9.0 系统的配置包括：

Android9.0 system configuration includes:

1.在 `device\rockchip\common\BoardConfig.mk` 中打开 AB 升级配置项。

Open the configuration item for AB upgrading in `device\rockchip\common\BoardConfig.mk`

将 `BOARD_USES_AB_IMAGE` 配置设置为 true，默认为 false.

Set `BOARD_USES_AB_IMAGE` configuration as true, which default value is false.

```
BOARD_USES_AB_IMAGE := false
```

2.在对应的 device\rockchip\rkxxx 目录下，确认是否已经有 parameter\_ab.txt 分区表文件，如果已有，则直接跳过这一步；如果没有 parameter\_ab.txt 文件，则按如下步骤执行：

In the corresponding directory of device\rockchip\rkxxx, confirm whether there is parameter\_ab.txt partition table or not, if yes, directly skip this step. If there is no parameter\_ab.txt file, execute as the following steps:

#### (1) 新建 parameter\_ab.txt 分区表文件

##### Create parameter\_ab.txt partition table file

该文件从对应 parameter.txt 拷贝一份，然后在此基础上，进行修改，核心是针对每个要升级的分区划分两个分区 a 和 b，最后删除 recovery 分区并且将 boot 分区的大小改为 64MB。

Copy a file from the corresponding parameter.txt, and then modify based on this file. The key point is to divide two partitons a and b for each partition to be upgraded, and finally delete recovery partition and modify the boot partition size to 64MB.

一个参考 parameter\_ab.txt 如下：

An example of parameter\_ab.txt is shown as below:

```
FIRMWARE_VER:9.0
MACHINE_MODEL:RK3326
MACHINE_ID:007
MANUFACTURER: RK3326
MAGIC: 0x5041524B
ATAG: 0x00200800
MACHINE: 3326
CHECK_MASK: 0x80
PWR_HLD: 0,0,A,0,1
TYPE: GPT
CMDLINE:mtdparts=rk29xxnand:0x00002000@0x00004000(uboot_a),0x00002000@0x00006000(uboot_b),0x00002000@0x00008000(trust_a),0x00002000@0x0000a000(trust_b),0x00002000@0x0000c000(misc),0x00008000@0x0000e000(resource),0x00010000@0x00016000(kernel),0x00002000@0x00026000(dtb),0x00002000@0x00028000(dtbo_a),0x00002000@0x0002a000(dtbo_b),0x00000800@0x0002c000(vbmeta_a),0x00000800@0x0002c800(vbmeta_b),0x00020000@0x0002d000(boot_a),0x00020000@0x0004d000(boot_b),0x00038000@0x0006d000(backup),0x00002000@0x000a5000(security),0x000c0000@0x000a7000(cache),0x00300000@0x00167000(system_a),0x00300000@0x00467000(system_b),0x00008000@0x00767000(metadata),0x000c0000@0x0076F000(vendor_a),0x000c0000@0x0082F000(vendor_b),0x00040000@0x008EF000(oem_a),0x00040000@0x0092F000(oem_b),0x00000400@0x0096F000(frp),-@0x0096F400(userdata:grow)
uuid:system=af01642c-9b84-11e8-9b2a-234eb5e198a0
```

#### (2) 新增针对 AB 的 fstab 文件 fstab.rk30board\_AB

##### Create fstab file fstab.rk30board\_AB for AB

AB 分区增加 slotselect 挂载参数（system 分区增加 slotselect 参数，删除 oem 分区项），同时将 frp, parameter, baseparameter, resource 的分区节点添加进去。

AB partition adds slotselect loading parameter (system partition adds slotselect parameter, and deletes oem partition item), and adds the partition nodes of frp, parameter, baseparameter and resource in parallel.

一个参考文件如下：

A reference file is shown as below:

```
# Android fstab file.
#<src>
# The filesystem that contains the filesystem checker binary (typically /system) cannot
# specify MF_CHECK, and must come before any filesystems that do specify MF_CHECK
<mnt_point>    <type>    <mnt_flags and options>    <fs_mgr_flags>
/dev/block/by-name/system / ext4 ro,barrier=1 wait,avb,slotselect
/dev/block/by-name/metadata /mnt/vendor/metadata ext4 noatime,nodiratime,nosuid,nodev,noauto_da_alloc,discard wait
/dev/block/by-name/misc /misc emmc defaults
/dev/block/by-name/frp /frp emmc defaults
/dev/block/by-name/parameter /parameter emmc defaults
/dev/block/by-name/baseparameter /baseparameter emmc defaults
/dev/block/by-name/resource /resource emmc defaults
/devices/platform/*usb* auto vfat defaults voldmanaged=usb:auto
/dev/block/zram0 none swap defaults zramsize=50%
# For sdmmc
/devices/platform/ff370000.dwmcc/mmc_host* auto auto defaults voldmanaged=sdcard1:auto,encryptable=userdata
# Full disk encryption has less effect on rk3326, so default to enable this.
/dev/block/by-name/userdata /data f2fs noatime,nodiratime,nosuid,nodev,discard,inline_xattr wait,check,notrim,encrypt
able-/mnt/vendor/metadata/key_file /data f2fs noatime,nodiratime,nosuid,nodev,discard,inline_xattr wait,check,notrim,encrypt
/dev/block/by-name/cache /cache ext4 noatime,nodiratime,nosuid,nodev,noauto_da_alloc,discard wait,check
```

(3) device\rockchip\rkxxx 下根据已有的 manifest.xml，新建 manifest\_ab.xml 文件。manifest\_ab.xml 文件只需在原有 manifest.xml 文件上新增如下配置即可：

Under device\rockchip\rkxxx, create a new manifest\_ab.xml file based on the existing manifest.xml. The manifest\_ab.xml file just needs to add the following configuration to the original manifest.xml file:

```
<hal format="hidl">
  <name>android.hardware.boot</name>
  <transport>hwbinder</transport>
  <version>1.0</version>
  <interface>
    <name>IBootControl</name>
    <instance>default</instance>
  </interface>
</hal>
```

(4) device\rockchip\rkxxx 下的 BoardConfig 配置 TARGET\_RECOVERY\_FSTAB，使其指向刚刚创建的 fstab.rk30board\_AB 文件。同时配置 DEVICE\_MANIFEST\_FILE，使其指向新建的 manifest\_ab.xml 文件。

Configure TARGET\_RECOVERY\_FSTAB for BoardConfig in device\rockchip\rkxxx to make it point to the newly created fstab.rk30board\_AB file and configure DEVICE\_MANIFEST\_FILE to point to the newly created manifest\_ab.xml file.

BoardConfig.mk:

```
+
+ifeq ($(strip $(BOARD_USES_AB_IMAGE)), true)
+TARGET_RECOVERY_FSTAB := device/rockchip/rk3399/fstab.rk30board_AB
+DEVICE_MANIFEST_FILE := device/rockchip/rk3399/manifest_ab.xml
+endif
```

### 2.1.2 Android 10 系统配置 Android10.0 system configuration

Android 10 系统的配置包括:

Android10.0 system configuration includes:

**1.在 device\rockchip\rkxxx\BoardConfig.mk 中打开 AB 升级配置项。**

Open the configuration item for AB upgrading in **device\rockchip\rkxxx\BoardConfig.mk**

将 BOARD\_USES\_AB\_IMAGE 配置设置为 true, 默认为 false.

Set BOARD\_USES\_AB\_IMAGE configuration as true, which default value is false.

以 rk3326 为例:

Take RK3326 as example:

```
vim device/rockchip/rk3326_qt/BoardConfig.mk
```

```
#AB image definition
```

```
-BOARD_USES_AB_IMAGE := false
```

```
+BOARD_USES_AB_IMAGE := true
```

**2.在对应的 device\rockchip\rkxxx 目录下, 确认是否已经有 parameter\_ab.txt 分区表文件, 如果已有, 则直接跳过这一步; 如果没有 parameter\_ab.txt 文件, 则按如下步骤执行:**

**In the corresponding directory of device\rockchip\rkxxx, confirm whether there is parameter\_ab.txt partition table or not, if yes, directly skip this step. If there is no parameter\_ab.txt file, execute as the following steps:**

**(1) 新建 parameter\_ab.txt 分区表文件**

**Create parameter\_ab.txt partition table file**

该文件从对应 parameter.txt 拷贝一份, 然后在此基础上, 进行修改, 核心是针对每个要升级的分区划分两个分区 a 和 b, 最后删除 recovery 分区并且将 boot 分区的大小改为 64MB。

Copy a file from the corresponding parameter.txt, and then modify based on this file. The key point is to divide two partitons a and b for each partition to be upgraded, and finally delete recovery partition and modify the boot partition size to 64MB.

**需要注意 super 分区不需要区分 a 和 b, 只需要有一个 super 分区, 其大小设置为非 AB 时 super 的 2 倍。**

**Need to notice that super partition doesn't need to separate a and b, it only needs one super partition, and its size should be set to 2 times of the super partition with non-AB.**

一个参考 parameter\_ab.txt 如下:

An example of parameter\_ab.txt is shown as below:

```
device\rockchip\rk3326\rk3326_qt:
```

```
FIRMWARE_VER:10.0
```

```
MACHINE_MODEL:RK3326
```

```
MACHINE_ID:007
```

```
MANUFACTURER: RK3326
```

```
MAGIC: 0x5041524B
```

```
ATAG: 0x00200800
```

```
MACHINE: 3326
```



CHECK\_MASK: 0x80

PWR\_HLD: 0,0,A,0,1

TYPE: GPT

CMDLINE:mtdparts=rk29xxnand:0x00002000@0x00004000(**uboot\_a**),0x00002000@0x00006000(**uboot\_b**),0x00002000@0x00008000(**trust\_a**),0x00002000@0x0000a000(**trust\_b**),0x00002000@0x0000c000(misc),0x00002000@0x0000e000(dtb),0x00002000@0x00010000(**dtbo\_a**),0x00002000@0x00012000(**dtbo\_b**),0x00000800@0x00014000(**vbmata\_a**),0x00000800@0x00014800(**vbmata\_b**),0x00030000@0x00015000(**boot\_a**),0x00030000@0x00045000(**boot\_b**),0x00038000@0x00075000(backup),0x00002000@0x000ad000(security),0x000c0000@0x000af000(cache),0x00008000@0x0016f000(metadata),0x00000400@0x00177000(frp),0x00c28000@0x00177400(**super**),-@0x00d9f400(userdata:grow)

## (2) 新增针对 AB 的 recovery fstab 文件 recovery.fstab\_AB

### Create recovery fstab file recovery.fstab\_AB for AB

与对应的 fstab.rk30board 的主要区别在于 AB 分区增加 slotselect 挂载参数 (system/vendor/odm/product 增加 slotselect 参数), 同时将 frp, parameter, baseparameter, resource 的分区节点添加进去, 并更改 data 区的挂载方式选项。

The main difference from the corresponding fstab.rk30board is that AB partition adds slotselect loading parameter (system/vendor/odm/product adds slotselect parameter), in parallel, adds the partition nodes of frp, parameter, baseparameter and resource, and modifies the loading method of data partition.

一个参考文件如下:

A reference file is as below:

device\rockchip\rk3326\rk3326\_qt\recovery.fstab\_AB:

```
# Android fstab file.
#<src>
# The filesystem that contains the filesystem checker binary (typically /system) cannot
# specify MF_CHECK, and must come before any filesystems that do specify MF_CHECK
system /system ext4 ro,barrier=1 wait,slotselect,logical,first_stage_mount
vendor /vendor ext4 ro,barrier=1 wait,slotselect,logical,first_stage_mount
odm /odm ext4 ro,barrier=1 wait,slotselect,logical,first_stage_mount
product /product ext4 ro,barrier=1 wait,slotselect,logical,first_stage_mount
/dev/block/by-name/metadata /metadata ext4 noatime,nosuid,discard,sync wait,formattable,first_stage_mount
/dev/block/by-name/misc /misc emmc defaults defaults
/dev/block/by-name/cache /cache ext4 noatime,nodiratime,nosuid,nodev,noauto_da_alloc,discard wait,check
/dev/block/mmcblk0p1 /mnt/external_sd vfat /dev/block/mmcblk0 defaults
/dev/block/by-name/frp /frp emmc defaults defaults
/dev/block/by-name/baseparameter /baseparameter emmc defaults defaults
/dev/block/by-name/backup /backup emmc defaults defaults
/dev/block/zram0 none swap defaults zramsize=50%
/dev/block/by-name/userdata /data f2fs defaults defaults
```

(3) device\rockchip\rkxxx 下根据已有的 manifest.xml, 新建 manifest\_ab.xml 文件。manifest\_ab.xml 文件只需在原有 manifest.xml 文件上新增如下配置即可:

Under device\rockchip\rkxxx, create a new manifest\_ab.xml file based on the existing manifest.xml. The manifest\_ab.xml file just needs to add the following configuration to the original manifest.xml file:

```
<hal format="hidl">
  <name>android.hardware.boot</name>
  <transport>hwbinder</transport>
  <version>1.0</version>
  <interface>
    <name>IBootControl</name>
```

```

        <instance>default</instance>
    </interface>
</hal>

```

( 4 ) device\rockchip\rkxxx 下的 BoardConfig 中导入 AB 配置，包括 TARGET\_RECOVERY\_FSTAB，使其指向刚刚创建的 recovery.fstab\_AB 文件。同时配置 DEVICE\_MANIFEST\_FILE，使其指向新建的 manifest\_ab.xml 文件。

Load AB configuration including TARGET\_RECOVERY\_FSTAB to BoardConfig in device\rockchip\rkxxx to make it point to the newly created recovery.fstab\_AB file and configure DEVICE\_MANIFEST\_FILE to point to the newly created manifest\_ab.xml file.

device\rockchip\rk3326\rk3326\_qt:

```
diff --git a/rk3326_qt/BoardConfig.mk b/rk3326_qt/BoardConfig.mk
```

```
index 1e78940..159a3b6 100755
```

```
--- a/rk3326_qt/BoardConfig.mk
```

```
+++ b/rk3326_qt/BoardConfig.mk
```

```
+# AB image definition
```

```
+BOARD_USES_AB_IMAGE := true
```

```
+
```

```
+ifeq ($(strip $(BOARD_USES_AB_IMAGE)), true)
```

```
+    include device/rockchip/common/BoardConfig_AB.mk
```

```
+    TARGET_RECOVERY_FSTAB := device/rockchip/rk3326/rk3326_qt/recovery.fstab_AB
```

```
+endif
```

device\rockchip\rk3326:

BoardConfig.mk:

```

ifeq ($(strip $(BOARD_USES_AB_IMAGE)), true)
    DEVICE_MANIFEST_FILE := device/rockchip/rk3326/manifest_ab.xml
else
    DEVICE_MANIFEST_FILE := device/rockchip/rk3326/manifest.xml
endif

```

## 2.2 kernel dts 配置 kernel dts configuration

对于 Android 10.0 来说，kernel 不需要任何配置。

For Android10.0, kernel doesn't need to do any configuration.

对于 Android 9.0 来说，kernel dts 需要按如下配置。包括添加 oem 项，同时将 slotselect 标记添加到 vendor 的 fsmgr\_flags，参考配置如下：

For Android9.0, kernel dts needs to configure as below. Add oem item, and add slotselect symbol to fsmgr\_flags of vendor in parallel. The reference configuration is shown as below:

```

--- a/arch/arm64/boot/dts/rockchip/rk3326-863-lp3-v10-avb.dts
+++ b/arch/arm64/boot/dts/rockchip/rk3326-863-lp3-v10-avb.dts
@@ -24,7 +24,14 @@
        dev = "/dev/block/platform/ff390000.dwmcc/by-name/vendor";
        type = "ext4";
        mnt_flags = "ro,barrier=1,inode_readahead_blks=8";
        fsmgr_flags = "wait,avb";
        fsmgr_flags = "wait,avb,slotselect";
    };
    oem {
        compatible = "android,oem";
        dev = "/dev/block/platform/ff390000.dwmcc/by-name/oem";
        type = "ext4";
        mnt_flags = "ro,barrier=1,inode_readahead_blks=8";
        fsmgr_flags = "wait,slotselect";
    };
};

```

## 2.3 uboot 配置 uboot configuration

在 uboot 中，针对具体芯片的配置文件，添加 CONFIG\_ANDROID\_AB=y 配置项，参考配置如下截图所示：

In uboot, add CONFIG\_ANDROID\_AB=y configuration item in the configuration file of the specific chipset. The reference configuration is shown as below:

```

diff --git a/configs/rk3326_defconfig b/configs/rk3326_defconfig
old mode 100644
new mode 100755
index 0465f23..d64648c
--- a/configs/rk3326_defconfig
+++ b/configs/rk3326_defconfig
@@ -114,3 +114,4 @@ CONFIG_OPTEE_CLIENT=y
 CONFIG_OPTEE_V2=y
 CONFIG_OPTEE_ALWAYS_USE_SECURITY_PARTITION=y
 CONFIG_TEST_ROCKCHIP=y
+CONFIG_ANDROID_AB=y

```

## 2.4 烧写工具 AndroidTool 增加分区 Add partition for flash tool AndroidTool

增加 B 分区的下载项，同时所有 AB 分区都烧写相同的固件。具体增加方法请参考《Rockchip Parameter File Format Ver1.3》。

Add the download item for B partition, and make all AB partitions flash the same images. Please refer to 《Rockchip Parameter File Format Ver1.3》 for the detailed method.

一个烧写工具截图如下：

A flash tool screenshot is shown as below:



### 3 AB 系统与 OTA 包编译 AB system and OTA package compiling

编译 AB 系统固件步骤（务必按如下步骤执行）：

The steps to compile AB system image (please strictly follow below steps):

lunch xxx

make installclean -j32 OR make clean

make -j32

make otapackage -j32

mkimage\_ab.sh ota

注意：mkimage\_ab.sh 文件从 device/rockchip/common 目录拷贝到 Android 根目录。

Note: copy mkimage\_ab.sh file from the directory of device/rockchip/common to the root directory of Android.

### 4 验证方法（客户端与服务器） Validation method (client and server)

Rockchip AB 系统支持正常系统下的无缝升级（一边下载升级包，一边升级）。

Rockchip AB system supports the seamless upgrading in normal system (upgrading is on-going, while downloading the upgrade package).

## 4.1 无缝升级验证 Seamless upgrading validation

在无缝升级过程中，升级包可以一边下载，一边升级。这时候需要有一个 HTTP 服务器和一个升级客户端。

During seamless upgrading process, the package can be downloaded and upgraded in parallel. Here we need a HTTP server and an upgrading client.

请使用以下 update\_device.py 验证。至于产品化的升级客户端和升级服务器需要客户自行搭建，升级客户端可以参考 Android 默认提供的 update\_engine\_client。关于 update\_engine\_client 的使用方法请参考如下验证方法 update\_device.py，该脚本就是通过 adb 最终调用 update\_engine\_client 来实现升级的。

As for verification, please use update\_device.py that described below. Customers need to setup their own upgrading client and upgrading server for the product and the upgrading client can refer to the default update\_engine\_client provided by Android. For the use of update\_engine\_client, please refer to the following verification method update\_device.py, the script is finally upgraded by calling update\_engine\_client through adb.

**验证方法：update\_device.py**

**Validation Method: update\_device.py**

update\_device.py 脚本通过 adb 方式，将 Linux 主机变成 HTTP 服务器，然后调用 update\_engine\_client 来实现无缝升级。

update\_device.py script changes Linux host to be HTTP server through adb, and then invokes update\_engine\_client to achieve the seamless upgrading.

使用方法如下：在 Linux 主机中执行如下命令（**要使用 Linux 主机,Windows 主机会有问题，同时确保该 Linux 主机 adb 功能正常**）：

The usage is as below: execute the following command in Linux host (**must use Linux host but not Windows host, and make sure the Linux host adb function works normally**):

system/update\_engine/scripts/update\_device.py {升级包名字}

system/update\_engine/scripts/update\_device.py {upgrade package name}

示例如下：

The example is shown as below:



```
jdy@jdy-Latitude-E6440: /media/jdy/LDsecond/rk3326/rk3326_0.X$ sudo system/update_engine/scripts/update_device.py ~/rk3326_evb-ota-eng.jdy.zi
[sudo] jdy 的密码:
INFO:root:Running: adb reverse tcp:1234 tcp:37213
INFO:root:Running: adb shell su 0 update_engine_client --update --follow --payload=http://127.0.0.1:1234/payload --offset=5501 --size=4519145
--headers="FILE_HASH=w2F5sNI8wF0hJHEyFgyEEz+uTlsJ108z+MlIhC0q7g=
FILE_SIZE=451914571
METADATA_HASH=s7dLj4bHgFLYp7aGTLT6t8kooj8Qfs6DWEfG348yyCo=
METADATA_SIZE=59119
USER_AGENT=Dalvik (something, something)
NETWORK_ID=0
"
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_IDLE (0), 0)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_UPDATE_AVAILABLE (2), 0)
127.0.0.1 - - [17/Jul/2018 17:24:40] "GET /payload HTTP/1.1" 206 -
INFO:root:Servicing request for /payload from /home/jdy/rk3326_evb-ota-eng.jdy.zip [5501, 451920072] length: 451914571
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 4.84229e-05)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0100547)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.020061)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0300673)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0400735)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0500798)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0600861)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0700924)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0800987)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.0901049)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.100111)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.110118)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.120124)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.13013)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.140136)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.150143)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.160149)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.170155)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.180161)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.190168)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.200174)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.21018)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.220187)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.230193)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.240199)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.250205)
```

```
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.230193)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.240199)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.250205)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.260212)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.270218)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.280224)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.290231)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.300237)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.310243)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.320249)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.330256)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.340262)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.350268)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.360275)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.370281)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.380287)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.390293)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.4003)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.410306)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.420312)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.430318)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.440325)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.450331)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.460337)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.470344)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.48035)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.490356)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.500362)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.510369)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.520375)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.530381)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.540388)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.550394)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.5604)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.570406)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.580413)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.590419)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.600425)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.610432)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.620438)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.630444)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.64045)
[INFO:update_engine_client_android.cc(90)] onStatusUpdate(UPDATE_STATUS_DOWNLOADING (3), 0.650457)
```



Copyright © 2019 Fuzhou Rockchip Electronics Co., Ltd.

UPDATE\_STATUS\_UPDATED\_NEED\_REBOOT 地打印信息，如上截图所示。此时手动重启设备，就可以切换到新的升级后的系统。

The above screenshots show the complete upgrading process. After upgrading successfully, it will print information UPDATE\_STATUS\_UPDATED\_NEED\_REBOOT as shown above. Now manually reboot the device, and it will switch to the newly upgraded system.

## 5 注意事项 Notice

1.AB needs miniloader support, specifically:

RK3399 >= V1.18

RK3326 >= V1.18

RK3288 >= V2.58

RK3368 >= V2.68

其他芯片对应的 miniloader 版本号，请向对应的项目接口人确认。

For other chipsets, please check with the corresponding project contact to confirm the miniloader version.