

# Instructions to separate the build system image from the SDK

---

ID: RK-SM-YF-386

Release Version: V1.5.1

Release Date: 2020-12-08

Security Level: ☐Top-Secret ☐Secret ☐Internal ☒Public

## DISCLAIMER

THIS DOCUMENT IS PROVIDED “AS IS”. ROCKCHIP ELECTRONICS CO., LTD.(“ROCKCHIP”)DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

## Trademark Statement

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

**All rights reserved. ©2020. Rockchip Electronics Co., Ltd.**

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: [www.rock-chips.com](http://www.rock-chips.com)

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: [fae@rock-chips.com](mailto:fae@rock-chips.com)

## Preface

## Overview

The document presents the separate compiling kernel U-Boot or Rootfs of Rockchip RV1126/RV1109 Linux SDK, aiming to help engineers get started with RV1126/RV1109 Linux SDK faster.

**[NOTICE]: Please update SDK version to V1.3.0 or the latest**

Get the version of SDK: `realpath .repo/manifests/rv1126_rv1109_linux_release.xml`

## Product Version

Chipset	Kernel Version
RV1126/RV1109	Linux 4.19

## Intended Audience

This document (this guide) is mainly intended for:

- Technical support engineers
- Software development engineers

## Revision History

Version	Author	Date	Revision History
2020-08-10	V1.0.0	CWW	alpha
2020-08-12	V1.1.0	CWW	1. Add idblock.bin compile instructions 2. Add drivers insmod
2020-09-01	V1.2.0	CWW	1. Support eMMC compile instructions
2020-09-10	V1.3.0	CWW	1. Add Debug info chapter
2020-09-15	V1.4.0	CWW	1. Support AB system compilation
2020-09-27	V1.5.0	CWW	1. Fix BSP library build 2. Add print cif info
2020-12-08	V1.5.1	CWW	1. Fix insmod driver module

## Instructions to separate the build system image from the SDK

1. U-Boot compilation
  - 1.1 Get U-Boot code from SDK
  - 1.2 For SPI NOR U-Boot compilation
  - 1.3 For eMMC U-Boot compilation
    - 1.3.1 Non-support AB system
    - 1.3.2 Support AB system
  - 1.4 Instructions to U-Boot images
2. Linux kernel compilation
  - 2.1 Get linux kernel code from SDK
  - 2.2 Build command explanation
  - 2.3 For SPI NOR linux kernel compilation
  - 2.4 For eMMC linux kernel compilation
    - 2.4.1 Build eMMC kernel without peripheral drivers
    - 2.4.2 Build eMMC kernel with peripheral drivers

- 2.5 Package drivers (only for building without peripheral drivers into kernel)
- 2.6 Instructions to linux kernel image
- 2.7 Instructions to drivers insmod (only for building without peripheral drivers into kernel)
- 3. Root filesystem compilation
  - 3.1 Get tarball of build-busybox and compile
  - 3.2 Instructions to auto mount partition
- 4. Manufacture programmer firmware image for SPI NOR
- 5. Instructions to compile the libraries of BSP
  - 5.1 Command to build BSP's libraries
  - 5.2 BSP's files
- 6. Debug info
  - 6.1 CPU debug info
    - 6.1.1 CPU frequency debug
      - 6.1.1.1 Print CPU frequency
      - 6.1.1.2 Set CPU fixed frequency
    - 6.1.2 Print CPU thermal
    - 6.1.3 Disable CPU thermal control
  - 6.2 Encode debug info
    - 6.2.1 Print encode frame rate
  - 6.3 Print CIF info
  - 6.4 Print ISPP info
  - 6.5 Print ISP info

# 1. U-Boot compilation

---

## 1.1 Get U-Boot code from SDK

Get thses directories from root directory of SDK:

Directory or File	Instructions
rkbin	about DDR and prebuilt loader bin
u-boot	U-Boot code
prebuilts	cross-compile tool

## 1.2 For SPI NOR U-Boot compilation

```
cd u-boot
./make.sh rv1126-spi-nor-tiny
./make.sh spl-s # or ./make.sh --spl
./make.sh --idblock --spl
```

## 1.3 For eMMC U-Boot compilation

### 1.3.1 Non-support AB system

```
cd u-boot
./make.sh rv1126
./make.sh spl-s # or ./make.sh --spl
# parameter e.g.
#
mtdparts=rk29xxnand:0x00002000@0x00004000 (uboot),0x00010000@0x00006000 (boot),0x00
010000@0x00016000 (rootfs),-@0x00026000 (data:grow)
```

### 1.3.2 Support AB system

```
cd u-boot
./make.sh rv1126-ab
./make.sh spl-s # or ./make.sh --spl
# parameter e.g.
#
mtdparts=rk29xxnand:0x00002000@0x00004000 (uboot_a),0x00002000@0x00006000 (uboot_b)
,0x00001000@0x00008000 (misc),0x00010000@0x00009000 (boot_a),0x00010000@0x00019000 (
boot_b),0x00020000@0x00029000 (system_a),0x00020000@0x00049000 (system_b),-
@0x00069000 (data:grow)
```

## 1.4 Instructions to U-Boot images

the name of image	comment
rv1126_spl_loader_*.bin	loader file
uboot.img	U-Boot image
idblock.bin	the IDBlock partition file for firmware_merger tool

## 2. Linux kernel compilation

### 2.1 Get linux kernel code from SDK

Get thses directories from root directory of SDK:

Directory or File	Instructions
kernel	linux kernel code
prebuilts	cross-compile tool

## 2.2 Build command explanation

Build command format:

```
# configure linux kernel
# args1: chip architecture (e.g. arm)
# args2: linux kernel defconfig filename (e.g. xxx_defconfig)
# args3: linux kernel defconfig fragment filename (option)
make ARCH=args1 args2 args3
make menuconfig # this step is optional

# make kernel image
# args1: chip architecture (e.g. arm)
# args2: linux kernel dts's filename (e.g. arch/arm/boot/dts/rv1126-38x38-v10-
emmc.dts)
# -j12: allow 12 jobs compilation at once
make ARCH=args1 args2.img -j12
```

## 2.3 For SPI NOR linux kernel compilation

```
make ARCH=arm rv1126_defconfig rv1126-spi-nor.config
make ARCH=arm rv1126-38x38-v10-spi-nor.img -j12
```

## 2.4 For eMMC linux kernel compilation

### 2.4.1 Build eMMC kernel without peripheral drivers

```
make ARCH=arm rv1126_defconfig rv1126-emmc-drivers-modules.config
make ARCH=arm rv1126-38x38-v10-emmc.img -j12
```

### 2.4.2 Build eMMC kernel with peripheral drivers

```
make ARCH=arm rv1126_defconfig rv1126-emmc-drivers-builtin.config
make ARCH=arm rv1126-38x38-v10-emmc.img -j12
```

## 2.5 Package drivers (only for building without peripheral drivers into kernel)

```
make modules_install ARCH=arm INSTALL_MOD_STRIP=1 INSTALL_MOD_PATH=./drivers-ko
# remove unused soft link
rm -f drivers-ko/lib/modules/4.19.111/build drivers-
ko/lib/modules/4.19.111/source
```

## 2.6 Instructions to linux kernel image

the name of image	comment
zboot.img	linux kernel image
drivers-ko	the directory of linux kernel drivers

## 2.7 Instructions to drivers insmod (only for building without peripheral drivers into kernel)

```
# stop udevd before insmod driver modules
udevadm control --stop-exec-queue

# insmod videobuf2
insmod kernel/drivers/media/common/videobuf2/videobuf2-memops.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-dma-contig.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-common.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-v4l2.ko
insmod kernel/drivers/media/common/videobuf2/videobuf2-vmalloc.ko

# insmod drm
insmod kernel/drivers/gpu/drm/drm_kms_helper.ko
insmod kernel/drivers/gpu/drm/rockchip/rockchipdrm.ko

# insmod audio
insmod kernel/sound/soundcore.ko
insmod kernel/sound/core/snd.ko
insmod kernel/sound/core/snd-timer.ko
insmod kernel/sound/core/snd-pcm.ko
insmod kernel/sound/core/snd-pcm-dmaengine.ko
insmod kernel/sound/soc/snd-soc-core.ko
insmod kernel/sound/soc/codecs/snd-soc-dummy-codec.ko
insmod kernel/sound/soc/codecs/snd-soc-rk817.ko
insmod kernel/sound/soc/rockchip/snd-soc-rockchip-i2s-tdm.ko
insmod kernel/sound/soc/generic/snd-soc-simple-card-utils.ko
insmod kernel/sound/soc/generic/snd-soc-simple-card.ko

# insmod isp isp cif rk_ircut and sensor
insmod kernel/drivers/media/v4l2-core/v4l2-fwnode.ko
insmod kernel/drivers/media/i2c/os04a10.ko
insmod kernel/drivers/media/i2c/imx415.ko
insmod kernel/drivers/media/i2c/rk_ircut.ko
insmod kernel/drivers/phy/rockchip/phy-rockchip-mipi-rx.ko
insmod kernel/drivers/media/platform/rockchip/cif/video_rkcif.ko
insmod kernel/drivers/media/platform/rockchip/isp/video_rkisp.ko
insmod kernel/drivers/media/platform/rockchip/ispp/video_rkispp.ko
echo 1 > /sys/module/video_rkisp/parameters/clr_unready_dev
echo 1 > /sys/module/video_rkispp/parameters/mode

# insmod vcodec
insmod kernel/drivers/video/rockchip/mpp/rk_vcodec.ko
```

```
# insmod usb for adb
insmod kernel/drivers/phy/rockchip/phy-rockchip-naneng-usb2.ko
insmod kernel/drivers/usb/dwc3/dwc3-of-simple.ko
insmod kernel/drivers/usb/dwc3/dwc3.ko

# insmod for adc key
insmod kernel/drivers/input/keyboard/adc-keys.ko

# insmod for led flash
insmod kernel/drivers/leds/led-class-flash.ko
insmod kernel/drivers/leds/leds-rgb13h.ko

# insmod sdcard ko
insmod kernel/drivers/mmc/host/dw_mmc.ko
insmod kernel/drivers/mmc/host/dw_mmc-pltfm.ko
insmod kernel/drivers/mmc/host/dw_mmc-rockchip.ko
insmod kernel/drivers/mmc/host/rk_sdmmc_ops.ko

# audio codec
insmod kernel/sound/soc/codecs/snd-soc-es8311.ko

# rtc
insmod kernel/drivers/rtc/rtc-pcf8563.ko

# pwm fill light
insmod kernel/drivers/leds/leds-pwm.ko

# restart udevd after insmod driver modules
udevadm control --start-exec-queue
```

## 3. Root filesystem compilation

---

### 3.1 Get tarball of build-busybox and compile

Get busybox tarball from path: `device/rockchip/rv1126_rv1109/prebuilt-packages/build-busybox`

```
# unpack busybox tarball
tar xjf busybox-1.27.2-patch-reboot-arg.tar.bz2

# copy rockchip's busybox defconfig
# busybox_spi_nor_defconfig used for spi nor
# busybox_emmc_defconfig used for eMMC (default)
cp busybox-1.27.2-patch/configs/busybox_defconfig busybox-
1.27.2/configs/busybox_defconfig

# change directory to busybox
cd busybox-1.27.2

# config defconfig
make busybox_defconfig

# compile, Notice: the cross compile tool is in the prebuilts directory of SDK
```

```

make ARCH=arm install CROSS_COMPILE=~/.RV1109-SDK/prebuilts/gcc/linux-x86/arm/gcc-arm-8.3-2019.03-x86_64-arm-linux-gnueabi/bin/arm-linux-gnueabi- -j32

# unpack base root filesystem which is prebuilt bin, e.g. target-emmc-v1.0.0.tar.bz2
tar xjf target-emmc-v1.0.0.tar.bz2

# copy busybox target bin and libs to target directory (option)
cp busybox-1.27.2/_install/* target/ -rfa

# package root filesystem with squashfs
mksquashfs target rootfs.squashfs -noappend -comp xz

# package root filesystem with ext4, e.g.
tar xjf tools.tar.bz2
./tools/mkfs-ext4/do-mkfs.ext4.sh target rootfs.ext4 64M

# the command of unpack squashfs filesystem : unsquashfs ./rootfs.squashfs

```

**NOTICE:** The library named `/usr/lib/libv4l/plugins/libv4l-mplane.so` **MUST** be placed in the rootfs.

## 3.2 Instructions to auto mount partition

target-emmc-v1.0.0.tar.bz2 support auto mount the partitions which config in the file of `/etc/fstab`. Auto mount script: `target/etc/init.d/S21mountall.sh`

Refer to the partition of userdata

```

cat target/etc/fstab
# <file system> <mount pt>      <type>  <options>      <dump>  <pass>
/dev/root      /                ext2     rw,noauto      0        1
proc           /proc           proc     defaults        0        0
devpts         /dev/pts        devpts   defaults,gid=5,mode=620 0        0
tmpfs          /dev/shm        tmpfs    mode=0777       0        0
tmpfs          /tmp            tmpfs    mode=1777       0        0
tmpfs          /run            tmpfs    mode=0755,nosuid,nodev 0        0
sysfs          /sys            sysfs    defaults        0        0
debug          /sys/kernel/debug debugfs   defaults        0        0
/dev/block/by-name/userdata  /userdata      ext2     defaults        0        2

```

## 4. Manufacture programmer firmware image for SPI NOR

Get `firmware_merger` from path: `device/rockchip/rv1126_rv1109/prebuilt-packages/firmware_merger`

```

# Instructions to the tool of firmware_merger
# -P : assign the config of partition and input image
# ./ : config output file Firmware.img
./firmware_merger -P setting.ini ./

# Instructions to the directory of firmware_merger

```



```

firmware_merger
├─ Firmware.img                # Generate firmware image
├─ firmware_merger             # Execute binary
├─ Readme.txt                  #
├─ RKDevTool_Release_v2.74     # Download program
│   ├─ RKDevTool.exe           #
│   ├─ RKDevTool_manual_v1.2_cn.pdf #
│   └─ RKDevTool_manual_v1.2_en.pdf #
├─ rockdev                     # Images for package
│   ├─ idblock.bin             # Get from SDK's u-boot directory
│   ├─ rootfs.squashfs         #
│   ├─ rv1126_spl_loader_***.bin # Get from SDK's u-boot directory
│   ├─ uboot.img               # Get from SDK's u-boot directory
│   └─ zboot.img               # Get from SDK's kernel directory
├─ setting.ini                 #
├─ user_manual.txt             #
└─ burn-screenshot.png        #

```

## 5. Instructions to compile the libraries of BSP

Get these directories from root directory of SDK:

Directory or File	Instructions
buildroot	buildroot's source
external	rockchip BSP codes
prebuilts	cross-compile tool
envsetup.sh	link to buildroot/build/envsetup.sh
Makefile	link to buildroot/build/Makefile

### 5.1 Command to build BSP's libraries

```

source envsetup.sh rockchip_rv1126_rv1109_libs

make -j12

```

### 5.2 BSP's files

```

tree buildroot/output/rockchip_rv1126_rv1109_libs/BSP/
buildroot/output/rockchip_rv1126_rv1109_libs/BSP/
├─ example
│   ├─ CMakeLists.txt
│   └─ common
│       ├─ sample_common.h
│       └─ sample_common_isp.c

```

```

└─ iqfiles
├─ FEC_mesh_2688_1520_imx347_4IR
│  ├─ meshxf_level0.bin
│  ├─ meshxf_level1.bin
│  ├─ meshxf_level2.bin
│  ├─ meshxf_level3.bin
│  ├─ meshxf_level4.bin
│  ├─ meshxi_level0.bin
│  ├─ meshxi_level1.bin
│  ├─ meshxi_level2.bin
│  ├─ meshxi_level3.bin
│  ├─ meshxi_level4.bin
│  ├─ meshyf_level0.bin
│  ├─ meshyf_level1.bin
│  ├─ meshyf_level2.bin
│  ├─ meshyf_level3.bin
│  ├─ meshyf_level4.bin
│  ├─ meshyi_level0.bin
│  ├─ meshyi_level1.bin
│  ├─ meshyi_level2.bin
│  ├─ meshyi_level3.bin
│  └─ meshyi_level4.bin
├─ FEC_mesh_2688_1520_os04a10_4IR
│  ├─ meshxf_level0.bin
│  ├─ meshxf_level1.bin
│  ├─ meshxf_level2.bin
│  ├─ meshxf_level3.bin
│  ├─ meshxf_level4.bin
│  ├─ meshxi_level0.bin
│  ├─ meshxi_level1.bin
│  ├─ meshxi_level2.bin
│  ├─ meshxi_level3.bin
│  ├─ meshxi_level4.bin
│  ├─ meshyf_level0.bin
│  ├─ meshyf_level1.bin
│  ├─ meshyf_level2.bin
│  ├─ meshyf_level3.bin
│  ├─ meshyf_level4.bin
│  ├─ meshyi_level0.bin
│  ├─ meshyi_level1.bin
│  ├─ meshyi_level2.bin
│  ├─ meshyi_level3.bin
│  └─ meshyi_level4.bin
├─ FEC_mesh_2688_1520_os04a10_6IR
│  ├─ meshxf_level0.bin
│  ├─ meshxf_level1.bin
│  ├─ meshxf_level2.bin
│  ├─ meshxf_level3.bin
│  ├─ meshxf_level4.bin
│  ├─ meshxi_level0.bin
│  ├─ meshxi_level1.bin
│  ├─ meshxi_level2.bin
│  ├─ meshxi_level3.bin
│  ├─ meshxi_level4.bin
│  ├─ meshyf_level0.bin
│  ├─ meshyf_level1.bin
│  ├─ meshyf_level2.bin
│  └─ meshyf_level3.bin

```

```
| | | └─ meshyf_level4.bin
| | | └─ meshyi_level0.bin
| | | └─ meshyi_level11.bin
| | | └─ meshyi_level12.bin
| | | └─ meshyi_level13.bin
| | | └─ meshyi_level14.bin
| | └─ FEC_mesh_3840_2160_imx415_3.6mm
| | | └─ meshxf_level0.bin
| | | └─ meshxf_level11.bin
| | | └─ meshxf_level12.bin
| | | └─ meshxf_level13.bin
| | | └─ meshxf_level14.bin
| | | └─ meshxi_level0.bin
| | | └─ meshxi_level11.bin
| | | └─ meshxi_level12.bin
| | | └─ meshxi_level13.bin
| | | └─ meshxi_level14.bin
| | | └─ meshyf_level0.bin
| | | └─ meshyf_level11.bin
| | | └─ meshyf_level12.bin
| | | └─ meshyf_level13.bin
| | | └─ meshyf_level14.bin
| | | └─ meshyi_level0.bin
| | | └─ meshyi_level11.bin
| | | └─ meshyi_level12.bin
| | | └─ meshyi_level13.bin
| | | └─ meshyi_level14.bin
| | └─ gc2053_CMK-OT1726-PG1_29IR-2MP-F25.xml
| | └─ gc2053_YT-RV1109-2-V1_40IR-2MP-F20.xml
| | └─ gc2093_YT-RV1109-2-V1_40IR-2MP-F20.xml
| | └─ gc4c33_PCORW0009A_40IRC-4M.xml
| | └─ imx307_CMK-OT0837-PT2_YT-2929_UNV-40IRC-2M-F20.xml
| | └─ imx334_CMK-OT1522-FG3_CS-P1150-IRC-8M-FAU.xml
| | └─ imx347_JSD3425-C1_40IRC.xml
| | └─ imx378_A12N01B_48IRC-12M-F18.xml
| | └─ imx415_YT10092_IR0147-28IRC-8M-F20-hdr3.xml
| | └─ imx415_YT10092_IR0147-28IRC-8M-F20.xml
| | └─ imx415_YT10092_IR0147-36IRC-8M-F20-hdr3.xml
| | └─ imx415_YT10092_IR0147-36IRC-8M-F20.xml
| | └─ imx415_YT10092_IR0147-60IRC-8M-F20-hdr3.xml
| | └─ imx415_YT10092_IR0147-60IRC-8M-F20.xml
| | └─ LDCH_mesh_2688_1520_imx347_4IR
| | | └─ mesh_level0.bin
| | | └─ mesh_level11.bin
| | | └─ mesh_level12.bin
| | | └─ mesh_level13.bin
| | | └─ mesh_level14.bin
| | └─ LDCH_mesh_2688_1520_os04a10_4IR
| | | └─ mesh_level0.bin
| | | └─ mesh_level11.bin
| | | └─ mesh_level12.bin
| | | └─ mesh_level13.bin
| | | └─ mesh_level14.bin
| | └─ LDCH_mesh_2688_1520_os04a10_6IR
| | | └─ mesh_level0.bin
| | | └─ mesh_level11.bin
| | | └─ mesh_level12.bin
| | | └─ mesh_level13.bin
```

- └─ mesh\_level4.bin
- └─ LDCH\_mesh\_3840\_2160\_imx415\_3.6mm
  - └─ mesh\_level0.bin
  - └─ mesh\_level1.bin
  - └─ mesh\_level2.bin
  - └─ mesh\_level3.bin
  - └─ mesh\_level4.bin
- └─ os04a10\_CMK-OT1607-FV1\_M12-40IRC-4MP-F16.xml
- └─ os04a10\_CMK-OT1607-FV1\_M12-60IRC-4MP-F16.xml
- └─ ov02k10\_O2F0068\_2D2A-40IRC-2M-F18.xml
- └─ ov02k10\_ORCF-0249-00-PD-V1\_xuye.xml
- └─ ov2718\_YT-RV1109-3-V1\_M43-4IR-2MP-F2.xml
- └─ ov4689\_JSD3425-C1\_JSD3425-C1-36IRC-4M-F20.xml
- └─ s5kgmlsp\_PCORW0009A\_4mm-4M.xml
- └─ s5kgmlsp\_S5KGM1ST03\_40IR-12M-F20.xml
- └─ sc200ai\_CMK-OT1607-FV1\_M12-40IRC-4MP-F16\_tmp2\_addnr3.xml
- └─ Makefile
- └─ rkmedia\_audio\_test.c
- └─ rkmedia\_isp\_test.c
- └─ rkmedia\_main\_stream\_with\_jpeg\_test.c
- └─ rkmedia\_venc\_avbr\_test.c
- └─ rkmedia\_venc\_cover\_test.c
- └─ rkmedia\_venc\_jpeg\_test.c
- └─ rkmedia\_venc\_mjpeg\_test.c
- └─ rkmedia\_venc\_offline\_test.c
- └─ rkmedia\_venc\_osd\_test.c
- └─ rkmedia\_venc\_roi\_osd\_test.c
- └─ rkmedia\_venc\_smartp\_test.c
- └─ rkmedia\_vi\_double\_cameras\_test.c
- └─ rkmedia\_vi\_get\_frame\_test.c
- └─ rkmedia\_vi\_md\_test.c
- └─ rkmedia\_vi\_multi\_bind\_test.c
- └─ rkmedia\_vi\_od\_test.c
- └─ rkmedia\_vi\_rga\_test.c
- └─ rkmedia\_vi\_venc\_change\_resolution\_test.c
- └─ rkmedia\_vi\_venc\_test.c
- └─ rkmedia\_vi\_vo\_test.c
- └─ rkmedia\_vi\_work\_mode\_test.c
- └─ uintTest
  - └─ buffer
    - └─ buffer\_pool\_test.cc
    - └─ CMakeLists.txt
  - └─ CMakeLists.txt
  - └─ ffmpeg
    - └─ CMakeLists.txt
    - └─ ffmpeg\_enc\_mux\_test.cc
  - └─ flow
    - └─ audio\_decoder\_flow\_test.cc
    - └─ audio\_encoder\_flow\_test.cc
    - └─ audio\_loop\_test.cc
    - └─ audio\_process\_test.cc
    - └─ CMakeLists.txt
    - └─ flow\_event\_test.cc
    - └─ flow\_stress\_test.cc
    - └─ FlowTest.cc
    - └─ link\_flow\_test.cc
    - └─ move\_detection\_flow\_test.cc
    - └─ muxer\_flow\_test.cc

```
| | | | | occlusion_detection_flow_test.cc
| | | | | rga_filter_flow_test.cc
| | | | | through_guard_jpeg_test.cc
| | | | | video_encoder_bps_test.cc
| | | | | video_encoder_flow_test.cc
| | | | | video_encoder_osd_test.cc
| | | | | video_encoder_roi_test.cc
| | | | | video_smart_encoder_test.cc
| | | | |
| | | | | live555
| | | | | | CMakeLists.txt
| | | | | | h264_frames
| | | | | | | 0.h264_frame
| | | | | | | 10.h264_frame
| | | | | | | 1.h264_frame
| | | | | | | 2.h264_frame
| | | | | | | 3.h264_frame
| | | | | | | 4.h264_frame
| | | | | | | 5.h264_frame
| | | | | | | 6.h264_frame
| | | | | | | 7.h264_frame
| | | | | | | 8.h264_frame
| | | | | | | 9.h264_frame
| | | | | | rtsp_multi_server_test.cc
| | | | | | rtsp_server_test.cc
| | | | |
| | | | | ogg
| | | | | | CMakeLists.txt
| | | | | | ogg_decode_test.cc
| | | | | | ogg_encode_test.cc
| | | | |
| | | | | rkmp
| | | | | | CMakeLists.txt
| | | | | | mpp_dec_test_320_240.jpg
| | | | | | mpp_dec_test.cc
| | | | | | mpp_dec_test.h264
| | | | | | mpp_dec_test.hevc
| | | | | | mpp_enc_test_320_240.nv12
| | | | | | mpp_enc_test.cc
| | | | |
| | | | | stream
| | | | | | camera_capture_test.cc
| | | | | | CMakeLists.txt
| | | | | | drm_display_test.cc
| | | | |
| | | | | uvc
| | | | | | CMakeLists.txt
| | | | | | uvc_flow_test.cc
| | | | |
| | | | | vqefiles
| | | | | | 16k
| | | | | | | RKAP_AecPara.bin
| | | | | | 8k
| | | | | | | RKAP_AecPara.bin
| | | | |
| | | | | include
| | | | | | rga
| | | | | | | drmgrga.h
| | | | | | | RgaApi.h
| | | | | | | rga.h
| | | | | | | RockchipRga.h
| | | | | | | RockchipRgaMacro.h
| | | | |
| | | | | rkaiq
| | | | | | algos
| | | | | | a3dlut
```

```

├── rk_aiq_types_a3dlut_algo.h
├── rk_aiq_types_a3dlut_algo_int.h
├── rk_aiq_types_a3dlut_hw.h
├── rk_aiq_uapi_a3dlut_int.h
├── ablc
│   ├── rk_aiq_types_ablc_algo.h
│   ├── rk_aiq_types_ablc_algo_int.h
│   ├── rk_aiq_types_ablc_hw.h
│   └── rk_aiq_uapi_ablc_int.h
├── accm
│   ├── rk_aiq_types_accm_algo.h
│   ├── rk_aiq_types_accm_algo_int.h
│   ├── rk_aiq_types_accm_hw.h
│   └── rk_aiq_uapi_accm_int.h
├── acp
│   ├── rk_aiq_types_acp_algo.h
│   ├── rk_aiq_types_acp_algo_int.h
│   └── rk_aiq_uapi_acp_int.h
├── adebayer
│   ├── rk_aiq_types_algo_adebayer.h
│   ├── rk_aiq_types_algo_adebayer_int.h
│   └── rk_aiq_uapi_adebayer_int.h
├── adehaze
│   ├── rk_aiq_types_adehaze_algo.h
│   ├── rk_aiq_types_adehaze_algo_int.h
│   ├── rk_aiq_types_adehaze_hw.h
│   └── rk_aiq_uapi_adehaze_int.h
├── adpcc
│   ├── rk_aiq_types_adpcc_algo.h
│   ├── rk_aiq_types_adpcc_algo_int.h
│   ├── rk_aiq_types_adpcc_hw.h
│   └── rk_aiq_uapi_adpcc_int.h
├── ae
│   ├── rk_aiq_types_ae_algo.h
│   ├── rk_aiq_types_ae_algo_int.h
│   ├── rk_aiq_types_ae_hw.h
│   ├── rk_aiq_uapi_ae_int.h
│   └── rk_aiq_uapi_ae_int_types.h
├── af
│   ├── rk_aiq_af_hw_v200.h
│   ├── rk_aiq_types_af_algo.h
│   ├── rk_aiq_types_af_algo_int.h
│   └── rk_aiq_uapi_af_int.h
├── afec
│   ├── fec_algo.h
│   ├── rk_aiq_types_afec_algo.h
│   ├── rk_aiq_types_afec_algo_int.h
│   └── rk_aiq_uapi_afec_int.h
├── agamma
│   ├── rk_aiq_types_agamma_algo.h
│   ├── rk_aiq_types_agamma_algo_int.h
│   ├── rk_aiq_types_agamma_hw.h
│   └── rk_aiq_uapi_agamma_int.h
├── agic
│   ├── rk_aiq_types_algo_agic.h
│   ├── rk_aiq_types_algo_agic_int.h
│   └── rk_aiq_uapi_agic_int.h
├── ahdr

```

- └─ rk\_aiq\_types\_ahdr\_algo.h
- └─ rk\_aiq\_types\_ahdr\_algo\_int.h
- └─ rk\_aiq\_types\_ahdr\_stat\_v200.h
- └─ rk\_aiq\_uapi\_ahdr\_int.h
- └─ aie
  - └─ rk\_aiq\_types\_aie\_algo.h
  - └─ rk\_aiq\_types\_aie\_algo\_int.h
- └─ aldch
  - └─ rk\_aiq\_types\_aldch\_algo.h
  - └─ rk\_aiq\_types\_aldch\_algo\_int.h
  - └─ rk\_aiq\_uapi\_aldch\_int.h
- └─ alsc
  - └─ rk\_aiq\_types\_alsc\_algo.h
  - └─ rk\_aiq\_types\_alsc\_algo\_int.h
  - └─ rk\_aiq\_types\_alsc\_hw.h
  - └─ rk\_aiq\_uapi\_alsc\_int.h
- └─ anr
  - └─ rk\_aiq\_types\_anr\_algo.h
  - └─ rk\_aiq\_types\_anr\_algo\_int.h
  - └─ rk\_aiq\_types\_anr\_hw.h
  - └─ rk\_aiq\_uapi\_anr\_int.h
- └─ aorb
  - └─ rk\_aiq\_orb\_hw.h
  - └─ rk\_aiq\_types\_orb\_algo.h
- └─ asd
  - └─ rk\_aiq\_types\_asd\_algo.h
  - └─ rk\_aiq\_uapi\_asd\_int.h
- └─ assharp
  - └─ rk\_aiq\_types\_asharp\_algo.h
  - └─ rk\_aiq\_types\_asharp\_algo\_int.h
  - └─ rk\_aiq\_types\_asharp\_hw.h
  - └─ rk\_aiq\_uapi\_asharp\_int.h
- └─ awb
  - └─ rk\_aiq\_types\_awb\_algo.h
  - └─ rk\_aiq\_types\_awb\_algo\_int.h
  - └─ rk\_aiq\_types\_awb\_stat\_v200.h
  - └─ rk\_aiq\_types\_awb\_stat\_v201.h
  - └─ rk\_aiq\_types\_awb\_stat\_v2xx.h
  - └─ rk\_aiq\_uapi\_awb\_int.h
- └─ rk\_aiq\_algo\_des.h
- └─ common
  - └─ gen\_mesh
    - └─ genMesh.h
    - └─ genMesh\_static\_32bit
    - └─ genMesh\_static\_64bit
- └─ linux
  - └─ compiler.h
  - └─ rk-camera-module.h
  - └─ rk-led-flash.h
  - └─ v4l2-controls.h
  - └─ videodev2.h
- └─ mediactl
  - └─ mediactl.h
  - └─ mediactl-priv.h
  - └─ tools.h
  - └─ v4l2subdev.h
- └─ opencv2
- └─ calib3d

- └─ calib3d\_c.h
- └─ core
  - └─ core\_c.h
  - └─ cuda
    - └─ detail
  - └─ cv\_cpu\_dispatch.h
  - └─ cv\_cpu\_helper.h
  - └─ cvdef.h
  - └─ detail
  - └─ hal
    - └─ interface.h
    - └─ msa\_macros.h
  - └─ opencv
    - └─ runtime
      - └─ autogenerated
  - └─ types\_c.h
  - └─ utils
- └─ cvconfig.h
- └─ dnn
  - └─ utils
- └─ features2d
  - └─ hal
    - └─ interface.h
- └─ flann
  - └─ all\_indices.h
  - └─ allocator.h
  - └─ any.h
  - └─ autotuned\_index.h
  - └─ composite\_index.h
  - └─ config.h
  - └─ defines.h
  - └─ dist.h
  - └─ dummy.h
  - └─ dynamic\_bitset.h
  - └─ general.h
  - └─ ground\_truth.h
  - └─ hdf5.h
  - └─ heap.h
  - └─ hierarchical\_clustering\_index.h
  - └─ index\_testing.h
  - └─ kdtree\_index.h
  - └─ kdtree\_single\_index.h
  - └─ kmeans\_index.h
  - └─ linear\_index.h
  - └─ logger.h
  - └─ lsh\_index.h
  - └─ lsh\_table.h
  - └─ matrix.h
  - └─ nn\_index.h
  - └─ object\_factory.h
  - └─ params.h
  - └─ random.h
  - └─ result\_set.h
  - └─ sampling.h
  - └─ saving.h
  - └─ simplex\_downhill.h
  - └─ timer.h
- └─ gapi



- └─ cpu
- └─ fluid
- └─ gpu
- └─ infer
- └─ ocl
- └─ own
- └─ plaidml
- └─ render
- └─ streaming
- └─ util
- └─ highgui
  - └─ highgui\_c.h
- └─ imgcodecs
  - └─ imgcodecs\_c.h
  - └─ ios.h
  - └─ legacy
    - └─ constants\_c.h
- └─ imgproc
  - └─ detail
  - └─ hal
    - └─ interface.h
  - └─ imgproc\_c.h
  - └─ types\_c.h
- └─ lib
  - └─ 3rdparty
- └─ ml
- └─ objdetect
- └─ photo
  - └─ legacy
    - └─ constants\_c.h
- └─ stitching
  - └─ detail
- └─ video
  - └─ legacy
    - └─ constants\_c.h
- └─ videoio
  - └─ cap\_ios.h
  - └─ legacy
    - └─ constants\_c.h
  - └─ videoio\_c.h
- └─ rk\_aiq\_comm.h
- └─ rk\_aiq.h
- └─ rk\_aiq\_pool.h
- └─ rk\_aiq\_types.h
- └─ shared\_item\_pool.h
- └─ iq\_parser
  - └─ RkAiqCalibDbTypes.h
- └─ rkisp\_api.h
- └─ uAPI
  - └─ rk\_aiq\_user\_api\_a3dlut.h
  - └─ rk\_aiq\_user\_api\_ablc.h
  - └─ rk\_aiq\_user\_api\_accm.h
  - └─ rk\_aiq\_user\_api\_acp.h
  - └─ rk\_aiq\_user\_api\_adebayer.h
  - └─ rk\_aiq\_user\_api\_adehaze.h
  - └─ rk\_aiq\_user\_api\_adpcc.h
  - └─ rk\_aiq\_user\_api\_ae.h
  - └─ rk\_aiq\_user\_api\_afec.h

```

| | | | └─ rk_aiq_user_api_af.h
| | | | └─ rk_aiq_user_api_agamma.h
| | | | └─ rk_aiq_user_api_agic.h
| | | | └─ rk_aiq_user_api_ahdr.h
| | | | └─ rk_aiq_user_api_aldch.h
| | | | └─ rk_aiq_user_api_alsc.h
| | | | └─ rk_aiq_user_api_anr.h
| | | | └─ rk_aiq_user_api_asd.h
| | | | └─ rk_aiq_user_api_asharp.h
| | | | └─ rk_aiq_user_api_awb.h
| | | | └─ rk_aiq_user_api_debug.h
| | | | └─ rk_aiq_user_api_imgproc.h
| | | | └─ rk_aiq_user_api_sysctl.h
| | └─ xcore
| |   └─ base
| |     └─ xcam_common.h
| |     └─ xcam_defs.h
└─ rkmedia
    └─ rkmedia_adec.h
    └─ rkmedia_aenc.h
    └─ rkmedia_ai.h
    └─ rkmedia_ao.h
    └─ rkmedia_api.h
    └─ rkmedia_buffer.h
    └─ rkmedia_common.h
    └─ rkmedia_event.h
    └─ rkmedia_move_detection.h
    └─ rkmedia_occlusion_detection.h
    └─ rkmedia_rga.h
    └─ rkmedia_venc.h
    └─ rkmedia_vi.h
    └─ rkmedia_vo.h
└─ lib
    └─ libasound.so -> libasound.so.2.0.0
    └─ libasound.so.2 -> libasound.so.2.0.0
    └─ libasound.so.2.0.0
    └─ libavcodec.so -> libavcodec.so.58.35.100
    └─ libavcodec.so.58 -> libavcodec.so.58.35.100
    └─ libavcodec.so.58.35.100
    └─ libavformat.so -> libavformat.so.58.20.100
    └─ libavformat.so.58 -> libavformat.so.58.20.100
    └─ libavformat.so.58.20.100
    └─ libavutil.so -> libavutil.so.56.22.100
    └─ libavutil.so.56 -> libavutil.so.56.22.100
    └─ libavutil.so.56.22.100
    └─ libdrm.so -> libdrm.so.2.4.0
    └─ libdrm.so.2 -> libdrm.so.2.4.0
    └─ libdrm.so.2.4.0
    └─ libeasymedia.so -> libeasymedia.so.1
    └─ libeasymedia.so.1 -> libeasymedia.so.1.0.1
    └─ libeasymedia.so.1.0.1
    └─ libmd_share.so
    └─ libod_share.so
    └─ librga.so -> librga.so.2
    └─ librga.so.2 -> librga.so.2.0.0
    └─ librga.so.2.0.0
    └─ librkaiq.so
    └─ libRKAP_AEC.so

```

```
|─ libRKAP_ANR.so
|─ libRKAP_Common.so
|─ librockchip_mpp.so -> librockchip_mpp.so.1
|─ librockchip_mpp.so.0
|─ librockchip_mpp.so.1 -> librockchip_mpp.so.0
|─ libswresample.so -> libswresample.so.3.3.100
|─ libswresample.so.3 -> libswresample.so.3.3.100
|─ libswresample.so.3.3.100
|─ libv4l2.so -> libv4l2.so.0.0.0
|─ libv4l2.so.0 -> libv4l2.so.0.0.0
|─ libv4l2.so.0.0.0
|─ libv4lconvert.so -> libv4lconvert.so.0.0.0
|─ libv4lconvert.so.0 -> libv4lconvert.so.0.0.0
└─ libv4lconvert.so.0.0.0
```

## 6. Debug info

---

### 6.1 CPU debug info

#### 6.1.1 CPU frequency debug

##### 6.1.1.1 Print CPU frequency

```
# print current cpu frequency
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_cur_freq
1008000

# print cpu available frequencies
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_available_frequencies
408000 600000 816000 1008000 1200000 1296000
```

##### 6.1.1.2 Set CPU fixed frequency

```
# set CPU 600MHz fixed frequency
echo userspace > /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor
echo 600000 > /sys/devices/system/cpu/cpu0/cpufreq/scaling_setspeed
```

##### 6.1.2 Print CPU thermal

```
cat /sys/class/thermal/thermal_zone0/temp
```

### 6.1.3 Disable CPU thermal control

```
# disable thermal control
echo user_space > /sys/class/thermal/thermal_zone0/policy
# disable frequency limit
echo 0 > /sys/class/thermal/thermal_zone0/cdev0/cur_state
echo 0 > /sys/class/thermal/thermal_zone0/cdev1/cur_state
```

## 6.2 Encode debug info

### 6.2.1 Print encode frame rate

```
# enable print fps log
echo 0x100 > /sys/module/rk_vcodec/parameters/mpp_dev_debug

# disable print fps log
echo 0 > /sys/module/rk_vcodec/parameters/mpp_dev_debug
```

## 6.3 Print CIF info

```
cat /proc/rkcif_mipi_lvds
```

```
Driver Version:v00.01.08
Work Mode:ping pong
aclk_cif:500000000
hclk_cif:250000000
dclk_cif:297000000
Input Info:
    src subdev:m01_f_os04a10 1-0036-1
    interface:mipi csi2
    lanes:4
    vc channel: 0 1
    hdr mode: hdr_x2
    format:SBGGR10_1X10/2688x1520@30
    crop.bounds:(0, 0)/2688x1520
Output Info:
    format:BG10/2688x1520(0,0)
    compact:enable
    frame amount:79
    fps:30
    irq statistics:
        total:158
        csi over flow:0
        csi bandwidth lack:0
        all err count:0
        frame dma end:158
```

## 6.4 Print ISPP info

```
cat /proc/rkispp0
```

```
cat /proc/rkispp0
rkispp0      Version:v00.01.05
Input        rkispp0 Format:FBC420 Size:3840x2160 (frame:15441 rate:41ms delay:20ms)
Output       rkispp_m_bypass Format:FBC0 Size:3840x2160 (frame:15440 rate:41ms
delay:45ms)
Output       rkispp_scale0 Format:NV12 Size:1280x720 (frame:15440 rate:41ms
delay:45ms)
Output       rkispp_scale1 Format:NV12 Size:720x480 (frame:15440 rate:41ms
delay:45ms)
Output       rkispp_scale2 Format:NV12 Size:1280x720 (frame:15440 rate:41ms
delay:45ms)
TNR          ON(0xd00000d) (mode: 2to1) (global gain: disable) (frame:15441
time:12ms) CNT:0x0 STATE:0x1e000000
NR           ON(0x47) (external gain: enable) (frame:15441 time:12ms) 0x5f0:0x0
0x5f4:0x0
SHARP        ON(0x1b) (YNR input filter: ON) (local ratio: ON) 0x630:0x0
FEC          OFF(0x2) (frame:0 time:0ms) 0xc90:0x0
ORB          OFF(0x0)
Interrupt    Cnt:46278 ErrCnt:0
clk_ispp     500000000
aclk_ispp    500000000
hclk_ispp    250000000
```

## 6.5 Print ISP info

```
cat /proc/rkisp0
```

```
cat /proc/rkisp0
rkisp0      Version:v00.01.05
Input       rkcif_mipi_lvds Format:SGBRG10_1X10 Size:3840x2160@30fps Offset(0,0) |
RDBK_X1(frame:15584 rate:40ms)
Output      rkispp0 Format:FBC420 Size:3840x2160 (frame:15583 rate:39ms)
Interrupt   Cnt:62011 ErrCnt:0
clk_isp     594000000
aclk_isp    500000000
hclk_isp    250000000
DPCC0       ON(0x40000005)
DPCC1       ON(0x40000005)
DPCC2       ON(0x40000005)
BLS         ON(0x40000001)
SDG         OFF(0x80446197)
LSC         ON(0x1)
AWBGAIN     ON(0x80446197) (gain: 0x010d010d, 0x02260227)
DEBAYER     ON(0xf000111)
CCM         ON(0xc0000001)
GAMMA_OUT   ON(0xc0000001)
CPROC       ON(0xf)
IE          OFF(0x0) (effect: BLACKWHITE)
WDR         OFF(0x30cf0)
```

HDRTMO	ON(0xc8505a25)
HDRMGE	OFF(0x0)
RAWNR	ON(0xc0100001)
GIC	OFF(0x0)
DHAZ	ON(0xc0001009)
3DLUT	OFF(0x2)
GAIN	ON(0xc0010010)
LDCH	OFF(0x0)
CSM	FULL(0x80446197)
SIAF	OFF(0x0)
SIAWB	OFF(0x0)
YUVAE	ON(0x400100f3)
SIHST	ON(0x38000107)
RAWAF	ON(0x7)
RAWAWB	ON(0x4037e887)
RAWAE0	ON(0x40000003)
RAWAE1	ON(0x400000f5)
RAWAE2	ON(0x400000f5)
RAWAE3	ON(0x400000f5)
RAWHIST0	ON(0x40000501)
RAWHIST1	ON(0x60000501)
RAWHIST2	ON(0x60000501)
RAWHIST3	ON(0x60000501)