

GTEMP-0225 Rev 1

Replacing the Head and Chin Rest Collar



Note: You do not have to remove any covers to replace the head and chin rest collar.

1. Description

The head and chin rest collar is a piece of trim that fits to the top of the head and chin rest.

Tool Requirements

You must supply the following tools:

- Metric allen keys.
- Metric spanners.
- Flathead screwdriver.



Note: The tool references mentioned in this guide are ISO tool references.

Before Removing or Replacing the Head and Chin Rest Collar

Before removing or replacing the head and chin rest collar, make sure that:


- The unit is disconnected from the main power supply by switching off the circuit breaker in the electrical cabinet.
- The unit is switched off.
- You have the required tools.
- You have the appropriate new head and chin rest collar.

GTEMP-0225 Rev 1

2. Removing the Head and Chin Rest Collar

To remove the head and chin rest collar, follow these steps:

1. Slide off the plastic cover (A) .



GTEMP-0225 Rev 1

1. Remove the two screws. (B)
2. Remove the collar. (C)

3. Replacing the Head and Chin Rest Collar

To replace the head and chin rest collar, follow these steps:

1. Place the collar on the head and chin rest. (C)
2. Insert and tighten the two screws. (B)
3. Replace the plastic cover. (A)
4. Register the intervention.

LAST PAGE OF THE DOCUMENT