

Soundiation: User Manual

Last update: January 11, 2022


Contact: Tianquan Tang (tianquan@connect.hku.hk)

- *Soundiation* runs on Microsoft Windows with MATLAB 2010a or above versions installed.
- *Soundiation* supports parallel computation:
 - Parallel computation greatly reduces computational time, depended on the cores number of computer.
 - To enable parallel computation, we need to activate MATLAB parallel pool by simply typing

```
>> matlabpool;           % for MATLAB 2010a
```

or

```
>> parpool;
```

on Command Window before running the GUI.
- Start *Soundiation* in MATLAB:
 - Set the Current Folder direction to “.\Soundiation\src”:or type


```
>> addpath('<folderpath>\Soundiation\src');
```

on Command Window to open the interface.
 - Type

```
>> main_interface;
```

on Command Window to open the interface.

➤ Main interface



2. Parametric control panel

3. Functional panel and Control panel

➤ Result visualization panel

Figure 1:
Visualize the levitated particle.

Figure 2:
Visualize the position relationship between transducer array and the levitated particle.
(If **Transducer array (circular oscillator)** feature is selected)

Figure 4 to Figure 9:
Visualize the time-variation position and orientation.
(If **Transducer array (circular oscillator)** feature is selected)




Figure 3:
Visualize incident pressure wavefield.

Figure 10:
Visualize the time-variation trajectory. The solid line and the arrows indicate the translational and rotational motions, respectively.
(If **Transducer array (circular oscillator)** feature is selected)

➤ Parametric control panel (Overall)

Particle parameters:
Define the particle physical properties.

Boundary conditions:
Define the boundary condition of the particle.

Medium parameters:
Define the medium physical properties.

Calculation controls

Particle parameters

NOTE: if averaged radius changed, we have to re-select GEOs again.

Ellipsoidal particle

Cn [0.002 0 0.0004]

Particle density 15 kg/m³

Averaged radius 0.002 m

Initial position [0.002 0 0] m

Initial orientation [0 0 0] rad

Particle visualization

Boundary conditions

B.C. (default: Sound-hard)

Host-fluid parameters

Medium (default: Air)

Fluid density 1.224 kg/m³

Speed of sound 340 m/s

Dynamic viscosity 0.0000185 Pa s

Wavefront parameters

Frequency 40000 Hz

Integration radius 0.005 m

Transducer array (circular osci...)

Controls: plane-type wavefront

Pressure (amp) 1 Pa

Controls: transducer array

Transducer number 2

Transducer radius 0.005 m

Radial velocity (amp) 1.5 m/s

Interdistance 0.02 m

Transducer positions [0 0 0; 0.01 0 0] m

Phase delay [0 0] rad

Relative amplitude delay [1 1]

Transducer visualization

Wavefield (xOz plane)

Wavefront parameters:
Define the incident wavefield.

➤ Parametric control panel (Particle & Medium parameters, and B.C.)

Particle parameters

NOTE: if averaged radius changed, we have to re-select GEOs again.

Ellipsoidal particle

Cn [0.002 0 0.0004]

Particle density 15 kg/m³

Averaged radius 0.002 m

Initial position [0.002 0 0] m

Initial orientation [0 0 0] rad

Particle visualization

Visualize the geometry based on "Particle parameters" in **Figure 1** of "Result visualization panel".

Geometries (default: Spherical)

Geometries (default: Spherical)






Spherical particle

Ellipsoidal particle

Cone particle

Diamond particle

Others (user-specified 'Cn')



User-specified mapping coefficient:
Cn = [0.002 0 -0.0005 0 -0.00025]

Boundary conditions

B.C. (default: Sound-hard)

B.C. (default: Sound-hard)

Host-fluid Sound-hard B.C.

Sound-soft B.C.

Boundary conditions:

there are two common options, *sound-hard* (Neumann) and *sound-soft* (Dirichlet) conditions.

Host-fluid parameters

Medium (default: Air)

Medium (default: Air)

Fluid Air

Water

Speed of sound 340 m/s

Dynamic viscosity 0.0000185 Pa s

Medium:

there are two common options, *air* and *water* medium. The medium properties are automatically implanted once the "Medium popup menu" is selected.

➤ Parametric control panel (Wavefront parameters)

Wavefront parameters

Frequency

40000

Hz

Integration radius

0.005

m

Transducer array (circular osci...

▼

Wavefront (default: Plane wave) ▼

Wavefront (default: Plane wave)

Plane travelling wave

Transducer array (circular oscillator)

Controls: plane-type wavefront

Pressure (amp)

1

Pa

Controls: transducer array

Transducer number

2

Transducer radius

0.005

m

Radial velocity (amp)

1.5

m/s

Interdistance

0.02

m

Transducer positions

[0 0 0; 0.01 0 0]

m

Phase delay

[0 0]

rad

Relative amplitude delay

[1 1]

Transducer visualization

Transducer positions

[0 0 0; 0.01 0 0]

m

Phase delay

[0 0]

rad

Relative amplitude delay

[1 1]

Wavefield (xOz plane)

Frequency: set the operating frequency of incident wave.

Integration radius: define the spherical space that the acoustic fields are approximated by partial-wave expansion series;
(we found “integration radius ≈ 0.005 m” can get a high accurate radiation force and torque through validating with the full three-dimensional numerical simulations in COMSOL)

Visualize the acoustic pressure field in Figure 3 of “Result visualization panel”.

Pressure (amp): set the pressure amplitude of the incident plane wave.
(ONLY activated when the “Wavefront popup menu” selects Plane travelling wave feature)


Radial velocity (amp): set the radial vibration amplitude of the circular oscillator of the transducers.


Interdistance: set the initial vertical distance between the mass center of particle and transducer array.

Transducer positions: set the initial positions of transducer. Each row gives the x-, y-, and z-positions of a transducer.

Phase&Relative amplitude delay: set the phase and amplitude parameters of the transducer array.
(The above parameters ONLY activated when the “Wavefront popup menu” selects Transducer array (circular oscillator) feature)

Visualize the particle-transducer system based on “Particle parameters” and “Controls: Transducer array” parameters in Figure 2 of “Result visualization panel”.





➤ Functional panel and Control panel

**Prediction of the radiation
force and torque**

**Calculation the acoustophoretic
process of the particle**

Functions

Radiation force and torque

Radiation force N

Radiation torque N m

Calculation

Acoustophoresis for transducer array ONLY

Time step s ; Ending time s

Current calculated for time s

Calculation Data saved in:

Controls

Select saved figure: Save figure Reset Reset and Exit

**Save figures and Reset
parameters to default values**

➤ Functional panel

Radiation force and torque

Radiation force

Radiation torque

Present the predicted radiation force and torque:

Radiation force = $[-7.3206e-008 \ 8.2886e-020 \ 2.6585e-006]$ N,

Radiation torque = $[5.3267e-022 \ 3.7968e-010 \ -5.9868e-023]$ N · m;

i.e.,

$$\begin{cases} F_{\text{rad},x} = -7.3206 \times 10^{-8} \text{ N} \\ F_{\text{rad},y} = +8.2886 \times 10^{-20} \text{ N} \\ F_{\text{rad},z} = +2.6585 \times 10^{-8} \text{ N} \end{cases} \text{ and } \begin{cases} T_{\text{rad},x} = +5.3267 \times 10^{-22} \text{ N} \cdot \text{m} \\ T_{\text{rad},y} = +3.7968 \times 10^{-10} \text{ N} \cdot \text{m} \\ T_{\text{rad},z} = -5.9868 \times 10^{-23} \text{ N} \cdot \text{m} \end{cases}$$

Click on the “Calculation” button to predict the radiation force and torque.

Acoustophoresis for transducer array ONLY

Time step s; Ending time s

Current calculated for time s

Data saved in:

Click on the “Calculation” button to start the acoustophoretic prediction.

Time step: set the time step for iterative calculation of the particle dynamics.

Ending time: set the ending moment.


Current calculated for time: indicate the progress of the calculation.

Data saved in: specify the fold direction to save the data of the particle position and orientation at different moments in file “MyFilename.txt”.

Note: when the vertical distance between the mass center of particle and transducer array (i.e., the interdistance) small than 0.01 mm , we stop the dynamic calculation and regard the particle cannot be trapped.

(The above parameters **ONLY** activated when the “Wavefront popup menu” selects **Transducer array (circular oscillator)** feature)

➤ Control panel (Save figures, Reset and Exit)



➤ Template: saved data of particle acoustophoresis (MyFilename.txt)

```
1 %Computational parameters
2
3 Geometry = Ellipsoidal particle;
4     Cn = [0.002      0      0.0004];
5     Particle density = 15 [kg/m^3];
6     Particle radius = 0.002 [m];
7     Initial position = [0.002 0 0] [m];
8     Initial orientation = [0 0 0] [rad];
9
10 Boundary condition = B.C. (default: Sound-hard);
11
12 Medium = Medium (default: Air);
13     Fluid density = 1.224 [kg/m^3];
14     Fluid sound speed = 340 [m/s];
15     Fluid dynamic viscosity = 0.0000185 [Pa s];
16
17 Wave type = Transducer array (circular oscillator);
18     Frequency = 40000 [Hz];
19     Integration radius = 0.005 [m];
20     Transducer number = 2;
21     Transducer radius = 0.005 [m];
22     Transducer vibration radial velocity = 1.5 [m/s];
23     Interdistance between the particle and the array = 0.02 [m];
24     Transducer position matrix = [0 0 0; 0.01 0 0] [m];
25     Transducer phase delay = [0 0] [rad];
26     Transducer relative amplitude delay = [1 1];
27
28
29
```

Parameters saved in “MyFilename.txt”:
the saved computational parameters, including the particle parameters, the boundary condition, the medium parameters, and the wavefront parameters.

➤ Template: saved data of particle acoustophoresis (MyFilename.txt)

```
30 %Dynamic data:
31
32 Time [ms]      X_position [m]      Y_position [m]      Z_position [m]      X_angle [rad]      Y_angle [rad]      Z_angle [rad]
33 0.000000      0.002000      0.000000      0.000000      0.000000      0.000000      0.000000
34 0.100000      0.001990      0.000000      -0.000325      0.000000      0.010207      -0.000000
35 0.200000      0.001976      0.000000      -0.000642      0.000000      0.022184      -0.000000
36 0.300000      0.001959      0.000000      -0.000952      0.000000      0.036192      -0.000000
37 0.400000      0.001938      0.000000      -0.001255      0.000000      0.052507      -0.000000
38 0.500000      0.001913      0.000000      -0.001550      0.000000      0.071411      -0.000000
39 0.600000      0.001883      0.000000      -0.001840      0.000000      0.093175      -0.000000
40 0.700000      0.001847      0.000000      -0.002123      0.000000      0.118038      -0.000000
41 0.800000      0.001806      0.000000      -0.002401      0.000000      0.146180      -0.000000
42 0.900000      0.001759      0.000000      -0.002672      0.000000      0.177683      -0.000000
43 1.000000      0.001707      0.000000      -0.002938      0.000000      0.212502      -0.000000
44 1.100000      0.001649      0.000000      -0.003198      0.000000      0.250422      -0.000000
45 1.200000      0.001586      0.000000      -0.003451      0.000000      0.291036      -0.000000
46 1.300000      0.001521      0.000000      -0.003696      -0.000000      0.333745      -0.000000
47 1.400000      0.001455      0.000000      -0.003932      -0.000000      0.377769      -0.000000
48 1.500000      0.001389      0.000000      -0.004158      -0.000000      0.422205      -0.000000
49 1.600000      0.001328      0.000000      -0.004375      -0.000000      0.466098      -0.000000
50 1.700000      0.001272      0.000000      -0.004582      -0.000000      0.508538      -0.000000
51 1.800000      0.001223      0.000000      -0.004780      -0.000000      0.548753      -0.000000
52 1.900000      0.001182      0.000000      -0.004971      -0.000000      0.586172      -0.000000
53 2.000000      0.001150      0.000000      -0.005155      -0.000000      0.620451      -0.000000
54 2.100000      0.001127      0.000000      -0.005336      -0.000000      0.651449      -0.000000
55 2.200000      0.001112      0.000000      -0.005513      -0.000000      0.679183      -0.000000
56 2.300000      0.001105      0.000000      -0.005689      -0.000000      0.703768      -0.000000
57 2.400000      0.001106      0.000000      -0.005863      -0.000000      0.725379      -0.000000
58 2.500000      0.001112      0.000000      -0.006038      -0.000000      0.744217      -0.000000
59 2.600000      0.001124      0.000000      -0.006214      -0.000000      0.760493      -0.000000
60 2.700000      0.001141      0.000000      -0.006392      -0.000000      0.774424      -0.000000
61 2.800000      0.001162      0.000000      -0.006574      -0.000000      0.786230      -0.000000
62 2.900000      0.001186      0.000000      -0.006760      -0.000000      0.796141      -0.000000
63 3.000000      0.001213      0.000000      -0.006954      -0.000000      0.804413      -0.000000
64 3.100000      0.001241      0.000000      -0.007156      -0.000000      0.811333      -0.000000
65 3.200000      0.001270      0.000000      -0.007368      -0.000000      0.817254      -0.000000
66 3.300000      0.001301      0.000000      -0.007594      -0.000000      0.822613      -0.000000
67 3.400000      0.001331      0.000000      -0.007833      -0.000000      0.827991      -0.000000
```

Time-variant data saved in “MyFilename.txt”:
the saved position and orientation data of the particle in different moments.

