

Lab 11

Part B – 64 Bit Two-Level Priority Encoder

Description

- In this module, you will:
 1. setup a program that can communicate using a serial protocol over USB with the FPGA.
 - You can install this program either on your laptop or a lab computer, but the computer you choose to install on **must be able to connect to the FPGA normally with Vivado.**
 2. synthesize, implement, upload, and test a hardware description for a two-level priority encoder, encapsulated within a serial transceiver.



Procedure

Project Creation


1. Download the files below from Canvas and place them in a new folder titled `lab11b`.
 - Note: You may wish to separate the transceiver files from the 2LPE files as you will re-use the former in Parts C and D.
 - 2LPE Files – for Part B only
 - `mux_generic.vhd`
 - `priority_encoder_8.vhd`
 - `priority_encoder_64_2l.vhd`
 - Transceiver Files – for Parts B, C, and D
 - `basys3_mk8_apex.xdc`
 - `d_flip_flop.vhd`
 - `mk8_apex_64.vhd`
 - `mk8_container_lab11.vhd`
 - `mk8_rx_module.vhd`
 - `mk8_tx_module.vhd`
 - `mk8_xcvr_generic.vhd`
 - `synchronizer_2ff.vhd`
2. Open Vivado and create a new project titled appropriately.
 - If you have not memorized how to do this by now, consult a previous lab handout (ex. `06B`).
 - For your convenience, the board identifier is `xc7a35tcpg236-1`.
 - You can copy and paste this directly into the search bar in the device select menu.
 - You can also find the board with the same options as before: `General Purpose`, `Artix-7`, `cpg236`, `-1`.

3. Enable VHDL 2008 for the 2LPE file.

- To do this graphically:
 - In the **PROJECT MANAGER** pane, in the **Sources** subpane, expand the **apex** top-level component, and then its **hw : hw_container** subcomponent.
 - Click on the entry **encoder : priority_encoder_64**.
 - In the **Source File Properties** subpane below, look for the **Type** property. Click the three dots next to the box containing **VHDL**.



- In the dialog that opens, expand the dropdown and select **VHDL 2008**.




- Click **OK**.
- **Important:** Repeat for the **hw : hw_container** entry/file.

- Alternatively, you can open the **Tcl Console** subpane at the bottom by selecting the corresponding tab, and enter the following command:

```
set_property file_type {VHDL 2008} [get_files -filter {FILE_TYPE == VHDL}]
```

Adding the Clocking Wizard IP Core

4. On the left sidebar, at the bottom of the **PROJECT MANAGER** dropdown, click on **IP Catalog**.
5. In the search bar, type "clocking wizard", then **double-click** on the search result for Clocking Wizard.



6. In the clocking wizard dialog that opens, at the bottom under **Input Clock Information**, scroll to the right to reveal the **Source** column of the table. For the value in that column in the row for the "Primary" input clock, click the dropdown and switch it to **Global Buffer**.

- This step is critical, otherwise implementation will fail!

Clocking Options Output Clocks Port Renaming **MMCM Settings** Summary

Clock Monitor

☐ Enable Clock Monitoring

Primitive

☒ MMCM ☐ PLL

Clocking Features

☒ Frequency Synthesis ☐ Minimize Power

☒ Phase Alignment ☐ Spread Spectrum

☐ Dynamic Reconfig ☐ Dynamic Phase Shift

☐ Safe Clock Startup

Jitter Optimization

☒ Balanced

☐ Minimize Output Jitter

☐ Maximize Input Jitter filtering

Dynamic Reconfig Interface Options

☒ AXI4Lite ☐ DRP ☐ Phase Duty Cycle Config ☐ Write DRP registers

Input Clock Information

	Input Clock	Port Name	Input Frequency(MHz)		Jitter Options	Input Jitter	Source
<input checked="" type="checkbox"/>	Primary	clk_in1	100.000	10.000 - 800.000	UI	0.010	Single ended clock capable pi
<input type="checkbox"/>	Secondary	clk_in2	100.000	60.000 - 120.000		0.010	Single ended clock capable pin Differential clock capable pin Global buffer No buffer

- Near the top of the dialog, switch to the Output Clocks tab. Under the **Port Name** column, rename the port `clk_out` to `clk_100mhz`. Check the box in the **Output Clock** column labeled `clk_out2`. Rename the port to `clk_hw` in the **Port Name** column. In the same row, under **Output Freq (MHz)**, change **Requested** to `200.000`.

Clocking Options ¹ Output Clocks Port Renaming MMCM Settings Summary									
The phase is calculated relative to the active input clock.									
Output Clock	Port Name	Output Freq (MHz)		Phase (degrees)		Duty Cycle (%)		Drives	
		Requested	Actual	Requested	Actual	Requested	Actual		
<input checked="" type="checkbox"/> clk_out1 ²	clk_100mhz	100.000	100.000000	0.000	0.000	50.000	50.0	BUFG	
³ <input checked="" type="checkbox"/> clk_out2	clk_hw ⁴	200.000 ⁵	200.000000	0.000	0.000	50.000	50.0	BUFG	
<input type="checkbox"/> clk_out3	clk_out3	100.000	N/A	0.000	N/A	50.000	N/A	BUFG	
<input type="checkbox"/> clk_out4	clk_out4	100.000	N/A	0.000	N/A	50.000	N/A	BUFG	
<input type="checkbox"/> clk_out5	clk_out5	100.000	N/A	0.000	N/A	50.000	N/A	BUFG	
<input type="checkbox"/> clk_out6	clk_out6	100.000	N/A	0.000	N/A	50.000	N/A	BUFG	
<input type="checkbox"/> clk_out7	clk_out7	100.000	N/A	0.000	N/A	50.000	N/A	BUFG	

- Finally, click **OK** at the bottom right. A dialog may appear, if so, click **Generate**.


Hardware Review and Upload

- Follow along with the instructor to briefly review the hardware.
- Open **Elaborated Design**, review the schematic alongside the instructor, and **take screenshots for your report**.
 - Take a screenshot of the main schematic (no components expanded).
 - Expand the **hw** block, and then the **encoder** block inside it. Take a screenshot of just the two-level priority encoder.
- Run synthesis, implementation, and bitstream generation. Then, open the Hardware Manager.
 - Take a screenshot of the resource utilization (LUTs and FFs) to add to your report.**
- Before proceeding, plug the FPGA development board into your computer using the provided Micro-USB to USB-A cable.
- At the top, in the green banner (or under the **Open Hardware Manager** dropdown) click **Open Target**, then **Auto Connect**.
- Once the device is connected, select **Program Device** (in either of the locations where **Open Target** was previously).
 - See **06B-handout** for troubleshooting steps, or ask the instructor or TA.
- Click **Program** to upload the bitstream to the FPGA.

Enabling Serial Communication

16. Install the SerialTool program.

- Navigate to https://www.serialtool.com/_en/index.php.
- Click **Download** on the main page. This prompts a donation page.
- Click **Download** on the donation page. You do not have to donate.
- Download the appropriate version for your operating system:
 - Windows or Linux – MacOS is supported by SerialTool, but not by Vivado, so you will not be able to use a Mac for this.
- Run the installer.
 - If running on a lab computer, you will need to install "for me only."




- Other than that, it is fairly straightforward. You can accept all default settings, just keep clicking **Next**, until reaching the final page, and click **Finish**.


17. Run SerialTool.

- If you just installed it, it may start automatically.
- You will have to press one of three buttons to start the application.
 - It will tell you which, it is different every time you start it up. This is because the application is freeware.
- Note that each session (each time you launch the program) is limited to 100 packets. However, this is will not be an issue for the scope of our lab work unless you spam data over the serial connection far beyond what is instructed in this handout.


18. Select the first option on the sidebar (a gear with a serial connector).



- Alternatively:
 - Top menu bar: **Controls**
 - First option: **Serial Port Configuration**



19. At the bottom of the dialog that appears, if no ports are already shown, **Scan Serial Ports**.



The image shows the 'Serial Port Configuration' dialog box. At the top is a table with columns: Device, Description, Alias, Change Serial, and Action. Below the table, the 'Selected Port' and 'Status' are shown as 'Not assigned to any serial.' Configuration options include BaudRate (9600), Bits (8), Parity (NONE), Stop Bits (1), Flow Control (None), RTS (SET at start), and DTR (SET at start). There are checkboxes for 'Open COM Port automatically (AutoStart)' and 'Serial Reading Thread in LOOP Mode'. The 'Last Byte timeout (ms)' is set to 50. At the bottom, there is a 'Number of Serial Ports' dropdown set to 1, a 'Scan Serial Ports' button (highlighted with a red box), a 'Save Configuration' button, a 'Reset Serials' button, and a 'Help' button.

Device	Description	Alias	Change Serial	Action
--------	-------------	-------	---------------	--------

Selected Port: **Status:** Not assigned to any serial.

BaudRate: 9600 Bits: 8 Parity: NONE Stop Bits: 1

Flow Control: None RTS: ☐ SET at start DTR: ☐ SET at start


☐ Open COM Port automatically (AutoStart)

☐ Serial Reading Thread in LOOP Mode

Last Byte timeout (ms): 50

Number of Serial Ports: 1 **Scan Serial Ports** Save Configuration Reset Serials Help

20. A serial port should appear. Click the dropdown that says **NOT ASSIGNED**, then click **1**:




The image shows the 'Serial Port Configuration' dialog box after scanning. The table now contains one entry: Device 1, Description '[COM6] - USB Serial Port FTDI', Alias '1', Change Serial 'NOT ASSIGNED', and Action 'OPEN'. The 'Change Serial' dropdown menu is open, showing options 'NOT ASSIGNED', '1', and '2'. The option '1' is highlighted with a red box.

Device	Description	Alias	Change Serial	Action
1	[COM6] - USB Serial Port FTDI	1	NOT ASSIGNED NOT ASSIGNED 1 2	OPEN

21. Use the following (mostly default) configuration:


- BaudRate: 9600
- Bits: 8
- Parity: NONE
- Stop Bits: 1
- **Serial Reading Thread in LOOP Mode: Checked**
 - This setting is the only one that is not default, you will need to check this box.
 - If you do not, SerialTool will prompt you to do so after the next step.

22. Click **OPEN** on the port:




23. Close the dialog box (*not* the serial port!) if it does not disappear automatically.

24. On the sidebar, click the **HEX** terminal button, shown below. Your screen should then appear how it does on the right side of the image below.



- Alternatively, on the top menu, click **View**, then **Hex Terminal**.

25. Select the **HEX** radio button at the top.



Hardware Testing and Analysis

26. The text box that is by default filled with `000102030405060708090a0b0c0d0e0f` is what you are sending to the FPGA.

- Remove the last half, so that what remains is `0001020304050607`. This is 64 bits in hexadecimal.

27. Press **SEND** to send the data to the FPGA. For the two-level priority encoder, you should receive a response that looks like this:

Session Packets List:				Hex Terminal:																
				Timestamp	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
00000000	1712536794.790	1	→	8	[01<<P:000001]	07/04/2024@20:39:54.790	00	01	02	03	04	05	06	07						
00000001	1712536794.865	1	←	8	[01<<P:000002]	07/04/2024@20:39:54.865	00	00	00	00	00	00	30							

- How to read this:
 - The pane on the left:
 - The blue is transmission and the red is receipt.
 - The decimal number is the timestamp (in unix time).
 - The column labeled with what looks like a ruler is the transmission length, in bytes.
 - For this module, it will be 8.
 - The pane on the right:
 - This will show both incoming and outgoing data.

28. If entering an input that is not all zeroes, you should also see the leftmost LED light up. This is the **valid** output.

29. Press the center button (**reset**) to reset the transceiver and prepare it for the next transmission.

30. Repeat for each input below (the first is provided again for you). Do your results match the expected output?

- Note that everything is in hexadecimal.
- Do not enter spaces into SerialTool, the spaces are there only to help you read the inputs.

Input	Expected Output	Valid LED
0001 0203 0405 0607	30	1
0000 0000 0000 0000	00	0
0000 0000 0000 0001	00	1
8000 0000 0000 0000	3F	1
0123 4567 89AB CDEF	38	1
0000 0F50 0B20 0A70	2B	1

31. Take a screenshot of the SerialTool window after testing all the inputs above, to attach to your lab report.

Deliverables

- Include as part of your **informal report**:
 - A screenshot of the Elaborated Design schematic (Step 10)
 - A screenshot of the FPGA resource utilization (LUTs, FFs) (Step 11)
 - A screenshot of SerialTool containing your testing results (Step 30)
 - A brief comment on whether your experimental results match the expected results.

Outcomes

- Practice working with VHDL.
- Practice using Vivado for hardware synthesis and implementation.
- Practice programming and testing a hardware description on an FPGA development board.
- Understand how to use serial communication to test hardware descriptions.
- Learn how to use a serial communication software to send data to and receive data from an FPGA development board.
- Learn how to add an Intellectual Property (IP) Core to a Vivado project.
- Learn how to use an onboard MMCM to generate a faster clock from the base 100 MHz clock on the FPGA development board.