

release.txt

## **GSFLOW Release Notes**

This file describes changes introduced into GSFLOW with each official release. These changes include enhancements and bug fixes that extend applicability of the software but may also affect simulation results.

NOTE: Any use of trade, product, or firm names is for descriptive purposes only and does not imply endorsement by the U.S. Government. Although this software has been developed and used by the USGS, no warranty, expressed or implied, is made by the USGS or the U.S. Government as to its accuracy and functionality and related material, nor shall the fact of distribution constitute any such warranty, and no responsibility is assumed by the USGS in connection therewith.

### **CONTENTS**

Abstract .....	2
System Requirements .....	3
Input-File Instructions .....	3
Documentation and Additional Resources .....	4
Functionality .....	5
Release History .....	7
Current Version .....	7
A. PRMS Modules .....	8
B. MODFLOW Packages .....	18
C. GSFLOW Modules .....	19
Previous Versions .....	20

## **ABSTRACT**

GSFLOW is a coupled Groundwater and Surface-Water Flow model based on the integration of the U.S. Geological Survey Precipitation-Runoff Modeling System (PRMS; Markstrom and others, 2015) and the U.S. Geological Survey Modular Groundwater Flow Model (MODFLOW-2005, Harbaugh, 2005; MODFLOW-NWT, Niswonger and others, 2011). In addition to the basic PRMS and MODFLOW simulation methods, several additional simulation methods were developed and existing PRMS modules and MODFLOW packages were modified to facilitate integration of the models. Methods were developed to route flow among the PRMS Hydrologic Response Units (HRUs), between HRUs and the MODFLOW finite-difference cells, and between HRUs and streams and lakes. PRMS and MODFLOW have similar modular programming methods, which allow for their integration while retaining independence that permits substitution of, and extension with, additional PRMS modules and MODFLOW packages.

GSFLOW was developed to simulate coupled groundwater/surface-water flow in one or more watersheds by simultaneously simulating flow across the land surface, within subsurface saturated and unsaturated materials, and within streams and lakes. Climate data consisting of measured or estimated precipitation, air temperature, and solar radiation, as well as groundwater stresses (such as withdrawals) and boundary conditions are the driving factors for a GSFLOW simulation. GSFLOW can be used to evaluate the effects of such factors as land-use change, climate variability, and groundwater withdrawals on surface and subsurface flow. The model incorporates well documented methods for simulating runoff and infiltration from precipitation; balancing energy and mass budgets of the plant canopy, snowpack, and soil zone; and simulating the interaction of surface water with groundwater in watersheds that range from a few square kilometers to several thousand square kilometers, and for time periods that range from months to several decades. An important aspect of GSFLOW is its ability to conserve water mass and to provide comprehensive water budgets.

GSFLOW allows for three simulation modes—coupled (GSFLOW), PRMS-only, and MODFLOW-only. The capability of having PRMS-only and MODFLOW-only simulations in GSFLOW allows incremental model setup that provides flexibility in model calibration.

GSFLOW operates on a daily time step. In addition to the MODFLOW variable-length stress period used to specify changes in stress or boundary conditions, GSFLOW uses internal daily stress periods for adding recharge to the water table and calculating flows to streams and lakes. Only the first stress period specified in the MODFLOW input files can be designated as steady state for integrated simulations. No computations pertaining to PRMS are executed for an initial steady-state stress period.

There have been several applications of GSFLOW to real-world systems since the initial release of the software in 2008. Many of these applications are referenced on the USGS GSFLOW webpage (<http://water.usgs.gov/ogw/gsfLOW/index.html>).

## SYSTEM REQUIREMENTS

GSFLOW is written in the Fortran 90 and C programming languages. The code has been used on personal computers running various forms of the Microsoft Windows operating system and Linux based computers.

## INPUT-FILE INSTRUCTIONS

Instructions for preparing input files for GSFLOW were provided with the first release of GSFLOW as Appendix 1 in Markstrom and others (2008). Since that time, new functionality has been added to the software; parameters and variables have been added, modified, and deleted; and some of the original functionality has been removed. As a result, it has been necessary to update the original input instructions with each new release of GSFLOW.

Instructions for preparing input files for the current version of GSFLOW (version 1.2.0) can be found in three resources; users are encouraged to review these resources when developing a GSFLOW model:

**GSFLOW-specific instructions:** The file 'GSFLOW\_Input\_Instructions.pdf' is located in the 'doc' subdirectory of the GSFLOW release. This file includes descriptions and tables of the GSFLOW and PRMS modules and MODFLOW packages available in GSFLOW, as well as GSFLOW-specific input parameters and output variables. In addition, PRMS modules and MODFLOW packages that are not available in GSFLOW are identified. Input instructions provided in this file supersede some of the information found in Appendix 1 in Markstrom and others (2008), which provides a general discussion of the terminology, styles, and formats of GSFLOW inputs and the definitions of each of the GSFLOW input files.

**PRMS Files:** Up-to-date specifications for PRMS version 4.0.1 dimensions, parameters, and input and output variables, as well as a brief description of each PRMS module, are provided in several tables on the PRMS-IV software distribution page: [ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS\\_tableUpdates\\_4.0.1.pdf](ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS_tableUpdates_4.0.1.pdf) In addition, documentation for the `nhru_summary`, `map_results`, and `climate_hru` modules can be found in the 'Related reports' subdirectory of the 'doc' directory of the GSFLOW distribution folder.

**MODFLOW Files:** Up-to-date descriptions of the input requirements for all MODFLOW-2005 and MODFLOW-NWT Packages and Processes are provided in the *Online Guide to MODFLOW-2005* (<http://water.usgs.gov/ogw/modflow/MODFLOW-2005-Guide/>) and *Online Guide to MODFLOW-NWT* (<http://water.usgs.gov/ogw/modflow-nwt/MODFLOW-NWT-Guide/>).

## DOCUMENTATION AND ADDITIONAL RESOURCES

**GSFLOW:** Documentation and additional resources for GSFLOW are available at <http://water.usgs.gov/ogw/gsflow/index.html> and [http://wwwbrr.cr.usgs.gov/projects/SW\\_MoWS/GSFLOW.html](http://wwwbrr.cr.usgs.gov/projects/SW_MoWS/GSFLOW.html). PDFs of the three reports listed below are provided in the 'doc' subdirectory of the GSFLOW release folder.

Henson, W.R., Medina, R.L., Mayers, C.J., Niswonger, R.G., and Regan, R.S., 2013, CRT—Cascade routing tool to define and visualize flow paths for grid-based watershed models: U.S. Geological Survey Techniques and Methods, book 6, chap. D2, 28 p., <http://pubs.usgs.gov/tm/tm6d2/>.

Markstrom, S.L., Niswonger, R.G., Regan, R.S., Prudic, D.E., and Barlow, P.M., 2008, GSFLOW—Coupled ground-water and surface-water flow model based on the integration of the precipitation-runoff modeling system (PRMS) and the modular ground-water flow model (MODFLOW–2005): U.S. Geological Survey Techniques and Methods, book 6, chap. D1, 240 p., <http://pubs.usgs.gov/tm/tm6d1/>.

Regan, R.S., Niswonger, R.G., Markstrom, S.L., and Barlow, P.M., 2015, Documentation of a restart option for the U.S. Geological Survey coupled groundwater and surface-water flow (GSFLOW) model: U.S. Geological Survey Techniques and Methods, book 6, chap. D3, 19 p., <http://dx.doi.org/10.3133/tm6D3/>.

**PRMS and MODFLOW:** Documentation and additional resources for PRMS and MODFLOW are available at [http://wwwbrr.cr.usgs.gov/projects/SW\\_MoWS/PRMS.html](http://wwwbrr.cr.usgs.gov/projects/SW_MoWS/PRMS.html) and <http://water.usgs.gov/ogw/modflow/>, respectively.

Harbaugh, A.W., 2005, MODFLOW-2005, the U.S. Geological Survey modular ground-water model--the Ground-Water Flow Process: U.S. Geological Survey Techniques and Methods 6-A16, variously paginated.

Leavesley, G.H., Lichty, R.W., Troutman, B.M., and Saindon, L.G., 1983, Precipitation-runoff modeling system--User's manual: U.S. Geological Survey Water-Resources Investigations Report 83-4238, 207 p.

Leavesley, G.H., Restrepo, P.J., Markstrom, S.L., Dixon, M., and Stannard, L.G., 1996, The Modular Modeling System (MMS): User's manual: U.S. Geological Survey Open-File Report 96-151, 142 p.

Markstrom, S.L., Regan, R.S., Hay, L.E., Viger, R.J., Webb, R.M.T., Payn, R.A., and LaFontaine, J.H., 2015, PRMS-IV, the precipitation-runoff modeling system, version 4: U.S. Geological Survey Techniques and Methods, book 6, chap. B7, 158 p., <http://dx.doi.org/10.3133/tm6B7>.

Niswonger, R.G., Panday, Sorab, and Ibaraki, Motomu, 2011, MODFLOW-NWT, A Newton formulation for MODFLOW-2005: U.S. Geological Survey Techniques and Methods 6-A37, 44 p.

Niswonger, R.G., Prudic, D.E., and Regan, R.S., 2006, Documentation of the Unsaturated-Zone Flow (UZF1) Package for modeling unsaturated flow between the land surface and the water table with MODFLOW-2005: U.S. Geological Survey Techniques and Methods 6-A19, 62 p.

Niswonger, R.G., and Prudic, D.E., 2005, Documentation of the Streamflow-Routing (SFR2) Package to include unsaturated flow beneath streams—A modification to SFR1: U.S. Geological Survey Techniques and Methods 6-A13, 50 p.

Viger, R.J., Hay, L.E., Jones, J.W., and Buell, G.R., 2010, Effects of including surface depressions in the application of the Precipitation-Runoff Modeling System in the Upper Flint River Basin, Georgia: U.S. Geological Survey Scientific Investigations Report 2010-5062, 36 p.

## **FUNCTIONALITY, Version 1.2.0**

**PRMS Modules and Utility Routines** (listed in computation order; **new** indicates ‘new for version 1.2.0’; all are modules, unless noted; modules `strmflow_lake` and `prms_summary`, which are included with PRMS-IV are not included with GSFLOW)

<code>basin</code>	Basin Module
<code>cascade</code>	Cascading-Flow Module
<code>climateflow</code>	Climate and Flow Parameters and Variables Input (Utility Routine)
<code>prms_time</code>	Time Variable Computation (Utility Routine) ( <b>new</b> )
<code>soltab</code>	Potential Solar-Radiation Module
<code>obs</code>	Observed-Data Module
<code>temp_1sta</code>	One-Station Air-Temperature-Distribution Module
<code>temp_laps</code>	Lapse-Station Air-Temperature-Distribution Module
<code>temp_dist2</code>	Inverse-Distance Air-Temperature-Distribution Module
<code>precip_1sta</code>	One-Station Precipitation-Distribution Module
<code>precip_laps</code>	Lapse-Station Precipitation-Distribution Module
<code>precip_dist2</code>	Inverse-Distance Precipitation-Distribution Module
<code>xyz_dist</code>	Multiple Linear Regression Precipitation and Temperature-Distribution Module
<code>ide_dist</code>	Inverse distance and elevation Precipitation and Temperature-Distribution Module ( <b>new</b> )
<code>climate_hru</code>	Pre-computed and Distributed climate Module
<code>frost_date</code>	Preprocess Spring and Fall Frost Module ( <b>new</b> )
<code>ddsolrad</code>	Degree-Day Solar-Radiation Distribution Module
<code>ccsolrad</code>	Cloud-Cover Solar-Radiation Distribution Module

potet_jh	Jensen-Haise Potential-Evapotranspiration Module
potet_hamon	Hamon Potential-Evapotranspiration Module
potet_pan	Pan-Evaporation Potential-Evapotranspiration Module
potet_hs	Hargreaves and Samani Potential-Evapotranspiration Module (new)
potet_pt	Priestly–Taylor Potential-Evapotranspiration Module (new)
potet_pm	Penman–Monteith Potential-Evapotranspiration Module (new)
transp_frost	Frost Based Active Transpiration Period Module (new)
transp_tindex	Temperature Index Based Active Transpiration Period Module
intcp	Precipitation-Interception Module
snowcomp	Snow Module
srnoff_smidx	Nonlinear source Area Surface-Runoff and Infiltration Module
srnoff_carea	Linear Source Area Surface-Runoff and Infiltration Module
soilzone	Soil-Zone Module
gwflow <sup>1</sup>	Ground-Water Reservoir Module
subbasin	Subbasin Module
routing <sup>1</sup>	Stream Network Computations Routing (Utility Routine) (new)
strmflow <sup>1</sup>	Streamflow Module
muskingum <sup>1</sup>	Muskingum Streamflow Routing Module (new)
strmflow_in_out <sup>1</sup>	Streamflow routing with inflow equals outflow for each segment (new)
water_balance	Water Balance Debug (Utility Routine) (new)
nhru_summary	Nhru Based Summary Output Module
basin_sum <sup>1</sup>	Watershed Flow-Summary Module
map_results <sup>1</sup>	Map Based Output Module
write_climate_hru	Generate Climate-by-HRU Files(Preprocess Routine)

<sup>1</sup>This module is used for PRMS-only simulations.

<sup>2</sup>Note that the names of PRMS modules are different than those shown in the GSFLOW manual (TM 6-D1) and in previous release notes. A warning message is printed if an old name is used, but the code is downward compatible so users do not need to change the old module names.

### **MODFLOW Packages**

BAS	Basic Package
BCF	Block-Centered Flow Package
UPW	Upstream-Weighting Flow Package
LPF	Layer-Property Flow Package
HUF	Hydrogeologic-Unit Flow Package
HFB	Horizontal Flow Barrier Package
WEL	Well Package
GHB	General Head Boundary Package
FHB	Flow and Head Boundary Package

CHD	Time-Variant Specified-Head Option
UZF	Unsaturated-Zone Flow Package
SFR	Streamflow-Routing Package
LAK	Lake Package
GAG	Gage Package
MNW1	Version 1 of the Multi-Node Well Package
MNW2	Version 2 of the Multi-Node Well Package
SIP	Strongly Implicit Procedure Package
DE4	Direct Solver Package
PCG	Preconditioned-Conjugate Gradient Package
GMG	Geometric Multi-Grid Solver Package
NWT	Newton Solver Package
OBS	Observation Process (only BAS, CHD, and GHB )

### **GSFLOW Modules**

gsflow_prms	Computational-Sequence Control for PRMS and GSFLOW
gsflow_modflow	Computational-Sequence Control for MODFLOW Module
gsflow_prms2mf	PRMS to MODFLOW Integration Module
gsflow_mf2prms	MODFLOW to PRMS Integration Module
gsflow_budget	Watershed-Budget Summary Module
gsflow_sum	Flow-Components Summary Module

## **RELEASE HISTORY**

### **Current Version, 1.2.0 (August 1, 2015)**

This version of GSFLOW is based on MODFLOW-NWT version 1.0.9, MODFLOW-2005 version 1.11.0, and PRMS version 4.0.1. Substantial enhancements were added for this version of the software, in particular the inclusion of a restart capability for GSFLOW (Regan and others, 2015) and the integration of several (but not all) of the new PRMS-IV modules documented by Markstrom and others (2015). The restart capability is fully documented in Regan and others (2015); no additional information about the capability is included in these release notes. Those PRMS-IV modules that have been included with this version of GSFLOW are identified above in the 'PRMS Modules' functionality list. All of the new modules are described in detail by Markstrom and others (2015). Some input and output options are not available in the current GSFLOW release, such as those related to the `strmflow_lake` module.

In addition to the major enhancements, a number of bug fixes and slight modifications have been made to the software; those bug fixes and modifications that are more than simply cosmetic are described below, beginning with changes to the PRMS Modules and then progressing to changes to the MODFLOW Packages and GSFLOW Modules.

## A. PRMS Modules

The PRMS version (4.0.1) included in GSFLOW version 1.2 is based on PRMS-IV as documented in Markstrom and others (2015), with the addition of the flexible-dimension option (described below) and new modules and parameters; minor bug fixes; additional checks for valid input values; and general code clean-up. Code clean-up was done with the following objectives: (a) to reduce mixed floating-point computations by changing some variables to double precision (and some to single precision) and using FORTRAN intrinsic functions to convert variables prior to mixed-precision computations—this change might produce slight changes to results for associated computations; (b) to reduce HRU based loops; and (c) to increase consistency of screen output. Note: for large models, users can reduce the size of the input Parameter Files by not including parameters for which the PRMS-assigned default values represent the needs of the application. A message is printed to the screen for each parameter that is used in a simulation at its default value and is not specified in the Parameter File. For example, if the default value of **careas\_max**, which is 0.6, is the value needed for all HRUs, that parameter does not need to be specified in the Parameter File.

Detailed descriptions of changes made for PRMS version 4.0.1 are described in the PRMS release notes included with the PRMS distribution ([http://wwwbrr.cr.usgs.gov/projects/SW\\_MoWS/PRMS.html](http://wwwbrr.cr.usgs.gov/projects/SW_MoWS/PRMS.html)). Changes in the specification of user inputs are reported as updates to tables in the Users' Manual (tables 2, 1-2, 1-3, and 1-5). The following sections highlight some of the more important changes.

### General Updates and Enhancements

- Flexible dimension option: Previously, parameters had only one option for the number of values [that is, the dimension(s)] specified in the Parameter File. Now, many parameters can be specified using the original dimension(s) or using compatible dimensions up to a maximum number of values based on the specified dimension(s). For example, some parameters had a maximum dimension of **nmonths** and now have a maximum dimension of **nhru,nmonths**. Possible dimensions for a parameter with a maximum dimension of **nhru,nmonths** are **one**, **nmonths**, **nsub**, **nsub**, **nmonths**, **nhru**, and **nhru,nmonths**. Possible dimensions for a parameter with a maximum dimension of **nhru** are **one**, **nsub**, and **nhru**. Possible dimensions for a parameter with a maximum dimension of **nssr** are **one**, **nsub**, and **nssr**. Possible dimensions for a parameter with a maximum dimension of **ngw** are **one**, **nsub**, and **ngw**. GSFLOW will read the dimension and number of values and load the parameter array used in the model to the maximum dimension. Thus, the user has several options to specify the number of parameter values based on the spatial and temporal variability of the parameter, available data, or some other modeling purpose. As the number of HRUs is increased, the specified parameter values to the maximum dimension the amount of memory used for an execution will be greater by the memory difference between the original maximum number values



and new maximum number of values. The maximum number of values for most parameters has not changed. Maximum parameter dimensions are identified in PRMS-IV updated tables 1-1 and 1-3 ([ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS\\_tableUpdates\\_4.0.1.pdf](ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS_tableUpdates_4.0.1.pdf)).

The flexible dimension option was added to accommodate simulation of large model domains that require increased spatial and/or temporal distribution of parameter values. Additionally, the number of lines in Parameter Files can be significantly reduced by specifying a single (dimension **one**) or **nsub** values for parameters that have a constant value for all HRUs or subbasins. This capability may change results when dimensions are specified to be greater than the original dimension(s). If the parameter dimensions are not changed, results should be the same. However, some computations in the `ddsolrad` and `ccsolrad` modules are based on variables for each HRU rather than basin-wide variables, so the potential solar radiation (variable `swrad`) can be significantly different than previous versions for large model domains.

An example of a parameter with a maximum number of values equal to **nhru** that might have the same value for all HRUs when specified as a regular grid is **hru\_area**. In this case, the area of each HRU can be specified as:

```
####  
hru_area  
1  
one  
2  
90.0
```

- The short-hand method for specification of parameter values as described on pages 4-5 in the 'GSFLOW\_v1.1.3\_Updates.pdf' document included in the GSFLOW distribution is deprecated and no longer supported. While this option is available with this GSFLOW release, it is recommended that users do not use it and that they convert any existing models to use the flexible dimension option.
- Surface-Depression Storage: Simulation of surface-depression storage is supported with this version of GSFLOW. See Markstrom and others (2015) and Viger and others (2010) for a description of this option, as well as the updated PRMS-IV [tables 1-3 and 1-5](#) ([ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS\\_tableUpdates\\_4.0.1.pdf](ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS_tableUpdates_4.0.1.pdf)) for descriptions of all current surface-depression input and computed results.
- Restart option (or Use of Initial Conditions Files option): This option has been enhanced with bug fixes. Modules affected: `potet_pan`, `transp_tindex`, `temp_dist2`, `obs`, `gwflow`, `intcp`, `climateflow`, `temp_1sta`, `temp_laps`,

`srunoff_smidx`, `srunoff_carea`, `snowcomp`, `soilzone`, `transp_tindex`, `basin_sum`, and `xyz_dist`. Restart code removed from `subbasin` module.

- **Solar Radiation and ET:** Modifications made to the solar-radiation modules described on page 15 may lead to noticeable changes in simulation results for areally extensive basins in which there are large contrasts in topographic relief throughout the basin. For example, the modifications led to changes in simulated results for the Sagehen GSFLOW model distributed with the release because of the large relief in the basin and presence of north- and south-facing slopes.

### **New Modules and Utility Routines**

- Several new PRMS modules have been added for this GSFLOW release (`ide_dist`, `potet_hs`, `potet_pt`, `potet_pm`, `transp_frost`, `frost_date`, `muskingum`, and `strmflow_in_out`). See the PRMS-IV documentation manual for complete descriptions of these modules and online [table 2](#) for brief descriptions of each module (as well as table 1 in “GSFLOW\_Input\_Instructions.pdf”).
- `nhru_summary` module: Output CSV files of user-selected output variables (see ‘`nhru_summary.pdf`’ in the ‘`doc\Related reports`’ subdirectory of the GSFLOW distribution file.
- `routing`: A utility routine to compute segment variables used with stream-routing modules `muskingum` and `strmflow_in_out`. Most code for this routine was originally in the `muskingum` module.
- `prms_time`: A utility routine to set time-related variables for each time step that are used by most other modules. Most code was originally in the `obs` module.
- `water_balance`: A utility routine to compute debug water budgets for the major hydrologic processes when control parameter **`print_debug`** is specified equal to 1. Code for this utility was originally in modules `intcp`, `soilzone`, `srunoff_smidx`, `srunoff_carea`, `snowcomp`, and `gwflow`.

### **New Parameters**

#### **New Parameters Specified in the Control File**

- **`parameter_check_flag`**: A 0 value means perform parameter-range checks on a number of parameters, such as **`soil_moist_max`**, **`soil_rechr_max`**, **`smidx_coef`**, **`smidx_exp`**, **`covden_win`**, **`covden_sum`**, and **`hru_aspect`**, and to treat some of those parameter-range checks as WARNINGS, as done for most parameters in previous versions; if specified as 1, these checks are treated as ERRORS; if specified as 2, the parameters are checked and then the simulation stops, even if no ERRORS are found; default value = 1. Modules affected: `potet_jh`,

- `precip_dist2`, `precip_laps`, `soilzone`, `soltab`, `srunoff_smidx`, and `srunoff_carea`. It is recommended that a value of 1 be used for initial simulations so that possible parameter specifications are within valid ranges.
- **cbh\_check\_flag**: A 0 value means do not check values in CBH file; 1 means to check for invalid values (for example, less than lower bound or greater than upper bound), reading past the end of file during a simulation, and non-sequential time series, such as not having the correct number of days in each year; default value = 1. Specifying **cbh\_check\_flag** equal to 0 should only be done after the CBH file(s) are verified using **cbh\_check\_flag** specified equal to 1. Setting **cbh\_check\_flag** equal to 0 can reduce execution time.
  - **cbh\_binary\_flag**: A 0 value means all CBH Files are text files, the only option in previous versions; 1 means all CBH files are in binary format and generated using the same input order of values as would be done for a text CBH File.
  - **humidity\_cbh\_flag**: Flag to specify to read a CBH File with humidity values (0=no; 1=yes; default = 0).
  - **humidity\_day**: File name of the humidity CBH file; this can be a full or relative path.
  - **windspeed\_cbh\_flag**: Flag to specify to read a CBH file with wind-speed values (0=no; 1=yes; default = 0).
  - **windspeed\_day**: File name of the wind-speed CBH file; this can be a full or relative path.
  - **print\_debug**: New option added: specifying a -1 value minimizes warning messages and other messages printed to the screen during a simulation, such as the current stress period and time step and when values of parameter **soil\_rechr\_max** is specified greater than **soil\_moist\_max**. This can reduce execution time.

#### New Parameters and Dimensions Specified in the Parameter File(s)

- **potet\_cbh\_adj(nhru,nmonths)**: Calibration coefficient for values specified in a **potet\_day** CBH file; valid range 0.5 to 1.5; default value = 1.0.
- **snowpack\_init(nhru)**: Initial snowpack-water equivalent, in inches; valid range 0.0 to 500.0; default value = 0.0.
- **tmax\_allrain\_sta(nrain,nmonths)**: Monthly (January to December) maximum air temperature when precipitation is assumed to be all rain; if the maximum air temperature at a precipitation-measurement station is greater than or equal to this value, then precipitation is assumed to be all rain; default value = 38.0. Parameter **tmax\_allrain(nhru,nmonths)** is used to determine the form of values distributed to HRUs. Specified for module `ide_dist`.
- **tmax\_allsnow\_sta(nrain,nmonths)**: Monthly (January to December) maximum air temperature when precipitation is assumed to be all snow; if the maximum air temperature at a precipitation-measurement station is less than or equal to this value, then precipitation is assumed to be all snow; default value = 32.0.

Parameter **tmax\_allsnow(nhru,nmonths)** is used to determine the form of precipitation values distributed to HRUs. Specified for module `ide_dist`.

- **tmax\_allrain\_dist(nmonths)**: Maximum air temperature when parameter **adjust\_snow(nhru,nmonths)** is used precipitation adjustment assumed to be all rain; if the computed HRU maximum air temperature is greater than or equal to this value, precipitation is all rain, default = 38.0. Parameter **tmax\_allrain(nhru,nmonths)** is used to determine the form of precipitation values distributed to HRUs. For exiting models, users need to add parameter **tmax\_allrain\_dist** as a copy of the existing parameter **tmax\_allrain**. Both parameters are required for models using module `xyz_dist`.
- **tmax\_allsnow\_dist(nmonths)**: Maximum air temperature when precipitation is assumed to be all snow; if the computed HRU maximum air temperature is less than or equal to this value, precipitation is all snow, default = 32.0. Parameter **tmax\_allsnow(nhru,nmonths)**: Maximum air temperature when precipitation is assumed to be all rain; is used to determine the form of values distributed to HRUs. Parameter **tmax\_allsnow(nhru,nmonths)** is used to determine the form of precipitation values distributed to HRUs. For exiting models, users need to add parameter **tmax\_allsnow\_dist** as a copy of the existing parameter **tmax\_allsnow**. Both parameters are required for models using module `xyz_dist`.

### Parameters and Variables Removed

See the PRMS-IV updated [tables](#)

([ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS\\_tableUpdates\\_4.0.1.pdf](ftp://brrftp.cr.usgs.gov/pub/mows/software/prms/4.0.1/PRMS_tableUpdates_4.0.1.pdf)) for descriptions of these parameters.

### Parameters Specified in the Control File

- **soilzone\_module**: Not needed because the `soilzone` module is always active.

### Parameters and Dimensions Specified in Parameter Files

- **adj\_by\_hru**, **rain\_sub\_adj**, and **snow\_sub\_adj** parameters that were specified for module `climate_hru` are unnecessary because parameters **rain\_adj** and **snow\_adj** can have the dimensions (**nsub,nmonths**) due to the new flexible in the dimension capability; thus, when using `climate_hru` for the precipitation distribution module use **rain\_adj(nsub,nmonths)** and **snow\_adj(nsub,nmonths)** to replace **rain\_sub\_adj** and **snow\_sub\_adj**.
- **hru\_ssres**, **ssr\_gwres**, and **hru\_gwres** parameters are not needed as **nhru** must equal **nssr** and **ngw**.
- **basin\_area** parameter is not needed as it is computed based on **hru\_area**.
- **nform**: this dimension removed as it is not used.
- **form\_data**: this input variable removed as it is not used.
- **snow**: input variable named changed to **snowdepth** to be more explicit about its meaning.

### Screen Output Changes

- Increased consistency of screen output for module descriptions, HRU identification numbers, and dates.
- When module `climate_hru` is active for more than one type of CBH file, the module description is printed for each climate type. For example, if `climate_hru` is used to input temperature and precipitation values, a line is printed with the `climate_hru` version identification for the active Temperature Distribution and Precipitation Distribution modules. Previously, the identification was printed once no matter how many climate types were input using `climate_hru`.

### Changes by Process

#### Input Data

`climate_hru` module:

- Allows CBH Files to be input in binary format when control parameter **`cbh_binary_flag`** is specified equal to 1.
- Values for CHB Files are not checked for having valid values unless control parameter **`cbh_check_flag`** is specified equal to 1 (default value); setting this parameter to 0 can reduce execution time.
- Humidity and wind speed CBH Files can be input, which are needed for new module `potet_pm`.
- Parameters to adjust precipitation by subbasin are no longer used because parameters **`snow_cbh_adj`** and **`rain_cbh_adj`** can be dimensioned (**`nsub,nmonths`**) using the flexible dimension option. Thus, models that used the subbasin specification need to be updated to remove parameters **`adj_by_hru`** and **`hru_subbasin`** and names for parameters **`snow_sub_adj`** and **`rain_sub_adj`** changed to **`snow_cbh_adj`** and **`rain_cbh_adj`**, respectively.
- Values in potential evapotranspiration CBH Files can be adjusted using new parameter **`potet_cbh_adj`**.

`obs` module:

- Removed dimension **`nform`** and variable *`form_data`* because they are not used, users need to remove both of these if they are specified in a Data File.
- Variable named *`snow`* changed to *`snowdepth`*. Users need to make this change if snow depth is specified in a Data File.
- Code related to time step moved to new `prms_time` utility routines.
- Values in Data File no longer checked for NaN values. This can reduce execution time.

## Climate

- Parameters used in equations optionally can use two-dimensional arrays (**nhru,nmonths**) to add spatial variation for large models. However, this change is backward compatible with existing models. Modules affected: `precip_1sta`, `precip_laps`, `precip_dist2`, `xyz_dist`, and `climate_hru` (parameters **tmax\_allrain**, **tmax\_allsnow**, **adjmix\_rain**); `temp_1sta`, `temp_laps`, and `xyz_dist` (parameters **tmax\_adj(nhru,nmonths)**, **tmin\_adj(nhru,nmonths)**); `temp_1sta` (parameters **tmax\_lapse(nhru,nmonths)** and **tmin\_lapse(nhru,nmonths)**).
- Small values ( $< 1.0E-05$ ) of input precipitation are not ignored. This was done because in some cases—such as with output from General Circulation Models—computed precipitation could include small values. Modules affected: `precip_1sta`, `precip_laps`, `climate_hru`, and `xyz_dist`.
- Added error check for computed values of  $tmin > tmax$  when determining form of precipitation. Modules affected: `climate_hru`, `ide_dist`, `precip_1sta`, `precip_laps`, and `xyz_dist`.
- Modules `temp_1sta` and `temp_laps`: the initial value used to replace a missing value was changed from 50.0 to the value of **tmax\_allrain(start\_month)**; this only affects the first time step. **Bug fix**: if too many missing values (greater than parameter **max\_missing**) are found, an error message is printed and the execution stops, instead of continuing.
- Modules `xyz_dist` and `ide_dist`: values of measured precipitation as specified in the Data File were used in calculations that could change the original value; thus, if these values were output, they may not match the values specified in the Data File. Now the modules use new arrays that are originally set to the measured values and allowed to be modified in computations, but not affect input values.
- Module `xyz_dist`: error check added to be sure that at least two climate stations are in the Data File.
  - Parameters **adjust\_snow** and **adjust\_rain** have maximum dimensions (**nrain,nmonths**) because the adjustments are applied to measured precipitation from the Data File instead of (**nmonths**). This change does not affect existing models.
  - Added parameters **tmax\_allsnow\_dist** and **tmax\_allrain\_dist(nmonths)**; these are the used to determine the form of the measured precipitation specified in the Data File. For existing models, users need to add copies of **tmax\_allsnow** and **tmax\_allrain** to the Parameter File and then change the copies to have the parameter names **tmax\_allsnow\_dist** and **tmax\_allrain\_dist**. Thus, all four parameters must be specified. The **tmax\_allsnow** and **tmax\_allrain** parameters are used to determine the form of HRU distributed precipitation values and now have maximum dimensions (**nhru,nmonths**).

## Solar Radiation

ccsolrad and ddsolrad modules:

- Some solar radiation equations were dependent on basin-area weighted average and monthly varying parameter values. All computations are now computed based on parameters for each HRU. **This can lead to noticeable changes in results for larger basins.** For example, in the `ccsolrad` module, a single cloud cover fraction was computed for the current month based on a basin value for minimum and maximum temperature and monthly cloud cover parameter values. Now, the cloud cover fraction is computed based on the HRU daily minimum and maximum temperature and values of the cloud-cover parameters that can be specified for each HRU and month. Similarly, in module `ddsolrad` the degree-day and radiation adjustment values are computed for each HRU instead of as basin-wide values.
- `ddsolrad` module: **Bug fix:** if the computed radiation-adjustment factor based on parameters `dday_slope` and `dday_intcp` is greater than the value of parameter `radmax`, it is set to `radmax` rather than as computed. The check was added as a precaution and to be consistent with module `ccsolrad`.
- **Bug fix:** modules incorrectly assumed that the simulation time period was always winter for Southern Hemisphere applications. This meant that solar radiation adjustment values as specified by parameter `radj_wppt` were always used for models located in the Southern Hemisphere; thus, values for parameter `radj_sppt` were not used.
- **Bug fix:** check added to be sure at least one value of parameter `hru_solsta` is specified greater than 0 when dimension `nsol` is specified greater than 0. If all values of `hru_solsta` were specified equal to 0, an array would be referenced beyond its memory limit, which could produce errant results or cause the simulation to abort.

## Potential Evapotranspiration

- Module `potet_pan`: **Bug fix:** added check to be sure pan evaporation data are included in the Data File. Added check for values of parameter `hru_pansta` specified greater than dimension `nevap` or equal to 0. If either condition or no pan evaporation data are in the Data File, an error message(s) is printed and execution stops.
- Module `potet_jh`: Added check for values of parameter `jh_coef_hru` specified greater than 150 or less than -50 and values of `jh_coef` specified greater than 10 or less than -1; if true, a warning message is printed when control parameter `parameter_check_flag` is specified equal to 0; else, an error message is printed and execution stops.

## Canopy

- Module `transp_tindex`: **Bug fix:** When the value of parameter `transp_end` equals the current month and the current day is the first day of the month, transpiration is turned off (variable `transp_on` is set to 0) and the related local

- variables, *transp\_check* and *tmax\_sum*, are set to 0. After this check, if the current month equals the value of parameter **transp\_beg**, *transp\_check* and *tmax\_sum* are checked to determine if transpiration needs to be turned on if the value of *tmax\_sum* is greater than the value of parameter **transp\_tmax**. If true, variable *transp\_on* is set to 1, *transp\_check* is set to 1, and *tmax\_sum* is set to 0. Previously, the checks were reversed, which could keep transpiration on for a few days in a month, depending on the value of *tmax\_sum* when the values of **transp\_beg** and **transp\_end** were specified equal to each other.
- Parameters used in equations optionally can use two-dimensional arrays (**nhru,nmonths**) or one-dimensional arrays (**nhru**) to add spatial variation for large models. However, this change is backward compatible with existing models. Modules affected: `intcp` (parameters **epan\_coef(nhru,nmonths)** and **potet\_sublim(nhru)**).
  - Module `intcp`: snow interception on an HRU is computed based on any precipitation on the HRU rather than also in the basin. Previously, snow interception in the canopy was not computed on HRUs if precipitation occurred anywhere in the basin. **This could lead to noticeable change in results for large models**, but, may not affect results for small basins.

#### Cascades

- Code related to cascading flow in stream segments and lakes removed. Cascade variables related to groundwater cascades changed to double precision.
- Two groundwater cascade arrays were initialized **ngw** number of times instead of once. This fix slightly reduces execution time for PRMS-only simulations.
- Tolerance used to check for the fraction leaving an HRU or GWR adding up to exactly 1.0 was changed from 1.00001 to 1.001. If this check finds an issue, the cascade links are adjusted.

#### Snow Dynamics (module `snowcomp`)

- Added check to be sure values of *snowcov\_area* are not equal to zero when a snowpack exists. This would be very rare and only possible when the first value of a snow-depletion curve was specified equal to zero.
- Checks were added to be sure *pkwater\_equiv* is set to 0.0 if it is computed as negative. For example, there was the possibility that the snowpack water equivalent was computed as a value < 0 when the amount of free water in the snowpack was less than the computed amount of free water that the snowpack could hold. Though this condition is likely very rare, it could have resulted in **very slight differences** in results in to the value of variables *pkwater\_equiv*, *pk\_depth*, and *snowmelt*.
- Bug fix**: Computation of snowpack density and snowpack depth are computed based on a finite-difference approximation, which produced slightly incorrect results for days when new snow falls when a snowpack does not exist. This bug



could produce significant errors when the new snowfall is large compared to the existing snowpack.

- Canopy density on each HRU for each time step is used in computations instead of only values of parameter **covden\_win**. This could result in **noticeable changes in results** when snow falls on a day during the transpiration period (growing season) and the value of **covden\_sum** is significantly different than the value of **covden\_win** for an HRU.
- If values for parameters **den\_init** and/or **den\_max** are specified less than 1.0E-06, they are set to 1.0E-06 instead of 0.1 and 0.6, respectively.
- **Bug fix:** If values of **cov\_type** were specified equal to 4 (coniferous), the computed convection-condensation value that is based on parameter **cecn\_coef** was not reduced by half as it should for all tree types. Specifying **cov\_type** equal 4 is not fully implemented and is treated the same as **cov\_type** equal 3. Few models are believed to have used **cov\_type** equal 4; those that did could see differences in results related to the snowpack.

#### Surface Runoff (modules `srunoff_smidx` and `srunoff_carea`)

- Added check for values of parameter **carea\_max** specified greater than 1.0; if true, an error message is printed and execution stops.
- Added check for the computation of the maximum contributing area for module `srunoff_smidx` based on the values of parameters **smidx\_coef**, **smidx\_exp**, and **soil\_moist\_max**. If the maximum contributing area for any HRU is greater than 2.0, a warning message is printed if control parameter **parameter\_check\_flag** specified equal to 1. When this condition is true, it indicates that the values of **smidx\_coef** and **smidx\_exp** can be insensitive as compared to the values of **carea\_max**, thus increasing values of **smidx\_coef** or **smidx\_exp** could have no effect on computed results.

#### Soilzone Processes (module `soilzone`)

- Error check added for interflow computation for the equation  $\text{SQRT}(\text{coef\_lin}^{**2.0} + 4.0 * \text{coef\_sq} * \text{ssres\_in}) = 0.0$ ; if true, a divide by 0 would have occurred; this would have been a very rare condition if ever.
- **Bug fix:** Corrected setting of variable *soil\_zone\_max* to account for parameter **soil\_moist\_max** only being applicable to the pervious area of each HRU. This does not affect other soilzone computations, just the values of variables *soil\_zone\_max* and *soil\_moist\_frac*, which are computed results that are not used in other computations.
- Water-balance check when control parameter **print\_debug** = 1 was incorrect when swale HRUs are present because the computed evaporation from swale HRUs was not included in the water-balance equation.
- Added checks for computed infiltration less than 0.0 and computed interflow coefficient equal to 0.0; these conditions would not likely occur.

- Can remove from the Parameter File parameter **gvr\_hru\_id** when dimensions **nhru** equals **nhrucell**.

#### Groundwater flow (module `gwflow`)

- Values of parameter **gwflow\_coef** that are specified greater than 1.0 are now allowed; a warning is issued in this case.
- **Bug fix:** Any water added due to specified values of parameter **gwstor\_min** was incorrectly added twice.
- Warning checks of some parameters used incorrect array index; thus, the value printed was incorrect.
- If any HRUs were specified as inactive, then the parameter values of all remaining HRUs were not checked for being valid values.

#### Output Reports (modules `basin_sum` and `map_results`)

- Module `map_results`: (a) Added option to output daily mapped results (parameter **mapvars\_freq** specified equal to 7). (b) Notes: the units of output variables are equal to the units of the variable for **mapvars\_units** specified equal to 0. Units for variables could be, for example, inches, inches/day, degrees Fahrenheit, and degrees Celsius. However, when the **mapvars\_units** value is specified greater than 0, the units of all selected **map\_results** output variables as specified by control parameter **mapOutVar\_names** must have units of either inches or inches/day, because the code only converts inches to a metric unit. (c) **Bug fix:** if parameter **mapvars\_freq** was specified equal to 4 the yearly results were not computed.
- Module `basin_sum`: Water-balance computations did not include water in stream segments when using the `muskingum` module or surface-depression storage computations. Water-balance computations are only computed when control parameter **print\_debug** is set to 1.
- **Bug fix:** Previous versions used variable *basin\_stflow\_in* instead of *basin\_stflow\_out* to set the basin-outflow variable *basin\_cfs*; this bug only occurred when the `muskingum` module was active.
- Can remove from the Parameter File parameters **gvr\_hru\_id**, **gvr\_cell\_id** and **gvr\_cell\_pct** when dimensions **nhru** equals **nhrucell**.

## **B. MODFLOW Packages**

GSFLOW version 1.2.0 is based on MODFLOW-NWT version 1.0.9, as well as updates that have been made to MODFLOW-2005 version 1.11.0. Since the last GSFLOW release (version 1.1.6) there have been two MODFLOW-NWT releases (versions 1.0.8 and 1.0.9) and two MODFLOW-2005 releases (versions 1.10.00 and 1.11.0). Changes

made to MODFLOW-NWT and MODFLOW-2005 are described in the release notes for those codes; users are encouraged to review those release notes in addition to the notes provided below.

#### Specific notes on the MODFLOW Packages:

1. Although the current release versions of MODFLOW-NWT (1.0.9) and MODFLOW-2005 (1.11.0) include the Seawater Intrusion (SWI2) Package, GSFLOW version 1.2 does not. Other Packages that are distributed with MODFLOW-NWT and MODFLOW-2005 that are not a part of GSFLOW (as described in the original GSFLOW documentation by Markstrom and others, 2008) are the RCH, EVT, ETS, IBS, SUB, DRT, RIV, DRN, and RES Packages, as well as the STR, SWR (MODFLOW-NWT only), SWT, LMT, SWI, and HYDMOD Packages and capabilities. The PCGN Solution Package also was removed for this version of GSFLOW.

2. Changes made to MODFLOW-NWT since the version 1.0.9 release are the following: (a) a minor bug was fixed that relates to simulating unsaturated-zone flow beneath lakes; (b) some variables in the SFR2 Package were initialized; and (c) some variables in the UZF Package for calculating runoff were initialized.

3. Multi-Node Well (MNW2) Package: A bug was fixed to correct budget calculations when the UPW Package was used with MNW2.

### C. GSFLOW Modules

Changes to the GSFLOW Modules are:

1. Previous versions of GSFLOW required that a PRMS Parameter File be specified in the Control File for a MODFLOW-only simulation. The code has been updated so that the user no longer needs to specify a PRMS Parameter File for a MODFLOW-only simulation. Thus, for a MODFLOW-only simulation, the Control File could be as short as the following example for the Sagehen Creek GSFLOW model distributed with the software:

```
Control File for a MODFLOW-only simulation, Sagehen Creek Watershed
####
model_mode
1
4
MODFLOW
####
modflow_name
1
4
../input/modflow/sagehen.mf.nam
```

Note, however, that for restart simulations, the user also will need to specify control parameters **modflow\_time\_zero**, **start\_time**, and **end\_time**.

2. A bug was discovered in the conversion of time units from MODFLOW to GSFLOW units. Previous versions of the code assumed that all MODFLOW time units were in days. MODFLOW models that used units other than days resulted in incorrect GSFLOW results. The code was changed to allow time units other than days to be used for MODFLOW input, as defined through variable ITMUNI that is specified within the Discretization (DIS) file. The bug required modifications be made to the `gsflow_budget`, `gsflow_sum`, `gsflow_prms2mf`, and `gsflow_mf2prms` modules.

3. Another small change was made in the calculation of change in storage for all lakes used for printing the budget to the overall GSFLOW budget. This change had a small effect on values of lake-storage change printed to the CSV and GSFLOW budget files.

4. Code was added to the `gsflow_prms` module to check for deprecated-module names. If these names are found, a warning message is printed. To maintain compatibility with previous versions of the software, the deprecated-module name is set to the current name.

## **Previous Versions**

### **Version 1.1.6 03/20/2013:**

This version of GSFLOW is based on MODFLOW-2005 version 1.9.01, MODFLOW-NWT version 1.0.7, and PRMS version 3.0.5. A number of enhancements and bug fixes have been done for this release. All of the updates are described in file "GSFLOW\_v1.1.6\_Updates.pdf."

### **Version 1.1.5 01/15/2012:**

This version of GSFLOW is based on MODFLOW-2005 version 1.8, MODFLOW-NWT version 1.0.3, and PRMS version 3.4179. Several enhancements and bug fixes have been done for this release. Important enhancements include addition of the Newton Formulation for MODFLOW and the Map Results and Climate by HRU Distribution Modules for PRMS. All of the updates are described in the files "GSFLOW\_v1.1.5\_Updates.pdf," "Map\_results.pdf," "Climate\_hru.pdf," "Appendix1\_Tables\_v1.1.5.pdf," and "SFR2\_for\_GSFLOW\_v1.1.5.pdf."

#### **Version 1.1.4 06/01/2011:**

This version of GSFLOW is based on MODFLOW-2005 version 1.8 and PRMS version 2.3116. Users are encouraged to review the release materials for MODFLOW-2005 for a full description of updates made for version 1.8.

A number of changes and bug fixes were made for this release. The modifications are grouped by PRMS modules and MODFLOW Packages.

#### **PRMS Modules:**

Potential Solar Radiation Module (`soltab_hru_prms.f`): The area-weighted mean basin latitude was computed incorrectly for models having inactive cells. This bug affected the computation of potential solar radiation on a horizontal plane for the basin latitude and snow computations involving solar radiation.

Cascading-Flow Module (`cascade_prms.f`): The default values for **hru\_down\_id** and **gw\_down\_id** were changed from 1 to 0. If an HRU is determined to be a swale, an error message is issued and the simulation stops if the value of **hru\_type** is not specified with the value 3.

Ground-Water Reservoir Module (`gwflow_casc_prms.f`): Units for variables *gw\_in\_ssr*, *gw\_in\_soil*, and *gwres\_in* were computed in units of inches. They are now computed in units of acre-inches, as documented.

Surface-Runoff and Infiltration Modules (`srunoff_smidx_casc.f` and `srunoff_carea_casc.f`): Evaporation from impervious areas of HRUs is now computed at the potential evapotranspiration rate rather than at the rate of unsatisfied potential evapotranspiration. Also, a check was added to `srunoff_carea_casc.f` to be sure the computed contributing area used to compute surface runoff does not exceed 1.0. This check is made for each HRU for each time step.

Lapse-Station Temperature-Distribution Module (`temp_laps_prms.f`): If the altitudes of the temperature-measurement stations used to compute lapse rates are equal, the code sets the difference to 1.0 in units based on the value of **elev\_units**. This was done to avoid divide by zero.

Precipitation-Distribution Modules (`precip_prms.f`, `precip_laps_prms.f`, `precip_dist2_prms`, `xyz_dist.f`): If the computed maximum and minimum air temperatures are equal, the difference is set to 0.01 degrees Fahrenheit. Also, for module `precip_laps_prms.f`, if the altitudes of precipitation measurement stations used to compute lapse rates are equal, the code sets the difference to 1.0 in units based on the value of **elev\_units**. This was done to avoid divide by zero.

## **MODFLOW Packages:**

Lake Package (gwf2lak7.f): Corrected two bugs. The first caused the package to incorrectly set the uppermost active cell beneath a lake cell to **NLAY**. The second occurred in the calculation of outflow to a stream for specified outflow diversions; the lake stage was not being set correctly.

Unsaturated-Flow Package (gwf2uzf1.f and gwfuzfmodule.f): Added deallocate statements for the variables **CHECKTIME**, **MORE** and **LAYNUM**. The default value for the variable **SURFDEP** was changed from 1.0 to 1.0x10-6.

Streamflow-Routing Package (gwf2sfr7.f and gwfsfrmodule.f): Modifications were made to correct the effects of lakes inundating stream cells. Seepage in inundated stream cells was not being set to zero in the budget routine.

## **Version 1.1.3 03/01/2011:**

This version of GSFLOW is based on MODFLOW-2005 version 1.8. Users are encouraged to review the release materials for MODFLOW-2005 for a full description of updates made for version 1.8. This version of GSFLOW includes (1) the new Grid Report Module, (2) enhanced input options for the PRMS Parameter File, (3) a new option for the SFR2 Package to specify streamflows to simulated stream segments in tabular files that are external to the SFR2 main input file, and (4) several other smaller modifications and enhancements. All of the updates are described in the file 'GSFLOW\_v1.1.3\_Updates.pdf' provided in the .\doc\GSFLOW subdirectory. Revised input instructions for the SFR2 Package (for use with GSFLOW) are provided in file 'SFR2\_for\_GSFLOW\_v1.1.3.pdf' in the same directory. The Appendix 1 tables ('Appendix1\_Tables\_v1.1.3.pdf') also have been updated for the new Grid Report Module. Users are encouraged to review the updated documents.

## **Version 1.1.2 07/23/2010:**

This version of GSFLOW is based on MODFLOW-2005 version 1.8. Users are encouraged to review the release materials for MODFLOW-2005 for a full description of updates made for version 1.8.

### **Documentation Issues:**

1. A new version of PRMSmanual.pdf was added to the 'doc' subdirectory to replace the previous, corrupted version.
2. An updated version of Appendix1\_Tables\_v1.1.pdf has been added to the 'doc\GSFLOW' subdirectory with the following changes:

a. Table A1-19 (Soil-Zone Module): parameters **ssr2gw\_exp**, **ssr2gw\_rate**, and **ssstor\_init** can only have the dimension **nssr**. Thus, delete "or **nhrucell**" from the dimension column. Also, parameter **ssrmax\_coef** is no longer used and should be removed from Parameter Files. (Table A1-18 in the GSFLOW manual, USGS TM6-D1 should also be updated.)

b. Table A1-4: Dimensions one, nmonths, and ndays no longer need to be specified in a GSFLOW Parameter File. (Table A1-4 in USGS TM6-D1 should also be updated.)

Note on dimension parameters **nhru**, **nssr**, and **ngw**:

The three dimension parameters **nhru**, **nssr**, and **ngw**, which are specified in the dimensions section of the PRMS Parameter File, must all be equal when running GSFLOW in either PRMS-only or GSFLOW modes. If the three parameters are not equal, a message will be written to the user's screen and the parameters will be set equal to one another by the code.

Unsaturated-Zone Flow Package (gwf2uzf1.f):

1. An enhancement was done to increase the internal check made by UZF of the ratio of *ROOTDEPTH* to the thickness of the cell from 0.90 to 0.99.
2. Fixed memory out-of-bounds bug for array *BOTM* when **IUZFBND** was specified as less than zero. This problem was fixed by taking the absolute value of **IUZFBND** when used to access arrays.

Cascade Module (cascade\_prms.f):

Added check to ignore any cascade links that have invalid values specified for parameters **hru\_up\_id** or **gw\_up\_id**, such as less than 1 or greater than dimension **nhru**.

Subbasin Computation Module (subbasin\_prms.f):

If the code is executed in GSFLOW mode, subbasin streamflow variables will not be calculated.

Precipitation- and Temperature-Distribution Modules

(precip\_dist2\_prms.f and temp\_dist2\_prms.f):

Added input-data check to be sure that at least one climate station has a valid value for both precipitation and air temperature for each time step (as specified in the Data File). If all values of precipitation and air temperature are invalid for a time step, such as might occur if all values are specified as missing, a message is printed to the user's screen and the simulation is terminated.

Soil-Zone Module (soilzone\_prms.f):

1. Added a variable that saves the current version-date of the module. This variable is written to the *gsflow.log* file.
2. Enhanced debug option: If **print\_debug**, which is specified in the GSFLOW Control File, is set to 7, messages related to inconsistencies in the soil-zone input parameters are

written to the new file `soilzone_prms.dbg` in the user's current directory. Previously, these warning messages were written to the user's screen.

3. Added check to determine if swale HRUs are generating water storage (ponding on the surface) in excess of three times the specified value of parameter **sat\_threshold**. If this is the case, a message is written to the `soilzone_prms.dbg` file if `print_debug` has been specified as 7. It is recommended that users set **print\_debug** to 7 for initial GSFLOW simulations, and that the `soilzone_dbg` file be examined to identify any parameter inconsistencies or potential problems with swale discretization prior to calibrating a model.

GSFLOW Computation-Control Module (`gsflow_prms.f`):

Added a variable that saves the current version date of the module. This variable is written to the `gsflow.log` file.

GSFLOW Conversion Factors Module (`gsflow_setconv.f`):

Bug fix: Fixed possible use of incorrect index for arrays *Gwc\_row* and *Gwc\_col*.

GSFLOW Integration Module (`gsflow_prms2mf.f`):

1. Added input-data check to be sure that if an HRU is specified as a lake, the associated MODFLOW lake id is specified other than 0 for parameter **lake\_hru\_id**. If an error is detected, an error message is printed to the user's screen and model execution is terminated.
2. Corrected the computation of the number of soilzone computations per time step, which is printed in tabular form to the `gsflow.log` file.
3. Fixed a bug that caused the possible override of computed flows in transient GSFLOW simulations with flows specified in MODFLOW input files. Any specified flows in the MODFLOW input files are used in steady-state mode and ignored in transient mode of a GSFLOW simulation.

GSFLOW Summary Module (`gsflow_sum.f`):

Fixed the values reported for total basin precipitation and evaporation to include lake precipitation and evaporation.

### **Version 1.1.1 02/12/2010:**

This version of GSFLOW is based on MODFLOW-2005 version 1.8, which includes the Multi-Node Well version 2 Package. Additional minor changes also were made to version 1.8 that are explained in the MODFLOW-2005 release documents.

Added module `transp_tindex_prms`: This module is used to determine the active period of plant transpiration. The module is based on code previously located in the `potet_jh_prms`, `potet_hamon_hru_prms`, and `potet_pan_prms` modules. Therefore, those modules were changed as well.



Module snowcomp\_prms:

1. A new output variable has been added:

*basin\_snowdepth*, which is the basin area-weighted average snow depth.

Module soilzone\_prms:

1. Three new output variables have been added:

*gw\_recharge\_day*, which is the sum of *soil\_to\_gw* and *ssr\_to\_gw* for each HRU for each daily time step

*gw\_recharge\_tot*, which is the sum of *soil\_to\_gw* and *ssr\_to\_gw* for each HRU for the total simulation time period

*basin\_gw\_recharge*, which is the basin area-weighted sum of *soil\_to\_gw* and *ssr\_to\_gw*

2. Parameter **ssrmax\_coef**, which is the maximum amount of gravity drainage to a PRMS groundwater reservoir or MODFLOW finite-difference cell, was set to a value of 1.0, the default value. Previously, the variable could range to a maximum value of 20.0, which was incorrect.

3. Added consistency checks to be sure the following parameters are not specified to a value less than zero: **soil\_moist\_max**, **soil\_moist\_init**, **soil\_rechr\_max**, **soil\_rechr\_init**, **ssstor\_init**, and **sat\_threshold**.

Module gsflow\_prms2mf:

1. Added parameter **mnsziter**, which is the minimum number of computations per time step that are computed by the Soil Zone Module. Computations within the Soil Zone Module include Dunnian runoff, interflow, changes in storage within the soil-zone reservoirs, components of evapotranspiration, and potential gravity drainage. The sequence of these computations is described in Table 9 of the GSFLOW documentation report (USGS Techniques and Methods 6-D1, p. 51). The following provides a more detailed explanation than is found in the GSFLOW manual of the conditions under which a GSFLOW time step concludes.

GSFLOW is based on an iterative-solution method in which convergence for each time step is ultimately dependent on whether or not changes in groundwater heads and flow rates meet closure criteria specified in the MODFLOW solver packages. If the MODFLOW convergence criteria are met, then GSFLOW continues to the next time step; if the convergence criteria are not met but the maximum number of MODFLOW iterations per time step is exceeded (as specified using variable **MXITER** or **ITMX** in the MODFLOW solver packages), then GSFLOW will print a warning message and continue to the next time step. Note that this differs from MODFLOW, in which MODFLOW stops if **MXITER** or **ITMX** are exceeded.

Convergence of groundwater heads and flow rates is dependent in part on the amount of gravity drainage that drains from the soil zone to the underlying unsaturated and

saturated zones. The amount of gravity drainage is dependent on the potential gravity drainage computed by the Soil Zone Module and the vertical hydraulic conductivity and heads within the MODFLOW finite-difference cells. In many cases, heads and groundwater flow rates may converge faster if the amount of gravity drainage from the soil zone is no longer changing, which means that the MODFLOW computations will no longer be dependent on feedback from the Soil Zone Module.

Three GSFLOW input parameters are provided to allow the user to stop the soil-zone computations prior to convergence of the groundwater heads and flow rates. These parameters are (1) **szconverge**, which is the maximum allowed change in gravity drainage from the soil zone for all HRUs between iterations required before the soil-zone computations cease; (2) **mnsziter**, which is defined above; and (3) **mxsziter**, which is the maximum number of computations per time step that are computed by the Soil Zone Module. Parameters **szconverge** and **mxsziter** have been available since the initial release of GSFLOW (see Table A1-25 in USGS Techniques and Methods 6-D1). Computations within the soil zone cease under three conditions listed in order of precedence: (1) the MODFLOW closure criteria are met or **MXITER** or **ITMX** is reached; (2) the maximum number of soil-zone computations is reached, as specified by parameter **mxsziter**; or (3) the maximum change in gravity drainage from the soil zone for all HRUs between iterations is less than the value specified for parameter **szconverge**. When conditions 2 or 3 are met, all computations done by the Soil Zone Module are held constant for the remainder of the current time step until MODFLOW-related convergence criteria are met (or **MXITER** or **ITMX** is exceeded). In addition, the amount of interflow and surface runoff to streams and lakes are held constant when soil-zone computations cease within a time step.

Previous versions of GSFLOW set the minimum number of soil-zone computations to 4, which is now the default value for **mnsziter**; **mnsziter** must be specified to be greater than 2. Specifying too small a value for **mxsziter** for complex GSFLOW models can stop soil-zone computations within a time step before the MODFLOW solution reaches a stable value; this may cause groundwater discharge from some finite-difference cells in subsequent iterations to be significantly different than that computed at the iteration in which the soil-zone computations ceased. In general, more complex models will require higher values of **mnsziter** and **mxsziter** than less complex models. Recent experience with GSFLOW indicates that (1) **mnsziter** and **mxsziter** should be set to values that equal the approximate average number and the maximum number, respectively, of MODFLOW iterations that are expected for any time step; and (2) that for some simulations, it may be advantageous to not limit the number of soil-zone computations by setting both **mnsziter** and **mxsziter** equal to **MXITER** or **ITMX** to allow for full feedback between PRMS and MODFLOW for each time step. The GSFLOW user may need to experiment with the values specified for **szconverge**, **mnsziter**, and **mxsziter** to be sure that the GSFLOW calculations have converged to stable values.

For the convenience of the user, the number of MODFLOW iterations and soil-zone computations are printed to the screen for the first day of each month and for each time step in the gsflow.log file. Also, if the number of iterations for a time step exceeds 75, the date and time of this time step is printed to the screen. At the end of a simulation, a summary table is printed to the screen and to the gsflow.log file giving the total and average number of MODFLOW iterations and soil-zone computations, as well as the total time the simulation took.

2. Bug fix: corrected do loop index of arrays used to check whether or not soilzone states are oscillating.

Module gsflow\_prms:

1. Module subbasin\_prms can now be called in both GSFLOW and PRMS-only modes. Previously, it could be called in PRMS-only mode. However, the user should be aware that some output variables written by the module are not relevant to a GSFLOW simulation, specifically those related to the PRMS groundwater module: *sub\_inq*, *sub\_cfs*, *sub\_cms*, *sub\_gwflow*, and *subinc\_gwflow*. The subbasin\_prms module is useful in GSFLOW mode for computation of several subbasin states and fluxes, such as *sub\_interflow*, *sub\_precip*, *sub\_pkweqv*, *subinc\_interflow*, *subinc\_sroff*, *subinc\_precip*, *subinc\_snowmelt*, *subinc\_pkweqv*, *subinc\_actet*, *sub\_actet*, *sub\_sroff*, *sub\_snowmelt*, and *subinc\_snowcov*.

#### **Version 1.1.00 11/18/2009:**

This version of GSFLOW is based on MODFLOW-2005 version 1.7. Added ability to specify inactive and swale hydrologic response unit types and the ability to calculate streamflow at internal basin nodes (the latter for PRMS-only simulations). Several additional bug fixes and minor enhancements were made for this release. All of the changes are described in the file 'GSFLOW\_v1.1\_Updates.pdf' located in the \doc\GSFLOW directory. Updated input formats for the PRMS and GSFLOW modules, including several new input parameters, are provided in the file 'Appendix1\_Tables\_v1.1.pdf,' which is also included in the \doc\GSFLOW directory. Also made changes to the Sagehen sample problem by simplifying the MODFLOW Name File and making the MODFLOW transient stress period consistent with the total number of time steps simulated by GSFLOW; these changes did not affect the results of the sample problem.

#### **Version 1.0.00 03/05/2008:**

This version is the initial release.