

Miner's Coffee

**A Powerful and Accessible
GPU Mining Software**

USER DOCUMENT



Content

Before You start	3
Terms	4
General Instructions	4
1) Installation	4
2) Use	4
3) Error	4
4) Daemon	5
5) Turn off	5
Software Overview	6
Navigation Bar	6
Monitor	7
Mining	8
Statistics	9
Device Information	10
Overclocking	10
Virtual Memory Settings	11
Team Information	12
Operational Instructions:	12

Before You start

Appreciation for your purchase of this software.

This software can provide users with the best mining user experience

Before you start using the software, please read this chapter to familiarize yourself with the main functions

Find the analysis of professional vocabulary on the noun analysis page.

Find the method to download, use, and close the software in the software instructions.

Find the meaning and location of all components and pages on the UI in the software overview.

View the method and process of using software for mining monitoring in the operation introduction.

Terms

GPU Clock: The GPU's core frequency is measured in megahertz (MHz), which represents "million cycles per second." Generally speaking, the higher the core frequency, the faster the GPU and the more work per second.

VRAM Clock: Video memory frequency refers to the frequency at which the video memory is working on the graphics card by default, in MHz (Megahertz). The video memory frequency reflects the speed of the video memory to a certain extent.

Power Draw: W (Watt) is the unit, used to calculate power consumption

Hashrate: The number of hash collisions that can be done per second. The unit is MH/s (Mega-hashes per Second).

Coin: Type of cryptocurrency. At the current version, we only support Ether (ETH).

Core: Program used to mine the crypto. At the current version, we only support NBMiner.

Pool: An aggregation of multiple miners.

Wallet: Your mining account, you need to go to a mining pool to register one.

Worker: The name of the mining rig (any name you like).


General Instructions

1) Installation

You can download the software compressed package from our designated address.

2) Use

After decompression, you can find the MinerCoffee.exe file in code/MinersCoffee-release. Double-click the exe file to run it.



At the same time, please allow the computer OS to access to the software.

3) Error


A) GPU Driver Error



Only NVIDIA GPUs are supported. If so, please install the newest driver from www.nvidia.com.

4) Daemon

The button at the top of the software does not completely close the software. We will hide the UI and prompt you to continue using the software in the background. You can find our software icon in the back-end, click it to show the UI.



5) Turn off

You can enter `ctrl + C` in the supporting terminal to stop the software, or enter the background program, right-click the icon, and click close.

Monitor



Temperature Module	Display the value of max and min temperature of all your devices on real-time. Show max temperature history on the chart.
GPU Module	Display max and min GPU Clock\VRAM Clock\Fan Speed\Power Draw Information among all devices
Mining Module	(Only effectively display after starting mining) Display Hashrate\Estimated income\and Effective Rate
Free Disk Space	Display your disk usage information

Mining

Mining Parameters

Coin

ETH

Core

NBMiner

Pool

sparkpool

Start Mining

Wallet


Worker

Log

Refresh


Mining Parameters	Select box for your Coin/Core/Pool Input box for wallet and worker's name Push the button to start and stop mining
Log Module	Display log information for error checking

Statistics




Statistics	Select device and date interval and automatic display the history statistic
Device#	Select which device you are interested in
Start	Select date for History interval query front end
End	Select date for History interval query back end

Device Information



Devices Module	Display all NVIDIA devices' information on your computer
----------------	----------------------------------------------------------


Overclocking



Device	Select which device you are interested in
--------	-------------------------------------------

number	
Temp Limit	Set your temperature limit to protect your Device
Group scrolling	Automatically/manually adjust Power limit/GPU Clock/VRAM clock/Fan Speed and push Apply to confirm your adjustment
Automatic Settings	Provided choice to set automatic overclocking


Virtual Memory Settings




Virtual memory Information	Display information about virtual MEMORY
Disk part	Select disk to create virtual memory
Max/min size	Set your memory sets
Apply/cancel	Push buttons to apply/ cancel apply

Team Information


Dev Team




Haotian Ma
118010220



Yu Mao
118010224



Wei Wu
118010335



Shiqi Zhang
118010416

Miner's Coffee
CUHKSZ CSC4001 Course Project

Hope this will enhance your mining experience


Once a miner, always a miner.

Dev Team	Team members' information
----------	---------------------------


Operational Instructions:

Step 1: Complete the information in the mining parameters, especially the wallet name and miner name, and then press the start button to start mining.

Step 2: When a prompt to start mining is displayed in the log, it means that mining has started successfully. If you need to change the mining information, you should press the stop button to stop mining, complete the information again and repeat step 1.



Step3: Observe your GPU temperature changes, Hashrate and other information on the overview page to ensure that your mining progresses normally. After the first few seconds, your estimated income page will display the specific value instead of N/A, as shown in the figure.



Step 4: You can go to 127.0.0.1:22333 for more specific mining information (if NBMiner is used).

33

门教程 - React 欢迎, 张诗琪 - Bla... 领扣 (LeetCode) - ... Ant Design - 一个... 极客时间-轻松学习... GAMES101: 现代... Linggle 10^12- La...

NBMiner 37.1

矿工信息									
矿工状态	已连接								
在线时间	0天 00:01:58								
挖矿算法	ethash								
用户名1	sp_uvw2.rog								
矿池地址1	cn.sparkpool.com:13333								
用户名2	undefined								
矿池地址2	undefined								


显卡信息											
显卡	算力1	算力2	接受份额1	拒绝份额1	无效份额1	接受份额2	拒绝份额2	温度	功耗	风扇	核心频率
Geforce RTX 2070 with Max-Q Design	31.03 MH/s	0.000 H/s	1	0	0	undefined	undefined	75 C	79 W	0 %	1185 MHz
总计	31.03 MH/s	0.000 H/s	-	-	-	-	-	-	79 W	-	-

矿池统计数据1						
当前难度	矿池延迟	10分钟算力	4小时算力	24小时算力	接受份额	拒绝份额
8,000 G	87 ms	68.38 M	68.38 M	68.38 M	1	0


矿池统计数据2						
当前难度	矿池延迟	10分钟算力	4小时算力	24小时算力	接受份额	拒绝份额
undefined	undefined ms	undefined	undefined	undefined	undefined	undefined

获取最新版本: [Github](#) 加入官方QQ群, 获取最新动态: 795224121

Step 5: On the overclocking setting page, you can get the current value according to the position of the slide bar, slide the slide bar to set the value, click the apply button and then adjust.



Step 6: Of course, if you are a novice, you can choose to use our automatic overclocking recommendation function, as long as you click the AUTO OC button below, we will set the overclocking according to your GPU type.



Step 7: View historical data. On the history page, you can select the time interval and device number you are interested in to call up the historical data. The data we display includes temperature, GPU clock, memclock, fanspeed, and powerdraw. You can move the mouse to the icon to zoom the axis

(Please note, please do not check the date in the future or the history 30 days ago)

Step 8: For better use, you can set the virtual memory. You can view the amount of free memory of each disk on the overview page, and then select and set the disk on the virtual memory setting page.

Virtual Memory Info

AllocatedBaseSize	8483
CurrentUsage	106
Description	C:\pagefile.sys
InstallDate	20210327013300.091279+480
Name	C:\pagefile.sys
PeakUsage	314
Status	None
TempPageFile	FALSE

Virtual Memory

Disk Part. C:/

Max Size 17

Min Size 2

Apply

Cancel Auto Page