

Electrical System Form FSAE-2015

Portland State University

Car #E221



Team Contact: Quinn Sullivan qsullivan11@gmail.com

Table of Contents

Table of Contents	2
I List of Figures.....	6
II List of Tables.....	7
III. List of Abbreviations.....	8
1 System Overview	9
2 Electrical Systems.....	11
2.1 Shutdown Circuit.....	11
2.1.1 Description/concept.....	11
2.1.2 Wiring / additional circuitry	11
2.1.3 Position in car	12
2.2 IMD.....	13
2.2.1 Description (type, operation parameters)	13
2.2.2 Wiring/cables/connectors/	14
2.2.3 Position in car	15
2.3 Inertia Switch	16
2.3.1 Description (type, operation parameters)	16
2.3.2 Wiring/cables/connectors/	17
2.3.3 Position in car	17
2.4 Brake Plausibility Device	17
2.4.1 Description/additional circuitry	17
2.4.2 Wiring	18
2.4.3 Position in car/mechanical fastening/mechanical connection.....	18
2.5 Reset / Latching for IMD and BMS.....	18
2.5.1 Description/circuitry	18
2.5.2 Wiring/cables/connectors	18
2.5.3 Position in car	18
2.6 Shutdown System Interlocks	19
2.6.1 Description/circuitry	19
2.6.2 Wiring/cables/connectors	19
2.6.3 Position in car	19
2.7 Tractive system active light	19
2.7.1 Description/circuitry	19
2.7.2 Wiring/cables/connectors	20

2.7.3	Position in car	22
2.8	Measurement points	23
2.8.1	Description.....	23
2.8.2	Wiring, connectors, cables.....	23
2.8.3	Position in car	23
2.9	Pre-Charge circuitry.....	23
2.9.1	Description.....	23
2.9.2	Wiring, cables, current calculations, connectors	23
2.9.3	Position in car	24
2.10	Discharge circuitry	24
2.10.1	Description.....	24
2.10.2	Wiring, cables, current calculations, connectors	24
2.10.3	Position in car	25
2.11	HV Disconnect (HVD).....	25
2.11.1	Description.....	25
2.11.2	Wiring, cables, current calculations, connectors	25
2.11.3	Position in car	25
2.12	Ready-To-Drive-Sound (RTDS)	25
2.12.1	Description.....	25
2.12.2	Wiring, cables, current calculations, connectors	26
2.12.3	Position in car	26
3	Accumulator	27
3.1	Accumulator pack 1	27
3.1.1	Overview/description/parameters	27
3.1.2	Cell description	27
3.1.3	Cell configuration.....	28
3.1.4	Cell temperature monitoring.....	28
3.1.5	Battery management system	28
3.1.6	Accumulator indicator.....	29
3.1.7	Wiring, cables, current calculations, connectors	29
3.1.8	Accumulator insulation relays	29
3.1.9	Fusing.....	30
3.1.10	Charging	31
3.1.11	Mechanical Configuration/materials.....	31

3.1.12	Position in car	32
3.2	Accumulator pack 2	32
4	Energy meter mounting	33
4.1	Description	33
4.2	Wiring, cables, current calculations, connectors	33
4.3	Position in car	33
5	Motor controller	34
5.1	Motor controller 1	34
5.1.1	Description, type, operation parameters	34
5.1.2	Wiring, cables, current calculations, connectors	34
5.1.3	Position in car	35
6	Motors	37
6.1	Motor 1	37
6.1.1	Description, type, operating parameters	37
6.1.2	Wiring, cables, current calculations, connectors	38
6.1.3	Position in car	39
7	Torque encoder	41
7.1	Description/additional circuitry	41
7.2	Torque Encoder Plausibility Check	42
7.3	Wiring	43
7.4	Position in car/mechanical fastening/mechanical connection	44
8	Additional LV-parts interfering with the tractive system	45
8.1	Vehicle Control Unit	45
8.1.1	Description	45
8.1.2	Wiring, cables,	45
8.1.3	Position in car	47
8.2	DC/DC converter	48
8.2.1	Description	48
8.2.2	Wiring, cables,	48
8.2.3	Position in car	49
9	Overall Grounding Concept	51
9.1	Description of the Grounding Concept	51
9.2	Grounding Measurements	51
10	Firewall(s)	52

Portland State University, Car E221

10.1	Firewall 1.....	52
10.1.1	Description/materials.....	52
10.1.2	Position in car.....	52
11.	Appendix.....	53

I List of Figures

Figure 1-1: Block diagram of the tractive system	9
Figure 1-2: Block diagram of the controls/GLV system.....	9
Figure 2-1: Schematics of shutdown circuit.....	12
Figure 2-2: Shutdown Circuit location.....	13
Figure 2-3: Inertia switch location drawing	17
Figure 2-4 TSAL & RTDS enclosure drawing.....	20
Figure 2-5 Wiring diagram of TSAL	21
Figure 2-6 Board Layout of TSAL (board dimensions are in inches).....	22
Figure 2-7 Position of TSAL in the car, under the top of the main roll hoop	22
Figure 2-8 Wiring diagram of RTDS (LV fuses not included for brevity).....	26
Figure 5-1 Position of the motor controller (rear and isometric view)	35
Figure 5-2 Position of the motor controller (side view).....	36
Figure 6-1 Plot of power vs. RPM and Torque vs. RPM for Remy HVH250 motor	38
Figure 6-2 Motor traction connection	39
Figure 6-3 Motor and enclosure placement (rear view).....	40
Figure 6-4 Motor and enclosure placement (side view)	40
Figure 7-1 Torque encoder functional description	42
Figure 7-2 Motor Controller torque input mapping	43
Figure 7-3 Torque encoder wiring schematics (simplified).....	44
Figure 7-4 Location of the pedal assembly.....	44
Figure 10-1 Position of rear firewall	52
Figure 0-1 DC/DC converter specs (Section 8.2).....	53

II List of Tables

Table 1.1 General parameters.....	10
Table 2.1 List of switches in the shutdown circuit	11
Table 2.2 Wiring – Shutdown circuit	12
Table 2.3 Parameters of the IMD.....	14
Table 2.4 Parameters of the Inertia Switch	17
Table 2.5 Torque encoder data.....	18
Table 2.6 Parameters of the TSAL	20
Table 2.7 General data of the pre-charge resistor	23
Table 2.8 General data of the pre-charge relay.....	24
Table 2.9 General data of the discharge circuit.....	25
Table 3.1 Main accumulator parameters	27
Table 3.2 Main cell specification.....	28
Table 3.3 Wire data of company A, 0.205 mm ²	29
Table 3.4 Basic AIR data	30
Table 3.5 Basic fuse data.....	30
Table 3.6 Fuse Protection Table.....	31
Table 3.7 General charger data	31
Table 5.1 General motor controller data.....	34
Table 5.2 Wire data of Irradicated Exrad Shielded 2 AWG battery cable.....	35
Table 6.1 General motor data	38
Table 7.1 Torque encoder data.....	41

III. List of Abbreviations

A: Amps

AIR: Accumulator Isolation Relays

AMS: Accumulator Management System

ATF: Automatic Transmission Fluid

AWG: American Wire Gauge

BMS: Battery Management System

CAN: Controller Area Network

DC: Direct Current

DCP: Direct Current Pulse

GLVS: Grounded Low Voltage System

HT: High Torque

HV: High Voltage

HVD: High Voltage Disconnect

IMD: Insulation Monitoring Device

RTDS: Ready-To-Drive-Sound

SST: Speed Start Measurement

TEPD: Throttle Encoder Plausibility Device

TSAL: Tractive System Active Light

TSMP: Tractive System Measuring Points

TSMS: Tractive System Master Switch

VCU: Vehicle Control Unit

VDC: Voltage Direct Current

1 System Overview

The electrical system is divided into two sub-systems. The low voltage system is 12V DC, the high voltage is 196 V max. The goal of the system is to keep things simple, reliable, and safe. The selection of using proven hardware and components was used instead of recreating components whenever possible. High-level diagram of the tractive system is shown in Figure 1-1, block diagram of individual subsystems is shown in Figure 1-2. Basic information about the car can be found in Table 1.1.




Figure 1-1: Block diagram of the tractive system




Figure 1-2: Block diagram of the controls/GLV system

Portland State University, Car E221

Maximum Tractive-system voltage:	196 VDC
Nominal Tractive-system voltage:	180 VDC
Control-system voltage:	12 VDC
Accumulator configuration:	48s2p
Max voltage per container	98 VDC
Total Accumulator capacity:	35Ah
Motor type:	Permanent magnet AC motor
Number of motors:	1
Maximum combined motor power in kW	50 kW (68 hp)

Table 1.1 General parameters

2 Electrical Systems

2.1 Shutdown Circuit

2.1.1 Description/concept

The shutdown circuit contains the safety circuits listed in Table 2.1. Everything is in series, except the AIR's are in parallel with each other. If circuit is opened by the AMS or IMD, the tractive system is disabled until being manually reset by a person directly at the car which is not the driver. The driver cannot reactivate the tractive system, they can't physically reach the reset buttons in the rear of the car. No remote reset is installed.

The two master switches will electrically turn off the 12V supply, and open the AIR's when switched "off". For the brake over travel switch, there is a rod attached to a toggle switch, which pulls open a contact on a relay. The tractive system does apply regenerative braking, and current flows to the high voltage battery pack. If the shutdown circuit is disconnected, both tractive system current and regenerative current is disconnected. The motor controller "bleeds" off excess energy.

Part	Function
Main Switches (GLVMS, TSMS)	Normally open
Brake over travel switch (BOTS)	Normally closed
Shutdown buttons (SDB)	Normally closed
Insulation Monitoring Device (IMD)	Normally open
Accumulator Management System (BMS)	Normally open
Inertia Switch	Normally closed
Interlocks - charger, AMS, IMD, BSPD, accumulators	Closed when circuits are connected
Brake System Plausibility Device	Normally Closed

Table 2.1 List of switches in the shutdown circuit

2.1.2 Wiring / additional circuitry

The shutdown circuit wiring is 18 AWG, stranded insulated copper wire with all components in series. All connections are made using IP 65 rated Deutsch connectors. The schematic of shutdown circuit is shown in Figure 2-1. Table 2.2 summarizes basic info about the shutdown circuit.



Commented [f1]: Needs to be fixed

Figure 2-1: Schematics of shutdown circuit

Total Number of AIRs:	6
Current per AIR:	0.13A
Additional parts consumption within the shutdown circuit:	3A
Total current:	3.78A
Cross sectional area of the wiring used:	0.823 mm ² (18 AWG)

Table 2.2 Wiring – Shutdown circuit

2.1.3 Position in car

The shutdown circuit is distributed throughout the car, as shown in Figure 2-2.




Figure 2-2: Shutdown Circuit location

2.2 IMD

2.2.1 Description (type, operation parameters)

An insulation monitoring device (IMD) is installed in the tractive system that continuously monitors the electrical insulation resistance between the active HV conductors of the drive system and the chassis ground reference earth. The IMD is a Bender A-ISOMETER @ iso-F1 IR155-3204. The response value of the IMD is set to 500 Ohm / Volt, related to the maximum tractive system operation voltage. The tractive system maximum voltage is 196V, so the IMD is at 98 k-ohms. The IMD specs are shown in Table 2.3.

Once power is switched on the IMD performs a Speed Start measurement (SST). This provides the first estimated insulation resistance during a maximum time of 2 seconds. The Direct Current Pulse (DCP) system starts immediately after to continuously take measurements. Faults in the connecting wires or any functional faults will be recognized, and drive a relay open.

The status of the IMD is shown to the driver by an indicator light in the cockpit that is easily visible even in bright sunlight. In the case of a fault, too low insulation resistance, IMD error, ground error, undervoltage detected or IMD loss of power, the relay will open, and a normally closed contact will close, an indicator light will turn on. It is wired in series with a 470 ohm resistor to decrease the current to ~19 mA. The IMD indicator light is clearly marked with the lettering "IMD".

In case of an insulation failure or an IMD failure, the IMD will open the shutdown circuit without the influence of any programmable logic. If the shutdown circuit is opened by the IMD the tractive system will remain disabled until being manually reset by a person directly at the car which is not the driver. It is not possible for the driver to re-activate the tractive system from within the car in case of an IMD

fault because the reset button is at the rear of the car out of the driver's reach. No remote reset is installed.

Applying an IMD test resistor, with a value less than 98 k-ohms, between HV+ and GLV system ground deactivates the system. Disconnecting the test resistor does not reactivate the system. The tractive system remains inactive until it is manually reset.

Supply voltage range:	10..36VDC
Supply voltage	14VDC
Environmental temperature range:	-40..105°C
Selftest interval:	Startup, then 15 minute intervals
High voltage range:	DC 0..1000V
Set response value:	98 k-ohms (500 ohms/volt)
Max. operation current:	2mA
Approximate time to shut down at 50% of the response value:	20s

Table 2.3 Parameters of the IMD

2.2.2 Wiring/cables/connectors/

The connections on the vehicle side use metal ring terminals. The connections on the IMD side use a harness secured to the board. The XLA wires are [Thermax M22759/16-18-3 orange 18 AWG cable](#). None of the GLVS wiring and components are orange in color. The high voltage wires are fused with 6.3A Bussmann BK-S505H-V-6.3-R fuses rated at 400 VDC, with datasheet shown in Figure 11-1. The IMD circuit schematics is shown in Figure 2-3.

Commented [f2]: Needs to be updated



Figure 2-3 IMD circuit schematics

2.2.3 Position in car

IMD is located in the lower accumulator container, as shown in Figure 2-4. More information about the accumulator container can be found in section Accumulator pack 1.



Figure 2-4 IMD position

2.3 Inertia Switch

2.3.1 Description (type, operation parameters)

The inertia switch is a First Technology Resettable Crash Sensor, rated at opening the circuit at 10 g or more of deceleration. It is in series with the shutdown circuit, and upon impact, it will activate the circuit and open the AIRs, stopping current flow. The inertia switch will remain open until the button is manually pressed, closing the circuit. Our inertia switch is mounted on close to the driver's dash (see Figure 2-5). It is removable to test functionality.

Inertia Switch type:	First Technology resettable crash sensor
Supply voltage range:	10..36VDC
Supply voltage:	12VDC
Environmental temperature range:	-40..105°C
Max. operation current:	10A
Trigger characteristics:	10g for 50ms / 16g for 15ms

Table 2.4 Parameters of the Inertia Switch

2.3.2 Wiring/cables/connectors/

The wiring used for the inertia switch is stranded 18 AWG wire. The connectors is IP65 rated Deutsch connector. It is wired in series with the shutdown circuit.

2.3.3 Position in car

Mounted vertically to the front roll hoop as shown in Figure 2-5.




Figure 2-5: Inertia switch location drawing

2.4 Brake Plausibility Device

2.4.1 Description/additional circuitry

Describe how your electronic hardware brake plausibility system works (this is in addition to your ECU controlled brake plausibility software), provide tables with main operation parameters, and

Commented [f3]: Keith

Commented [f4]: Maybe we can just measure the torque encoder?

describe additional circuitry used to check or for an implausibility. Describe how the system reacts if an implausibility or error is detected.

Brake sensor used:	ABC Sensor
Torque encoder used:	potentiometer
Supply voltages:	5V
Maximum supply currents:	20mA
Operating temperature:	-20..180 °C
Output used to control AIRs:	Open a relay

Table 2.5 Torque encoder data

2.4.2 Wiring

Describe the wiring, show schematics including the circuit board, show data regarding the cables and connectors used. If not detailed in section 2.1, be sure to show how the device opens the shutdown circuit.

2.4.3 Position in car/mechanical fastening/mechanical connection

Provide CAD-renderings showing all relevant parts and discuss the mechanical connection of the sensors to the pedal assembly. Mark the parts in the rendering, if necessary.

2.5 Reset / Latching for IMD and BMS

Commented [f5]: TBD

2.5.1 Description/circuitry

Describe the concept and circuitry of the latching/reset system for a tripped IMD or BMS. Describe the method for resetting the IMD and BMS.

2.5.2 Wiring/cables/connectors

Describe wiring, show schematics, describe connectors and cables used and show useful data regarding the wiring. If not detailed in section 2.1, be sure to show how the device opens the shutdown circuit.

2.5.3 Position in car

Provide CAD-renderings showing the relevant parts. Mark the parts in the rendering, if necessary.

2.6 Shutdown System Interlocks

2.6.1 Description/circuitry

Describe the concept and circuitry of the Shutdown System Interlocks.

Note: Interlocks are circuits used to open the shutdown circuit if a connector is disconnected or enclosure is opened. This is not the entire shutdown circuit.

2.6.2 Wiring/cables/connectors

Describe wiring, show schematics, describe connectors and cables used and show useful data regarding the wiring.

2.6.3 Position in car

Provide CAD-renderings showing the relevant parts. Mark the parts in the rendering, if necessary.

2.7 Tractive system active light

2.7.1 Description/circuitry

The tractive system active light (TSAL) is LED lights, red in color, and flashes at a frequency of ~3 Hz. It is clearly visible 360 degrees around the entire car when the tractive system is activated. Each light is 12 lumens, bright enough to be clearly visible by a person standing 3 meters away from the TSAL. It is the only light located anywhere near that area. The 3 Hz frequency is created by TSAL circuitry (basically 555 timer and two transistors). The light is provided by red waterproofed LED strip, that is powered by 12V and is cut to size.

TSAL is placed in cylindrical enclosure under the main roll hoop. Inside the enclosure is also RTDS buzzer. The enclosure is 3D printed, consists of two parts that are glued together, as shown in Figure 2-6.

Supply voltage:	12VDC
Max. operational current:	700mA
Lamp type	LED
Power consumption:	4.5 W
Brightness	100 Lumen
Frequency:	3.2Hz
Size (length x height x width):	3" x 1.5" x 1.5"

Table 2.6 Parameters of the TSAL




Figure 2-6 TSAL & RTDS enclosure drawing

2.7.2 Wiring/cables/connectors

HV+ lead is connected on the motor side of the main contactor, and HV- is connected on most negative lead. When the precharge circuit has completed, and the main contactor closes, tractive system voltage is at ~196 VDC max. There is a zener diode at the HV+ input, preventing voltages < 60 V to activate circuit. LR8 high voltage linear regulator provides power to ILD74 optocoupler, which separates HV and LV. Timer 555 is powered by 12V and takes care of periodical switching of the transistors. That way we can switch larger loads necessary to power the lights. We tested the circuit and it provides satisfactory results. The wiring diagram is shown in Figure 2-7, the PCB layout is shown in Figure 2-8.

TSAL has 4 LV inputs (LIGHT+, LIGHT-, GND, 12V+) and two HV inputs (HV+, HV-). TSAL PCB is inside the main contactor box, with only LIGHT+ and LIGHT- 18AWG wires coming the the TSAL enclosure under the roll hoop. This way HV leads don't have to be outside the contactor box, making design simpler.




Figure 2-7 Wiring diagram of TSAL




Figure 2-8 Board Layout of TSAL (board dimensions are in inches)

2.7.3 Position in car

The light is mounted on the top of the roll hoop, and is unable to contact the driver's helmet (we measured that there is enough clearance), as shown in Figure 2-9.




Figure 2-9 Position of TSAL in the car, under the top of the main roll hoop

2.8 Measurement points

Commented [f7]: Quinn

2.8.1 Description

Describe the housing used and how it can be accessed, etc. Describe how the measurement points protected/covered when not in use and how the electrical connections on the back of the measurement points are protected when the measurement points are being used.

2.8.2 Wiring, connectors, cables

Describe wiring, show schematics, and describe connectors and cables used and show useful data regarding the wiring. Include details on the protection resistor including resistance, voltage and power rating.

2.8.3 Position in car

Provide CAD-renderings showing the relevant parts. Mark the parts in the rendering, if necessary.

2.9 Pre-Charge circuitry

Commented [f8]: Quinn

2.9.1 Description

Describe your concept of the pre-charge circuitry.

2.9.2 Wiring, cables, current calculations, connectors

Describe wiring, show schematics, describe connectors and cables used and show useful data regarding the wiring.

- ▲ Give a plot "Percentage of Maximum Voltage" vs. time
- ▲ Give a plot Current vs. time
- ▲ For each plot, give the basic formula describing the plots

Additionally fill out the tables:

Resistor Type:	ABC Resistor
Resistance:	680Ω
Continuous power rating:	60W
Overload power rating:	200W for 30 sec
Voltage rating:	1500V
Cross-sectional area of the wire used:	0.205 mm ²

Table 2.7 General data of the pre-charge resistor

Relay Type:	DEF Relay
Contact arrangement:	SPDT, SPST, SPCO, SPTT, DPST,
Continuous DC current:	25A
Voltage rating	2000VDC
Cross-sectional area of the wire used:	0.205 mm ²

Table 2.8 General data of the pre-charge relay

2.9.3 Position in car

Provide CAD-renderings showing all relevant parts. Mark the parts in the rendering, if necessary.

2.10 Discharge circuitry

Commented [f9]: Quinn

2.10.1 Description

Describe your concept of the discharge circuitry.

2.10.2 Wiring, cables, current calculations, connectors

Describe wiring, show schematics, describe connectors and cables used and show useful data regarding the wiring.

- ▲ Give a plot "Voltage" vs. time
- ▲ Give the formula describing this behavior
- ▲ Give a plot "Discharge current" vs. time
- ▲ Give the formula describing your plot

Additionally fill out the table:

Resistor Type:	ABC Resistor
Resistance:	680Ω
Continuous power rating:	350W
Overload power rating:	600W for 20 sec
Voltage rating:	1500V
Maximum expected current:	0.7A
Average current:	0.3A
Cross-sectional area of the wire used:	0.205 mm ²

Table 2.9 General data of the discharge circuit

2.10.3 Position in car

Provide CAD-renderings showing all relevant parts. Mark the parts in the rendering, if necessary.

2.11 HV Disconnect (HVD)

Commented [f10]: Quinn

2.11.1 Description

Describe your concept of the HVD and how it can be operated.

2.11.2 Wiring, cables, current calculations, connectors

Describe wiring, show schematics, describe connectors and cables and show useful data regarding the wiring. Include information on the working voltage and current rating of the HVD.

2.11.3 Position in car

Provide CAD-renderings showing all relevant parts. Mark the parts in the rendering, if necessary.

2.12 Ready-To-Drive-Sound (RTDS)

2.12.1 Description

The RTDS is a sustained 3 kHz tone emitted at 80 dBA for 2 seconds. One buzzer will be used, and will have max 75 mA current supplied by the 12V battery. This indicates the tractive system is on, and the precharge circuit has completed, and the vehicle is ready to drive and will be propelled once the driver presses the accelerator pedal. We are using **PUI Audio AI-5025-TWT-R buzzer**.

Once the motor controller changes its state into “Ready-to-drive”, the Vehicle Control Unit (VCU) reads its state over CAN and triggers the “Forward Enable” switch on the motor controller (J1-30) as well as RTDS circuit (using the enable pin on the buzzer).

The car can be set to Ready-to-Drive mode by applying the following steps:

1. switch on Tractive System Master Switch
2. switch on Low Voltage Master Switch
3. The motor controller will initiate precharge and if the voltage at the controller DC HV inputs is higher than 100V after 4 seconds of precharge, it will close main contactor
4. The motor controller is in standby mode now
5. Driver has to press simultaneously brake pedal and flip the FORWARD_ENABLE switch to ON set the vehicle into Ready-to-Drive mode

If any of these points are not met, the car cannot go into ready to drive mode.

2.12.2 Wiring, cables, current calculations, connectors

The RTDS will be powered by the 12V grounded low voltage system, have a 75 mA maximum current, and is controlled by the VCU. The entire circuit will use 18 gauge wire. The circuit is shown in Figure 2-10.



Figure 2-10 Wiring diagram of RTDS (LV fuses not included for brevity)

2.12.3 Position in car

The buzzer (which is basically the whole circuit) is placed together with TSAL in the oval enclosure under main roll hoop. That way the sound will be loud and clear. The position of the RTDS circuit is shown in Figure 2-9.

Commented [MP11]: Wrong circuit!!! VCU driver directly the buzzer

3 Accumulator

3.1 Accumulator pack 1

3.1.1 Overview/description/parameters

Describe concept of accumulator pack, provide table with main parameters like number of cells, cell stacks separated by maintenance plugs, cell configuration, resulting voltages->minimum, maximum, nominal, currents, capacity etc.

Fill out the following table:

Maximum Voltage:	550VDC
Nominal Voltage:	500VDC
Minimum Voltage:	300VDC
Maximum output current:	405A for 10s
Maximum nominal current:	250A
Maximum charging current:	50A
Total numbers of cells:	200
Cell configuration:	100s2p
Total Capacity:	21.6 MJ
Number of cell stacks < 120VDC	5

Table 3.1 Main accumulator parameters

3.1.2 Cell description

Describe the cell type used and the chemistry, provide table with main parameters.

Fill out the following table:

Cell Manufacturer and Type	Kokam XYZ
Cell nominal capacity:	5.4 Ah
Maximum Voltage:	4.2 V
Nominal Voltage:	3.7V
Minimum Voltage:	2.8V
Maximum output current:	20C for 10s
Maximum nominal output current:	15C
Maximum charging current:	5C
Maximum Cell Temperature (discharging)	65°C
Maximum Cell Temperature (charging)	55°C
Cell chemistry:	LiFePO4

Table 3.2 Main cell specification

3.1.3 Cell configuration

Describe cell configuration, cell interconnect, show schematics of electrical configuration and CAD of connection techniques, cover additional parts like internal cell fuses etc.

3.1.4 Cell temperature monitoring

Describe how the temperature of the cells is monitored, where the temperature sensors are placed, how many cells are monitored, etc. Show schematics, cover additional parts, etc.

3.1.5 Battery management system

Describe the BMS used including at least the following:

- Sense wiring protection (fusing / fusible link wire used)
- What upper and lower voltage does the BMS react at and how does it react?
- What cell temperature does the BMS react at and how does it react?
- Show tables of operation parameters
- Describe how many cells are sensed by each BMS board, the configuration of the cells, the configuration of the boards and how any comms wiring between boards is protected

- Describe how the BMS is able to open the AIRs if any error is detected
- Describe where galvanic isolation occurs between TS and GLV system connections.

3.1.6 Accumulator indicator

Describe the indicator, show wiring, provide tables with operation, PCB design, etc.

3.1.7 Wiring, cables, current calculations, connectors

Describe the internal wiring, show schematics, provide calculations for currents and voltages and show data regarding the cables and connectors used.

- ⚠ Discuss maximum expected current, DC and AC how long will this be provided?
- ⚠ Compare the maximum values to nominal currents
- ⚠ Give a table for each kind of wire in your tractive-system:
- ⚠ Describe your maintenance plugs, provide pictures
- ⚠ Use tables like the one shown below:

Wire type	Company A,
Continuous current rating:	150A
Cross-sectional area	0.205 mm ²
Maximum operating voltage:	800VDC
Temperature rating:	150 °C
Wire connects the following components:	Cell and BMS

Table 3.3 Wire data of company A, 0.205 mm²

3.1.8 Accumulator insulation relays

Describe the AIRs used and their main operation parameters, use tables, etc.

Additionally fill out the following table:

Relay Type:	ABC Relay
Contact arrangement:	SPST
Continuous DC current rating:	100A
Overload DC current rating:	200A for 10sec
Maximum operation voltage:	800VDC
Nominal coil voltage:	24VDC
Normal Load switching:	Make and break up to 300A
Maximum Load switching	10 times at 1500A

Table 3.4 Basic AIR data

3.1.9 Fusing

Describe the fuses used and their main operation parameters, use tables, etc.

Additionally fill out the following table for each fuse type used:

Fuse manufacturer and type:	ABC Fuse company, MNO Fuse
Continuous current rating:	150A
Maximum operating voltage	500VDC
Type of fuse:	High speed
I ² t rating:	1500A ² s at 450VDC
Interrupt Current (maximum current at which the fuse can interrupt the current)	10000A

Table 3.5 Basic fuse data

Create a table with components and wires protected by the fuse(s) and the according continuous current rating, below is an example table with some potential entries. Complete this table with information for your design and add/remove additional locations as applicable. Ensure that the rating of all of the components is greater than the rating of the fuse such that none of the other components become the fuse.

Location	Wire Size	Wire Ampacity	Fuse type	Fuse rating
Cells to AIRs	2 AWG	XXX	MNO Fuse	XXX
AIR to Motor controller	0 AWG	XXX	2x MNO Fuse	XXX
AIR to TSAL	20 AWG	XXX	EFG Fuse	XXX
Accumulator output connector	2 AWG	XXX		
Cells to BMS				

Table 3.6 Fuse Protection Table

3.1.10 Charging

Describe how the accumulator will be charged. How will the charger be connected? How will the accumulator be supervised during charging? Show schematics, CAD-Renderings, etc., if needed

Additionally fill out the table:

Charger Type:	ABC Charger
Maximum charging power:	3kW
Maximum charging voltage:	550V
Maximum charging current:	20A
Interface with accumulator	CAN-Bus, proprietary, serial communication...
Input voltage:	230 VAC
Input current:	16A

Table 3.7 General charger data

3.1.11 Mechanical Configuration/materials

Describe the concept of the container, show how the cells are mounted, use CAD-Renderings, show data regarding materials used, etc.

3.1.12 Position in car

Provide CAD-renderings showing the relevant parts. Mark the parts in the rendering, if necessary. Ensure that the required mechanical structure to protect the accumulator and other electrical components is clearly identified.

3.2 Accumulator pack 2

...

If identical parts are used, just refer to the corresponding sections, don't copy and paste.

4 Energy meter mounting

Commented [f12]: Has to be redone

4.1 Description

Describe where the energy meter is mounted and how, etc.

4.2 Wiring, cables, current calculations, connectors

Describe the wiring, show schematics, provide calculations for currents and voltages, and show data regarding the cables and connectors used.

4.3 Position in car

Provide CAD-renderings showing all relevant parts. Mark the parts in the rendering, if necessary.

5 Motor controller

5.1 Motor controller 1

5.1.1 Description, type, operation parameters

The motor is operated by a RMS PM100 motor controller. The motor has software onboard that varies the voltage supply to the motor based on input directly from the motor, as well as CAN messages from the vehicle control unit. Basic information is provided in Table 5.1.

Fill out the following table:

Motor controller type:	RMS PM100DX Controller
Maximum continuous power:	105kW
Maximum peak power:	122kW for 10s
Maximum Input voltage:	360VDC
Output voltage:	187VAC
Maximum continuous output current:	300A
Maximum peak current:	350A for 5s
Control method:	CAN, Hardware IO
Cooling method:	Water cooled via radiator
Auxiliary supply voltage:	12VDC

Table 5.1 General motor controller data

5.1.2 Wiring, cables, current calculations, connectors

The low voltage side of the controller uses 2 AMPSEAL connectors (one 35 pin, and one 23 pin). All low voltage wires will use the same 18 AWG wire as the rest of the low voltage system, all wires will be rated to maximum tractive system voltage, at least 196V.

High voltage AC and DC wires are 2 AWG cable rated for a 600 V/ 255 A current. All 5 cables are installed to the controller as specified by the manufacturer, and bolted securely. The controller uses hex tool metal cable glands (cord grips). All tractive system conductors will be enclosed in orange, non-conductive conduit rated for at least 600V, securely fastened at each termination.

2 AWG cable is used outside of the Accumulator containers, instead of 4 AWG cable, because of the limited availability of the high voltage quick disconnects that include interlock mechanisms that can accept smaller gauge cable and still satisfy rule requirement and be watertight. Also, the high voltage AC/DC connections on the PM100 controller are designed to accept 2 AWG cable, along with the 3-phase connections on the Remy motor. Information about wiring is summarized in Table 5.2.

Commented [13]: Not sure if this will satisfy comment 49, but is my interpretation of why we are doing it this way. feel free to comment

Wire type:	Irradiated Exrad Shielded 2 AWG battery cable
Current rating:	255A
Maximum operating voltage:	600V
Temperature rating:	-70 to 150 °C

Table 5.2 Wire data of Irradiated Exrad Shielded 2 AWG battery cable

5.1.3 Position in car

It is our understanding that it is acceptable to have the motor controller protrude out of the main hoop supports because in the vertical side and rear planes the controller is still protected on all sides with 3 members, and is above the 350 mm side impact structure.




Figure 5-1 Position of the motor controller (rear and isometric view)




Figure 5-2 Position of the motor controller (side view)

6 Motors

6.1 Motor 1

6.1.1 Description, type, operating parameters

The Remy HVH 250 115 HT is the high torque (115mm core) version. The motor is rated for 87 kW peak power. This application runs at a reduced voltage (196V) and power rating (42kW). The motor is broken down into the following components:

1. Cartridge- The cartridge contains the bearings, rotor, stator and resolver. The cartridge is close-tolerance to ensure magnetic air gap.
2. Stator- The stator allows high current within the windings. It is 10-pole with series and parallel windings. It also contains temperature sensors to signal controller to limit power and excessive temperatures.
3. Rotor- The rotor provides magnetic performance by optimizing magnetic positioning, power density and rotational inertia.
4. Resolver- The resolver receives field coil excitation from, and returns sensor coil signals to the inverter to provide precision rotor position information for accurate synchronization of the signals supplied by the inverter.
5. Enclosure - The enclosure houses the cartridge, carries the shaft load, and supports the weight of the motor. The final motor enclosure is a 6 mm aluminum cylinder with two end plates.

Basic motor information is summarized in Table 6.1. Figure 6-1 shows plot of motor power and torque vs RPM.

Motor Manufacturer and Type:	Remy HVH 250
Motor principle	permanent magnet AC
Maximum continuous power:	120 kW
Peak power:	160kW
Input voltage:	276 VAC
Nominal current:	200 A
Peak current:	300 A
Maximum torque:	330 Nm
Nominal torque:	248 Nm
Cooling method:	Oil-injected

Table 6.1 General motor data




Figure 6-1 Plot of power vs. RPM and Torque vs. RPM for Remy HVH250 motor

6.1.2 Wiring, cables, current calculations, connectors

There are two connectors, one for low voltage and high voltage. The low voltage connector is a 10-pin Delphi Metri-pack 150. This is the resolver connector, and also transmits temperature data to the controller.

The high voltage is a 3 phase, 320 volt, 200 amp continuous, 300 amp peak connector. This application will require the wire to be rated at 220 amps for 196 volt use. As prescribed by the controller manufacturer, 2 AWG shielded cable is used, and the ampacity is 255A, and our tractive system is fused upstream in the accumulator containers to 70A. The line to line voltage is 196 volts, and the value is determined from the controller nominal voltage input:

$$V_{ac} = \frac{V_{DC}}{\sqrt{2}} = \frac{264}{\sqrt{2}} = 196V$$

220 amps peak is determined from the power curve supplied by Remy for a 196 volt input.

The high voltage connector is a 2 AWG battery cable lug on each of the three motor phases. For this connection we choose the Molex 19221-0418 Battery Cable Lugs. The motor terminals have an OEM positive locking washer fixed on the terminals. The cables are attached to a housing with cable glands that require a wrench to remove, and the motor cables are shielded. The housing completely encloses the tractive system cables, and it is not possible to touch them with the housing in place.

Portland State University, Car E221

Orange conduit will be installed to protect the cables. The motor traction connection is shown in Figure 6-2.




Figure 6-2 Motor traction connection

6.1.3 Position in car

The motor will be mounted at the rearmost structural section of the chassis, as shown in Figure 6-3 and Figure 6-4.




Figure 6-3 Motor and enclosure placement (rear view)




Figure 6-4 Motor and enclosure placement (side view)

7 Torque encoder

7.1 Description/additional circuitry

The torque encoder used is originally from Toyota Prius and has two hall-effect position sensors, and produces two outputs. Basic info about the torque encoder is shown in Table 7.1., the encoder diagram and output voltage mapping is shown in Figure 7-1. The torque encoder signal is sent to the VCU to perform plausibility check. From VCU it is sent to motor controller. The signal is not amplified (the requested torque can be only lowered) before being sent to the motor controller.

Torque encoder manufacturer and type:	Toyota Prius Throttle Pedal 78120-47050
Torque encoder principle:	Hall-Effect
Supply voltage:	5 VDC
Maximum supply current:	20mA
Operating temperature:	-40 to 85 C
Used output:	0-5V

Table 7.1 Torque encoder data




Figure 7-1 Torque encoder functional description

7.2 Torque Encoder Plausibility Check

The two torque encoders need to be within 10% pedal travel of each other. We know that the produced voltages are offset (see above), so first we have to map the voltages to a pedal position. If the implausibility occurs, motor controller is disabled (by opening ENABLE input to the controller) and the output voltage of the torque encoder is pulled low (0V). The encoder plausibility checks work as following:

1. Feed both encoder outputs into analog inputs (0-5V) on VCU
2. VCU checks if the values are not below minimal threshold (1.6V and 0.8V respectively) – if so, that means the pedal is grounded, and motor controller is disabled
3. If both inputs are above high threshold (3.6V/4.4V) it means the encoder is open (analog inputs on VCU are internally pulled high) and the motor controller is disabled
4. VCU maps analog values to the throttle position ($0.8V/1.6V = 0\%$ throttle, $3.6V/4.4V = 100\%$ throttle), the mapping is shown in Figure 7-1
5. If both values are not within 10% of each other, the motor controller is disabled
6. 5V PWM output of VCU is connected to motor controller analog input (0-5V). The lower of two encoder inputs is used as desired throttle for the controller. Throttle is mapped to PWM duty cycle (0% throttle = 0% PWM, 100% throttle = 100% PWM duty cycle).
7. Internal RC filter on the motor controller smooths out PWM into analog value
8. Motor controller is set to use following thresholds (see Figure 7-2), effectively performing another plausibility check:

- a. PEDAL_LO: minimal allowed voltage, lower value triggers controller fault and disables the controller
- b. ACCEL_MIN: voltage between PEDAL_LO and ACCEL_MIN is mapped to a constant regenerative torque (REGEN_LIMIT)
- c. COAST_LO: voltage between ACCEL_MIN and COAST_LO is linearly mapped to torque between REGEN_LIMIT and zero
- d. COAST_HI: voltage between COAST_LO and coast HI is mapped to zero torque
- e. ACCEL_MAX: voltage between COAST_HI and ACCEL_MAX is linearly mapped from zero to max allowed torque
- f. PEDAL_HI: voltage higher than PEDAL_HI is considered a fault (open connection) and disables motor controller

9. If all checks passed, then the desired torque is applied by the motor controller




Figure 7-2 Motor Controller torque input mapping

7.3 Wiring

The wiring of the torque encoder is 18 AWG wire that connects to the plausibility system, and then to the motor controller. The internal voltage regulator in VCU provides 5V power for the throttle encoder. Simplified schematics is shown in Figure 7-3.

Commented [MP14]: Not entirely true, VCU first does FW_ENABLE open and 100ms it will open shutdown...



Figure 7-3 Torque encoder wiring schematics (simplified)

7.4 Position in car/mechanical fastening/mechanical connection

The torque encoder are hall-effect sensors located in an OEM accelerator assembly. The assembly is bolted to a 40 degree angled mount, which is bolted to the pedal box, as shown in Figure 7-4.




Figure 7-4 Location of the pedal assembly

8 Additional LV-parts interfering with the tractive system

Commented [f15]: TBD – VCU, power supply

8.1 Vehicle Control Unit

8.1.1 Description

Although VCU is not a part of tractive system, this section summarizes basic information about it. Our VCU is GEVCU (General Electric Vehicle Control Unit) from EVTV Motor Verks. VCU is interfacing several subsystems, and also serves as the main BMS board. VCU uses Arduino IDE for programming, and the custom code, located at: https://github.com/podhrmic/Arduino_eVCU

8.1.2 Wiring, cables,

VCU is connected to the following subsystems:

- VCU – Motor controller:
 - Insulated CAN bus (RMS_CAN_H, RMS_CAN_L)
 - Digital output (FW_ENABLE_RELAY) to disable motor controller
- VCU – Throttle encoder:
 - Analog input (TEPD_ANIN) from torque encoder
 - PWM (TEPD_PWM_OUT) commanded torque
 - 5V power (TEPD_VDD) and ground (TEPD_GND)
- VCU – Battery Modules:
 - Insulated CAN bus (BMS_CAN_H, BMS_CAN_L)
 - 12V power (BMS-12V)
- VCU – AMS Latching circuit:
 - Digital output (AMS_LATCH)
- VCU – Shutdown circuit:
 - Digital output (SHUTDOWN_RELAY)
 - Digital input (SHUTDOWN_STATUS)
- VCU – Brake switch:
 - Digital input (BRAKE_STATUS)
- VCU – BSPD:
 - Digital input (BSPD_STATUS)
- VCU – IMD:
 - Digital input (IMD_STATUS)
- VCU – DC/DC Converter
 - Digital output (DC/DC_EN) as remote control for DC/DC converter (via relay)
- VCU – Dashboard
 - Digital output (AMS LED)

VCU has AMP Seal 35pin connector (identical to the connector on motor controller), and all LV wires will be 18 AWG, rated for or above maximum tractive system voltage (196V). The pinout is shown in Figure 8-1.




Figure 8-1 VCU pinout

Digital input to VCU has a pull-up resistor (normally high) as shown in Figure 8-2. That means the logic is inverted, i.e. if voltage is present on the input, VCU reads logic LOW.




Figure 8-2 VCU Digital input schematics, DIN2 is from the AMPSEAL connector, D50 goes directly into Arduino chip

Digital Output from VCU is a “sinking source” which means that when logic HIGH it connects the input to the LVGND and conducts, when logic LOW the input is floating and doesn’t conduct, as shown in Figure 8-3.




Figure 8-3 VCU Digital output, DOUT0 and DOUT1 are on AMPSEAL connector, D4 and D5 are outputs from Arduino chip

Analog input is 12V tolerant, with a voltage divider of $V_{read} = \frac{10k}{10k+16k} = 0.384 V_{in}$ and since the internal Arduino ADC is 3.3V max (and has 12-bit resolution), we can measure voltage in range of 0-8.5V, resolution is 8mV. For sensing 12V we need to add another voltage divider at the input. The analog input circuit is shown in




Figure 8-4 VCU Analog input circuit, AIN1 is from AMPSEAL connector, A2 is analog input directly fed to Arduino chip

8.1.3 Position in car

ECU is located above the top accumulator container, as shown in Figure 8-5



Figure 8-5 VCU position

8.2 DC/DC converter

8.2.1 Description

We are using Mean Well SP-200-12 DC/DC converter to charge our LV motorcycle battery during the race. The converter accepts DC input from 120 to 370 VDC and provides 11.4-13.2-VDC output as shown in Figure 11-3. Max output is 200W which at 12.6V means 15.8A max which is well within the current rating of 18AWG wire. We adjusted the controller to provide 13.9V Open-Loop Voltage because under load of 5A the voltage drops to convenient 12.4V.

8.2.2 Wiring, cables,

The converter is connected to HV+ and HV- and is protected by a 5A 250V fuse. The output is fed directly to the LV battery. The connection diagram is shown in Figure 8-6. The converter is controlled remotely from VCU, using a normally-open relay on HV+ line. That way the DC/DC converter is switched off during charging. Our power budget is 7A (12VDC) during normal operation (including the pump cooling the motor controller), and 12A (12VDC) with the fan on.

Commented [MP16]: add proper fuse

Commented [f17R16]:



Figure 8-6 DC/DC Converter connection diagram

8.2.3 Position in car

DC/DC controller is located in the Accumulator Container 2 (lower), as shown in Figure 8-7.



Figure 8-7 DC/DC converter position

9 Overall Grounding Concept

9.1 Description of the Grounding Concept

The chassis of the car will be used as the common ground for the low voltage system. The chassis is made of steel, and will have additional connections to keep the resistance to common ground below the required 300 mOhms. This includes areas of the chassis within 100mm of the tractive system. Other components of the vehicle that may become conductive will have measures taken to ensure <5 Ohms resistance to common ground.

9.2 Grounding Measurements

The 12V battery that supplies the GLVS is located in the LV component area below the driver's seat. Measurements will be taken in several locations to ensure grounding requirements are met, and extra grounding straps added to keep resistance below 300 mOhms. The fiberglass body is not within 100 mm of any HV component. Also fiberglass can't possibly become conductive.

10 Firewall(s)

10.1 Firewall 1

10.1.1 Description/materials

A 1/16" FR4 sheet with Aluminum on the motor side behind the seat is used as the firewall. The tractive side is 0.6 mm thick Aluminium. This material meets the required scratch and puncture resistance of the UL94-V0 standards.

10.1.2 Position in car

The firewall placement is shown in Figure 10-1




Figure 10-1 Position of rear firewall

11. Appendix

Commented [f18]: TBD

Xxx

Specifications

Catalog Number	Voltage Rating Vac	Max. Voltage Rating ¹		Interrupting Rating (A) ² Under			Typical DC Cold Resistance Ω ³	Typical Voltage Drop (mV) ⁴	Typical Value I ² t (A ² s) ⁵	Agency Approvals			
		AC	DC	250 Vac	Max Volts	400 Vdc				250Vac			
										TUV ⁶	CQC ⁶	CCC ⁶	cURus ⁷
S505H-500-R	250	600	400	1500	100	1500	0.507	295	0.188				x
S505H-800-R	250	600	400	1500	100	1500	0.237	189	0.632				x
S505H-1-R	250	600	400	1500	100	1500	0.14	153	1.28			X	x
S505H-1.25-R	250	600	400	1500	100	1500	0.108	150	2.22			X	x
S505H-1.6-R	250	600	400	1500	100	1500	0.07	125	6.78			X	x
S505H-2-R	250	600	400	1500	100	1500	0.055	128	11.44	X		X	x
S505H-2.5-R	250	600	400	1500	100	1500	0.04	126	24.23	X		X	x
S505H-3.15-R	250	600	400	1500	100	1500	0.031	121	43.55	X		X	x
S505H-4-R	250	600	400	1500	100	1500	0.019	90	38.45	X		X	x
S505H-5-R	250	600	400	1500	100	1500	0.015	89	71.3	X		X	x
S505H-6.3-R	250	500	400	1500	100	1500	0.011	80	111.4	X		X	x
S505H-8-R	250	500	400	1500	100	1500	0.007	76	228.2	X	X		x
S505H-10-R	250	500	400	1500	100	1500	0.006	72	349.5	X	X		x

Figure 11-1 S505H series fuse (Section 2.1), Complete datasheet at http://www.mouser.com/ds/2/87/BUS_Elx_DS_4406_S505H_Series-335925.pdf

Electric Properties	Method	Value
Dielectric Withstand Voltage	per IPC-TM-650	>1500 V
Insulation Resistance (after 24 hours)	IPC-TM-650 Test 2.6.3.4	5x10 ¹² Ω

Figure 11-2Acrylic Conformal Coating 419C (Section 2.7), full datasheet located at <http://www.mgchemicals.com/products/protective-coatings/conformal/acrylic-conformal-coating-419c/>

Figure 11-3 DC/DC converter specs (Section 8.2), complete datasheet located at <http://www.onlinecomponents.com/datasheet/sp200135.aspx?p=11953391>

Numbering according to chapter 1 to 10

A datasheet for motor controller one for example has to have the numbering 11.10.5

Example appendix entry:

11.2.2 – Bender IR155-3203 IMD ratings

Referred from 2.1.1.

Portland State University, Car E221

Technical data

Insulation coordination acc. to IEC 60664-1

Protective separation (reinforced insulation)

between (L+/L-) – (Kl. 31, Kl. 15, E, KE, MHS, MLS, OKHS)

Voltage test AC 3500 V/1 min

Supply/IT system being monitored

Supply voltage U_S DC 10...36 V

Max. operating current I_S 150 mA

Max. current I_k 2 A

6 A/2 ms inrush current

HiV voltage range (L+/L-) U_N AC 0...1000 V (peak value)

0...660 V rms (10 Hz...1 kHz)

DC 0...1000 V

Power consumption < 2 W

Response values

Response value hysteresis (DCP) 25 %

Response value R_{an} 100 k Ω ...1 M Ω

Undervoltage detection 0...500 V

Measuring range

Measuring range 0...10 M Ω

Undervoltage detection 0...500 V default setting: 0 V (inactive)

Relative uncertainty

good > 2* R_{an} ; bad < 0.5* R_{an}

SST (≤ 2 s) 0...85 k Ω $\rightarrow \pm 20$ k Ω

Relative uncertainty DCP (default setting 100 k Ω) 100 k Ω ...10 M Ω $\rightarrow \pm 15\%$

Relative uncertainty output M (fundamental frequency) $\pm 5\%$ at each frequency

(10 Hz; 20 Hz; 30 Hz; 40 Hz; 50 Hz)

Relative uncertainty

undervoltage detection $U_N \geq 100$ V $\rightarrow \pm 10\%$; at $U_N \geq 300$ V $\rightarrow \pm 5\%$

Relative uncertainty (SST) "Good condition" $\geq 2* R_{an}$

"Bad condition" $\leq 0.5* R_{an}$

Complete data sheet located at: http://www.bender-de.com/fileadmin/products/doc/IR155-32xx-V004_DB_en.pdf