



```
347 SP_API SeStatus seSetIQCaptureType(int device, SeIQCaptureType captureType);
348 SP_API SeStatus seSetIQCenterFreq(int device, double centerFreqHz);
349 SP_API SeStatus seSetIQCenterFreq(int device, double "centerFreqHz");
350 SP_API SeStatus seSetIQSampleRate(int device, int decimation);
351 SP_API SeStatus seSetIQBandwidth(int device, SeBool enableSoftwareFilter, double bandwidth);
352 SP_API SeStatus seSetIQExtTriggerEdge(int device, SeTriggerEdge edge);
353 SP_API SeStatus seSetIQExtTriggerEdge(int device, SeTriggerEdge "edge");
354
355 SP_API SeStatus seSetAudioCenterFreq(int device, double centerFreqHz);
356 SP_API SeStatus seSetAudioType(int device, SeAudioType audioType);
357 SP_API SeStatus seSetAudioFilters(int device, double ifBandwidth, double audioBpf, double audioHPF);
358 SP_API SeStatus seSetAudioDeemphasis(int device, double deemphasis);
359
360 SP_API SeStatus seConfigure(int device, SeMode mode);
361 SP_API SeStatus seGetCurrentMode(int device, SeMode "mode");
362 SP_API SeStatus seAbort(int device);
363
364 SP_API SeStatus seSetSweepParameters(int device, double "actualBW", double "actualVBW",
365                                     double "actualStartFreq", double "binSize", int "sweepSize");
366 SP_API SeStatus seSetRealTimeParameters(int device, double "actualBW", int "sweepSize", double "actual
367                                     double "binSize", int "frameWidth", int "frameHeight", double "p
368 SP_API SeStatus seSetIQParameters(int device, double "sampleRate", double "bandwidth");
369
370 // Performs a single sweep, blocking function
371 SP_API SeStatus seSetSweep(int device, float "sweepMin", float "sweepMax", int64_t "nsSinceEpoch");
372
373 // Queue sweep mechanisms
374 SP_API SeStatus seStartSweep(int device, int pos);
375 SP_API SeStatus seFinishSweep(int device, int pos, float "sweepMin", float "sweepMax", int64_t "nsSince
376
377 SP_API SeStatus seGetRealTimeFrame(int device, float "frame", float "alphaFrame", float "sweepMin",
378                                     float "sweepMax", int "frameCount", int64_t "nsSinceEpoch");
379
380 //SP_API SeStatus seSetIQSample(int device, float "iqBuf", int "iqBufSize", SeBool purge);
381 SP_API SeStatus seSetIQ(int device, float "iqBuf", int "iqBufSize", double "triggers", int triggerBufSize,
382                                     int64_t "nsSinceEpoch", SeBool purge, int "sampleLoss", int "samplesRemaining");
383
384 SP_API SeStatus seSetAudio(int device, float "audio");
385
386 SP_API SeStatus seSetGPSInfo(int device, SeBool refresh, SeBool "updated", int64_t "secSinceEpoch",
387
388     VTUserDataTrailerField isReferenceLock;
389     VTUserDataTrailerField isOverRange;
390     VTUserDataTrailerField isSampleLoss;
391     uint32_t associatedContextPktCount;
392 } VTUserDataTrailer;
393
394 #typedef struct VTUserDataPkt {
395     VTUserDataPkt& operator= (const VTUserDataPkt& pkt) {
396         prologue = pkt.prologue;
397         trailer = pkt.trailer;
398         data.resize(pkt.data.size());
399         memcpy(&data[0], &kkt.data[0], data.size());
400         return *this;
401     }
402     VTUserPktPrologue prologue;
403     std::vector<float> data;
404     VTUserDataTrailer trailer;
405 } VTUserDataPkt;
406
407 #typedef struct VTUserContextIndicators {
408     bool isContextFieldChanged;
409     bool isBandwidth;
410     bool isRffreq;
411     bool isRefLevel;
412     bool isAtten;
413     bool isSampleRate;
414     bool isTemperature;
415     bool isDevId;
416     bool isDevModel;
417     bool isGPS;
418 } VTUserContextIndicators;
419
420 #typedef struct VTUserGPS {
421     double latitude;
422     double longitude;
423     double altitude;
424     uint32_t seconds;
425     uint32_t picosec;
```

Spike™ SCPI Programming Manual

User Guide

Spike™ SCPI Programming Manual

Published 2/27/2023
©2023, Signal Hound
1502 SE Commerce Ave, Suite 101
Battle Ground, WA
Phone 360-217-0112

Contents

1 Version Notes	5
2 Introduction / About SCPI	5
3 SCPI command basics.....	5
3.1 Commands	5
3.2 Multiple commands	6
3.3 Parameters	7
3.4 Return Values.....	7
3.5 Special Characters	8
4 Getting Started	8
5 Functionality provided through SCPI	9
6 Examples	10
7 Functions	10
7.1 Display.....	10
7.2 Common Commands	11
7.3 Format	12
7.3.1 Ascii Trace Format	12
7.3.2 Real Trace Format	12
7.3.3 Ascii I/Q Format.....	13
7.3.4 Binary I/Q Format	13
7.4 System Functions.....	13
7.4.1 Device Management	15
7.4.2 Errors.....	16
7.5 Mode/Measurements	17
7.5.1 Instrument (Mode).....	17
7.5.2 Initiate (Single/Continuous)	18
7.6 Limit Lines	18
7.7 Path Loss Tables.....	20
7.8 Reference.....	21
7.9 Spectrum Analysis.....	22
7.9.1 Sweep Configuration	22
7.9.2 Traces.....	27
7.9.3 Markers.....	28
7.9.4 Trace Math	31
7.9.5 Channel Power.....	32
7.9.6 Occupied Bandwidth	34
7.9.7 Intermodulation Distortion	34
7.9.8 Peak Table	35

7.10 Zero-Span	37
7.10.1 Configuration	37
7.10.2 I/Q Data	39
7.10.3 Fetch Results	39
7.11 Scalar Network Analysis	40
7.11.1 Frequency Configuration	40
7.11.2 Sweep Configuration	41
7.11.3 Traces.....	42
7.11.4 Markers.....	42
7.12 Phase Noise Measurements	42
7.12.1 Sweep Configuration	42
7.12.2 Traces.....	44
7.12.3 Marker	45
7.12.4 Jitter Configuration	45
7.12.5 Decade Table	46
7.13 Harmonic Measurements	47
7.13.1 Configuration	47
7.13.2 Fetch Results	48
7.14 Analog Demodulation	49
7.14.1 Configuration	49
7.14.2 Fetch Results	50
7.15 Digital Demodulation	50
7.15.1 Configuration	50
7.15.2 Sweep.....	56
7.15.3 Fetch Results	56
7.16 Spectrum Emission Mask.....	57
7.16.1 Configuration	57
7.16.2 Offset Table	61
7.16.3 Measurement	61
7.16.4 Marker	62
7.17 Noise Figure	63
7.17.1 Configuration	63
7.17.2 Calibration and Measurement	67
7.17.3 Fetch Results	68
7.18 Bluetooth® Low Energy Measurements	68
7.18.1 Configuration	68
7.18.2 Fetch Results	70
7.19 WLAN Measurements	71
7.19.1 Configuration	71
7.19.2 Fetch Results	72
7.20 LTE Measurements.....	74
7.20.1 Configuration	74
7.20.2 Fetch Results	76

7.21 Audio Player	78
7.21.1 Configuration	78

1 Version Notes

SCPI commands can and will change as the Spike software evolves. It is recommended that when you update Spike in an installation that is controlled via SCPI, to review the version notes and determine if any functionality needs to be updated. See the separate document title *scpi_version_notes.txt* for a full list of changes for each version of the Spike software.

2 Introduction / About SCPI

SCPI (Standard Commands for Programmable Instruments) is a standard which covers the set of commands used to program various instruments. The standard covers the syntax, form, behavior, etc. of these commands in attempt to reduce development time for the user.

For the purposes of Signal Hound and the Spike software, a user can send SCPI commands to Spike to control and make measurements using the Spike software in an automatic fashion. SCPI commands are sent to instruments over many interfaces, commonly GPIB, VXI, USB, Ethernet, etc. The Spike software accepts commands over a network socket. The Spike software will accept a single network connection in which it can receive SCPI commands and send responses.

This document will cover the basics of SCPI commands, how to get started programming the Spike software, and will cover the full SCPI command set implemented by the Spike software.

3 SCPI command basics

This section contains a quick overview of the SCPI command syntax and usage to the extent that is relevant to the Spike software. Spike does not utilize all functionality in the SCPI standard and as such said functionality will not be covered here.

3.1 Commands

A SCPI command is comprised of a series of keywords separated by colons. A command may be followed by a '?' to represent a query, a series of parameters separated by spaces, or both.

`:SENSE:FREQUENCY:CENTER 1GHz` (Example command for setting the center frequency to 1GHz)

`:sense:frequency:center?` (Example command for querying the current center frequency)

Commands are case insensitive. Each keyword in a command can have a short and long form. Both can be used interchangeably.

`:SENSe:FREQuency:CENTer` is a command with three keywords. Each keyword has a short and long form. The short form is denoted by the uppercase characters and the long form is the full keyword including the upper and lower-case characters. For example, `FREQ` is the short form of `FREQUENCY`. When constructing a command, the short and long form can be interchanged. For example, you could construct the command as such, `:SENS:FREQUENCY:CENT` where `SENSE` and `CENTER` are sent as short form and `FREQUENCY` as longform.

Some commands are options and are denoted as such by the '[' characters.

`[:SENSe]:FREQuency:CENTer` is a command where the first keyword is optional. This command can be sent as `FREQ:CENT` and still be interpreted correctly.

Commands are terminated with a newline character. For example

```
:SENS:FREQ:CENT 1GHz\n
```

Spike will begin processing the commands once a newline is reached. Additionally, a newline will reset the current keyword path.

3.2 Multiple commands

Multiple commands can be sent to the device at once using the semi colon character separating each command.

```
:SENS:FREQ:CENT 1GHz; :SENS:FREQ:SPAN 10MHz\n
```

This is an example of sending two commands at once. Additionally, when sending multiple commands, you don't need to repeat all keywords leading up to the final keyword for commands after the first.

```
:SENS:FREQ:CENT 1GHz; SPAN 10MHz\n
```

Here `SPAN` retains the `:SENS:FREQ:` keywords from the previous command. To prevent this from happening use the colon character leading the second command. For example

```
:SENS:FREQ:CENT 1GHz; :SPAN 10MHz\n
```

This is an invalid series of commands, since span is prefixed with a colon command which reset the previous keywords.

3.3 Parameters

There are several types of parameters that can be sent in commands.

Boolean	ON OFF 0 1
Keyword <bool>	Character specific strings for a given command. These keywords can also have short and long form.
Numeric <integer> <double>	Numeric parameters take either the form of integer or decimal values. Examples include 1 1.23 9 3.14
Frequency <freq>	These are numeric parameters with a frequency suffix. Possible frequency suffixes include HZ KHZ MHZ GHZ The suffixes are case insensitive. If a suffix is not present, Hz is the default unit. Examples include 1kHz 20MHz 12GHz Any function that returns a frequency will return the frequency in Hz with no suffix present.
Amplitude <amplitude>	These are numeric parameters with an amplitude suffix. Possible amplitude suffixes include DBM DBMV DBUV MV The suffixes are case insensitive. A suffix must be present unless indicated otherwise. Examples include -20DBM 60dbuv If a function returns an amplitude, it will return the amplitude in the current software units without a suffix.

3.4 Return Values

Values returned from the Spike software (as a result of sending a query command) are separated by a semi-colon if multiple query commands are sent in one string and are terminated by a newline. For example, sending

```
"CALC:MARK:MAX; X?; Y?\n"
```

results in a return string of

"1000000;-20\n"

The command sent performs a peak search and queries the X and Y positions of the marker. The return is the X and Y positions separated by a semicolon and terminated with a newline.

3.5 Special Characters

This section describes the numerous special characters that are present in the commands in this document.

Character	Description	Example
	Vertical stroke between parameters indicates multiple choices	FLATtop GAUSSian The choices are between FLATTOP or GAUSSIAN. Provide one or the other.
[]	Square brackets indicate an optional keyword	:SYSTem:ERRor[:NEXT]? Next is an optional keyword and the command could also be composed as :SYSTem:ERRor?
<>	Angle brackets around a parameter indicate a type and angle brackets should not be included in the user command.	*RCL <int> <int> is the type of parameter and an example of using this command would be *RCL 1 Notice the angle brackets are not included.

4 Getting Started

See the SCPI examples found in the SDK download on any of the Signal Hound product download pages. The examples use the C programming language and a common VISA library implementation.

Instrument control is performed by connecting to the Spike software on TCP/IP port 5025. On this port, a user can send and receive raw SCPI commands. It is not necessary to use a I/O library like VISA to communicate with the Spike software but it can simplify several operations. It is possible to communicate directly over the socket with socket programming. The computer that is

communicating with the Spike software does not have to be the same computer running the Spike software and does not have to be a Windows platform.

It is recommended to use a VISA library if available. Several implementations of VISA exist. Commonly used ones include Keysight's I/O libraries, and NI's VISA libraries. You can also use VISA implementations that exist in other languages/environments such as MATLAB, LabVIEW, and Python.

Connecting to the socket interface using VISA looks like this

```
viOpen(rm, "TCPIP::localhost::5025::SOCKET", VI_NULL, VI_NULL, &inst);
```

Additionally, when using a VISA library, it is necessary to set the VI_ATTR_TERMCHAR_EN attribute to true. This will terminate the read operation when the termination character is received. The termination character should be set to the newline ('\n') character if it is not set by default. The code for this is below.

```
viSetAttribute(inst, VI_ATTR_TERMCHAR_EN, VI_TRUE);
```

```
viSetAttribute(inst, VI_ATTR_TERMCHAR, '\n');
```

Only one connection to the Spike software can be active at a time. The connection can be terminated by either closing the socket connection, either through the socket library you are using, the viClose function if you are using a VISA library, or by closing your application. Spike will immediately begin waiting for another socket connection when the previous one is ended.

5 Functionality provided through SCPI

The table below details what functionality is covered under the current SCPI command set. Functionality will be added over time. If functionality you need it not available, please contact us at aj@signalhound.com to make requests.

Functionality	Implemented
Swept Analysis – Sweep Settings	Yes
Swept Analysis – Trace controls	Yes
Swept Analysis – Marker controls	Yes
Swept Analysis – Channel power, occupied bandwidth	Yes
Swept Analysis – Peak table	Yes
Swept Analysis – Sweep recording/playback	No
Path Loss Tables	Yes

Limit Lines	Yes
Spectrogram/Waterfall plot controls	No
Persistence display controls	No
Real-Time (Since real-time shares several controls with swept analysis, any functionality provided for swept analysis will be available for real-time measurement mode)	Partial
Zero-Span	Partial (I/Q captures only)
Harmonic Measurements	Yes
Scalar Network Analysis	Yes
Phase Noise Measurements	Yes
Digital Modulation Analysis	Yes
EMC Precompliance	No
Analog Demodulation	Yes
Interference Hunting	No
Spectrum Emission Mask	Yes
Noise Figure	Yes
BLE Analysis	Yes
WLAN Modulation Analysis	Yes
LTE	Yes

6 Examples

All SCPI examples are provided in the API SDK download which can be downloaded on any of the device download pages on the Signal Hound website.

7 Functions

7.1 Display

Command	:DISPlay:HIDE <bool> :DISPlay:HIDE? :DISPlay:ANNotation:TITLe <string> :DISPlay:ANNotation:TITLe? :DISPlay:ANNotation:CLear
Description	HIDE, When set to true, hides the Spike application. The application will be hidden in the taskbar but will continue to be visible in the task manager. The SCPI lockout dialog, device connecting progress dialog, no device connected alert dialog and multiple devices connected alert dialog will be hidden, overriding related settings in the preferences menu. HIDE?, Returns true when the application is not visible.

	TITLE, Set the measurement title. CLEAR, Remove the title. Has the same effect as setting the title with an empty string.
Examples	DISP:HIDE 1 DISP:HIDE? DISP:ANN:TITLE "Current Measurement" DISP:ANN:TITLE? DISPLAY:ANNOTATION:CLEAR
Software Controls	File Menu -> Edit -> Title File Menu -> Edit -> Clear Title
Couplings	None
Preset	Default is no title
Notes	

7.2 Common Commands

The Spike software supports the following common commands.

Command	*IDN? *OPC *OPC? *RCL <int> *SAV <int> *RST
Description	*IDN?, Query the serial number and name of the device. *OPC, Waits for the current operation to complete before processing the next command. See the Mode/Measurements section for more information on the OPC command. *OPC?, Wait for the current operation to complete before processing the next command. Returns 1 when the operation completes. See the Mode/Measurements section for more information on the OPC command. *RCL, Load preset [1-9]. *SAV, Save preset [1-9]. *RST, Same as PRESet, see below.
Examples	*IDN? *OPC? *RCL 1 *SAV 1
Software Controls	Status Bar File Menu -> Presets -> Load File Menu -> Presets -> Save Preset
Couplings	None
Preset	N/A
Notes	

7.3 Format

Command	<code>:FORMat:TRACe[:DATA] ASCii REAL</code> <code>:FORMat:TRACe[:DATA]?</code> <code>:FORMat:IQ[:DATA] ASCii BINary</code> <code>:FORMat:IQ[:DATA]?</code>
Description	<code>TRACe:DATA</code> , Specify the format of the returned trace data from the <code>TRACe[:DATA]?</code> command. <code>IQ:DATA</code> , Specify the format of the returned IQ data from the <code>FETCH:ZS? 1</code> command.
Examples	<code>:FORM:TRAC REAL</code> <code>:FORMAT:TRACE:DATA ASCII</code> <code>:FORMAT:IQ:DATA BIN</code> <code>:FORM:IQ?</code>
Software Controls	N/A
Couplings	None
Preset	Ascii
Notes	See format description below

7.3.1 Ascii Trace Format

When the ascii format is specified, traces are returned as an ascii string of the form

```
<ascii value 1>,<ascii value 2>,...,<ascii value N>
```

An example of this is

```
-89.324,-102.784,-27.641,...,-112.882<NL>
```

7.3.2 Real Trace Format

When the real format is specified, traces are returned in a block data transfer. A block data transfer is of the form

```
#NBBBBDDDDD...D<NL>
```

Where

- Leading character of a block data transfer. Always present.

N – Number of decimal digits in the total byte count.

BBBB – The total byte count of the payload of the block data transfer. More specifically, the number of bytes that follow the byte count. This number must be N decimal digits long.

DDDD...D – The binary data.

An example block data transfer is below

```
#212ABCDEFGHijkl<NL>
```

The 2 following the # denotes that the byte count is 2 decimal digits. The '12' following this is the byte count. Note it is 2 decimal digits long. Note: The '#' '2' and '12' should be read as ascii characters. 'ABC...JKL' is the data. The data in this example is 12 bytes long. The data should be read as bytes and not ascii.

Trace data is sent in little endian order, or least significant bytes first. Trace data is sent as successive 32-bit floating point values.

7.3.3 Ascii I/Q Format

See Ascii Trace Format.

7.3.4 Binary I/Q Format

See Real Trace Format. I/Q data is sent as successive 16-bit integer values.

7.4 System Functions

The following commands are used to perform system level software actions and query information about the system.

Command	:SYSTem:CLoSe
	:SYSTem:PRESet
	:SYSTem:PRESet?
	:SYSTem:PRESet[:USER]:SAVe <filename>
	:SYSTem:PRESet[:USER]:LOAD <filename>
	:SYSTem:VERsion?
	:SYSTem:COMMunicate:GTLocal
	:SYSTem:IMAGe:SAVe <filename>

	:SYSTem:IMAGe:SAVe:QUICK :SYSTem:PRINt :SYSTem:TEMPerature? :SYSTem:VOLTagE? :SYSTem:CURRent?
Description	<p>CLOSe, Disconnect any active device and closes the Spike software. There is not a way to reopen the software using SCPI commands. This will also terminate the socket connection with the Spike software.</p> <p>PRESet, Presets the active device. This will power cycled the active device and return the software to the initial power on state. This process can take between 6-20 seconds depending on the device type.</p> <p>PRESet?, Presets the active device. This will close and reopen the active device. This process can take between 6-20 seconds depending on the device type. Returns 0 or 1 depending on success. (1 for success)</p> <p>PRESet[:USER]:SAVE, Save a preset with the given file name. The file name should have extension ".ini".</p> <p>PRESet[:USER]:LOAD, Load the preset given by the file name. If the preset does not exist, nothing occurs. The file name should have extension ".ini".</p> <p>VERsion?, Returns the Spike software version number.</p> <p>COMMunicate:GTLocal, Puts Spike in local mode.</p> <p>IMAGe:SAVe, Save and image with the specified filename.</p> <p>IMAGe:SAVe:QUICK, Quick save image. Same functionality as the Image quick save file menu option.</p> <p>PRINt, Print with the default system print settings.</p> <p>TEMPerature?, Returns the current internal temperature of the active device, in degrees celsius.</p> <p>VOLTagE?, Returns the measured voltage of the active device, in volts.</p> <p>CURRent?, Returns the measured current of the active device, in amps. (BB and SM series devices only. SA series devices return 0.)</p>
Examples	<pre> SYST:CLOS SYST:PRESET? SYST:PRESET:USER:SAVE "C:/Users/Me/Documents/SignalHound/customPreset2.ini" SYST:PRESET:USER:LOAD "C:/Users/Me/Documents/SignalHound/customPreset2.ini" SYSTEM:VERSION? SYST:COMM:GTL SYST:IMAG:SAV "C:/Users/Me/Documents/SignalHound/img.png" (Usage of image save with VISA in C) viPrintf(inst, "SYST:IMAG:SAV \"C:/Users/Me/Documents/SignalHound/img.png\"\\n"); SYSTEM:IMAG:SAVE:QUICK </pre>

	SYSTEM:PRINT
	SYST:TEMP?
	SYST:VOLTAGE?
	SYSTEM:CURRENT?
Software Controls	Status Bar File Menu -> File -> Exit Preset File Menu -> Save User Preset File Menu -> Load User Preset File Menu -> Help -> About Spike Remote Mode Dialog -> Return to Local File Menu -> File -> Save As Image File Menu -> File -> Quick Save Image File Menu -> File -> Print
Couplings	None
Preset	N/A
Notes	

7.4.1 Device Management

The functions below allow you to remotely manage the active device in the Spike software. This is useful for error recovery in the event a device disconnect occurs due, or if one is managing multiple Signal Hound devices on one PC.

Connecting Signal Hound devices can take between 3-20 seconds depending on the type of device and the state of the device prior to interfacing it. If the VISA timeout is shorter than the time it takes to connect the device in the Spike software, you will need to loop on timeout until you receive the connect status return.

Command	:SYSTem:DEvice:ACTive? :SYSTem:DEvice:COUnT? :SYSTem:DEvice:LISt? :SYSTem:DEvice:CURRent? :SYSTem:DEvice:CONnect? <int> :SYSTem:DEvice:DISConnect?
Description	ACTive?, Returns whether or not a device is currently connected and active in the software. Look at the *IDN? function to request information about the device. COUnT?, Returns the number of devices connected to the PC. No device may be active when this function is called. IE, you must call DISConnect? before calling this function. Any networked device that have been configured will be counted in the returned value. LISt?, Returns the connection strings for all devices available to connect in the Spike software. To determine how many devices are present, use the COUnT? function. For USB devices, this is serial numbers returned as ascii integers and

	<p>comma separated. If any networked devices have been configured they will be returned in the list with the following format SOCKET::IP::PORT example, SOCKET::192.168.1.1::12345 This entire string can be sent to the connect function to connect to a networked device. CURRent?, Returns the currently active device's connection string. See LIST? for format. CONnect?, Connect a device in the Spike software. For USB devices, you need to provide the serial number of the device to connect. For networked devices, send a string with format SOCKET::IP::PORT example, SOCKET::192.168.1.1::12345 Returns 0 or 1 depending on if the device successfully opened. DISConnect?, Disconnects any device actively connected in Spike. Returns 1 when finished.</p>
Examples	SYST:DEV:ACT? SYST:DEV:COUNT? SYSTEM:DEVICE:LIST? SYSTEM:DEVICE:CURR? SYSTEM:DEVICE:CONNECT? 30700189 SYSTEM:DEVICE:CONNECT? SOCKET::192.168.2.10::51665 SYSTEM:DEV:CONNECT? SYST:DEV:DISC?
Software	File Menu -> File -> Connect
Controls	File Menu -> File -> Disconnect
Couplings	Only one device can be active at a time in Spike.
Preset	N/A
Notes	

7.4.2 Errors

The Spike software maintains a list of system errors available to the user. Errors are stored with a unique ID, name, and description. The types of issues represented in the error list are settings conflicts, SCPI issues such as invalid parameter types or instructions, file I/O errors, etc.

See the SCPI examples to see how to poll Spike for any present errors.

The errors are returned in the form

```
"ID,description;error information"
```

ID is a unique integer for the error. The description is an ascii text description for the error, and error information is any additional context information for the error generated. An example error message is below.

```
"-2,Invalid Parameter;Expected frequency parameter"
```


This error indicates the SCPI parser was expecting a frequency parameter and was either unable to find it or was unable to parse it as a frequency.

Once the error queue is empty, the software will return the 'no error' error when the next system error is requested. 'No error' has an ID of 0.

Command	:SYSTem:ERRor:COUNT? :SYSTem:ERRor[:NEXT]? :SYSTem:ERRor:CLEAr
Description	COUNT?, Returns the number of errors in the error queue. NEXT?, Returns the next error in the queue, and removing it from the queue. CLEAR, Remove all errors from the queue, returns nothing.
Examples	SYST:ERR:COUN? SYSTEM:ERROR:NEXT? SYST:ERR? SYST:ERR:CLEAr
Software Controls	None, remote only
Couplings	None
Preset	N/A
Notes	None

7.5 Mode/Measurements

7.5.1 Instrument (Mode)

These commands control the measurement mode of the Spike software.

Command	:INSTrument[:SElect] SA RTSA ZS HARMonics NA PNoise DDEMod EMI ADEMod IH SEMask NFIGure WLAN BLE LTE :INSTrument[:SElect]? :INSTrument:RECALibrate
Description	SElect, Determines the current measurement mode. RECALibrate, Perform a device recalibration.
Examples	INST SA
Software Controls	File Menu -> Analysis Mode Recal (Button)
Couplings	None
Preset	Sweep mode is selected by default.
Notes	

7.5.2 Initiate (Single/Continuous)

The commands are used to control when measurements are performed in the application. For automated measurements, it is common/recommended to disable `CONTinuous` measurement and control when the software performs the next measurement (sweep/IQ acquisition/etc) with the `INIT:IMM` command.

Command	<code>:INITiate:CONTinuous ON OFF 0 1</code> <code>:INITiate:CONTinuous?</code> <code>:INIT[:IMMediate]</code>
Description	<code>CONTinuous</code> , Enable/Disable continuous measurement operation. This state is global and will affect all measurements. When enabled, measurements are automatically triggered after the previous measurement is finished. When disabled, measurements are triggered only on the <code>IMMediate</code> command. <code>IMMediate</code> , Trigger a measurement. Has no effect if <code>CONTinuous</code> is enabled.
Examples	<code>INIT:CONT OFF</code> <code>INIT</code>
Software Controls	Single (button) Auto (button)
Couplings	None
Preset	<code>CONTinuous</code> set enabled by default.
Notes	None

7.6 Limit Lines

These commands control the limit lines which are available in sweep, real-time, and network analysis measurement modes. If no numeric suffix is provided to specify a limit line, the last used suffix is assumed. The last used suffix defaults to 1.

Command	<code>:CALCulate:LLINe[1 2 3 4 5 6]:STATe ON OFF 0 1</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:STATe?</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:TITLe</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:TITLe?</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:TRACe <int></code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:TRACe?</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:TYPE UPPer LOWer</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:TYPE?</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:REFerence FIXed RELative</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:REFerence?</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:REFerence:TRANSform</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:INTerpolate LINear LOGarithmic</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:INTerpolate?</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:PAUSE[:STATe] ON OFF 0 1</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:PAUSE[:STATe]?</code> <code>:CALCulate:LLINe[1 2 3 4 5 6]:DISPlay:LINE[:STATe]</code>
---------	--

	:CALCulate:LLINE[1 2 3 4 5 6]:DISPlay:LINE[:STATe]? :CALCulate:LLINE[1 2 3 4 5 6]:DISPlay:RESult[:STATe] :CALCulate:LLINE[1 2 3 4 5 6]:DISPlay:RESult[:STATe]? :CALCulate:LLINE[1 2 3 4 5 6]:OFFSet:Y <double> :CALCulate:LLINE[1 2 3 4 5 6]:OFFSet:Y? :CALCulate:LLINE[1 2 3 4 5 6]:BUIlD:POINts <int> :CALCulate:LLINE[1 2 3 4 5 6]:BUIlD:POINts? :CALCulate:LLINE[1 2 3 4 5 6]:BUIlD :CALCulate:LLINE[1 2 3 4 5 6]:POINts? :CALCulate:LLINE[1 2 3 4 5 6]:DATA <freq1>, <amp11>, ... :CALCulate:LLINE[1 2 3 4 5 6]:DATA? :CALCulate:LLINE[1 2 3 4 5 6]:FAIL? :CALCulate:LLINE[1 2 3 4 5 6]:CLEAr :CALCulate:LLINE:ALL:CLEAr
Description	STATe, Enable or disable testing of this limit line. If there are not at least 2 points in the limit line, testing doesn't occur despite being enabled. TITLe, Specify the name of the limit line. TRACe, Specify which trace is tested against this limit line. TYPE, Specify whether the limit line is tested as an upper bound or lower bound. REFerence, Specify whether the limit line values are fixed/absolute or relative to the center frequency and ref level. REFerence:TRANsform, Convert the limit line reference type between fixed and relative by recalculating points based on the current configuration. INTerpolate, Specify whether the limit line uses linear or logarithmic interpolation. PAUSE:STATe, When enabled, a failure of this limit will pause the sweep update. DISPlay:LINE:STATe, When enabled, the limit line will be visible on the graticule. DISPlay:RESult:STATe, When enabled, the limit line pass/fail result will be visible on the graticule. OFFset:Y, Specify a dB offset to the limit line. BUIlD:POINts, Specify how many points to use when building limit line from trace. BUIlD, Build limit line points from trace, max holding across frequency sections. POINts?, Returns the number of points in the limit line as an integer. DATA, Specify the points in the limit line, will override any existing points. Points are specified as freq/amplitude pairs where the amplitude is specified as dBm. DATA?, Returns the points in the limit line. Points are returned as freq/amplitude pairs where the frequencies are specified as Hz and the amplitudes as dBm. FAIL?, Returns 1 when the limit test has failed, 0 if passed. CLEAr, Resets the selected limit line. Removes all points stored. ALL:CLEAr, Resets all limit lines.
Examples	CALC:LLINE1:STATe ON CALC:LLINE1:TITLe Current Limits CALC:LLINE:TRACe 2 CALC:LLINE:TYPE LOW CALC:LLINE:REF REL CALC:LLINE:REF:TRAN CALC:LLINE:INTERPOLATE LINEAR

	CALC:LLINE2:PAUS:STAT OFF CALC:LLINE:DISPlay:LINE CALC:LLINE:DISPlay:RESult CALC:LLIN1:OFF:Y 20 CALC:LLINE:BUILD:POINTs? CALC:LLINE:BUILD CALC:LLINE1:POINTS? CALC:LLINE3:DATA 1e9,-10,2e9,-20 CALC:LLINE3:DATA 1GHZ,-10,2GHZ,-20 (Two points, 1 and 2 GHZ, -10dBm to -20dBm) CALC:LLINE3:DATA? CALC:LLINE1:FAIL? CALC:LLINE1:CLEAR CALC:LLINE:ALL:CLEAR
Software Controls	Manage Limit Lines -> Enabled Manage Limit Lines -> Name Manage Limit Lines -> Trace Manage Limit Lines -> Type Manage Limit Lines -> Reference Manage Limit Lines -> Convert To Manage Limit Lines -> Interpolation Manage Limit Lines -> Pause on Break Manage Limit Lines -> Show Line Manage Limit Lines -> Show Result Manage Limit Lines -> Offset (dB) Manage Limit Lines -> Points To Build Manage Limit Lines -> Build Line Manage Limit Lines -> Modify Points Manage Limit Lines -> Number of Points
Couplings	None
Preset	Cleared.
Notes	

7.7 Path Loss Tables

These commands control the path loss tables which are available in sweep, real-time, zero-span, harmonics, digital modulation analysis, EMC precompliance, analog demod, and interference hunting measurement modes. If no numeric suffix is provided to specify a path loss table, the last used suffix is assumed. The last used suffix defaults to 1.

Command	:SENSe:CORRection:PATHloss[1-8]:STATe ON OFF 0 1 :SENSe:CORRection:PATHloss[1-8]:STATe? :SENSe:CORRection:PATHloss[1-8]:DESCRiption <string> :SENSe:CORRection:PATHloss[1-8]:DESCRiption?
---------	--

	:SENSe:CORRection:PATHloss[1-8]:POINts? :SENSe:CORRection:PATHloss[1-8]:DATA <freq1>, <offset1>, ... :SENSe:CORRection:PATHloss[1-8]:DATA? :SENSe:CORRection:PATHloss[1-8]:CLEAr :SENSe:CORRection:PATHloss:ALL:CLEAr
Description	STATe, Enable or disable application of this path loss table. DESCRiption, Specify the name/description of this path loss table. POINts?, Returns the number of points in the path loss table as an integer. DATA, Specify the points in the path loss table, will override any existing points. Points are specified as freq/offset pairs where the offset is specified as dB. DATA?, Returns the points in the path loss table. Points are returned as freq/offset pairs where the frequencies are specified as Hz and the offsets as dB. CLEAr, Resets the selected path loss table. Removes all points stored. ALL:CLEAr, Resets all path loss tables.
Examples	SENSe:CORRection:PATHloss3:STATe ON SENSe:CORRection:PATHloss3:DESC Table Three SENSe:CORRection:PATHloss3:POINts? SENSe:CORRection:PATHloss3:DATA 1e9,-10,2e9,-20 SENSe:CORRection:PATHloss3:DATA 1GHZ,-10,2GHZ,-20 (Two points, 1 and 2 GHZ, -10dBm to -20dBm) SENSe:CORRection:PATHloss3:DATA? SENSe:CORRection:PATHloss3:CLEAr
Software Controls	Manage Path Loss Tables -> Enabled Manage Path Loss Tables -> Name/Description Manage Path Loss Tables -> Edit Manage Path Loss Tables -> Clear Manage Path Loss Tables -> Number of Points
Couplings	None
Preset	Cleared.
Notes	

7.8 Reference

These commands control the reference oscillator settings the of the spectrum analyzer.

Command	[:SENSe]:ROSCillator:SOURce INTernal EXTernal OUTput [:SENSe]:ROSCillator:SOURce?
Description	Specify whether the spectrum analyzer should lock to the internal reference or an external reference, and whether the reference out is being used. This function works for all Signal Hound spectrum analyzers, however, the SA44B does not have a reference out so OUTput will not have an effect. This modifies the settings in the Reference dialog of the Settings menu.

The exact behavior and correspondence to Spike is device-dependent. This table maps the SCPI command to Spike Reference dialog settings for each device:

	INTernal	EXTernal	OUTput
SM200	Use Internal Reference	Use External Reference + Internal Out Enabled to FALSE	Use Internal Reference + Internal Out Enabled to TRUE
BB60C	Use Internal Reference	Use External Reference (AC)	Reference Out
SA124B	Not Set, Use Internal Reference	Use External Reference	Internal Reference Out
SA44B	Not Set, Use Internal Reference	Use External Reference	NO CHANGE

Conflicts that normally result in user dialogs will not appear when using this SCPI command. To verify the correct value has been set and accepted, use the query command.

Examples	:SENSE:ROSCILLATOR:SOURCE INTERNAL ROSC:SOUR EXT ROSC:SOUR OUT rosc:source?
Software Controls	Settings -> Reference
Couplings	None
Preset	On program startup, internal reference is selected.
Notes	None

7.9 Spectrum Analysis

7.9.1 Sweep Configuration

These commands control the receiver configuration in the swept analysis mode.

7.9.1.1 Frequency

These commands control the frequency range of the sweeps in swept analysis mode.

Command	[:SENSe] :FREQuency:CENTer <freq> UP DOWN [:SENSe] :FREQuency:CENTer? [MIN MAX] [:SENSe] :FREQuency:START <freq> [:SENSe] :FREQuency:START? [:SENSe] :FREQuency:STOP <freq> [:SENSe] :FREQuency:STOP? [:SENSe] :FREQuency:CENTer:STEP [:INCRement] <freq> [:SENSe] :FREQuency:CENTer:STEP [:INCRement] ? [:SENSe] :FREQuency:SPAN <freq> UP DOWN
---------	--

	<code>[:SENSe] :FREQuency:SPAN?</code>
Description	<p><code>CENTer</code>, Set the measurement center frequency. This can cause the start or stop frequency to change if the device is unable to maintain the current span with the new center frequency. This can have the side effect of changing the span/start/stop frequencies.</p> <p><code>CENTer?</code>, Query the current center frequency. Returned as Hz. By passing the MIN or MAX arguments, the user can query the upper and lower frequency limits for a sweep.</p> <p><code>STARt</code>, Change the sweep start frequency. The lower bound for the start frequency is determined with the <code>CENt? MIN</code> command.</p> <p><code>STARt?</code>, Query the current measurement start frequency in Hz.</p> <p><code>STOP</code>, Set the sweep stop frequency. The upper bound for the stop frequency is determined with the <code>CENt? MAX</code> command.</p> <p><code>STOP?</code>, Query the current measurement stop frequency in Hz.</p> <p><code>CENTer:STEP[:INCRement]</code>, Set the step amount the center frequency changes by when using the UP or DOWN parameters on the <code>CENTer</code> command.</p> <p><code>CENTer:STEP[:INCRement]?</code>, Query the center frequency step size in Hz.</p> <p><code>SPAN</code>, Set the sweep span. This will change the start/stop and potentially center frequency of the sweep in attempt to meet the span requested.</p> <p><code>SPAN?</code>, Query the span in Hz.</p>
Examples	<pre>SENS:FREQ:CENT 1GHz SENSE:FREQUENCY:CENTER? MAX FREQ:CENT UP FREQ:SPAN 20MHz FREQUENCY:CENTER:STEP 10KHZ</pre>
Software Controls	<p>Sweep Settings Controls -> Frequency -> Center</p> <p>Sweep Settings Controls -> Frequency -> Span</p> <p>Sweep Settings Controls -> Frequency -> Start</p> <p>Sweep Settings Controls -> Frequency -> Stop</p> <p>Sweep Settings Controls -> Frequency -> Step</p>
Couplings	Span is coupled with RBW and VBW. It is recommended to set RBW and VBW to auto whenever changing the span by large factors. Start/Stop is coupled with Center/Span.
Preset	Full span sweep.
Notes	Changing any frequency setting will trigger a re-sweep.

7.9.1.2 Power

These commands affect the RF front end of the device. Not all settings are available for each Signal Hound spectrum analyzer. It is recommended to leave attenuation/gain/preamp set to auto and control the RF leveling with reference level.

Command	<pre>[:SENSe] :POWeR[:RF]:RLEVel <amplitude> UP DOWN [:SENSe] :POWeR[:RF]:RLEVel? [:SENSe] :POWeR[:RF]:RLEVel:UNIT?</pre>
---------	--

	<pre>[:SENSe]:POWer[:RF]:RLEVel:OFFSet <double> [:SENSe]:POWer[:RF]:RLEVel:OFFSet? [:SENSe]:POWer[:RF]:PDIVision <double> [:SENSe]:POWer[:RF]:PDIVision? [:SENSe]:POWer[:RF]:ATTenuation <int> [:SENSe]:POWer[:RF]:ATTenuation? [:SENSe]:POWer[:RF]:ATTenuation:AUTO <bool> [:SENSe]:POWer[:RF]:ATTenuation:AUTO? [:SENSe]:POWer[:RF]:GAIN <int> [:SENSe]:POWer[:RF]:GAIN? [:SENSe]:POWer[:RF]:GAIN:AUTO <bool> [:SENSe]:POWer[:RF]:GAIN:AUTO? [:SENSe]:POWer[:RF]:PREAMP <int> [:SENSe]:POWer[:RF]:PREAMP? [:SENSe]:POWer[:RF]:PREAMP:AUTO <bool> [:SENSe]:POWer[:RF]:PREAMP:AUTO? [:SENSe]:POWer[:RF]:MW:PRESelector[:STATE] <bool> [:SENSe]:POWer[:RF]:MW:PRESelector[:STATE]? [:SENSe]:POWer[:RF]:SPURReject <bool> [:SENSe]:POWer[:RF]:SPURReject?</pre>
Description	<p>RLEVel, Set the reference level. If UP or DOWN is specified, the reference level is increased or decreased by the div amount (when reference level is a logarithmic unit).</p> <p>RLEVel?, Return the current reference level as dBm.</p> <p>RLEVel:UNIT?, Return the current amplitude unit used to express reference level.</p> <p>RLEVel:OFFSet, Set the reference level offset in dB.</p> <p>PDIVision, specify the plot vertical division (1/10th of the plot height) as dB. Logarithmic scale only.</p> <p>ATTenuation, Specify the attenuation index. It is recommended to leave attenuation set to auto and set the reference level instead.</p> <p>GAIN, Specify the gain index. It is recommended to leave gain set to auto and set the reference level instead.</p> <p>PREAMP, Specify whether the preamp is on/off. Only valid for the SA devices. It is recommended to leave preamp set to auto and set the reference level instead.</p> <p>MW:PRESelector, SM200A only. Set the preselector state on or off. The preselector filters affected by this setting are below 650MHz.</p> <p>MW:SPURReject, Enable/Disable the software spur reject algorithm.</p>
Examples	<pre>SENSE:POWER:RF:RLEVEL -20DBM POW:RLEV 90DBUV POW:RLEV:UNIT? POW:PDIV 6 POW:ATT:AUTO? SENS:POW:RF:GAIN:AUTO ON POW:RF:SPURR OFF</pre>
Software Controls	<p>Sweep Settings Controls -> Amplitude -> Ref Level</p> <p>Measurements Controls -> Offsets -> Ref Offset</p> <p>Sweep Settings Controls -> Amplitude -> Div</p>

	Sweep Settings Controls -> Amplitude -> Attenuation Sweep Settings Controls -> Amplitude -> Gain Sweep Settings Controls -> Amplitude -> Preamp File Menu -> Settings -> Preselector File Menu -> Settings -> Spur Reject
Couplings	If atten, gain, or preamp is set to auto, ref level overrides all their settings. All three must be set to non-auto values to override ref level. It is recommended to set them all to auto and only set the ref level.
Preset	The default value of reference level is device dependent, and the default unit is dBm. Div is set to 10 by default. Attenuation is set to auto by default. Gain is set to auto by default. Preamp is set to auto by default. Spur Reject is enabled for SA devices, and disabled for others. Preselector is disabled by default.
Notes	Changing any of these settings will trigger a re-sweep.

7.9.1.3 Bandwidth

These commands control the FFT processing for the receivers. These settings are highly coupled with the frequency range and sweep time. Additionally, there are several RBW/VBW restrictions present based on device type and span.

Command	<pre>[:SENSe]:BANDwidth[:RESolution] <freq> UP DOWN [:SENSe]:BANDwidth[:RESolution]? [:SENSe]:BANDwidth[:RESolution]:AUTO ON OFF 0 1 [:SENSe]:BANDwidth[:RESolution]:AUTO? [:SENSe]:BANDwidth:VIDeo <freq> UP DOWN [:SENSe]:BANDwidth:VIDeo? [:SENSe]:BANDwidth:VIDeo:AUTO ON OFF 0 1 [:SENSe]:BANDwidth:VIDeo:AUTO? [:SENSe]:BANDwidth:SHAPE FLATtop NUTTall GAUSSian [:SENSe]:BANDwidth:SHAPE?</pre>
Description	RESolution, Specify the RBW. If UP or DOWN is specified, the RBW is stepped in a 1/3/10 sequence. VIDeo, Specify the VBW. If UP or DOWN is specified, the VBW is stepped in a 1/3/10 sequence. SHAPE, Specify the FFT window function.
Examples	<pre>SENS:BAND:RES 10kHz BANDWIDTH:RESOLUTION 1MHz BAND:VID? SENSE:BAND:VIDEO:AUTO ON</pre>
Software Controls	Sweep Settings Controls -> Bandwidth -> RBW Sweep Settings Controls -> Bandwidth -> Auto RBW Sweep Settings Controls -> Bandwidth -> VBW Sweep Settings Controls -> Bandwidth -> Auto VBW

Couplings	<p>RBW is coupled with VBW and Span. RBW will also have additional restrictions depending on the active device. If you are changing the span by more than a large factor (>2-4) then it is suggested to set RBW and VBW to auto before changing span.</p> <p>VBW is also coupled with sweep time. In most cases, if sweep time implies a lower VBW settings, then the lower setting is used (internally only).</p>
Preset	<p>RBW is set to auto by default.</p> <p>VBW is set to auto by default.</p> <p>Shape is set to Flattop by default.</p>
Notes	Changing any bandwidth setting will trigger a re-sweep.

7.9.1.4 Sweep

The sweep commands control additional FFT settings of the receiver.

Command	<pre>[:SENSe]:SWEep:TIME <double> [:SENSe]:SWEep:TIME? [:SENSe]:SWEep:DETEctor:FUNCTion AVERage MINMAX MIN MAX [:SENSe]:SWEep:DETEctor:FUNCTion? [:SENSe]:SWEep:DETEctor:UNITs POWer SAMPle VOLTage LOG [:SENSe]:SWEep:DETEctor:UNITs?</pre>
Description	<p>TIME, Specified as seconds. Controls the overall acquisition length for the sweep. If the sweep time is smaller than is needed for the current RBW/VBW settings, then sweep time is ignored. If sweep time is longer than necessary for the current RBW/VBW settings, then VBW is lowered to meet the requested sweep time. The VBW is lowered internally and won't be represented in the VBW settings.</p> <p>DETEctor:FUNCTion, Controls how the VBW processing is performed. If average, overlapping FFTs are averaged together. If MIN/MAX, overlapping FFTs are min/max held. MIN or MAX is the same processing as min/max but only returns one of the resulting arrays.</p> <p>DETEctor:UNITs, Controls the units in which the detector function is performed in.</p>
Examples	<pre>SWE:TIME 0.1 SENS:DET:FUNC AVER SENSE:DETECTOR:FUNCTION? SWE:DET:UNIT POW</pre>
Software Controls	<p>Sweep Settings Controls -> Acquisition -> Swp Time</p> <p>Sweep Settings Controls -> Acquisition -> Detector</p> <p>Sweep Settings Controls -> Acquisition -> Video Units</p>
Couplings	RBW is coupled with VBW and Span. RBW will also have additional restrictions depending on the active device. If you are changing the span by more than a large factor (>2-4) then it is suggested to set RBW and VBW to auto before changing span.
Preset	<p>Sweep time is set to 1ms (0.001) by default.</p> <p>Detector is set to average by default.</p> <p>Detector units is set to power by default.</p>
Notes	Time is specified in seconds, 1ms minimum.

Changing any of these settings will trigger a re-sweep.

7.9.2 Traces

The trace commands control the user configurable traces for sweep mode. At any point there is an active trace that is selected with the `TRACe:SElect` command. All other commands operate on the current selected trace.

It may be necessary to request the entire selected sweep from the software. To do this, use the `DATA?` command. The sweep data will be returned as comma separated ascii floating point values. For example,

`-107.12,-88.4,-30.72,-91.94,-111.6,...`

To determine the frequency of any given point in the sweep, use the `XSTART?` and `XINCrement?` commands. The frequency of a given point is given by the equation,

Frequency of j 'th point = `XSTART + j * XINCREMENT`

where j is a zero based index into the array of sweep points.

Command	<code>:TRACe:SElect <int></code> <code>:TRACe:SElect?</code> <code>:TRACe:TYPE OFF WRITe AVERAge MAXhold MINhold MINMAX</code> <code>:TRACe:AVERAge:COUNt <int></code> <code>:TRACe:AVERAge:COUNt?</code> <code>:TRACe:AVERAge:CURRent?</code> <code>:TRACe:COPY <int></code> <code>:TRACe:UPDate[:STATe] ON OFF 0 1</code> <code>:TRACe:UPDate[:STATe]?</code> <code>:TRACe:DISPlay[:STATe] ON OFF 0 1</code> <code>:TRACe:DISPlay[:STATe]?</code> <code>:TRACe:CLEar</code> <code>:TRACe:CLEar:ALL</code> <code>:TRACe:XSTART?</code> <code>:TRACe:XINCrement?</code> <code>:TRACe:POINts?</code> <code>:TRACe[:DATA]?</code>
Description	<code>SElect</code> , Specify a trace index [1,6]. All future operations occur on this trace. <code>TYPE</code> , Specify the behavior of the trace. <code>AVERAge:COUNt</code> , Specify the number of traces that are averaged together to create the final sweep. <code>AVERAge:CURRent</code> , Retrieve the current number of traces that have been averaged together to create the final sweep.

	<p>COPY, Copy the currently selected trace to the trace specified by the supplied parameter. The supplied parameter should be between the value [1,6] and should not equal the currently selected trace. If the destination trace type is off, the trace type is set to clear and write. Update is set to off and display is set to on for the destination trace.</p> <p>UPDate:STATE, Specify if the trace updates when a new sweep is acquired from the device.</p> <p>DISPlay:STATE, Specify if the trace is hidden.</p> <p>CLEAr, Clear the selected trace. For example, if the current sweep is a max hold, sweep, and is cleared, the trace will be replaced with the next sweep from the device.</p> <p>CLEAr:ALL, Clear all the traces.</p> <p>XSTART?, Retrieve the frequency of the first point in the sweep as Hz. Useful for calculating the frequency of each point in the trace data returned from the :TRACe:DATA? command.</p> <p>XINCrement?, Retrieve the frequency step between two points in the trace data as Hz. Useful for calculating the frequency of each point in the trace data.</p> <p>POINTs?, Returns the number of points in the trace data.</p> <p>TRACe:DATA? Returns the trace data.</p>
Examples	<pre>TRAC:SEL 2 TRAC:TYPE AVER TRACE:COPY 2 TRACE:AVERAGE:COUNT 10 TRACE:AVER:CURR? TRAC:UPD ON TRAC:DISP ON</pre>
Software Controls	<p>Measurements Controls -> Traces -> Trace</p> <p>Measurements Controls -> Traces -> Type</p> <p>Measurements Controls -> Traces -> Avg Count</p> <p>Measurements Controls -> Traces -> Curr Avg</p> <p>Measurements Controls -> Traces -> Copy To</p> <p>Measurements Controls -> Traces -> Update</p> <p>Measurements Controls -> Traces -> Hide</p> <p>Measurements Controls -> Traces -> Clear</p>
Couplings	
Preset	<p>All traces but 1 are set to OFF type.</p> <p>Trace 1 is set to clear and write.</p>
Notes	<p>Changing these settings will not trigger a re-sweep.</p> <p>Changing the trace display state will take effect immediately.</p> <p>Clearing a trace will not take effect until the next sweep.</p> <p>Traces are not updated until another sweep comes in from the device.</p>

7.9.3 Markers

The marker commands control the Spike sweep markers. Select the active marker with the **MARKer:SElect** command. All marker commands will operate on the active marker.

Several commands operate on peaks. Peaks must meet the peak criteria which can be set with the `EXCursion` and `THReshold` commands.

Command	:CALCulate:MARKer:SElect <int> :CALCulate:MARKer:SElect? :CALCulate:MARKer:STATe ON OFF 0 1 :CALCulate:MARKer:STATe? :CALCulate:MARKer:TRACe <int> :CALCulate:MARKer:TRACe? :CALCulate:MARKer:MODE POSition NOISE CHPower NDB :CALCulate:MARKer:MODE? :CALCulate:MARKer:UPDate ON OFF 0 1 :CALCulate:MARKer:UPDate? :CALCulate:MARKer:DELTA ON OFF 0 1 :CALCulate:MARKer:DELTA? :CALCulate:MARKer:PKTRack ON OFF 0 1 :CALCulate:MARKer:PKTRack? :CALCulate:MARKer:X <freq> :CALCulate:MARKer:X? :CALCulate:MARKer:Y? :CALCulate:MARKer:MAXimum :CALCulate:MARKer:MAXimum:NEXT :CALCulate:MARKer:MAXimum:LEFT :CALCulate:MARKer:MAXimum:RIGHT :CALCulate:MARKer:MINimum :CALCulate:MARKer:PEAK:EXCursion <double> :CALCulate:MARKer:PEAK:EXCursion? :CALCulate:MARKer:PEAK:THReshold <amplitude> :CALCulate:MARKer:PEAK:THReshold? :CALCulate:MARKer:CHPower:WIDth <freq> :CALCulate:MARKer:CHPower:WIDth? :CALCulate:MARKer:NDB[:OFFset] <double> :CALCulate:MARKer:NDB[:OFFset]? :CALCulate:MARKer:NDB:BANDwidth? :CALCulate:MARKer:NDB:RLEFt? :CALCulate:MARKer:NDB:RRIGHt? :CALCulate:MARKer[:SET]:CENTer :CALCulate:MARKer[:SET]:RLEVel
Description	SElect, Select the active marker. STATe, Turn the marker on/off. TRACe, Specify which trace to place the marker on. The trace must also be active to be able to retrieve marker measurements. MODE, Switch between positional and noise marker. UPDate, When update is disabled, the marker will hold its current position and will not update on future sweep updates.

DELTA, When delta is enabled, the delta reference takes the current marker position and the marker measurement returns the delta frequency and amplitude between the current marker position and the delta reference.

PKTRace, When enabled, the marker performs a peak search on each new trace update.

X, Move the marker position to the specified frequency.

X?, Retrieve the marker position frequency as Hz.

Y?, Retrieve the marker position amplitude according to marker type. Position and channel power markers return dBm, and noise markers return dBm/Hz. N dB markers also return the amplitude at their position in dBm. N dB results are retrieved using the N dB commands.

MAXimum, Perform a peak search.

MAXimum:NEXT, Move the marker to the next highest peak. Only peaks that meet the peak criteria are considered.

MAXimum:LEFT, Move the marker to the next peak to the left of its current position. Only peaks that meet the peak criteria are considered.

MAXimum:RIGHT, Move the marker to the next peak to the right of its current position (higher frequency). Only peaks that meet the peak criteria are considered.

MINimum, Perform a minimum peak search.

PEAK:EXCursion, Specify the peak excursion in dB. How many dB above surrounding points the point must be before being considered a peak.

PEAK:THReshold, Specify the peak threshold. A point must exceed this amount before being considered as a peak. Once the threshold test is met, then the excursion test is ran. If it meets both, then a point is considered a peak.

PEAK:THReshold?, Returns the current threshold as dBm.

CHPower:WIDth, Specify the width of the channel power marker measurement as a frequency.

NDB[:OFFset], Specify the offset of the N dB marker measurement in dB.

NDB:BANDwidth? Retrieve the width of the N dB band.

NDB:RLEFt? Retrieve the left edge frequency of the N dB band.

NDB:RRIGHt? Retrieve the right edge frequency of the N dB band.

[:SET] :CENTer, Set the sweep center frequency to the current marker frequency.

[:SET] :RLEVel, Set the sweep reference level to the current marker amplitude.

Examples

```

CALC:MARK:SEL 1
CALC:MARK:STAT ON
CALCULATE:MARKER:TRACE 1
CALCULATE:MARKER:MODE POS
CALCULATE:MARKER:UPDATE ON
CALC:MARK:PEAK:THR -100DBM
CALC:MARK:PEAK:EXC 6
CALC:MARK:MAX
CALC:MARK:Y?
CALC:MARK:MIN
CALC:MARK:CHP:WIDTH 20MHZ
CALC:MARK:NDB -5.0
CALC:MARK:NDB:BAND?

```

	CALC:MARK:NDB:RLEF?
	CALC:MARK:NDB:RRIG?
Software Controls	Measurements Controls -> Markers -> Marker Measurements Controls -> Markers -> Active Measurements Controls -> Markers -> Place On Measurements Controls -> Markers -> Type Measurements Controls -> Markers -> Update Measurements Controls -> Markers -> Delta Measurements Controls -> Markers -> Pk Tracking Measurements Controls -> Markers -> Set Freq Measurements Controls -> Markers -> Peak Search Measurements Controls -> Markers -> Peak Left Measurements Controls -> Markers -> Peak Right Measurements Controls -> Markers -> Min Peak Measurements Controls -> Markers -> Next Peak Measurements Controls -> Markers -> Pk Excurs. Measurements Controls -> Markers -> Pk Threshold Measurements Controls -> Markers -> Ch Power Width Measurements Controls -> Markers -> N dB Offset Measurements Controls -> Markers -> To Center Measurements Controls -> Markers -> To Ref
Couplings	
Preset	All markers are disabled and set to Position/Normal type.
Notes	Changing the state of a marker will take effect immediately. For example, a peak search (MAXimum) command will move the marker immediately and allow you to request the updated frequency and amplitude without needing to re-sweep.

7.9.4 Trace Math

For more information on trace math, see the Spike user manual.

Command	:CALCulate:MATH[:STATe] <bool> :CALCulate:MATH[:STATe]? :CALCulate:MATH:FIRST <int> :CALCulate:MATH:FIRST? :CALCulate:MATH:SECond <int> :CALCulate:MATH:SECond? :CALCulate:MATH:RESult <int> :CALCulate:MATH:RESult? :CALCulate:MATH:OP PDIFF PSUM LOFFset LDIFF :CALCulate:MATH:OP? :CALCulate:MATH:OFFSet <double> :CALCulate:MATH:OFFSet?
Description	STATe, Enabled or disable the trace math function. FIRST, Specify the first operand trace in the selected trace math function. Valid values are [1,6].

	<p>SECond, Specify the second operand trace in the selected trace math function. Valid values are [1,6].</p> <p>REsult, Specify the result trace in the selected trace math function. Valid values are [1,6].</p> <p>OP, Specify the trace math function.</p> <p>OFFSet, Specify the offset to use in the logarithm trace math functions.</p>
Examples	<pre> CALC:MATH ON CALC:MATH:FIRST 1 CALC:MATH:SECOND 2 CALC:MATH:RESULT 3 CALC:MATH:OP LDIFF CALC:MATH:OFFSET -50 </pre>
Software Controls	<p>Measurements -> Trace Math -> Enabled</p> <p>Measurements -> Trace Math -> Op 1</p> <p>Measurements -> Trace Math -> Op 2</p> <p>Measurements -> Trace Math -> Result</p> <p>Measurements -> Trace Math -> Operation</p> <p>Measurements -> Trace Math -> Offset</p>
Couplings	None
Preset	
Notes	

7.9.5 Channel Power

These commands control the channel power measurement in the Spike software. Through these commands you can configure a main channel and up to 5 adjacent channels and simultaneously measure channel and adjacent channel power.

Command	<pre> [:SENSe]:CHPower:STATe ON OFF 0 1 [:SENSe]:CHPower:STATe? [:SENSe]:CHPower:TRACe <int> [:SENSe]:CHPower:TRACe? [:SENSe]:CHPower:WIDth <freq> [:SENSe]:CHPower:WIDth? [:SENSe]:CHPower:CHANnel:STATe <int>,ON OFF 0 1 [:SENSe]:CHPower:CHANnel:STATe? <int> [:SENSe]:CHPower:CHANnel:OFFSet <int>,<freq> [:SENSe]:CHPower:CHANnel:OFFSet? <int> [:SENSe]:CHPower:CHANnel:WIDth <int>,<freq> [:SENSe]:CHPower:CHANnel:WIDth? <int> [:SENSe]:CHPower:CHPower? [:SENSe]:CHPower:CHPower:LOWer? <int> [:SENSe]:CHPower:CHPower:UPPer? <int> [:SENSe]:CHPower:ACPower:LOWer? <int> [:SENSe]:CHPower:ACPower:UPPer? <int> </pre>
Description	STATe, Enables/disables the channel power measurement.

	<p>TRACe, Selects which trace the channel power measurement is performed on.</p> <p>WIDth, Specifies the width of the main channel power measurement as a frequency.</p> <p>CHANnel:STATe, Enables/disables the measurement of an adjacent channel.*</p> <p>CHANnel:OFFSet, Specifies the offset from center of an adjacent channel.*</p> <p>CHANnel:WIDth, Specifies the width of an adjacent channel.*</p> <p>CHPower?, Returns the channel power of the main channel.</p> <p>CHPower:LOWer?, Returns the lower channel power of an adjacent channel.*</p> <p>CHPower:UPPer?, Returns the upper channel power of an adjacent channel.*</p> <p>ACPower:LOWer?, Returns the lower adjacent power[†] of an adjacent channel.*</p> <p>ACPower:UPPer?, Returns the upper adjacent power[†] of an adjacent channel.*</p> <p>* Read the notes on how to specify a channel.</p> <p>[†] This is the power of the center channel minus the power of the channel specified.</p>
Examples	<pre> SENSE:CHPOWER:STATE ON SENSE:CHPOWER:TRACE 1 SENS:CHPOWER:WID 20MHz SENS:CHPOW:CHAN:STAT 1,ON SENS:CHPOW:CHAN:OFFSET 2,1GHZ SENS:CHPOW:CHAN:WID 3,20MHZ CHP:CHP? CHP:CHP:LOW? 1 CHP:ACP:UPP? 3 </pre>
Software Controls	<p>Channel Power Controls -> Enabled</p> <p>Channel Power Controls -> Target</p> <p>Channel Power Controls -> Width</p> <p>Channel Power Controls -> Power</p> <p>Channel Power Controls -> Channels Table -> State</p> <p>Channel Power Controls -> Channels Table -> Offset</p> <p>Channel Power Controls -> Channels Table -> Bandwidth</p> <p>Channel Power Controls -> Channels Table -> Lower (dBc)</p> <p>Channel Power Controls -> Channels Table -> Lower (dBm)</p> <p>Channel Power Controls -> Channels Table -> Upper (dBc)</p> <p>Channel Power Controls -> Channels Table -> Upper (dBm)</p>
Couplings	
Preset	Disabled by default.
Notes	<p>Any changes to channel power will not take effect until the next sweep. It is recommended to configure the desired channel after configuring the sweep settings but before you perform a sweep.</p> <p>There are 5 adjacent channels, each with an upper and lower component. Each adjacent channel is defined by a frequency offset from the main channel, and a bandwidth. They are specified as integers from 1 through 5.</p>

7.9.6 Occupied Bandwidth

These commands allow you to configure the occupied bandwidth measurement in the Spike software.

Command	<code>[:SENSe]:OBWidth:STATe ON OFF 0 1</code> <code>[:SENSe]:OBWidth:STATe?</code> <code>[:SENSe]:OBWidth:TRACe <int></code> <code>[:SENSe]:OBWidth:TRACe?</code> <code>[:SENSe]:OBWidth:PERCent <double></code> <code>[:SENSe]:OBWidth:PERCent?</code> <code>[:SENSe]:OBWidth:OBWidth?</code> <code>[:SENSe]:OBWidth:CENTer?</code> <code>[:SENSe]:OBWidth:POWer?</code>
Description	STATe , Enable or disable the occupied bandwidth measurement. TRACe , Specify which trace the occupied bandwidth measurement is performed on. PERCent , The occupied bandwidth measurement must contain N% of the total energy of the sweep. Specified as a percent. OBWidth? , Returns the bandwidth of the occupied bandwidth measurement as Hz. CENTer? , Returns the center frequency of the occupied bandwidth measurement as Hz. POWer? , Returns the power of the occupied bandwidth measurement.
Examples	<code>OBW:STAT ON</code> <code>OBW:TRAC 1</code> <code>OBW:PERC 99</code> <code>OBW:OBW?</code> <code>OBW:CENT?</code> <code>OBW:POW?</code>
Software Controls	Measurements Controls -> Occupied Bandwidth -> Enabled Measurements Controls -> Occupied Bandwidth -> Target Measurements Controls -> Occupied Bandwidth -> % Power
Couplings	None
Preset	Disabled by default.
Notes	The occupied bandwidth measurement is updated only after a sweep is performed.

7.9.7 Intermodulation Distortion

These commands allow you to configure the intermodulation distortion measurement in the Spike software.

Command	<code>[:SENSe]:IMD:STATe ON OFF 0 1</code> <code>[:SENSe]:IMD:STATe?</code> <code>[:SENSe]:IMD:FREQuency? F1 F2 IM3L IM3U</code> <code>[:SENSe]:IMD:TPOWer? F1 F2 IM3L IM3U</code> <code>[:SENSe]:IMD:TPOWer:DIFf? IM3L IM3U</code> <code>[:SENSe]:IMD:TOI? IM3L IM3U</code>
---------	---

Description	<p>STATe, Enable or disable the intermodulation distortion measurement.</p> <p>FREQuency?, Returns the frequency of the specified intermodulation product: f_1, f_2, lower third order product ($2f_1 - f_2$), or upper third order product ($2f_2 - f_1$).</p> <p>TPOWeR?, Returns the tonal power in dBm of the specified intermodulation product.</p> <p>TPOWeR:DIFF?, Returns the tonal power difference in dBc between the specified third order product and its corresponding first order product.</p> <p>TOI?, Returns the third-order intercept in dBm of the specified third order product.</p>
Examples	<p>IMD:STAT ON</p> <p>IMD:FREQ? F1</p> <p>IMD:TPOW? F2</p> <p>IMD:TPOW:DIFF? IM3L</p> <p>IMD:TOI? IM3U</p>
Software Controls	<p>Intermod Distortion Panel -> Enabled</p> <p>Intermod Distortion Panel -> Product</p> <p>Intermod Distortion Panel -> Frequency</p> <p>Intermod Distortion Panel -> Amplitude (dBm)</p> <p>Intermod Distortion Panel -> Amplitude (dBc)</p> <p>Intermod Distortion Panel -> TOI (dBm)</p>
Couplings	None
Preset	Disabled by default.
Notes	The intermodulation distortion measurement is updated only after a sweep is performed. It is possible for the third-order intermodulation products to be outside the frequency span of the sweep. In this case, zero will be returned from any of the query functions for third-order products. In Spike, "Out of Range" is displayed in the frequency readout of the affected products.

7.9.8 Peak Table

These commands control the Peak Table display panel in Swept Analysis mode.

Command	<pre>[:SENSe]:PEAK:TABLE:STATe ON OFF 0 1 [:SENSe]:PEAK:TABLE:STATe? [:SENSe]:PEAK:TABLE:TRACe <int> [:SENSe]:PEAK:TABLE:TRACe? [:SENSe]:PEAK:TABLE:THReshold <double> [:SENSe]:PEAK:TABLE:THReshold? [:SENSe]:PEAK:TABLE:EXCursion <double> [:SENSe]:PEAK:TABLE:EXCursion? [:SENSe]:PEAK:TABLE:SORT FREQuency AMPLitude [:SENSe]:PEAK:TABLE:SORT? [:SENSe]:PEAK:TABLE:COUNt? [:SENSe]:PEAK:TABLE:MAX <int> [:SENSe]:PEAK:TABLE:MAX? [:SENSe]:PEAK:TABLE:FREQuency? <int> [:SENSe]:PEAK:TABLE:AMPLitude? <int> [:SENSe]:PEAK:TABLE:FREQuency:DELTA? <int> [:SENSe]:PEAK:TABLE:AMPLitude:DELTA? <int></pre>
Description	STATe, Enables/disables the Peak Table panel.

	<p>TRACe, Selects which trace the peak measurements are performed on.</p> <p>THReshold, Specify the peak threshold in dBm. A point must exceed this amount before being considered as a peak. Once the threshold test is met, then the excursion test is ran. If it meets both, then a point is considered a peak.</p> <p>EXCursion, Specify the peak excursion in dB. How many dB above surrounding points the point must be before being considered a peak.</p> <p>SORT, Specifies the sort order of the table. Peaks can be sorted by frequency or amplitude. Frequency is ascending; amplitude is descending.</p> <p>COUNT?, Returns the number of peaks in the table. This is the number of peaks that have met the criteria specified. This value can change after each sweep.</p> <p>MAX, Specify the maximum number of peaks that can appear in the table. This value must be between [0, 99].</p> <p>FREQuency?, Returns the frequency of the specified peak.*</p> <p>AMPLitude?, Returns the amplitude of the specified peak.*</p> <p>FREQuency:DELTA?, Returns the frequency difference between the specified peak and the first peak in the list.*</p> <p>AMPLitude:DELTA?, Returns the amplitude difference between the specified peak and the first peak in the list.*</p> <p>* Read the notes on how to specify a peak.</p>
Examples	<pre> SENSE:PEAK:TABLE:STATE ON SENSE:PEAK:TABLE:TRACE 1 SENS:PEAK:TABL:THRESHOLD -90 SENS:PEAK:TABL:EXC -6 SENS:PEAK:TABL:SORT FREQ PEAK:TABL:COUNT? PEAK:TABL:FREQ? 1 PEAK:TABL:AMPL? 2 PEAK:TABL:FREQ:DELTA? 3 PEAK:TABL:AMPL:DELTA? 4 </pre>
Software Controls	<p>Peak Table Controls -> Enabled</p> <p>Peak Table Controls -> Target Trace</p> <p>Peak Table Controls -> Threshold</p> <p>Peak Table Controls -> Excursion</p> <p>Peak Table Controls -> Sort Order</p> <p>Peak Table Controls -> Max Peaks</p> <p>Peak Table -> Peak</p> <p>Peak Table -> Frequency</p> <p>Peak Table -> Amplitude</p> <p>Peak Table -> Delta Freq</p> <p>Peak Table -> Delta Ampl</p>
Couplings	
Preset	Disabled by default.
Notes	Any changes to the Peak Table panel will not take effect until the next sweep. It is recommended to configure the desired peak settings after configuring the sweep settings but before you perform a sweep.

There are a maximum of 16 peaks in the table, each with frequency, amplitude, delta frequency, and delta amplitude properties. Each peak is specified as an integer from 1 through 16.

If a peak is specified that is greater than the number of peaks in the table (eg. peak 7 when COUNT? returns 5), then a value of zero is returned for all properties.

7.10 Zero-Span

7.10.1 Configuration

These commands control the receiver configuration in zero-span mode.

7.10.1.1 Capture Settings

These commands control the configuration of the capture in zero-span mode.

Command	<pre>[:SENSe]:ZS:CAPture:RLEVel <amplitude> [:SENSe]:ZS:CAPture:RLEVel? [:SENSe]:ZS:CAPture:CENTer <freq> UP DOWN [:SENSe]:ZS:CAPture:CENTer? [MIN MAX] [:SENSe]:ZS:CAPture:CENTer:STEP[:INCRement] <freq> [:SENSe]:ZS:CAPture:CENTer:STEP[:INCRement]? [:SENSe]:ZS:CAPture:SRATe <freq> [:SENSe]:ZS:CAPture:SRATe? [:SENSe]:ZS:CAPture:IFBWidth <freq> [:SENSe]:ZS:CAPture:IFBWidth? [:SENSe]:ZS:CAPture:IFBWidth:AUTO ON OFF 0 1 [:SENSe]:ZS:CAPture:IFBWidth:AUTO? [:SENSe]:ZS:CAPture:SWEep:TIME <double> [:SENSe]:ZS:CAPture:SWEep:TIME?</pre>
Description	<p>RLEVel, Set the reference level.</p> <p>RLEVel?, Return the current reference level as dBm.</p> <p>CENTer, Set the measurement center frequency.</p> <p>CENTer?, Query the current center frequency. Returned as Hz. By passing the MIN or MAX arguments, the user can query the upper and lower frequency limits for a capture.</p> <p>CENTer:STEP[:INCRement], Set the step amount the center frequency changes by when using the UP or DOWN parameters on the CENTer command.</p> <p>CENTer:STEP[:INCRement]?, Query the center frequency step size in Hz.</p> <p>SRATe, Specify the sample rate of the capture. This determines how much decimation will be applied to the full signal.</p> <p>IFBWidth, Specify the IF bandwidth, only active when AUTO is set to false.</p> <p>IFBWidth:AUTO, When enabled, the Spike software will automatically choose an appropriate IF bandwidth for the measurement.</p>

	<code>SWEEP:TIME</code> , Specified as seconds. Controls the overall acquisition length of the capture.
Examples	<code>SENSE:ZS:CAPTURE:RLEVEL -20DBM</code> <code>SENS:ZS:CAP:CENT 1GHz</code> <code>SENSE:ZS:CAPTURE:CENTER? MAX</code> <code>ZS:CAP:CENT UP</code> <code>ZS:CAPTURE:SRATE 50MHZ</code> <code>ZS:CAP:IFBW?</code> <code>ZS:CAP:SWEEP:TIME .002</code>
Software Controls	Zero-Span Settings Controls -> Capture Settings -> Ref Level Zero-Span Settings Controls -> Capture Settings -> Center Zero-Span Settings Controls -> Capture Settings -> Step Zero-Span Settings Controls -> Capture Settings -> Sample Rate Zero-Span Settings Controls -> Capture Settings -> IF BW Zero-Span Settings Controls -> Capture Settings -> Auto IFBW Zero-Span Settings Controls -> Capture Settings -> Swp Time
Couplings	Sample rate is coupled with IFBW. It is recommended to set IFBW to auto when changing the sample rate.
Preset	Full sample rate capture at center of device range.
Notes	

7.10.1.2 Trigger Settings

Command	<code>:TRIGger:ZS:SOURce IMMEDIATE IF EXTernal FMT</code> <code>:TRIGger:ZS:SOURce?</code> <code>:TRIGger:ZS:SLOPe POSitive NEGative</code> <code>:TRIGger:ZS:SLOPe?</code> <code>:TRIGger:ZS:IF:LEVel <amplitude></code> <code>:TRIGger:ZS:IF:LEVel?</code> <code>:TRIGger:ZS:POSition <double></code> <code>:TRIGger:ZS:POSition?</code>
Description	<code>SOURce</code> , Specify the trigger type. <code>SLOPe</code> , Specify rising edge (positive) or falling edge. <code>IF:LEVel</code> , Specify the trigger level of the IF trigger. <code>POSition</code> , Specify the trigger delay of the IF or ext trigger, the percentage of samples of the capture displayed before the trigger.
Examples	<code>TRIG:ZS:SOURCE IF</code> <code>TRIG:ZS:SLOP POS</code> <code>TRIG:ZS:IF:LEV?</code> <code>TRIGGER:ZS:POSITION 20.0</code>
Software Controls	Zero-Span Settings Controls -> Trigger Settings -> Trigger Type Zero-Span Settings Controls -> Trigger Settings -> Trigger Edge Zero-Span Settings Controls -> Trigger Settings -> Trigger Level Zero-Span Settings Controls -> Trigger Settings -> Trigger Position
Couplings	None
Preset	Source set to immediate.

Position set to 10.00%.
Notes

7.10.2 I/Q Data

A zero-span capture consists of a sequence of complex I/Q points. The number of points is determined by the sample rate and sweep time. Usually, *points = sample rate * sweep time*.

Each complex point has an in-phase and quadrature component, each of which is represented as a 32-bit floating point number. Data is returned as an array of values where the complex components are interleaved. For example,

$I_1, Q_1, I_2, Q_2, \dots$

The I/Q data can be represented in ASCII or binary format. If ASCII is chosen, the data will be returned as a comma separated list of ASCII floating point values. For example,

$-0.08213204145, 0.04985508695, -0.08225408942, 0.05008481443, \dots$

In binary format, the values are scaled to 16-bit integers. The current reference level is used as scaler. To retrieve the floating point values, use the following equation:

$$float = \frac{short}{32768} \sqrt{reflevel}$$

where *reflevel* is represented in mW.

For large captures, binary format is faster and more efficient. Format is set using the `:FORMat:IQ[:DATA]` command.

7.10.3 Fetch Results

These functions are used to retrieve the measurement results. Fetch commands do not perform any measurement. The measurement must be performed with the INIT command when in single trigger mode or can be retrieved at any time in continuous measurement mode.

Command	<code>:FETCh:ZS? <int></code>
Description	<code>ZS?</code> , Fetch I/Q data and other measurement parameters. The integer parameter specifies which to retrieve.
	1. I/Q data in ASCII or binary format (see "I/Q Data" section above)

	2. Length of I/Q data. This is the number of complex I/Q data points (eg. (I_1, Q_1) is a single point).
	10. Average power as reported on the AM vs Time plot. Returned as dBm.
Examples	:FETCH:ZS? 1 :FETCH:ZS? 2 :FETCH:ZS? 10
Software Controls	N/A
Couplings	None
Preset	
Notes	

7.11 Scalar Network Analysis

These commands control Spike in the Scalar Network Analysis measurement mode. Several commands are shared with standard spectrum analysis.

7.11.1 Frequency Configuration

Note that the commands shared with sweep measurement mode are listed here again.

Command	[:SENSe] :FREQuency:CENTer <freq> UP DOWN [:SENSe] :FREQuency:CENTer? [MIN MAX] [:SENSe] :FREQuency:START <freq> [:SENSe] :FREQuency:START? [:SENSe] :FREQuency:STOP <freq> [:SENSe] :FREQuency:STOP? [:SENSe] :FREQuency:CENTer:STEP [:INCRement] <freq> [:SENSe] :FREQuency:CENTer:STEP [:INCRement] ? [:SENSe] :FREQuency:SPAN <freq> UP DOWN [:SENSe] :FREQuency:SPAN?
Description	CENTer, Set the measurement center frequency. This can cause the start or stop frequency to change if the device is unable to maintain the current span with the new center frequency. This can have the side effect of changing the span/start/stop frequencies. CENTer?, Query the current center frequency. Returned as Hz. By passing the MIN or MAX arguments, the user can query the upper and lower frequency limits for a sweep. START, Change the sweep start frequency. The lower bound for the start frequency is determined with the CENT? MIN command. START?, Query the current measurement start frequency in Hz. STOP, Set the sweep stop frequency. The upper bound for the stop frequency is determined with the CENT? MAX command. STOP?, Query the current measurement stop frequency in Hz. CENTer:STEP [:INCRement], Set the step amount the center frequency changes by when using the UP or DOWN parameters on the CENTer command.

	<p>CENTER:STEP[:INCRement]?, Query the center frequency step size in Hz.</p> <p>SPAN, Set the sweep span. This will change the start/stop and potentially center frequency of the sweep in attempt to meet the span requested.</p> <p>SPAN?, Query the span in Hz.</p>
Examples	<p>SENS:FREQ:CENT 1GHz</p> <p>SENSE:FREQUENCY:CENTER? MAX</p> <p>FREQ:CENT UP</p> <p>FREQ:SPAN 20MHz</p> <p>FREQUENCY:CENTER:STEP 10KHZ</p>
Software Controls	<p>Sweep Settings Controls -> Frequency -> Center</p> <p>Sweep Settings Controls -> Frequency -> Span</p> <p>Sweep Settings Controls -> Frequency -> Start</p> <p>Sweep Settings Controls -> Frequency -> Stop</p> <p>Sweep Settings Controls -> Frequency -> Step</p>
Couplings	<p>Span is coupled with RBW and VBW. It is recommended to set RBW and VBW to auto whenever changing the span by large factors. Start/Stop is coupled with Center/Span.</p>
Preset	Full span sweep.
Notes	Changing any frequency setting will trigger a re-sweep.

7.11.2 Sweep Configuration

Command	<pre>[:SENSe]:NA:SWEep:POINts <int> [:SENSe]:NA:SWEep:POINts? [:SENSe]:NA:SWEep:TYPE PASSive ACTive [:SENSe]:NA:SWEep:TYPE? [:SENSe]:NA:SWEep:HRANge ON OFF 0 1 [:SENSe]:NA:SWEep:HRANge? [:SENSe]:NA:VIEW:SCALe LOG VSWR [:SENSe]:NA:VIEW:SCALe? [:SENSe]:NA:VIEW:RLEVel <double> [:SENSe]:NA:VIEW:RLEVel? [:SENSe]:NA:VIEW:DIV <double> [:SENSe]:NA:VIEW:DIV? [:SENSe]:CORRection:NA:STORe:THRU [:SENSe]:CORRection:NA:STORe:THRU:HIGH [:SENSe]:CORRection:NA:STORe:THRU:ACTive?</pre>
Description	<p>POINts, Specify a suggested sweep size. The final sweep size takes this setting into consideration as well as hardware limitations when determining the final sweep size.</p> <p>TYPE, Specify whether an active or passive device is being measured. This will affect the attenuation and gain used during the sweep. Failure to properly set this value may result in reduced dynamic range or IF overload.</p> <p>HRANge, If high range is enabled, the software will optimize the sweep for dynamic range when a 20dB pad store through is performed. Sweep speed will decrease when selected.</p>

	<p><code>VIEW:SCALE</code>, Specify whether the plot is in log or VSWR units. A unique reference level and div are stored for both scale types.</p> <p><code>VIEW:RLEVEL</code>, Specify the reference level. When log scale is selected, the rlevel is specified as dBm, when VSWR is selected, rlevel is specified as SWR directly. Do not specify units.</p> <p><code>VIEW:DIV</code>, Specify the plot vertical scale as either dB or SWR (depending on what scale is currently selected). Do not specify units. In each case, the div is 1/10th the vertical scale of the plot.</p> <p><code>NA:STORE:THRU</code>, Perform a store through calibration.</p> <p><code>NA:STORE:THRU:HIGH</code>, Perform a store through high range calibration.</p> <p><code>NA:STORE:THRU:ACTIVE?</code>, Returns true when a calibration is active.(The store through has been performed for the current sweep settings.)</p>
Examples	<pre>SENS:FREQ:CENT 1GHz SENSE:FREQUENCY:CENTER? MAX FREQ:CENT UP FREQ:SPAN 20MHz FREQUENCY:CENTER:STEP 10KHZ</pre>
Software Controls	<p>Sweep Settings Controls -> Frequency -> Center</p> <p>Sweep Settings Controls -> Frequency -> Span</p> <p>Sweep Settings Controls -> Frequency -> Start</p> <p>Sweep Settings Controls -> Frequency -> Stop</p> <p>Sweep Settings Controls -> Frequency -> Step</p>
Couplings	Span is coupled with RBW and VBW. It is recommended to set RBW and VBW to auto whenever changing the span by large factors. Start/Stop is coupled with Center/Span.
Preset	Full span sweep.
Notes	Changing any frequency setting will trigger a re-sweep.

7.11.3 Traces

See [Traces](#)

7.11.4 Markers

See [Markers](#)

7.12 Phase Noise Measurements

These commands control Spike in the Phase Noise measurement mode. Phase noise measurements are only available for certain Signal Hound devices (SA and SM series spectrum analyzers).

7.12.1 Sweep Configuration

Configure the carrier search and phase noise measurement parameters.

Command	<pre> [:SENSe]:PNoise:CARRier:THReshold:MINimum <double> [:SENSe]:PNoise:CARRier:THReshold:MINimum? [:SENSe]:PNoise:CARRier:THReshold:VALid? [:SENSe]:PNoise:CARRier:THReshold:FREQuency? [:SENSe]:PNoise:CARRier:THReshold:AMPLitude? [:SENSe]:PNoise:VIEW:RLEVel <double> [:SENSe]:PNoise:VIEW:RLEVel? [:SENSe]:PNoise:VIEW:PDIVision <double> [:SENSe]:PNoise:VIEW:PDIVision? [:SENSe]:PNoise:FREQuency:CENTer <frequency> [:SENSe]:PNoise:FREQuency:CENTer? [:SENSe]:PNoise:FREQuency:OFFSet:STARt <frequency> [:SENSe]:PNoise:FREQuency:OFFSet:STARt? [:SENSe]:PNoise:FREQuency:OFFSet:STOP <frequency> [:SENSe]:PNoise:FREQuency:OFFSet:STOP? [:SENSe]:PNoise:AMRejection ON OFF 0 1 [:SENSe]:PNoise:AMRejection? </pre>
Description	<p>CARRier:THReshold:MINimum, Specify the minimum amplitude required in dBm (do not include units) needed for a signal to be detected as a carrier.</p> <p>CARRier:THReshold:VALid?, Returns whether a carrier was detected.</p> <p>CARRier:THReshold:FREQuency?, Returns the detected frequency of the carrier in Hz.</p> <p>CARRier:THReshold:AMPLitude?, Returns the detected amplitude of the carrier as dBm.</p> <p>VIEW:RLEVel, Specify the plot reference level as dBc/Hz.</p> <p>VIEW:PDIVision, Specify the plot division height as a floating point value.</p> <p>FREQuency:CENTer, Specify the carrier search frequency window. A search window with 200kHz span centered at the specified frequency is used for detecting a carrier.</p> <p>FREQuency:OFFSet:STARt, Specify the start frequency of the phase noise sweep as an offset from the detected carrier center frequency in Hz. Values must be between 10Hz and 10kHz and will be clamped to the closest value from the list [10Hz, 100Hz, 1kHz, 10kHz].</p> <p>FREQuency:OFFSet:STOP, Specify the stop frequency of the phase noise sweep as an offset from the detected carrier center frequency in Hz. Values must be between 1kHz and 10MHz and will be clamped to the closest value from the list [1kHz, 10kHz, 100kHz, 1MHz, 10MHz]</p> <p>AMRejection, Toggle AM rejection. When enabled, the amplitude of the signal is normalized to reduce any phase noise contribution from AM.</p>
Examples	<pre> PN:CARR:THR:MIN -20 PN:CARR:THR:VAL? PN:VIEW:RLEV -50 PN:VIEW:DIV 15 PN:FREQ:CEN 1GHz PN:FREQ:OFFS:STAR 100Hz PN:FREQ:OFFSET:STOP 1MHz PN:AMR ON </pre>

Software Controls	Phase Noise -> Sweep Settings -> Ampl Thresh
	Phase Noise -> Sweep Settings -> Carrier Freq
	Phase Noise -> Sweep Settings -> Start Freq
	Phase Noise -> Sweep Settings -> Stop Freq
	Phase Noise -> Sweep Settings -> Disp Ref
	Phase Noise -> Sweep Settings -> Div
	Phase Noise -> Sweep Settings -> AM Reject
Couplings	Stop offset frequency must be 1 decade larger than the start offset.
Preset	
Notes	Carrier detection occurs before every phase noise sweep. Carrier valid, freq, and amplitude can be queried for each completed phase noise sweep. If a carrier is not detected, valid returns false, and the trace data and markers are not updated.

7.12.2 Traces

There are 3 user configurable traces for phase noise measurements. Any active user traces are updated after each phase noise sweep.

Command	:TRACe:PNoise:SElect 1 2 3 :TRACe:PNoise:SElect? :TRACe:PNoise:TYPE OFF NORMal AVERage REFerence :TRACe:PNoise:TYPE? :TRACe:PNoise:AVERage:COUNt <int> :TRACe:PNoise:AVERage:COUNt? :TRACe:PNoise:TO 1 2 3 :TRACe:PNoise:CLEar
Description	SElect, Specify the active trace index. All future operations will occur on this trace. TYPE, Specify the trace type. Select OFF to disable the trace, NORMal for the standard clear/write operation, AVERage performs averaging over the last AVERage:COUNt sweeps and REFerence stops the trace from updating (effectively holding the current values). AVERage:COUNt, Specify the number of sweeps that will be averaged together when trace is set to average type. TO, Move the current trace to the selected trace. The selected trace type will be set to reference. CLEAr, Clear the current average accumulation.
Examples	TRAC:PN:SEL 1 TRAC:PN:TYPE AVER TRAC:PN:AVER:COUN 20 TRAC:PN:TO 2
Software Controls	Phase Noise -> Trace Settings -> Trace Phase Noise -> Trace Settings -> Type Phase Noise -> Trace Settings -> Avg Count Phase Noise -> Trace Settings -> Move To Phase Noise -> Trace Settings -> Clear Avg
Couplings	None

Preset	Trace 1 set to normal type. Trace 2/3 set to off.
Notes	

7.12.3 Marker

There is a single marker available for phase noise measurements. The marker can be placed on one of the 3 user configurable traces. Delta measurements can be enabled. A reference marker is placed at the current marker location when the delta measurement is enabled.

Command	:CALCulate:PNoise:MARKer[:STATe] ON OFF 0 1 :CALCulate:PNoise:MARKer[:STATe]? :CALCulate:PNoise:MARKer:TRACe 1 2 3 :CALCulate:PNoise:MARKer:TRACe? :CALCulate:PNoise:MARKer:DELTA ON OFF 0 1 :CALCulate:PNoise:MARKer:DELTA? :CALCulate:PNoise:MARKer:X <frequency> :CALCulate:PNoise:MARKer:X? :CALCulate:PNoise:MARKer:Y?
Description	STATe, Enable/disable the marker TRACe, Select which trace the marker is placed on. The marker is updated immediately. DELTA, Enable/disable the delta marker. A reference marker is created when the delta functionality is enabled. It is possible to update the reference marker on an already active delta marker simply by enabling delta again. X, Set the marker frequency as an offset from the carrier frequency. X?, Query the frequency of the marker as a frequency offset from the carrier. If the reference marker is active, the frequency returned is the difference between the reference marker and the current position. Y?, Query the amplitude of the marker as dBc/Hz. If the ref. marker is active, the value returned is the dB difference between the ref. marker and the current position.
Examples	CALC:PN:MARK ON CALC:PN:MARK:TRAC 1 CALC:PN:MARK:X 10kHz CALC:PN:MARK:DELTA ON CALC:PN:MARK:Y?
Software Controls	Phase Noise -> Marker Settings -> Trace Phase Noise -> Marker Settings -> Enabled Phase Noise -> Marker Settings -> Delta Marker
Couplings	None
Preset	Disabled by default.
Notes	

7.12.4 Jitter Configuration

Perform a jitter measurement on any of the 3 user traces.

Command	:CALCulate:PNoise:JITTer[:STATe] ON OFF 0 1 :CALCulate:PNoise:JITTer[:STATe]? :CALCulate:PNoise:JITTer:TRACe 1 2 3 :CALCulate:PNoise:JITTer:TRACe? :CALCulate:PNoise:JITTer:STARt <frequency> :CALCulate:PNoise:JITTer:STARt? :CALCulate:PNoise:JITTer:STOP <frequency> :CALCulate:PNoise:JITTer:STOP? :CALCulate:PNoise:JITTer:RMS? :CALCulate:PNoise:JITTer:PHASe?
Description	STATe, Enable/disable the jitter measurement. TRACe, Specify the target trace of the jitter measurement. STARt, Specify the start frequency of the jitter measurement as an offset from the carrier frequency. STOP, Specify the stop frequency of the jitter measurement as an offset from the carrier frequency. RMS?, Query the RMS Jitter of the measurement in seconds. PHASe?, Query the Phase Jitter of the measurement in radians.
Examples	:CALC:PN:JITT ON :CALC:PN:JITT:STAR 1KHz :CALC:PN:JITT:STOP 1MHz :CALC:PN:JITT:RMS? :CALCULATE:PNOISE:JITTER:PHASE?
Software Controls	Phase Noise -> Jitter Settings -> Enabled Phase Noise -> Jitter Settings -> Trace Phase Noise -> Jitter Settings -> Meas Start Phase Noise -> Jitter Settings -> Meas Stop
Couplings	None
Preset	Disabled by default.
Notes	

7.12.5 Decade Table

These commands simply toggle the display of the decade table. To measure the points that the decade table is showing, use the marker to loop through the desired decades and read back the amplitude.

Command	:CALCulate:PNoise:DECade:TABLE[:STATe] ON OFF 0 1 :CALCulate:PNoise:DECade:TABLE[:STATe]?
Description	STATe, Enable/disable the decade table display.
Examples	:CALC:PN:DEC:TABL ON
Software Controls	Phase Noise -> Decade Table -> Enabled
Couplings	None
Preset	Enabled by default.

7.13 Harmonic Measurements

7.13.1 Configuration

These commands configure the harmonic measurement.

Command	<pre>[:SENSe]:HARMonics:NUMBer <int> [:SENSe]:HARMonics:NUMBer? [:SENSe]:HARMonics:TRACKing[:STATe] ON OFF 0 1 [:SENSe]:HARMonics:TRACKing[:STATe]? [:SENSe]:HARMonics:MODE PEAK CHPower [:SENSe]:HARMonics:MODE? [:SENSe]:HARMonics:FREQuency:FUNDamental <freq> UP DOWN [:SENSe]:HARMonics:FREQuency:FUNDamental? [:SENSe]:HARMonics:FREQuency:STEP[:INCRement] <freq> [:SENSe]:HARMonics:FREQuency:STEP[:INCRement]? [:SENSe]:HARMonics:FREQuency:SPAN <freq> [:SENSe]:HARMonics:FREQuency:SPAN? [:SENSe]:HARMonics:BANDwidth[:RESolution] <freq> [:SENSe]:HARMonics:BANDwidth[:RESolution]? [:SENSe]:HARMonics:BANDwidth:VIDeo <freq> [:SENSe]:HARMonics:BANDwidth:VIDEO? [:SENSe]:HARMonics:POWEr[:RF]:RLEVel <double> [:SENSe]:HARMonics:POWEr[:RF]:RLEVel? [:SENSe]:HARMonics:VIEW:RLEVel <double> [:SENSe]:HARMonics:VIEW:RLEVel? [:SENSe]:HARMonics:VIEW:PDIVision <double> [:SENSe]:HARMonics:VIEW:PDIVision? [:SENSe]:HARMonics:TRACe:TYPE WRITe MAXhold [:SENSe]:HARMonics:TRACe:TYPE?</pre>
Description	<p>NUMBer, Specify the number of harmonics to be measured and displayed on screen.</p> <p>MODE, Specify the measurement mode for a harmonics peak amplitude. When peak is selected, a peak search algorithm is performed on the measured span. When channel power is selected over the entire measured harmonic span.</p> <p>TRACKing:STATe, When enabled the fundamental frequency is tracked. When peak measurement mode is selected, the frequency of the peak is used, when channel power measurement mode is selected, the center of the occupied bandwidth is tracked. With tracking enabled, the harmonics are measured at multiples of the measured fundamental and the fundamental is always drawn centered on the measured frequency.</p> <p>FREQuency:FUNDamental, Specify the center frequency of the 1st harmonic or fundamental.</p> <p>FREQuency:STEP[:INCRement], Specify the step frequency. Used to step the fundamental frequency.</p>

	<p>FREQuency:SPAN, Specify the span of each measurement window at each harmonic.</p> <p>BANDwidth[:RESolution], Specify the RBW of the measurement at each harmonic.</p> <p>BANDwidth:VIDeo, Specify the VBW of the measurement at each harmonic.</p> <p>POWer[:RF]:RLEVel, Specify the measurement reference level as dBm. This value should be greater than the expected input power to prevent IF/ADC overload.</p> <p>VIEW:RLEVel, Specify the plot reference level as dBm. This affects only the plot y-axis.</p> <p>VIEW:PDIVision, Specify the division height of the plot in dB. The division height is 1/10th of the plot height.</p> <p>TRACe:TYPE, Specify the trace behavior.</p>
Examples	<pre> :HARM:NUMB 8 :HARM:MODE PEAK :HARM:FREQ:FUND 1GHz :HARM:FREQ:STEP 1KHZ :HARM:FREQ:FUND DOWN :HARM:FREQ:SPAN 10kHz :HARM:BAND:RES 100Hz; VID 100Hz :HARM:POW:RF:RLEV 0 :HARM:VIEW:RLEV 5; PDIV 10 :HARM:TRAC:TYPE WRITE </pre>
Software Controls	<p>Harmonic Settings Panel -> Center Freq</p> <p>Harmonic Settings Panel -> Step</p> <p>Harmonic Settings Panel -> Span</p> <p>Harmonic Settings Panel -> RBW</p> <p>Harmonic Settings Panel -> VBW</p> <p>Harmonic Settings Panel -> Input Level</p> <p>Harmonic Settings Panel -> Disp Ref</p> <p>Harmonic Settings Panel -> Div</p> <p>Harmonic Settings Panel -> Harm Count</p> <p>Harmonic Settings Panel -> Meas Type</p> <p>Harmonic Settings Panel -> Trace Type</p>
Couplings	VBW must be less than or equal to RBW
Preset	
Notes	Span and RBW are limited.

7.13.2 Fetch Results

These commands retrieve the measurement results of the harmonic measurement. These commands do not issue a resweeps nor wait for a completed measurement. It is recommended to configure the software for single triggered measurements and using the `INIT` and `*OPC?` commands to initiate and wait for a measurement to complete before fetching measurement results.

Command	[:SENSe]:FETCh:HARMonics:FREQuency? <int> [:SENSe]:FETCh:HARMonics:AMPLitude? <int> [:SENSe]:FETCh:HARMonics:DISToTtion?
Description	FREQuency?, Fetch the specified harmonics peak frequency. AMPLitude?, Fetch the specified harmonics amplitude in dBm. DISToTtion?, Fetch the measured total harmonic distortion in %
Examples	:SENS:FETC:HARM:FREQ? 1 (Fetch the fundamental harm. freq) :FETC:HARM:FREQ? 10 (Fetch the 10th harm. freq) :FETC:HARM:AMPL? 2 :FETC:HARM:DIST?
Software Controls	N/A
Couplings	None
Preset	
Notes	

7.14 Analog Demodulation

7.14.1 Configuration

Command	[:SENSe]:ADEMod:FREQuency:CENTer <freq> UP DOWN [:SENSe]:ADEMod:FREQuency:CENTer? [:SENSe]:ADEMod:FREQuency:CENTer:STEP[:INCRement] <freq> [:SENSe]:ADEMod:FREQuency:CENTer:STEP[:INCRement]? [:SENSe]:ADEMod:POWer[:RF]:RLEVel <amplitude> [:SENSe]:ADEMod:POWer[:RF]:RLEVel? [:SENSe]:ADEMod:LPFilteR <freq> [:SENSe]:ADEMod:LPFilteR?
Description	CENTer, Specify the measurement center frequency. STEP, Specify the center frequency step amount when using the UP DOWN parameters. RLEVel, Specify the measurement reference level. This should be large than the highest expected input power. LPFilteR, Specify the analog low pass filter cutoff frequency.
Examples	ADEMOD:FREQ:CENT 1GHz ADEMOD:FREQ:CENT UP ADEMOD:FREQ:CENT:STEP 1KHz ADEMOD:POW:RLEV -20DBM ADEMOD:LPF 10KHZ
Software Controls	Analog Demod Controls -> Center Freq Analog Demod Controls -> Step Analog Demod Controls -> Input Level Analog Demod Controls -> Low Pass Freq
Couplings	None
Preset	
Notes	

7.14.2 Fetch Results

Command	:FETCh:ADEMod:AM? <int> :FETCh:ADEMod:FM? <int>
Description	<p>AM?, Fetch AM demodulation metrics. The integer parameter specifies the metric to retrieve. Possible integer values are below. Can specify a list of metrics to request as comma separated list. The metrics will be returned as a comma separated list in the order they were requested.</p> <ol style="list-style-type: none">1. Returns carrier frequency in Hz2. Returns carrier power in dBm3. Returns AM modulation rate in Hz4. Returns AM Depth (RMS) as %5. Returns AM Depth (Peak+) as %6. Returns AM Depth (Peak-) as %7. Returns AM SINAD as dB8. Returns AM THD as % <p>FM?, Fetch FM demodulation metrics. The integer provided specifies the metric to retrieve. Possible integer values are below. Can specify a list of metrics to request as comma separated list. The metrics will be returned as a comma separated list in the order they were requested.</p> <ol style="list-style-type: none">1. Returns carrier frequency in Hz2. Returns carrier power in dBm3. Returns FM modulation rate in Hz4. Returns FM Depth (RMS) in Hz5. Returns FM Depth (Peak+) in Hz6. Returns FM Depth (Peak-) in Hz7. Returns FM SINAD as dB8. Returns FM THD as %
Examples	:FETCh:ADEMOD:AM? 1,2,3,4,5,6,7,8 :FETCh:ADEMOD:FM? 7,8
Software Controls	N/A
Couplings	None
Preset	
Notes	

7.15 Digital Demodulation

7.15.1 Configuration

7.15.1.1 Measurement

These commands modify the digital demod measurement parameters.

Command	<pre> [:SENSe]:DDEMod:FREQuency:CENTer <freq> UP DOWN [:SENSe]:DDEMod:FREQuency:CENTer? [:SENSe]:DDEMod:FREQuency:CENTer:STEP[:INCRement] <freq> [:SENSe]:DDEMod:FREQuency:CENTer:STEP[:INCRement]? [:SENSe]:DDEMod:POWer[:RF]:RLEVel <amplitude> [:SENSe]:DDEMod:POWer[:RF]:RLEVel? [:SENSe]:DDEMod:SRATe <freq> [:SENSe]:DDEMod:SRATe? [:SENSe]:DDEMod:MODulation BPSK DBPSK QPSK DQPSK OQPSK PI4QPSK 8PSK D8PSK QAM16 QAM32 QAM64 QAM256 QAM1024 FSK2 FSK4 ASK2 CUSTom [:SENSe]:DDEMod:MODulation? [:SENSe]:DDEMod:RLENgth <int> [:SENSe]:DDEMod:RLENgth? [:SENSe]:DDEMod:FILTer NYQuist RNYQuist GAUSSian RECTangle [:SENSe]:DDEMod:FILTer? [:SENSe]:DDEMod:FILTer:ABT <double> [:SENSe]:DDEMod:FILTer:ABT? [:SENSe]:DDEMod:IFBWidth:AUTO ON OFF 0 1 [:SENSe]:DDEMod:IFBWidth:AUTO? [:SENSe]:DDEMod:IFBWidth <freq> [:SENSe]:DDEMod:IFBWidth? [:SENSe]:DDEMod:AVERage[:STATe] ON OFF 0 1 [:SENSe]:DDEMod:AVERage[:STATe]? [:SENSe]:DDEMod:AVERage:COUNT <int> [:SENSe]:DDEMod:AVERage:COUNT? </pre>
Description	<p>CENTer, Set the center frequency of the measurement.</p> <p>CENTer:STEP, Set the center frequency step amount.</p> <p>RLEV, Set the reference level of the measurement. This value should be higher than the expected peak power of the input signal. Setting it closer to the actual peak input will optimize for dynamic range.</p> <p>SRATe, Specify the sample rate of the input modulated signal.</p> <p>MODulation, Specify the modulation type of the input signal.</p> <p>RLENgth, Specify the measurement window length in symbols.</p> <p>FILTer, Specify the measurement and reference filter.</p> <p>ABT, Specify the filter alpha/beta coefficient.</p> <p>IFBWidth:AUTO, When enabled, the Spike software will automatically choose an appropriate IF bandwidth for the measurement, (usually 2x the sample rate)</p> <p>IFBWidth, Specify the IF bandwidth, only active when AUTO is set to false.</p> <p>AVERage:STATe, Enable measurement averaging.</p> <p>AVERage, Specify the average count.</p>
Examples	<pre> :DDEMod:FREQ:CENT 400MHZ :ddem:pow:rlev -20dbm :DDEMod:SRAT 1MHz :DDEMod:MOD FSK2 :ddemod:rlength 127 :ddemod:filter rnyquist </pre>

	:DDem:FILT:ABT 0.22 :DDem:IFBW:AUTO ON :DDem:IFBW 2MHz :DDem:AVER ON :DDem:AVER:COUN 10
Software Controls	Modulation Analysis Control Panel -> Center Freq Modulation Analysis Control Panel -> Freq Step Modulation Analysis Control Panel -> Input Power Modulation Analysis Control Panel -> Sample Rate Modulation Analysis Control Panel -> Symbol Count Modulation Analysis Control Panel -> Modulation Modulation Analysis Control Panel -> Source Filter Modulation Analysis Control Panel -> Filter Alpha Modulation Analysis Control Panel -> Auto IF BW Modulation Analysis Control Panel -> IF BW Modulation Analysis Control Panel -> Averaging Modulation Analysis Control Panel -> Average Count
Couplings	None
Preset	IF bandwidth set to auto Averaging enabled
Notes	

7.15.1.2 Custom Modulation

Command	[:SENSe]:DDEMod:CUSTom:IQ:VALid? [:SENSe]:DDEMod:CUSTom:IQ:LENGth? [:SENSe]:DDEMod:CUSTom:IQ:DATA <float>,<float>,...,<float> [:SENSe]:DDEMod:CUSTom:IQ:DATA?
Description	VALid?, Returns 1 when the custom constellation is valid. LENGth?, Returns the number of symbols in the custom constellation. DATA, Specify the constellation symbols as IQ values. IQ values are specified as comma separated real numbers, alternating IQ values. If an odd number of real values are provided the last value is ignored. If any value is an invalid real number, the command fails and throws a system error. While not strictly necessary, it is suggested to scale the constellation so that the maximum symbol magnitude is 1. See the example below. DATA?, Returns the constellation symbols as a comma separated list of alternating IQ values.
Examples	:DDem:CUST:IQ:VAL? :DDem:CUST:IQ:LENG? Specify the constellation for QPSK IQ values are specified as alternating real/imaginary pairs <i>I1,Q1,I2,Q2,...,In,Qn</i> :DDem:CUST:IQ:DATA 1,1,-1,1,-1,-1,1,-1 The command above specifies a constellation with the 4 points

	[1,1], [-1,1], [-1,-1], [1,-1]
	The response from DATA? is in the same format at the DATA command above. :DDEM:CUST:IQ:DATA?
Software Controls	Modulation Analysis Control Panel -> Edit Custom Mod
Couplings	None
Preset	Custom mod is empty by default.
Notes	

7.15.1.3 Trigger

Command	:TRIGger:DDEMod:SOURce IMMEDIATE IF EXTERNAL :TRIGger:DDEMod:SOURce? :TRIGger:DDEMod:IF:LEVel <amplitude> :TRIGger:DDEMod:IF:LEVel? :TRIGger:DDEMod:DELAy <int> :TRIGger:DDEMod:DELAy?
Description	SOURce, Specify the trigger type. IF:LEVel, Specify the trigger level of the IF trigger. DELAy, Specify the trigger delay of the IF or ext trigger, the number of symbols after the trigger to start the measurement.
Examples	:TRIG:DDEM:SOUR IF :TRIG:DDEM:IF:LEV -50DBM :TRIG:DDEM:DELAY 100
Software Controls	Modulation Analysis Control Panel -> Trigger Type Modulation Analysis Control Panel -> Trigger Level Modulation Analysis Control Panel -> Trigger Delay
Couplings	None
Preset	Source set to immediate. Delay set to 0.
Notes	

7.15.1.4 Sync Search

These commands affect the sync pattern search.

Command	[:SENSe]:DDEMod:SYNC[:STATe] ON OFF 0 1 [:SENSe]:DDEMod:SYNC[:STATe]? [:SENSe]:DDEMod:SYNC:SWORd:PATtern <hex string> [:SENSe]:DDEMod:SYNC:SWORd:PATtern? [:SENSe]:DDEMod:SYNC:SWORd:LENGth <int> [:SENSe]:DDEMod:SYNC:SWORd:LENGth? [:SENSe]:DDEMod:SYNC:SLENGth <int> [:SENSe]:DDEMod:SYNC:SLENGth?
---------	---

	[:SENSe]:DDEMod:SYNC:OFFSet <int> [:SENSe]:DDEMod:SYNC:OFFSet?
Description	<p>STATE, Enable/disable sync search.</p> <p>SWORd:PATtern, The pattern to trigger on for the trigger pattern. Patterns will be converted to uppercase when provided otherwise.</p> <p>SWORd:LENGth, The length in symbols of the pattern trigger. The pattern length is not necessarily the same length as the pattern itself. A shorter length uses only a portion of the pattern and a longer length pads the pattern with 'zeros'</p> <p>SLENGth, Search length for the pattern trigger.</p> <p>OFFSet, Offsets the measurement from the beginning of a successful sync search. Can be negative.</p>
Examples	<p>:DDEMod:SYNC ON</p> <p>:DDEMod:SYNC:SWOR:PATT AA11</p> <p>:DDEMod:SYNC:SWOR:LENG 16</p> <p>:DDEMod:SYNC:SLEN 1000</p> <p>:DDEMod:SYNC:OFFS -128</p>
Software Controls	<p>Modulation Analysis Control Panel -> Sync Search -> Enabled</p> <p>Modulation Analysis Control Panel -> Sync Search -> Pattern</p> <p>Modulation Analysis Control Panel -> Sync Search -> Pattern Length</p> <p>Modulation Analysis Control Panel -> Sync Search -> Search Length</p> <p>Modulation Analysis Control Panel -> Sync Search -> Offset</p>
Couplings	None
Preset	<p>Sync search disabled.</p> <p>Offset is 0.</p>
Notes	

7.15.1.5 Compensation

These commands determine what type of compensations are performed on the measurement. When the compensations are active, they are performed before error metrics are measured.

Command	[:SENSe]:DDEMod:COMPensate:IQINVersion[:STATe] ON OFF 0 1 [:SENSe]:DDEMod:COMPensate:IQINVersion[:STATe]? [:SENSe]:DDEMod:COMPensate:IQOFFset[:STATe] ON OFF 0 1 [:SENSe]:DDEMod:COMPensate:IQOFFset[:STATe]? [:SENSe]:DDEMod:COMPensate:ADRoop[:STATe] ON OFF 0 1 [:SENSe]:DDEMod:COMPensate:ADRoop[:STATe]?
Description	<p>IQINVersion, Enabled or disable IQ swap</p> <p>IQOFFset, When enabled, IQ offset is removed from the signal.</p> <p>ADRoop, When enabled, linear amplitude errors are corrected for in the signal.</p>
Examples	<p>:DDEMod:COMP:IQINV ON</p> <p>:DDEMod:COMPENSATE:IQOFFSET:STATE 1</p> <p>:DDEMod:COMP:ADR?</p>
Software Controls	<p>Modulation Analysis Control Panel -> I/Q Inversion</p> <p>Modulation Analysis Control Panel -> IQ Offset</p>

	Modulation Analysis Control Panel -> Ampl Droop
Couplings	None
Preset	I/Q Offset enabled by default I/Q inversion disabled by default Ampl droop disabled by default
Notes	

7.15.1.6 Equalization

These commands affect the adaptive equalizer.

Command	[:SENSe]:DDEMod:EQUalization[:STATe] ON OFF 0 1 [:SENSe]:DDEMod:EQUalization[:STATe]? [:SENSe]:DDEMod:EQUalization:LENGth <int> [:SENSe]:DDEMod:EQUalization:LENGth? [:SENSe]:DDEMod:EQUalization:CONVergence <double> [:SENSe]:DDEMod:EQUalization:CONVergence? [:SENSe]:DDEMod:EQUalization:HOLD[:STATe] ON OFF 0 1 [:SENSe]:DDEMod:EQUalization:HOLD[:STATe]? [:SENSe]:DDEMod:EQUalization:RESet
Description	STATe, Enabled or disable equalization. LENGth, Length of the equalization filter in symbols. Must be odd. CONVergence, Adaptive rate. Higher number adapt faster but are more unstable. HOLD, When enabled, adaptation step is bypassed but equalization is still applied. RESet, Resets the equalization filter to the unit impulse response (pass through).
Examples	:DDEMod:EQU ON :DDEMod:EQU:LENG 15 :DDEMod:EQU:CONV 10.0 :DDEMod:EQU:HOLD ON :DDEMod:EQU:RESET
Software Controls	Modulation Analysis Control Panel -> Equalization -> Enabled Modulation Analysis Control Panel -> Equalization -> Filter Len Modulation Analysis Control Panel -> Equalization -> Convergence Modulation Analysis Control Panel -> Equalization -> Hold Modulation Analysis Control Panel -> Equalization -> Reset
Couplings	None
Preset	Equalization is disabled. Filter Length is 5. Convergence is 1.0. Hold is off.
Notes	

7.15.2 Sweep

These functions are used to retrieve spectrum data from the digital demodulation measurement mode.

Command	[:SENSe]:DDEMod:TRACe:SWEep:XStARt? [:SENSe]:DDEMod:TRACe:SWEep:XINCrement? [:SENSe]:DDEMod:TRACe:SWEep:POINts? [:SENSe]:DDEMod:TRACe:SWEep:DATA?
Description	XStARt?, Get the frequency value associated with the first sample in the returned data. XINCrement?, Get the frequency spacing for the samples in the returned data. POINts?, Get the number of points returned by the DATA function. DATA?, Get the spectrum trace.
Examples	
Software Controls	N/A
Couplings	None
Preset	
Notes	

7.15.3 Fetch Results

These functions are used to retrieve the measurement results. Fetch commands do not perform any measurement. The measurement must be performed with the INIT command when in single trigger mode or can be retrieved at any time in continuous measurement mode.

Command	:FETCh:DDEMod? <int>
Description	DDEMod?, Fetch digital demodulation metrics. The integer parameter specifies the metric to retrieve. Possible integer values are below. Can specify a list of metrics to request as comma separated list. The metrics will be returned as a comma separated list in the order they were requested. 1. RMS EVM average as % 2. RMS EVM peak as % 3. RMS mag error average as % 4. RMS mag error peak as % 5. RMS phase error average as % 6. RMS phase error peak as % 7. IQ offset average as dB 8. IQ offset peak as dB 9. Frequency error average as Hz 10. Frequency error peak as Hz 11. RF power average as dBm 12. RF power peak as dBm

-
- 13. SNR average as dB
 - 14. SNR peak as dB
 - 15. RMS FSK error average as %
 - 16. RMS FSK error peak as %
 - 17. FSK deviation avg as Hz
 - 18. FSK deviation peak as Hz
 - 29. Current average count
 - 30. Demod bits as binary string
40. Constellation result length (see 41). Length in complex samples for PSK/QAM demodulations, or frequency samples for FSK demodulations.
41. Constellation results. This returns the I/Q values displayed on the constellation plot. When PSK/QAM demodulation is active, this is an array of complex values, and when FSK is selected, this is an array of scaled frequency values. This array is equal in length to the value returned in 40. This length is the symbol count times the oversample rate. For instance, with a symbol count of 128 and oversample rate of 16, this array should be 2048 samples (either complex or real). In this example, every 16th sample is the sampled symbol, with the transitions in-between. If FSK is selected, a real array is returned. The FSK frequency array returned should be scaled by the average frequency deviation returned in 17 (i.e. multiply every value in the returned array by the FSK avg dev). For complex constellation results, it is recommended to return to set :FORMAT: IQ to ascii (default), otherwise the I/Q data will be scaled to full scale 16-bit binary.

Examples	:FETCH:DDEMOD? 1,2,3,4,5,6,7,8 :FETCH:DDEMOD? 7,8
Software Controls	N/A
Couplings	None
Preset	
Notes	

7.16 Spectrum Emission Mask

7.16.1 Configuration

These commands control the receiver and measurement configuration in the spectrum emission mask mode.

7.16.1.1 Frequency

These commands control the frequency range of the sweeps in spectrum emission mask mode.

Command	[:SENSe] :SEMask:FREQuency:CENTer <freq> UP DOWN [:SENSe] :SEMask:FREQuency:CENTer? [:SENSe] :SEMask:FREQuency:CENTer:STEP[:INCRement] <freq> [:SENSe] :SEMask:FREQuency:CENTer:STEP[:INCRement]
---------	---

	[:SENSe]:SEMask:FREQuency:SPAN <freq> [:SENSe]:SEMask:FREQuency:SPAN?
Description	CENTer, Set the center frequency of the measurement. CENTer:STEP, Set the center frequency step amount. SPAN, Set the sweep span.
Examples	:SEMask:FREQ:CENT 1GHz :SEM:FREQUENCY:CENTER? :semask:freq:cent up :sem:freq:span 20mhz :SEMASK:FREQUENCY:CENTER:STEP 10e3
Software Controls	SEM Settings Control Panel -> Frequency -> Center Freq SEM Settings Control Panel -> Frequency -> Step SEM Settings Control Panel -> Frequency -> Span
Couplings	Span is coupled with RBW and VBW. It is recommended to set RBW and VBW to auto whenever changing the span by large factors.
Preset	None
Notes	Changing any frequency setting will trigger a re-sweep.

7.16.1.2 Bandwidth

These commands control the FFT processing for the receivers. These settings are highly coupled with the frequency range. Additionally, there are several RBW/VBW restrictions present based on device type and span.

Command	[:SENSe]:SEMask:BANDwidth[:RESolution] <freq> UP DOWN [:SENSe]:SEMask:BANDwidth[:RESolution]? [:SENSe]:SEMask:BANDwidth[:RESolution]:AUTO ON OFF 0 1 [:SENSe]:SEMask:BANDwidth[:RESolution]:AUTO? [:SENSe]:SEMask:BANDwidth:VIDeo <freq> UP DOWN [:SENSe]:SEMask:BANDwidth:VIDeo? [:SENSe]:SEMask:BANDwidth:VIDeo:AUTO ON OFF 0 1 [:SENSe]:SEMask:BANDwidth:VIDeo:AUTO?
Description	RESolution, Specify the RBW. If UP or DOWN is specified, the RBW is stepped in a 1/3/10 sequence. VIDeo, Specify the VBW. If UP or DOWN is specified, the VBW is stepped in a 1/3/10 sequence.
Examples	:SEMask:BAND:RES 10kHz :SENS:SEMask:BANDWIDTH:VIDEO 1e6 :SEM:BAND:VID? semask:band:vid:auto on
Software Controls	SEM Settings Control Panel -> Bandwidth -> RBW SEM Settings Control Panel -> Bandwidth -> Auto RBW SEM Settings Control Panel -> Bandwidth -> VBW SEM Settings Control Panel -> Bandwidth -> Auto VBW
Couplings	RBW is coupled with VBW and Span. RBW will also have additional restrictions depending on the active device. If you are changing the span by more than a large

	factor (>2-4) then it is suggested to set RBW and VBW to auto before changing span. VBW is also coupled with sweep time. In most cases, if sweep time implies a lower VBW settings, then the lower setting is used (internally only).
Preset	RBW is set to auto by default. VBW is set to auto by default.
Notes	Changing any bandwidth setting will trigger a re-sweep.

7.16.1.3 Amplitude

These commands affect the RF front end of the device.

Command	<code>[:SENSe]:POWer[:RF]:RLEVel <double></code> <code>[:SENSe]:POWer[:RF]:RLEVel?</code> <code>[:SENSe]:POWer[:RF]:PDIVision <double></code> <code>[:SENSe]:POWer[:RF]:PDIVision?</code>
Description	RLEVel , Set the reference level in dBm. PDIVision , specify the plot vertical division (1/10 th of the plot height) as dB. Logarithmic scale only.
Examples	<code>:SEM:POWER:RF:RLEVEL -20</code> <code>:SEM:POW:PDIV 6</code>
Software Controls	SEM Settings Control Panel -> Amplitude -> Ref Level SEM Settings Control Panel -> Amplitude -> Div
Couplings	None
Preset	The default value of reference level is device dependent. Div is set to 10 by default.
Notes	Changing any of these settings will trigger a re-sweep.

7.16.1.4 Detector / Trace

These commands control the detector and trace settings of the receiver.

Command	<code>[:SENSe]:SEMask:SWEep:DETEctor:FUNCTion AVERage MINMAX</code> <code>[:SENSe]:SEMask:SWEep:DETEctor:FUNCTion?</code> <code>[:SENSe]:SEMask:SWEep:DETEctor:UNITs POWer SAMPle VOLTage LOG</code> <code>[:SENSe]:SEMask:SWEep:DETEctor:UNITs?</code> <code>:TRACe:SEMask:TYPE WRITe MAXhold</code> <code>:TRACe:SEMask:TYPE?</code>
Description	DETEctor:FUNCTion , Controls how the VBW processing is performed. If average, overlapping FFTs are averaged together. If min/max, overlapping FFTs are min/max held. DETEctor:UNITs , Controls the units in which the detector function is performed in. TYPE , Specify the trace type. Select WRITE for the standard clear/write operation, and MAXHOLD to persist the maximum amplitudes at each frequency bin.
Examples	<code>:SEM:SWEEP:DET:FUNC AVER</code> <code>:SEM:SWEEP:DETECTOR:FUNCTION?</code>

	<code>semask:sweep:det:unit pow</code> <code>:TRACe:SEMask:TYPE WRITE</code>
Software Controls	SEM Settings Control Panel -> Detector / Trace -> Detector SEM Settings Control Panel -> Detector / Trace -> Video Units SEM Settings Control Panel -> Detector / Trace -> Trace Type
Couplings	The trace type determines the data that will be measured against the mask.
Preset	Detector is set to average by default. Detector units is set to power by default. Trace type is set to clear/write by default.
Notes	Changing any of these settings will trigger a re-sweep.

7.16.1.5 Measurement Reference

These commands control the configuration of the reference used in mask construction.

Command	<code>[SENSe:]SEMask:REF:TYPE PSD PEAK DIRect</code> <code>[SENSe:]SEMask:REF:TYPE?</code> <code>[SENSe:]SEMask:REF:BANDwidth:MODE AUTO MANual</code> <code>[SENSe:]SEMask:REF:BANDwidth:MODE?</code> <code>[SENSe:]SEMask:REF:BANDwidth <freq></code> <code>[SENSe:]SEMask:REF:BANDwidth?</code> <code>[SENSe:]SEMask:REF:LEVEL <double></code> <code>[SENSe:]SEMask:REF:LEVEL?</code>
Description	<code>REF:TYPE</code> , Controls how the reference measurement is taken. <code>PSD</code> performs a channel power computation, <code>PEAK</code> does a peak search, and <code>DIRECT</code> uses the amplitude value set directly by user. <code>REF:BANDwidth:MODE</code> , Controls the mode of setting the width of the measurement band. <code>AUTO</code> chooses a value automatically, <code>MANUAL</code> uses a width entered by user. <code>REF:BANDwidth</code> , Controls the width of the measurement band in manual mode. <code>REF:LEVEL</code> , Controls the reference amplitude level in direct set mode.
Examples	<code>:SEM:REF:TYPE PSD</code> <code>:SEM:REF:BANDWIDTH:MODE MAN</code> <code>:SEM:REF:BAND 100MHZ</code> <code>:SEMask:REF:BAND?</code> <code>semask:ref:level -20</code>
Software Controls	SEM Settings Control Panel -> Measurement Reference -> Meas Type SEM Settings Control Panel -> Measurement Reference -> Width Set SEM Settings Control Panel -> Measurement Reference -> Width SEM Settings Control Panel -> Measurement Reference -> Reference
Couplings	The width mode sets whether the width is used for channel power and peak calculations. The reference measurement type determines whether the direct set level is used in measurement.
Preset	Reference measurement type is set to <code>PEAK</code> by default Width mode is set to <code>AUTO</code> by default.
Notes	Changing any of these settings will trigger a re-sweep.

7.16.2 Offset Table

These functions load data into offset tables in memory and read back offset table defining the current mask.

Command	[SENSe:]SEMask:OFFSet:DATA <enabled1>, <startFreq1>, <stopFreq1>, <startLimit1>, <stopLimit1>, <model>, ... [SENSe:]SEMask:OFFSet:DATA?
Description	OFFSet:DATA, Specify the sets of offset parameters in the offset table in memory as the current mask. This will override any existing offsets. Offsets are specified as sets of six parameters: enabled: ON OFF 0 1 startFreq: <freq> startLimit: <freq> stopLimit: <double> startFreq: <double> mode: RELative ABSolute
Examples	:SEMASK:OFFSET:DATA 1, 13E6, 37E6, -13, -37, REL, OFF, 7MHZ, 11E6, -7, -11, ABSOLUTE
Software Controls	Offset Table
Couplings	These offsets define the mask the trace is currently being tested against.
Preset	
Notes	

7.16.3 Measurement

These functions return measurements from spectrum emission mask mode, testing the trace against the current mask defined in the offset table.

Command	[SENSe:]SEMask:CARRier:POWer? [SENSe:]SEMask:OFFSet:FAIL? [SENSe:]SEMask:OFFSet[1-16]:FAIL? [SENSe:]SEMask:OFFSet[1-16]:LOWer:FAIL? [SENSe:]SEMask:OFFSet[1-16]:UPper:FAIL? [SENSe:]SEMask:OFFSet[1-16]:MARgin? [SENSe:]SEMask:OFFSet[1-16]:MARgin:LOWer? [SENSe:]SEMask:OFFSet[1-16]:MARgin:UPper? [SENSe:]SEMask:OFFSet[1-16]:PEAK:LEVel:LOWer? [SENSe:]SEMask:OFFSet[1-16]:PEAK:LEVel:UPper? [SENSe:]SEMask:OFFSet[1-16]:PEAK:FREQuency:LOWer? [SENSe:]SEMask:OFFSet[1-16]:PEAK:FREQuency:UPper?
---------	--

Description	<p>CARRier:POWer?, Retrieves the current power used as the reference for the masks.</p> <p>OFFSet:FAIL?, Returns 1 if mask fails, 0 if passes.</p> <p>OFFSet[1-16]:FAIL?, Returns 1 if specified offset fails, 0 if it passes.</p> <p>OFFSet[1-16]:LOWer:FAIL?, Returns 1 if lower range of specified offset fails, 0 if it passes.</p> <p>OFFSet[1-16]:UPper:FAIL?, Returns 1 if upper range of specified offset fails, 0 if it passes.</p> <p>OFFSet[1-16]:MARgin?, Retrieves worst margin (limit - peak) of specified offset.</p> <p>OFFSet[1-16]:MARgin:LOWer?, Retrieves margin (limit - peak) of lower range of specified offset.</p> <p>OFFSet[1-16]:MARgin:UPper?, Retrieves margin (limit - peak) of upper range of specified offset.</p> <p>OFFSet[1-16]:PEAK:LEVel:LOWer?, Retrieves peak level of lower range of specified offset.</p> <p>OFFSet[1-16]:PEAK:LEVel:UPper?, Retrieves peak level of upper range of specified offset.</p> <p>OFFSet[1-16]:PEAK:FREQuency:LOWer?, Retrieves frequency at peak of lower range of specified offset.</p> <p>OFFSet[1-16]:PEAK:FREQuency:UPper?, Retrieves frequency at peak of upper range of specified offset.</p>
Examples	<p>:SEMASK:CARR:POW?</p> <p>:SEM:OFFSET:FAIL?</p> <p>:SEM:OFFS7:MARGIN?</p> <p>:SEM:OFFS7:PEAK:LEVEL:LOWER?</p> <p>:SEM:OFFS7:PEAK:FREQ:UPPER?</p>
Software Controls	Reference, Results
Couplings	None
Preset	
Notes	

7.16.4 Marker

The marker commands control the marker in spectrum emission mask mode.

Command	<p>:CALCulate:SEMask:MARKer:STATe ON OFF 0 1</p> <p>:CALCulate:SEMask:MARKer:STATe?</p> <p>:CALCulate:SEMask:MARKer:DELta ON OFF 0 1</p> <p>:CALCulate:SEMask:MARKer:DELta?</p> <p>:CALCulate:SEMask:MARKer:X <freq></p> <p>:CALCulate:SEMask:MARKer:X?</p> <p>:CALCulate:SEMask:MARKer:Y?</p> <p>:CALCulate:SEMask:MARKer:MAXimum</p> <p>:CALCulate:SEMask:MARKer:MINimum</p> <p>:CALCulate:SEMask:MARKer:NEXT</p> <p>:CALCulate:SEMask:MARKer:PREVious</p>
---------	--

Description	<p>STATe, Turn the marker on/off.</p> <p>DELTA, When delta is enabled, the delta reference takes the current marker position and the marker measurement returns the delta frequency and amplitude between the current marker position and the delta reference.</p> <p>X, Move the marker position to the specified frequency.</p> <p>X?, Retrieve the marker position frequency as Hz.</p> <p>Y?, Retrieve the marker position amplitude.</p> <p>MAXimum, Perform a peak search.</p> <p>MINimum, Perform a minimum search.</p> <p>NEXT, Move marker to next graph on plot.</p> <p>PREVious, Move marker to previous graph on plot.</p>
Examples	<p>CALC:SEM:MARK:STAT ON</p> <p>CALC:SEM:MARK:X 1GHz</p> <p>CALC:SEM:MARK:DELTA ON</p> <p>CALC:SEM:MARK:Y?</p> <p>CALC:SEM:MARK:MAX</p> <p>CALC:SEM:MARK:NEXT</p>
Software Controls	<p>Plot -> Left-Click</p> <p>Plot Context Menu -> Disable Marker</p> <p>Plot Context Menu -> Place Delta Marker</p> <p>Plot Context Menu -> Disable Delta Marker</p> <p>Plot -> Marker Readout</p> <p>Plot Context Menu -> Peak Search</p> <p>Plot Context Menu -> Minimum Search</p> <p>Plot -> Down Arrow</p> <p>Plot -> Up Arrow</p>
Couplings	
Preset	Marker is disabled.
Notes	Changing the state of a marker will take effect immediately. For example, a peak search (MAXimum) command will move the marker immediately and allow you to request the updated frequency and amplitude without needing to re-sweep.

7.17 Noise Figure

These commands control the receiver and measurement configuration and retrieve measurement results for the Noise Figure measurement mode.

7.17.1 Configuration

7.17.1.1 Frequency List

These commands control the list of frequency points at which measurements will take place.

Command	<p>[:SENSe] :NFIGure:FREQuency:MODE SWEPT FIXEd</p> <p>[:SENSe] :NFIGure:FREQuency:MODE?</p> <p>[:SENSe] :NFIGure:FREQuency:START <freq></p>
---------	--

	<pre> [:SENSe]:NFIGure:FREQuency:START? [:SENSe]:NFIGure:FREQuency:STOP <freq> [:SENSe]:NFIGure:FREQuency:STOP? [:SENSe]:NFIGure:FREQuency:CENTer <freq> [:SENSe]:NFIGure:FREQuency:CENTer? [MIN MAX] [:SENSe]:NFIGure:FREQuency:SPAN <freq> [:SENSe]:NFIGure:FREQuency:SPAN? [:SENSe]:NFIGure:FREQuency:POINts <int> [:SENSe]:NFIGure:FREQuency:POINts? [:SENSe]:NFIGure:FREQuency:FIXed <freq> [:SENSe]:NFIGure:FREQuency:FIXed? [:SENSe]:NFIGure:FREQuency:LIST:DATA? </pre>
Description	<p>MODE, Set how the list of measurement frequencies is determined. In SWEpt, the points are linearly distributed between the <i>Start</i> and <i>Stop</i> frequencies, with <i>Points</i> determining the number of points. In FIXed mode, a single frequency is measured, specified by <i>Fixed Freq</i>.</p> <p>MODE?, Query how the list of measurement frequencies is determined.</p> <p>START, Change the measurement list start frequency in Swept mode. The lower bound for the start frequency is determined with the CENT? MIN command.</p> <p>START?, Query the current measurement list start frequency in Hz.</p> <p>STOP, Set the measurement list stop frequency in Swept mode. The upper bound for the stop frequency is determined with the CENT? MAX command.</p> <p>STOP?, Query the current measurement list stop frequency in Hz.</p> <p>CENTer, Set the measurement list center frequency in Swept mode.</p> <p>CENTer?, Query the current measurement list center frequency in Hz. By passing the MIN or MAX arguments, the user can query the upper and lower frequency limits for a measurement.</p> <p>SPAN, Set the measurement list span in Swept mode. This will change the start/stop and potentially center frequency of the measurement list in attempt to meet the span requested.</p> <p>SPAN?, Query the measurement list span in Hz.</p> <p>POINts, Set the number of measurement points distributed across the <i>Span</i> in Swept mode.</p> <p>POINts?, Query the number of measurement points.</p> <p>FIXed, Set the frequency of the measurement in Fixed mode.</p> <p>FIXed?, Query the frequency of the measurement in Hz.</p> <p>LIST:DATA?, Get the list of measurement frequencies in Hz.</p>
Examples	<pre> SENSE:NFIGure:FREQUENCY:MODE SWEpt SENS:NFIG:FREQ:STAR 1GHz NFIG:FREQ:STOP 500MHz SENSE:NFIG:FREQUENCY:CENTER? MAX NFIG:FREQ:SPAN? NFIG:FREQ:POIN 101 NFIG:FREQ:FIX? NFIG:FREQ:LIST:DATA? </pre>

Software Controls	Noise Figure Settings -> Frequency List -> Freq Mode
	Noise Figure Settings -> Frequency List -> Start
	Noise Figure Settings -> Frequency List -> Stop
	Noise Figure Settings -> Frequency List -> Center
	Noise Figure Settings -> Frequency List -> Span
	Noise Figure Settings -> Frequency List -> Points
	Noise Figure Settings -> Frequency List -> Fixed Freq
Couplings	Start/Stop is coupled with Center/Span.
Preset	11 points from 1 – 2 GHz.
Notes	Changing any frequency list setting will invalidate the calibration (Cal State: Uncal).

7.17.1.2 Measurement

Command	<pre>[:SENSe]:NFIGure:POWer[:RF]:RLEVel <double> [:SENSe]:NFIGure:POWer[:RF]:RLEVel? [:SENSe]:NFIGure:BANDwidth[:RESolution] <freq> UP DOWN [:SENSe]:NFIGure:BANDwidth[:RESolution]? [:SENSe]:NFIGure:BANDwidth[:RESolution]:AUTO ON OFF 0 1 [:SENSe]:NFIGure:BANDwidth[:RESolution]:AUTO? [:SENSe]:NFIGure:BANDwidth:VIDeo <freq> UP DOWN [:SENSe]:NFIGure:BANDwidth:VIDeo? [:SENSe]:NFIGure:BANDwidth:VIDeo:AUTO ON OFF 0 1 [:SENSe]:NFIGure:BANDwidth:VIDeo:AUTO? [:SENSe]:NFIGure[:MEAS]:SPAN <freq> [:SENSe]:NFIGure[:MEAS]:SPAN? [:SENSe]:NFIGure:AVERage[:STATe] ON OFF 0 1 [:SENSe]:NFIGure:AVERage[:STATe]? [:SENSe]:NFIGure:AVERage:COUNt <integer> [:SENSe]:NFIGure:AVERage:COUNt? [:SENSe]:NFIGure:CORRection:TCOLd:VALue <double> [:SENSe]:NFIGure:CORRection:TCOLd:VALue? [:SENSe]:NFIGure:ALERt[:STATe] ON OFF 0 1 [:SENSe]:NFIGure:ALERt[:STATe]? [:SENSe]:NFIGure:CORRection:ENR:TABLE:COUNt? [:SENSe]:NFIGure:CORRection:ENR:TABLE:NEW [:SENSe]:NFIGure:CORRection:ENR:TABLE:LOAD[:ID] <integer> [:SENSe]:NFIGure:CORRection:ENR:TABLE[:ID]? [:SENSe]:NFIGure:CORRection:ENR:TABLE:TITLe <string> [:SENSe]:NFIGure:CORRection:ENR:TABLE:TITLe? [:SENSe]:NFIGure:CORRection:ENR:TABLE:POINts? [:SENSe]:NFIGure:CORRection:ENR:TABLE:DATA <freq1>, <enr1>, ... [:SENSe]:NFIGure:CORRection:ENR:TABLE:DATA? [:SENSe]:NFIGure:CORRection:ENR:CALibration:TABLE[:ID] <integer> [:SENSe]:NFIGure:CORRection:ENR:CALibration:TABLE[:ID]? [:SENSe]:NFIGure:CORRection:ENR:MEASurement:TABLE[:ID] <integer> [:SENSe]:NFIGure:CORRection:ENR:MEASurement:TABLE[:ID]?</pre>
Description	<p>RLEVel, Specify the reference level of the measurement in dBm.</p> <p>RESolution, Specify the RBW. If UP or DOWN is specified, the RBW is stepped in a 1/3/10 sequence.</p> <p>RESolution:AUTO, Automatically choose the RBW.</p>

	<p>VIDeo, Specify the VBW. If UP or DOWN is specified, the VBW is stepped in a 1/3/10 sequence.</p> <p>VIDeo:AUTO, Automatically choose the VBW.</p> <p>MEAS:SPAN, Specify the span of each sweep.</p> <p>AVERage, Specify whether multiple sweeps are averaged together.</p> <p>AVERage:COUNT, Specify the number of sweeps that are averaged together.</p> <p>AVERage:COUNT?, Query the number of averaged sweeps.</p> <p>CORRection:TCOLd:VALue, Specify room temperature in Kelvin.</p> <p>CORRection:TCOLd:VALue?, Query room temperature.</p> <p>ALERt, Specify whether a series of beeps will play when a sweep has finished.</p> <p>ALERt?, Query whether an alert will play on sweep completion.</p> <p>CORRection:ENR:TABLE:COUNT?, Query the count of ENR tables, corresponding to noise sources.</p> <p>ENR:TABLE:NEW, Create a new ENR table.</p> <p>TABLE:LOAD, Load an ENR table by ID for programmatic access.</p> <p>TABLE?, Query the ID of the currently loaded ENR table.</p> <p>TABLE:TITLe, Set the title of the currently loaded ENR table.</p> <p>TABLE:TITLe?, Query the title of the loaded ENR table.</p> <p>TABLE:POINts?, Query the number of points in the loaded ENR table.</p> <p>TABLE:DATA, Set the (frequency, enr) points in the loaded ENR table.</p> <p>TABLE:DATA?, Get the list of points in the loaded ENR table.</p> <p>CALibration:TABLE, Specify which ENR table will be used for calibration.</p> <p>CALibration:TABLE?, Query the calibration ENR table.</p> <p>MEASurement:TABLE, Specify which ENR table will be used for measurement.</p> <p>MEASurement:TABLE?, Query the measurement ENR table.</p>
Examples	<pre> SENSE:NFIGURE:POWER:RF:RLEVEL 10 NFIG:BANDWIDTH:RESOLUTION 10kHz SENS:NFIG:BAND:RES:AUTO ON NFIG:BAND:VID? NFIG:BAND:VID:AUTO OFF NFIG:MEAS:SPAN 4MHZ NFIG:AVERAGE ON NFIG:AVER:COUN 10 NFIG:CORR:TCOLD:VAL 290.0 NFIG:ALERt OFF NFIG:CORR:ENR:TABLE:COUNT? NFIG:CORR:ENR:TABLE:NEW NFIG:CORR:ENR:TABLE:LOAD 2 NFIG:CORR:ENR:TABLE? NFIG:CORR:ENR:TABLE:TITLE Keysight 346B 123456789 NFIG:CORR:ENR:TABLE:DATA 10000000,15.45,100e6,15.45 NFIG:CORR:ENR:CAL:TABLE 3 NFIG:CORR:ENR:MEAS:TABLE 1 </pre>
Software Controls	<p>Noise Figure Settings -> Amplitude -> Ref Level</p> <p>Noise Figure Settings -> Bandwidth -> RBW</p> <p>Noise Figure Settings -> Bandwidth -> Auto RBW</p>

	Noise Figure Settings -> Bandwidth -> VBW Noise Figure Settings -> Bandwidth -> Auto VBW Noise Figure Settings -> Measurement -> Meas Span Noise Figure Settings -> Measurement -> Averaging Noise Figure Settings -> Measurement -> Avg Number Noise Figure Settings -> Measurement -> Room Temp (K) Noise Figure Settings -> Measurement -> Play Alert Noise Figure Settings -> Measurement -> Noise Source (Cal) Noise Figure Settings -> Measurement -> Noise Source (Meas) Noise Figure Settings -> Measurement -> Manage ENR Tables
Couplings	RBW is coupled with VBW and Meas Span. RBW will also have additional restrictions depending on the active device. If you are changing the meas span by more than a large factor (>2-4) then it is suggested to set RBW and VBW to auto before changing meas span.
Preset	RBW is set to auto by default. VBW is set to auto by default.
Notes	

7.17.2 Calibration and Measurement

Command	[:SENSe]:NFIGure:CALibration:STATe? [:SENSe]:NFIGure:CALibration:INITiate [:SENSe]:NFIGure:MEASurement:INITiate [:SENSe]:NFIGure:CONTinue [:SENSe]:NFIGure:ABORt :STATus:NFIGure:NEXT? :STATus:NFIGure:PROGress?
Description	<p>CALibration:STATe?, Returns the current cal state. Possible values are</p> <ul style="list-style-type: none"> - uncal – There is no valid calibration currently stored. High measurement error is likely unless the DUT has at least 30 dB gain. - semical – There is a valid stored calibration, however the measurement accuracy has been reduced due to changes in the configuration since last cal. - cal – There is a valid stored calibration whose settings are identical to the current configuration. <p>CALibration:INITiate, Begin calibration process. MEASurement:INITiate, Begin measurement process. CONTinue, Continue calibration or measurement after the next action has been taken. ABORt, Stop any calibration or measurement in progress. Corresponding data is not retained. NEXT?, Query the next action user needs to take before continuing measurement. PROGress?, Query the percentage progress of the current sweep. If there is no sweep currently in progress, this will return 100%. This is a more verbose alternative to simply waiting for sweep to finish with *OPC.</p>
Examples	SENSe:NFIG:CAL:STAT?

	SENSE:NFIGURE:CALIBRATION:INITIATE NFIG:MEAS:INIT NFIG:CONT NFIG:ABORT STATUS:NFIG:NEXT? STAT:NFIG:PROG?
Software Controls	Noise Figure Toolbar -> Cal State (Label) Noise Figure Toolbar -> Calibrate (Button) Noise Figure Toolbar -> Measure (Button) Noise Figure Progress Dialog -> Abort (Button) Noise Figure Prompt Dialog -> Ok (Button) Noise Figure Progress Dialog -> Progress Bar
Couplings	
Preset	
Notes	

7.17.3 Fetch Results

Command	:FETCh:NFIGure? :FETCh:NFIGure:GAIN?
Description	FETCh:NFIGure? Fetch the list of noise figure measurements for each point in the frequency list. FETCh:NFIGure:GAIN? Fetch the list of gain measurements for each point in the frequency list.
Examples	:FETCh:NFIG? :FETCh:NFIG:GAIN?
Software Controls	Noise Figure plot Gain plot Results table
Couplings	None
Preset	
Notes	

7.18 Bluetooth® Low Energy Measurements

These commands control the receiver and measurement configuration and retrieve measurement results for the Bluetooth Low Energy measurement mode.

7.18.1 Configuration

7.18.1.1 Measurement

Command	[SENSe]:BLE:MEAS DEMOD IBE [SENSe]:BLE:MEAS? [SENSe]:BLE:FREQuency:CENTer <freq> [SENSe]:BLE:FREQuency:CENTer?
---------	---

	[SENSe]:BLE:FREQuency:CENTer:STEP[:INCRement] <freq> [SENSe]:BLE:FREQuency:CENTer:STEP[:INCRement]? [SENSe]:BLE:IFBW <freq> [SENSe]:BLE:IFBW? [SENSe]:BLE:CHANnel:INDeX <int> [SENSe]:BLE:CHANnel:INDeX? [SENSe]:BLE:CHANnel:AUTO <bool> [SENSe]:BLE:CHANnel:AUTO? [SENSe]:BLE:POW[:RF]:RLEVel <double> [SENSe]:BLE:POW[:RF]:RLEVel?
Description	MEAS, Specify the active Bluetooth measurement, demodulation vs in-band emission testing. CENTer, Specify the center frequency of the demodulation measurements. CENTer:STEP[:INCRement], Specify the center frequency step size. IFBW, Specify the measurement bandwidth for demodulation measurements. CHANnel:INDeX, When auto channel index is false, channel index is used to seed the PDU dewhitening. CHANnel:AUTO, When enabled, channel index is inferred from the center frequency. RLEVel, Specify the reference level of the measurement in dBm.
Examples	BLE:MEAS DEMOD BLE:FREQ:CENT 2.402GHz BLE:FREQ:CENT:STEP 2MHz BLE:IFBW 2.2MHz BLE:CHANNEL:INDEX 38 BLE:CHANNEL:AUTO 1 BLE:POW:RF:RLEVEL 10
Software Controls	Bluetooth Low Energy Settings -> Measurement Bluetooth Low Energy Settings -> Carrier Freq Bluetooth Low Energy Settings -> Step Freq Bluetooth Low Energy Settings -> Bandwidth Bluetooth Low Energy Settings -> Channel Index Bluetooth Low Energy Settings -> Override Ch. Index Bluetooth Low Energy Settings -> Ref Level
Couplings	
Preset	
Notes	

7.18.1.2 Trigger

Command	:TRIGger:BLE:SLENgth <time> :TRIGger:BLE:SLENgth?
Description	SLENgth, Specify the measurement capture length in which to search for a Bluetooth Low Energy packet.
Examples	:TRIG:WLAN:SLEN 100ms
Software Controls	Bluetooth Low Energy Settings -> Search Len

Couplings	None
Preset	
Notes	

7.18.2 Fetch Results

Command	:FETCh:BLE? <int>
Description	<p>FETCh:BLE, Fetch Bluetooth Low Energy demodulation metrics. The integer parameter specifies the metric to retrieve. Possible integer values are below. Can specify a list of metrics to request as comma separated list. The metrics will be returned as a comma separated list in the order they were requested.</p> <ol style="list-style-type: none"> 1. Average count for output power TRM measurements (as int) 2. Total average output power as dBm 3. Max average power as dBm 4. Peak power of last measurement as dBm 5. Avg power of last measurement as dBm 6. Pk – Avg power of last measurement as dBm <ol style="list-style-type: none"> 100. f1 Avg as Hz 101. f2 Avg as Hz 102. f2 Max ratio as double 103. f2 / f1 as double <ol style="list-style-type: none"> 200. CFO and drift measurement count as int 201. Preamble CFO as Hz 202. Max CFO as Hz 203. Max drift as Hz 204. Max drift / 50us as Hz 205. Max overall CFO as Hz 206. Max overall drift as Hz 207. Max overall drift / 50us as Hz <ol style="list-style-type: none"> 300. Pass fail status for in-band emissions (IBE) measurement, false if measurement not performed. 301. IBE tx channel as int, -1 if measurement not performed. 302. IBE peak power as dBm, 0 if measurement not performed. 303. IBE adjacent power lower as dBm, 0 if measurement not performed. 304. IBE adjacent power upper as dBm, 0 if measurement not performed. 305. IBE failed channels as int, -1 if measurement not performed. <ol style="list-style-type: none"> 400. PDU type as string 403. Access address bits as binary string 404. PDU bits as binary string (de-whitened if applicable) 403. Full packet bits as binary string (not de-whitened or decoded)
Examples	:FETC:BLE 1,2,3,4,5,6

	:FETC:BLE 1
Software Controls	Transmitter characteristics and in band emissions measurement results windows.
Couplings	None
Preset	
Notes	

7.19 WLAN Measurements

These commands control the receiver and measurement configuration in the WLAN measurement mode.

7.19.1 Configuration

7.19.1.1 Measurement

These commands affect the demodulation and receiver parameters of the measurement.

Command	[:SENSe]:WLAN:STANdard BG AG N20 N40 AC20 AC40 AH [:SENSe]:WLAN:STANdard? [:SENSe]:WLAN:SYMBols:DSSS <int> [:SENSe]:WLAN:SYMBols:DSSS? [:SENSe]:WLAN:PSDU:DECode <bool> [:SENSe]:WLAN:PSDU:DECode? [:SENSe]:WLAN:SYMBol:OFFSet <double> [:SENSe]:WLAN:SYMBol:OFFSet? [:SENSe]:WLAN:FREQuency:CENTer <freq> [:SENSe]:WLAN:FREQuency:CENTer? [:SENSe]:WLAN:FREQuency:CENTer:STEP[:INCRement] <freq> [:SENSe]:WLAN:FREQuency:CENTer:STEP[:INCRement]? [:SENSe]:WLAN:IFBW <freq> [:SENSe]:WLAN:IFBW? [:SENSe]:WLAN:POWer[:RF]:RLEVel <double> [:SENSe]:WLAN:POWer[:RF]:RLEVel?
Description	STANdard, Select the WLAN modulation standard. SYMBols:DSSS, Specify how many DSSS symbols to demodulate/decode. PSDU:DECode, Enable OFDM PSDU decoding for BCC encoded waveforms. SYMBol:OFFSet, Specify a GI timing offset between -100 and 0 (%) CENTer, Specify the center frequency of the WLAN measurement. CENTer:STEP[:INCRement], Specify the center frequency step size. IFBW, Specify the IF bandwidth of the measurement. This is applied as a low pass filter before the WLAN demodulation occurs. POWer[:RF]:RLEVel, Specify the reference level of the measurement in dBm. This controls the sensitivity of the measurement.
Examples	:WLAN:STAN N20 :WLAN:SYM:DSSS 512

	:WLAN:PSDU:DEC false :WLAN:SYMBOL:OFFSET -25 :WLAN:FREQ:CENT 2.442GHz :WLAN:FREQ:CENT:STEP 20MHz :WLAN:IFBW 20MHz :WLAN:POW:RLEV -20
Software Controls	WLAN Settings -> Standard WLAN Settings -> Max DSSS Syms WLAN Settings -> Decode PSDU WLAN Settings -> Symbol Offset WLAN Settings -> Carrier Freq WLAN Settings -> Step Freq WLAN Settings -> IF BW WLAN Settings -> Ref Level
Couplings	None
Preset	Symbol Offset = -50%
Notes	

7.19.1.2 Trigger

These commands affect the triggering and capturing parameters of the measurement.

Command	:TRIGger:WLAN:SLENgth <time> :TRIGger:WLAN:SLENgth? :TRIGger:WLAN:IF:THRESHold <double> :TRIGger:WLAN:IF:THRESHold? :TRIGger:WLAN:IF:LEVEl <double> :TRIGger:WLAN:IF:LEVEl?
Description	SLENgth, Specify the measurement capture length. IF:THRESHold, Specify the OFDM trigger threshold in dB. IF:LEVEl, Specify the DSSS video trigger level in dBm.
Examples	:TRIG:WLAN:SLEN 100ms :TRIG:WLAN:IF:THRESHOLD 10 :TRIG:WLAN:IF:LEV -40
Software Controls	WLAN Settings -> Search Len WLAN Settings -> OFDM Trig Threshold WLAN Settings -> DSSS Trig Level
Couplings	None
Preset	
Notes	

7.19.2 Fetch Results

This command is used to retrieve the results of a WLAN measurement.

Command	:FETCh:WLAN? <int>
Description	<p>FETCh:WLAN, Fetch WLAN demodulation metrics. The integer parameter specifies the metric to retrieve. Possible integer values are below. Can specify a list of metrics to request as comma separated list. The metrics will be returned as a comma separated list in the order they were requested.</p> <p>When the WLAN standard is set to 802.11 a/n/ac/ah, the integers below correspond to the following measurement results.</p> <ol style="list-style-type: none"> 1. Modulation as text 2. Modulation encoding as text 3. Guard interval as text 4. Frequency error as Hz 5. EVM as % 6. EVM as dB 7. Avg Power as dBm 8. Peak Power as dBm 9. Crest factor 10. Initial scrambler state 11. Symbol count 12. Payload bit count 13. Sample rate error as ppm 14. Bandwidth as MHz. For WLAN-AH, this is the detected BW of the measured packet. <p>When the WLAN standard is set to 802.11 b, the integers below correspond to the following measurement results.</p> <ol style="list-style-type: none"> 1. Modulation as text 2. Preamble as text 3. Payload bit count 4. EVM as % 5. EVM as dB 6. Freq error as Hz 7. Avg power as dBm 8. Peak power as dBm 9. Crest factor
Examples	<pre>:FETC:WLAN 1,2,3,4,5,6 :FETC:WLAN 1</pre>
Software Controls	
Couplings	None
Preset	
Notes	

7.20 LTE Measurements

Both single frequency and scanning LTE measurements can be performed with the SCPI commands. Configuration of the scan bands themselves cannot be performed via SCPI. For that reason, we recommend configuring a preset with the desired scan bands ahead of time and using SCPI to load that preset. Once the preset is loaded, scans can be manually performed, and the cell search results table can be queried with the FETCH command. Single frequency measurements can be performed, and most demodulation values can be retrieved with the FETCH command.

7.20.1 Configuration

Command	<pre>[:SENSe]:LTE:FREQuency:CENTer <freq> [:SENSe]:LTE:FREQuency:CENTer? [:SENSe]:LTE:FREQuency:CENTer:STEP[:INCRement] <freq> [:SENSe]:LTE:FREQuency:CENTer:STEP[:INCRement]? [:SENSe]:LTE:CORRelation:THREShold <double> [:SENSe]:LTE:CORRelation:THREShold? [:SENSe]:LTE:POW[:RF]:RLEVel <double> [:SENSe]:LTE:POW[:RF]:RLEVel? [:SENSe]:LTE:MEAS:INClude <bool> [:SENSe]:LTE:MEAS:INClude? [:SENSe]:LTE:SCAN:TYPE SINGLE CONTInuous [:SENSe]:LTE:SCAN:TYPE? [:SENSe]:LTE:SCAN:RESults:SORT RSSI FREQuency TIME [:SENSe]:LTE:SCAN:RESults:SORT? [:SENSe]:LTE:SCAN:RESults:KEEP LAST PEAK [:SENSe]:LTE:SCAN:RESults:KEEP? [:SENSe]:LTE:SCAN:RESults:GROUP <bool> [:SENSe]:LTE:SCAN:RESults:GROUP? [:SENSe]:LTE:SCAN:RESults:MAX <int> [:SENSe]:LTE:SCAN:RESults:MAX? [:SENSe]:LTE:SCAN:STARt? [:SENSe]:LTE:SCAN:ACTive? [:SENSe]:LTE:SCAN:STOP? [:SENSe]:LTE:SCAN:RESults:COUNt? [:SENSe]:LTE:SCAN:RESults:INDEX <int> [:SENSe]:LTE:SCAN:RESults:INDEX? [:SENSe]:LTE:SCAN:RESults:CLEar</pre>
Description	<p>CENTER, Set the center frequency of the single frequency LTE measurement.</p> <p>STEP, Set the frequency step. Stepping not available via SCPI, use FREQ:CENTER directly.</p> <p>RLEVel, Set the reference level (in dBm) for the single frequency LTE measurement.</p> <p>THREShold, Set the cell search correlation threshold. Must be between 0 and 1.</p>

	<p>INClude, When enabled, single frequency measurements are included in the cell search results.</p> <p>TYPE, Set whether the configured scan occurs once or continuously per “start scan”.</p> <p>SORT, Determines how the cell search result entries are sorted.</p> <p>KEEP, When cell search results are grouped, determines which measurement is displayed for that given grouping.</p> <p>GROUP, Enables cell search result grouping.</p> <p>MAX, Determines the maximum number of entries visible in the cell search results window.</p> <p>START?, Starts the scan, returns 1 once the scan has been started.</p> <p>ACTIVE?, Returns 1 if the scan is active.</p> <p>STOP?, Stops the scan. Returns 1 when complete.</p> <p>COUNT?, Returns the number of rows in the cell scan results table.</p> <p>INDEX, Set the index into the cell scan results table to be used with the FETCH command.</p> <p>CLEAR, Clears the cell search results table.</p>
Examples	<pre> :LTE:FREQ:CENTER 751MHz :LTE:POW:RF:RLEVEL -20 :LTE:MEAS:INCLUDE 1 :LTE:SCAN:TYPE SINGLE :LTE:SCAN:RESULTS:SORT FREQ :LTE:SCAN:RES:KEEP PEAK :LTE:SCAN:RES:GROUP 1 :LTE:SCAN:RESULTS:MAX 100 :LTE:SCAN:START? :LTE:SCAN:ACTIVE? :LTE:SCAN:STOP? </pre>
Software Controls	<p>LTE Settings -> Center Freq</p> <p>LTE Settings -> Freq Step</p> <p>LTE Settings -> Ref Level</p> <p>LTE Settings -> Include in Results</p> <p>LTE Scan Settings -> Scan Type</p> <p>LTE Scan Settings -> Sort By</p> <p>LTE Scan Settings -> Keep</p> <p>LTE Scan Settings -> Group Results</p> <p>LTE Scan Settings -> Max Results</p> <p>LTE Scan Settings -> Start Scan</p> <p>LTE Scan Settings -> Stop Scan</p> <p>LTE Cell Search Results -> File -> Clear</p>
Couplings	None
Preset	

Notes	We recommend the scan not being active when querying the COUNT? or setting the scan table INDEX, as if a scan is active the cell search results table can be continuously changing.
-------	---

7.20.2 Fetch Results

This function is used to retrieve measurement results from both single frequency and scanning LTE measurements. Fetch commands do not perform the actual measurement, only retrieves the measurement result. We recommend the measurement be in an idle state when querying results. This ensures measurement values are not being updated mid-way through a fetch query.

Command	:FETCh:LTE? <int>
Description	<p>LTE?, Fetch LTE measurement value. The integer parameter specifies the value to retrieve. Possible integer values are below. Can specify a list of metrics to request as comma separated list. The metrics will be returned as a comma separated list in the order they were requested.</p> <p>The following parameters retrieve measurements from the single frequency LTE result.</p> <ol style="list-style-type: none"> 1. Frequency of measurement 2. Channel power as dBm 3. Peak power 4. Peak to average power ratio 5. RSSI 6. RSRP 7. RSRQ 8. Freq error 9. Correlation result 10. PSS EVM 11. PBCH EVM 50. GPS Latitude 51. GPS Longitude 100. Phy. Cell ID 101. Phy. Group ID 102. Phy. Sector ID 103. Bandwidth 104. Duplex Mode 105. Cyclic Prefix 106. Number of ports 107. PHICH 108. Ng 109. Frame number

150. MIB bits

200. SIB1 Valid

201. EARFCN

202. TAC

203. Cell ID

204. Cell Barred

210. PLMN Count

211. MCC #1

212. MNC #1

213. Country String #1

214. Network String #1

215. MCC #2

216. MNC #2

217. Country String #2

218. Network String #2

219. MCC #3

220. MNC #3

221. Country String #3

222. Network String #3

223. MCC #4

224. MNC #4

225. Country String #4

226. Network String #4

250. SIB1 bits

The following parameters retrieve measurements from the cell search results table. Which row the results are retrieved from are determined by the index specified with the LTE:SCAN:RESULTS:INDEX command.

301. Frequency

302. EARFCN

303. RSSI

304. RSRP

305. RSRQ

306. Cell ID

307. Phy. Cell ID

308. Bandwidth

309. Duplex Mode

310. # of ports

311. PLMN Count

312. MCC #1

313. MNC #1

314. Country String #1

315. Network String #1

	316. Time as milliseconds since epoch
	319. GPS Latitude
	320. GPS Longitude
Examples	:FETCH:LTE? 1,2,3,4,5,6,7,8
Software Controls	N/A
Couplings	None
Preset	
Notes	

7.21 Audio Player

These commands control the audio player utility in Spike. The audio player can be started and stopped using these commands. The demodulation parameters can also be adjusted.

7.21.1 Configuration

Command	[:SENSe]:AUDio:START [:SENSe]:AUDio:STOP [:SENSe]:AUDio:FREQuency:CENTer <frequency> [:SENSe]:AUDio:FREQuency:CENTer? [:SENSe]:AUDio:MOD AM FM LSB USB CW [:SENSe]:AUDio:MOD? [:SENSe]:AUDio:BANDwidth:IF <frequency> [:SENSe]:AUDio:BANDwidth:IF? [:SENSe]:AUDio:BANDwidth:LOW <frequency> [:SENSe]:AUDio:BANDwidth:LOW? [:SENSe]:AUDio:BANDwidth:HIGh <frequency> [:SENSe]:AUDio:BANDwidth:HIGh? [:SENSe]:AUDio:FM:DEEMphasis <double> [:SENSe]:AUDio:FM:DEEMphasis?
Description	START, Open the audio player. If the audio player is already open, does nothing. STOP, Closes the audio player. If the audio player is already closed, does nothing. CENTer, Set the center frequency of the audio player. MOD, Set the audio demodulation type. IF, Set the IF bandwidth of the audio player. This is the filter applied before audio demodulation. LOW, Set the audio low pass filter. HIGh, Set the audio high pass filter. DEEMphasis, Set the FM deemphasis in us.
Examples	:AUDIO:START :AUDIO:STOP :AUDIO:MOD FM :AUDIO:FREQ:CENTER 97.0MHz

	:AUDIO:BAND:IF 120kHz :AUDIO:BAND:LOW 10kHz :AUDIO:BAND:HIGH 100HZ :AUDIO:FM:DEEMPHASIS 75
Software Controls	Utilities -> Audio Player Audio Player -> Center Frequency Audio Player -> Audio Type Audio Player -> Bandwidth Audio Player -> Low Pass Audio Player -> High Pass Audio Player -> Deemphasis
Couplings	None
Preset	
Notes	While the audio player is open, only commands in the audio subsystem should be sent to the Spike software.