


Application Software for WT series Power Analyzers 761941 WTVIEWER E

Real-time control over multichannel power measurements

WTVIEWER E software enables PC connectivity for Yokogawa power analyzers such as the WT3000E, WT1800E, WT500 and WT300E through Ethernet, USB, GPIB or RS232. With multichannel measurements, multi-unit connectivity and multilingual support, the WTVIEWER E allows users to easily control, monitor, collect, analyze, and save remote measurements from up to any 4 power analyzers simultaneously.



Real-time Control

WTVIEWER E allows users to analyze and control remote measurements in real-time or use previously acquired data. In the online mode, users have real time control of measurements from each connected instrument, allowing them to remotely start or stop integration or collect live measurement values. In the offline mode as well users can analyze the latest acquired or previously stored data.

Multichannel Measurements

With the WTVIEWER E, users can simultaneously view up to 12 waveforms, 8 trends, 8 vectors and 6 harmonic bar graphs in split screen mode or zoom in using cursors for more detail on a particular area of interest. Users can also customize, save and load screen layouts as well as specify the data to be saved in CSV format. The software also allows users to create custom computations combining values from multiple power analyzers.



With customizable split screen display of readings in numeric, bar, trend or vector formats, the WTVIEWER E simplifies the acquisition, storage and analysis of multichannel measurements from up to 4 power analyzers simultaneously.

Multi-unit Connectivity

WTVIEWER E enables synchronized measurement of up to 4 WT instruments in any combination regardless of model, element type or optional modules. The software auto detects connected instruments and displays a list from which users can modify wiring systems, voltage and current ranges, update intervals, synchronization sources, display formats and other measurement conditions.

Precision Making

Ideal for multichannel power measurements

The WTViewerE allows users to:

- Connect, synchronize and configure up to four power analyzers in any combination via Ethernet, USB, GPIB or RS232
- Remotely monitor, collect, and analyze live or stored multichannel measurements in a numeric, bar, trend, or vector formats
- Perform user defined computations combining values from multiple power analyzers
- Save or load configurations, measurement data, screen layouts and more

Overview of specifications

Compatible WT series model

Series model	Model	Firmware version
WT3000E/WT3000 series	WT3001E/WT3002E/WT3003E/WT3004E	No restriction
	WT3000 (760301/760302/760303/760304)	6.11 or later
WT1800E/WT1800 series	WT1801E/WT1802E/WT1803E/WT1804E/WT1805E/WT1806E	No restriction
	WT1801/WT1802/WT1803/WT1804/WT1805/WT1806	2.31 or later
WT500 series	WT500 (760201/760202/760203)	1.21 or later
WT300E/WT300 series	WT310E/WT310EH/WT332E/WT333E WT310/WT310HC/WT332/WT333	No restriction

Functions

Measuring items	Normal, Harmonics, Integration
Display screens	Numeric, Waveform ^{*1} ~ ^{*4} , Trend, Harmonic list ^{*2} , Harmonic bar graph ^{*2} , Vector ^{*2} ~ ^{*3} and Analysis graph
Data acquisition interval	50 ms at maximum speed
Data conversion	Numeric and Waveform data: CSV format (.csv)
Languages supported	English, Japanese, Simplified Chinese, French, German, Hungarian, Korean, Russian, Spanish, Italian

*1 Harmonic measurement option must be installed in the WT300 or WT300E.

*2 Harmonic measurement option must be installed in the WT.

*3 A vector window cannot be displayed on the WT300 or WT300E.

*4 When WT update interval is 1 second or longer and the WT waveform observation period is same as the update interval, measured waveform data can be acquired continuously. Continuous waveform data cannot be acquired from the WT300 or WT300E.

System Requirements

PC	Equivalent to Intel Core i5-2430M or higher with 4 GB RAM or higher and 1 TB free space on HDD
Operating system	English version of Windows 7, Windows 8.1, or Windows 10
Communication interface	GPIB, RS232, Ethernet (10BASE-T, 100BASE-TX, or 1000BASE-T), USB Rev. 1.1 or higher

Model

Model	Product name
761941	WTViewerE

■ Any company's name and product names mentioned in this document are trade names, trademarks or registered trademarks of their respective companies.

NOTICE

- Before operating the product, read the user's manual thoroughly for proper and safe operation.

YOKOGAWA



<http://tmi.yokogawa.com/>

YMI-KS-MI-SE05

YOKOGAWA TEST & MEASUREMENT CORPORATION

Global Sales Dept. /Phone: +81-422-52-6237 E-mail: tm@cs.jp.yokogawa.com
Facsimile: +81-422-52-6462

YOKOGAWA CORPORATION OF AMERICA

YOKOGAWA EUROPE B.V.

YOKOGAWA SHANGHAI TRADING CO., LTD.

YOKOGAWA ELECTRIC KOREA CO., LTD.

YOKOGAWA ENGINEERING ASIA PTE. LTD.

YOKOGAWA INDIA LTD.

YOKOGAWA ELECTRIC CIS LTD.

YOKOGAWA AMERICA DO SUL LTDA.

YOKOGAWA MIDDLE EAST & AFRICA B.S.C(c)

Phone: +31-88-4641000
Phone: +86-21-6239-6363
Phone: +82-2-2628-3810
Phone: +65-6241-9933
Phone: +91-80-4158-6396
Phone: +7-495-737-78-68
Phone: +55-11-5681-2400
Phone: +973-17-358100

E-mail: tmi@us.yokogawa.com
E-mail: tmi@nl.yokogawa.com
E-mail: tech@ysh.com.cn
E-mail: TMI@kr.yokogawa.com
E-mail: TMI@sg.yokogawa.com
E-mail: tmi@in.yokogawa.com
E-mail: info@ru.yokogawa.com
E-mail: help.ymatmi@bh.yokogawa.com

Facsimile: +86-21-6880-4987
Facsimile: +82-2-2628-3899
Facsimile: +65-6241-9919
Facsimile: +91-80-2852-1442
Facsimile: +7-495-737-78-69

Facsimile: +973-17-336100

Subject to Change without notice.

Copyright © 2017, Yokogawa Test & Measurement Corporation

[Ed: 02/b]

Printed in Japan, 804(KP)