

Running Iperf on WICED-SDK Console Application

Iperf is available in the WICED SDK console test application. Load the console application onto a WICED evaluation board, then connect with a terminal program (eg. PuTTY) with parameters 115200 8N1.

Once the console application boots, standard IPerf commands are available through the console. Before running IPerf, the application needs to join to a Wi-Fi Access Point (AP) as a Wi-Fi client (WICED STA) or start a Wi-Fi AP (WICED SoftAP). Some useful examples follow.

Joining a Wi-Fi AP as WICED STA

The STA needs to join a Wi-Fi AP and either assign an IP address statically or use DHCP. The following is an example of joining an open Wi-Fi AP and assigning a fixed IP address:

```
> join your_ssid open 0102 192.168.1.108 255.255.255.0 192.168.1.1
Joining : your_ssid
Successfully joined : your_ssid
Network ready IP: 192.168.1.108
Network mask: 255.255.255.0
Gateway IP: 192.168.1.1
> ping 192.168.1.1
Pinging: 192.168.1.1
Ping Reply 9ms
```

Starting WICED SoftAP

To start a SoftAP:

```
start_ap <ssid> <open|wpa2|wpa2_aes> <key> <channel> <wps>
```

Notes and known issues:

- Starting a Soft AP in open mode (no encryption) requires a dummy argument for <key>
- SoftAP may be stopped by using the stop_ap command.

Examples:

Start an AP using WPA2-AES:

```
> start_ap YOUR_AP_SSID wpa2_aes 12345678 6
```

Start an AP using WPA2/WPA mixed mode:

```
> start_ap YOUR_AP_SSID wpa2 12345678 6
```

Start an AP using open mode (no encryption):

```
> start_ap YOUR_AP_SSID open DUMMY_KEY
```

Standard Iperf Commands

To run Iperf in a thread so that other Iperf instances can also be run, see the `thread_spawn` commands further below. The number of Iperf threads that can run depends on the available memory on the WICED module. The BCM943362WCD4 module can generally support two Iperf threads.

Start a TCP server:

```
> iperf -s
```

Start a UDP server:

```
> iperf -s -u
```

Start a UDP Multicast server bound to 224.1.1.1:

```
> iperf -s -u -B 224.1.1.1
```

Start a TCP client:

```
> iperf -c 192.168.1.136
```

Start a UDP client and send at voice priority (using the `-S` option), for 90 seconds at 10 Mbps, followed by the same command at video, best effort and background levels of priority:

```

> iperf -c 192.168.1.136 -u -s 7 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[ ID] Interval      Transfer    Bandwidth
[  0] 0.0-90.0 sec  95.3 MBytes 8.88 Mbits/sec
[  0] Sent 67995 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec  95.2 MBytes 8.87 Mbits/sec  1.383 ms 106/67996 (0.16%)

> iperf -c 192.168.1.136 -u -s 5 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[ ID] Interval      Transfer    Bandwidth
[  0] 0.0-90.0 sec  93.7 MBytes 8.73 Mbits/sec
[  0] Sent 66817 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec  93.7 MBytes 8.73 Mbits/sec  1.210 ms  9/66818 (0.013%)

> iperf -c 192.168.1.136 -u -s 0 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[  0] 0.0-90.0 sec  90.6 MBytes 8.44 Mbits/sec
[  0] Sent 64607 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec  90.6 MBytes 8.44 Mbits/sec  1.449 ms  2/64608 (0.0031%)

> iperf -c 192.168.1.136 -u -s 1 -t 90 -b 10M
-----
Client connecting to 192.168.1.136, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[  0] 0.0-90.0 sec  42.1 MBytes 3.92 Mbits/sec
[  0] Sent 30037 datagrams
[  0] Server Report:
[  0] 0.0-90.0 sec  42.1 MBytes 3.92 Mbits/sec  3.077 ms 30/30038 (0.1%)

```

Start a UDP Multicast client:

```
> iperf -c 224.1.1.1 -u
-----
Client connecting to 224.1.1.1, UDP port 5001
Sending 1470 byte datagrams
Setting multicast TTL to 1
UDP buffer size: 8.00 KByte (default)
-----
[ ID] Interval          Transfer      Bandwidth
[  0] 0.0-10.1 sec    1002 KBytes    816 Kbits/sec
[  0] Sent 698 datagrams
```

Starting Iperf UDP server and client in separate threads (ThreadX NetX example):

```

> thread_spawn 7 iperf -s -u -i 10 -p 6000
Started thread 0x200130a8 ("iperf")
Spawning a listener.
-----
Server listening on UDP port 6000
Receiving 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
> thread_spawn 7 iperf -c 192.168.1.139 -u -i 10 -t 90
Started thread 0x200149c8 ("iperf")
-----
Client connecting to 192.168.1.139, UDP port 5001
Sending 1470 byte datagrams
UDP buffer size: 8.00 KByte (default)
-----
[ 1] local 0.0.0.0 port 5001 connected with 192.168.1.139 port 5001
> Spawning a server.
[ ID] Interval      Transfer      Bandwidth
[ 1] 0.0-10.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 0] 0.0-10.0 sec  1.25 MBytes  1.05 Mbits/sec    3.894 ms    0/ 891 (0%)
[ 1] 10.0-20.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 0] 10.0-20.0 sec  1.25 MBytes  1.05 Mbits/sec    3.709 ms    0/ 892 (0%)
[ 1] 20.0-30.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 0] 20.0-30.0 sec  1.25 MBytes  1.05 Mbits/sec    4.050 ms    0/ 891 (0%)
[ 1] 30.0-40.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 0] 30.0-40.0 sec  1.25 MBytes  1.05 Mbits/sec    6.100 ms    0/ 891 (0%)
[ 1] 40.0-50.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 0] 40.0-50.0 sec  1.25 MBytes  1.05 Mbits/sec    6.219 ms    0/ 892 (0%)
[ 1] 50.0-60.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 0] 50.0-60.0 sec  1.25 MBytes  1.05 Mbits/sec    9.140 ms    0/ 892 (0%)
[ 0] 0.0-60.0 sec  7.50 MBytes  1.05 Mbits/sec    8.462 ms    0/ 5351 (0%)
[ 1] 60.0-70.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 1] 70.0-80.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 1] 80.0-90.0 sec  1.25 MBytes  1.05 Mbits/sec
[ 1] 0.0-90.0 sec  11.3 MBytes  1.05 Mbits/sec
[ 1] Sent 8026 datagrams
[ 1] Server Report:
[ 1] 0.0-90.0 sec  11.2 MBytes  1.05 Mbits/sec    5.338 ms    3/ 8027 (0.037%)
Thread 0x200149c8 (iperf) exited with return value 0

>

```

Restrictions & Known Issues

- If Iperf is run without first associating and getting an IP address WICED will reset.
- If Iperf is started in client mode and cannot connect with the server then WICED will lock up.
- Joining an open WLAN and using a fixed IP address requires inputting a dummy key because the join command is designed to also cater for security.
- Many Iperf parameters cannot be changed, for example TCP window size and max segment size.
- Unless using the thread_spawn command, after running an Iperf server the WICED module must be reset, i.e. there is no break key to restore the console prompt.
- Iperf was designed to run as a process rather than in a thread, and expects the operating system to clean up after Iperf exits. This cleanup does not happen with an RTOS, even after using the thread_kill command. Therefore after running an Iperf server in a thread, if a new test requires a new setting for an Iperf server then

the WICED module should be rebooted and reconfigured.

- It is not advisable to run an lperf client and lperf server in separate threads concurrently. lperf is designed to run as a separate process and it does not appear to work properly when a client and server are run in separate threads on an RTOS.
- Using the lperf -i command to print statistics at small time intervals, e.g. 1 second intervals, will degrade throughput performance.