
User Manual

for S32K14X BASE Driver

Document Number: UM2BASEASR4.3 Rev0001R1.0.1
Rev. 1.0





Contents

| Section number | Title | Page |
|-------------------------|--|------|
| Chapter 1 | | |
| Revision History | | |
| Chapter 2 | | |
| Introduction | | |
| 2.1 | Supported Derivatives..... | 23 |
| 2.2 | Overview..... | 23 |
| 2.3 | About this Manual..... | 24 |
| 2.4 | Acronyms and Definitions..... | 24 |
| 2.5 | Reference List..... | 25 |
| Chapter 3 | | |
| Driver | | |
| 3.1 | Requirements..... | 27 |
| 3.2 | Driver Design Summary..... | 27 |
| 3.3 | Hardware Resources..... | 29 |
| 3.4 | Deviation from Requirements..... | 29 |
| 3.5 | Driver limitations..... | 29 |
| 3.6 | Driver usage and configuration tips..... | 30 |
| 3.7 | Runtime Errors..... | 30 |
| 3.8 | Software specification..... | 30 |
| 3.8.1 | Define Reference..... | 30 |
| 3.8.1.1 | Define COMPILER_VENDOR_ID..... | 30 |
| 3.8.1.2 | Define COMPILER_AR_RELEASE_MAJOR_VERSION..... | 31 |
| 3.8.1.3 | Define COMPILER_AR_RELEASE_MINOR_VERSION..... | 31 |
| 3.8.1.4 | Define COMPILER_AR_RELEASE_REVISION_VERSION..... | 31 |
| 3.8.1.5 | Define COMPILER_SW_MAJOR_VERSION..... | 32 |
| 3.8.1.6 | Define COMPILER_SW_MINOR_VERSION..... | 32 |
| 3.8.1.7 | Define COMPILER_SW_PATCH_VERSION..... | 32 |
| 3.8.1.8 | Define AUTOMATIC..... | 33 |

| Section number | Title | Page |
|----------------|-----------------------------------|------|
| 3.8.1.9 | Define CONST..... | 33 |
| 3.8.1.10 | Define CONSTP2CONST..... | 33 |
| 3.8.1.11 | Define CONSTP2VAR..... | 34 |
| 3.8.1.12 | Define FUNC..... | 34 |
| 3.8.1.13 | Define NULL_PTR..... | 34 |
| 3.8.1.14 | Define P2CONST..... | 35 |
| 3.8.1.15 | Define P2FUNC..... | 35 |
| 3.8.1.16 | Define P2VAR..... | 35 |
| 3.8.1.17 | Define TYPEDEF..... | 36 |
| 3.8.1.18 | Define VAR..... | 36 |
| 3.8.1.19 | Define ADC_CODE..... | 36 |
| 3.8.1.20 | Define ADC_CONST..... | 37 |
| 3.8.1.21 | Define ADC_APPL_DATA..... | 37 |
| 3.8.1.22 | Define ADC_APPL_CONST..... | 37 |
| 3.8.1.23 | Define ADC_APPL_CODE..... | 38 |
| 3.8.1.24 | Define ADC_CALLOUT_CODE..... | 38 |
| 3.8.1.25 | Define ADC_VAR_NOINIT..... | 38 |
| 3.8.1.26 | Define ADC_VAR_POWER_ON_INIT..... | 39 |
| 3.8.1.27 | Define ADC_VAR_FAST..... | 39 |
| 3.8.1.28 | Define ADC_VAR..... | 39 |
| 3.8.1.29 | Define CAN_CODE..... | 40 |
| 3.8.1.30 | Define CAN_CONST..... | 40 |
| 3.8.1.31 | Define CAN_APPL_DATA..... | 40 |
| 3.8.1.32 | Define CAN_APPL_CONST..... | 40 |
| 3.8.1.33 | Define CAN_APPL_CODE..... | 41 |
| 3.8.1.34 | Define CAN_CALLOUT_CODE..... | 41 |
| 3.8.1.35 | Define CAN_VAR_NOINIT..... | 41 |
| 3.8.1.36 | Define CAN_VAR_POWER_ON_INIT..... | 42 |
| 3.8.1.37 | Define CAN_VAR_FAST..... | 42 |

| Section number | Title | Page |
|----------------|-------------------------------------|------|
| 3.8.1.38 | Define CAN_VAR..... | 42 |
| 3.8.1.39 | Define CRCU_CODE..... | 43 |
| 3.8.1.40 | Define CRCU_CONST..... | 43 |
| 3.8.1.41 | Define CRCU_APPL_DATA..... | 43 |
| 3.8.1.42 | Define CRCU_APPL_CONST..... | 44 |
| 3.8.1.43 | Define CRCU_APPL_CODE..... | 44 |
| 3.8.1.44 | Define CRCU_CALLOUT_CODE..... | 44 |
| 3.8.1.45 | Define CRCU_VAR_NOINIT..... | 44 |
| 3.8.1.46 | Define CRCU_VAR_POWER_ON_INIT..... | 45 |
| 3.8.1.47 | Define CRCU_VAR_FAST..... | 45 |
| 3.8.1.48 | Define CRCU_VAR..... | 45 |
| 3.8.1.49 | Define CANIF_CODE..... | 46 |
| 3.8.1.50 | Define CANIF_CONST..... | 46 |
| 3.8.1.51 | Define CANIF_APPL_DATA..... | 46 |
| 3.8.1.52 | Define CANIF_APPL_CONST..... | 47 |
| 3.8.1.53 | Define CANIF_APPL_CODE..... | 47 |
| 3.8.1.54 | Define CANIF_CALLOUT_CODE..... | 47 |
| 3.8.1.55 | Define CANIF_VAR_NOINIT..... | 48 |
| 3.8.1.56 | Define CANIF_VAR_POWER_ON_INIT..... | 48 |
| 3.8.1.57 | Define CANIF_VAR_FAST..... | 48 |
| 3.8.1.58 | Define CANIF_VAR..... | 48 |
| 3.8.1.59 | Define DEM_CODE..... | 49 |
| 3.8.1.60 | Define DEM_CONST..... | 49 |
| 3.8.1.61 | Define DEM_APPL_DATA..... | 49 |
| 3.8.1.62 | Define DEM_APPL_CONST..... | 50 |
| 3.8.1.63 | Define DEM_APPL_CODE..... | 50 |
| 3.8.1.64 | Define DEM_CALLOUT_CODE..... | 50 |
| 3.8.1.65 | Define DEM_VAR_NOINIT..... | 51 |
| 3.8.1.66 | Define DEM_VAR_POWER_ON_INIT..... | 51 |

| Section number | Title | Page |
|----------------|-----------------------------------|------|
| 3.8.1.67 | Define DEM_VAR_FAST..... | 51 |
| 3.8.1.68 | Define DEM_VAR..... | 52 |
| 3.8.1.69 | Define DET_CODE..... | 52 |
| 3.8.1.70 | Define DET_CONST..... | 52 |
| 3.8.1.71 | Define DET_APPL_DATA..... | 52 |
| 3.8.1.72 | Define DET_APPL_CONST..... | 53 |
| 3.8.1.73 | Define DET_APPL_CODE..... | 53 |
| 3.8.1.74 | Define DET_CALLOUT_CODE..... | 53 |
| 3.8.1.75 | Define DET_VAR_NOINIT..... | 54 |
| 3.8.1.76 | Define DET_VAR_POWER_ON_INIT..... | 54 |
| 3.8.1.77 | Define DET_VAR_FAST..... | 54 |
| 3.8.1.78 | Define DET_VAR..... | 55 |
| 3.8.1.79 | Define DIO_CODE..... | 55 |
| 3.8.1.80 | Define DIO_CONST..... | 55 |
| 3.8.1.81 | Define DIO_APPL_DATA..... | 56 |
| 3.8.1.82 | Define DIO_APPL_CONST..... | 56 |
| 3.8.1.83 | Define DIO_APPL_CODE..... | 56 |
| 3.8.1.84 | Define DIO_CALLOUT_CODE..... | 56 |
| 3.8.1.85 | Define DIO_VAR_NOINIT..... | 57 |
| 3.8.1.86 | Define DIO_VAR_POWER_ON_INIT..... | 57 |
| 3.8.1.87 | Define DIO_VAR_FAST..... | 57 |
| 3.8.1.88 | Define DIO_VAR..... | 58 |
| 3.8.1.89 | Define ETH_CODE..... | 58 |
| 3.8.1.90 | Define ETH_CONST..... | 58 |
| 3.8.1.91 | Define ETH_APPL_DATA..... | 59 |
| 3.8.1.92 | Define ETH_APPL_CONST..... | 59 |
| 3.8.1.93 | Define ETH_APPL_CODE..... | 59 |
| 3.8.1.94 | Define ETH_CALLOUT_CODE..... | 60 |
| 3.8.1.95 | Define ETH_VAR_NOINIT..... | 60 |

| Section number | Title | Page |
|----------------|---|------|
| 3.8.1.96 | Define ETH_VAR_POWER_ON_INIT..... | 60 |
| 3.8.1.97 | Define ETH_VAR_FAST..... | 60 |
| 3.8.1.98 | Define ETH_VAR..... | 61 |
| 3.8.1.99 | Define ETH_AR_RELEASE_MAJOR_VERSION_ETHGENERALTYPES..... | 61 |
| 3.8.1.100 | Define ETH_AR_RELEASE_MINOR_VERSION_ETHGENERALTYPES..... | 61 |
| 3.8.1.101 | Define ETH_AR_RELEASE_REVISION_VERSION_ETHGENERALTYPES..... | 62 |
| 3.8.1.102 | Define ETH_MODULE_ID_ETHGENERALTYPES..... | 62 |
| 3.8.1.103 | Define ETH_SW_MAJOR_VERSION_ETHGENERALTYPES..... | 62 |
| 3.8.1.104 | Define ETH_SW_MINOR_VERSION_ETHGENERALTYPES..... | 63 |
| 3.8.1.105 | Define ETH_SW_PATCH_VERSION_ETHGENERALTYPES..... | 63 |
| 3.8.1.106 | Define ETH_VENDOR_ID_ETHGENERALTYPES..... | 63 |
| 3.8.1.107 | Define FEE_CODE..... | 63 |
| 3.8.1.108 | Define FEE_CONST..... | 64 |
| 3.8.1.109 | Define FEE_APPL_DATA..... | 64 |
| 3.8.1.110 | Define FEE_APPL_CONST..... | 64 |
| 3.8.1.111 | Define FEE_APPL_CODE..... | 65 |
| 3.8.1.112 | Define FEE_CALLOUT_CODE..... | 65 |
| 3.8.1.113 | Define FEE_VAR_NOINIT..... | 65 |
| 3.8.1.114 | Define FEE_VAR_POWER_ON_INIT..... | 66 |
| 3.8.1.115 | Define FEE_VAR_FAST..... | 66 |
| 3.8.1.116 | Define FEE_VAR..... | 66 |
| 3.8.1.117 | Define FLS_CODE..... | 67 |
| 3.8.1.118 | Define FLS_CONST..... | 67 |
| 3.8.1.119 | Define FLS_APPL_DATA..... | 67 |
| 3.8.1.120 | Define FLS_APPL_CONST..... | 67 |
| 3.8.1.121 | Define FLS_APPL_CODE..... | 68 |
| 3.8.1.122 | Define FLS_CALLOUT_CODE..... | 68 |
| 3.8.1.123 | Define FLS_VAR_NOINIT..... | 68 |
| 3.8.1.124 | Define FLS_VAR_POWER_ON_INIT..... | 69 |

| Section number | Title | Page |
|----------------|---|------|
| 3.8.1.125 | Define FLS_VAR_FAST..... | 69 |
| 3.8.1.126 | Define FLS_VAR..... | 69 |
| 3.8.1.127 | Define FR_APPL_CODE..... | 70 |
| 3.8.1.128 | Define FR_APPL_CONST..... | 70 |
| 3.8.1.129 | Define FR_APPL_DATA..... | 70 |
| 3.8.1.130 | Define FR_CALLOUT_CODE..... | 71 |
| 3.8.1.131 | Define FR_CIDX_GCOLDSTARTATTEMPTS..... | 71 |
| 3.8.1.132 | Define FR_CIDX_GCYCLECOUNTMAX..... | 71 |
| 3.8.1.133 | Define FR_CIDX_GDACTIONPOINTOFFSET..... | 71 |
| 3.8.1.134 | Define FR_CIDX_GDBIT..... | 72 |
| 3.8.1.135 | Define FR_CIDX_GDCASRXLOWMAX..... | 72 |
| 3.8.1.136 | Define FR_CIDX_GDCYCLE..... | 72 |
| 3.8.1.137 | Define FR_CIDX_GDDYNAMICSLOTIDLEPHASE..... | 72 |
| 3.8.1.138 | Define FR_CIDX_GDIGNOREAFTERTX..... | 73 |
| 3.8.1.139 | Define FR_CIDX_GDMACROTICK..... | 73 |
| 3.8.1.140 | Define FR_CIDX_GDMINISLOT..... | 73 |
| 3.8.1.141 | Define FR_CIDX_GDMINISLOTACTIONPOINTOFFSET..... | 73 |
| 3.8.1.142 | Define FR_CIDX_GDNIT..... | 73 |
| 3.8.1.143 | Define FR_CIDX_GDSAMPLECLOCKPERIOD..... | 74 |
| 3.8.1.144 | Define FR_CIDX_GDSTATICSLOT..... | 74 |
| 3.8.1.145 | Define FR_CIDX_GDSYMBOLWINDOW..... | 74 |
| 3.8.1.146 | Define FR_CIDX_GDSYMBOLWINDOWACTIONPOINTOFFSET..... | 74 |
| 3.8.1.147 | Define FR_CIDX_GDTSSTRANSMITTER..... | 74 |
| 3.8.1.148 | Define FR_CIDX_GDWAKEUPRXIDLE..... | 75 |
| 3.8.1.149 | Define FR_CIDX_GDWAKEUPRXLOW..... | 75 |
| 3.8.1.150 | Define FR_CIDX_GDWAKEUPRXWINDOW..... | 75 |
| 3.8.1.151 | Define FR_CIDX_GDWAKEUPTXACTIVE..... | 75 |
| 3.8.1.152 | Define FR_CIDX_GDWAKEUPTXIDLE..... | 75 |
| 3.8.1.153 | Define FR_CIDX_GLISTENNOISE..... | 76 |

| Section number | Title | Page |
|----------------|--|------|
| 3.8.1.154 | Define FR_CIDX_GMACROPERCYCLE..... | 76 |
| 3.8.1.155 | Define FR_CIDX_GMAXWITHOUTCLOCKCORRECTFATAL..... | 76 |
| 3.8.1.156 | Define FR_CIDX_GMAXWITHOUTCLOCKCORRECTPASSIVE..... | 76 |
| 3.8.1.157 | Define FR_CIDX_GNETWORKMANAGEMENTVECTORLENGTH..... | 76 |
| 3.8.1.158 | Define FR_CIDX_GNUMBEROFMINISLOTS..... | 77 |
| 3.8.1.159 | Define FR_CIDX_GNUMBEROFSTATICSLOTS..... | 77 |
| 3.8.1.160 | Define FR_CIDX_GPAYLOADLENGTHSTATIC..... | 77 |
| 3.8.1.161 | Define FR_CIDX_GSYNCFRAMEIDCOUNTMAX..... | 77 |
| 3.8.1.162 | Define FR_CIDX_PALLOWHALTDUETOCLOCK..... | 78 |
| 3.8.1.163 | Define FR_CIDX_PALLOWPASSIVETOACTIVE..... | 78 |
| 3.8.1.164 | Define FR_CIDX_PCHANNELS..... | 78 |
| 3.8.1.165 | Define FR_CIDX_PCLUSTERDRIFTDAMPING..... | 78 |
| 3.8.1.166 | Define FR_CIDX_PDACCEPTEDSTARTUPRANGE..... | 78 |
| 3.8.1.167 | Define FR_CIDX_PDECODINGCORRECTION..... | 79 |
| 3.8.1.168 | Define FR_CIDX_PDELAYCOMPENSATIONA..... | 79 |
| 3.8.1.169 | Define FR_CIDX_PDELAYCOMPENSATIONB..... | 79 |
| 3.8.1.170 | Define FR_CIDX_PDLISTENTIMEOUT..... | 79 |
| 3.8.1.171 | Define FR_CIDX_PDMICROTICK..... | 79 |
| 3.8.1.172 | Define FR_CIDX_PEXTERNALSYNC..... | 80 |
| 3.8.1.173 | Define FR_CIDX_PFALLBACKINTERNAL..... | 80 |
| 3.8.1.174 | Define FR_CIDX_PKEYSLOTID..... | 80 |
| 3.8.1.175 | Define FR_CIDX_PKEYSLOTONLYENABLED..... | 80 |
| 3.8.1.176 | Define FR_CIDX_PKEYSLOTUSEDFORSTARTUP..... | 80 |
| 3.8.1.177 | Define FR_CIDX_PKEYSLOTUSEDFORSYNC..... | 81 |
| 3.8.1.178 | Define FR_CIDX_PLATESTTX..... | 81 |
| 3.8.1.179 | Define FR_CIDX_PMACROINITIALOFFSETA..... | 81 |
| 3.8.1.180 | Define FR_CIDX_PMACROINITIALOFFSETB..... | 81 |
| 3.8.1.181 | Define FR_CIDX_PMICROINITIALOFFSETA..... | 81 |
| 3.8.1.182 | Define FR_CIDX_PMICROINITIALOFFSETB..... | 82 |

| Section number | Title | Page |
|----------------|--|------|
| 3.8.1.183 | Define FR_CIDX_PMICROPERCYCLE..... | 82 |
| 3.8.1.184 | Define FR_CIDX_PNMVECTOREARLYUPDATE..... | 82 |
| 3.8.1.185 | Define FR_CIDX_POFFSETCORRECTIONOUT..... | 82 |
| 3.8.1.186 | Define FR_CIDX_POFFSETCORRECTIONSTART..... | 82 |
| 3.8.1.187 | Define FR_CIDX_PPAYLOADLENGTHDYNMAX..... | 83 |
| 3.8.1.188 | Define FR_CIDX_PRATECORRECTIONOUT..... | 83 |
| 3.8.1.189 | Define FR_CIDX_PSAMPLESPERMICROTICK..... | 83 |
| 3.8.1.190 | Define FR_CIDX_PSECONDKEYSLOTID..... | 83 |
| 3.8.1.191 | Define FR_CIDX_PTWOKEYSLOTMODE..... | 83 |
| 3.8.1.192 | Define FR_CIDX_PWAKEUPCHANNEL..... | 84 |
| 3.8.1.193 | Define FR_CIDX_PWAKEUPPATTERN..... | 84 |
| 3.8.1.194 | Define FR_CODE..... | 84 |
| 3.8.1.195 | Define FR_CONST..... | 84 |
| 3.8.1.196 | Define FR_SLOTMODE_SINGLE..... | 85 |
| 3.8.1.197 | Define FR_VAR..... | 85 |
| 3.8.1.198 | Define FR_VAR_FAST..... | 85 |
| 3.8.1.199 | Define FR_VAR_NOINIT..... | 86 |
| 3.8.1.200 | Define FR_VAR_POWER_ON_INIT..... | 86 |
| 3.8.1.201 | Define GPT_CODE..... | 86 |
| 3.8.1.202 | Define GPT_CONST..... | 87 |
| 3.8.1.203 | Define GPT_APPL_DATA..... | 87 |
| 3.8.1.204 | Define GPT_APPL_CONST..... | 87 |
| 3.8.1.205 | Define GPT_APPL_CODE..... | 87 |
| 3.8.1.206 | Define GPT_CALLOUT_CODE..... | 88 |
| 3.8.1.207 | Define GPT_VAR_NOINIT..... | 88 |
| 3.8.1.208 | Define GPT_VAR_POWER_ON_INIT..... | 88 |
| 3.8.1.209 | Define GPT_VAR_FAST..... | 89 |
| 3.8.1.210 | Define GPT_VAR..... | 89 |
| 3.8.1.211 | Define ICU_CODE..... | 89 |

| Section number | Title | Page |
|----------------|------------------------------------|------|
| 3.8.1.212 | Define ICU_CONST..... | 90 |
| 3.8.1.213 | Define ICU_APPL_DATA..... | 90 |
| 3.8.1.214 | Define ICU_APPL_CONST..... | 90 |
| 3.8.1.215 | Define ICU_APPL_CODE..... | 91 |
| 3.8.1.216 | Define ICU_CALLOUT_CODE..... | 91 |
| 3.8.1.217 | Define ICU_VAR_NOINIT..... | 91 |
| 3.8.1.218 | Define ICU_VAR_POWER_ON_INIT..... | 91 |
| 3.8.1.219 | Define ICU_VAR_FAST..... | 92 |
| 3.8.1.220 | Define ICU_VAR..... | 92 |
| 3.8.1.221 | Define LIN_CODE..... | 92 |
| 3.8.1.222 | Define LIN_CONST..... | 93 |
| 3.8.1.223 | Define LIN_APPL_DATA..... | 93 |
| 3.8.1.224 | Define LIN_APPL_CONST..... | 93 |
| 3.8.1.225 | Define LIN_APPL_CODE..... | 94 |
| 3.8.1.226 | Define LIN_CALLOUT_CODE..... | 94 |
| 3.8.1.227 | Define LIN_VAR_NOINIT..... | 94 |
| 3.8.1.228 | Define LIN_VAR_POWER_ON_INIT..... | 95 |
| 3.8.1.229 | Define LIN_VAR_FAST..... | 95 |
| 3.8.1.230 | Define LIN_VAR..... | 95 |
| 3.8.1.231 | Define MCEM_CODE..... | 95 |
| 3.8.1.232 | Define MCEM_CONST..... | 96 |
| 3.8.1.233 | Define MCEM_APPL_DATA..... | 96 |
| 3.8.1.234 | Define MCEM_APPL_CONST..... | 96 |
| 3.8.1.235 | Define MCEM_APPL_CODE..... | 97 |
| 3.8.1.236 | Define MCEM_CALLOUT_CODE..... | 97 |
| 3.8.1.237 | Define MCEM_VAR_NOINIT..... | 97 |
| 3.8.1.238 | Define MCEM_VAR_POWER_ON_INIT..... | 98 |
| 3.8.1.239 | Define MCEM_VAR_FAST..... | 98 |
| 3.8.1.240 | Define MCEM_VAR..... | 98 |

| Section number | Title | Page |
|----------------|------------------------------------|------|
| 3.8.1.241 | Define MCL_CODE..... | 99 |
| 3.8.1.242 | Define MCL_CONST..... | 99 |
| 3.8.1.243 | Define MCL_APPL_DATA..... | 99 |
| 3.8.1.244 | Define MCL_APPL_CONST..... | 99 |
| 3.8.1.245 | Define MCL_APPL_CODE..... | 100 |
| 3.8.1.246 | Define MCL_CALLOUT_CODE..... | 100 |
| 3.8.1.247 | Define MCL_VAR_NOINIT..... | 100 |
| 3.8.1.248 | Define MCL_VAR_POWER_ON_INIT..... | 101 |
| 3.8.1.249 | Define MCL_VAR_FAST..... | 101 |
| 3.8.1.250 | Define MCL_VAR..... | 101 |
| 3.8.1.251 | Define MCU_CODE..... | 102 |
| 3.8.1.252 | Define MCU_CONST..... | 102 |
| 3.8.1.253 | Define MCU_APPL_DATA..... | 102 |
| 3.8.1.254 | Define MCU_APPL_CONST..... | 103 |
| 3.8.1.255 | Define MCU_APPL_CODE..... | 103 |
| 3.8.1.256 | Define MCU_CALLOUT_CODE..... | 103 |
| 3.8.1.257 | Define MCU_VAR_NOINIT..... | 103 |
| 3.8.1.258 | Define MCU_VAR_POWER_ON_INIT..... | 104 |
| 3.8.1.259 | Define MCU_VAR_FAST..... | 104 |
| 3.8.1.260 | Define MCU_VAR..... | 104 |
| 3.8.1.261 | Define PORT_CODE..... | 105 |
| 3.8.1.262 | Define PORT_CONST..... | 105 |
| 3.8.1.263 | Define PORT_APPL_DATA..... | 105 |
| 3.8.1.264 | Define PORT_APPL_CONST..... | 106 |
| 3.8.1.265 | Define PORT_APPL_CODE..... | 106 |
| 3.8.1.266 | Define PORT_CALLOUT_CODE..... | 106 |
| 3.8.1.267 | Define PORT_VAR_NOINIT..... | 107 |
| 3.8.1.268 | Define PORT_VAR_POWER_ON_INIT..... | 107 |
| 3.8.1.269 | Define PORT_VAR_FAST..... | 107 |

| Section number | Title | Page |
|----------------|--------------------------------------|------|
| 3.8.1.270 | Define PORT_VAR..... | 107 |
| 3.8.1.271 | Define PWM_CODE..... | 108 |
| 3.8.1.272 | Define PWM_CONST..... | 108 |
| 3.8.1.273 | Define PWM_APPL_DATA..... | 108 |
| 3.8.1.274 | Define PWM_APPL_CONST..... | 109 |
| 3.8.1.275 | Define PWM_APPL_CODE..... | 109 |
| 3.8.1.276 | Define PWM_CALLOUT_CODE..... | 109 |
| 3.8.1.277 | Define PWM_VAR_NOINIT..... | 110 |
| 3.8.1.278 | Define PWM_VAR_POWER_ON_INIT..... | 110 |
| 3.8.1.279 | Define PWM_VAR_FAST..... | 110 |
| 3.8.1.280 | Define PWM_VAR..... | 111 |
| 3.8.1.281 | Define RAMTST_CODE..... | 111 |
| 3.8.1.282 | Define RAMTST_CONST..... | 111 |
| 3.8.1.283 | Define RAMTST_APPL_DATA..... | 111 |
| 3.8.1.284 | Define RAMTST_APPL_CONST..... | 112 |
| 3.8.1.285 | Define RAMTST_APPL_CODE..... | 112 |
| 3.8.1.286 | Define RAMTST_CALLOUT_CODE..... | 112 |
| 3.8.1.287 | Define RAMTST_VAR_NOINIT..... | 113 |
| 3.8.1.288 | Define RAMTST_VAR_POWER_ON_INIT..... | 113 |
| 3.8.1.289 | Define RAMTST_VAR_FAST..... | 113 |
| 3.8.1.290 | Define RAMTST_VAR..... | 114 |
| 3.8.1.291 | Define SCHM_CODE..... | 114 |
| 3.8.1.292 | Define SCHM_CONST..... | 114 |
| 3.8.1.293 | Define SCHM_APPL_DATA..... | 115 |
| 3.8.1.294 | Define SCHM_APPL_CONST..... | 115 |
| 3.8.1.295 | Define SCHM_APPL_CODE..... | 115 |
| 3.8.1.296 | Define SCHM_CALLOUT_CODE..... | 115 |
| 3.8.1.297 | Define SCHM_VAR_NOINIT..... | 116 |
| 3.8.1.298 | Define SCHM_VAR_POWER_ON_INIT..... | 116 |

| Section number | Title | Page |
|----------------|-----------------------------------|------|
| 3.8.1.299 | Define SCHM_VAR_FAST..... | 116 |
| 3.8.1.300 | Define SCHM_VAR..... | 117 |
| 3.8.1.301 | Define SPI_CODE..... | 117 |
| 3.8.1.302 | Define SPI_CONST..... | 117 |
| 3.8.1.303 | Define SPI_APPL_DATA..... | 118 |
| 3.8.1.304 | Define SPI_APPL_CONST..... | 118 |
| 3.8.1.305 | Define SPI_APPL_CODE..... | 118 |
| 3.8.1.306 | Define SPI_CALLOUT_CODE..... | 119 |
| 3.8.1.307 | Define SPI_VAR_NOINIT..... | 119 |
| 3.8.1.308 | Define SPI_VAR_POWER_ON_INIT..... | 119 |
| 3.8.1.309 | Define SPI_VAR_FAST..... | 119 |
| 3.8.1.310 | Define SPI_VAR..... | 120 |
| 3.8.1.311 | Define WDG_CODE..... | 120 |
| 3.8.1.312 | Define WDG_CONST..... | 120 |
| 3.8.1.313 | Define WDG_APPL_DATA..... | 121 |
| 3.8.1.314 | Define WDG_APPL_CONST..... | 121 |
| 3.8.1.315 | Define WDG_APPL_CODE..... | 121 |
| 3.8.1.316 | Define WDG_CALLOUT_CODE..... | 122 |
| 3.8.1.317 | Define WDG_VAR_NOINIT..... | 122 |
| 3.8.1.318 | Define WDG_VAR_POWER_ON_INIT..... | 122 |
| 3.8.1.319 | Define WDG_VAR_FAST..... | 123 |
| 3.8.1.320 | Define WDG_VAR..... | 123 |
| 3.8.1.321 | Define WDGIF_CODE..... | 123 |
| 3.8.1.322 | Define WDGIF_CONST..... | 123 |
| 3.8.1.323 | Define WDGIF_APPL_DATA..... | 124 |
| 3.8.1.324 | Define WDGIF_APPL_CONST..... | 124 |
| 3.8.1.325 | Define WDGIF_APPL_CODE..... | 124 |
| 3.8.1.326 | Define WDGIF_CALLOUT_CODE..... | 125 |
| 3.8.1.327 | Define WDGIF_VAR_NOINIT..... | 125 |

| Section number | Title | Page |
|----------------|--|------|
| 3.8.1.328 | Define WDGIF_VAR_POWER_ON_INIT..... | 125 |
| 3.8.1.329 | Define WDGIF_VAR_FAST..... | 126 |
| 3.8.1.330 | Define WDGIF_VAR..... | 126 |
| 3.8.1.331 | Define AUTOSAR_COMSTACKDATA..... | 126 |
| 3.8.1.332 | Define BUSTRCV_E_ERROR..... | 127 |
| 3.8.1.333 | Define BUSTRCV_OK..... | 127 |
| 3.8.1.334 | Define COMSTACKTYPE_AR_RELEASE_MAJOR_VERSION..... | 127 |
| 3.8.1.335 | Define COMSTACKTYPE_AR_RELEASE_MINOR_VERSION..... | 128 |
| 3.8.1.336 | Define COMSTACKTYPE_AR_RELEASE_REVISION_VERSION..... | 128 |
| 3.8.1.337 | Define COMSTACKTYPE_SW_MAJOR_VERSION..... | 128 |
| 3.8.1.338 | Define COMSTACKTYPE_SW_MINOR_VERSION..... | 128 |
| 3.8.1.339 | Define COMSTACKTYPE_SW_PATCH_VERSION..... | 128 |
| 3.8.1.340 | Define COMSTACKTYPE_VENDOR_ID..... | 129 |
| 3.8.1.341 | Define NTFRSLT_E_ABORT..... | 129 |
| 3.8.1.342 | Define NTFRSLT_E_CANCELTION_NOT_OK..... | 129 |
| 3.8.1.343 | Define NTFRSLT_E_CANCELTION_OK..... | 130 |
| 3.8.1.344 | Define NTFRSLT_E_INVALID_FS..... | 130 |
| 3.8.1.345 | Define NTFRSLT_E_NO_BUFFER..... | 131 |
| 3.8.1.346 | Define NTFRSLT_E_NOT_OK..... | 131 |
| 3.8.1.347 | Define NTFRSLT_E_PARAMETER_NOT_OK..... | 132 |
| 3.8.1.348 | Define NTFRSLT_E_RX_ON..... | 132 |
| 3.8.1.349 | Define NTFRSLT_E_TIMEOUT_A..... | 132 |
| 3.8.1.350 | Define NTFRSLT_E_TIMEOUT_BS..... | 133 |
| 3.8.1.351 | Define NTFRSLT_E_TIMEOUT_CR..... | 133 |
| 3.8.1.352 | Define NTFRSLT_E_UNEXP_PDU..... | 133 |
| 3.8.1.353 | Define NTFRSLT_E_VALUE_NOT_OK..... | 134 |
| 3.8.1.354 | Define NTFRSLT_E_WFT_OVRN..... | 134 |
| 3.8.1.355 | Define NTFRSLT_E_WRONG_SN..... | 135 |
| 3.8.1.356 | Define NTFRSLT_OK..... | 135 |

| Section number | Title | Page |
|----------------|--|------|
| 3.8.1.357 | Define NTFRSLT_PARAMETER_OK..... | 135 |
| 3.8.1.358 | Define CONSTP2FUNC..... | 136 |
| 3.8.1.359 | Define EXIT_INTERRUPT..... | 136 |
| 3.8.1.360 | Define ISR..... | 136 |
| 3.8.1.361 | Define MCAL_AR_RELEASE_MAJOR_VERSION..... | 137 |
| 3.8.1.362 | Define MCAL_AR_RELEASE_MINOR_VERSION..... | 137 |
| 3.8.1.363 | Define MCAL_AR_RELEASE_REVISION_VERSION..... | 137 |
| 3.8.1.364 | Define MCAL_MODULE_ID..... | 137 |
| 3.8.1.365 | Define MCAL_SW_MAJOR_VERSION..... | 138 |
| 3.8.1.366 | Define MCAL_SW_MINOR_VERSION..... | 138 |
| 3.8.1.367 | Define MCAL_SW_PATCH_VERSION..... | 138 |
| 3.8.1.368 | Define MCAL_VENDOR_ID..... | 138 |
| 3.8.1.369 | Define P2P2CONST..... | 138 |
| 3.8.1.370 | Define P2P2VAR..... | 139 |
| 3.8.1.371 | Define ResumeAllInterrupts..... | 139 |
| 3.8.1.372 | Define STATIC..... | 139 |
| 3.8.1.373 | Define SuspendAllInterrupts..... | 140 |
| 3.8.1.374 | Define MEMMAP_VENDOR_ID..... | 140 |
| 3.8.1.375 | Define MEMMAP_AR_RELEASE_MAJOR_VERSION..... | 140 |
| 3.8.1.376 | Define MEMMAP_AR_RELEASE_MINOR_VERSION..... | 141 |
| 3.8.1.377 | Define MEMMAP_AR_RELEASE_REVISION_VERSION..... | 141 |
| 3.8.1.378 | Define MEMMAP_SW_MAJOR_VERSION..... | 141 |
| 3.8.1.379 | Define MEMMAP_SW_MINOR_VERSION..... | 142 |
| 3.8.1.380 | Define MEMMAP_SW_PATCH_VERSION..... | 142 |
| 3.8.1.381 | Define MEMMAP_ERROR..... | 142 |
| 3.8.1.382 | Define CPU_BIT_ORDER..... | 143 |
| 3.8.1.383 | Define CPU_BYTE_ORDER..... | 143 |
| 3.8.1.384 | Define CPU_TYPE..... | 143 |
| 3.8.1.385 | Define CPU_TYPE_16..... | 144 |

| Section number | Title | Page |
|----------------|---|------|
| 3.8.1.386 | Define CPU_TYPE_32..... | 144 |
| 3.8.1.387 | Define CPU_TYPE_8..... | 144 |
| 3.8.1.388 | Define FALSE..... | 145 |
| 3.8.1.389 | Define HIGH_BYTE_FIRST..... | 145 |
| 3.8.1.390 | Define LOW_BYTE_FIRST..... | 145 |
| 3.8.1.391 | Define LSB_FIRST..... | 145 |
| 3.8.1.392 | Define MSB_FIRST..... | 146 |
| 3.8.1.393 | Define PLATFORM_AR_RELEASE_MAJOR_VERSION..... | 146 |
| 3.8.1.394 | Define PLATFORM_AR_RELEASE_MINOR_VERSION..... | 146 |
| 3.8.1.395 | Define PLATFORM_AR_RELEASE_REVISION_VERSION..... | 147 |
| 3.8.1.396 | Define PLATFORM_SW_MAJOR_VERSION..... | 147 |
| 3.8.1.397 | Define PLATFORM_SW_MINOR_VERSION..... | 147 |
| 3.8.1.398 | Define PLATFORM_SW_PATCH_VERSION..... | 147 |
| 3.8.1.399 | Define PLATFORM_VENDOR_ID..... | 147 |
| 3.8.1.400 | Define TRUE..... | 148 |
| 3.8.1.401 | Define E_NOT_OK..... | 148 |
| 3.8.1.402 | Define E_OK..... | 148 |
| 3.8.1.403 | Define STATUSTYPEDEFINED..... | 148 |
| 3.8.1.404 | Define STD_ACTIVE..... | 149 |
| 3.8.1.405 | Define STD_HIGH..... | 149 |
| 3.8.1.406 | Define STD_IDLE..... | 149 |
| 3.8.1.407 | Define STD_LOW..... | 150 |
| 3.8.1.408 | Define STD_OFF..... | 150 |
| 3.8.1.409 | Define STD_ON..... | 150 |
| 3.8.1.410 | Define STD_TYPES_AR_RELEASE_MAJOR_VERSION..... | 151 |
| 3.8.1.411 | Define STD_TYPES_AR_RELEASE_MINOR_VERSION..... | 151 |
| 3.8.1.412 | Define STD_TYPES_AR_RELEASE_REVISION_VERSION..... | 151 |
| 3.8.1.413 | Define STD_TYPES_SW_MAJOR_VERSION..... | 151 |
| 3.8.1.414 | Define STD_TYPES_SW_MINOR_VERSION..... | 151 |

| Section number | Title | Page |
|----------------|---|------|
| 3.8.1.415 | Define STD_TYPES_SW_PATCH_VERSION..... | 152 |
| 3.8.1.416 | Define STD_TYPES_VENDOR_ID..... | 152 |
| 3.8.2 | Enum Reference..... | 152 |
| 3.8.2.1 | Enumeration Can_ReturnType..... | 152 |
| 3.8.2.2 | Enumeration Can_StateTransitionType..... | 153 |
| 3.8.2.3 | Enumeration CanIf_ControllerModeType..... | 153 |
| 3.8.2.4 | Enumeration Eth_FilterActionType..... | 154 |
| 3.8.2.5 | Enumeration Eth_ModeType..... | 154 |
| 3.8.2.6 | Enumeration Eth_ReturnType..... | 155 |
| 3.8.2.7 | Enumeration Eth_RxStatusType..... | 155 |
| 3.8.2.8 | Enumeration Eth_StateType..... | 156 |
| 3.8.2.9 | Enumeration Fr_ChannelType..... | 156 |
| 3.8.2.10 | Enumeration Fr_ErrorModeType..... | 157 |
| 3.8.2.11 | Enumeration Fr_POCTestType..... | 157 |
| 3.8.2.12 | Enumeration Fr_RxLPduStatusType..... | 158 |
| 3.8.2.13 | Enumeration Fr_SlotModeType..... | 158 |
| 3.8.2.14 | Enumeration Fr_StartupStateType..... | 158 |
| 3.8.2.15 | Enumeration Fr_TxLPduStatusType..... | 159 |
| 3.8.2.16 | Enumeration Fr_WakeupStatusType..... | 159 |
| 3.8.2.17 | Enumeration BufReq_ReturnType..... | 160 |
| 3.8.2.18 | Enumeration TpDataStateType..... | 160 |
| 3.8.2.19 | Enumeration TPPParameterType..... | 161 |
| 3.8.2.20 | Enumeration Lin_FrameCsModelType..... | 161 |
| 3.8.2.21 | Enumeration Lin_FrameResponseType..... | 162 |
| 3.8.2.22 | Enumeration Lin_StatusType..... | 162 |
| 3.8.3 | Function Reference..... | 163 |
| 3.8.4 | Structs Reference..... | 163 |
| 3.8.4.1 | Structure Can_PduType..... | 163 |
| 3.8.4.2 | Structure Fr_POCTestType..... | 164 |

| Section number | Title | Page |
|----------------|------------------------------------|------|
| 3.8.4.3 | Structure Lin_PduType..... | 165 |
| 3.8.4.4 | Structure Mcal_DemErrorType..... | 166 |
| 3.8.4.5 | Structure PduInfoType..... | 167 |
| 3.8.4.6 | Structure RetryInfoType..... | 168 |
| 3.8.4.7 | Structure Std_VersionInfoType..... | 169 |
| 3.8.5 | Types Reference..... | 170 |
| 3.8.5.1 | Typedef Can_IdType..... | 170 |
| 3.8.5.2 | Typedef Can_HwHandleType..... | 170 |
| 3.8.5.3 | Typedef Eth_DataType..... | 171 |
| 3.8.5.4 | Typedef Eth_FrameType..... | 171 |
| 3.8.5.5 | Typedef PduIdType..... | 171 |
| 3.8.5.6 | Typedef PduLengthType..... | 172 |
| 3.8.5.7 | Typedef BusTrcvErrorType..... | 172 |
| 3.8.5.8 | Typedef NetworkHandleType..... | 172 |
| 3.8.5.9 | Typedef NotifResultType..... | 172 |
| 3.8.5.10 | Typedef Lin_FrameDIType..... | 173 |
| 3.8.5.11 | Typedef Lin_FramePidType..... | 173 |
| 3.8.5.12 | Typedef boolean..... | 173 |
| 3.8.5.13 | Typedef float32..... | 173 |
| 3.8.5.14 | Typedef float64..... | 174 |
| 3.8.5.15 | Typedef sint16..... | 174 |
| 3.8.5.16 | Typedef sint16_least..... | 174 |
| 3.8.5.17 | Typedef sint32..... | 174 |
| 3.8.5.18 | Typedef sint32_least..... | 175 |
| 3.8.5.19 | Typedef sint8..... | 175 |
| 3.8.5.20 | Typedef sint8_least..... | 175 |
| 3.8.5.21 | Typedef uint16..... | 175 |
| 3.8.5.22 | Typedef uint16_least..... | 176 |
| 3.8.5.23 | Typedef uint32..... | 176 |

| Section number | Title | Page |
|----------------|--------------------------------|------|
| 3.8.5.24 | Typedef uint32_least..... | 176 |
| 3.8.5.25 | Typedef uint8..... | 176 |
| 3.8.5.26 | Typedef uint8_least..... | 177 |
| 3.8.5.27 | Typedef StatusType..... | 177 |
| 3.8.5.28 | Typedef Std_ReturnType..... | 177 |
| 3.9 | Symbolic Names Disclaimer..... | 177 |

Chapter 4 Tresos Configuration Plug-in

| | | |
|-------|--|-----|
| 4.1 | Configuration elements of Base..... | 179 |
| 4.2 | Form CommonPublishedInformation..... | 179 |
| 4.2.1 | ArReleaseMajorVersion (CommonPublishedInformation)..... | 179 |
| 4.2.2 | ArReleaseMinorVersion (CommonPublishedInformation)..... | 180 |
| 4.2.3 | ArReleaseRevisionVersion (CommonPublishedInformation)..... | 180 |
| 4.2.4 | ModuleId (CommonPublishedInformation)..... | 181 |
| 4.2.5 | SwMajorVersion (CommonPublishedInformation)..... | 181 |
| 4.2.6 | SwMinorVersion (CommonPublishedInformation)..... | 182 |
| 4.2.7 | SwPatchVersion (CommonPublishedInformation)..... | 182 |
| 4.2.8 | VendorApiInfix (CommonPublishedInformation)..... | 183 |
| 4.2.9 | VendorId (CommonPublishedInformation)..... | 183 |

Chapter 1

Revision History

Table 1-1. Revision History

| Revision | Date | Author | Description |
|----------|------------|---------------|--|
| 1.0 | 21/06/2019 | NXP MCAL Team | Updated version for ASR 4.3.1S32K14XR1.0.1 |



Chapter 2

Introduction

This User Manual describes NXP Semiconductors AUTOSAR Base (BASE) for S32K14X .

AUTOSAR BASE driver configuration parameters and deviations from the specification are described in BASE Driver chapter of this document. AUTOSAR BASE driver requirements and APIs are described in the AUTOSAR BASE driver software specification document.

2.1 Supported Derivatives

The software described in this document is intended to be used with the following microcontroller devices of NXP Semiconductors .

Table 2-1. S32K14X Derivatives

| | |
|--------------------|--|
| NXP Semiconductors | s32k148_lqfp144, s32k148_lqfp176, s32k148_mapbga100, s32k146_lqfp144, s32k146_lqfp100, s32k146_lqfp64, s32k146_mapbga100, s32k144_lqfp100, s32k144_lqfp64, s32k144_mapbga100, s32k142_lqfp100, s32k142_lqfp64, s32k118_lqfp48, s32k118_lqfp64, s32k142_lqfp48, s32k144_lqfp48, s32k148_lqfp100 |
|--------------------|--|

All of the above microcontroller devices are collectively named as S32K14X .

2.2 Overview

AUTOSAR (AUTomotive Open System ARchitecture) is an industry partnership working to establish standards for software interfaces and software modules for automobile electronic control systems.

AUTOSAR

- paves the way for innovative electronic systems that further improve performance, safety and environmental friendliness.
- is a strong global partnership that creates one common standard: "Cooperate on standards, compete on implementation".
- is a key enabling technology to manage the growing electrics/electronics complexity. It aims to be prepared for the upcoming technologies and to improve cost-efficiency without making any compromise with respect to quality.
- facilitates the exchange and update of software and hardware over the service life of the vehicle.

2.3 About this Manual

This Technical Reference employs the following typographical conventions:

Boldface type: Bold is used for important terms, notes and warnings.

Italic font: Italic typeface is used for code snippets in the text. Note that C language modifiers such "const" or "volatile" are sometimes omitted to improve readability of the presented code.

Notes and warnings are shown as below:

Note

This is a note.

2.4 Acronyms and Definitions

Table 2-2. Acronyms and Definitions

| Term | Definition |
|---------|-------------------------------------|
| API | Application Programming Interface |
| ASM | Assembler Language |
| AUTOSAR | Automotive Open System Architecture |
| BSMI | Basic Software Make file Interface |
| C/CPP | C and C++ Source Code |
| DEM | Diagnostic Event Manager |
| DET | Development Error Tracer |
| N/A | Not Applicable |
| MCU | Micro Controller Unit |
| VLE | Variable Length Encoding |

2.5 Reference List

Table 2-3. Reference List

| # | Title | Version |
|---|--|----------------------------------|
| 1 | S32K14X Reference Manual | Reference Manual, Rev. 9, 9/2018 |
| 2 | S32K142 Mask Set Errata for Mask 0N33V (0N33V) | 30/11/2017 |
| 3 | S32K144 Mask Set Errata for Mask 0N57U (0N57U) | 30/11/2017 |
| 4 | S32K146 Mask Set Errata for Mask 0N73V (0N73V) | 30/11/2017 |
| 5 | S32K148 Mask Set Errata for Mask 0N20V (0N20V) | 25/10/2018 |
| 6 | S32K118 Mask Set Errata for Mask 0N97V (0N97V) | 07/01/2019 |

Chapter 3

Driver

3.1 Requirements

BASE is an custom module, so AUTOSAR only specifies some guidelines for the design and configuration. Other details for this module can be found in EB tresos Studio developer's guide. This module contains stubs from several AutoSAR components. The requirements used for the files present in this module are available in the Software Specification documents from Table [Reference List](#) .

3.2 Driver Design Summary

The BASE module contains the common files/definitions needed by the MCAL. This means that it is a dependency for all other MCAL modules.

The BASE module consists from a list of C header files that can be split into 3 categories:

- AutoSAR required files (that AutoSAR specifies and must not be modified)
- Stubs - files that are required by AutoSAR but are provided as examples in the NXP SemiconductorsS32K14X MCAL release. They must be re-written by the integrator.
- Files that are required by the NXP SemiconductorsS32K14X MCAL and must not be modified.

Below you can find the descriptions for each file present in the BASE module:

Table 3-1. Description of files inside the BASE module

| File Name | File Type | Description |
|--------------------|---|---|
| Can_GeneralTypes.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines/typedefs/constants that are needed by the MCAL drivers. Note: The following files need to be included prior to include Can_GeneralTypes.h - ComStack_Cfg.h and Can_Cfg.h |

Table continues on the next page...

Table 3-1. Description of files inside the BASE module (continued)

| File Name | File Type | Description |
|--------------------|---|--|
| Compiler.h | AutoSAR specified file - must not be modified. | This is a file with content fully defined by the AutoSAR standard. AutoSAR requires that no modification must be done to the contents of this file. During integration this file can be overwritten with another one with the same C content. The NXP SemiconductorsS32K14X MCAL release provides this file and can be used as-is. |
| Compiler_Cfg.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines that are needed by the MCAL drivers. This file defines the compiler memory and pointer classes to be used for MCAL. The value of the defines must be set by each integrator. |
| ComStack_Cfg.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines/typedefs/constants that are needed by the MCAL drivers. |
| ComStack_Type.s.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines/typedefs/constants that are needed by the MCAL drivers. |
| Eth_GeneralTypes.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines/typedefs/constants that are needed by the MCAL drivers. |
| Fr_GeneralTypes.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines/typedefs/constants that are needed by the MCAL drivers. |
| Lin_GeneralTypes.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines/typedefs/constants that are needed by the MCAL drivers. |
| Mcal.h | MCAL specific file. | This is a file that specific to NXP SemiconductorsS32K14X MCAL release. It contains defines and macros needed by MCAL drivers. It contains several macros defined for every compiler supported by MCAL (but not all compilers are available for all releases - for a list of compilers supported by this release please check the release note document). If no operating system is used, the following 4 macros can be overwritten by the integrators depending on their environment: <ul style="list-style-type: none"> • ISR • EXIT_INTERRUPT • SuspendAllInterrupts • ResumeAllInterrupts If the integrated project uses an AutoSAR operating system, this file must be used as-is. |
| MemMap.h | Stub file. Must be replaced by all integrators. | This file is a stub. Its name and content is specified by AutoSAR but in the NXP SemiconductorsS32K14X MCAL release it contains only the defines/typedefs/constants that are needed by the MCAL drivers. This file contains the memory mapping instructions/pragmas needed for every memory section from the MCAL code. The default content of this file only renames some sections and has the pragmas to clearly mark the RAM code sections. Depending on the integrating environment, this entire file must be updated. |
| Platform_Types.h | AutoSAR specified file - | This is a file with content fully defined by the AutoSAR standard. AutoSAR requires that no modification must be done to the contents of this file. |

Table continues on the next page...

Table 3-1. Description of files inside the BASE module (continued)

| File Name | File Type | Description |
|-----------------|--|---|
| | must not be modified. | During integration this file can be overwritten with another one with the same C content. The NXP SemiconductorsS32K14X MCAL release provides this file and can be used as-is. |
| RegLockMacros.h | MCAL specific file - to be used as-is. | This is a file that specific to NXP SemiconductorsS32K14X MCAL release. It contains defines needed by MCAL drivers. |
| Reg_eSys.h | MCAL specific file - to be used as-is. | This is a file that specific to NXP SemiconductorsS32K14X MCAL release. It contains defines needed by MCAL drivers. |
| SilRegMacros.h | MCAL specific file - to be used as-is. | This is a file that specific to NXP SemiconductorsS32K14X MCAL release. It contains defines and macros needed by MCAL drivers. |
| Soc_lps.h | MCAL specific file - to be used as-is. | This is a file that specific to NXP SemiconductorsS32K14X MCAL release. It contains defines and macros needed by MCAL drivers. |
| StdRegMacros.h | MCAL specific file - to be used as-is. | This is a file that specific to NXP SemiconductorsS32K14X MCAL release. It contains defines and macros needed by MCAL drivers. |
| Std_Types.h | AutoSAR specified file - must not be modified. | This is a file with content fully defined by the AutoSAR standard. AutoSAR requires that no modification must be done to the contents of this file. During integration this file can be overwritten with another one with the same C content. The NXP SemiconductorsS32K14X MCAL release provides this file and can be used as-is. |
| modules.h | MCAL specific file - to be used as-is. | This is a file that is generated by Base plugin and contains defines needed by MCAL drivers. |

3.3 Hardware Resources

None.

3.4 Deviation from Requirements

None

3.5 Driver limitations

None

3.6 Driver usage and configuration tips

None

3.7 Runtime Errors

The module does not generate any DEM errors at runtime.

Table 3-2. Runtime Errors

| Function | Error Code | Condition triggering the error |
|----------|------------|--------------------------------|
| N/A | N/A | N/A |

3.8 Software specification

The following sections contains driver software specifications.

3.8.1 Define Reference

Constants supported by the driver are as per AUTOSAR BASE Driver software specification Version 4.3 Rev0001 .

3.8.1.1 Define COMPILER_VENDOR_ID

Parameters that shall be published within the compiler abstraction header file and also in the module's description file.

Implements: DBASE03023

Table 3-3. Define COMPILER_VENDOR_ID Description

| | |
|--------------------|--------------------|
| Name | COMPILER_VENDOR_ID |
| Initializer | 43 |

3.8.1.2 Define COMPILER_AR_RELEASE_MAJOR_VERSION

Parameters that shall be published within the compiler abstraction header file and also in the module's description file.

Implements: DBASE03023

**Table 3-4. Define COMPILER_AR_RELEASE_MAJOR_VERSION
Description**

| | |
|--------------------|-----------------------------------|
| Name | COMPILER_AR_RELEASE_MAJOR_VERSION |
| Initializer | 4 |

3.8.1.3 Define COMPILER_AR_RELEASE_MINOR_VERSION

Parameters that shall be published within the compiler abstraction header file and also in the module's description file.

Implements: DBASE03023

**Table 3-5. Define COMPILER_AR_RELEASE_MINOR_VERSION
Description**

| | |
|--------------------|-----------------------------------|
| Name | COMPILER_AR_RELEASE_MINOR_VERSION |
| Initializer | 3 |

3.8.1.4 Define COMPILER_AR_RELEASE_REVISION_VERSION

Parameters that shall be published within the compiler abstraction header file and also in the module's description file.

Implements: DBASE03023

Table 3-6. Define COMPILER_AR_RELEASE_REVISION_VERSION
Description

| | |
|--------------------|--------------------------------------|
| Name | COMPILER_AR_RELEASE_REVISION_VERSION |
| Initializer | 1 |

3.8.1.5 Define COMPILER_SW_MAJOR_VERSION

Parameters that shall be published within the compiler abstraction header file and also in the module's description file.

Implements: DBASE03023

Table 3-7. Define COMPILER_SW_MAJOR_VERSION
Description

| | |
|--------------------|---------------------------|
| Name | COMPILER_SW_MAJOR_VERSION |
| Initializer | 1 |

3.8.1.6 Define COMPILER_SW_MINOR_VERSION

Parameters that shall be published within the compiler abstraction header file and also in the module's description file.

Implements: DBASE03023

Table 3-8. Define COMPILER_SW_MINOR_VERSION
Description

| | |
|--------------------|---------------------------|
| Name | COMPILER_SW_MINOR_VERSION |
| Initializer | 0 |

3.8.1.7 Define COMPILER_SW_PATCH_VERSION

Parameters that shall be published within the compiler abstraction header file and also in the module's description file.

Implements: DBASE03023

Table 3-9. Define COMPILER_SW_PATCH_VERSION Description

| | |
|--------------------|---------------------------|
| Name | COMPILER_SW_PATCH_VERSION |
| Initializer | 1 |

3.8.1.8 Define AUTOMATIC

The memory class AUTOMATIC shall be provided as empty definition, used for the declaration of local pointers.

Implements: DBASE03004

Table 3-10. Define AUTOMATIC Description

| | |
|--------------------|-----------|
| Name | AUTOMATIC |
| Initializer | |

3.8.1.9 Define CONST

The compiler abstraction shall define the CONST macro for the declaration and definition of constants.

Implements: DBASE03012

Table 3-11. Define CONST Description

| | |
|--------------------|-----------------|
| Name | CONST |
| Initializer | const consttype |

3.8.1.10 Define CONSTP2CONST

The compiler abstraction shall define the CONSTP2CONST macro for the declaration and definition of constant pointers accessing constants.

Implements: DBASE03013

Table 3-12. Define CONSTP2CONST Description

| | |
|--------------------|-----------------------|
| Name | CONSP2CONST |
| Initializer | const ptrtype * const |

3.8.1.11 Define CONSTP2VAR

The compiler abstraction shall define the CONSTP2VAR macro for the declaration and definition of constant pointers accessing variables.

Implements: DBASE03014

Table 3-13. Define CONSTP2VAR Description

| | |
|--------------------|-----------------|
| Name | CONSP2VAR |
| Initializer | ptrtype * const |

3.8.1.12 Define FUNC

The compiler abstraction shall define the FUNC macro for the declaration and definition of functions, that ensures correct syntax of function declarations as required by a specific compiler.

Implements: DBASE03015

Table 3-14. Define FUNC Description

| | |
|--------------------|---------|
| Name | FUNC |
| Initializer | rettype |

3.8.1.13 Define NULL_PTR

The compiler abstraction shall provide the NULL_PTR define with a void pointer to zero definition.

Implements: DBASE03009

Table 3-15. Define NULL_PTR Description

| | |
|--------------------|-------------|
| Name | NULL_PTR |
| Initializer | ((void *)0) |

3.8.1.14 Define P2CONST

The compiler abstraction shall define the P2CONST macro for the declaration and definition of pointers in RAM pointing to constants.

Implements: DBASE03017

Table 3-16. Define P2CONST Description

| | |
|--------------------|-----------------|
| Name | P2CONST |
| Initializer | const ptrtype * |

3.8.1.15 Define P2FUNC

The compiler abstraction shall define the P2FUNC macro for the type definition of pointers to functions.

Implements: DBASE03018

Table 3-17. Define P2FUNC Description

| | |
|--------------------|--------------------|
| Name | P2FUNC |
| Initializer | rettype (*fctname) |

3.8.1.16 Define P2VAR

The compiler abstraction shall define the P2VAR macro for the declaration and definition of pointers in RAM, pointing to variables.

Implements: DBASE03019**Table 3-18. Define P2VAR Description**

| | |
|--------------------|-----------|
| Name | P2VAR |
| Initializer | ptrtype * |

3.8.1.17 Define TYPEDEF

The memory class TYPEDEF shall be provided as empty definition. This memory class shall be used within type definitions, where no memory qualifier can be specified. This can be necessary for defining pointer types, with e.g. P2VAR, where the macros require two parameters. First parameter can be specified in the type definition (distance to the memory location referenced by the pointer), but the second one (memory allocation of the pointer itself) cannot be defined at this time. Hence memory class TYPEDEF shall be applied.

Implements: DBASE03011**Table 3-19. Define TYPEDEF Description**

| | |
|--------------------|---------|
| Name | TYPEDEF |
| Initializer | |

3.8.1.18 Define VAR

The compiler abstraction shall define the VAR macro for the declaration and definition of variables.

Implements: DBASE03022**Table 3-20. Define VAR Description**

| | |
|--------------------|---------|
| Name | VAR |
| Initializer | vartype |

3.8.1.19 Define ADC_CODE

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-21. Define ADC_CODE Description

| | |
|--------------------|----------|
| Name | ADC_CODE |
| Initializer | |

3.8.1.20 Define ADC_CONST

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-22. Define ADC_CONST Description

| | |
|--------------------|-----------|
| Name | ADC_CONST |
| Initializer | |

3.8.1.21 Define ADC_APPL_DATA

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-23. Define ADC_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | ADC_APPL_DATA |
| Initializer | |

3.8.1.22 Define ADC_APPL_CONST

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-24. Define ADC_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | ADC_APPL_CONST |
| Initializer | |

3.8.1.23 Define ADC_APPL_CODE

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-25. Define ADC_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | ADC_APPL_CODE |
| Initializer | |

3.8.1.24 Define ADC_CALLOUT_CODE

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-26. Define ADC_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | ADC_CALLOUT_CODE |
| Initializer | |

3.8.1.25 Define ADC_VAR_NOINIT

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-27. Define ADC_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | ADC_VAR_NOINIT |
| Initializer | |

3.8.1.26 Define ADC_VAR_POWER_ON_INIT

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-28. Define ADC_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | ADC_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.27 Define ADC_VAR_FAST

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-29. Define ADC_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | ADC_VAR_FAST |
| Initializer | |

3.8.1.28 Define ADC_VAR

ADC memory and pointer classes.

Implements: DBASE04001

Table 3-30. Define ADC_VAR Description

| | |
|--------------------|---------|
| Name | ADC_VAR |
| Initializer | |

3.8.1.29 Define CAN_CODE

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-31. Define CAN_CODE Description

| | |
|-------------|----------|
| Name | CAN_CODE |
| Initializer | |

3.8.1.30 Define CAN_CONST

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-32. Define CAN_CONST Description

| | |
|-------------|-----------|
| Name | CAN_CONST |
| Initializer | |

3.8.1.31 Define CAN_APPL_DATA

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-33. Define CAN_APPL_DATA Description

| | |
|-------------|---------------|
| Name | CAN_APPL_DATA |
| Initializer | |

3.8.1.32 Define CAN_APPL_CONST

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-34. Define CAN_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | CAN_APPL_CONST |
| Initializer | |

3.8.1.33 Define CAN_APPL_CODE

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-35. Define CAN_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | CAN_APPL_CODE |
| Initializer | |

3.8.1.34 Define CAN_CALLOUT_CODE

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-36. Define CAN_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | CAN_CALLOUT_CODE |
| Initializer | |

3.8.1.35 Define CAN_VAR_NOINIT

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-37. Define CAN_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | CAN_VAR_NOINIT |
| Initializer | |

3.8.1.36 Define CAN_VAR_POWER_ON_INIT

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-38. Define CAN_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | CAN_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.37 Define CAN_VAR_FAST

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-39. Define CAN_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | CAN_VAR_FAST |
| Initializer | |

3.8.1.38 Define CAN_VAR

CAN memory and pointer classes.

Implements: DBASE04001

Table 3-40. Define CAN_VAR Description

| | |
|--------------------|---------|
| Name | CAN_VAR |
| Initializer | |

3.8.1.39 Define CRCU_CODE

CRCU memory and pointer classes.

Implements:

Table 3-41. Define CRCU_CODE Description

| | |
|--------------------|-----------|
| Name | CRCU_CODE |
| Initializer | |

3.8.1.40 Define CRCU_CONST

CRCU memory and pointer classes.

Implements:

Table 3-42. Define CRCU_CONST Description

| | |
|--------------------|------------|
| Name | CRCU_CONST |
| Initializer | |

3.8.1.41 Define CRCU_APPL_DATA

CRCU memory and pointer classes.

Implements:

Table 3-43. Define CRCU_APPL_DATA Description

| | |
|--------------------|----------------|
| Name | CRCU_APPL_DATA |
| Initializer | |

3.8.1.42 Define CRCU_APPL_CONST

CRCU memory and pointer classes.

Implements:

Table 3-44. Define CRCU_APPL_CONST Description

| | |
|--------------------|-----------------|
| Name | CRCU_APPL_CONST |
| Initializer | |

3.8.1.43 Define CRCU_APPL_CODE

CRCU memory and pointer classes.

Implements: DBASE04001

Table 3-45. Define CRCU_APPL_CODE Description

| | |
|--------------------|----------------|
| Name | CRCU_APPL_CODE |
| Initializer | |

3.8.1.44 Define CRCU_CALLOUT_CODE

CRCU memory and pointer classes.

Implements:

Table 3-46. Define CRCU_CALLOUT_CODE Description

| | |
|--------------------|-------------------|
| Name | CRCU_CALLOUT_CODE |
| Initializer | |

3.8.1.45 Define CRCU_VAR_NOINIT

CRCU memory and pointer classes.

Implements:

Table 3-47. Define CRCU_VAR_NOINIT Description

| | |
|--------------------|-----------------|
| Name | CRCU_VAR_NOINIT |
| Initializer | |

3.8.1.46 Define CRCU_VAR_POWER_ON_INIT

CRCU memory and pointer classes.

Implements:

Table 3-48. Define CRCU_VAR_POWER_ON_INIT Description

| | |
|--------------------|------------------------|
| Name | CRCU_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.47 Define CRCU_VAR_FAST

CRCU memory and pointer classes.

Implements:

Table 3-49. Define CRCU_VAR_FAST Description

| | |
|--------------------|---------------|
| Name | CRCU_VAR_FAST |
| Initializer | |

3.8.1.48 Define CRCU_VAR

CRCU memory and pointer classes.

Implements:**Table 3-50. Define CRCU_VAR Description**

| | |
|--------------------|----------|
| Name | CRCU_VAR |
| Initializer | |

3.8.1.49 Define CANIF_CODE

CANIF memory and pointer classes.

Implements: DBASE04001**Table 3-51. Define CANIF_CODE Description**

| | |
|--------------------|------------|
| Name | CANIF_CODE |
| Initializer | |

3.8.1.50 Define CANIF_CONST

CANIF memory and pointer classes.

Implements: DBASE04001**Table 3-52. Define CANIF_CONST Description**

| | |
|--------------------|-------------|
| Name | CANIF_CONST |
| Initializer | |

3.8.1.51 Define CANIF_APPL_DATA

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-53. Define CANIF_APPL_DATA Description

| | |
|--------------------|-----------------|
| Name | CANIF_APPL_DATA |
| Initializer | |

3.8.1.52 Define CANIF_APPL_CONST

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-54. Define CANIF_APPL_CONST Description

| | |
|--------------------|------------------|
| Name | CANIF_APPL_CONST |
| Initializer | |

3.8.1.53 Define CANIF_APPL_CODE

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-55. Define CANIF_APPL_CODE Description

| | |
|--------------------|-----------------|
| Name | CANIF_APPL_CODE |
| Initializer | |

3.8.1.54 Define CANIF_CALLOUT_CODE

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-56. Define CANIF_CALLOUT_CODE Description

| | |
|--------------------|--------------------|
| Name | CANIF_CALLOUT_CODE |
| Initializer | |

3.8.1.55 Define CANIF_VAR_NOINIT

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-57. Define CANIF_VAR_NOINIT Description

| | |
|--------------------|------------------|
| Name | CANIF_VAR_NOINIT |
| Initializer | |

3.8.1.56 Define CANIF_VAR_POWER_ON_INIT

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-58. Define CANIF_VAR_POWER_ON_INIT Description

| | |
|--------------------|-------------------------|
| Name | CANIF_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.57 Define CANIF_VAR_FAST

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-59. Define CANIF_VAR_FAST Description

| | |
|--------------------|----------------|
| Name | CANIF_VAR_FAST |
| Initializer | |

3.8.1.58 Define CANIF_VAR

CANIF memory and pointer classes.

Implements: DBASE04001

Table 3-60. Define CANIF_VAR Description

| | |
|--------------------|-----------|
| Name | CANIF_VAR |
| Initializer | |

3.8.1.59 Define DEM_CODE

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-61. Define DEM_CODE Description

| | |
|--------------------|----------|
| Name | DEM_CODE |
| Initializer | |

3.8.1.60 Define DEM_CONST

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-62. Define DEM_CONST Description

| | |
|--------------------|-----------|
| Name | DEM_CONST |
| Initializer | |

3.8.1.61 Define DEM_APPL_DATA

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-63. Define DEM_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | DEM_APPL_DATA |
| Initializer | |

3.8.1.62 Define DEM_APPL_CONST

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-64. Define DEM_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | DEM_APPL_CONST |
| Initializer | |

3.8.1.63 Define DEM_APPL_CODE

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-65. Define DEM_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | DEM_APPL_CODE |
| Initializer | |

3.8.1.64 Define DEM_CALLOUT_CODE

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-66. Define DEM_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | DEM_CALLOUT_CODE |
| Initializer | |

3.8.1.65 Define DEM_VAR_NOINIT

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-67. Define DEM_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | DEM_VAR_NOINIT |
| Initializer | |

3.8.1.66 Define DEM_VAR_POWER_ON_INIT

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-68. Define DEM_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | DEM_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.67 Define DEM_VAR_FAST

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-69. Define DEM_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | DEM_VAR_FAST |
| Initializer | |

3.8.1.68 Define DEM_VAR

DEM memory and pointer classes.

Implements: DBASE04001

Table 3-70. Define DEM_VAR Description

| | |
|-------------|---------|
| Name | DEM_VAR |
| Initializer | |

3.8.1.69 Define DET_CODE

DET memory and pointer classes.

Implements: DBASE04001

Table 3-71. Define DET_CODE Description

| | |
|-------------|----------|
| Name | DET_CODE |
| Initializer | |

3.8.1.70 Define DET_CONST

DET memory and pointer classes.

Implements: DBASE04001

Table 3-72. Define DET_CONST Description

| | |
|-------------|-----------|
| Name | DET_CONST |
| Initializer | |

3.8.1.71 Define DET_APPL_DATA

DET memory and pointer classes.

Implements: DBASE04001

Table 3-73. Define DET_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | DET_APPL_DATA |
| Initializer | |

3.8.1.72 Define DET_APPL_CONST

DET memory and pointer classes.

Implements: DBASE04001

Table 3-74. Define DET_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | DET_APPL_CONST |
| Initializer | |

3.8.1.73 Define DET_APPL_CODE

DET memory and pointer classes.

Implements: DBASE04001

Table 3-75. Define DET_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | DET_APPL_CODE |
| Initializer | |

3.8.1.74 Define DET_CALLOUT_CODE

DET memory and pointer classes.

Implements: DBASE04001

Table 3-76. Define DET_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | DET_CALLOUT_CODE |
| Initializer | |

3.8.1.75 Define DET_VAR_NOINIT

DET memory and pointer classes.

Implements: DBASE04001

Table 3-77. Define DET_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | DET_VAR_NOINIT |
| Initializer | |

3.8.1.76 Define DET_VAR_POWER_ON_INIT

DET memory and pointer classes.

Implements: DBASE04001

Table 3-78. Define DET_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | DET_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.77 Define DET_VAR_FAST

DET memory and pointer classes.

Implements: DBASE04001

Table 3-79. Define DET_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | DET_VAR_FAST |
| Initializer | |

3.8.1.78 Define DET_VAR

DET memory and pointer classes.

Implements: DBASE04001

Table 3-80. Define DET_VAR Description

| | |
|--------------------|---------|
| Name | DET_VAR |
| Initializer | |

3.8.1.79 Define DIO_CODE

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-81. Define DIO_CODE Description

| | |
|--------------------|----------|
| Name | DIO_CODE |
| Initializer | |

3.8.1.80 Define DIO_CONST

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-82. Define DIO_CONST Description

| | |
|--------------------|-----------|
| Name | DIO_CONST |
| Initializer | |

3.8.1.81 Define DIO_APPL_DATA

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-83. Define DIO_APPL_DATA Description

| | |
|-------------|---------------|
| Name | DIO_APPL_DATA |
| Initializer | |

3.8.1.82 Define DIO_APPL_CONST

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-84. Define DIO_APPL_CONST Description

| | |
|-------------|----------------|
| Name | DIO_APPL_CONST |
| Initializer | |

3.8.1.83 Define DIO_APPL_CODE

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-85. Define DIO_APPL_CODE Description

| | |
|-------------|---------------|
| Name | DIO_APPL_CODE |
| Initializer | |

3.8.1.84 Define DIO_CALLOUT_CODE

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-86. Define DIO_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | DIO_CALLOUT_CODE |
| Initializer | |

3.8.1.85 Define DIO_VAR_NOINIT

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-87. Define DIO_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | DIO_VAR_NOINIT |
| Initializer | |

3.8.1.86 Define DIO_VAR_POWER_ON_INIT

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-88. Define DIO_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | DIO_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.87 Define DIO_VAR_FAST

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-89. Define DIO_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | DIO_VAR_FAST |
| Initializer | |

3.8.1.88 Define DIO_VAR

DIO memory and pointer classes.

Implements: DBASE04001

Table 3-90. Define DIO_VAR Description

| | |
|--------------------|---------|
| Name | DIO_VAR |
| Initializer | |

3.8.1.89 Define ETH_CODE

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-91. Define ETH_CODE Description

| | |
|--------------------|----------|
| Name | ETH_CODE |
| Initializer | |

3.8.1.90 Define ETH_CONST

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-92. Define ETH_CONST Description

| | |
|--------------------|-----------|
| Name | ETH_CONST |
| Initializer | |

3.8.1.91 Define ETH_APPL_DATA

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-93. Define ETH_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | ETH_APPL_DATA |
| Initializer | |

3.8.1.92 Define ETH_APPL_CONST

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-94. Define ETH_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | ETH_APPL_CONST |
| Initializer | |

3.8.1.93 Define ETH_APPL_CODE

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-95. Define ETH_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | ETH_APPL_CODE |
| Initializer | |

3.8.1.94 Define ETH_CALLOUT_CODE

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-96. Define ETH_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | ETH_CALLOUT_CODE |
| Initializer | |

3.8.1.95 Define ETH_VAR_NOINIT

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-97. Define ETH_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | ETH_VAR_NOINIT |
| Initializer | |

3.8.1.96 Define ETH_VAR_POWER_ON_INIT

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-98. Define ETH_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | ETH_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.97 Define ETH_VAR_FAST

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-99. Define ETH_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | ETH_VAR_FAST |
| Initializer | |

3.8.1.98 Define ETH_VAR

ETH memory and pointer classes.

Implements: DBASE04001

Table 3-100. Define ETH_VAR Description

| | |
|--------------------|---------|
| Name | ETH_VAR |
| Initializer | |

3.8.1.99 Define ETH_AR_RELEASE_MAJOR_VERSION_ETHGENERALTYPES

Violates: MISRA rule 1.4

**Table 3-101. Define ETH_AR_RELEASE_MAJOR_VERSION_ETHGENERALTYPES
Description**

| | |
|--------------------|--|
| Name | ETH_AR_RELEASE_MAJOR_VERSION_ETHGENERALTYPES |
| Initializer | 4 |

3.8.1.100 Define ETH_AR_RELEASE_MINOR_VERSION_ETHGENERALTYPES

Violates: MISRA rule 1.4

Table 3-102. Define ETH_AR_RELEASE_MINOR_VERSION_ETHGENERALTYPES
Description

| | |
|--------------------|--|
| Name | ETH_AR_RELEASE_MINOR_VERSION_ETHGENERALTYPES |
| Initializer | 3 |

3.8.1.101 Define ETH_AR_RELEASE_REVISION_VERSION_ETHGENERALTYPES

Violates: MISRA rule 1.4

Table 3-103. Define ETH_AR_RELEASE_REVISION_VERSION_ETHGENERALTYPES
Description

| | |
|--------------------|---|
| Name | ETH_AR_RELEASE_REVISION_VERSION_ETHGENERALTYPES |
| Initializer | 1 |

3.8.1.102 Define ETH_MODULE_ID_ETHGENERALTYPES

Table 3-104. Define ETH_MODULE_ID_ETHGENERALTYPES
Description

| | |
|--------------------|-------------------------------|
| Name | ETH_MODULE_ID_ETHGENERALTYPES |
| Initializer | 0 |

3.8.1.103 Define ETH_SW_MAJOR_VERSION_ETHGENERALTYPES

Violates: MISRA rule 1.4

Table 3-105. Define ETH_SW_MAJOR_VERSION_ETHGENERALTYPES
Description

| | |
|--------------------|--------------------------------------|
| Name | ETH_SW_MAJOR_VERSION_ETHGENERALTYPES |
| Initializer | 1 |

3.8.1.104 Define ETH_SW_MINOR_VERSION_ETHGENERALTYPES

Violates: MISRA rule 1.4

Table 3-106. Define ETH_SW_MINOR_VERSION_ETHGENERALTYPES
Description

| | |
|--------------------|--------------------------------------|
| Name | ETH_SW_MINOR_VERSION_ETHGENERALTYPES |
| Initializer | 0 |

3.8.1.105 Define ETH_SW_PATCH_VERSION_ETHGENERALTYPES

Violates: MISRA rule 1.4

Table 3-107. Define ETH_SW_PATCH_VERSION_ETHGENERALTYPES
Description

| | |
|--------------------|--------------------------------------|
| Name | ETH_SW_PATCH_VERSION_ETHGENERALTYPES |
| Initializer | 1 |

3.8.1.106 Define ETH_VENDOR_ID_ETHGENERALTYPES

Table 3-108. Define ETH_VENDOR_ID_ETHGENERALTYPES
Description

| | |
|--------------------|-------------------------------|
| Name | ETH_VENDOR_ID_ETHGENERALTYPES |
| Initializer | 43 |

3.8.1.107 Define FEE_CODE

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-109. Define FEE_CODE Description

| | |
|--------------------|----------|
| Name | FEE_CODE |
| Initializer | |

3.8.1.108 Define FEE_CONST

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-110. Define FEE_CONST Description

| | |
|--------------------|-----------|
| Name | FEE_CONST |
| Initializer | |

3.8.1.109 Define FEE_APPL_DATA

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-111. Define FEE_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | FEE_APPL_DATA |
| Initializer | |

3.8.1.110 Define FEE_APPL_CONST

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-112. Define FEE_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | FEE_APPL_CONST |
| Initializer | |

3.8.1.111 Define FEE_APPL_CODE

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-113. Define FEE_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | FEE_APPL_CODE |
| Initializer | |

3.8.1.112 Define FEE_CALLOUT_CODE

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-114. Define FEE_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | FEE_CALLOUT_CODE |
| Initializer | |

3.8.1.113 Define FEE_VAR_NOINIT

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-115. Define FEE_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | FEE_VAR_NOINIT |
| Initializer | |

3.8.1.114 Define FEE_VAR_POWER_ON_INIT

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-116. Define FEE_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | FEE_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.115 Define FEE_VAR_FAST

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-117. Define FEE_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | FEE_VAR_FAST |
| Initializer | |

3.8.1.116 Define FEE_VAR

FEE memory and pointer classes.

Implements: DBASE04001

Table 3-118. Define FEE_VAR Description

| | |
|--------------------|---------|
| Name | FEE_VAR |
| Initializer | |

3.8.1.117 Define FLS_CODE

FLS memory and pointer classes.

Implements: DBASE04001

Table 3-119. Define FLS_CODE Description

| | |
|--------------------|----------|
| Name | FLS_CODE |
| Initializer | |

3.8.1.118 Define FLS_CONST

FLS memory and pointer classes.

Implements: DBASE04001

Table 3-120. Define FLS_CONST Description

| | |
|--------------------|-----------|
| Name | FLS_CONST |
| Initializer | |

3.8.1.119 Define FLS_APPL_DATA

FLS memory and pointer classes.

Implements: DBASE04001

Table 3-121. Define FLS_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | FLS_APPL_DATA |
| Initializer | |

3.8.1.120 Define FLS_APPL_CONST

FLS memory and pointer classes.

Implements: DBASE04001

**Table 3-122. Define FLS_APPL_CONST
Description**

| | |
|--------------------|----------------|
| Name | FLS_APPL_CONST |
| Initializer | |

3.8.1.121 Define FLS_APPL_CODE

FLS memory and pointer classes.

Implements: DBASE04001

**Table 3-123. Define FLS_APPL_CODE
Description**

| | |
|--------------------|---------------|
| Name | FLS_APPL_CODE |
| Initializer | |

3.8.1.122 Define FLS_CALLOUT_CODE

FLS memory and pointer classes.

Implements: DBASE04001

**Table 3-124. Define FLS_CALLOUT_CODE
Description**

| | |
|--------------------|------------------|
| Name | FLS_CALLOUT_CODE |
| Initializer | |

3.8.1.123 Define FLS_VAR_NOINIT

FLS memory and pointer classes.

Implements: DBASE04001

Table 3-125. Define FLS_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | FLS_VAR_NOINIT |
| Initializer | |

3.8.1.124 Define FLS_VAR_POWER_ON_INIT

FLS memory and pointer classes.

Implements: DBASE04001

Table 3-126. Define FLS_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | FLS_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.125 Define FLS_VAR_FAST

FLS memory and pointer classes.

Implements: DBASE04001

Table 3-127. Define FLS_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | FLS_VAR_FAST |
| Initializer | |

3.8.1.126 Define FLS_VAR

FLS memory and pointer classes.

Implements: DBASE04001

Table 3-128. Define FLS_VAR Description

| | |
|--------------------|---------|
| Name | FLS_VAR |
| Initializer | |

3.8.1.127 Define FR_APPL_CODE

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-129. Define FR_APPL_CODE Description

| | |
|--------------------|--------------|
| Name | FR_APPL_CODE |
| Initializer | |

3.8.1.128 Define FR_APPL_CONST

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-130. Define FR_APPL_CONST Description

| | |
|--------------------|---------------|
| Name | FR_APPL_CONST |
| Initializer | |

3.8.1.129 Define FR_APPL_DATA

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-131. Define FR_APPL_DATA Description

| | |
|--------------------|--------------|
| Name | FR_APPL_DATA |
| Initializer | |

3.8.1.130 Define FR_CALLOUT_CODE

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-132. Define FR_CALLOUT_CODE Description

| | |
|--------------------|-----------------|
| Name | FR_CALLOUT_CODE |
| Initializer | |

3.8.1.131 Define FR_CIDX_GCOLDSTARTATTEMPTS

Table 3-133. Define FR_CIDX_GCOLDSTARTATTEMPTS Description

| | |
|--------------------|----------------------------|
| Name | FR_CIDX_GCOLDSTARTATTEMPTS |
| Initializer | 17U |

3.8.1.132 Define FR_CIDX_GCYCLECOUNTMAX

Table 3-134. Define FR_CIDX_GCYCLECOUNTMAX Description

| | |
|--------------------|------------------------|
| Name | FR_CIDX_GCYCLECOUNTMAX |
| Initializer | 18U |

3.8.1.133 Define FR_CIDX_GDACTIONPOINTOFFSET

Table 3-135. Define FR_CIDX_GDACTIONPOINTOFFSET Description

| | |
|--------------------|-----------------------------|
| Name | FR_CIDX_GDACTIONPOINTOFFSET |
| Initializer | 25U |

3.8.1.134 Define FR_CIDX_GDBIT

Table 3-136. Define FR_CIDX_GDBIT Description

| | |
|-------------|---------------|
| Name | FR_CIDX_GDBIT |
| Initializer | 26U |

3.8.1.135 Define FR_CIDX_GDCASRXLOWMAX

Table 3-137. Define FR_CIDX_GDCASRXLOWMAX Description

| | |
|-------------|-----------------------|
| Name | FR_CIDX_GDCASRXLOWMAX |
| Initializer | 27U |

3.8.1.136 Define FR_CIDX_GDCYCLE

Macros which can be passed into Fr_ReadCCConfig as parameter Fr_ConfigParamIdx.

Details:

Each macro (index) uniquely identifies a configuration parameter which value can be read out of the controllers configuration using Fr_ReadCCConfig.

Covers FR657

Implements: DFR32010

Table 3-138. Define FR_CIDX_GDCYCLE Description

| | |
|-------------|-----------------|
| Name | FR_CIDX_GDCYCLE |
| Initializer | 0U |

3.8.1.137 Define FR_CIDX_GDDYNAMICSLOTIDLEPHASE

Table 3-139. Define FR_CIDX_GDDYNAMICSLOTIDLEPHASE Description

| | |
|-------------|--------------------------------|
| Name | FR_CIDX_GDDYNAMICSLOTIDLEPHASE |
| Initializer | 28U |

3.8.1.138 Define FR_CIDX_GDIGNOREAFTERTX

Table 3-140. Define FR_CIDX_GDIGNOREAFTERTX Description

| | |
|-------------|-------------------------|
| Name | FR_CIDX_GDIGNOREAFTERTX |
| Initializer | 54U |

3.8.1.139 Define FR_CIDX_GDMACROTICK

Table 3-141. Define FR_CIDX_GDMACROTICK Description

| | |
|-------------|---------------------|
| Name | FR_CIDX_GDMACROTICK |
| Initializer | 4U |

3.8.1.140 Define FR_CIDX_GDMINISLOT

Table 3-142. Define FR_CIDX_GDMINISLOT Description

| | |
|-------------|--------------------|
| Name | FR_CIDX_GDMINISLOT |
| Initializer | 30U |

3.8.1.141 Define FR_CIDX_GDMINISLOTACTIONPOINTOFFSET

Table 3-143. Define FR_CIDX_GDMINISLOTACTIONPOINTOFFSET Description

| | |
|-------------|-------------------------------------|
| Name | FR_CIDX_GDMINISLOTACTIONPOINTOFFSET |
| Initializer | 29U |

3.8.1.142 Define FR_CIDX_GDNIT

Table 3-144. Define FR_CIDX_GDNIT Description

| | |
|-------------|---------------|
| Name | FR_CIDX_GDNIT |
| Initializer | 7U |

3.8.1.143 Define FR_CIDX_GDSAMPLECLOCKPERIOD**Table 3-145. Define FR_CIDX_GDSAMPLECLOCKPERIOD Description**

| | |
|--------------------|-----------------------------|
| Name | FR_CIDX_GDSAMPLECLOCKPERIOD |
| Initializer | 31U |

3.8.1.144 Define FR_CIDX_GDSTATICSLOT**Table 3-146. Define FR_CIDX_GDSTATICSLOT Description**

| | |
|--------------------|----------------------|
| Name | FR_CIDX_GDSTATICSLOT |
| Initializer | 8U |

3.8.1.145 Define FR_CIDX_GDSYMBOLWINDOW**Table 3-147. Define FR_CIDX_GDSYMBOLWINDOW Description**

| | |
|--------------------|------------------------|
| Name | FR_CIDX_GDSYMBOLWINDOW |
| Initializer | 32U |

3.8.1.146 Define FR_CIDX_GDSYMBOLWINDOWACTIONPOINTOFFSET**Table 3-148. Define FR_CIDX_GDSYMBOLWINDOWACTIONPOINTOFFSET Description**

| | |
|--------------------|---|
| Name | FR_CIDX_GDSYMBOLWINDOWACTIONPOINTOFFSET |
| Initializer | 33U |

3.8.1.147 Define FR_CIDX_GDTSSTRANSMITTER**Table 3-149. Define FR_CIDX_GDTSSTRANSMITTER Description**

| | |
|--------------------|--------------------------|
| Name | FR_CIDX_GDTSSTRANSMITTER |
| Initializer | 34U |

3.8.1.148 Define FR_CIDX_GDWAKEUPRXIDLE**Table 3-150. Define FR_CIDX_GDWAKEUPRXIDLE Description**

| | |
|--------------------|------------------------|
| Name | FR_CIDX_GDWAKEUPRXIDLE |
| Initializer | 35U |

3.8.1.149 Define FR_CIDX_GDWAKEUPRXLOW**Table 3-151. Define FR_CIDX_GDWAKEUPRXLOW Description**

| | |
|--------------------|-----------------------|
| Name | FR_CIDX_GDWAKEUPRXLOW |
| Initializer | 36U |

3.8.1.150 Define FR_CIDX_GDWAKEUPRXWINDOW**Table 3-152. Define FR_CIDX_GDWAKEUPRXWINDOW Description**

| | |
|--------------------|--------------------------|
| Name | FR_CIDX_GDWAKEUPRXWINDOW |
| Initializer | 9U |

3.8.1.151 Define FR_CIDX_GDWAKEUPTXACTIVE**Table 3-153. Define FR_CIDX_GDWAKEUPTXACTIVE Description**

| | |
|--------------------|--------------------------|
| Name | FR_CIDX_GDWAKEUPTXACTIVE |
| Initializer | 37U |

3.8.1.152 Define FR_CIDX_GDWAKEUPTXIDLE**Table 3-154. Define FR_CIDX_GDWAKEUPTXIDLE Description**

| | |
|--------------------|------------------------|
| Name | FR_CIDX_GDWAKEUPTXIDLE |
| Initializer | 38U |

3.8.1.153 Define FR_CIDX_GLISTENNOISE**Table 3-155. Define FR_CIDX_GLISTENNOISE Description**

| | |
|--------------------|----------------------|
| Name | FR_CIDX_GLISTENNOISE |
| Initializer | 19U |

3.8.1.154 Define FR_CIDX_GMACROPERCYCLE**Table 3-156. Define FR_CIDX_GMACROPERCYCLE Description**

| | |
|--------------------|------------------------|
| Name | FR_CIDX_GMACROPERCYCLE |
| Initializer | 3U |

3.8.1.155 Define FR_CIDX_GMAXWITHOUTCLOCKCORRECTFATAL**Table 3-157. Define FR_CIDX_GMAXWITHOUTCLOCKCORRECTFATAL Description**

| | |
|--------------------|--------------------------------------|
| Name | FR_CIDX_GMAXWITHOUTCLOCKCORRECTFATAL |
| Initializer | 20U |

3.8.1.156 Define FR_CIDX_GMAXWITHOUTCLOCKCORRECTPASSIVE**Table 3-158. Define FR_CIDX_GMAXWITHOUTCLOCKCORRECTPASSIVE Description**

| | |
|--------------------|--|
| Name | FR_CIDX_GMAXWITHOUTCLOCKCORRECTPASSIVE |
| Initializer | 21U |

3.8.1.157 Define FR_CIDX_GNETWORKMANAGEMENTVECTORLENGTH

Table 3-159. Define FR_CIDX_GNETWORKMANAGEMENTVECTORLENGTH
Description

| | |
|-------------|--|
| Name | FR_CIDX_GNETWORKMANAGEMENTVECTORLENGTH |
| Initializer | 22U |

3.8.1.158 Define FR_CIDX_GNUMBEROFMINISLOTS

Table 3-160. Define FR_CIDX_GNUMBEROFMINISLOTS
Description

| | |
|-------------|----------------------------|
| Name | FR_CIDX_GNUMBEROFMINISLOTS |
| Initializer | 5U |

3.8.1.159 Define FR_CIDX_GNUMBEROFSTATICSLOTS

Table 3-161. Define FR_CIDX_GNUMBEROFSTATICSLOTS
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_GNUMBEROFSTATICSLOTS |
| Initializer | 6U |

3.8.1.160 Define FR_CIDX_GPAYLOADLENGTHSTATIC

Table 3-162. Define FR_CIDX_GPAYLOADLENGTHSTATIC
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_GPAYLOADLENGTHSTATIC |
| Initializer | 23U |

3.8.1.161 Define FR_CIDX_GSYNCFRAMEIDCOUNTMAX

Table 3-163. Define FR_CIDX_GSYNCFRAMEIDCOUNTMAX
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_GSYNCFRAMEIDCOUNTMAX |
| Initializer | 24U |

3.8.1.162 Define FR_CIDX_PALLOWHALTDUETOCLOCK**Table 3-164. Define FR_CIDX_PALLOWHALTDUETOCLOCK
Description**

| | |
|--------------------|------------------------------|
| Name | FR_CIDX_PALLOWHALTDUETOCLOCK |
| Initializer | 55U |

3.8.1.163 Define FR_CIDX_PALLOWPASSIVETOACTIVE**Table 3-165. Define FR_CIDX_PALLOWPASSIVETOACTIVE
Description**

| | |
|--------------------|-------------------------------|
| Name | FR_CIDX_PALLOWPASSIVETOACTIVE |
| Initializer | 39U |

3.8.1.164 Define FR_CIDX_PCHANNELS**Table 3-166. Define FR_CIDX_PCHANNELS Description**

| | |
|--------------------|-------------------|
| Name | FR_CIDX_PCHANNELS |
| Initializer | 40U |

3.8.1.165 Define FR_CIDX_PCLUSTERDRIFTDAMPING**Table 3-167. Define FR_CIDX_PCLUSTERDRIFTDAMPING
Description**

| | |
|--------------------|------------------------------|
| Name | FR_CIDX_PCLUSTERDRIFTDAMPING |
| Initializer | 41U |

3.8.1.166 Define FR_CIDX_PDACCEPTEDSTARTUPRANGE**Table 3-168. Define FR_CIDX_PDACCEPTEDSTARTUPRANGE
Description**

| | |
|--------------------|--------------------------------|
| Name | FR_CIDX_PDACCEPTEDSTARTUPRANGE |
| Initializer | 16U |

3.8.1.167 Define FR_CIDX_PDECODINGCORRECTION

Table 3-169. Define FR_CIDX_PDECODINGCORRECTION Description

| | |
|-------------|-----------------------------|
| Name | FR_CIDX_PDECODINGCORRECTION |
| Initializer | 42U |

3.8.1.168 Define FR_CIDX_PDELAYCOMPENSATIONA

Table 3-170. Define FR_CIDX_PDELAYCOMPENSATIONA Description

| | |
|-------------|-----------------------------|
| Name | FR_CIDX_PDELAYCOMPENSATIONA |
| Initializer | 43U |

3.8.1.169 Define FR_CIDX_PDELAYCOMPENSATIONB

Table 3-171. Define FR_CIDX_PDELAYCOMPENSATIONB Description

| | |
|-------------|-----------------------------|
| Name | FR_CIDX_PDELAYCOMPENSATIONB |
| Initializer | 44U |

3.8.1.170 Define FR_CIDX_PDLISTENTIMEOUT

Table 3-172. Define FR_CIDX_PDLISTENTIMEOUT Description

| | |
|-------------|-------------------------|
| Name | FR_CIDX_PDLISTENTIMEOUT |
| Initializer | 2U |

3.8.1.171 Define FR_CIDX_PDMICROTICK

Table 3-173. Define FR_CIDX_PDMICROTICK Description

| | |
|-------------|---------------------|
| Name | FR_CIDX_PDMICROTICK |
| Initializer | 53U |

3.8.1.172 Define FR_CIDX_PEXTERNALSYNC**Table 3-174. Define FR_CIDX_PEXTERNALSYNC
Description**

| | |
|--------------------|-----------------------|
| Name | FR_CIDX_PEXTERNALSYNC |
| Initializer | 56U |

3.8.1.173 Define FR_CIDX_PFALLBACKINTERNAL**Table 3-175. Define FR_CIDX_PFALLBACKINTERNAL
Description**

| | |
|--------------------|---------------------------|
| Name | FR_CIDX_PFALLBACKINTERNAL |
| Initializer | 57U |

3.8.1.174 Define FR_CIDX_PKEYSLOTID**Table 3-176. Define FR_CIDX_PKEYSLOTID Description**

| | |
|--------------------|--------------------|
| Name | FR_CIDX_PKEYSLOTID |
| Initializer | 10U |

3.8.1.175 Define FR_CIDX_PKEYSLOTONLYENABLED**Table 3-177. Define FR_CIDX_PKEYSLOTONLYENABLED
Description**

| | |
|--------------------|-----------------------------|
| Name | FR_CIDX_PKEYSLOTONLYENABLED |
| Initializer | 58U |

3.8.1.176 Define FR_CIDX_PKEYSLOTUSEDFORSTARTUP**Table 3-178. Define FR_CIDX_PKEYSLOTUSEDFORSTARTUP
Description**

| | |
|--------------------|--------------------------------|
| Name | FR_CIDX_PKEYSLOTUSEDFORSTARTUP |
| Initializer | 59U |

3.8.1.177 Define FR_CIDX_PKEYSLOTUSEDFORSYNC

Table 3-179. Define FR_CIDX_PKEYSLOTUSEDFORSYNC
Description

| | |
|-------------|-----------------------------|
| Name | FR_CIDX_PKEYSLOTUSEDFORSYNC |
| Initializer | 60U |

3.8.1.178 Define FR_CIDX_PLATESTTX

Table 3-180. Define FR_CIDX_PLATESTTX Description

| | |
|-------------|-------------------|
| Name | FR_CIDX_PLATESTTX |
| Initializer | 11U |

3.8.1.179 Define FR_CIDX_PMACROINITIALOFFSETA

Table 3-181. Define FR_CIDX_PMACROINITIALOFFSETA
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_PMACROINITIALOFFSETA |
| Initializer | 45U |

3.8.1.180 Define FR_CIDX_PMACROINITIALOFFSETB

Table 3-182. Define FR_CIDX_PMACROINITIALOFFSETB
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_PMACROINITIALOFFSETB |
| Initializer | 46U |

3.8.1.181 Define FR_CIDX_PMICROINITIALOFFSETA

Table 3-183. Define FR_CIDX_PMICROINITIALOFFSETA
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_PMICROINITIALOFFSETA |
| Initializer | 47U |

3.8.1.182 Define FR_CIDX_PMICROINITIALOFFSETB**Table 3-184. Define FR_CIDX_PMICROINITIALOFFSETB
Description**

| | |
|--------------------|------------------------------|
| Name | FR_CIDX_PMICROINITIALOFFSETB |
| Initializer | 48U |

3.8.1.183 Define FR_CIDX_PMICROPERCYCLE**Table 3-185. Define FR_CIDX_PMICROPERCYCLE
Description**

| | |
|--------------------|------------------------|
| Name | FR_CIDX_PMICROPERCYCLE |
| Initializer | 1U |

3.8.1.184 Define FR_CIDX_PNMVECTOREARLYUPDATE**Table 3-186. Define FR_CIDX_PNMVECTOREARLYUPDATE
Description**

| | |
|--------------------|------------------------------|
| Name | FR_CIDX_PNMVECTOREARLYUPDATE |
| Initializer | 61U |

3.8.1.185 Define FR_CIDX_POFFSETCORRECTIONOUT**Table 3-187. Define FR_CIDX_POFFSETCORRECTIONOUT
Description**

| | |
|--------------------|------------------------------|
| Name | FR_CIDX_POFFSETCORRECTIONOUT |
| Initializer | 12U |

3.8.1.186 Define FR_CIDX_POFFSETCORRECTIONSTART**Table 3-188. Define FR_CIDX_POFFSETCORRECTIONSTART
Description**

| | |
|--------------------|--------------------------------|
| Name | FR_CIDX_POFFSETCORRECTIONSTART |
| Initializer | 13U |

3.8.1.187 Define FR_CIDX_PPAYLOADLENGTHDYNMAX

Table 3-189. Define FR_CIDX_PPAYLOADLENGTHDYNMAX
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_PPAYLOADLENGTHDYNMAX |
| Initializer | 49U |

3.8.1.188 Define FR_CIDX_PRATECORRECTIONOUT

Table 3-190. Define FR_CIDX_PRATECORRECTIONOUT Description

| | |
|-------------|----------------------------|
| Name | FR_CIDX_PRATECORRECTIONOUT |
| Initializer | 14U |

3.8.1.189 Define FR_CIDX_PSAMPLESPERMICROTICK

Table 3-191. Define FR_CIDX_PSAMPLESPERMICROTICK
Description

| | |
|-------------|------------------------------|
| Name | FR_CIDX_PSAMPLESPERMICROTICK |
| Initializer | 50U |

3.8.1.190 Define FR_CIDX_PSECONDKEYSLOTID

Table 3-192. Define FR_CIDX_PSECONDKEYSLOTID
Description

| | |
|-------------|--------------------------|
| Name | FR_CIDX_PSECONDKEYSLOTID |
| Initializer | 15U |

3.8.1.191 Define FR_CIDX_PTWOKEYSLOTMODE

Table 3-193. Define FR_CIDX_PTWOKEYSLOTMODE
Description

| | |
|-------------|-------------------------|
| Name | FR_CIDX_PTWOKEYSLOTMODE |
| Initializer | 62U |

3.8.1.192 Define FR_CIDX_PWAKEUPCHANNEL**Table 3-194. Define FR_CIDX_PWAKEUPCHANNEL
Description**

| | |
|--------------------|------------------------|
| Name | FR_CIDX_PWAKEUPCHANNEL |
| Initializer | 51U |

3.8.1.193 Define FR_CIDX_PWAKEUPPATTERN**Table 3-195. Define FR_CIDX_PWAKEUPPATTERN
Description**

| | |
|--------------------|------------------------|
| Name | FR_CIDX_PWAKEUPPATTERN |
| Initializer | 52U |

3.8.1.194 Define FR_CODE

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-196. Define FR_CODE Description

| | |
|--------------------|---------|
| Name | FR_CODE |
| Initializer | |

3.8.1.195 Define FR_CONST

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-197. Define FR_CONST Description

| | |
|-------------|----------|
| Name | FR_CONST |
|-------------|----------|

Table continues on the next page...

Table 3-197. Define FR_CONST Description (continued)

| | |
|-------------|--|
| Initializer | |
|-------------|--|

3.8.1.196 Define FR_SLOTMODE_SINGLE

This macro is used for backward compatibility with Autosar 3.0 definition of Fr_SlotModeType Covers FR599.

Implements: DFR32011

Table 3-198. Define FR_SLOTMODE_SINGLE Description

| | |
|-------------|----------------------|
| Name | FR_SLOTMODE_SINGLE |
| Initializer | FR_SLOTMODE_KEYSLLOT |

3.8.1.197 Define FR_VAR

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-199. Define FR_VAR Description

| | |
|-------------|--------|
| Name | FR_VAR |
| Initializer | |

3.8.1.198 Define FR_VAR_FAST

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-200. Define FR_VAR_FAST Description

| | |
|--------------------|-------------|
| Name | FR_VAR_FAST |
| Initializer | |

3.8.1.199 Define FR_VAR_NOINIT

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-201. Define FR_VAR_NOINIT Description

| | |
|--------------------|---------------|
| Name | FR_VAR_NOINIT |
| Initializer | |

3.8.1.200 Define FR_VAR_POWER_ON_INIT

FlexRay memory and pointer classes.

Implements: DBASE04001

Table 3-202. Define FR_VAR_POWER_ON_INIT Description

| | |
|--------------------|----------------------|
| Name | FR_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.201 Define GPT_CODE

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-203. Define GPT_CODE Description

| | |
|--------------------|----------|
| Name | GPT_CODE |
| Initializer | |

3.8.1.202 Define GPT_CONST

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-204. Define GPT_CONST Description

| | |
|--------------------|-----------|
| Name | GPT_CONST |
| Initializer | |

3.8.1.203 Define GPT_APPL_DATA

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-205. Define GPT_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | GPT_APPL_DATA |
| Initializer | |

3.8.1.204 Define GPT_APPL_CONST

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-206. Define GPT_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | GPT_APPL_CONST |
| Initializer | |

3.8.1.205 Define GPT_APPL_CODE

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-207. Define GPT_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | GPT_APPL_CODE |
| Initializer | |

3.8.1.206 Define GPT_CALLOUT_CODE

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-208. Define GPT_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | GPT_CALLOUT_CODE |
| Initializer | |

3.8.1.207 Define GPT_VAR_NOINIT

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-209. Define GPT_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | GPT_VAR_NOINIT |
| Initializer | |

3.8.1.208 Define GPT_VAR_POWER_ON_INIT

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-210. Define GPT_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | GPT_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.209 Define GPT_VAR_FAST

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-211. Define GPT_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | GPT_VAR_FAST |
| Initializer | |

3.8.1.210 Define GPT_VAR

GPT memory and pointer classes.

Implements: DBASE04001

Table 3-212. Define GPT_VAR Description

| | |
|--------------------|---------|
| Name | GPT_VAR |
| Initializer | |

3.8.1.211 Define ICU_CODE

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-213. Define ICU_CODE Description

| | |
|--------------------|----------|
| Name | ICU_CODE |
| Initializer | |

3.8.1.212 Define ICU_CONST

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-214. Define ICU_CONST Description

| | |
|--------------------|-----------|
| Name | ICU_CONST |
| Initializer | |

3.8.1.213 Define ICU_APPL_DATA

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-215. Define ICU_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | ICU_APPL_DATA |
| Initializer | |

3.8.1.214 Define ICU_APPL_CONST

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-216. Define ICU_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | ICU_APPL_CONST |
| Initializer | |

3.8.1.215 Define ICU_APPL_CODE

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-217. Define ICU_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | ICU_APPL_CODE |
| Initializer | |

3.8.1.216 Define ICU_CALLOUT_CODE

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-218. Define ICU_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | ICU_CALLOUT_CODE |
| Initializer | |

3.8.1.217 Define ICU_VAR_NOINIT

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-219. Define ICU_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | ICU_VAR_NOINIT |
| Initializer | |

3.8.1.218 Define ICU_VAR_POWER_ON_INIT

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-220. Define ICU_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | ICU_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.219 Define ICU_VAR_FAST

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-221. Define ICU_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | ICU_VAR_FAST |
| Initializer | |

3.8.1.220 Define ICU_VAR

ICU memory and pointer classes.

Implements: DBASE04001

Table 3-222. Define ICU_VAR Description

| | |
|--------------------|---------|
| Name | ICU_VAR |
| Initializer | |

3.8.1.221 Define LIN_CODE

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-223. Define LIN_CODE Description

| | |
|--------------------|----------|
| Name | LIN_CODE |
| Initializer | |

3.8.1.222 Define LIN_CONST

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-224. Define LIN_CONST Description

| | |
|--------------------|-----------|
| Name | LIN_CONST |
| Initializer | |

3.8.1.223 Define LIN_APPL_DATA

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-225. Define LIN_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | LIN_APPL_DATA |
| Initializer | |

3.8.1.224 Define LIN_APPL_CONST

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-226. Define LIN_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | LIN_APPL_CONST |
| Initializer | |

3.8.1.225 Define LIN_APPL_CODE

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-227. Define LIN_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | LIN_APPL_CODE |
| Initializer | |

3.8.1.226 Define LIN_CALLOUT_CODE

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-228. Define LIN_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | LIN_CALLOUT_CODE |
| Initializer | |

3.8.1.227 Define LIN_VAR_NOINIT

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-229. Define LIN_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | LIN_VAR_NOINIT |
| Initializer | |

3.8.1.228 Define LIN_VAR_POWER_ON_INIT

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-230. Define LIN_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | LIN_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.229 Define LIN_VAR_FAST

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-231. Define LIN_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | LIN_VAR_FAST |
| Initializer | |

3.8.1.230 Define LIN_VAR

LIN memory and pointer classes.

Implements: DBASE04001

Table 3-232. Define LIN_VAR Description

| | |
|--------------------|---------|
| Name | LIN_VAR |
| Initializer | |

3.8.1.231 Define MCEM_CODE

MCEM memory and pointer classes.

Implements:

Table 3-233. Define MCEM_CODE Description

| | |
|--------------------|-----------|
| Name | MCEM_CODE |
| Initializer | |

3.8.1.232 Define MCEM_CONST

MCEM memory and pointer classes.

Implements:

Table 3-234. Define MCEM_CONST Description

| | |
|--------------------|------------|
| Name | MCEM_CONST |
| Initializer | |

3.8.1.233 Define MCEM_APPL_DATA

MCEM memory and pointer classes.

Implements:

Table 3-235. Define MCEM_APPL_DATA Description

| | |
|--------------------|----------------|
| Name | MCEM_APPL_DATA |
| Initializer | |

3.8.1.234 Define MCEM_APPL_CONST

MCEM memory and pointer classes.

Implements:**Table 3-236. Define MCEM_APPL_CONST Description**

| | |
|--------------------|-----------------|
| Name | MCEM_APPL_CONST |
| Initializer | |

3.8.1.235 Define MCEM_APPL_CODE

MCEM memory and pointer classes.

Implements:**Table 3-237. Define MCEM_APPL_CODE Description**

| | |
|--------------------|----------------|
| Name | MCEM_APPL_CODE |
| Initializer | |

3.8.1.236 Define MCEM_CALLOUT_CODE

MCEM memory and pointer classes.

Implements:**Table 3-238. Define MCEM_CALLOUT_CODE Description**

| | |
|--------------------|-------------------|
| Name | MCEM_CALLOUT_CODE |
| Initializer | |

3.8.1.237 Define MCEM_VAR_NOINIT

MCEM memory and pointer classes.

Implements:

Table 3-239. Define MCEM_VAR_NOINIT Description

| | |
|--------------------|-----------------|
| Name | MCEM_VAR_NOINIT |
| Initializer | |

3.8.1.238 Define MCEM_VAR_POWER_ON_INIT

MCEM memory and pointer classes.

Implements:**Table 3-240. Define MCEM_VAR_POWER_ON_INIT Description**

| | |
|--------------------|------------------------|
| Name | MCEM_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.239 Define MCEM_VAR_FAST

MCEM memory and pointer classes.

Implements:**Table 3-241. Define MCEM_VAR_FAST Description**

| | |
|--------------------|---------------|
| Name | MCEM_VAR_FAST |
| Initializer | |

3.8.1.240 Define MCEM_VAR

MCEM memory and pointer classes.

Implements:**Table 3-242. Define MCEM_VAR Description**

| | |
|--------------------|----------|
| Name | MCEM_VAR |
| Initializer | |

3.8.1.241 Define MCL_CODE

MCL memory and pointer classes.

Implements:

Table 3-243. Define MCL_CODE Description

| | |
|--------------------|----------|
| Name | MCL_CODE |
| Initializer | |

3.8.1.242 Define MCL_CONST

MCL memory and pointer classes.

Implements:

Table 3-244. Define MCL_CONST Description

| | |
|--------------------|-----------|
| Name | MCL_CONST |
| Initializer | |

3.8.1.243 Define MCL_APPL_DATA

MCL memory and pointer classes.

Implements:

Table 3-245. Define MCL_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | MCL_APPL_DATA |
| Initializer | |

3.8.1.244 Define MCL_APPL_CONST

MCL memory and pointer classes.

Implements:

Table 3-246. Define MCL_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | MCL_APPL_CONST |
| Initializer | |

3.8.1.245 Define MCL_APPL_CODE

MCL memory and pointer classes.

Implements:

Table 3-247. Define MCL_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | MCL_APPL_CODE |
| Initializer | |

3.8.1.246 Define MCL_CALLOUT_CODE

MCL memory and pointer classes.

Implements:

Table 3-248. Define MCL_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | MCL_CALLOUT_CODE |
| Initializer | |

3.8.1.247 Define MCL_VAR_NOINIT

MCL memory and pointer classes.

Implements:**Table 3-249. Define MCL_VAR_NOINIT Description**

| | |
|--------------------|----------------|
| Name | MCL_VAR_NOINIT |
| Initializer | |

3.8.1.248 Define MCL_VAR_POWER_ON_INIT

MCL memory and pointer classes.

Implements:**Table 3-250. Define MCL_VAR_POWER_ON_INIT Description**

| | |
|--------------------|-----------------------|
| Name | MCL_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.249 Define MCL_VAR_FAST

MCL memory and pointer classes.

Implements:**Table 3-251. Define MCL_VAR_FAST Description**

| | |
|--------------------|--------------|
| Name | MCL_VAR_FAST |
| Initializer | |

3.8.1.250 Define MCL_VAR

MCL memory and pointer classes.

Implements:

Table 3-252. Define MCL_VAR Description

| | |
|--------------------|---------|
| Name | MCL_VAR |
| Initializer | |

3.8.1.251 Define MCU_CODE

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-253. Define MCU_CODE Description

| | |
|--------------------|----------|
| Name | MCU_CODE |
| Initializer | |

3.8.1.252 Define MCU_CONST

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-254. Define MCU_CONST Description

| | |
|--------------------|-----------|
| Name | MCU_CONST |
| Initializer | |

3.8.1.253 Define MCU_APPL_DATA

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-255. Define MCU_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | MCU_APPL_DATA |
| Initializer | |

3.8.1.254 Define MCU_APPL_CONST

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-256. Define MCU_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | MCU_APPL_CONST |
| Initializer | |

3.8.1.255 Define MCU_APPL_CODE

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-257. Define MCU_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | MCU_APPL_CODE |
| Initializer | |

3.8.1.256 Define MCU_CALLOUT_CODE

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-258. Define MCU_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | MCU_CALLOUT_CODE |
| Initializer | |

3.8.1.257 Define MCU_VAR_NOINIT

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-259. Define MCU_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | MCU_VAR_NOINIT |
| Initializer | |

3.8.1.258 Define MCU_VAR_POWER_ON_INIT

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-260. Define MCU_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | MCU_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.259 Define MCU_VAR_FAST

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-261. Define MCU_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | MCU_VAR_FAST |
| Initializer | |

3.8.1.260 Define MCU_VAR

MCU memory and pointer classes.

Implements: DBASE04001

Table 3-262. Define MCU_VAR Description

| | |
|--------------------|---------|
| Name | MCU_VAR |
| Initializer | |

3.8.1.261 Define PORT_CODE

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-263. Define PORT_CODE Description

| | |
|--------------------|-----------|
| Name | PORT_CODE |
| Initializer | |

3.8.1.262 Define PORT_CONST

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-264. Define PORT_CONST Description

| | |
|--------------------|------------|
| Name | PORT_CONST |
| Initializer | |

3.8.1.263 Define PORT_APPL_DATA

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-265. Define PORT_APPL_DATA Description

| | |
|--------------------|----------------|
| Name | PORT_APPL_DATA |
| Initializer | |

3.8.1.264 Define PORT_APPL_CONST

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-266. Define PORT_APPL_CONST Description

| | |
|--------------------|-----------------|
| Name | PORT_APPL_CONST |
| Initializer | |

3.8.1.265 Define PORT_APPL_CODE

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-267. Define PORT_APPL_CODE Description

| | |
|--------------------|----------------|
| Name | PORT_APPL_CODE |
| Initializer | |

3.8.1.266 Define PORT_CALLOUT_CODE

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-268. Define PORT_CALLOUT_CODE Description

| | |
|--------------------|-------------------|
| Name | PORT_CALLOUT_CODE |
| Initializer | |

3.8.1.267 Define PORT_VAR_NOINIT

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-269. Define PORT_VAR_NOINIT Description

| | |
|--------------------|-----------------|
| Name | PORT_VAR_NOINIT |
| Initializer | |

3.8.1.268 Define PORT_VAR_POWER_ON_INIT

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-270. Define PORT_VAR_POWER_ON_INIT Description

| | |
|--------------------|------------------------|
| Name | PORT_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.269 Define PORT_VAR_FAST

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-271. Define PORT_VAR_FAST Description

| | |
|--------------------|---------------|
| Name | PORT_VAR_FAST |
| Initializer | |

3.8.1.270 Define PORT_VAR

PORT memory and pointer classes.

Implements: DBASE04001

Table 3-272. Define PORT_VAR Description

| | |
|--------------------|----------|
| Name | PORT_VAR |
| Initializer | |

3.8.1.271 Define PWM_CODE

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-273. Define PWM_CODE Description

| | |
|--------------------|----------|
| Name | PWM_CODE |
| Initializer | |

3.8.1.272 Define PWM_CONST

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-274. Define PWM_CONST Description

| | |
|--------------------|-----------|
| Name | PWM_CONST |
| Initializer | |

3.8.1.273 Define PWM_APPL_DATA

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-275. Define PWM_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | PWM_APPL_DATA |
| Initializer | |

3.8.1.274 Define PWM_APPL_CONST

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-276. Define PWM_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | PWM_APPL_CONST |
| Initializer | |

3.8.1.275 Define PWM_APPL_CODE

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-277. Define PWM_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | PWM_APPL_CODE |
| Initializer | |

3.8.1.276 Define PWM_CALLOUT_CODE

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-278. Define PWM_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | PWM_CALLOUT_CODE |
| Initializer | |

3.8.1.277 Define PWM_VAR_NOINIT

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-279. Define PWM_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | PWM_VAR_NOINIT |
| Initializer | |

3.8.1.278 Define PWM_VAR_POWER_ON_INIT

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-280. Define PWM_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | PWM_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.279 Define PWM_VAR_FAST

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-281. Define PWM_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | PWM_VAR_FAST |
| Initializer | |

3.8.1.280 Define PWM_VAR

PWM memory and pointer classes.

Implements: DBASE04001

Table 3-282. Define PWM_VAR Description

| | |
|--------------------|---------|
| Name | PWM_VAR |
| Initializer | |

3.8.1.281 Define RAMTST_CODE

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-283. Define RAMTST_CODE Description

| | |
|--------------------|-------------|
| Name | RAMTST_CODE |
| Initializer | |

3.8.1.282 Define RAMTST_CONST

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-284. Define RAMTST_CONST Description

| | |
|--------------------|--------------|
| Name | RAMTST_CONST |
| Initializer | |

3.8.1.283 Define RAMTST_APPL_DATA

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-285. Define RAMTST_APPL_DATA Description

| | |
|--------------------|------------------|
| Name | RAMTST_APPL_DATA |
| Initializer | |

3.8.1.284 Define RAMTST_APPL_CONST

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-286. Define RAMTST_APPL_CONST Description

| | |
|--------------------|-------------------|
| Name | RAMTST_APPL_CONST |
| Initializer | |

3.8.1.285 Define RAMTST_APPL_CODE

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-287. Define RAMTST_APPL_CODE Description

| | |
|--------------------|------------------|
| Name | RAMTST_APPL_CODE |
| Initializer | |

3.8.1.286 Define RAMTST_CALLOUT_CODE

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-288. Define RAMTST_CALLOUT_CODE Description

| | |
|--------------------|---------------------|
| Name | RAMTST_CALLOUT_CODE |
| Initializer | |

3.8.1.287 Define RAMTST_VAR_NOINIT

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-289. Define RAMTST_VAR_NOINIT Description

| | |
|--------------------|-------------------|
| Name | RAMTST_VAR_NOINIT |
| Initializer | |

3.8.1.288 Define RAMTST_VAR_POWER_ON_INIT

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-290. Define RAMTST_VAR_POWER_ON_INIT Description

| | |
|--------------------|--------------------------|
| Name | RAMTST_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.289 Define RAMTST_VAR_FAST

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-291. Define RAMTST_VAR_FAST Description

| | |
|--------------------|-----------------|
| Name | RAMTST_VAR_FAST |
| Initializer | |

3.8.1.290 Define RAMTST_VAR

RamTST memory and pointer classes.

Implements: DBASE04001

Table 3-292. Define RAMTST_VAR Description

| | |
|--------------------|------------|
| Name | RAMTST_VAR |
| Initializer | |

3.8.1.291 Define SCHM_CODE

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-293. Define SCHM_CODE Description

| | |
|--------------------|-----------|
| Name | SCHM_CODE |
| Initializer | |

3.8.1.292 Define SCHM_CONST

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-294. Define SCHM_CONST Description

| | |
|--------------------|------------|
| Name | SCHM_CONST |
| Initializer | |

3.8.1.293 Define SCHM_APPL_DATA

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-295. Define SCHM_APPL_DATA Description

| | |
|--------------------|----------------|
| Name | SCHM_APPL_DATA |
| Initializer | |

3.8.1.294 Define SCHM_APPL_CONST

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-296. Define SCHM_APPL_CONST Description

| | |
|--------------------|-----------------|
| Name | SCHM_APPL_CONST |
| Initializer | |

3.8.1.295 Define SCHM_APPL_CODE

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-297. Define SCHM_APPL_CODE Description

| | |
|--------------------|----------------|
| Name | SCHM_APPL_CODE |
| Initializer | |

3.8.1.296 Define SCHM_CALLOUT_CODE

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-298. Define SCHM_CALLOUT_CODE Description

| | |
|--------------------|-------------------|
| Name | SCHM_CALLOUT_CODE |
| Initializer | |

3.8.1.297 Define SCHM_VAR_NOINIT

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-299. Define SCHM_VAR_NOINIT Description

| | |
|--------------------|-----------------|
| Name | SCHM_VAR_NOINIT |
| Initializer | |

3.8.1.298 Define SCHM_VAR_POWER_ON_INIT

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-300. Define SCHM_VAR_POWER_ON_INIT Description

| | |
|--------------------|------------------------|
| Name | SCHM_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.299 Define SCHM_VAR_FAST

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-301. Define SCHM_VAR_FAST Description

| | |
|--------------------|---------------|
| Name | SCHM_VAR_FAST |
| Initializer | |

3.8.1.300 Define SCHM_VAR

SchM memory and pointer classes.

Implements: DBASE04001

Table 3-302. Define SCHM_VAR Description

| | |
|--------------------|----------|
| Name | SCHM_VAR |
| Initializer | |

3.8.1.301 Define SPI_CODE

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-303. Define SPI_CODE Description

| | |
|--------------------|----------|
| Name | SPI_CODE |
| Initializer | |

3.8.1.302 Define SPI_CONST

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-304. Define SPI_CONST Description

| | |
|--------------------|-----------|
| Name | SPI_CONST |
| Initializer | |

3.8.1.303 Define SPI_APPL_DATA

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-305. Define SPI_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | SPI_APPL_DATA |
| Initializer | |

3.8.1.304 Define SPI_APPL_CONST

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-306. Define SPI_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | SPI_APPL_CONST |
| Initializer | |

3.8.1.305 Define SPI_APPL_CODE

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-307. Define SPI_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | SPI_APPL_CODE |
| Initializer | |

3.8.1.306 Define SPI_CALLOUT_CODE

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-308. Define SPI_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | SPI_CALLOUT_CODE |
| Initializer | |

3.8.1.307 Define SPI_VAR_NOINIT

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-309. Define SPI_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | SPI_VAR_NOINIT |
| Initializer | |

3.8.1.308 Define SPI_VAR_POWER_ON_INIT

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-310. Define SPI_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | SPI_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.309 Define SPI_VAR_FAST

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-311. Define SPI_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | SPI_VAR_FAST |
| Initializer | |

3.8.1.310 Define SPI_VAR

SPI memory and pointer classes.

Implements: DBASE04001

Table 3-312. Define SPI_VAR Description

| | |
|--------------------|---------|
| Name | SPI_VAR |
| Initializer | |

3.8.1.311 Define WDG_CODE

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-313. Define WDG_CODE Description

| | |
|--------------------|----------|
| Name | WDG_CODE |
| Initializer | |

3.8.1.312 Define WDG_CONST

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-314. Define WDG_CONST Description

| | |
|--------------------|-----------|
| Name | WDG_CONST |
| Initializer | |

3.8.1.313 Define WDG_APPL_DATA

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-315. Define WDG_APPL_DATA Description

| | |
|--------------------|---------------|
| Name | WDG_APPL_DATA |
| Initializer | |

3.8.1.314 Define WDG_APPL_CONST

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-316. Define WDG_APPL_CONST Description

| | |
|--------------------|----------------|
| Name | WDG_APPL_CONST |
| Initializer | |

3.8.1.315 Define WDG_APPL_CODE

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-317. Define WDG_APPL_CODE Description

| | |
|--------------------|---------------|
| Name | WDG_APPL_CODE |
| Initializer | |

3.8.1.316 Define WDG_CALLOUT_CODE

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-318. Define WDG_CALLOUT_CODE Description

| | |
|--------------------|------------------|
| Name | WDG_CALLOUT_CODE |
| Initializer | |

3.8.1.317 Define WDG_VAR_NOINIT

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-319. Define WDG_VAR_NOINIT Description

| | |
|--------------------|----------------|
| Name | WDG_VAR_NOINIT |
| Initializer | |

3.8.1.318 Define WDG_VAR_POWER_ON_INIT

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-320. Define WDG_VAR_POWER_ON_INIT Description

| | |
|--------------------|-----------------------|
| Name | WDG_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.319 Define WDG_VAR_FAST

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-321. Define WDG_VAR_FAST Description

| | |
|--------------------|--------------|
| Name | WDG_VAR_FAST |
| Initializer | |

3.8.1.320 Define WDG_VAR

WDG memory and pointer classes.

Implements: DBASE04001

Table 3-322. Define WDG_VAR Description

| | |
|--------------------|---------|
| Name | WDG_VAR |
| Initializer | |

3.8.1.321 Define WDGIF_CODE

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-323. Define WDGIF_CODE Description

| | |
|--------------------|------------|
| Name | WDGIF_CODE |
| Initializer | |

3.8.1.322 Define WDGIF_CONST

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-324. Define WDGIF_CONST Description

| | |
|--------------------|-------------|
| Name | WDGIF_CONST |
| Initializer | |

3.8.1.323 Define WDGIF_APPL_DATA

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-325. Define WDGIF_APPL_DATA Description

| | |
|--------------------|-----------------|
| Name | WDGIF_APPL_DATA |
| Initializer | |

3.8.1.324 Define WDGIF_APPL_CONST

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-326. Define WDGIF_APPL_CONST Description

| | |
|--------------------|------------------|
| Name | WDGIF_APPL_CONST |
| Initializer | |

3.8.1.325 Define WDGIF_APPL_CODE

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-327. Define WDGIF_APPL_CODE Description

| | |
|--------------------|-----------------|
| Name | WDGIF_APPL_CODE |
| Initializer | |

3.8.1.326 Define WDGIF_CALLOUT_CODE

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-328. Define WDGIF_CALLOUT_CODE Description

| | |
|--------------------|--------------------|
| Name | WDGIF_CALLOUT_CODE |
| Initializer | |

3.8.1.327 Define WDGIF_VAR_NOINIT

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-329. Define WDGIF_VAR_NOINIT Description

| | |
|--------------------|------------------|
| Name | WDGIF_VAR_NOINIT |
| Initializer | |

3.8.1.328 Define WDGIF_VAR_POWER_ON_INIT

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-330. Define WDGIF_VAR_POWER_ON_INIT Description

| | |
|--------------------|-------------------------|
| Name | WDGIF_VAR_POWER_ON_INIT |
| Initializer | |

3.8.1.329 Define WDGIF_VAR_FAST

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-331. Define WDGIF_VAR_FAST Description

| | |
|--------------------|----------------|
| Name | WDGIF_VAR_FAST |
| Initializer | |

3.8.1.330 Define WDGIF_VAR

WDGIF memory and pointer classes.

Implements: DBASE04001

Table 3-332. Define WDGIF_VAR Description

| | |
|--------------------|-----------|
| Name | WDGIF_VAR |
| Initializer | |

3.8.1.331 Define AUTOSAR_COMSTACKDATA

Define for ComStack Data.

Implements: DBASE04001

Table 3-333. Define AUTOSAR_COMSTACKDATA Description

| | |
|--------------------|----------------------|
| Name | AUTOSAR_COMSTACKDATA |
| Initializer | |

3.8.1.332 Define BUSTRCV_E_ERROR

Bus transceiver detected an unclassified error.

Details:

General return codes for BusTrcvErrorType

Implements: DBASE02012

Table 3-334. Define BUSTRCV_E_ERROR Description

| | |
|--------------------|-----------------|
| Name | BUSTRCV_E_ERROR |
| Initializer | 0x01 |

3.8.1.333 Define BUSTRCV_OK

There is no bus transceiver error seen or transceiver does not support the detection of bus errors.

Details:

General return codes for BusTrcvErrorType

Implements: DBASE02012

Table 3-335. Define BUSTRCV_OK Description

| | |
|--------------------|------------|
| Name | BUSTRCV_OK |
| Initializer | 0x00 |

3.8.1.334 Define COMSTACKTYPE_AR_RELEASE_MAJOR_VERSION

Table 3-336. Define COMSTACKTYPE_AR_RELEASE_MAJOR_VERSION Description

| | |
|--------------------|---------------------------------------|
| Name | COMSTACKTYPE_AR_RELEASE_MAJOR_VERSION |
| Initializer | 4 |

3.8.1.335 Define COMSTACKTYPE_AR_RELEASE_MINOR_VERSION**Table 3-337. Define COMSTACKTYPE_AR_RELEASE_MINOR_VERSION
Description**

| | |
|--------------------|---------------------------------------|
| Name | COMSTACKTYPE_AR_RELEASE_MINOR_VERSION |
| Initializer | 3 |

**3.8.1.336 Define
COMSTACKTYPE_AR_RELEASE_REVISION_VERSION****Table 3-338. Define COMSTACKTYPE_AR_RELEASE_REVISION_VERSION
Description**

| | |
|--------------------|--|
| Name | COMSTACKTYPE_AR_RELEASE_REVISION_VERSION |
| Initializer | 1 |

3.8.1.337 Define COMSTACKTYPE_SW_MAJOR_VERSION**Table 3-339. Define COMSTACKTYPE_SW_MAJOR_VERSION
Description**

| | |
|--------------------|-------------------------------|
| Name | COMSTACKTYPE_SW_MAJOR_VERSION |
| Initializer | 1 |

3.8.1.338 Define COMSTACKTYPE_SW_MINOR_VERSION**Table 3-340. Define COMSTACKTYPE_SW_MINOR_VERSION
Description**

| | |
|--------------------|-------------------------------|
| Name | COMSTACKTYPE_SW_MINOR_VERSION |
| Initializer | 0 |

3.8.1.339 Define COMSTACKTYPE_SW_PATCH_VERSION

Table 3-341. Define COMSTACKTYPE_SW_PATCH_VERSION Description

| | |
|--------------------|-------------------------------|
| Name | COMSTACKTYPE_SW_PATCH_VERSION |
| Initializer | 1 |

3.8.1.340 Define COMSTACKTYPE_VENDOR_ID

Parameters that shall be published within the standard types header file and also in the module's description file.

Implements: DBASE02013

Table 3-342. Define COMSTACKTYPE_VENDOR_ID Description

| | |
|--------------------|------------------------|
| Name | COMSTACKTYPE_VENDOR_ID |
| Initializer | 43 |

3.8.1.341 Define NTFRSLT_E_ABORT

Flow control (FC) N_PDU with FlowStatus = OVFLW received.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-343. Define NTFRSLT_E_ABORT Description

| | |
|--------------------|-----------------|
| Name | NTFRSLT_E_ABORT |
| Initializer | 0x09 |

3.8.1.342 Define NTFRSLT_E_CANCELATION_NOT_OK

Request cancellation has not been executed Due to an internal error the requested cancelation has not been executed. This will happen e.g. if the to be canceled transmission has been executed already.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-344. Define NTFRSLT_E_CANCELATION_NOT_OK
Description

| | |
|--------------------|------------------------------|
| Name | NTFRSLT_E_CANCELATION_NOT_OK |
| Initializer | 0x0C |

3.8.1.343 Define NTFRSLT_E_CANCELATION_OK

Requested cancellation has been executed.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-345. Define NTFRSLT_E_CANCELATION_OK
Description

| | |
|--------------------|--------------------------|
| Name | NTFRSLT_E_CANCELATION_OK |
| Initializer | 0x0B |

3.8.1.344 Define NTFRSLT_E_INVALID_FS

Invalid or unknown FlowStatus value has been received.

Details:

General return codes for NotifResultType

Implements: DBASE02011

**Table 3-346. Define NTFRSLT_E_INVALID_FS
Description**

| | |
|--------------------|----------------------|
| Name | NTFRSLT_E_INVALID_FS |
| Initializer | 0x06 |

3.8.1.345 Define NTFRSLT_E_NO_BUFFER

Indicates an abort of a transmission.

Details:

General return codes for NotifResultType

Implements: DBASE02011

**Table 3-347. Define NTFRSLT_E_NO_BUFFER
Description**

| | |
|--------------------|---------------------|
| Name | NTFRSLT_E_NO_BUFFER |
| Initializer | 0x0A |

3.8.1.346 Define NTFRSLT_E_NOT_OK

Message not successfully received or sent out.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-348. Define NTFRSLT_E_NOT_OK Description

| | |
|--------------------|------------------|
| Name | NTFRSLT_E_NOT_OK |
| Initializer | 0x01 |

3.8.1.347 Define NTFRSLT_E_PARAMETER_NOT_OK

The request for the change of the parameter did not complete successfully.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-349. Define NTFRSLT_E_PARAMETER_NOT_OK Description

| | |
|--------------------|----------------------------|
| Name | NTFRSLT_E_PARAMETER_NOT_OK |
| Initializer | 0x0E |

3.8.1.348 Define NTFRSLT_E_RX_ON

The parameter change request not executed successfully due to an ongoing reception.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-350. Define NTFRSLT_E_RX_ON Description

| | |
|--------------------|-----------------|
| Name | NTFRSLT_E_RX_ON |
| Initializer | 0x0F |

3.8.1.349 Define NTFRSLT_E_TIMEOUT_A

Timer N_Ar/N_As has passed its time-out value N_Asmx/N_Armax.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-351. Define NTFRSLT_E_TIMEOUT_A Description

| | |
|--------------------|---------------------|
| Name | NTFRSLT_E_TIMEOUT_A |
| Initializer | 0x02 |

3.8.1.350 Define NTFRSLT_E_TIMEOUT_BS

Timer N_Bs has passed its time-out value N_Bsmax.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-352. Define NTFRSLT_E_TIMEOUT_BS Description

| | |
|--------------------|----------------------|
| Name | NTFRSLT_E_TIMEOUT_BS |
| Initializer | 0x03 |

3.8.1.351 Define NTFRSLT_E_TIMEOUT_CR

Timer N_Cr has passed its time-out value N_Crmax.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-353. Define NTFRSLT_E_TIMEOUT_CR Description

| | |
|--------------------|----------------------|
| Name | NTFRSLT_E_TIMEOUT_CR |
| Initializer | 0x04 |

3.8.1.352 Define NTFRSLT_E_UNEXP_PDU

Unexpected protocol data unit received.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-354. Define NTFRSLT_E_UNEXP_PDU Description

| | |
|--------------------|---------------------|
| Name | NTFRSLT_E_UNEXP_PDU |
| Initializer | 0x07 |

3.8.1.353 Define NTFRSLT_E_VALUE_NOT_OK

The parameter change request not executed successfully due to a wrong value.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-355. Define NTFRSLT_E_VALUE_NOT_OK Description

| | |
|--------------------|------------------------|
| Name | NTFRSLT_E_VALUE_NOT_OK |
| Initializer | 0x10 |

3.8.1.354 Define NTFRSLT_E_WFT_OVRN

Flow control WAIT frame that exceeds the maximum counter N_WFTmax received.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-356. Define NTFRSLT_E_WFT_OVRN Description

| | |
|--------------------|--------------------|
| Name | NTFRSLT_E_WFT_OVRN |
| Initializer | 0x08 |

3.8.1.355 Define NTFRSLT_E_WRONG_SN

Unexpected sequence number (PCI.SN) value received.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-357. Define NTFRSLT_E_WRONG_SN Description

| | |
|--------------------|--------------------|
| Name | NTFRSLT_E_WRONG_SN |
| Initializer | 0x05 |

3.8.1.356 Define NTFRSLT_OK

Action has been successfully finished.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-358. Define NTFRSLT_OK Description

| | |
|--------------------|------------|
| Name | NTFRSLT_OK |
| Initializer | 0x00 |

3.8.1.357 Define NTFRSLT_PARAMETER_OK

The parameter change request has been successfully executed.

Details:

General return codes for NotifResultType

Implements: DBASE02011

Table 3-359. Define NTFRSLT_PARAMETER_OK Description

| | |
|--------------------|----------------------|
| Name | NTFRSLT_PARAMETER_OK |
| Initializer | 0x0D |

3.8.1.358 Define CONSTP2FUNC

The compiler abstraction for const pointer to function.

Implements: DBASE05031

Table 3-360. Define CONSTP2FUNC Description

| | |
|--------------------|---------------------------|
| Name | CONSP2FUNC |
| Initializer | rettype (* const fctname) |

3.8.1.359 Define EXIT_INTERRUPT

Compiler abstraction for returning from an ISR if no OS is present.

Implements: DBASE05006

Table 3-361. Define EXIT_INTERRUPT Description

| | |
|--------------------|--|
| Name | EXIT_INTERRUPT |
| Initializer | SuspendAllInterrupts(); *((volatile uint32*)((uint32)INTC_BASEADDR + (uint32)INTC_EOIR_OFFSET)) = 0U |

3.8.1.360 Define ISR

Compiler abstraction for creating an interrupt handler if no OS is present.

Implements: DBASE05016

Table 3-362. Define ISR Description

| | |
|--------------------|-----------------------------------|
| Name | ISR |
| Initializer | INTERRUPT_FUNC void IsrName(void) |

3.8.1.361 Define MCAL_AR_RELEASE_MAJOR_VERSION

Table 3-363. Define MCAL_AR_RELEASE_MAJOR_VERSION Description

| | |
|--------------------|-------------------------------|
| Name | MCAL_AR_RELEASE_MAJOR_VERSION |
| Initializer | 4 |

3.8.1.362 Define MCAL_AR_RELEASE_MINOR_VERSION

Table 3-364. Define MCAL_AR_RELEASE_MINOR_VERSION Description

| | |
|--------------------|-------------------------------|
| Name | MCAL_AR_RELEASE_MINOR_VERSION |
| Initializer | 3 |

3.8.1.363 Define MCAL_AR_RELEASE_REVISION_VERSION

Table 3-365. Define MCAL_AR_RELEASE_REVISION_VERSION Description

| | |
|--------------------|----------------------------------|
| Name | MCAL_AR_RELEASE_REVISION_VERSION |
| Initializer | 1 |

3.8.1.364 Define MCAL_MODULE_ID

Table 3-366. Define MCAL_MODULE_ID Description

| | |
|--------------------|----------------|
| Name | MCAL_MODULE_ID |
| Initializer | 0 |

3.8.1.365 Define MCAL_SW_MAJOR_VERSION**Table 3-367. Define MCAL_SW_MAJOR_VERSION
Description**

| | |
|--------------------|-----------------------|
| Name | MCAL_SW_MAJOR_VERSION |
| Initializer | 1 |

3.8.1.366 Define MCAL_SW_MINOR_VERSION**Table 3-368. Define MCAL_SW_MINOR_VERSION
Description**

| | |
|--------------------|-----------------------|
| Name | MCAL_SW_MINOR_VERSION |
| Initializer | 0 |

3.8.1.367 Define MCAL_SW_PATCH_VERSION**Table 3-369. Define MCAL_SW_PATCH_VERSION
Description**

| | |
|--------------------|-----------------------|
| Name | MCAL_SW_PATCH_VERSION |
| Initializer | 1 |

3.8.1.368 Define MCAL_VENDOR_ID**Table 3-370. Define MCAL_VENDOR_ID Description**

| | |
|--------------------|----------------|
| Name | MCAL_VENDOR_ID |
| Initializer | 43 |

3.8.1.369 Define P2P2CONST

The compiler abstraction for pointer to pointer to constant.

Implements: DBASE05026

Table 3-371. Define P2P2CONST Description

| | |
|--------------------|------------------|
| Name | P2P2CONST |
| Initializer | const ptrtype ** |

3.8.1.370 Define P2P2VAR

The compiler abstraction for pointer to pointer to variable.

Implements: DBASE05025

Table 3-372. Define P2P2VAR Description

| | |
|--------------------|------------|
| Name | P2P2VAR |
| Initializer | ptrtype ** |

3.8.1.371 Define ResumeAllInterrupts

Compiler abstraction for re-enabling all interrupts if no OS is present.

Implements: DBASE05020

Table 3-373. Define ResumeAllInterrupts Description

| | |
|--------------------|--------------------------|
| Name | ResumeAllInterrupts |
| Initializer | ASM_KEYWORD(" wrteei 1") |

3.8.1.372 Define STATIC

The compiler abstraction shall provide the STATIC define for abstraction of compiler keyword static. Keep here for backward compatibility. It has been removed from ASR4.0.

Implements: DBASE05030

Table 3-374. Define STATIC Description

| | |
|--------------------|--------|
| Name | STATIC |
| Initializer | static |

3.8.1.373 Define SuspendAllInterrupts

Compiler abstraction for disabling all interrupts if no OS is present.

Implements: DBASE05021

Table 3-375. Define SuspendAllInterrupts Description

| | |
|--------------------|--------------------------|
| Name | SuspendAllInterrupts |
| Initializer | ASM_KEYWORD(" wrteei 0") |

3.8.1.374 Define MEMMAP_VENDOR_ID

Parameters that shall be published within the memory map header file and also in the module's description file.

Implements: DBASE02002

Table 3-376. Define MEMMAP_VENDOR_ID Description

| | |
|--------------------|------------------|
| Name | MEMMAP_VENDOR_ID |
| Initializer | 43 |

3.8.1.375 Define MEMMAP_AR_RELEASE_MAJOR_VERSION

Parameters that shall be published within the memory map header file and also in the module's description file.

Implements: DBASE02002

**Table 3-377. Define MEMMAP_AR_RELEASE_MAJOR_VERSION
Description**

| | |
|--------------------|---------------------------------|
| Name | MEMMAP_AR_RELEASE_MAJOR_VERSION |
| Initializer | 4 |

3.8.1.376 Define MEMMAP_AR_RELEASE_MINOR_VERSION

Parameters that shall be published within the memory map header file and also in the module's description file.

Implements: DBASE02002

**Table 3-378. Define MEMMAP_AR_RELEASE_MINOR_VERSION
Description**

| | |
|--------------------|---------------------------------|
| Name | MEMMAP_AR_RELEASE_MINOR_VERSION |
| Initializer | 3 |

3.8.1.377 Define MEMMAP_AR_RELEASE_REVISION_VERSION

Parameters that shall be published within the memory map header file and also in the module's description file.

Implements: DBASE02002

**Table 3-379. Define MEMMAP_AR_RELEASE_REVISION_VERSION
Description**

| | |
|--------------------|------------------------------------|
| Name | MEMMAP_AR_RELEASE_REVISION_VERSION |
| Initializer | 1 |

3.8.1.378 Define MEMMAP_SW_MAJOR_VERSION

Parameters that shall be published within the memory map header file and also in the module's description file.

Implements: DBASE02002

**Table 3-380. Define MEMMAP_SW_MAJOR_VERSION
Description**

| | |
|--------------------|-------------------------|
| Name | MEMMAP_SW_MAJOR_VERSION |
| Initializer | 1 |

3.8.1.379 Define MEMMAP_SW_MINOR_VERSION

Parameters that shall be published within the memory map header file and also in the module's description file.

Implements: DBASE02002

**Table 3-381. Define MEMMAP_SW_MINOR_VERSION
Description**

| | |
|--------------------|-------------------------|
| Name | MEMMAP_SW_MINOR_VERSION |
| Initializer | 0 |

3.8.1.380 Define MEMMAP_SW_PATCH_VERSION

Parameters that shall be published within the memory map header file and also in the module's description file.

Implements: DBASE02002

**Table 3-382. Define MEMMAP_SW_PATCH_VERSION
Description**

| | |
|--------------------|-------------------------|
| Name | MEMMAP_SW_PATCH_VERSION |
| Initializer | 1 |

3.8.1.381 Define MEMMAP_ERROR

Symbol used for checking correctness of the includes.

Implements: DBASE02001

Table 3-383. Define MEMMAP_ERROR Description

| | |
|--------------------|--------------|
| Name | MEMMAP_ERROR |
| Initializer | |

3.8.1.382 Define CPU_BIT_ORDER

Bit order on register level.

Implements: DBASE08017

Table 3-384. Define CPU_BIT_ORDER Description

| | |
|--------------------|---------------|
| Name | CPU_BIT_ORDER |
| Initializer | (MSB_FIRST) |

3.8.1.383 Define CPU_BYTE_ORDER

The byte order on memory level shall be indicated in the platform types header file using the symbol CPU_BYTE_ORDER.

Implements: DBASE08018

Table 3-385. Define CPU_BYTE_ORDER Description

| | |
|--------------------|-------------------|
| Name | CPU_BYTE_ORDER |
| Initializer | (HIGH_BYTE_FIRST) |

3.8.1.384 Define CPU_TYPE

Processor type.

Implements: DBASE08019

Table 3-386. Define CPU_TYPE Description

| | |
|--------------------|---------------|
| Name | CPU_TYPE |
| Initializer | (CPU_TYPE_32) |

3.8.1.385 Define CPU_TYPE_16

16bit Type Processor

Implements: DBASE08020**Table 3-387. Define CPU_TYPE_16 Description**

| | |
|--------------------|-------------|
| Name | CPU_TYPE_16 |
| Initializer | 16 |

3.8.1.386 Define CPU_TYPE_32

32bit Type Processor

Implements: DBASE08021**Table 3-388. Define CPU_TYPE_32 Description**

| | |
|--------------------|-------------|
| Name | CPU_TYPE_32 |
| Initializer | 32 |

3.8.1.387 Define CPU_TYPE_8

8bit Type Processor

Implements: DBASE08022**Table 3-389. Define CPU_TYPE_8 Description**

| | |
|--------------------|------------|
| Name | CPU_TYPE_8 |
| Initializer | 8 |

3.8.1.388 Define FALSE

Boolean false value.

Implements: DBASE08023

Table 3-390. Define FALSE Description

| | |
|--------------------|-------|
| Name | FALSE |
| Initializer | 0 |

3.8.1.389 Define HIGH_BYTE_FIRST

HIGH_BYTE_FIRST Processor.

Implements: DBASE08024

Table 3-391. Define HIGH_BYTE_FIRST Description

| | |
|--------------------|-----------------|
| Name | HIGH_BYTE_FIRST |
| Initializer | 0 |

3.8.1.390 Define LOW_BYTE_FIRST

LOW_BYTE_FIRST Processor.

Implements: DBASE08025

Table 3-392. Define LOW_BYTE_FIRST Description

| | |
|--------------------|----------------|
| Name | LOW_BYTE_FIRST |
| Initializer | 1 |

3.8.1.391 Define LSB_FIRST

LSB First Processor.

Implements: DBASE08026

Table 3-393. Define LSB_FIRST Description

| | |
|--------------------|-----------|
| Name | LSB_FIRST |
| Initializer | 1 |

3.8.1.392 Define MSB_FIRST

MSB First Processor.

Implements: DBASE08027

Table 3-394. Define MSB_FIRST Description

| | |
|--------------------|-----------|
| Name | MSB_FIRST |
| Initializer | 0 |

3.8.1.393 Define PLATFORM_AR_RELEASE_MAJOR_VERSION

Table 3-395. Define PLATFORM_AR_RELEASE_MAJOR_VERSION Description

| | |
|--------------------|-----------------------------------|
| Name | PLATFORM_AR_RELEASE_MAJOR_VERSION |
| Initializer | 4 |

3.8.1.394 Define PLATFORM_AR_RELEASE_MINOR_VERSION

Table 3-396. Define PLATFORM_AR_RELEASE_MINOR_VERSION Description

| | |
|--------------------|-----------------------------------|
| Name | PLATFORM_AR_RELEASE_MINOR_VERSION |
| Initializer | 3 |

3.8.1.395 Define PLATFORM_AR_RELEASE_REVISION_VERSION

Table 3-397. Define PLATFORM_AR_RELEASE_REVISION_VERSION
Description

| | |
|-------------|--------------------------------------|
| Name | PLATFORM_AR_RELEASE_REVISION_VERSION |
| Initializer | 1 |

3.8.1.396 Define PLATFORM_SW_MAJOR_VERSION

Table 3-398. Define PLATFORM_SW_MAJOR_VERSION
Description

| | |
|-------------|---------------------------|
| Name | PLATFORM_SW_MAJOR_VERSION |
| Initializer | 1 |

3.8.1.397 Define PLATFORM_SW_MINOR_VERSION

Table 3-399. Define PLATFORM_SW_MINOR_VERSION
Description

| | |
|-------------|---------------------------|
| Name | PLATFORM_SW_MINOR_VERSION |
| Initializer | 0 |

3.8.1.398 Define PLATFORM_SW_PATCH_VERSION

Table 3-400. Define PLATFORM_SW_PATCH_VERSION
Description

| | |
|-------------|---------------------------|
| Name | PLATFORM_SW_PATCH_VERSION |
| Initializer | 1 |

3.8.1.399 Define PLATFORM_VENDOR_ID

Table 3-401. Define PLATFORM_VENDOR_ID Description

| | |
|-------------|--------------------|
| Name | PLATFORM_VENDOR_ID |
| Initializer | 43 |

3.8.1.400 Define TRUE

Boolean true value.

Implements: DBASE08035

Table 3-402. Define TRUE Description

| | |
|-------------|------|
| Name | TRUE |
| Initializer | 1 |

3.8.1.401 Define E_NOT_OK

Return code for failure/error.

Implements: DBASE12005

Table 3-403. Define E_NOT_OK Description

| | |
|-------------|----------|
| Name | E_NOT_OK |
| Initializer | 0x01 |

3.8.1.402 Define E_OK

Success return code.

Implements: DBASE12004

Table 3-404. Define E_OK Description

| | |
|-------------|------|
| Name | E_OK |
| Initializer | 0x00 |

3.8.1.403 Define STATUSTYPEDEFINED

Because E_OK is already defined within OSEK, the symbol E_OK has to be shared. To avoid name clashes and redefinition problems, the symbols have to be defined in the following way (approved within implementation).

Table 3-405. Define STATUSTYPEDEFINED Description

| | |
|--------------------|-------------------|
| Name | STATUSTYPEDEFINED |
| Initializer | |

3.8.1.404 Define STD_ACTIVE

Logical state active.

Implements: DBASE12008

Table 3-406. Define STD_ACTIVE Description

| | |
|--------------------|------------|
| Name | STD_ACTIVE |
| Initializer | 0x01 |

3.8.1.405 Define STD_HIGH

Physical state 5V or 3.3V.

Implements: DBASE12006

Table 3-407. Define STD_HIGH Description

| | |
|--------------------|----------|
| Name | STD_HIGH |
| Initializer | 0x01 |

3.8.1.406 Define STD_IDLE

Logical state idle.

Implements: DBASE12009

Table 3-408. Define STD_IDLE Description

| | |
|--------------------|----------|
| Name | STD_IDLE |
| Initializer | 0x00 |

3.8.1.407 Define STD_LOW

Physical state 0V.

Implements: DBASE12007

Table 3-409. Define STD_LOW Description

| | |
|--------------------|---------|
| Name | STD_LOW |
| Initializer | 0x00 |

3.8.1.408 Define STD_OFF

OFF state.

Implements: DBASE12011

Table 3-410. Define STD_OFF Description

| | |
|--------------------|---------|
| Name | STD_OFF |
| Initializer | 0x00 |

3.8.1.409 Define STD_ON

ON State.

Implements: DBASE12010

Table 3-411. Define STD_ON Description

| | |
|--------------------|--------|
| Name | STD_ON |
| Initializer | 0x01 |

3.8.1.410 Define STD_TYPES_AR_RELEASE_MAJOR_VERSION**Table 3-412. Define STD_TYPES_AR_RELEASE_MAJOR_VERSION Description**

| | |
|--------------------|------------------------------------|
| Name | STD_TYPES_AR_RELEASE_MAJOR_VERSION |
| Initializer | 4 |

3.8.1.411 Define STD_TYPES_AR_RELEASE_MINOR_VERSION**Table 3-413. Define STD_TYPES_AR_RELEASE_MINOR_VERSION Description**

| | |
|--------------------|------------------------------------|
| Name | STD_TYPES_AR_RELEASE_MINOR_VERSION |
| Initializer | 3 |

3.8.1.412 Define STD_TYPES_AR_RELEASE_REVISION_VERSION**Table 3-414. Define STD_TYPES_AR_RELEASE_REVISION_VERSION Description**

| | |
|--------------------|---------------------------------------|
| Name | STD_TYPES_AR_RELEASE_REVISION_VERSION |
| Initializer | 1 |

3.8.1.413 Define STD_TYPES_SW_MAJOR_VERSION**Table 3-415. Define STD_TYPES_SW_MAJOR_VERSION Description**

| | |
|--------------------|----------------------------|
| Name | STD_TYPES_SW_MAJOR_VERSION |
| Initializer | 1 |

3.8.1.414 Define STD_TYPES_SW_MINOR_VERSION**Table 3-416. Define STD_TYPES_SW_MINOR_VERSION
Description**

| | |
|--------------------|----------------------------|
| Name | STD_TYPES_SW_MINOR_VERSION |
| Initializer | 0 |

3.8.1.415 Define STD_TYPES_SW_PATCH_VERSION**Table 3-417. Define STD_TYPES_SW_PATCH_VERSION
Description**

| | |
|--------------------|----------------------------|
| Name | STD_TYPES_SW_PATCH_VERSION |
| Initializer | 1 |

3.8.1.416 Define STD_TYPES_VENDOR_ID

Parameters that shall be published within the standard types header file and also in the module's description file.

Implements: DBASE12012, DBASE12013, DBASE12014, DBASE12015, DBASE12016, DBASE12017, DBASE12018

Table 3-418. Define STD_TYPES_VENDOR_ID Description

| | |
|--------------------|---------------------|
| Name | STD_TYPES_VENDOR_ID |
| Initializer | 43 |

3.8.2 Enum Reference

Enumeration of all constants supported by the driver are as per AUTOSAR BASE Driver software specification Version 4.3 Rev0001 .

3.8.2.1 Enumeration Can_ReturnType

Can_ReturnType.

Details:

CAN Return Types from Functions.

Implements: DCAN02414

Table 3-419. Enumeration Can_ReturnType Values

| Name | Initializer | Description |
|------------|-------------|---|
| CAN_OK | 0U | Operation was ok executed. |
| CAN_NOT_OK | | Operation was not ok executed. |
| CAN_BUSY | | Operation was rejected because of busy state. |

3.8.2.2 Enumeration Can_StateTransitionType

CAN State Modes of operation.

Details:

State transitions that are used by the function CAN_SetControllerMode().

Implements: DCAN02415

Table 3-420. Enumeration Can_StateTransitionType Values

| Name | Initializer | Description |
|--------------|-------------|---------------------------------------|
| CAN_T_STOP | 0U | CANIF_CS_STARTED -> CANIF_CS_STOPPED. |
| CAN_T_START | | CANIF_CS_STOPPED -> CANIF_CS_STARTED. |
| CAN_T_SLEEP | | CANIF_CS_STOPPED -> CANIF_CS_SLEEP. |
| CAN_T_WAKEUP | | CANIF_CS_SLEEP -> CANIF_CS_STOPPED. |

3.8.2.3 Enumeration CanIf_ControllerModeType

CanIf_ControllerModeType.

Details:

Operating modes of the CAN Controller and CAN Driver

Table 3-421. Enumeration CanIf_ControllerModeType Values

| Name | Initializer | Description |
|------------------|-------------|---------------|
| CANIF_CS_UNINIT | 0U | UNINIT mode. |
| CANIF_CS_SLEEP | | SLEEP mode. |
| CANIF_CS_STARTED | | STARTED mode. |
| CANIF_CS_STOPPED | | STOPPED mode. |

3.8.2.4 Enumeration Eth_FilterActionType

Action type for PHY address filtering.

Details:

The Enumeration type describes the action to be taken for the MAC address given in *PhysAddrPtr

Table 3-422. Enumeration Eth_FilterActionType Values

| Name | Initializer | Description |
|------------------------|-------------|----------------------------|
| ETH_ADD_TO_FILTER | 0 | Add address to the filter. |
| ETH_REMOVE_FROM_FILTER | | Remove address. |

3.8.2.5 Enumeration Eth_ModeType

The Ethernet controller mode.

Details:

This type is used to store the information whether the Ethernet controller is stopped or running.

Table 3-423. Enumeration Eth_ModeType Values

| Name | Initializer | Description |
|-----------------|-------------|--------------------------|
| ETH_MODE_DOWN | 0 | Controller is shut down. |
| ETH_MODE_ACTIVE | | Controller is active. |

3.8.2.6 Enumeration Eth_ReturnType

The Ethernet specific return type.

Details:

This return type informs about the function success/failure status.

Table 3-424. Enumeration Eth_ReturnType Values

| Name | Initializer | Description |
|-----------------|-------------|-----------------------------------|
| ETH_OK | 0 | Success. |
| ETH_E_NOT_OK | | General failure. |
| ETH_E_NO_ACCESS | | Ethernet hardware access failure. |

3.8.2.7 Enumeration Eth_RxStatusType

The Ethernet reception status.

Details:

This status is returned by theEth_Receive()function to indicate whether any frame has been received and if yes, whether there is any frame still waiting in the queue (for anotherEth_Receive()call).

Table 3-425. Enumeration Eth_RxStatusType Values

| Name | Initializer | Description |
|------------------|-------------|--|
| ETH_RECEIVED | 0 | A frame has been received and there are no more frames in the queue. |
| ETH_NOT_RECEIVED | | No frames received. |

Table continues on the next page...

Table 3-425. Enumeration Eth_RxStatusType Values (continued)

| Name | Initializer | Description |
|----------------------------------|-------------|--|
| ETH_RECEIVED_MORE_DATA_AVAILABLE | | A frame received and at least another one in the queue detected. |
| ETH_RECEIVED_FRAMES_LOST | | Ethernet frame has been received, some frames got lost. |

3.8.2.8 Enumeration Eth_StateType

The Ethernet driver state.

Details:

A variable of this type holds the state of the Ethernet driver module. The driver is at the ETH_STATE_UNINIT at the beginning until the Eth_Init() function is called. The state remains equal to the ETH_STATE_INIT until the Eth_ControllerInit() function is called. Then the state is ETH_STATE_ACTIVE.

Table 3-426. Enumeration Eth_StateType Values

| Name | Initializer | Description |
|------------------|-------------|---|
| ETH_STATE_UNINIT | 0 | The driver has not been initialized yet. |
| ETH_STATE_INIT | | The driver has not been configured but the controller has not been initialized yet. |
| ETH_STATE_ACTIVE | | The driver was initialized and the controller was configured. |

3.8.2.9 Enumeration Fr_ChannelType

Details:

This type is used to select the channel.

Implements: DFR32001

Table 3-427. Enumeration Fr_ChannelType Values

| Name | Initializer | Description |
|---------------|-------------|-------------|
| FR_CHANNEL_A | 0U | |
| FR_CHANNEL_B | | |
| FR_CHANNEL_AB | | |

3.8.2.10 Enumeration Fr_ErrorModeType

Variables of this type are used for storage of FlexRay controller error mode.

Implements: DFR32009

Table 3-428. Enumeration Fr_ErrorModeType Values

| Name | Initializer | Description |
|------------------------|-------------|-------------|
| FR_ERRORMODE_ACTIVE | 0U | |
| FR_ERRORMODE_PASSIVE | | |
| FR_ERRORMODE_COMM_HALT | | |

3.8.2.11 Enumeration Fr_POCStateType

Details:

Variables of this type are used to store the POC:state of the controller.

Implements: DFR32007

Table 3-429. Enumeration Fr_POCStateType Values

| Name | Initializer | Description |
|----------------------------|-------------|-------------|
| FR_POCSTATE_CONFIG | 0U | |
| FR_POCSTATE_DEFAULT_CONFIG | | |
| FR_POCSTATE_HALT | | |
| FR_POCSTATE_NORMAL_ACTIVE | | |
| FR_POCSTATE_NORMAL_PASSIVE | | |
| FR_POCSTATE_READY | | |
| FR_POCSTATE_STARTUP | | |
| FR_POCSTATE_WAKEUP | | |

3.8.2.12 Enumeration Fr_RxLPduStatusType

Transmit resource status is stored to variable of this type.

Implements: DFR32003

Table 3-430. Enumeration Fr_RxLPduStatusType Values

| Name | Initializer | Description |
|---------------------------------|-------------|-------------|
| FR_RECEIVED | 0U | |
| FR_NOT_RECEIVED | | |
| FR_RECEIVED_MORE_DATA_AVAILABLE | | |

3.8.2.13 Enumeration Fr_SlotModeType

This type is used to store the slot mode of the controller.

Details:

Covers FR506

Implements: DFR32008

Table 3-431. Enumeration Fr_SlotModeType Values

| Name | Initializer | Description |
|-------------------------|-------------|-------------|
| FR_SLOTMODE_KEYSLLOT | 0U | |
| FR_SLOTMODE_ALL_PENDING | | |
| FR_SLOTMODE_ALL | | |

3.8.2.14 Enumeration Fr_StartupStateType

Details:

Variable of this type is used to query the FlexRay controller Startup state.

Implements: DFR32004

Table 3-432. Enumeration Fr_StartupStateType Values

| Name | Initializer | Description |
|---|-------------|-------------|
| FR_STARTUP_UNDEFINED | 0U | |
| FR_STARTUP_COLDSTART_LISTEN | | |
| FR_STARTUP_INTEGRATION_COLDSTART_CHECK | | |
| FR_STARTUP_COLDSTART_JOIN | | |
| FR_STARTUP_COLDSTART_COLLISION_RESOLUTION | | |
| FR_STARTUP_COLDSTART_CONSISTENCY_CHECK | | |
| FR_STARTUP_INTEGRATION_LISTEN | | |
| FR_STARTUP_INITIALIZE_SCHEDULE | | |
| FR_STARTUP_INTEGRATION_CONSISTENCY_CHECK | | |
| FR_STARTUP_COLDSTART_GAP | | |

3.8.2.15 Enumeration Fr_TxLPduStatusType

Transmit resource status is stored to variable of this type.

Implements: DFR32005

Table 3-433. Enumeration Fr_TxLPduStatusType Values

| Name | Initializer | Description |
|--------------------|-------------|-------------|
| FR_TRANSMITTED | 0U | |
| FR_NOT_TRANSMITTED | | |

3.8.2.16 Enumeration Fr_WakeupStatusType

Details:

Variable of this type is used to query the FlexRay controller Wakeup status.

Implements: DFR32006

Table 3-434. Enumeration Fr_WakeupStatusType Values

| Name | Initializer | Description |
|-----------------------------|-------------|-------------|
| FR_WAKEUP_UNDEFINED | 0U | |
| FR_WAKEUP_RECEIVED_HEADER | | |
| FR_WAKEUP_RECEIVED_WUP | | |
| FR_WAKEUP_COLLISION_HEADER | | |
| FR_WAKEUP_COLLISION_WUP | | |
| FR_WAKEUP_COLLISION_UNKNOWN | | |
| FR_WAKEUP_TRANSMITTED | | |

3.8.2.17 Enumeration BufReq_ReturnType

Variables of this type are used to store the result of a buffer request.

Implements: DBASE02009

Table 3-435. Enumeration BufReq_ReturnType Values

| Name | Initializer | Description |
|-----------------|-------------|---|
| BUFREQ_OK | 0 | Buffer request accomplished successful. |
| BUFREQ_E_NOT_OK | 1 | Buffer request not successful. Buffer cannot be accessed. |
| BUFREQ_E_BUSY | 2 | Temporarily no buffer available. It's up the requestor to retry request for a certain time. |
| BUFREQ_E_OVFL | 3 | No Buffer of the required length can be provided. |

3.8.2.18 Enumeration TpDataStateType

Variables of this type shall be used to store the state of TP buffer.

Implements: DBASE02010

Table 3-436. Enumeration TpDataStateType Values

| Name | Initializer | Description |
|----------------|-------------|---|
| TP_DATACONF | 0 | Indicates that all data, that have been copied so far, are confirmed and can be removed from the TP buffer. |
| TP_DATARETRY | 1 | Indicates that this API call shall copy already copied data in order to recover from an error. |
| TP_CONFPENDING | 2 | Indicates that the previously copied data must remain in the TP. |
| TP_NORETRY | 3 | Indicate that the copied transmit data can be removed from the buffer after it has been copied. |

3.8.2.19 Enumeration TPParameterType

Specify the parameter to which the value has to be changed (BS or STmin)

Implements: DBASE02008

Table 3-437. Enumeration TPParameterType Values

| Name | Initializer | Description |
|----------|-------------|---|
| TP_STMIN | 0 | Separation Time. |
| TP_BS | 1 | Block Size. |
| TP_BC | 2 | Band width control parameter used in FlexRay transport protocol module. |

3.8.2.20 Enumeration Lin_FrameCsModelType

Checksum models for the LIN Frame.

Details:

This type is used to specify the Checksum model to be used for the LIN Frame.

Implements: DLIN05031

Table 3-438. Enumeration Lin_FrameCsModelType Values

| Name | Initializer | Description |
|-----------------|-------------|--------------------------|
| LIN_ENHANCED_CS | | Enhanced checksum model. |
| LIN_CLASSIC_CS | | Classic checksum model. |

3.8.2.21 Enumeration Lin_FrameResponseType

Frame response types.

Details:

This type is used to specify whether the frame processor is required to transmit the response part of the LIN frame.

Implements: DLIN05034

Table 3-439. Enumeration Lin_FrameResponseType Values

| Name | Initializer | Description |
|---------------------|-------------|--|
| LIN_MASTER_RESPONSE | | Response is generated from this (master) node. |
| LIN_SLAVE_RESPONSE | | Response is generated from a remote slave node. |
| LIN_SLAVE_TO_SLAVE | | Response is generated from one slave to another slave. For the master the response will be anonymous, it does not have to receive the response. |

3.8.2.22 Enumeration Lin_StatusType

LIN Frame and Channel states operation.

Details:

LIN operation states for a LIN channel or frame, as returned by the API service Lin_GetStatus(). part of the LIN frame.

Implements: DLIN05036

Table 3-440. Enumeration Lin_StatusType Values

| Name | Initializer | Description |
|---------------------|-------------|--|
| LIN_NOT_OK | 0 | Development or production error occurred. |
| LIN_TX_OK | | Successful transmission. |
| LIN_TX_BUSY | | Ongoing transmission (Header or Response). |
| LIN_TX_HEADER_ERROR | | Erroneous header transmission such as:. |
| LIN_TX_ERROR | | Erroneous transmission such as:. |
| LIN_RX_OK | | Reception of correct response. |
| LIN_RX_BUSY | | Ongoing reception: at least one response byte has been received, but the checksum byte has not been received. |
| LIN_RX_ERROR | | Erroneous reception such as:. |
| LIN_RX_NO_RESPONSE | | No response byte has been received so far. This is a mess !! Frame status is mixed with channel status but i kept it here only because of LIN168. |
| LIN_OPERATIONAL | | Normal operation;. |
| LIN_CH_SLEEP | | Sleep mode operation;. |

3.8.3 Function Reference

Functions of all functions supported by the driver are as per AUTOSAR BASE Driver software specification Version 4.3 Rev0001 .

3.8.4 Structs Reference

Data structures supported by the driver are as per AUTOSAR BASE Driver software specification Version 4.3 Rev0001 .

3.8.4.1 Structure Can_PduType

Can_PduType.




Figure 3-1. Struct Can_PduType

Details:

Type used to provide ID, DLC, SDU from CAN interface to CAN driver. $HTH/HRH = ID + DLC + SDU$.

Implements: DCAN02417

Declaration:

```
typedef struct
{
    Can_IdType id,
    uint8 length,
    uint8* sdu,
    PduIdType swPduHandle
} Can_PduType;
```

Table 3-441. Structure Can_PduType member description

| Member | Description |
|-------------|--|
| id | CAN L-PDU = Data Link Layer Protocol Data Unit. Consists of Identifier, DLC and Data(SDU) It is uint32 for CAN_EXTENDEDID=STD_ON, else is uint16. |
| length | DLC = Data Length Code (part of L-PDU that describes the SDU length). |
| sdu | CAN L-SDU = Link Layer Service Data Unit. Data that is transported inside the L-PDU. |
| swPduHandle | The L-PDU Handle = defined and placed inside the CanIf module layer. Each handle represents an L-PDU, which is a constant structure with information for Tx/Rx processing. |

3.8.4.2 Structure Fr_POCTestStatusType

Variables of this type are used to query the flexRay controller status.




Figure 3-2. Struct Fr_POCStatusType

Implements: DFR32002

Declaration:

```
typedef struct
{
    boolean CHIHaltRequest,
        boolean ColdstartNoise,
        Fr_ErrorModeType ErrorMode,
        boolean Freeze,
        Fr_SlotModeType SlotMode,
        Fr_StartupStateType StartupState,
        Fr_POCStateType State,
        Fr_WakeupStatusType WakeupStatus
} Fr_POCStatusType;
```

Table 3-442. Structure Fr_POCStatusType member description

| Member | Description |
|----------------|--|
| CHIHaltRequest | TRUE means that noise detected on bus during startup |
| ColdstartNoise | TRUE means that there is pending halt request |
| ErrorMode | TRUE means that internal error causing transition to the POC:Halt state or FREEZE command occurred |
| Freeze | Contains FlexRay controller slot mode |
| SlotMode | Contains FlexRay controller wakeup status |
| StartupState | Contains FlexRay controller error mode |
| State | Contains FlexRay controller startup state |
| WakeupStatus | Contains FlexRay controller POC state |

3.8.4.3 Structure Lin_PduType

The LIN identifier (0..0x3F) with its parity bits.




Figure 3-3. Struct Lin_PduType

Details:

This Type is used to provide PID, checksum model, data length and SDU pointer from the LIN Interface to the LIN driver.

Implements: DLIN05035

Declaration:

```
typedef struct
{
    Lin_FrameCsModelType Cs,
    Lin_FrameDlType Dl,
    Lin_FrameResponseType Drc,
    Lin_FramePidType Pid,
    uint8* SduPtr
} Lin_PduType;
```

Table 3-443. Structure Lin_PduType member description

| Member | Description |
|--------|-----------------------|
| Cs | Checksum model type. |
| Dl | Data length. |
| Drc | Response type. |
| Pid | LIN frame identifier. |
| SduPtr | Pointer to Sdu. |

3.8.4.4 Structure Mcal_DemErrorType

Typedef for DEM error management implemented by MCAL drivers.




Figure 3-4. Struct Mcal_DemErrorType

Implements: DBASE05032

Declaration:

```
typedef struct
{
    uint32 id,
    uint32 state
} Mcal_DemErrorType;
```

Table 3-444. Structure Mcal_DemErrorType member description

| Member | Description |
|--------|---|
| id | enabling/disabling the DEM error: Active=STD_ON/ Inactive=STD_OFF |
| state | ID of DEM error (0 if STD_OFF) |

3.8.4.5 Structure PduInfoType

Variables of this type are used to store the basic information about a PDU of any type, namely a pointer variable pointing to it's SDU (payload), and the corresponding length of the SDU in bytes.




Figure 3-5. Struct PduInfoType

Implements: DBASE02006

Declaration:

```
typedef struct
{
    uint8* SduDataPtr,
        PduLengthType SduLength
} PduInfoType;
```

Table 3-445. Structure PduInfoType member description

| Member | Description |
|------------|---|
| SduDataPtr | pointer to the SDU (i.e. payload data) of the PDU |
| SduLength | length of the SDU in bytes |

3.8.4.6 Structure RetryInfoType

Variables of this type shall be used to store the information about Tp buffer handling.




Figure 3-6. Struct RetryInfoType

Implements: DBASE02007

Declaration:


```
typedef struct
{
    TpDataStateType TpDataState,
    PduLengthType TxTpDataCnt
} RetryInfoType;
```

Table 3-446. Structure RetryInfoType member description

| Member | Description |
|-------------|--|
| TpDataState | The enum type to be used to store the state of Tp buffer |
| TxTpDataCnt | length of the SDU in bytes |

3.8.4.7 Structure Std_VersionInfoType

This type shall be used to request the version of a BSW module using the "ModuleName"_GetVersionInfo() function.

**Figure 3-7. Struct Std_VersionInfoType**

Implements: DBASE12003

Declaration:

```
typedef struct
{
    uint16 moduleID,
    uint8 sw_major_version,
    uint8 sw_minor_version,
    uint8 sw_patch_version,
    uint16 vendorID
} Std_VersionInfoType;
```

Table 3-447. Structure Std_VersionInfoType member description

| Member | Description |
|------------------|-------------|
| moduleID | 0 |
| sw_major_version | 1 |
| sw_minor_version | 0 |
| sw_patch_version | 2 |
| vendorID | 43 |

3.8.5 Types Reference

Types supported by the driver are as per AUTOSAR BASE Driver software specification Version 4.3 Rev0001 .

3.8.5.1 Typedef Can_IdType

Can_IdType.

Details:

Type for storing the Identifier Length Type: Normal /Extended.

- used by "Can_MessageBufferConfigObjectType" structure. The driver does not distinguish between Extended and Mixed transmission modes. Extended transmission mode of operation behaves the same as Mixed mode.

Implements: DCAN02420

Type: uint16

3.8.5.2 Typedef Can_HwHandleType

Can_HwHandleType.

Details:

Represents the hardware object handles of a CAN hardware unit. For CAN hardware units with more than 255 HW objects use extended range.

- used by "Can_Write" function. The driver does not distinguish between Extended and Mixed transmission modes. Extended transmission mode of operation behaves the same as Mixed mode.

Implements: DCAN02421

Type: uint16

3.8.5.3 Typedef Eth_DataType

Type used to pass transmit/receive data to/from the driver.

Details:

This type was defined as 8 bit wide unsigned integer because this definition is available on all CPU types.

Type: uint8

3.8.5.4 Typedef Eth_FrameType

Frame type.

Details:

This type is used to pass the value of type/length field in the Ethernet frame header. It is 16 bits long unsigned integer.

- Values less than or equal to 1500 represent the length.
- Values greater than 1500 represent the type (i.e. 0x800 = IP).

Type: uint16

3.8.5.5 Typedef PduldType

This type serve as a unique identifier of a PDU within a software module. Allowed ranges: uint8 .. uint16.

Implements: DBASE02002

Type: uint32

3.8.5.6 Typedef PduLengthType

This type serve as length information of a PDU in bytes. Allowed ranges: uint8 .. uint32.

Implements: DBASE02002

Type: uint32

3.8.5.7 Typedef BusTrcvErrorType

Variables of this type are used to return the bus status evaluated by a transceiver.

Implements: DBASE02005

Type: uint8

3.8.5.8 Typedef NetworkHandleType

Variables of the type NetworkHandleType are used to store the identifier of a communication channel.

Implements: DBASE02004

Type: uint8

3.8.5.9 Typedef NotifResultType

Variables of this type are used to store the result status of a notification (confirmation or indication).

Implements: DBASE02003

Type: uint8

3.8.5.10 Typedef Lin_FrameDlType

Data length of a LIN Frame.

Details:

This type is used to specify the number of SDU data bytes to copy.

Implements: DLIN05032

Type: uint8

3.8.5.11 Typedef Lin_FramePidType

The LIN identifier (0..0x3F) with its parity bits.

Details:

Represents all valid protected Identifier used by Lin_SendHeader().

Implements: DLIN05033

Type: uint8

3.8.5.12 Typedef boolean

The standard AUTOSAR type boolean shall be implemented on basis of an eight bits long unsigned integer.

Implements: DBASE08002

Type: unsigned char

3.8.5.13 Typedef float32

32bit long floating point data type

Implements: DBASE08015

Type: float

3.8.5.14 Typedef float64

64bit long floating point data type

Implements: DBASE08016

Type: double

3.8.5.15 Typedef sint16

Signed 16 bit integer with range of -32768 ..+32767 (0x8000..0x7FFF) - 15 bit + 1 sign bit.

Implements: DBASE08007

Type: signed short

3.8.5.16 Typedef sint16_least

Signed integer at least 16 bit long. Range - at least -32768 ..+32767. At least 15 bit + 1 bit sign.

Implements: DBASE08013

Type: signed long

3.8.5.17 Typedef sint32

Signed 32 bit integer with range of -2147483648.. +2147483647 (0x80000000..0x7FFFFFFF) - 31 bit + 1 sign bit.

Implements: DBASE08008

Type: signed long

3.8.5.18 Typedef sint32_least

Signed integer at least 32 bit long. Range - at least -2147483648.. +2147483647. At least 31 bit + 1 bit sign.

Implements: DBASE08014

Type: signed long

3.8.5.19 Typedef sint8

Signed 8 bit integer with range of -128 ..+127 (0x80..0x7F) - 7 bit + 1 sign bit.

Implements: DBASE08006

Type: signed char

3.8.5.20 Typedef sint8_least

Signed integer at least 8 bit long. Range - at least -128 ..+127. At least 7 bit + 1 bit sign.

Implements: DBASE08012

Type: signed long

3.8.5.21 Typedef uint16

Unsigned 16 bit integer with range of 0 ..+65535 (0x0000..0xFFFF) - 16 bit.

Implements: DBASE08004

Type: unsigned short

3.8.5.22 Typedef uint16_least

Unsigned integer at least 16 bit long. Range of at least 0 ..+65535 (0x0000..0xFFFF) - 16 bit.

Implements: DBASE08010

Type: unsigned long

3.8.5.23 Typedef uint32

Unsigned 32 bit integer with range of 0 ..+4294967295 (0x00000000..0xFFFFFFFF) - 32 bit.

Implements: DBASE08005

Type: unsigned long

3.8.5.24 Typedef uint32_least

Unsigned integer at least 32 bit long. Range of at least 0 ..+4294967295 (0x00000000..0xFFFFFFFF) - 32 bit.

Implements: DBASE08011

Type: unsigned long

3.8.5.25 Typedef uint8

Unsigned 8 bit integer with range of 0 ..+255 (0x00..0xFF) - 8 bit.

Implements: DBASE08003

Type: unsigned char

3.8.5.26 Typedef uint8_least

Unsigned integer at least 8 bit long. Range of at least 0 ..+255 (0x00..0xFF) - 8 bit.

Implements: DBASE08009

Type: unsigned long

3.8.5.27 Typedef StatusType

This type is defined for OSEK compliance.

Implements: DBASE12001

Type: unsigned char

3.8.5.28 Typedef Std_ReturnType

This type can be used as standard API return type which is shared between the RTE and the BSW modules.

Implements: DBASE12002

Type: uint8

3.9 Symbolic Names Disclaimer

All containers having the symbolic name tag set as true in the Autosar schema will generate defines like:

```
#define <Container_Short_Name> <Container_ID>
```

For this reason it is forbidden to duplicate the name of such containers across the MCAL configuration, or to use names that may trigger other compile issues (e.g. match existing #ifdefs arguments).

Chapter 4

Tresos Configuration Plug-in

This chapter describes the Tresos configuration plug-in for the BASE Driver. The most of the parameters are described below.

4.1 Configuration elements of Base

Included forms :

- [Form CommonPublishedInformation](#)

4.2 Form CommonPublishedInformation

Common container, aggregated by all modules. It contains published information about vendor and versions.

| Published Information | |
|----------------------------------|-------|
| CommonPublishedInformation | |
| Name | Value |
| AUTOSAR Major Version | 4 |
| AUTOSAR Minor Version | 3 |
| AUTOSAR Release Revision Version | 1 |
| Module Id | 0 |
| Software Major Version | 1 |
| Software Minor Version | 0 |
| Software Patch Version | 1 |
| Vendor Api Infix | |
| Vendor Id | 43 |

Figure 4-1. Tresos Plugin snapshot for CommonPublishedInformation form.

4.2.1 ArReleaseMajorVersion (CommonPublishedInformation)

Major version number of AUTOSAR specification on which the appropriate implementation is based on.

Table 4-1. Attribute ArReleaseMajorVersion (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|---|
| Label | AUTOSAR Major Version |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | 4 |
| Invalid | Range <div> <div>>=4</div> <div><=4</div> </div> |

4.2.2 ArReleaseMinorVersion (CommonPublishedInformation)

Minor version number of AUTOSAR specification on which the appropriate implementation is based on.

Table 4-2. Attribute ArReleaseMinorVersion (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|---|
| Label | AUTOSAR Minor Version |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | 3 |
| Invalid | Range <div> <div>>=3</div> <div><=3</div> </div> |

4.2.3 ArReleaseRevisionVersion (CommonPublishedInformation)

Revision version number of AUTOSAR specification on which the appropriate implementation is based on.

Table 4-3. Attribute ArReleaseRevisionVersion (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|----------------------------------|
| Label | AUTOSAR Release Revision Version |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | 1 |
| Invalid | Range >=1 <=1 |

4.2.4 ModuleId (CommonPublishedInformation)

Module ID of this module from Module List.

Table 4-4. Attribute ModuleId (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|---------------------|
| Label | Module Id |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | 0 |
| Invalid | Range >=0 <=0 |

4.2.5 SwMajorVersion (CommonPublishedInformation)

Major version number of the vendor specific implementation of the module. The numbering is vendor specific.

Table 4-5. Attribute SwMajorVersion (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|------------------------|
| Label | Software Major Version |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |

Table continues on the next page...

Table 4-5. Attribute SwMajorVersion (CommonPublishedInformation) detailed description (continued)

| Property | Value |
|----------|---------------------|
| Default | 1 |
| Invalid | Range >=1 <=1 |

4.2.6 SwMinorVersion (CommonPublishedInformation)

Minor version number of the vendor specific implementation of the module. The numbering is vendor specific.

Table 4-6. Attribute SwMinorVersion (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|------------------------|
| Label | Software Minor Version |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | 0 |
| Invalid | Range >=0 <=0 |

4.2.7 SwPatchVersion (CommonPublishedInformation)

Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific.

Table 4-7. Attribute SwPatchVersion (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|------------------------|
| Label | Software Patch Version |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | 1 |
| Invalid | Range >=1 <=1 |

4.2.8 VendorApiInfix (CommonPublishedInformation)

In driver modules which can be instantiated several times on a single ECU, BSW00347 requires that the name of APIs is extended by the VendorId and a vendor specific name. This parameter is used to specify the vendor specific name. In total, the implementation specific name is generated as follows:

<ModuleName>_<VendorId>_<VendorApiInfix><Api name from SWS>. E.g. assuming that the VendorId of the implementor is 123 and the implementer chose a VendorApiInfix of "v11r456" a api name Can_Write defined in the SWS will translate to Can_123_v11r456Write. This parameter is mandatory for all modules with upper multiplicity > 1. It shall not be used for modules with upper multiplicity =1.

Table 4-8. Attribute VendorApiInfix (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|------------------|
| Label | Vendor Api Infix |
| Type | STRING_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | |
| Enable | false |

4.2.9 VendorId (CommonPublishedInformation)

Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list.

Table 4-9. Attribute VendorId (CommonPublishedInformation) detailed description

| Property | Value |
|---------------|-----------------------|
| Label | Vendor Id |
| Type | INTEGER_LABEL |
| Origin | Custom |
| Symbolic Name | false |
| Default | 43 |
| Invalid | Range >=43 <=43 |

How to Reach Us:**Home Page:**nxp.com**Web Support:**nxp.com/support

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

While NXP has implemented advanced security features, all products may be subject to unidentified vulnerabilities. Customers are responsible for the design and operation of their applications and products to reduce the effect of these vulnerabilities on customer's applications and products, and NXP accepts no liability for any vulnerability that is discovered. Customers should implement appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, AltiVec, C-5, CodeTEST, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, and UMEMS are trademarks of NXP B.V. All other product or service names are the property of their respective owners. AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamIQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-ME, ULINK-PLUS, ULINKpro, µVision, Versatile are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2019 NXP B.V.

Document Number UM2BASEASR4.3 Rev0001R1.0.1
Revision 1.0